

HP Photosmart 8700 series User's Guide

English



Copyrights and trademarks

© Copyright 2005 Hewlett-Packard Development Company, L.P.

The information contained herein is subject to change without notice. Reproduction, adaptation or translation without prior written permission is prohibited, except as allowed under the copyright laws.

Notice

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

The Hewlett-Packard Development Company, L.P. shall not be liable for incidental or consequential damages in connection with, or arising out of the furnishing, performance, or use of this document and the program material which it describes.

Trademarks

HP, the HP logo, and Photosmart are property of Hewlett-Packard Development Company, L.P.

The Secure Digital logo is a trademark of the SD Association.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

CompactFlash, CF, and the CF logo are trademarks of the CompactFlash Association (CFA).

Memory Stick, Memory Stick Duo, Memory Stick PRO, and Memory Stick PRO Duo are trademarks or registered trademarks of Sony Corporation.

MultiMediaCard is a trademark of Infineon Technologies AG of Germany, and is licensed to the MMCA (MultiMediaCard Association).

Microdrive is a trademark of Hitachi Global Storage Technologies.

xD-Picture Card is a trademark of Fuji Photo Film Co., Ltd., Toshiba Corporation, and Olympus Optical Co., Ltd.

Mac, the Mac logo, and Macintosh are registered trademarks of Apple Computer, Inc.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc.

and any use of such marks by Hewlett-Packard Company is under license.

PictBridge and the PictBridge logo are trademarks of the Camera & Imaging Products Association (CIPA).

Other brands and their products are trademarks or registered trademarks of their respective holders.

The embedded software in the printer is based in part on the work of the Independent JPEG Group.

The copyrights to certain photos within this document are retained by the original owners.

Regulatory model identification number VCVRA-0402

For regulatory identification purposes, the product is assigned a Regulatory Model Number. The Regulatory Model Number for the product is VCVRA-0402. This regulatory number should not be confused with the marketing name (HP Photosmart 8700 series printer) or product number (Q5745A).

Safety information

Always follow basic safety precautions when using this product to reduce risk of injury from fire or electric shock.



Warning To prevent fire or shock hazard, do not expose this product to rain or any type of moisture.

- Read and understand all instructions in the setup instructions that came in the box with the printer.
- Use only a grounded electrical outlet when connecting the unit to a power source. If you do not know whether the outlet is grounded, check with a qualified electrician.
- Observe all warnings and instructions marked on the product.
- Unplug this product from wall outlets before cleaning.
- Do not install or use this product near water or when you are wet.
- Install the product securely on a stable surface.

- Install the product in a protected location where no one can step on or trip over the power cord, and where the power cord will not be damaged.
- If the product does not operate normally, see the troubleshooting information in the onscreen HP Photosmart Printer Help.
- There are no operator serviceable parts inside. Refer servicing to qualified service personnel.
- Use in a well-ventilated area.

Environmental statements

Hewlett-Packard Company is committed to providing quality products in an environmentally sound manner.

Protecting the environment

This printer has been designed with several attributes to minimize impact on our environment. For more information, go to HP's Commitment to the Environment web site at www.hp.com/hpinfo/globalcitizenship/environment/.

Ozone production

This product generates no appreciable ozone gas (O₃).

Paper use

This product is suited for the use of recycled paper according to DIN 19309.

Plastics

Plastic parts over 24 grams (0.88 ounces) are marked according to international standards that enhance the ability to identify plastics for recycling purposes at the end of the printer life.

Material safety data sheets

Material Safety Data Sheets (MSDS) can be obtained from the HP web site at www.hp.com/go/msds. Customers without Internet access should contact HP Customer Care.

Recycling program

HP offers an increasing number of product return and recycling programs in many countries, and partners with some of the largest electronics recycling centers throughout the world. HP conserves resources by

reselling some of its most popular products.

This HP product contains lead in the solder, which may require special handling at the end of its life.

Important recycling information for our customers in the European Union:

To preserve the environment, this product must be recycled after its useful life as required by law. The symbol below indicates that this product may not be disposed in the general trash. Please return the product for proper recovery/disposal to the authorized collection location nearest to you. For more information regarding return and recycling of HP products generally, please visit: www.hp.com/hpinfo/globalcitizenship/environment/recycle/index.html.



Contents

1	Welcome	3
	Finding more information.....	4
	Printer parts.....	4
	Printer menu.....	7
2	Getting ready to print	9
	Loading paper.....	9
	Choosing the right paper.....	9
	Using specialty papers.....	10
	Loading your paper.....	11
	Inserting print cartridges.....	13
3	Basic printing from a computer	17
4	Using color management	19
	Using printer-based color management.....	19
	Using application-based color management.....	22
5	Exploring creative projects	25
	The large-format templates.....	25
	The HP Image Zone.....	26
	Printing borderless photos from a computer.....	27
6	Printing photos without a computer	29
	Connecting to other devices.....	29
	Printing photos from a memory card.....	30
	Inserting memory cards.....	30
	Supported file formats.....	30
	Inserting a memory card.....	31
	Saving photos to a computer from a memory card.....	32
	Removing a memory card.....	33
	Deciding which photos to print.....	33
	Selecting a photo layout.....	33
	Selecting photos to print.....	36
	Improving photo quality.....	37
	Doing common printing tasks from a memory card.....	37
	Printing photos from a digital camera.....	39
	Using a PictBridge camera.....	39
	Using a Bluetooth camera.....	39
	Printing from other Bluetooth devices.....	40
7	Care and maintenance	41
	Cleaning and maintaining the printer.....	41
	Cleaning the outside of the printer.....	41
	Automatically cleaning the print cartridges.....	41
	Manually cleaning the print cartridge contacts.....	42
	Printing a test page.....	42
	Aligning the print cartridges.....	43
	Printing a sample page.....	43
	Updating the software.....	43
	Storing the printer.....	44

Maintaining the supplies.....	44
Storing photo paper.....	45
Handling photo paper.....	45
Storing the print cartridges.....	45
8 Troubleshooting.....	47
Printer software installation problems.....	47
Printer hardware problems.....	48
Printing problems.....	50
Error messages.....	54
Paper errors.....	54
Print cartridge errors.....	55
Memory card errors.....	57
Computer printing errors.....	60
Network errors.....	60
9 HP Customer Care.....	61
HP Customer Care by phone.....	61
Placing a call.....	64
Return to HP repair service (North America only).....	64
Additional warranty options.....	64
a Networking.....	65
Networking basics (Windows and Macintosh).....	65
Internet connection.....	66
Recommended network configurations.....	66
Ethernet network without Internet access.....	66
Ethernet network with Internet access by dial-up modem.....	66
Ethernet network with broadband Internet access provided by a router.....	66
Connecting the printer to the network.....	66
Installing the printer software on a Windows computer.....	67
Installing the printer software on a Macintosh.....	69
Using the embedded web server.....	70
Printing a network configuration page.....	70
b Specifications.....	71
System requirements.....	71
Printer specifications.....	71
c HP Warranty.....	75
Index.....	77

1 Welcome

Thank you for purchasing an HP Photosmart 8700 series printer! With this new photo printer, you can print professional color and black-and-white photos to sell or display for generations.

This guide primarily provides details about specific printing tasks, including when printing from a computer. For more information about connecting the printer to a computer or printing from a computer, install the printer software and view the onscreen HP Photosmart Printer Help. For information about installing the software, see the setup instructions that came in the box with the printer.

The HP Photosmart 8700 series has features that appeal to serious professional and advanced amateur photographers as well as to creative home users:

Professional and advanced amateur photographers (Digital photography, fine arts)	Creative home users (Scrapbooking, arts and crafts, creative projects)
<ul style="list-style-type: none">• Turn the color management features of the printer on or off• Use color management to ensure that what you see on the computer screen matches the photos printed on the HP Photosmart• Use the color management features in concert with professional software such as Adobe® Photoshop® to produce high-quality, professional prints <p>For more information, see Using color management.</p>	<ul style="list-style-type: none">• Print borderless photos from the printer's control panel or from a computer• Use the HP Image Zone software for creative projects• Use special large-format templates for use in scrapbooking <p>For more information, see Exploring creative projects.</p>

The printer comes with the following documentation:


- **Quick Start booklet** or **Setup Guide**: The HP Photosmart 8700 series printer comes with setup instructions that explain how to set up the printer and install the printer software. Which document you receive with the printer varies by country/region.
- **User's Guide**: The *HP Photosmart 8700 series User's Guide* is the book you are reading. This book describes the basic features of the printer, explains how to use the printer without connecting a computer, and contains troubleshooting information.
- **HP Photosmart Printer Help**: The onscreen HP Photosmart Printer Help describes how to use the printer with a computer and contains software troubleshooting information.

Finding more information

After you have installed the HP Photosmart printer software on a computer, you can view the onscreen HP Photosmart Printer Help:


- **Windows PC:** From the **Start** menu, select **Programs** (in Windows XP, select **All Programs**) > **HP > Photosmart 320, 370, 7400, 8100, 8400, 8700 series > Photosmart Help**.
- **Macintosh:** Select **Help > Mac Help** in the Finder, then select **Library > HP Photosmart Printer Help**.

Printer parts




Front of printer

1	Out tray: Lift to access the Main tray.
2	Main tray: Place photo paper, plain paper, transparencies, envelopes, or other media in this tray for printing.
3	Top cover: Lift this cover to access the print cartridges and the print cartridge storage area, and to clear paper jams.
4	Control panel access door: Push down and release to access the printer control panel and screen. The panel pops up.
5	Cancel: Press this button to deselect photos, to exit a menu, or to stop an action you have requested. There is also a Cancel button on the printer control panel.
6	On: Press this button to turn on the printer or put it into power save mode.
7	Camera port: Use this port to connect a PictBridge™ digital camera to the printer, or to insert the optional HP Bluetooth® wireless printer adapter.
8	Memory card slots: Insert memory cards here.




Back of printer

- | | |
|---|--|
| 1 | Ethernet port: Use this port to connect the printer to a network. |
| 2 | USB port: Use this port to connect the printer to a computer. |
| 3 | Power cord connection: Use this port to connect the power cord included with the printer. |
| 4 | Rear access door: Remove this door to clear paper jams. |
| 5 | Rear feed slot: Use this slot for supported stiff stock media. Printing through this slot is possible only from the computer. The rear feed slot does not support photo board or banner printing. Be sure to load paper straight into the slot and guide it in so the paper does not skew. For more information, see Loading your paper . |
| 6 | Rear feed slot paper-width guide: Adjust this guide to fit close to the edge of the paper in the rear paper slot. |




Paper trays

- | | |
|---|--|
| 1 | Out tray: Lift to access the Main tray. |
| 2 | Front feed slot: Place paper here when you want to bypass the Main tray for a single print job. For photo media, have the emulsion (glossy) side down. Ideal for envelopes. |
| 3 | Front feed slot paper-width guide: Adjust this guide to fit close to the edge of the paper in the front feed slot. |
| 4 | Out tray extender: Pull it towards you to extend the Out tray to catch the printed paper as it is ejected from the printer. |
| 5 | Main tray: Place photo paper, plain paper, transparencies, envelopes, or other media in this tray for printing. For photo media, have the emulsion (glossy) side down. |
| 6 | Paper-length guide: Extend and adjust this guide to fit close to the end of small media in the Main tray. |
| 7 | Main tray release: Press and pull toward you to release and extend the Main tray. This lets you load large media that could not normally fit in the tray. |
| 8 | Main tray paper-width guide: Adjust this guide to fit close to the edge of the paper in the Main tray. This helps prevent paper skew. |




Control panel

1	Index page: Press to print an index page (contact sheet) of photos on a memory card.
2	Layout: Press to select the print layout for your photos.
3	Menu: Press to view the printer menu.
4	Navigation arrows: Press to navigate through menu options or photo numbers.
5	<input checked="" type="checkbox"/> : Press to select a photo number or menu option.
6	Print: Press to print selected photos from the inserted memory card.
7	Cancel: Press to deselect photos, to exit a menu, or to stop an action you have requested. There is also a Cancel button on the front left of the printer to the right of the On button.
8	Printer screen: Use this screen to view menus, page layout, ink status, and messages.



Printer screen

1	Messaging area: Displays printer messages and menus.
2	Animations: Displays printer activity animations.
3	Ink level: Displays the current ink level for each cartridge in the printer.
4	Selected photos: Displays the index numbers of photos selected from the printer control panel for printing.
5	Layout/print job status: Displays the current photo layout, number of pages to print, and layout slots being used.



Indicator lights

1	On light: Solid blue if the printer is on, otherwise off.
2	Memory card light: Solid green if a memory card is correctly inserted, flashing green if the printer is accessing a memory card, flashing red to indicate memory card errors, and off if no memory card is inserted or more than one card is inserted.
3	Status light: Flashing green if the printer is busy (non-printing activity), flashing red if there is an error or if some user action is required, solid amber if a nonrecoverable error has occurred.
4	Print light: Solid blue if the printer is ready to print, pulsing blue if the printer is busy printing.

Printer menu

Press **Menu** to access the printer menu.

To navigate the printer menu:

- Press ◀ or ▶ to scroll through the menus or options displayed on the printer screen.
- Any menu with a triangle next to it has submenus or options. Press ▾ to display the submenus or options.
- Press **Cancel** to exit the current menu.

The print menu structure

- **Print all:** Select to print all the photos on the memory card inserted in the printer.
- **Date/time stamp option**
 - **Date/time**
 - **Date only**
 - **Off** (default)

- **SmartFocus:** Turn on to focus images for clearer, sharper detail.
 - On
 - Off (default)
- **Digital Flash:** Turn on to improve photos with poor lighting and contrast.
 - On
 - Off (default)
- **Change the print quality**
 - Normal
 - Best (default)

Normal uses less ink than Best, and applies only to the current print job. The setting then automatically resets to Best.
- **Print a sample page:** Select to print a sample page useful for checking the print quality of the printer.
- **Print a test page:** Select to print a test page containing information about the printer that can help in troubleshooting problems.
- **Network settings**
 - **Display network IP address:** Select to display the IP address of the printer.
 - **Print network settings page:** Select to print a network configuration page that you can use for troubleshooting network connections or for the initial network setup.
 - **Reset network settings:** Select to reset the network settings to the factory defaults.
 - **Reset Bluetooth settings:** Select to reset the Bluetooth settings to the factory defaults.
- **Clean the print cartridges:** Select to clean the print cartridges. After the cleaning finishes, the printer prints a test page. You have the option to clean the cartridges again if the test page shows that they are still not clean.
- **Calibrate the printer:** Select to calibrate the printer.
- **Select paper settings**
 - **Auto-detect** (default): Lets the printer auto-detect paper type and width.
 - **Manually set:** Lets the user manually select paper type and width.
- **Select language:** Select to indicate the language you want used on the printer display.
- **Reset all menu settings:** Restores factory settings for all menu items except **Select language**.

2 Getting ready to print

This section includes information on the following:

- Loading paper
- Inserting print cartridges

Loading paper

Learn how to choose the right paper for your print job and how to load it into the correct tray for printing.

Choosing the right paper

For a list of available HP inkjet paper, or to purchase supplies, go to:

- www.hpshopping.com (U.S.)
- www.hp.com/go/supplies (Europe)
- www.hp.com/jp/supply_inkjet (Japan)
- www.hp.com/paper (Asia/Pacific)

To get the best and longest-lasting results from the printer, choose from these high-quality HP photo papers.

To print	Use this paper
High-quality, long-lasting prints and enlargements	HP Premium Plus photo paper
Medium to high resolution images— instant-dry, water resistant casual and business photos	HP Premium photo paper
Casual photos from e-mail and the web	HP Advanced Photo paper HP Photo paper HP Everyday photo paper
Text documents, draft versions, test and alignment pages	HP Premium inkjet paper



Note HP designs its photo papers to resist fading so your photos remain vibrant for years to come. For more detailed information on this subject, visit the HP web site. Go to www.hp.com/support, select your country/region and your language, then type HP Photosmart 8700 in the product/name search box. Press ENTER and then select the HP Photosmart 8700 series printer. In the **Question or keywords** search box enter `lightfastness` or `permanence` and then press ENTER. Click the topic you want to review.

To keep your paper in good condition for printing:

- Store the photo paper in its original packaging or in a resealable plastic bag.
- Keep the paper flat in a cool, dry place. If the corners curl, place the paper in a plastic bag and gently bend it in the opposite direction until it lies flat.
- Hold photo paper by the edges to avoid smears.

Using specialty papers



Note HP recommends using the Main tray for these specialty medias, but the rear feed slot can be used for stiffer medias. Check the HP web site at www.hp.com/support for more information about printing with fine art media.

Your HP printer also prints on a variety of non-HP specialty media. Experiment with some of the types listed here for special effects:

- Smooth Fine Art Paper
- William Turner Textured Surface
- German Etching
- Photo Rag
- Photo Rag Smooth Surface
- Fine Art Water Color
- Soft Fine Art Water Color
- Photo Rag Duo
- Soft Suede
- Gallery Gloss

Some media types may not be available in all countries/regions. Check with your local media provider.



Warning Do not use photo board as it can damage the printer.

Loading your paper

The HP Photosmart 8700 series supports the following paper sizes:




Supported paper sizes

When printing from a computer	When printing from the printer control panel
<ul style="list-style-type: none">• From 76 x 127 mm (3 x 5 inches) up to 324 x 476 mm (13 x 19 inches)• 216 mm (8.5 inch-wide) banner paper	<ul style="list-style-type: none">• 3.5 x 5 inches• 4 x 6 inches• 5 x 7 inches• 8 x 10 inches• 8.5 x 11 inches• 11 x 14 inches• 13 x 19 inches• 10 x 15 cm (with or without tab)• 13 x 18 cm• A3• A4• A6• L• 2L• Hagaki

Paper loading tips:

- Before loading paper, slide out the paper-width and length guides to make room for the paper. After loading paper, adjust the guides to fit close to the edges of the paper without bending the paper.
- Load only one type and size of paper at a time in the same tray.
- After loading paper, extend the Out tray extension to hold your printed pages. This prevents printed pages from dropping off of the Out tray.

Use the directions in the following table to load the most commonly used paper sizes into the printer.

Paper type	How to load	Tray to load								
Any supported photo or plain paper media	<ol style="list-style-type: none"> 1. Raise the Out tray (4). 2. Load paper print-side down. Press the Main tray release (2) and pull out the tray if needed for easier access. Check that the stack of paper is no higher than the top of the paper-length guide (3). 3. Adjust the Main tray paper-width guide (1), as needed. 4. Lower the Out tray (4). 	 <p>Main tray</p> <table border="1"> <tr> <td>1</td> <td>Main tray paper-width guide</td> </tr> <tr> <td>2</td> <td>Main tray release</td> </tr> <tr> <td>3</td> <td>Paper-length guide</td> </tr> <tr> <td>4</td> <td>Out tray</td> </tr> </table>	1	Main tray paper-width guide	2	Main tray release	3	Paper-length guide	4	Out tray
1	Main tray paper-width guide									
2	Main tray release									
3	Paper-length guide									
4	Out tray									
Any supported photo or plain paper media—ideal for envelopes	<ol style="list-style-type: none"> 1. Load paper print-side down into the front feed slot (1). If you are using tabbed paper, insert the paper so the tab feeds in last. 2. Adjust the front feed slot paper-width guide (3), as needed. 	 <p>Front feed slot</p> <table border="1"> <tr> <td>1</td> <td>Front feed slot</td> </tr> <tr> <td>2</td> <td>Out tray</td> </tr> <tr> <td>3</td> <td>Front feed slot paper-width guide</td> </tr> </table>	1	Front feed slot	2	Out tray	3	Front feed slot paper-width guide		
1	Front feed slot									
2	Out tray									
3	Front feed slot paper-width guide									
Stiff media, such as cardstock (Not supported : photo board and banner printing)	<ol style="list-style-type: none"> 1. Load paper print-side up into the rear feed slot (1). 2. Adjust the rear feed slot paper-width guide (2), as needed. <p>Tips</p> <ul style="list-style-type: none"> • To avoid jams and paper skewing, load one sheet at a time straight into the slot • Use only stiff stock media • Do not use for photo board or banner printing • Only use this slot when printing from a computer. Not for use when printing from the printer's control panel. 	 <p>Rear feed slot</p> <table border="1"> <tr> <td>1</td> <td>Rear feed slot</td> </tr> <tr> <td>2</td> <td>Rear feed slot paper-width guide</td> </tr> </table>	1	Rear feed slot	2	Rear feed slot paper-width guide				
1	Rear feed slot									
2	Rear feed slot paper-width guide									

Inserting print cartridges













The HP Photosmart 8700 series printer can print color and black-and-white photos, as well as documents. HP provides different types of print cartridges so you can choose the best cartridges for your project. The HP Photosmart 8700 series supports the HP Blue Photo print cartridge for color prints with richer blues and better color transitions.



Note The cartridge numbers you can use with this printer appear on the back cover of the printed *HP Photosmart 8700 series User's Guide*. If you have already used the printer several times, you can find the cartridge numbers in the HP Photosmart 8700 series Toolbox. **Windows users:** Right-click the small printer icon on the far right of the Windows taskbar, and select **Open HP Photosmart 8700 series Toolbox**. Click the **Estimated Ink Level** tab and then click the **Print Cartridge Ordering Information** button. **Macintosh users:** Click **HP Image Zone** in the Dock. Choose **Maintain Printer** from the **Settings** pop-up menu. Click **Utilities**, and then choose **Supplies** from the pop-up menu.

For optimum printing results, HP recommends using only HP print cartridges. Inserting a cartridge that is not in this table may invalidate the printer warranty.

Use the correct print cartridges

To print...	Insert this print cartridge in the left stall	Insert this print cartridge in the middle stall	Insert this print cartridge in the right stall
Full-color photos	 HP Blue Photo	 HP Tri-color	 HP Gray Photo
Black-and-white photos	 HP Blue Photo	 HP Tri-color	 HP Gray Photo
Sepia or antique photos	 HP Photo	 HP Tri-color	 HP Gray Photo
Text and colored line drawings	 HP Photo	 HP Tri-color	 HP Black




Caution Check that you are using the correct print cartridges. Also, note that HP does not recommend modifying or refilling HP cartridges. Damage that

results from modifying or refilling HP cartridges is not covered by the HP warranty.

For best print quality, HP recommends that you install all retail print cartridges before the date stamped on the box.



Insert or replace the print cartridges



Remove the pink tape



Do not touch here



Prepare the printer and cartridges

1. Make sure you have removed the cardboard from inside the printer and the power is on.
2. Lift the main cover of the printer.
3. Remove the bright pink tape from all cartridges.

Do not touch the ink nozzles or the copper-colored contacts, and do not re-tape the cartridges.

Insert the cartridges


1. If you are replacing a cartridge, push down and pull outward on the cartridge stall cover to open it and then pull the cartridge out.
2. Match the symbol on the cartridge label to the correct stall.
3. Hold the cartridge with the label on top and slide it at a slight upward angle into the stall so the copper-colored contacts go in first. Push the cartridge until it snaps into place.
4. Close the cartridge stall cover.
5. Repeat the previous steps to install the other cartridges, if necessary.
6. When you are finished installing cartridges, close the main cover.

You must install all three cartridges in order for the printer to work as intended.

Tip Ink-backup printing mode lets you keep printing even if one of the cartridges fails or runs out of ink. Remove the cartridge and close the main cover to enter ink-backup printing mode. The printer continues to print, but at a slower speed and with inferior print quality. A message reminds you that the printer is in ink-backup printing mode. Replace the cartridge as soon as possible.

The idle screen of the printer displays three icons showing the approximate ink level for each

Insert or replace the print cartridges (continued)

	<p>cartridge (100%, 75%, 50%, 25%, and nearly empty). Ink-level icons do not appear if any of the installed cartridges are not genuine HP cartridges.</p>
	<p>Each time you install or replace a print cartridge, a message prompts you to print an alignment page. This ensures high-quality prints.</p> <p>Align the cartridges</p> <ol style="list-style-type: none">1. Load paper in the Main tray.2. Follow the onscreen instructions to complete the cartridge alignment. <p>See Aligning the print cartridges.</p>

When you are not using a print cartridge



Whenever you remove a print cartridge from the printer, store it in a print cartridge protector. The cartridge protector keeps the ink from drying out. Storing the cartridge improperly can cause the cartridge to malfunction. A print cartridge protector comes in the box with the printer.

- To insert a cartridge into the cartridge protector, slide the cartridge into the protector at a slight angle and snap it securely into place.

Once you have inserted a cartridge into the cartridge protector, place it in the storage area located under the top cover.

3 Basic printing from a computer

You'll need to save your photos to the computer before you can use them with the printer driver software that lets you print photos from a computer. For more information, see [Saving photos to a computer from a memory card](#).

For information on installing the printer driver software, see the setup instructions that came in the box with the printer.

Be sure to download the latest printer software update every couple of months to ensure you have the latest features and improvements. For more information, see [Updating the software](#).

The print driver software is the interface that appears whenever you print. This section describes the print quality settings available for the HP Photosmart 8700 series in the print driver and how to select the most appropriate setting for the current print job.



Note The onscreen HP Photosmart Printer Help provides more information on the many print settings available when you print from a computer. To learn how to access the onscreen help, see [Finding more information](#).

To set print quality settings

1. Open the **Print** dialog box.

If you are using a Windows computer

- Click the **Paper/Quality** tab in the **Print** dialog box (Windows 2000/XP) or click **Properties** in the **Print** dialog box and then click the **Paper/Quality** tab (Windows 98).

If you are using a Macintosh

- a. Choose **Paper Type/Quality** in the **Copies & Pages** pop-up menu.
 - b. Click the **Paper** tab.
2. Select a setting from the **Print quality** (Windows) or **Quality** (Macintosh) pop-up menu:
 - **Fast Draft:** This 300 dpi setting provides the fastest speed and the most economical use of ink. Use it for proof copies of your photo or creative project. Print outs appear light.
 - **Fast Normal:** This 300 dpi setting provides the fastest speed for good quality prints. Use it for proof copies of your photos.
 - **Normal:** This 600 dpi setting provides the best balance between print quality and speed. Use it for your final prints.
 - **Best:** This 600 dpi setting provides the best balance between high quality and speed, and uses PhotoREt color enhancement. Use it for high quality prints.
 - **Maximum dpi:** This 4800 x 1200 dpi setting provides the highest quality prints possible, but requires long print times and a large amount of free disk space.

For more information on the HP print driver, do the following:

- **Windows:** From the **Start** menu, select **Programs** (in Windows XP, select **All Programs**) > **HP** > **Photosmart 320, 370, 7400, 8100, 8400, 8700 series** > **Photosmart Help**, then click **HP Photosmart Printer Help**. In the print dialog itself, right-click any option and click the **What's This?** box to learn more about that option.
- **Macintosh:** Select **Help** > **Mac Help** in the Finder, then select **Library** > **HP Photosmart Printer Help**.



Note For more information on color settings in the print driver, see [Using color management](#).

4 Using color management



Note This section provides some basic information about using color management with the HP Photosmart 8700 series. For more detailed information on this complex subject, visit the HP web site. Go to www.hp.com/support, select your country/region and your language, then type HP Photosmart 8700 in the product/name search box. Press ENTER and then select the HP Photosmart 8700 series printer. In the **Question or keywords** search box enter `color management` and then press ENTER. Click the topic you want to review.

In many cases, the default printer-based color management of the HP Photosmart 8700 series delivers good results, but if you need to have greater control over color management in your workflow, see [Using application-based color management](#).

Color management allows the colors in images or graphics to pass accurately between applications, operating systems, and imaging devices, such as cameras, scanners, monitors, and printers.

Digital cameras, scanners, and monitors use the RGB¹ color model, while commercial printers use the CMYK² color model. The differences between the two color models can cause printed photos to look markedly different from what you see on the monitor.



Warning It's possible to have color management features turned on both in the printer driver and in an application such as Adobe® Photoshop.® This double correction produces unsatisfactory results. Use either printer-based or application-based color management, but not both at the same time.



Note Color management is a complex subject and a detailed discussion is beyond the scope of this user guide. The HP Photosmart 8700 series User Guide provides a couple of typical examples, but for more information, see the documentation that came with your third-party image-editing software.

Using printer-based color management

The HP Photosmart 8700 series offers built-in automatic color management that's easy to configure. Printer-based color management produces attractive results and should be adequate for many users.

For information on a more advanced, professional-level form of color management, see [Using application-based color management](#).

-
- 1 The RGB color model is so-named because it creates colors by mixing red, green, and blue colored light. Technologies that rely on light (monitors, scanners, or digital cameras) use this model.
 - 2 The CMYK color model used in the printing industry is based on the light-absorbing qualities of ink printed on paper. CMYK stands for cyan, magenta, yellow, and black, the colors used in four-color process printing.

Printer driver color mode settings

Setting	When to use it
<p>Colorsmart/sRGB</p> <p>Most imaging devices, such as monitors, cameras, and scanners, normally use sRGB. The printer is also set to Colorsmart/sRGB by default. When set to this mode, the printer converts colors from sRGB to the printer's ink colors.</p> <p>Tip You should not have the printer set to this mode if you are also using ICC profiles and your application to manage color. This can result in decreased color fidelity since the colors are converted twice—first by the application and then by the printer.</p>	<ul style="list-style-type: none"> • When your digital camera, scanner, or image editing software is set to sRGB • For the easiest, most basic form of color management • When you are not using ICC profiles
<p>Adobe RGB or Adobe RGB (1998)</p> <p>You can set some imaging devices to Adobe RGB, an enhanced version of the sRGB color space, developed for high-fidelity digital photography. When set to this mode, the printer converts colors from Adobe RGB to the printer's ink colors.</p> <p>Tip You should not have the printer set to this mode if you are also using ICC profiles and your application to manage color. This can result in decreased color fidelity since the colors are converted twice—first by the application and then by the printer.</p>	<ul style="list-style-type: none"> • When your digital camera, scanner, or image editing software is set to Adobe RGB • For high-quality digital photography • When you are not using ICC profiles
<p>Managed by Application (Windows)</p> <p>Application Managed Colors (Mac OS)</p> <p>When set to this mode, the printer does not do any color management.</p> <p>Application-based color management lets image editing software handle color conversions from image color space to the printer ink colors. The conversion takes place in the image-editing software. Using application-based color management involves changing settings</p>	<ul style="list-style-type: none"> • When you want to use ICC profiles • When you want to use the color management features of imaging editing software, such as Adobe Photoshop • For the greatest level of control over color quality

Setting	When to use it
both in the printer driver and in your applications, and requires ICC profiles for all your devices. For more information, see Using application-based color management .	

In order to print using the color management features built into the HP Photosmart 8700 series, you have to change settings in the printer driver software and in the image editing software. Here is one example of a typical print job using printer-based color management with Adobe Photoshop (version 7 or CS).

To print using printer-based color management

1. Open the file you want to print in Adobe Photoshop.
2. Select **File > Print with Preview** in Adobe Photoshop. Make sure **Show More Options** is selected in the **Print with Preview** dialog box, then select **Color Management** from the pop-up menu.
3. In the **Print Space** area of the **Print with Preview** dialog box, select the same RGB color space setting you intend to use in the print driver (Windows). In most cases this is sRGB or Adobe RGB. On a Macintosh, choose **Printer Color Management** instead.
4. Click **Page Setup** in the **Print with Preview** dialog box, set up the page for the current image, as desired, then click **OK**.
5. Click **Print**.

If you are using a Windows computer

- a. Click **Properties** in the **Print** dialog box.
- b. Click the **Color** tab in the **Properties** dialog box.
- c. Select a color mode from the **Color management** pop-up menu in the **Print** dialog box:
 - Colorsmart/sRGB (default)
 - AdobeRGB

Select the same color mode you selected as an RGB working space in the Adobe Photoshop **Color Settings** dialog box.
- d. Click the **Paper/Quality** tab, select the desired paper type from the **Type is** pop-up menu, then click **OK**.

If you are using a Macintosh

- a. Choose **Paper Type/Quality** in the **Print** dialog box.
 - b. Choose a color mode from the **Color** pop-up menu in the **Print** dialog box:
 - Colorsmart/sRGB
 - AdobeRGB

Select the same color mode you selected as an RGB working space in the Adobe Photoshop **Color Settings** dialog box.
6. Click **OK** in the **Print** dialog box to begin printing.



Tip For best results when printing photos in black and white, make sure you install the HP Gray Photo print cartridge and select the **Print in Grayscale** option in the **Print** dialog box (Windows) or the **Grayscale** option in the **Color** pop-up menu of the **Print** dialog box (Mac OS). For finer control over the conversion of color photos to black and white, use image editing software to control the conversion.

Using application-based color management

Application-based color management offers more sophisticated control than the printer-based form, but also involves greater complexity and more steps.

For information on the printer-based color management built into the HP Photosmart 8700 series, see [Using printer-based color management](#).

Using application-based color management can involve:

- **Using device profiles:** Application-based color management relies on files called ICC³ device profiles. An ICC profile describes a device's color space. The software component of your color management system uses these profiles to convert colors between each device's color space. The HP Photosmart 8700 series **Typical** software installation installs HP ICC profiles automatically for the printer.
- **Calibrating the monitor:** Monitors exhibit a color degradation over time that can interfere with producing professional quality printed photography. As a result, the ICC profile that comes with most new monitors gradually becomes invalid and no longer accurately reflects the color space available on the device. Calibrating the monitor at least once a month to produce a custom ICC profile is the best way to ensure that the color space available on the monitor is accurately defined for your color management system. You can calibrate a monitor visually using system or utility software, such as Adobe Gamma, but this type of calibration does not meet the high-quality standards expected for professional photography. Professionals usually invest in a calibration kit consisting of software and a piece of hardware that captures the current state of the RGB environment on the monitor and saves it as a custom ICC profile. Monitor calibration kits are available from GretagMacBeth, Monaco Systems, and LaCie, as well as other manufacturers.

In order to print using application-based color management features, you have to change settings in the printer driver software and in the image editing software. Here is one example of a typical print job using application-based color management in Adobe Photoshop (version 7 or CS). See the documentation that came with your image-editing software for complete instructions on using the product's color management features.

To print using application-based color management

1. Open the photo you want to print in Adobe Photoshop.
2. Select **File > Print with Preview** in Adobe Photoshop.
3. Make sure **Show More Options** is checked in the **Print with Preview** dialog box, then select **Color Management** from the pop-up menu.

3 International Color Consortium. ICC enables profile-based color management solutions. For more information, see www.color.org.

4. In the **Print Space** area of the **Print with Preview** dialog box, select the appropriate HP Photosmart 8700 series profile for the paper and ink set you are using.
The HP Photosmart printer software installer installed several profiles for you automatically.
5. Select **Perceptual** from the **Intent** pop-up menu. Checking the **Use Black Point Compensation** option is also recommended.
6. Click **Page Setup** in the **Print with Preview** dialog box, set up the page for the current image, as desired, then click **OK**.
7. Click **Print** in the **Print with Preview** dialog box.

If you are using a Windows computer

- a. Click **Properties** in the **Print** dialog box.
- b. Click the **Color** tab in the **Print** dialog box.
- c. Select **Managed by application** from the **Color Management** area of the **Print** dialog box, then click **OK**.
- d. Click the **Paper/Quality** tab, select an appropriate paper type from the **Type Is** pop-up menu, then click **OK**.
- e. Click **OK** in the **Print** dialog box to begin printing.

If you are using a Macintosh

- a. Choose **Paper Type/Quality** in the **Print** dialog box.
 - b. Choose **Application Managed Colors** in the **Color** pop-up menu.
 - c. Select an appropriate paper type from the **Paper** pop-up menu.
8. Click **Print** in the **Print** dialog box.

5 Exploring creative projects

The HP Image Zone software that comes with the printer provides tools that make using photos in creative projects possible, as well as access to HP Instant Share, an online service that makes sharing photos with others easy. For more information on all the features of the HP Image Zone software, see the onscreen HP Photosmart Printer Help. See [Finding more information](#).



Note You must select the **Typical** option when you install the printer software or the HP Image Zone will not be installed.

This section contains information about:

- Using large-format templates in scrapbooking and other projects
- Using the HP Image Zone
- Printing borderless photos from a computer

The large-format templates

Large-format templates consist of a plain white background with fixed picture holders into which you can drag photos. Photos are automatically cropped by the picture holders. You can resize the photos and move them around within the picture holder.

Scrapbookers: be sure to visit the HP Scrapbooking web site at www.hp.com/go/scrapbooking. It's a great place to obtain free art downloads, layout ideas, scrapbooking tips, information about purchasing supplies, other online scrapbooking resources, and more. The site is available in English only.

Template page size	Description
B	Standard U.S./Imperial size. Also known as Ledger or US Legal. 11 x 17 inches. Approximately 279 x 432 mm.
B+	Standard U.S./Imperial size. Also known as Super B. 13 x 19 inches. Approximately 330 x 483 mm.
A3	Standard ISO size. 297 x 420 mm. Approximately 11.7 x 16.5 inches.
A3+	Standard ISO size. Also known as Super A3. 330 x 483 mm. Approximately 13 x 19 inches.
12 x 12 inches	Standard U.S./Imperial size. Also known as Photo 12 x 12. Popular for use in scrapbooking albums. Approximately 305 x 305 mm.

To place photos in a template

1. Select some photos and place them in a large-format template.
You can move a photo around in a template's picture holder.

If you are using a Windows computer

- a. In HP Image Zone on the **Projects** tab, click **Album Pages**.
- b. In the **Work** area, click a page size.
- c. Click a large-format template.
- d. Select photos from the **My Images** tab, then drag each photo from the **Selection Tray** into the desired page holder in the template.

If you are using a Macintosh

- a. Click **HP Image Zone** in the **Dock**.
- b. Click **Services**, then double-click **HP Image Print** in the **HP Image Zone** window.
- c. Select one or more photos, then click **Open**.
You can add additional photos to the **Drawer** later by clicking the + button. If the **Drawer** is not visible, click the **Drawer** button.
- d. Choose **Album Page** in the **Print Style** pop-up menu.
- e. Press the **Select Template** arrows to select a template.
- f. Drag each photo from the **Drawer** into the desired picture holder in the template.
- g. Click **Page Setup** to select a paper size from the **Paper Size** pop-up menu, and then click **OK**.
- h. Click **Print**.

For more information on the best print settings to use for quality printing from a computer, see [Basic printing from a computer](#).

Scrapbookers: add a new level of creativity and energy to your scrapbooking experience with HP Creative Scrapbook Assistant software. The powerful digital tools and hundreds of included high-quality, ready-made theme images in this affordable, innovative software make it fun to plan, create, archive, print, and share your scrapbook elements and pages. It's a new scrapbooking tool that's the perfect complement to the HP Photosmart 8700 series. Learn more about this software at the HP Scrapbooking web site: www.hp.com/go/scrapbooking. The software and web site are in English only. HP Creative Scrapbook Assistant may not be available in all countries/regions.

The HP Image Zone



Note You must select the **Typical** option when you install the printer software or the HP Image Zone will not be installed.

Use the HP Image Zone to get creative with your pictures: edit them, share them, and create fun projects such as greeting cards. To work with photos, you need to transfer them to a computer that you have connected to the printer. Insert a memory card with

photos. Follow the instructions on the computer screen to save them to your computer. For more information, see [Saving photos to a computer from a memory card](#).

The HP Image Zone lets you:

- Use your photos for creative projects, such as scrapbooking albums, greeting cards, and iron-on transfers
- Organize your photos in albums and search through them by keyword and dates (Windows only)
- Edit and enhance your photos by adding text or doing color correction
- Share your photos online through HP Instant Share with family and friends

For more information on the HP Image Zone, explore the onscreen HP Photosmart Printer Help:

- **Windows:** From the **Start** menu, select **Programs** (in Windows XP, select **All Programs**) > **HP** > **Photosmart 320, 370, 7400, 8100, 8400, 8700 series** > **Photosmart Help**, then click **Use the HP Image Zone**.
- **Macintosh:** Select **Help** > **Mac Help** in the Finder, then select **Library** > **HP Image Zone Help**.

Printing borderless photos from a computer

The quickest and easiest way to print a borderless photo from your computer is by using the HP Image Zone. The HP Image Zone is available on your computer if you selected **Typical** during the software installation.



Note You can also do borderless printing from within other imaging software. This section only includes instructions for printing borderless photos from the HP Image Zone.

Printing a borderless photo from Windows

1. Load photo paper in the printer.
2. Open the HP Image Zone, then choose a photo to print.
3. Click **Print**, then in the **HP Print** window click **Quick Print**, if it is not already selected.
4. Make sure the **Borderless sizes only** option is checked, then select the desired size from the **Paper Size** pop-up menu.
5. Enter the number of copies in **Copies of Current Image**.
6. Click **Print**.

Printing a borderless photo from a Macintosh

1. Load photo paper in the printer.
2. Click **HP Image Zone** in the Dock.
3. Double-click **HP Image Print** in the HP Image Zone window.
4. Choose one or more photos to print, then click **Open**.
5. Choose **Photo Print** from the **Print Style** pop-up menu, if it is not already chosen.
6. Choose the HP Photosmart 8700 series printer from the **Printer** pop-up menu.
7. Choose a borderless paper size from the **Paper Size** menu.
8. Make sure the **Print Borderless** option is checked, then click **Print Now**.



6 Printing photos without a computer

The HP Photosmart 8700 series printer lets you select and print photos without even turning on the computer. Once you've set up the printer using the setup instructions that came in the box with the printer, you can print from any of the following:


- Memory card
- PictBridge-compatible digital camera
- Bluetooth device

Connecting to other devices

This printer offers several types of connectivity that do not require a computer, such as memory cards, PictBridge cameras, and devices with Bluetooth wireless technology. Each connection type lets you do different things.

Connection type and what you need	This lets you...
<p>Memory cards</p>  <p>A memory card</p> <p>A compatible digital camera memory card Insert the memory card into the appropriate memory card slot on the front of the printer.</p>	<ul style="list-style-type: none">• Print directly from a memory card to the printer.• Print quick proofs of photos on a memory card directly from the printer control panel.• Save photos from a memory card inserted in the printer to a computer where you can enhance or organize them in the HP Image Zone or other software. For more information, see Saving photos to a computer from a memory card and Printing photos from a memory card.
<p>PictBridge</p>  <p>The PictBridge symbol</p> <p>A PictBridge-compatible digital camera and a USB cable. Connect the camera to the camera port on the front of the printer.</p>	<p>Print directly from a PictBridge-compatible digital camera to the printer.</p> <p>For more information, see Printing photos from a digital camera and the camera documentation.</p>

(continued)

Connection type and what you need	This lets you...
<p>Bluetooth</p>  <p>The HP bt300 Bluetooth® wireless printer adapter (Model: Q3395A)</p> <p>The HP bt300 Bluetooth wireless printer adapter goes into the camera port on the front of the printer and lets you use Bluetooth wireless technology for printing. See the documentation that came with the adapter and the onscreen HP Photosmart Printer Help for instructions.</p>	<p>Print from any device with Bluetooth wireless technology to the printer. For more information, see the documentation that came with the adapter.</p> <p>The adapter is not compatible with the Macintosh.</p>

Printing photos from a memory card

You can print photos from a memory card by inserting the card into the printer and using the printer control panel to select, enhance, and print photos. You can also print camera-selected photos—photos you marked for printing using a digital camera—directly from a memory card.

Printing from a memory card is quick and easy, and does not drain the digital camera batteries. For more information on inserting memory cards, see [Inserting memory cards](#).

Printing from a memory card is easy. This section tells you how to do the following:

- Insert a memory card
- Decide which photos to print
- Select a photo layout
- Select photos
- Improve photo quality
- Print the selected photos

Inserting memory cards

After you have taken pictures with a digital camera, you can remove the memory card from the camera and insert it into the printer to print your photos or save them to a computer. The printer can read the following types of memory cards: CompactFlash™, Memory Sticks, Microdrive™, MultiMediaCard™, Secure Digital™, and xD-Picture Card™.




Caution Using any other type of memory card may damage the memory card and the printer.

To learn about other ways of transferring photos from a digital camera to the printer, see [Connecting to other devices](#).

Supported file formats

The printer can recognize and print the following file formats directly from the memory card: JPEG and uncompressed TIFF. If a digital camera saves photos and video clips in other file formats, save the files to a computer and print them using a software application. For more information, see the onscreen HP Photosmart Printer Help.

Inserting a memory card



Memory card slots

1	CompactFlash I and II, Microdrive
2	Secure Digital, MultiMediaCard (MMC)
3	Memory Sticks
4	xD-Picture Card

Find the memory card in the following table and use the instructions to insert the card into the printer.

Guidelines:

- Insert only one memory card at a time.
- Gently push the memory card into the printer until it stops. The memory card does not insert all the way into the printer; do not try to force it.









Caution Inserting the memory card any other way may damage the card and the printer.

When the memory card is inserted correctly, the Memory Card light flashes and then remains solid green.



Caution Do not pull out a memory card while the Memory Card light is flashing. For more information, see [Removing a memory card](#).

Memory card	How to insert the memory card
 <p data-bbox="127 317 293 343">CompactFlash</p>	<ul data-bbox="410 175 1103 256" style="list-style-type: none"> • Front label faces up, and if the label has an arrow, the arrow points toward the printer • Edge with metal pinholes goes into the printer first
 <p data-bbox="127 557 284 583">Memory Stick</p>	<ul data-bbox="410 369 1110 513" style="list-style-type: none"> • Angled corner is on the left • Metal contacts face down • If you are using a Memory Stick Duo™ or Memory Stick PRO Duo™ card, attach the adapter that came with the card before you insert the card into the printer
 <p data-bbox="127 765 249 791">Microdrive</p>	<ul data-bbox="410 609 1103 690" style="list-style-type: none"> • Front label faces up, and if the label has an arrow, the arrow points toward the printer • Edge with metal pinholes goes into the printer first
 <p data-bbox="127 946 307 972">MultiMediaCard</p>	<ul data-bbox="410 814 763 869" style="list-style-type: none"> • Angled corner is on the right • Metal contacts face down
 <p data-bbox="127 1130 291 1156">Secure Digital</p>	<ul data-bbox="410 998 763 1053" style="list-style-type: none"> • Angled corner is on the right • Metal contacts face down
 <p data-bbox="127 1275 309 1302">xD-Picture Card</p>	<ul data-bbox="410 1182 864 1237" style="list-style-type: none"> • Curved side of card points toward you • Metal contacts face down

Saving photos to a computer from a memory card

You can save photos to a computer from any memory card inserted in the printer, if you have set up a USB connection between the two devices. You'll need to save the photos to your computer in order to use them in image editing software, such as the HP Image Zone. You must select **Typical** when you install the printer software or the HP Image Zone software will not be installed on your computer.

1. Insert a memory card into the printer.

If you are using a Windows computer

- a. Select **Copy pictures to a folder on my computer using Microsoft Scanner and Camera Wizard**.
- b. Follow the onscreen prompts.



Note The memory card also appears in Windows Explorer as a removable drive. You can open it and drag photos from the card to any location on your computer.

If you are using a Macintosh

- a. Wait for iPhoto to start and read the contents of the memory card.
- b. Click **Import** to save the photos on the card to your Macintosh.



Note The memory card also appears on the desktop as a drive icon. You can open it and drag photos from the card to any location on your Macintosh.

Removing a memory card

Wait until the Memory Card light stops flashing, then gently pull the memory card to remove it from the printer.



Caution Do not pull out a memory card while the Memory Card light is flashing. A flashing light means that the printer is accessing the memory card. Removing a memory card while it is being accessed may damage the printer and the memory card or corrupt the information on the memory card.


Deciding which photos to print

You can decide which photos to print from a memory card by printing a photo index and using the index numbers to select photos.

A photo index shows thumbnail views and index numbers for up to 2000 photos on a memory card. When printing an index page, use plain paper instead of photo paper to cut costs.

A photo index may be several pages long.

To print a photo index:

1. Insert a memory card.
2. Load several sheets of plain paper in the Main tray.
3. Press the **Index page** button, then press .




Selecting a photo layout

Press **Layout** on the printer to select a layout for the photos you want to print. All photos selected from the printer control panel will print in this layout. If you are not



using the **1 photo borderless** layout, the actual size of the prints will vary according to the size of paper you load in the printer, as shown in the following table.




Note The printer may rotate the photos to fit the layout.

Layout	Paper size (photo size)
 <p>1 photo borderless</p>	<p>The photo fills the page to match the paper size.</p>
 <p>1 photo per page, bordered</p>	<p>3.5 x 5 inches (3.25 x 4.75 inches) 4 x 6 inches (3.75 x 5.75 inches) 5 x 7 inches (4.75 x 6.75 inches) 8 x 10 inches (7.75 x 9.75 inches) 11 x 14 inches (10.75 x 13.75 inches) 13 x 19 inches (12.75 x 18.75 inches) 8.5 x 11 inches (8 x 10 inches) A6 (98.6 x 141.6 mm) A4 (200 x 250 mm) A3 (290.6 x 413.5 mm) 10 x 15 cm (95.2 x 146 mm) 13 x 18 cm (120.6 x 171.4 mm) Hagaki (93.6 x 141.6 mm) L (82.5 x 120.6 mm)</p>
 <p>2 photos per page</p>	<p>3.5 x 5 inches (2.25 x 3.25 inches) 4 x 6 inches (2.75 x 3.75 inches) 5 x 7 inches (3.25 x 4.75 inches) 8 x 10 inches (4.75 x 6.5 inches) 8.5 x 11 inches (5 x 7 inches) 11 x 14 inches (6.75 x 9.25 inches) 13 x 19 inches (8 x 10 inches) A6 (69.2 x 98.6 mm) A4 (130 x 180 mm) A3 (204.2 x 272.3 mm) 10 x 15 cm (69.2 x 98.6 mm)</p>

(continued)



Layout	Paper size (photo size)
	13 x 18 cm (84.1 x 120.6 mm) Hagaki (68 x 93.6 mm) L (58.7 x 82.5 mm)
 <p data-bbox="221 458 419 486">3 photos per page</p>	3.5 x 5 inches (1.5 x 2.25 inches) 4 x 6 inches (1.75 x 2.625 inches) 5 x 7 inches (2.25 x 3.375 inches) 8 x 10 inches (3.33 x 5 inches) 8.5 x 11 inches (4 x 6 inches) 11 x 14 inches (5 x 7.5 inches) 13 x 19 inches (6 x 9 inches) A6 (47.7 x 71.5 mm) A4 (100 x 150 mm) A3 (139.7 x 209.6 mm) 10 x 15 cm (45.7 x 69 mm) 13 x 18 cm (58.7 x 88 mm) Hagaki (45.2 x 67.8 mm) L (39.6 x 59.4 mm)
 <p data-bbox="221 1029 419 1057">4 photos per page</p>	3.5 x 5 inches (1.5 x 2.25 inches) 4 x 6 inches (1.75 x 2.5 inches) 5 x 7 inches (2.2 x 3.25 inches) 8 x 10 inches (3.5 x 4.75 inches) 8.5 x 11 inches (3.5 x 5 inches) 11 x 14 inches (4.75 x 6.75 inches) 13 x 19 inches (5 x 7 inches) A6 (47.7 x 69.2 mm) A4 (90 x 130 mm) A3 (133.4 x 190.5 mm) 10 x 15 cm (45.7 x 66 mm) 13 x 18 cm (58.7 x 84.1 mm) Hagaki (45.2 x 65 mm) L (39.6 x 57 mm)

(continued)

Layout	Paper size (photo size)
 <p data-bbox="244 331 438 357">9 photos per page</p>	<p data-bbox="706 170 1059 196">3.5 x 5 inches (1 x 1.375 inches)</p> <p data-bbox="706 210 1059 236">4 x 6 inches (1.125 x 1.5 inches)</p> <p data-bbox="706 249 1009 276">5 x 7 inches (1.5 x 2 inches)</p> <p data-bbox="706 289 1034 315">8 x 10 inches (2.25 x 3 inches)</p> <p data-bbox="706 329 1078 355">8.5 x 11 inches (2.5 x 3.25 inches)</p> <p data-bbox="706 369 1084 395">11 x 14 inches (3.25 x 4.25 inches)</p> <p data-bbox="706 409 1015 435">13 x 19 inches (4 x 6 inches)</p> <p data-bbox="706 449 927 475">A6 (30.7 x 40.5 mm)</p> <p data-bbox="706 489 889 515">A4 (64 x 84 mm)</p> <p data-bbox="706 529 939 555">A3 (88.9 x 120.6 mm)</p> <p data-bbox="706 569 1015 595">10 x 15 cm (29.6 x 39.3 mm)</p> <p data-bbox="706 609 996 635">13 x 18 cm (38 x 50.1 mm)</p> <p data-bbox="706 649 952 675">Hagaki (29 x 38.6 mm)</p> <p data-bbox="706 689 914 715">L (25.3 x 33.6 mm)</p>

Selecting photos to print

You select the photos you want to print by using the printer control panel.

If you want to...	Follow these steps
<p data-bbox="244 927 408 953">Select a photo</p>	<ol data-bbox="602 927 1116 1164" style="list-style-type: none"> <li data-bbox="602 927 883 953">1. Insert a memory card. <li data-bbox="602 956 1116 1012">2. Press ◀ or ▶ to display the index number of the photo you want to select. <li data-bbox="602 1015 1116 1105">3. Press  to select the photo. The index number appears in the Selected photos area of the printer screen. <li data-bbox="602 1109 1106 1164">4. To select additional photos, repeat steps 2 and 3.
<p data-bbox="244 1194 438 1220">Deselect a photo</p> <p data-bbox="244 1234 572 1347">When you deselect a photo, the printer discards any changes you made to the print settings for that photo.</p> <p data-bbox="244 1373 568 1454">Note Deselecting photos does not delete them from the memory card.</p>	<ol data-bbox="602 1194 1141 1307" style="list-style-type: none"> <li data-bbox="602 1194 1141 1248">1. Press ◀ or ▶ to display the photo you want to deselect. <li data-bbox="602 1251 1141 1307">2. Press Cancel to deselect the displayed photo for printing.
<p data-bbox="244 1482 463 1508">Deselect all photos</p>	<ol data-bbox="602 1482 1141 1595" style="list-style-type: none"> <li data-bbox="602 1482 1141 1564">1. Press Cancel until a message appears on the printer screen asking if you want to deselect all photos. <li data-bbox="602 1567 740 1595">2. Press .

Improving photo quality

The printer lets you improve the brightness or contrast of any photo printed from a memory card. These print settings do not change the original photo. They only affect printing.






Problem	How to correct it
Photos with poor brightness	<ol style="list-style-type: none">1. Press Menu.2. Press ▶ until Digital Flash appears, then click ☑.3. Press ▶ until On appears, then press ☑.
Blurred photos	<ol style="list-style-type: none">1. Press Menu.2. Press ▶ until AutoFocus appears, then click ☑.3. Press ▶ until On appears, then press ☑.

Doing common printing tasks from a memory card

This section describes some of the most common printing tasks you might want to do from a memory card.

If you want to...	Follow these steps:
Print a borderless photo You can print borderless photos without even being connected to a computer. Before you begin, make sure that the memory card is inserted in the printer and the paper tray you want to use is loaded with the correct paper.	<ol style="list-style-type: none">1. Press Layout on the printer until Layout: 1 photo borderless appears on the printer screen.2. Select the photo or photos you want to print. For more information, see Selecting photos to print.3. Press Print.
Change the print quality to Normal for one print job You can change the print quality for photos. Best quality is the default and produces the highest quality photos. Normal quality conserves ink and prints faster.	<ol style="list-style-type: none">1. Press Menu.2. Select Print quality, then press ☑.3. Select Normal, then press ☑. <p>Print quality will revert to Best after the next print job.</p>
Print one or more photos Before you begin, make sure that the memory card is inserted in the printer and the	<ol style="list-style-type: none">1. Press the Layout button to select a photo layout. Select Layout: 1 photo borderless for borderless prints.

(continued)

If you want to...	Follow these steps:
<p>paper tray you want to use is loaded with the correct paper.</p>	<ol style="list-style-type: none"> 2. Press ◀ or ▶ to display the index number of the photo you want to print, then press . You can repeat steps 1 and 2 to select more photos. 3. Press Print.
<p>Print all photos on the memory card</p> <p>Before you begin, make sure that the memory card is inserted in the printer and the paper tray you want to use is loaded with the correct paper.</p>	<ol style="list-style-type: none"> 1. Press the Layout button to select a photo layout. Select Layout: 1 photo borderless for borderless prints. 2. Press Menu. 3. Select Print all, then press  to begin printing all photos on the memory card.
<p>Print a continuous range of photos</p> <p>Before you begin, make sure that the memory card is inserted in the printer and the paper tray you want to use is loaded with the correct paper.</p>	<ol style="list-style-type: none"> 1. Press the Layout button to select a photo layout. Select Layout: 1 photo borderless for borderless prints. 2. Press ◀ or ▶ until the first photo you want to print appears on the printer screen, then press and hold  for at least two seconds. 3. Press ◀ or ▶ until the last photo you want to print appears on the printer screen, then press . The selected range of photos begins printing.
<p>Print camera-selected photos from a memory card</p> <p>When you select photos for printing using a digital camera, the camera creates a Digital Print Order Format (DPOF) file that identifies the selected photos. The printer can read DPOF 1.0 and 1.1 files directly from a memory card.</p>	<ol style="list-style-type: none"> 1. Use the digital camera to select the photos you want to print. For more information, see the documentation that came with the camera. 2. If you select default as the photo layout with the camera, press the Layout button on the printer to select a photo layout. If you select a photo layout other than default with the camera, photos print in the camera-selected layout regardless of the printer setting. 3. Load photo paper. 4. Remove the memory card from the digital camera and insert it into the printer. 5. When a message appears on the printer screen asking if you want to print the camera-selected photos, press . The photos you selected with a camera will print. <p>If the printer cannot find or read all of the camera-selected photos on the card, it will print those photos that it can read.</p> <p>After printing, the printer deletes the DPOF file and unmarks the photos.</p>

(continued)

If you want to...	Follow these steps:
Stop printing	To stop a print job in progress, press Cancel .

Printing photos from a digital camera

You can print photos by connecting a PictBridge digital camera directly to the camera port of the printer with a USB cable. If you have a digital camera with Bluetooth wireless technology, you can insert the optional HP Bluetooth® wireless printer adapter in the printer and send photos to the printer wirelessly.

When you print from a digital camera, the printer uses the settings that you selected on the camera. For more information, see the documentation that came with the camera.

Using a PictBridge camera

Using a PictBridge camera with the printer is easy and fast.



PictBridge camera being connected to camera port

1. Turn on the PictBridge digital camera and select the photos you want to print.
2. Load photo paper in the printer.
3. Make sure the camera is in PictBridge mode, then connect it to the camera port on the **front** of the printer using the USB cable that came with the camera. Once the printer recognizes the PictBridge camera, the selected photos print automatically.

Using a Bluetooth camera

If you have a digital camera with Bluetooth wireless technology, you can purchase the optional HP Bluetooth® wireless printer adapter and print from a camera using a Bluetooth wireless connection.

1. Load photo paper in the printer and check that the paper tray you want to use is engaged.

2. Insert the HP Bluetooth® wireless printer adapter into the camera port on the **front** of the printer.
The light on the adapter will flash when the adapter is ready to receive data.
3. Follow the instructions in the documentation that came with the digital camera to send photos to the printer.

Printing from other Bluetooth devices

You can also print from other devices with Bluetooth wireless technology besides digital cameras, such as PDAs, laptops, and mobile phones. For more information, see [Connecting to other devices](#), the onscreen HP Photosmart Printer Help, and the documentation that came with the device with Bluetooth wireless technology.



Note To use Bluetooth connectivity, all devices must have the necessary hardware and software installed. In addition, an HP Bluetooth® wireless printer adapter must be connected to the camera port on the front of the printer. The adapter is available separately. For more information, see the documentation that came with the adapter.

The basic procedure for printing from any device with Bluetooth wireless technology is the same:

1. Have the device search for available Bluetooth printers.
2. Select the printer when it appears on the device.
3. Print.

Check the documentation that came with the device for detailed instructions.

7 Care and maintenance

The HP Photosmart 8700 series printer requires very little maintenance. Follow the guidelines in this section to extend the life span of the printer and printing supplies, and to ensure that the photos you print are always of the highest quality.

Cleaning and maintaining the printer

Keep the printer and print cartridges clean and well maintained using the simple procedures in this section.

Cleaning the outside of the printer

1. Turn off the printer, then disconnect the power cord from the back of the printer.
2. Wipe the outside of the printer with a soft cloth that has been lightly moistened with water.



Caution Do not use any type of cleaning solution. Household cleaners and detergents may damage the printer finish. Do not clean the interior of the printer. Keep all fluids away from the interior. Do not lubricate the metal rod on which the print cartridge cradle slides. Noise is normal when the cradle moves back and forth.

Automatically cleaning the print cartridges

If you notice white lines or single-color streaks on the photos you print, the print cartridges may need to be cleaned. Do not clean the cartridges more often than necessary, since cleaning uses up ink. Follow the steps in this section to run an automatic cartridge-cleaning procedure.

1. Press **Menu** on the printer control panel.
2. Select **Clean cartridges**, then press .
3. Following the directions on the printer screen, load paper so the printer can print a test page after cleaning the cartridges. Use plain paper to conserve photo paper.
4. Press to begin cleaning the print cartridges.
5. When the printer finishes cleaning the cartridges and prints a test page, it asks whether you want to **Continue to second level cleaning**. Check the test page and select from the following options:

- If the test page has white streaks or missing colors, the print cartridges need to be cleaned again. Select to continue to a second level cleaning.
- If the print quality of the test page looks good, press **Cancel**.

You can clean the cartridges up to three times. Each successive cleaning is more thorough and uses more ink.

If you complete all three levels of cleaning using this procedure and you still notice white streaks or missing colors on the test page, you may need to clean the print

cartridge contacts. For more information, see [Manually cleaning the print cartridge contacts](#).



Note If a cartridge has been recently dropped, you may also see white streaks or missing colors in your prints. This problem is temporary and clears up within 24 hours.

Manually cleaning the print cartridge contacts

If you use the printer in a dusty environment, debris may accumulate on the copper-colored contacts and cause printing problems.

To clean the print cartridge contacts:

1. Gather the following items to clean the contacts:
 - Distilled water (tap water may contain contaminants that can damage the print cartridge)
 - Cotton swabs or other soft, lint-free material that will not stick to the print cartridge
2. Open the top cover of the printer.
3. Remove the print cartridge and place it on a piece of paper with the ink nozzle plate facing up. Be careful not to touch the copper-colored contacts or the ink nozzle plate with your fingers.



Caution Do not leave the print cartridge outside the printer for more than 30 minutes. Ink nozzles exposed to the air longer than this may dry out and cause printing problems.

4. Lightly moisten a cotton swab with distilled water and squeeze any excess water from the swab.
5. Gently wipe the copper-colored contacts with the cotton swab.



Caution Do not touch the ink nozzle plate. Touching the ink nozzle plate will result in clogs, ink failure, and bad electrical connections.

6. Repeat steps 4 and 5 until no ink residue or dust appears on a clean swab.
7. Insert the print cartridge in the printer, then close the top of the printer.

Printing a test page

You can print a test page to check the condition of the print cartridges.

1. Press **Menu** on the printer control panel.
2. Select **Print test page**, then press .

The test page contains the following information:



- | | |
|---|---|
| 1 | Image print quality. If the lined bars look good, photos should print well. |
| 2 | Ink nozzle quality. If there are white streaks in the solid bars on this page, try cleaning the print cartridge. For more information, see Automatically cleaning the print cartridges . |
| 3 | Estimated ink level. This indicator shows how much ink is left in the print cartridge. |
| 4 | Diagnostic information. Use the text information on this page when working with HP Customer Care to solve printing problems. |

Aligning the print cartridges

The first time you install a print cartridge in the printer, the printer performs a printer calibration automatically to align the cartridges. However, if colors in the photos you print are misaligned, or if the alignment page does not print correctly when you install a new print cartridge, use the following procedure to calibrate the printer manually. This process aligns the print cartridges.

1. Press **Menu** on the printer control panel.
2. Select **Calibrate the printer**, then press .

Printing a sample page

You can print a sample page to test the printer photo printing quality and to make sure the paper is loaded correctly.

1. Load paper in the Main tray. Use plain paper to conserve photo paper.
2. Press **Menu** on the printer control panel.
3. Select **Print a sample page**, then press .

Updating the software

Download the latest printer software update periodically to ensure you have the latest features and improvements. You can download printer software updates by going to www.hp.com/support or by using HP Software Update.



Note The printer software update that you download from the HP web site does not update the HP Image Zone software.

Downloading the software (Windows)



Note Make sure you are connected to the Internet before you use HP Software Update.

1. From the Windows **Start** menu, select **Programs** (in Windows XP, select **All Programs**) > **Hewlett-Packard** > **HP Software Update**. The HP Software Update window opens.
2. Click **Check Now**. HP Software Update searches the HP web site for printer software updates. If the computer does not have the most recent version of the printer software installed, a software update appears in the HP Software Update window.



Note If the computer has the most recent version of the printer software installed, the following message appears in the HP Software Update window: “No updates are available for your system at this time”.

3. If a software update is available, click the checkbox next to the software update to select it.
4. Click **Install**.
5. Follow the onscreen instructions to complete the installation.

Downloading the software (Macintosh)



Note Make sure you are connected to the Internet before you use HP Photosmart Updater.

1. On your Macintosh in the Finder, choose **Go > Applications**.
2. Choose **Hewlett-Packard > Photosmart > HP Photosmart Updater**.
3. Follow the onscreen instructions to check for software updates.
If you are behind a firewall, you need to enter the proxy server information in the updater.

Storing the printer

The printer is built to withstand long or short periods of inactivity.

- Store the printer indoors out of direct sunlight in a place without temperature extremes.
- If the printer and print cartridges have not been used for one month or more, clean the print cartridges before printing. For more information, see [Automatically cleaning the print cartridges](#).

Maintaining the supplies

For best results with photo paper, follow the guidelines in this section.

Storing photo paper

- Store the photo paper in its original packaging or in a resealable plastic bag.
- Store the packaged photo paper on a flat, cool, and dry surface.
- Return unused photo paper to the plastic bag. Paper left in the printer or exposed to the elements may curl.

Handling photo paper

- Always hold photo paper by the edges to avoid fingerprints.
- If the photo paper has curled edges, place it in its plastic storage bag and gently bend it in the opposite direction of the curl until the paper lies flat.

Storing the print cartridges

When you store the printer, always leave the active print cartridges inside the printer. The printer stores the print cartridges in a protective cap during the power-down cycle.



Caution Make sure the printer completes its power-down cycle before you unplug the power cord. This allows the printer to store the print cartridges properly.

Follow these tips to help maintain HP print cartridges and ensure consistent print quality:

- When you remove a print cartridge from the printer, store it in a print cartridge protector to prevent the ink from drying out. For more information, see [Inserting print cartridges](#).
- Keep all unused print cartridges in their original sealed packages until they are needed. Store print cartridges at room temperature (15–35 degrees C or 59–95 degrees F).
- Do not remove the plastic tape covering the ink nozzles until you are ready to install the print cartridge in the printer. If the plastic tape has been removed from the print cartridge, do not attempt to reattach it. Reattaching the tape damages the print cartridge.

8 Troubleshooting

The HP Photosmart printer is designed to be reliable and easy to use. This chapter answers frequently asked questions about using the printer and printing without a computer. It contains information about the following topics:

- Printer software installation problems
- Printer hardware problems
- Printing problems
- Error messages

For additional troubleshooting information, see:

Printer software and printing from a computer troubleshooting: The onscreen HP Photosmart Printer Help. For information about viewing the onscreen HP Photosmart Printer Help, see [Finding more information](#).

Printer software installation problems



Note Before contacting HP Customer Care, read this section for troubleshooting tips or go to the online support services at www.hp.com/support. The name of HP's support services may vary by country/region.

If the printer software did not install successfully or if the printer and computer are not communicating properly after software installation, check this section for possible solutions.

Check all cable connections between the printer and computer, and ensure that you are using the most recent version of the printer software.

The System Requirements dialog box appears during installation

Cause A component of the computer system does not meet minimum system requirements.

Solution Upgrade the component to the minimum system requirement and then reinstall the printer software.

The computer could not read the HP Photosmart CD

Solution Make sure the CD isn't dirty or scratched. If other CDs work but the HP Photosmart does not, you may have a damaged CD. You can request a new CD from HP Customer Care. If other CDs don't work, you may need to service the CD-ROM drive.

The installation software does not start automatically when the CD is inserted (Windows only)

Solution From the Windows **Start** menu, select **Run**. Click **Browse**, then navigate to the CD drive where you inserted the HP Photosmart CD. Double-click the **setup.exe** file.

The Found New Hardware Wizard opens but doesn't recognize the printer (Windows only)

Cause You may have connected the USB cable before completing the software installation.

Solution Disconnect the USB cable and restart the software installation. Connect the USB cable when prompted during software installation.

The system requirements check indicates that the computer is running an outdated version of Internet Explorer (Windows only)

Solution Press CTRL + SHIFT on the keyboard and click **Cancel** in the System Requirements dialog box to bypass the block and complete the software installation. You must update Internet Explorer immediately after installing the HP Photosmart software, or the HP software will not work properly. You do not have to reinstall the HP software after updating Internet Explorer.

The computer stops responding during software installation

Cause Virus protection software or another software program is running in the background and slowing down the installation process.

Solution Wait while the software finishes copying files; this may take several minutes. If, after several minutes, the computer is still not responding, restart the computer, pause or disable any active virus protection software, quit all other software programs, and then reinstall the printer software.

Printer hardware problems



Note 1 Before contacting HP Customer Care, read this section for troubleshooting tips or go to the online support services at www.hp.com/support. The name of HP's support services may vary by country/region.

Note 2 If you want to connect the printer to a computer with a USB cable, HP recommends using a cable of less than 3 meters (10 feet) in length to minimize injected noise due to potential high electromagnetic fields.

The Status light is flashing green but the printer is not printing

Solution The printer is busy processing information; wait for it to finish.

The Status light is flashing amber or red

Solution

- Check the printer screen for instructions. If a digital camera is connected to the printer, check the camera screen for instructions. If the printer is connected to a computer, check the computer monitor for instructions.
- Turn off the printer, then unplug its power cord. Wait about 10 seconds, then plug it in again. Turn on the printer.

If the Status light continues to flash red or stay amber, go to www.hp.com/support, or contact HP Customer Care.

The Status light flashed amber briefly after I turned the printer off

Solution This is a normal part of the power-down process; it does not indicate a problem with the printer.

The printer does not find the photos I stored on my memory card

Cause The memory card may contain file types the printer cannot read directly from the card.

Solution

- Save the photos to a computer, then print them from the computer. For more information, see the onscreen HP Photosmart Printer Help and the documentation that came with the camera.
- The next time you take photos, set the digital camera to save them in a file format the printer can read directly from the memory card. For a list of supported file formats, see [Printer specifications](#). For instructions on setting the digital camera to save photos in specific file formats, see the documentation that came with the camera.

The memory card may need to be reformatted if the problem persists.

The printer is plugged in but will not turn on

Solution

- The printer may have drawn too much power. Unplug the printer's power cord. Wait about 10 seconds, then plug the cord back in. Turn on the printer.
 - The printer may be plugged into a power strip that is turned off. Turn on the power strip, then turn on the printer.
 - The power cord could be defective. Make sure the green light on the power cord is lit.
-

The printer makes noises when I turn it on, or starts making noises after sitting unused for a while

Solution The printer may make noises after long periods of inactivity (approximately 2 weeks) or when its power supply has been interrupted and then restored. This is normal operation. The printer is performing an automatic maintenance procedure to ensure it produces the best quality output.

Printing problems



Note Before contacting HP Customer Care, read this section for troubleshooting tips or go to the online support services at www.hp.com/support. The name of HP's support services may vary by country/region.

The printer does not print borderless photos when I print from the control panel

Solution Press the **Layout** button until **Layout: 1 photo borderless** appears, then try to print again.

Printing is very slow

Cause You may be printing a PDF or a project containing high-resolution graphics or photos. Large, complex projects containing graphics or photos print slower than text documents.

Solution Consider using lower resolution graphics in the project, if possible, or allow for longer print times in your workflow.

Cause The printer may be in Ink-Backup Printing Mode. The printer enters this mode when one of the print cartridges has been removed or is out of ink.

Solution Replace the missing or empty cartridge.

Paper does not feed into the printer correctly from the Main tray

Solution

- There may be too much paper loaded in the tray. Remove some paper and try printing again.
 - The paper guides may not be adjusted correctly. Make sure the paper-width and paper-length guides fit close to the edges of the paper without bending the paper.
 - Two or more pieces of paper may be sticking together. Remove the paper from the Main tray, fan the edges of the stack to separate the sheets of paper, then reload the paper and try printing again.
 - If the paper is wrinkled or bent, try using different paper.
 - The paper may be too thin or too thick. Use HP inkjet paper for best results. For more information, see [Choosing the right paper](#).
-

Printed pages are dropping off of the Out tray

Solution Always extend the Out tray extension when you print.

The printout is rippled or curled

Solution The project you are printing uses a larger amount of ink than normal. Print the project from a computer, and use the printer software to lower the ink saturation level. See the onscreen HP Photosmart Printer Help for more information.

The document printed at an angle or is off-center

Solution

- The paper may not be loaded correctly. Reload the paper, making sure it is correctly oriented in the Main tray and that the paper-width and paper-length guides fit close to the edges of the paper. For paper-loading instructions, see [Loading your paper](#).
 - The printer may need to be calibrated. For more information, see [Aligning the print cartridges](#).
-

Colors are not printing satisfactorily

Solution

- You may not be using the best print cartridges for the project. For more information, see [Inserting print cartridges](#).
 - You may be printing in Ink-Backup Printing Mode. The printer enters Ink-Backup printing mode when one of the print cartridges is missing. Replace the missing cartridge.
 - A cartridge is out of ink. Replace it.
 - Some of the ink nozzles on a cartridge are clogged. Clean the cartridges. See [Automatically cleaning the print cartridges](#).
 - The color management settings of the printer may not be set properly. For more information, see [Using color management](#).
-

No page came out of the printer or the paper jammed while printing

Solution

- The printer may need attention. Read the printer screen for instructions.
- The power may be off or there may be a loose connection. Make sure the power is on and the power cord is securely connected.

- You may not have any paper in the Main tray, front feed slot, or rear feed slot. Check that the paper is loaded correctly. For paper-loading instructions, see [Loading your paper](#).
 - If the paper jammed while printing, try the following:
 - Turn off the printer, then unplug it from the power source. Clear the printer of any paper obstructing the paper path. Remove the rear access door. Gently remove the jammed paper from the printer, then replace the rear access door. Plug the printer back in and turn it on. Try printing again.
 - If you were printing labels, make sure a label did not become unglued from the label sheet while going through the printer.
-

Banner paper jams between the Main and Out trays

Solution There is too much banner paper in the Main tray. Clear the paper jam.

A blank page came out of the printer

Solution

- Check the ink-level icons on the printer screen. Replace any empty print cartridges. For more information, see [Inserting print cartridges](#).
 - You may have begun printing and then cancelled the process. If you cancelled the process before printing started, the printer may have already loaded paper in preparation for printing. The next time you print, the printer will eject the blank page before starting the new printing project.
 - You may be printing in Ink-Backup Printing Mode with only the black print cartridge installed and borderless printing turned on. Replace the missing print cartridge with a new one or turn off borderless printing. For more information about printing in Ink-Backup Printing Mode, see [Inserting print cartridges](#).
-

The photo did not print using the printer's default print settings

Solution You may have changed the print settings for the selected photo. Print settings you apply to an individual photo override the printer's default print settings. Discard all print settings that have been applied to an individual photo by deselecting the photo. For more information, see [Selecting photos to print](#).

The printer ejects the paper when preparing to print

Solution Direct sunlight could be interfering with the operation of the automatic paper sensor. Move the printer out of direct sunlight.

Print quality is poor

Solution

- You may be printing in Ink-Backup Printing Mode. The printer enters Ink-Backup Printing Mode when one of the print cartridges is missing. Replace the missing cartridge. For more information, see [Inserting print cartridges](#).
 - One of the print cartridges may be running out of ink. If a cartridge is running low on ink, replace it. For more information, see [Inserting print cartridges](#).
 - Use photo paper designed for the printer. For best results, use HP inkjet paper.
 - You may be printing on the wrong side of the paper. Make sure the paper is loaded **with the side to be printed facing down**.
 - You may have selected a low-resolution setting on the digital camera. Reduce the size of the image and try printing again. For better results in the future, set the digital camera to a higher photo resolution.
 - There may be a problem with a print cartridge. Try the following:
 - Remove and then reinsert the print cartridges.
 - Run an automatic print cartridge cleaning procedure from the printer control panel. For more information, see [Automatically cleaning the print cartridges](#).
 - Calibrate the printer from the control panel. For more information, see [Aligning the print cartridges](#).
 - Clean the copper-colored contacts on the print cartridges. For more information, see [Manually cleaning the print cartridge contacts](#).
 - If these solutions do not work, replace the print cartridge(s).
-

Photos are not printing correctly

Solution

- You may have loaded the photo paper incorrectly. Load the photo paper with the side to be printed facing down.
 - The photo paper may not have fed into the printer correctly. Try the following:
 - Check for a paper jam.
 - Insert the photo paper as far as it will go into the front feed slot.
 - Load one sheet of photo paper at a time.
-

The photos I marked for printing in the digital camera do not print

Solution Some digital cameras let you mark photos for printing in both the camera's internal memory and on the memory card. If you mark photos in the internal memory, and then move photos from the camera's internal memory to the memory card, the marks do not transfer. Mark photos for printing after you transfer them from the digital camera's internal memory to the memory card.

The photo is clipped when I print it

Cause You have transferred a photo from your computer to a memory card, inserted the card into the printer, and then tried to print the photo from the printer

control panel. This can cause clipping of the photo or change its size ratio in unexpected ways.

Solution Print the photo from the computer to avoid this distortion.

Error messages



Note Before contacting HP Customer Care, read this section for troubleshooting tips or go to the online support services at www.hp.com/support. The name of HP's support services may vary by country/region.

Error messages that appear on the printer screen can be divided into the following types:

- Paper errors
- Print cartridge errors
- Memory card errors
- Computer printing errors
- Network errors


Paper errors

Before contacting HP Customer Care, read this section for troubleshooting tips or go to the online support services at www.hp.com/support. The name of HP's support services may vary by country/region.


Error message: Paper jam. Clear jam then press .

Solution Turn off the printer, then unplug it from the power source. Clear the printer of any paper that may be obstructing the paper path. Remove the rear access door. Gently remove the jammed paper from the printer, then replace the rear access door. Plug the printer back in and turn it on.


Error message: Out of paper. Load paper then press .

Solution Load paper, then press  to print again. For paper-loading instructions, see [Loading your paper](#).

Error message: Unsupported media size.

Solution The printer cannot use the size of paper loaded in the paper tray. Press , then load a supported paper size instead. For a list of supported paper sizes, see [Printer specifications](#).

Error message: Automatic paper sensor failed.

Solution The automatic paper sensor is obstructed or damaged. Try moving the printer out of direct sunlight, then press  and try printing again. If this does

not work, go to www.hp.com/support or contact HP Customer Care. The name of HP's support services may vary by country/region.

Error message: Paper size mismatch

Cause The size of the paper in the paper tray does not match the photo size selected to print.

Solution Load a paper size that matches the photo size selected to print. For paper-loading instructions, see [Loading your paper](#).

Print cartridge errors

Before contacting HP Customer Care, read this section for troubleshooting tips or go to the online support services at www.hp.com/support. The name of HP's support services may vary by country/region.

Error message: Cartridge failed.

Solution The specified print cartridge may be old or damaged. Remove the cartridge and then reinstall it. For more information, see [Inserting print cartridges](#). If this does not work, replace the cartridge.

Error message: Cartridge failed. Replace it, or remove it to print using ink-backup printing mode.

Solution Remove the cartridge and then reinstall it. For more information, see [Inserting print cartridges](#). If this does not work, replace the cartridge. You can also print in Ink-Backup Printing Mode by removing the damaged cartridge.

Error message: One or more cartridges have failed. Please remove all cartridges. Reinsert them one at a time, closing the main door each time, to see which cartridges have failed.

Solution A print cartridge is old or damaged. Follow these steps to test print cartridges to see if one or more failed:

1. Remove all of the print cartridges.
 2. Reinsert one of the print cartridges in its appropriate print cartridge cradle.
 3. Close the main door. If the printer screen states that the inserted print cartridge has failed, replace it.
 4. Remove the print cartridge, then repeat steps 2–3 with the untested print cartridges.
-

Error message: Color cartridge not compatible. Use appropriate HP cartridge. —OR— Photo cartridge not compatible. Use appropriate HP cartridge. —OR— Right cartridge not compatible. Use appropriate HP cartridge.

Solution You have inserted a print cartridge that does not work with the printer. Replace the cartridge with one that is compatible with the printer. For more information, see [Inserting print cartridges](#).

Error message: Color Cartridge is not installed correctly. Please remove and reinsert it. —OR— Photo Cartridge is not installed correctly. Please remove and reinsert it. —OR— Cartridge is not installed correctly. Please remove and reinsert it.

Solution Remove the specified cartridge and reinstall it. For more information, see [Inserting print cartridges](#).

Error message: Color Cartridge is missing. —OR— Photo Cartridge is missing. —OR— Cartridge is missing. Please install and snap cartridge in completely.

Solution Install the specified cartridge using the instructions in [Inserting print cartridges](#).

Error message: Color Cartridge is low on ink. —OR— Photo Cartridge is low on ink. —OR— Cartridge is low on ink. You may need to replace it soon, or remove it to print using ink-backup printing mode.

Solution Replace the specified cartridge. For more information, see [Inserting print cartridges](#).

Error message: One or more cartridges have failed.

Solution Replace the failed cartridges with new HP print cartridges. For more information, see [Inserting print cartridges](#).

Error message: One or more cartridges are not compatible.

Solution One or more of the print cartridges are not HP print cartridges. Replace the non HP cartridges with supported HP print cartridges. For more information, see [Inserting print cartridges](#).

Error message: One or more cartridges are not installed correctly.


Solution Remove the print cartridges that are not installed correctly and then reinstall them following the procedures in [Inserting print cartridges](#).

Error message: One or more cartridges are low on ink.

Solution Replace the print cartridges that have low ink levels with new HP factory-filled print cartridges. For more information, see [Inserting print cartridges](#).


Error message: Cartridge service station is stuck.

Solution There is an obstruction blocking the path of the cartridge service station. The print cartridge service station is located beneath the print cartridge cradle when the printer is in an inactive state. Follow these steps to clear the obstruction:

1. Lift the top cover to access the print cartridges.
2. Clear any obstruction blocking the path of the cartridge service station.
3. Close the top cover.
4. Press the  button to continue.

Error message: Print cartridge cradle is stuck. Clear jam then press .

Solution Follow these steps to clear any obstruction in the path of the print cartridge cradle:

1. Lift the top cover to access the print cartridges.
2. Clear any obstruction in the cradle path.
3. Close the top cover.
4. Press the  button to continue.
The current page will eject and the print job will continue on the next available sheet of paper.

Error message: Top cover is open.

Solution Close the top cover of the printer.

Memory card errors

Before contacting HP Customer Care, read this section for troubleshooting tips or go to the online support services at www.hp.com/support. The name of HP's support services may vary by country/region.

Error message: Photo is missing. —OR— Some photos are missing.

Solution The printer cannot read the file on the memory card or one or more files specified for the job are missing from the memory card. Try saving the photos to the computer using the digital camera rather than the memory card. If a photo is missing, you may have accidentally deleted the photo from the card.

Error message: Card access error. Job was cancelled. See computer for details. Press . —OR— **File directory structure is corrupted. —OR— Card may be damaged. Job was cancelled. See computer for details. Press .**

Cause The printer cannot read the data on the memory card and cannot complete any current print or save jobs. The data may be corrupted or there may be a physical problem with the memory card.

Solution

- Save the files to the computer and access them from there.
 - If this does not work, use a new memory card or reformat the memory card using the digital camera. Any photos on the memory card will be lost.
 - If this does not work, the photo files may be damaged or unreadable. Before you contact HP Customer Care, try another memory card to determine if it is the printer or the memory card that is failing.
-

Error message: Can not print photos.

Cause More than 10 photos specified for a print job may be corrupt, missing, or are an unsupported file type. For information about supported file types, see [Printer specifications](#).

Solution

- Save the photos to the computer using the digital camera rather than the memory card.
 - Save the files to the computer and print from the computer.
 - Print a photo index page and reselect photos. For more information, see [Deciding which photos to print](#).
-

Error message: Card is password protected. Can not access card.

Solution The printer cannot read the memory card because the card is password-protected. Follow these steps:

1. Remove the memory card from the printer.
 2. Insert the memory card in the device you originally used to store the password on the memory card.
 3. Remove the password from the memory card using the same software you used to store the password.
 4. Remove the memory card and reinsert it in the printer memory card slot.
 5. Try printing again.
-

Error message: Card is locked. Can not access card.

Solution Make sure the lock switch on the card is in the unlocked position.

Error message: Card is not fully inserted. Push card in a little more.


Solution The printer can detect the memory card but cannot read it. Push the memory card gently into the memory card slot until it stops. For more information, see [Inserting a memory card](#).

Error message: Use only 1 card at a time. Please remove a memory card.

Solution The printer has two or more different types of memory cards inserted simultaneously or a memory card inserted and a digital camera connected to the camera port at the same time. Remove memory cards or disconnect the camera until only one card is in the printer or one camera is connected.

Error message: Card was removed. Job was cancelled. Press .

Solution You removed a memory card from the printer while it was busy printing a file from the card or saving files to the computer. Follow these steps:

1. Press the  button.
2. Reinsert the memory card and print selected photos or saved files again. The memory card must remain inserted until the print or save job is complete.

To avoid damage to memory cards in the future, do not remove them from the printer memory card slot while they are being accessed. For more information, see [Removing a memory card](#).

Error message: Camera selections (DPOF) file has error.

Solution The printer is unable to read a DPOF file due to corrupted data or an error on the memory card. Use the printer control panel to reselect the photos. For more information, see [Printing photos from a memory card](#).

Error message: Some camera-selected photos are not on card.

Solution Some camera-selected photos are missing or have been deleted. Try the following:

- Confirm that you did not accidentally delete the photo from the memory card.
 - Reselect the photos again using the digital camera.
 - Print a new photo index page to see the index numbers associated with each photo. For more information, see [Deciding which photos to print](#).
-

Error message: No new photos on card.

Solution There are no new photos on the memory card, or the photos have already been printed once. Select and print the desired photos.

Error message: Cannot display this photo.


Solution The memory card contains image formats the printer does not support or the file is corrupted. For a list of supported image formats, see [Printer specifications](#). Access photos using the computer. For information about accessing photos through the computer, see [Basic printing from a computer](#).

Error message: Memory card in backwards. The black side should face up.

Solution The memory card has been inserted upside down. Remove the memory card and reinsert it with the gold contacts facing down. For more information, see [Inserting a memory card](#).




Computer printing errors

Before contacting HP Customer Care, read this section for troubleshooting tips or go to the online support services at www.hp.com/support. The name of HP's support services may vary by country/region.

Error message: Printer memory is full. Job was cancelled. Press .

Solution The printer encountered a problem when saving files to the computer. Try the following:

- To clear the printer memory, turn the printer off, then turn it on again.
 - Print fewer photos at a time.
 - Save the photos to the computer and print from there.
 - Save the files to the computer using a memory card reader and then print from the computer.
-

Error message: Computer is not connected. To save photos...connect printer to computer. Press . —OR— Communication error. Check computer connection. Press . —OR— Data was not received. Check computer connection. Press  to continue. —OR— No response from computer.

Solution The printer cannot communicate properly with the computer. A printer driver may not be working or a cable may be loose. Make sure the USB cable is securely attached to both the computer and to the USB port on the back of the printer. If the cable is secure, verify that the printer software is installed.

Network errors

Before contacting HP Customer Care, read this section for troubleshooting tips or go to the online support services at www.hp.com/support. The name of HP's support services may vary by country/region. You can also find help with networking the printer by going to the home page of the embedded web server in the printer. See [To access help for the embedded web server](#).

Error message: Network not connected.

Solution The printer cannot find the network. Make sure the Ethernet cable is properly connected to the Ethernet port and the network. If your network requires a proxy IP address, access the embedded web server to set the proxy server settings. See [Using the embedded web server](#).

9 HP Customer Care



Note The name of HP's support services may vary by country/region.

If you have a problem, follow these steps:

1. Check the documentation that came with the printer.
 - **Quick Start booklet** or **Setup Guide**: The HP Photosmart 8700 series printer comes with setup instructions that explain how to set up the printer and install the printer software. Which document you receive with the printer varies by country/region.
 - **User's Guide**: The *User's Guide* is the book you are reading. This book describes the basic features of the printer, explains how to use the printer without connecting a computer, and contains hardware troubleshooting information.
 - **HP Photosmart Printer Help**: The onscreen HP Photosmart Printer Help describes how to use the printer with a computer and contains software troubleshooting information.
2. If you are unable to solve the problem using the information in the documentation, visit www.hp.com/support to do the following:
 - Access online support pages
 - Send HP an e-mail message for answers to your questions
 - Check for software updates
 - Connect with an HP technician by using Real Time ChatSupport options and availability vary by product, country/region, and language.
3. **For Europe only**: Contact your local point of purchase. If the printer has a hardware failure, you will be asked to bring the printer to where you purchased it. Service is free during the printer limited warranty period. After the warranty period, you will be quoted a service charge.
4. If you are unable to solve the problem using the onscreen HP Photosmart Printer Help or HP web sites, call HP Customer Care using the number for your country/region. For a list of country/region phone numbers, see [HP Customer Care by phone](#).

HP Customer Care by phone

While the printer is under warranty, you can obtain free phone support. For more information, see the warranty information included in the box, or go to www.hp.com/support to check the duration of your free support.

After the free phone support period, you can obtain help from HP at an additional cost. Contact your HP dealer or call the support phone number for your country/region for support options.

To receive HP support by phone, call the appropriate support phone number for your location. Standard phone company charges apply.

North America: Call 1-800-HP-INVENT (1-800-474-6836). U.S. phone support is available in both English and Spanish languages 24 hours a day, 7 days a week (days

and hours of support may change without notice). This service is free during the warranty period. A fee may apply outside the warranty period.

Western Europe: Customers in Austria, Belgium, Denmark, Spain, France, Germany, Ireland, Italy, Netherlands, Norway, Portugal, Finland, Sweden, Switzerland, and the United Kingdom should go to www.hp.com/support to access phone support numbers in their country/region.



Support for the following countries/regions is available at www.hp.com/support: Austria, Belgium, Central America & The Caribbean, Denmark, Spain, France, Germany, Ireland, Italy, Luxembourg, Netherlands, Norway, Portugal, Finland, Sweden, Switzerland, and the United Kingdom.

61 56 45 43	الجزائر
Argentina (Buenos Aires)	54-11-4708-1600
Argentina	0-800-555-5000
Australia	1300 721 147
Australia (out-of-warranty)	1902 910 910
800 171	البحرين
Brasil (Sao Paulo)	55-11-4004-7751
Brasil	0-800-709-7751
Canada (Mississauga Area)	(905) 206-4663
Canada	1-(800)-474-6836
Chile	800-360-999
中国	021-3881-4518 800-810-3888 服务编码: 3001
Colombia (Bogota)	571-606-9191
Colombia	01-8000-51-4746-8368
Costa Rica	0-800-011-1046
Česká republika	261 307 310
Ecuador (Andinatel)	1-999-119 ☎ 800-711-2884
Ecuador (Pacifitel)	1-800-225-528 ☎ 800-711-2884
2 532 5222	مصر
El Salvador	800-6160
Ελλάδα (από το εξωτερικό)	+ 30 210 6073603
Ελλάδα (εντός Ελλάδας)	801 11 22 55 47
Ελλάδα (από Κύπρο)	800 9 2649
Guatemala	1-800-711-2884
香港特別行政區	2802 4098
Magyarország	1 382 1111
India	1 600 44 7737
Indonesia	+62 (21) 350 3408
(0) 9 830 4848	ישראל
Jamaica	1-800-711-2884
日本	0570-000511
日本 (携帯電話の場合)	03-3335-9800

한국	1588-3003
Malaysia	1800 805 405
Mexico (Mexico City)	55-5258-9922
Mexico	01-800-472-68368
22 404747	المغرب
New Zealand	0800 441 147
Nigeria	1 3204 999
Panama	1-800-711-2884
Paraguay	009 800 54 1 0006
Perú	0-800-10111
Philippines	2 867 3551
Polska	22 5666 000
Puerto Rico	1-877-232-0589
República Dominicana	1-800-711-2884
România	(21) 315 4442
Россия (Москва)	095 7973520
Россия (Санкт-Петербург)	812 3467997
800 897 1444	السعودية
Singapore	6 272 5300
Slovakia	2 50222444
South Africa (International)	+ 27 11 2589301
South Africa (RSA)	086 0001030
Rest Of West Africa	+ 351 213 17 63 80
臺灣	02-8722-8000
ไทย	+66 (2) 353 9000
71 89 12 22	تونس
Trinidad & Tobago	1-800-711-2884
Türkiye	90 216 444 71 71
Україна	(380 44) 4903520
800 4520	الإمارات العربية المتحدة
United States	1-(800)-474-6836
Uruguay	0004-054-177
Venezuela (Caracas)	58-212-278-8666
Venezuela	0-800-474-68368
Việt Nam	+84 88234530

Placing a call

Call HP Customer Care while you are near the computer and printer. Be prepared to provide the following information:

- Printer model number (located on the front of the printer).
- Printer serial number (located on the bottom of the printer).
- Computer operating system.
- Version of printer driver:
 - **Windows PC:** To see the printer driver version, right-click the memory card icon in the Windows taskbar and select **About**.
 - **Macintosh:** To see the printer driver version, use the Print dialog box.
- Messages displayed on the printer screen or on the computer monitor.
- Answers to the following questions:
 - Has the situation you are calling about happened before? Can you recreate the situation?
 - Did you install any new hardware or software on the computer around the time that the situation occurred?

Return to HP repair service (North America only)

HP will arrange to have your product picked up and delivered to an HP Central Repair Center. We pay for the round-trip shipping and handling. This service is free for the duration of the hardware warranty period. This service is available in North America only.

Additional warranty options

Extended service plans are available for the printer at additional costs. Go to www.hp.com/support, select your country/region and language, then explore the services and warranty area for information about the extended service plans.

a Networking

The instructions in this section describe how to install the HP Photosmart 8700 series printer in an ethernet (wired) network. A wired setup allows the printer to communicate to computers through a router, hub, or switch. Broadband Internet access is required in order to take full advantage of the printer feature set.



Note For USB installation, see the setup instructions that came in the box.

Before proceeding with this section, make sure you have already set up your wired network. See the documentation that came with your network hardware. Also make sure you have set up the printer as described in the setup instructions that came in the box.

Networking basics (Windows and Macintosh)


Networking lets networked devices, such as computers and printers, communicate with each other. A wired or ethernet network is the most common type of network in offices and in homes.

The network adapter in the printer itself supports both 10 Mbps and 100 Mbps ethernet networks. To connect the printer to a network, you need a CAT-5 ethernet cable equipped with a RJ-45 plug. This is not the same as a USB cable. You must purchase the Ethernet cable separately. It is not included with the printer.



Caution Although the RJ-45 plug of a CAT-5 cable resembles a common telephone plug, it is not the same. Never use a regular phone wire to connect the printer to an ethernet network. You can damage the printer and other network devices by doing so.

The following illustration shows an example of the printer networked with several computers through a network hub, switch, or router. A cable or DSL modem links the hub and all the networked devices to broadband Internet access.



1	Cable or DSL modem connecting the networked devices to broadband Internet access
2	A network access point (hub, switch, or router) into which all the devices are connected through ethernet cables

Networked devices connect to each other through a central device. The most common types include:

- **Hubs:** A simple, inexpensive network device that lets several computers communicate with each other or share a common printer. Hubs are passive. They only provide a way for communication to flow between other devices.
- **Switches:** Switches are similar to hubs, but can examine the information sent between devices and forward the information only to the proper device. They can lessen bandwidth usage on a network and help keep it running more efficiently.
- **Routers:** Routers or gateways connect both devices and networks. A common use is to connect several home computers on a network to the Internet. Routers often also include a built-in firewall that can help protect a home network from unauthorized access.



Note For specific information about setting up and configuring the hardware on your network, see the documentation that came with the hardware.

Internet connection

If your network is connected to the Internet through a router or gateway, it is recommended that you use a router or gateway that supports Dynamic Host Configuration Protocol (DHCP). A gateway with DHCP support manages a pool of reserved IP addresses that it assigns dynamically as needed. See the documentation that came with the router or gateway.

Recommended network configurations

The following network configurations support the printer. Determine the type of network configuration you have, then see [Connecting the printer to the network](#) and [Installing the printer software on a Windows computer](#) or [Installing the printer software on a Macintosh](#) for instructions on connecting your printer to the network and then installing the software.

Ethernet network without Internet access

The computers and printer communicate with each other, forming a simple network, through a hub. None of the networked devices has access to the Internet.

Ethernet network with Internet access by dial-up modem

The computers and printer communicate with each other, forming a simple network, through a hub. One of the computers has access to the Internet through a modem and dial-up account. None of the other networked devices, including the printer, have direct access to the Internet.

Ethernet network with broadband Internet access provided by a router

The printer is connected to a router that acts as a gateway between the user network and the Internet. This is the ideal network configuration.

Connecting the printer to the network

To connect the printer to a wired network, you need the following:

- A network access point such as a hub, router, or switch with an open port
- A CAT-5 ethernet cable with RJ-45 plug




Note 1 You should not connect the printer directly to a computer using an ethernet cable. Peer-to-peer networking is not supported.

Note 2 After you connect the printer to the network as described in this section, you must install the printer software. See [Installing the printer software on a Windows computer](#) or [Installing the printer software on a Macintosh](#).

To connect the printer to the network

1. Connect the ethernet cable to the back of the printer.



Ethernet connection on the back of the printer

2. Connect the ethernet cable to an empty port on the hub, router, or switch.



After you finish connecting the printer to the network, install the printer software. You cannot print from a computer until you do the software installation.

- Installing the printer software on a Windows computer
- Installing the printer software on a Macintosh

Installing the printer software on a Windows computer



Note Set up the printer as indicated in the setup instructions that came in the box.

Installation time can range from 20 minutes (Windows XP) to 1 hour (Windows 98), the amount of available hard drive space, and the processor speed of the computer. Make sure you have

already connected the printer to the network with an ethernet cable before you begin the installation.



Note The printer software must be installed as described in this section on every networked computer from which you want to print to the HP Photosmart 8700 series printer. After the installation, printing is identical to printing through a USB connection.



Tip Do not use the Windows **Add Printer** control panel utility to install the printer software. You must use the HP installer to install the printer on a network properly.

To install the printer software

1. Print a network configuration page. You may need the information included in this report if the installer cannot detect the printer.
See [Printing a network configuration page](#).
2. Insert the HP Photosmart printer software CD into the computer's CD-ROM drive.
3. Click **Next** and follow the instructions provided by the Installer to check and prepare the system, and install drivers, plug-ins, and software. This takes several minutes.
4. At the **Connection Type** screen, select **Through the network**, then click **Next**. The **Searching** screen appears as the Setup program searches for the printer on the network.

If the Printer Found screen appears, do this:

- a. Verify that the printer description is correct. (Use the configuration page to verify the printer name and hardware address. See [Printing a network configuration page](#).)
- b. If the printer description is correct, select **Yes, install this printer**, then click **Next**. If more than one printer is found on the network, select **HP Photosmart 8700 series** as the device to configure and install, then click **Next**. If you have more than one HP Photosmart 8700 series printer on your network, use the Hardware Address (MAC) item listed in the network configuration page to identify the specific HP Photosmart 8700 series printer you want to install.

If the Check Cable Connection screen appears, do this:

- a. Follow the onscreen instructions, then select **Specify a printer by address**, then click **Next**.
 - b. On the **Specify Printer** screen, enter the Hardware Address (MAC) number listed in the network configuration page in the **Hardware Address (MAC)** box.
Example: 02bad065cb97
MAC stands for Media Access Control, a hardware address that identifies the printer on the network.
 - c. Enter the IP Address listed in the network configuration page in the **IP Address** box, then click **Next**.
Example: 169.254.203.151
 - d. When the **Printer Found** screen appears, select **Yes, install this printer**, then click **Next**.
 - e. In the **Confirm Settings** screen, click **Next**.
 - f. Follow the onscreen instructions.
5. When prompted, click **Finish** to exit the installation.

Installing the printer software on a Macintosh



Note Set up the printer as indicated in the setup instructions that came in the box.

Installation time can take 3-4 minutes depending on your operating system, the amount of available hard drive space, and the processor speed of the Macintosh. Make sure you have already connected the printer to the network with an ethernet cable before you begin the installation. If you have already installed this printer on a USB connection, you do not have to follow these instructions to do a network installation. Instead, see [To change a USB connected printer to a network connection](#).



Note The printer software must be installed as described in this section on every networked computer from which you want to print to the HP Photosmart 8700 series printer. After the installation, printing is identical to printing to a printer connected by a USB cable.

To install the printer software

1. Insert the HP Photosmart printer software CD into the Macintosh CD-ROM drive.
2. Double-click the CD icon on the desktop.
3. Double-click the Installer icon.
The **Authenticate** dialog appears.
4. Enter the **Name** and **Password** used to administer your Macintosh, then click **OK**.
5. Follow the onscreen instructions.
6. When the **HP Photosmart Install** window appears, choose **Easy Install**, then click **Install**.
7. In the **Select Printer** window, click the **Network** tab. The installer searches for any printers on the network.

If the printer is found, do this:

- a. Select the HP Photosmart 8700 series printer in the **Select Printer** window, then click **Utilities**.
- b. Follow the onscreen instructions to register the printer.

If the printer is not found, do this:

- a. Print a network configuration page and locate the IP Address entry listed on the page.
- b. Make sure the printer is connected by the correct type of CAT-5 ethernet cable to the network. See [Connecting the printer to the network](#).
- c. Click **Find**, enter the IP Address, then click **Save**.
- d. Select the HP Photosmart 8700 series printer in the **Select Printer** window, then click **Utilities**.
- e. Follow the onscreen instructions to register the printer.



Note Some browsers may not work with the online registration. If you encounter problems, either try another browser or skip this step.

8. Select the printer in the **Print** dialog box. If the printer does not appear in the list, select **Edit Printer List** to add the printer.
9. In the **Printer List** window, click **Add**.
10. Select **Rendezvous** from the drop-down list.
11. Select the printer from the list, then click **Add**.
That's it. You're done!

To change a USB connected printer to a network connection

1. Connect the printer to the network. See [Connecting the printer to the network](#).
2. Print a network configuration page and locate the IP Address entry.

3. Open a web browser and enter the IP Address to access the embedded web server in the printer. For more information on the embedded web server, see [Using the embedded web server](#).
4. Click the **Networking** tab.
5. Click **mDNS** in the Applications area on the left.
6. Enter a unique name (63 characters or less) in the **mDNS Service Name** box.
7. Click **Apply**.
8. Select the printer in the **Print** dialog box. If the printer does not appear in the list, select **Edit Printer List** to add the printer.
9. In the **Printer List** window, click **Add**.
10. Select **Rendezvous** from the drop-down list.
11. Select the printer from the list, then click **Add**.

Using the embedded web server

The embedded web server in the printer provides a simple way to manage the networked printer. Using any web browser from either a Windows or Macintosh computer, you can communicate with the printer over the network to:

- Check printer status and estimated ink levels
- View network statistics
- Adjust the printer network configuration such as specifying a proxy server, setting a DNS name, or manually entering an IP address
- Restrict access to configuration pages
- Order supplies
- Go to the HP web site for support

To access the embedded web server home page

1. Print a network configuration page. See [Printing a network configuration page](#).
2. Enter the printer IP address indicated on the network configuration page into the address box of your browser.

Example IP address: 10.0.0.81

The home page for the embedded web server appears.

For information about network terms and the embedded web server that is not covered in this guide, access the embedded web server help.





To access help for the embedded web server

1. Go to the embedded web server home page. See [To access the embedded web server home page](#).
2. Click **Help** in the **Other Links** area of the home page.

Printing a network configuration page

You can print a network configuration page from the printer without even being connected to a computer. The configuration page provides useful information regarding the printer IP address, network statistics, and other network settings. You can also display a summary of select network settings on the printer itself.

To print a detailed network configuration page

1. Press **Menu** on the printer.
2. Press  until **Network settings** appears, then press .
3. Press  until **Print network settings page** appears, then press .

b Specifications

This section lists the minimum system requirements for installation of the HP Photosmart printer software, and provides selected printer specifications.

System requirements

Component	Windows PC minimum	Macintosh minimum
Operating system	Microsoft® Windows 98, 2000 Professional, ME, XP Home, and XP Professional	Mac® OS X 10.1.5 through 10.3
Processor	Intel® Pentium® II (or equivalent) or higher	G3 or greater
RAM	64 MB (256 MB recommended)	128 MB (256 MB recommended)
Free disk space	600 MB (2 GB recommended)	500 MB
Video display	800 x 600, 16-bit or higher	800 x 600, 16-bit or higher
CD-ROM drive	4x	4x
Connectivity	USB: Microsoft Windows 98, 2000 Professional, ME, XP Home, and XP Professional Ethernet: using the Ethernet port PictBridge: using front camera port Bluetooth: using optional HP bt300 Bluetooth wireless printer adapter	USB: Front and back ports (Mac OS X 10.1.5 through 10.3) Ethernet: using the Ethernet port PictBridge: using front camera port
Browser	Microsoft Internet Explorer 5.5 or later	—

Printer specifications

Category	Specifications
Connectivity	USB: Microsoft Windows 98, 2000 Professional, ME, XP Home, and XP Professional; Mac OS X 10.1.5 through 10.3 Ethernet
Dimensions	Weight: 11.8 kg (26 lbs) Height: 203 mm (8 inches)

(continued)

Category	Specifications
	<p>Width: 643 mm (25.3 inches)</p> <p>Depth: 398 mm (15.7 inches)</p>
Environmental specifications	<p>Recommended during operation: 0–45° C (32–113° F), 20–80% RH</p> <p>Maximum during operation: 5–40° C (41–104° F), 5–95% RH</p> <p>Storage temperature range: -30–65° C (22–149° F)</p>
Image file formats	<p>JPEG Baseline</p> <p>TIFF 24-bit RGB uncompressed interleaved</p> <p>TIFF 24-bit YCbCr uncompressed interleaved</p> <p>TIFF 24-bit RGB packbits interleaved</p> <p>TIFF 8-bit gray uncompressed/packbits</p> <p>TIFF 8-bit palette color uncompressed/packbits</p> <p>TIFF 1-bit uncompressed/packbits/1D Huffman</p>
Media specifications	<p>Recommended maximum length: 483 mm (19 inches)</p> <p>Recommended maximum width: 330 mm (13 inches)</p> <p>Recommended maximum thickness: 292 µm (11.5 mil)</p> <p>Recommended plain paper media weight: 60 to 90 g/m² (16 to 24 lb.)</p> <p>Recommended maximum photo media weight: 280 g/m²</p>
Media sizes	<p>Supported sizes when printing from a computer</p> <p>76 x 127 mm to 330 x 483 mm (3 x 5 inches to 13 x 19 inches)</p> <p>Supported sizes when printing from the control panel</p> <p>Metric: 10 x 15 cm (with or without tab), 13 x 18 cm, A6, A3, A4, L, 2L; Imperial: 3.5 x 5 inches, 4 x 6 inches (with or without tab), 4 x 12 inches, 5 x 7 inches, 8 x 10 inches, 8.5 x 11 inches, 11 x 14 inches, 13 x 19 inches; Other: Hagaki</p>
Media types	<p>Paper (photo, plain, and inkjet)</p> <p>Envelopes</p> <p>Transparencies</p> <p>Labels</p> <p>Cards (index, greeting, Hagaki, A6, L-size)</p> <p>Iron-on transfers</p>
Memory cards	<p>CompactFlash Type I and II</p> <p>Microdrive</p> <p>MultiMediaCard</p>

(continued)

Category	Specifications
	Secure Digital Memory Sticks xD-Picture Card
Memory card-supported file formats	Printing: See Image file formats earlier in table. Saving: All file formats
Paper trays	Main tray 76 x 127 mm to 330 x 483 mm (3 x 5 inches to 13 x 19 inches) Front feed slot 10 x 15 cm (4 x 6 inches) to 330 x 483 mm (13 x 19 inches) Rear feed slot 76 x 127 mm to 330 x 483 mm (3 x 5 inches to 13 x 19 inches) Out tray All supported sizes
Paper tray capacity	Main tray 100 sheets of plain paper 14 envelopes 20–40 cards (depending on thickness) 20 sheets of banner paper 30 sheets of labels 25 photo paper, transparencies, or iron-on transfers Front feed slot 10 sheets of photo paper Rear feed slot 1 sheet of any media up to 292 µm (11.5 mil) thick Out tray 50 sheets of plain paper 20 sheets of photo paper, banner paper, or transparencies 10 cards or envelopes 25 sheets of labels or iron-on transfers
Power consumption	Printing: 29 W Idle: 6 W Off: 5 W
Power supply model number	0950-4476, 0957-2105; 100-240 Vac (+/-10%) 50/60 Hz (+/- 3 Hz)

(continued)

Category	Specifications
Print cartridges	<p>HP Gray Photo HP Color Photo HP Tri-color HP Black HP Blue Photo</p> <p>Note The cartridge numbers you can use with this printer appear on the back cover of the printed <i>HP Photosmart 8700 series User's Guide</i>. If you have already used the printer several times, you can find the cartridge numbers in the HP Photosmart 8700 series Toolbox. For more information on accessing the Toolbox, see <i>Inserting print cartridges</i>.</p>
USB support	<p>Microsoft Windows 98, 2000 Professional, ME, XP Home, and XP Professional Mac OS X 10.1.5 through 10.3</p> <p>HP recommends that the USB cable be less than 3 meters (10 feet) in length</p>
Network support	<p>Microsoft Windows 98, 2000 Professional, ME, XP Home, and XP Professional Mac OS X 10.1.5 through 10.3</p>

HP printer limited warranty statement

HP product	Duration of limited warranty
Software	90 days
Printer	1 year
Print cartridges	Until the HP ink is depleted or the end of warranty date printed on the cartridge has been reached, whichever comes first. This warranty does not cover HP ink products that have been refilled, remanufactured, refurbished, misused, or tampered with.
Accessories	1 year unless otherwise stated.

A. Extent of limited warranty

1. Hewlett-Packard (HP) warrants to the end-user customer that the HP products specified above will be free from defects in materials and workmanship for the duration specified above, which duration begins on the date of purchase by the customer.
2. For software products, HP's limited warranty applies only to a failure to execute programming instructions. HP does not warrant that the operation of any product will be uninterrupted or error free.
3. HP's limited warranty covers only those defects that arise as a result of normal use of the product, and does not cover any other problems, including those that arise as a result of:
 - a. Improper maintenance or modification;
 - b. Software, media, parts, or supplies not provided or supported by HP;
 - c. Operation outside the product's specifications;
 - d. Unauthorized modification or misuse.
4. For HP printer products, the use of a non-HP ink cartridge or a refilled ink cartridge does not affect either the warranty to the customer or any HP support contract with the customer. However, if printer failure or damage is attributable to the use of a non-HP or refilled ink cartridge, HP will charge its standard time and materials charges to service the printer for the particular failure or damage.
5. If HP receives, during the applicable warranty period, notice of a defect in any product which is covered by HP's warranty, HP shall either repair or replace the product, at HP's option.
6. If HP is unable to repair or replace, as applicable, a defective product which is covered by HP's warranty, HP shall, within a reasonable time after being notified of the defect, refund the purchase price for the product.
7. HP shall have no obligation to repair, replace, or refund until the customer returns the defective product to HP.
8. Any replacement product may be either new or like-new, provided that it has functionality at least equal to that of the product being replaced.
9. HP products may contain remanufactured parts, components, or materials equivalent to new in performance.
10. HP's Limited Warranty Statement is valid in any country where the covered HP product is distributed by HP. Contracts for additional warranty services, such as on-site service, may be available from any authorized HP service facility in countries where the product is distributed by HP or by an authorized importer.

B. Limitations of warranty

TO THE EXTENT ALLOWED BY LOCAL LAW, NEITHER HP NOR ITS THIRD PARTY SUPPLIERS MAKES ANY OTHER WARRANTY OR CONDITION OF ANY KIND, WHETHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, AND FITNESS FOR A PARTICULAR PURPOSE.

C. Limitations of liability

1. To the extent allowed by local law, the remedies provided in this Warranty Statement are the customer's sole and exclusive remedies.
2. TO THE EXTENT ALLOWED BY LOCAL LAW, EXCEPT FOR THE OBLIGATIONS SPECIFICALLY SET FORTH IN THIS WARRANTY STATEMENT, IN NO EVENT SHALL HP OR ITS THIRD PARTY SUPPLIERS BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY AND WHETHER ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

D. Local law

1. This Warranty Statement gives the customer specific legal rights. The customer may also have other rights which vary from state to state in the United States, from province to province in Canada, and from country to country elsewhere in the world.
2. To the extent that this Warranty Statement is inconsistent with local law, this Warranty Statement shall be deemed modified to be consistent with such local law. Under such local law, certain disclaimers and limitations of this Warranty Statement may not apply to the customer. For example, some states in the United States, as well as some governments outside the United States (including provinces in Canada), may:
 - a. Preclude the disclaimers and limitations in this Warranty Statement from limiting the statutory rights of a consumer (e.g., the United Kingdom);
 - b. Otherwise restrict the ability of a manufacturer to enforce such disclaimers or limitations; or
 - c. Grant the customer additional warranty rights, specify the duration of implied warranties which the manufacturer cannot disclaim, or allow limitations on the duration of implied warranties.
3. THE TERMS IN THIS WARRANTY STATEMENT, EXCEPT TO THE EXTENT LAWFULLY PERMITTED, DO NOT EXCLUDE, RESTRICT, OR MODIFY, AND ARE IN ADDITION TO, THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE SALE OF THE HP PRODUCTS TO SUCH CUSTOMERS.

Index

- A**
 - aligning print cartridges 14, 43
 - alignment page 43
- B**
 - black-and-white photos 13
 - Bluetooth
 - connecting to printer 29
 - wireless printer adapter 30
 - borderless prints
 - printing from a computer 27
 - printing from the control panel 37
 - buttons 6
- C**
 - cameras
 - Bluetooth 39
 - connecting to printer 29
 - PictBridge 39
 - port 4
 - printing from 39
 - care and maintenance 41
 - cartridges. *See* print cartridges
 - cleaning
 - print cartridges 41
 - printer 41
 - color management
 - application-based 22
 - calibrating a monitor 22
 - ICC device profiles 22
 - installing ICC profiles 22
 - printer-based 19
 - CompactFlash 30
 - computer
 - printing from 3, 17
 - system requirements 71
 - control panel 6
 - creative projects
 - HP Creative Scrapbook Assistant 26
 - large-format templates 25
 - scrapbooking 25
 - customer care. *See* HP Customer Care
- D**
 - digital cameras. *See* cameras
 - documentation, printer 3
- E**
 - error messages 54
 - ethernet 65
- F**
 - file formats, supported 31, 72
 - front feed slot 12
- H**
 - help. *See* troubleshooting
 - help, onscreen 3, 4
 - HP Creative Scrapbook Assistant 26
 - HP Customer Care 61
 - HP Image Zone 26
 - HP Software Update 43
- I**
 - ink cartridges. *See* print cartridges
 - ink level, checking 14, 42
 - ink-backup printing mode 14
 - inserting
 - memory cards 31
 - print cartridges 14
- J**
 - JPEG file format 31
- L**
 - large-format templates 25
 - layout
 - and photo size 33
 - large-format layout templates 25
 - lights 7
 - loading paper
 - in front feed slot 12
 - in Main tray 12
 - in rear feed slot 12
- M**
 - Main tray 12
 - memory card errors 57
 - memory cards
 - errors 57
 - inserting 31
 - printing from 30
 - removing 33
 - supported types 30
 - Memory Sticks 30
 - menu, printer 7
 - Microdrive 30
 - MultiMediaCard 30
- N**
 - network configuration page 70
 - networking
 - connecting printer to network 66
 - embedded web server 70
 - ethernet 65
 - network configuration page 70
 - software installation (Mac OS) 69
 - software installation (Windows) 67
- O**
 - onscreen Help 3
- P**
 - paper
 - buying and choosing 9
 - loading 11
 - maintaining 9, 44
 - specialty 10
 - specifications 71
 - storing 44
 - trays 4
 - paper jams 51
 - photos
 - improving quality 37
 - print cartridges, choosing 13
 - printing 30

- saving to computer 32
 - selecting for print 36
 - supported file formats 31, 72
- PictBridge cameras
 - camera port 39
- print cartridge protector 15
- print cartridges
 - aligning 43
 - choosing 13
 - cleaning 41
 - cleaning contacts 42
 - ink level, checking 14
 - ink-backup printing mode 14
 - inserting 14
 - numbers. *See* back cover of this guide
 - replacing 14
 - storing 15, 45
 - testing 42
- print driver
 - recommended settings 17
- print quality
 - changing 30
- printer
 - care and maintenance 41
 - cleaning 41
 - connecting 29
 - documentation 3
 - error messages 54
 - menu 7
 - parts 4
 - specifications 71
 - storing 44
- Printer Help
 - viewing 4
- printer screen 6
- printer software
 - updating 43
- printing
 - from a computer 17
 - from BlueTooth device 29
 - from cameras 39
 - from computer 3
 - from memory cards 29, 30
 - from PictBridge camera 29
 - photo index 33
 - photos 30
 - range of photos 30
 - test page 42
 - thumbnails 33

- troubleshooting problems
 - 50
 - without computer 29

Q

- quality
 - photo paper 44
 - photos 37
 - printing test page 42

R

- range
 - printing 30
- rear feed slot 12
- regulatory notices 79
- removing memory cards 33
- replacing print cartridges 14

S

- saving photos to computer 32
- scrapbooking
 - templates 25
- Secure Digital 30
- software
 - driver 17
 - HP Image Zone 26
 - print driver 17
 - templates 25
 - troubleshooting 47
- Sony Memory Sticks. *See* Memory Sticks
- specialty papers 10
- specifications 71
- storing
 - photo paper 44
 - print cartridge protector 15
 - print cartridges 15, 45
 - printer 44
- system requirements 71

T

- test page 42
- thumbnails, printing 33
- TIFF file format 31
- trays
 - front feed slot 5
 - Main tray 5, 12
 - Out tray 5
 - rear feed slot 5
- trays, paper 4
- troubleshooting
 - error messages 54

- flashing lights 48
- HP Customer Care 61
- printer hardware
 - problems 48
 - printing problems 50
 - software installation 47

U

- USB
 - port 4
 - specifications 71

X

- xD-Picture Card 30

Regulatory notices

Hewlett-Packard Company

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

Pursuant to Part 15.21 of the FCC Rules, any changes or modifications to this equipment not expressly approved by Hewlett-Packard Company may cause harmful interference, and void your authority to operate this equipment. Use of a shielded data cable is required to comply with the Class B limits of Part 15 of the FCC Rules.

For further information, contact: Hewlett-Packard Company, Manager of Corporate Product Regulations, 3000 Hanover Street, Palo Alto, CA 94304, (650) 857-1501.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, can cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

LED indicator statement

The display LEDs meet the requirements of EN 60825-1.

사용자 안내문 (한국 기기)

이 기기는 비업무용으로 전자파장애검정을 받은 기기여서, 주거지역에서는 다른 모든 지역에서 사용될 수 있습니다.

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると受信障害を引き起こすことがあります。
取り扱い説明書に従って正しい取り扱いをして下さい。

製品には、同梱された電源コードをお使い下さい。
同梱された電源コードは、他の製品では使用出来ません。