



# SGH-G600 User's Guide





# Important safety precautions



Failure to comply with the following precautions may be dangerous or illegal.

## Copyright information

- Bluetooth<sup>®</sup> is a registered trademark of the Bluetooth SIG, Inc. worldwide. Bluetooth QD ID: B012953
- Java<sup>™</sup> is a trademark or registered trademark of Sun Microsystems, Inc.
- Windows Media Player<sup>®</sup> is a registered trademark of Microsoft Corporation.

## Drive safely at all times

Do not use a hand-held phone while driving. Park your vehicle first.

## Switch off the phone when refuelling

Do not use the phone at a refuelling point (service station) or near fuels or chemicals.

## Switch off in an aircraft

Wireless phones can cause interference. Using them in an aircraft is both illegal and dangerous.

## Switch off the phone near all medical equipment

Hospitals or health care facilities may be using equipment that could be sensitive to external radio frequency energy. Follow any regulations or rules in force.

## Interference

All wireless phones may be subject to interference, which could affect their performance.

## Be aware of special regulations

Meet any special regulations in force in any area and always switch off your phone whenever it is forbidden to use it, or when it may cause interference or danger.


## Water resistance

Your phone is not water-resistant. Keep it dry.

## Sensible use

Use only in the normal position (held to your ear). Avoid unnecessary contact with the antenna when the phone is switched on.

## Emergency calls

Key in the emergency number for your present location, then press .

## Keep your phone away from small children

Keep the phone and all its parts, including accessories, out of the reach of small children.

## Accessories and batteries

Use only Samsung-approved batteries and accessories, such as headsets and PC data cables. Use of any unauthorised accessories could damage you or your phone and may be dangerous.

- The phone could explode if the battery is replaced with an incorrect type.
- Dispose of used batteries according to the manufacturer's instructions.



At very high volumes, prolonged listening to a headset can damage your hearing.

## Qualified service

Only qualified service personnel may repair your phone.

For more detailed safety information, see "Health and safety information" on page 40.

# About this Guide

This User's Guide provides you with condensed information about how to use your phone.

In this guide, the following instruction icons appear:




Indicates that you need to pay careful attention to the subsequent information regarding safety or phone features.



Indicates that you need to press the Navigation keys to scroll to the specified option and then select it.



Indicates a key on the phone. For example, [  ]



Indicates a soft key, whose function is displayed on the phone screen. For example, < **Menu** >



- **Camera and camcorder**

Use the camera module on your phone to take a photo or record a video.

## *Special features of your phone*



- **Synchronisation with Windows Media Player**

Transfer music files to your phone directly from the Windows Media Player.



- **Music player**

Play music files using your phone as a music player. You can use other phone functions while listening to music.



- **FM radio**

Listen to your favourite radio stations anytime, anywhere.



- **Image editor**

Crop, resize, rotate, and decorate your photos.



- **Digital data printing**

Print images, messages, and other personal data directly from your phone.



- **Offline mode**

Switch your phone to use its none-wireless functions in an airplane.



- **Bluetooth**

Transfer media files and personal data and connect to other devices using free, wireless Bluetooth technology.



- **Email**

Send and receive emails with image, video, and audio attachments.



- **SOS message**

Send SOS message to your family or friends for help in an emergency.



- **Voice recorder**

Record memos or sounds.

# Contents

## **Unpack 6**

*Make sure you have each item*

## **Get started 6**

*First steps to operating your phone*

Assemble and charge the phone ..... 6

Power on or off ..... 7

Your phone ..... 8

Keys and icons ..... 9

Access menu functions ..... 12

Enter text ..... 12

Customise your phone ..... 13

## **Step outside the phone 16**

*Begin with call functions, camera, music player, web browser, and other special features*

Make or answer calls ..... 16

Use the camera ..... 17

Play music ..... 18

Listen to the FM radio ..... 21

Browse the web ..... 23

Use Phonebook ..... 23

Send messages ..... 24

View messages ..... 26

Use Bluetooth ..... 27

## **Menu functions 29**

*All menu options listed*

## **Health and safety information 40**

## Overview of menu functions

To access Menu mode, press <**Menu**> in Idle mode.

### 1 Call log

- 1 Recent contacts
- 2 Missed calls
- 3 Dialed calls
- 4 Received calls
- 5 Delete all
- 6 Call manager

### 2 Phonebook

- 1 Contact list
- 2 FDN contacts
- 3 Create contact
- 4 Group
- 5 Speed dial
- 6 My namecard
- 7 Own number
- 8 Management
- 9 Service number<sup>1</sup>

### 3 Music

- 4 Google Search/  
Browser<sup>†</sup>

### 5 Messages

- 1 Create new message
- 2 My messages
- 3 Templates
- 4 Delete all
- 5 Settings
- 6 SOS messages
- 7 Broadcast messages
- 8 Memory status

### 6 My files

- 1 Images
- 2 Videos
- 3 Music
- 4 Sounds
- 5 Games & more
- 6 Other files
- 7 Memory card
- 8 Memory status

### 7 Calendar

### 8 Camera

### 9 FM radio

#### \* Applications<sup>††</sup>

- 1 Voice recorder
- 2 Image editor
- 3 Image stamp
- 4 Bluetooth
- 5 Browser<sup>†</sup>
- 6 Memo
- 7 World clock
- 8 Calculator
- 9 Converter
- 10 Timer
- 11 Stopwatch
- 12 SIM application toolkit<sup>1</sup>

### 0 Alarms

#### # Settings

- 1 Phone settings
- 2 Light settings
- 3 Display settings

#### # Settings

- 4 Message settings
- 5 Call settings
- 6 Phonebook settings
- 7 Calendar settings
- 8 Browser settings
- 9 Music player settings
- 10 Network settings
- 11 Security settings
- 12 Setup wizard
- 13 Memory settings
- 14 Reset settings

1. Available only if supported by your SIM card.

† If the Google Search service is not available, **Browser** will display in menu 4 instead of appearing in **Applications**.

†† If the Google Search service is not available, the order of submenus will change.

## Unpack

Make sure you have each item

- Phone
- Travel adapter
- Battery
- User's Guide

You can obtain various accessories from your local Samsung dealer.




The items supplied with your phone and the accessories available at your Samsung dealer may vary, depending on your country or service provider.

## Get started


First steps to operating your phone

### Assemble and charge the phone





## Removing the battery cover



## Power on or off

### Switch on

1. Open the phone.
2. Press and hold [📞].
3. If necessary, enter the PIN and press <OK>.
4. When the setup wizard opens, customise your phone according to your preferences.

### Switch off

1. Open the phone.
2. Press and hold [📞].


## Your phone

### Front view



1. Controls the backlight brightness to save the battery power.

### Rear view



When you close the phone, it locks the exposed keys to prevent any unwanted phone operations, from accidentally pressing any of the keys. To unlock the keys, press <Unlock> and then <OK>.

## Keys and icons

### Keys



Perform the function indicated on the bottom line of the display.



In Idle mode, access the following menus directly:

- Up: My menu mode
- Down/Left/Right: your favourite menus

In Menu mode, scroll through menu options.



In Idle mode, launch the web browser.

In Menu mode, select the highlighted menu option or confirm input.



Make or answer a call.

In Idle mode, retrieve numbers recently dialed, missed, or received.



Delete characters from the display or items in an application.



Press and hold to switch the phone on or off.

End a call.

In Menu mode, cancel input and return the phone to Idle mode.



Enter numbers, letters, and some special characters.



In Idle mode, press and hold [1] to access your voicemail server. Press and hold [0] to enter an international call prefix.



Enter special characters or perform special functions.



In Idle mode, press and hold [ # ] to activate or deactivate the Silent profile. Press and hold [ \* ] to enter a pause between numbers.



Adjust the phone volume.



In Idle mode, press and hold to turn on the camera.

In Camera mode, take a photo or record a video.

## Icons

The following icons may appear on the top line of the screen to indicate your phone's status. Depending on your country or service provider, the icons shown on the display may vary.



Signal strength



Call in progress



Out of your service area



Alarm set
























SOS message feature active



New message:


- : Text message
- : Multimedia message
- : Email
- : Voicemail

	Roaming network
	Call diverting feature active
	Bluetooth active
	Bluetooth headset or hands-free car kit connected
	GPRS network status <ul style="list-style-type: none"> <li>• Blue: GPRS network</li> <li>• Red: Transferring data in GPRS network</li> </ul>
	EDGE network status <ul style="list-style-type: none"> <li>• Blue: EDGE network</li> <li>• Red: Transferring data in EDGE network</li> </ul>
	Connecting to secured web page
	Home Zone

	Office Zone
	Memory card inserted
	Music playback in progress
	Music playback paused
	FM radio on
	Profile setting: <ul style="list-style-type: none"> <li>• : Normal</li> <li>• : Silent</li> <li>• : Driving</li> <li>• : Meeting</li> <li>• : Outdoor</li> <li>• : Offline</li> <li>• : User created</li> </ul>
	Battery power level

## Access menu functions

### Select an option




1. Press a desired soft key.
2. Press the Navigation keys to move to the next or previous option.
3. Press <**Select**> or [Centre] to confirm the function displayed or option highlighted.
4. Press <**Back**> to move up one level.  
Press [] to return to Idle mode.

### Use menu numbers

Press the number key corresponding to the option you want.

## Enter text

### Change the text input mode

- Press and hold [] to switch between T9 mode and ABC mode.
- Press [] to change case or switch to Number mode.
- Press and hold [] to switch to Symbol mode.

### ABC mode

**To enter a word:**  
Press the appropriate key until the character you want appears on the display.

T9 mode	<p>To enter a word:</p> <ol style="list-style-type: none"> <li>1. Press [2] to [9] to start entering a word.</li> <li>2. Enter the whole word before editing or deleting characters.</li> <li>3. When the word displays correctly, press [#] to insert a space. Otherwise, press [0] to display alternative word choices.</li> </ol>
Number mode	Press the keys corresponding to the digits you want.
Symbol mode	Press the corresponding number key to select a symbol.

#### Other operations

- Press [1] to enter punctuation marks or special characters.
- Press [#] to insert a space.
- Press the Navigation keys to move the cursor.
- Press [C] to delete characters one by one.
- Press and hold [C] to clear the entire display.

## Customise your phone

#### Display language

1. In Idle mode, press <Menu> and select **Settings** → **Phone settings** → **Language**.
2. Select a language.

Call ringer melody

To change the profile properties:

1. In Idle mode, press <Menu> and select **Settings** → **Phone settings** → **Phone profiles**.
2. Scroll to the profile you want.
3. Press <Options> and select **Edit**.
4. Select **Voice call ringtone** → a category → a ringtone.
5. Press <Options> and select **Save profile**.

To change the sound profile:

1. In Idle mode, press <Menu> and select **Settings** → **Phone settings** → **Phone profiles**.
2. Select the profile you want.

Key tone volume

In Idle mode, press [▲/▼] to adjust the key tone volume.

Idle mode wallpaper

1. In Idle mode, press <Menu> and select **Settings** → **Display settings** → **Home screen**.
2. Press [Left] or [Right] to select **Images**.
3. Select **Wallpaper**.



- 
4. Select an image category.
  5. Select an image.
  6. Press <**Save**>.

---

#### Menu mode skin colour

1. In Idle mode, press <**Menu**> and select **Settings** → **Display settings** → **My theme**.
2. Select a colour pattern.

---

#### Menu shortcuts

1. In Idle mode, press <**Menu**> and select **Settings** → **Phone settings** → **Shortcuts**.
2. Select a key.
3. Select a menu to be assigned to the key.

---

#### Silent profile

You can activate the Silent profile to avoid disturbing other people. In Idle mode, press and hold [#].

---

#### Phone lock





1. In Idle mode, press <**Menu**> and select **Settings** → **Security settings** → **Phone lock**.
2. Select **On**.
3. Enter a new 4- to 8-digit password and press <**OK**>.
4. Enter the new password again and press <**OK**>.

## Step outside the phone



Begin with call functions, camera, music player, web browser, and other special features

### Make or answer calls

#### Make a call

1. In Idle mode, enter an area code and phone number.
2. Press [].  
Press [/] to adjust the volume.
3. Press [] to end the call.

#### Answer a call

1. Press [] when the phone rings.
2. Press [] to end the call.


#### Use the speakerphone feature

During a call, press [Centre] and then <Yes> to activate the speaker.

Press [Centre] again to switch back to the earpiece.

#### Make a multi-party call


1. During a call, call the second participant.  
The first call is put on hold.
2. Press <Options> and select **Join**.
3. Repeat step 1 and 2 to add more participants.
4. During a multi-party call:
  - Press <Options> and select **Split** to have a private conversation with one participant.



- 
- Press <**Options**> and select **Remove** to drop one participant.
5. Press [>] to end the multi-party call.

## Use the camera

---

### Take a photo

1. In Idle mode, press and hold [>] to turn on the camera.
2. Rotate the phone to the left for landscape view.
3. Aim the lens at the subject and make any desired adjustments.

- 
4. Press [Centre] or [>] to take a photo. The photo is saved automatically.
  5. Press <> to take another photo.


---

### View a photo

1. In Idle mode, press <**Menu**> and select **My files** → **Images** → **My photos**.
2. Select the photo you want.

---

### Record a video

1. In Idle mode, press and hold [>] to turn on the camera.
2. Press [**1**] to switch to Record mode.

3. Rotate the phone to the left for landscape view.
4. Press [Centre] or [📷] to start recording.
5. Press <⏏> or [📷] to stop recording. The video is saved automatically.
6. Press <👉> to record another video.

#### View a video

1. In Idle mode, press <Menu> and select **My files** → **Videos** → **My video clips**.
2. Select the video you want.

## Play music

#### Prepare music files

Use these methods:

- Download from the wireless web.
- Download from a PC using the optional Samsung PC Studio. See Samsung PC Studio User's Guide.
- Receive via Bluetooth.
- Copy to a memory card. See the next section.
- Synchronise music files with Windows Media Player. See page 19.



When using a memory card, you need at least 15MB of free memory to use the music player.

---

### Copy music files to a memory card

1. Insert a memory card into the phone.
2. In Idle mode, press <Menu> and select **Settings** → **Phone settings** → **USB settings** → **Mass storage**.
3. Connect your phone and PC with an optional PC data cable.
4. Select **Open folder to view files** when a pop-up window appears on your PC.
5. Copy files from the PC to the memory card.
6. When you have finished, disconnect the phone from the PC.

---

### Synchronise with Windows Media Player

You can copy music files to the memory card by synchronising with Windows Media Player 11. You must use a 128 MB memory card or larger.

1. In Idle mode, press <Menu> and select **Settings** → **Phone settings** → **USB settings** → **Media player**.
2. Connect your phone and PC with an optional PC data cable.
3. Select **Sync digital media files to this device** when a pop-up window appears on your PC.

4. Enter the name of your phone and click **Finish**.
5. Select and drag the music files you want to the sync list.
6. Click **Start Sync**.
7. When synchronisation is finished, disconnect the phone from the PC.



- Do not remove the memory card from the phone or unplug the PC data cable while synchronising. It can cause data loss or errors in the music playlist.
- If you use the phone to format the memory card, all licenses and WM DRM files will be erased.

#### Play music files

1. In Idle mode, press **<Menu>** and select **Music**.
2. Select a music category → a music file.
3. During playback, use the following keys:
  - Centre: pause or resume playback.
  - Left: restart playback. Press it again within 3 seconds to return to the previous file. Press and hold to scan backward in a file.
  - Right: skip to the next file. Press and hold to scan forward in a file.

- 
- Up: open the playlist.
  - ▲/▼: adjust the volume.
4. Press [Down] to stop playback.

### Create your playlist

1. From the music player screen, press <Options> and select **Open playlist** → **All** → **Playlists**.
2. Press <Options> and select **Create playlist**.
3. Enter the title of the playlist and press [Centre].
4. Select the added playlist.
5. Press <Options> and select **Add** → a source.

6. Select a playlist, or select the files you want and press <Add>.
7. Press [Centre] to play music.

### Listen to the FM radio

#### Listen to the radio

1. Plug the connector of the supplied headset into the multi-function jack on the phone.
2. In Idle mode, press <Menu> and select **FM radio**.

3. Press [Centre] to turn on the radio.
4. When you turn on the FM radio for the first time, press <Yes> to start automatic tuning.  
Available radio stations are automatically saved.
5. Press [Left] or [Right] to find the radio station you want.
6. Press [Centre] to turn off the radio.

#### Store radio stations

#### By automatic tuning:

1. From the radio screen, press <Options> and select **Self-tuning**.
2. Press <Yes> to confirm.  
Available radio stations are automatically saved.

#### By manual setup:

1. From the radio screen, press [Left] or [Right] to select the radio station you want.
2. Press <Options> and select **Add to preset channels**.



## Browse the web

---

### Launch the web browser

In Idle mode, press [Centre]. The homepage of your service provider opens.

---

### Navigate the web

- To scroll through browser items, press [Up] or [Down].
- To select an item, press [Centre].
- To return to the previous page, press <Back>.
- To access browser options, press <Options>.

## Use Phonebook

---

### Add a contact

1. In Idle mode, enter a phone number.
  2. Press <Options> and select **Save** → a memory location → **New**.
  3. For **Phone**, select a number type.
  4. Specify contact information.
  5. Press [Centre] or <Save> to save the contact.
- 

### Find a contact

1. In Idle mode, press <Contacts>.
2. Enter the first few letters of the name you want.

3. Select a contact.
4. Scroll to a number and press [↩] to dial, or press [Centre] to edit contact information.

## Send messages

### Send a text message

1. In Idle mode, press <Menu> and select **Messages** → **Create new message** → **Message**.
2. Enter destination numbers and press [Down].
3. Enter the message text.
4. Press <Options> and select **Send** to send the message.

### Send a multimedia message

1. In Idle mode, press <Menu> and select **Messages** → **Create new message** → **Message**.
2. Enter destination numbers or email addresses.
3. Press <Options> and select **Advanced** → **Add subject**.
4. Press <OK>.
5. Enter the message subject and press [Down].
6. Enter the message text.
7. Press <Options> and select **Advanced** → **Add attachment**.

- 
8. Add a media file, Phonebook entry, or calendar item.
  9. Press <**Options**> and select **Send** to send the message.

---

#### Send an email

1. In Idle mode, press <**Menu**> and select **Messages** → **Create new message** → **Email**.
2. When the setup wizard opens, press <**Yes**> and customise settings for your email account.
3. Enter email addresses and press [Down].

4. Enter the email subject and press [Down].
5. Enter the email text.
6. Press <**Options**> and select **Attach multimedia** or **Attach organizer**.
7. Add image, video, sound, music files, document files, or calendar items.
8. Press <**Options**> and select **Send** to send the email.

## View messages

---

### View a text message

1. In Idle mode, press <Menu> and select **Messages** → **My messages** → **Inbox**.
  2. Select a text message.
- 

### View a multimedia message

1. In Idle mode, press <Menu> and select **Messages** → **My messages** → **Inbox**.
2. Select a multimedia message.

---

### View an email

1. In Idle mode, press <Menu> and select **Messages** → **My messages** → **Email inbox**.
2. Select **Check new mail**.
3. Select an email or a header.
4. If you selected a header, press <Options> and select **Retrieve** to view the body of the email.

## Use Bluetooth

Your phone is equipped with Bluetooth technology, enabling you to connect the phone wirelessly to other Bluetooth devices and exchange data with them, talk hands-free, or control the phone remotely.

### Turn on Bluetooth

1. In Idle mode, press **<Menu>** and select **Applications** → **Bluetooth** → **Activation** → **On**.
2. Select **My phone's visibility** → **On** to allow other devices to find your phone.

### Search for and pair with a Bluetooth device

1. In Idle mode, press **<Menu>** and select **Applications** → **Bluetooth** → **My devices** → **Search new device**.
2. Select a device.
3. Enter a Bluetooth PIN or the other device's Bluetooth PIN, if it has one, and press **<OK>**.  
When the owner of the other device enters the same code, the pairing is complete.

**Send data**

1. Access an application, such as **Phonebook**, **My files**, **Calendar**, or **Memo**.
2. Select the item you want to send.
3. Press **<Options>** and select **Send via** → **Bluetooth**.
4. For sending a contact, select which data you want to send.
5. Search for and select a device.
6. If necessary, enter the Bluetooth PIN and press **<OK>**.

**Receive data**

1. When a device attempts to access your phone, press **<Yes>** to permit the connection.
2. If necessary, press **<Yes>** to confirm that you are willing to receive.

## Menu functions

*All menu options listed*

This section provides brief explanations of menu functions on your phone.

### Call log

Menu	Description
Recent contacts, Missed calls, Dialled calls, Received calls	Check the most recent calls dialled, received, or missed.
Delete all	Delete all of the records in each call type.
Call manager → Call time	Check the time record for calls made and received.

Menu	Description
Call manager → Call costs	Check the cost of your calls, if supported by your SIM card.
Call manager → Reject list	Make a list of the phone numbers of callers to reject.

### Phonebook

Menu	Description
Contact list	Search for contact information stored in Phonebook.

## Menu functions

Menu	Description
FDN contacts	Create a list of contacts to be used in FDN (Fixed Dialling Number) mode, in which the phone allows outgoing calls only to the specified phone numbers, if your SIM card supports this feature.
Create contact	Add a new contact to Phonebook.
Group	Organise your contacts in caller groups.
Speed dial	Assign a speed dial number for your most frequently dialled numbers.
My namecard	Create a name card and send it to other people.

Menu	Description
Own number	Check your phone numbers, or assign a name to each of the numbers.
Management	Manage contacts in Phonebook or change the default settings for Phonebook.
Service number	View the SDN (Service Dialling Number) list assigned by your service provider, if supported by your SIM card.



## Music

Access and listen to all music files sorted by criteria. You can also make your own music playlists.

## Google Search/Browser

Depending on your country or service provider, you may have one of these menus here:

- **Google Search:** Launch the Google search engine to find information, news, images, or local services from around the web.
- **Browser:** Access up-to-date information and a wide variety of media content, such as wallpapers, ringtones, and music files.

## Messages

Menu	Description
Create new message	Create and send text, multimedia, or email messages.
My messages	Access messages that you have received, sent, or that have failed during sending.
Templates	Make and use templates of frequently used messages or passages.
Delete all	Delete messages in each message folder all at once.
Settings	Set up various options for using the messaging services.

## Menu functions

Menu	Description
SOS messages	Specify options for sending and receiving an SOS message. You can send an SOS message by pressing [▲/▼] 4 times when the phone is closed and the exposed keys are locked.
Broadcast messages	Change the settings for receiving broadcast messages.
Memory status	Check information about the memory currently in use.

## My files

Menu	Description
Images, Videos, Music, Sounds, Other files	Access media files and other files stored in the phone's memory.
Games & more	Access the embedded Java games.
Memory card	Access the files stored on a memory card. This menu is only available when you insert a memory card into the phone.
Memory status	Check information about the memory currently in use.

## Calendar

Keep track of your schedule.

## Camera

Use the camera embedded in your phone to take photos and record videos.

## FM radio

Listen to music or news via the FM radio on your phone.

## Applications

Menu	Description
Voice recorder	Record voice memos and any other sounds.

Menu	Description
Image editor	Edit your photos using various editing tools.
Image stamp	Make an outline stamp of a photo and merge it with another photo.
Bluetooth	Connect the phone wirelessly to other Bluetooth devices.
Browser <sup>†</sup>	Access up-to-date information and a wide variety of media content, such as wallpapers, ringtones, and music files.
Memo	Make memos for things that are important and manage them.

## Menu functions

Menu	Description
World clock	Set your local time zone and find out the current time in another part of the world.
Calculator	Perform arithmetic functions.
Converter	Do conversions, such as length and temperature.
Timer	Set a period of time for the phone to count down.
Stopwatch	Measure elapsed time.

Menu	Description
SIM application toolkit	Use a variety of additional services offered by your service provider. Depending on your SIM card, this menu may be available but labelled differently.

‡ If the Google Search service is not available depending on your country or service provider, **Browser** will move to menu 4.

### Alarms

Set a wake-up call to wake you up in the morning or an alarm to alert you to an event at a specific time.

## Settings

Menu	Description
Phone settings → Phone profiles	Change the sound settings of the phone for different events or situations.
Phone settings → Language	Select a language for the display text.
Phone settings → Shortcuts	Use the Navigation keys as shortcuts to access specific menus directly from Idle mode. [Up] is fixed as a shortcut to My menu mode.
Phone settings → Time and date	Change the time and date displayed on your phone.
Phone settings → Volume key	Set how the phone reacts if you press and hold [▲/▼] when a call comes in.

Menu	Description
Phone settings → Show caller information	Set the phone to display or block caller information on all missed calls and incoming messages.
Phone settings → My menu	Set up a menu of your own using your favourite menu items, which can be easily accessed by pressing [Up] in Idle mode.
Phone settings → Slide settings	Set how the phone reacts when you open it for an incoming call, and when you close it while using a function.

## Menu functions

Menu	Description
Phone settings → USB settings	Select a USB mode that will be used when you connect your phone to another device via USB interface.
Phone settings → Word suggestion	Set the phone to show the alternative word choices for your key presses in T9 mode.
Light settings → Backlight time	Select the length of time the backlight or display stays on when the phone is not used.
Light settings → Brightness	Adjust the brightness of the display for varying lighting conditions.

Menu	Description
Light settings → Keypad light	Set how the phone controls the use of the keypad light.
Display settings → Home screen	Change the background image that is displayed in Idle mode.
Display settings → My theme	Select a skin colour pattern for Menu mode.
Display settings → Text display	Change the display settings for the text displayed on the idle screen.
Display settings → Pop up list menu	Display the pop-up list that shows the menu options.

Menu	Description
Display settings → Dialling display	Customise the settings for the display while dialling.
Display settings → Greeting message	Enter the greeting that is displayed briefly when the phone is switched on.
Display settings → TV-out	Select a video system for your TV to view the phone display on the TV screen.
Display settings → Menu transition effect	Select a transition when you move between menus in Menu mode.
Message settings	Set up various options for using the messaging services.

Menu	Description
Call settings	Access network services for call functions.
Phonebook settings → Speed dial	Assign speed dial numbers for your most frequently dialled numbers.
Phonebook settings → Save new contacts to	Select a default memory location for saving contacts.
Phonebook settings → Own number	Check your phone numbers, or assign a name to each of the numbers.
Calendar settings → Starting day	Select which day of the week the calendar starts with.

## Menu functions

Menu	Description
Calendar settings → Default view by	Select the default calendar view mode.
Browser settings	Clear the cache or delete cookies or change the browser display settings. You can also select a connection profile to be used for accessing the wireless web.
Music player settings	Change the default settings for playing music.
Network settings → Select network	Select the network to be used while roaming outside of your home area, or let the network be chosen automatically.

Menu	Description
Network settings → Network mode	Change to an appropriate band when you travel abroad.
Security settings → Phone lock	Activate your phone password to protect your phone against unauthorised use.
Security settings → SIM lock	Set the phone to work only with the current SIM card by assigning a SIM lock password.
Security settings → PIN lock	Activate your PIN to protect your SIM card against unauthorised use.



Menu	Description
Security settings → Privacy lock	Lock access to call logs, contacts, messages, files, or memory card.
Security settings → Fixed dialling mode	Set the phone to restrict calls to a limited set of phone numbers, if supported by your SIM card.
Security settings → Change password	Change the phone password.
Security settings → Change PIN1 code	Change the PIN.

Menu	Description
Security settings → Change PIN2 code	Change your current PIN2, if supported by your SIM card.
Security settings → Mobile tracker	Set the phone to send the preset tracking message to your family or friends when someone tries to use your phone with another SIM card. This feature may be unavailable due to certain features supported by your service provider.

Menu	Description
Setup wizard	Quickly customise basic settings of your phone. Select the option you want for each setting by following the onscreen instructions.
Memory settings	Change the settings related with the memory and check information about the memory currently in use.
Reset settings	Reset the phone's settings you have changed.

## *Health and safety information*

### **SAR certification information**

This phone meets European Union (EU) requirements concerning exposure to radio waves.

Your mobile phone is a radio transmitter and receiver. It is designed and manufactured to not exceed the limits for exposure to radio-frequency (RF) energy, as recommended by the EU Council. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines were developed by independent scientific organisations through the periodic and thorough evaluation of scientific studies. The limits include a substantial safety margin designed to ensure the safety of all persons, regardless of age and health.

The exposure standard for mobile phones employs a unit of measurement known as Specific Absorption Rate (SAR). The SAR limit recommended by the EU Council is 2.0 W/kg.<sup>1</sup>

The highest SAR value for this model phone was 0.565 W/kg.

SAR tests are conducted using standard operating positions with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a base station, the lower the power output of the phone.

Before a new model phone is available for sale to the public, compliance with the European R&TTE Directive must be shown. This directive includes as one of its essential requirements the protection of the health and safety of the user and any other person.

---

1. The SAR limit for mobile phones used by the public is 2.0 watts/kilogram (W/kg) averaged over ten grams of body tissue. The limit incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements. The SAR values may vary, depending on national reporting requirements and the network band.

## **Precautions when using batteries**

---

- Never use a charger or battery that is damaged in any way.
- Use the battery only for its intended purpose.
- If you use the phone near the network's base station, it uses less power. Talk and standby time are greatly affected by the signal strength on the cellular network and the parameters set by the service provider.
- Battery charging time depends on the remaining battery charge, the type of battery, and the charger used. The battery can be charged and discharged hundreds of times, but it will gradually wear out. When the operation time is noticeably shorter than normal, it is time to buy a new battery.
- If left unused, a fully charged battery will discharge itself over time.
- Use only Samsung-approved batteries, and recharge your battery only with Samsung-approved chargers. Disconnect the charger from the power source when it is not in use.

- Do not leave the battery connected to a charger for more than a week, since overcharging may shorten its life.
- Extreme temperatures will affect the charging capacity of your battery: it may require cooling or warming first.
  - Do not leave the battery in hot or cold places because the capacity and lifetime of the battery will be reduced. Try to keep the battery at room temperature. A phone with a hot or cold battery may not work temporarily, even when the battery is fully charged. Li-ion batteries are particularly affected by temperatures below 0° C (32° F).
  - Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object like a coin, clip or pen causes a direct connection between the + and – terminals of the battery (metal strips on the battery). For example, do not carry a spare battery in a pocket or bag where the battery may contact metal objects. Short-circuiting the terminals may damage the battery or the object causing the short-circuiting.

- Dispose of used batteries in accordance with local regulations. Always recycle. Do not dispose of batteries in a fire.

### Road safety

---

Your wireless phone gives you the powerful ability to communicate by voice, almost anywhere, anytime. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When you are driving a car, driving is your first responsibility. When using your wireless phone while driving, follow local regulations in the country or region you are in.

### Operating environment

---

Remember to follow any special regulations in force in the area you are in, and always switch off your phone whenever it is forbidden to use it, or when it may cause interference or danger.

When connecting the phone or any accessory to another device, read its user's guide for detailed safety instructions. Do not connect incompatible products.

As with other mobile radio transmitting equipment, users are advised that for the satisfactory operation of the equipment and for the safety of personnel, it is recommended that the equipment should only be used in the normal operating position (held to your ear with the antenna pointing over your shoulder).

## **Electronic devices**

---

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone. Consult the manufacturer to discuss alternatives.

### **Pacemakers**

Pacemaker manufacturers recommend that a minimum distance of 15 cm (6 inches) be maintained between a wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research and recommendations of Wireless Technology Research. If you have any reason to suspect that interference is taking place, switch off your phone immediately.

### **Hearing aids**

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may wish to consult your hearing aid manufacturer to discuss alternatives.

### **Other medical devices**

If you use any other personal medical devices, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy.

Your physician may be able to assist you in obtaining this information.

Switch off your phone in health care facilities when regulations posted in these areas instruct you to do so.

### **Vehicles**

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle.

You should also consult the manufacturer of any equipment that has been added to your vehicle.

### **Posted facilities**

Switch off your phone in any facility where posted notices require you to do so.

### **Potentially explosive environments**

---

Switch off your phone when in any area with a potentially explosive atmosphere, and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Users are advised to switch off the phone while at a refuelling point (service station). Users are reminded of the need to observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants, or where blasting operations are in progress.

Areas with a potentially explosive atmosphere are often but not always clearly marked. They include the areas below decks on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas, such as propane or butane, areas where the air contains chemicals or particles, such as grain, dust or metal powders, and any other area where you would normally be advised to turn off your vehicle engine.


### **Emergency calls**

---

This phone, like any wireless phone, operates using radio signals, wireless, and landline networks as well as user-programmed functions, which cannot guarantee connection in all conditions. Therefore, you should never rely solely on any wireless phone for essential communications like medical emergencies.

To make or receive calls, the phone must be switched on and in a service area with adequate signal strength. Emergency calls may not be possible on all wireless phone networks or when certain network services and/or phone features are in use. Check with local service providers.

To make an emergency call:

1. Switch on the phone.
2. Key in the emergency number for your present location. Emergency numbers vary by location.
3. Press [].

Certain features like Call Barring may need to be deactivated before you can make an emergency call. Consult this document and your local cellular service provider.

## **Other important safety information**

---

- Only qualified personnel should service the phone or install the phone in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty applicable to the device.
- Check regularly that all wireless phone equipment in your vehicle is mounted and operating properly.
- Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the phone, its parts, or accessories.
- For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. Improperly installed wireless equipment could result in serious injury if the air bag inflates.
- Switch off your phone before boarding an aircraft. It is dangerous and illegal to use wireless phones in an aircraft because they can interfere with the operation of the aircraft.

- Failure to observe these instructions may lead to the suspension or denial of telephone services to the offender, or legal action, or both.

## **Care and maintenance**

---

Your phone is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you fulfill any warranty obligations and allow you to enjoy this product for many years.

- Keep your phone and all its parts and accessories out of the reach of small children and pets. They may accidentally damage these things or choke on small parts.
- Keep the phone dry. Precipitation, humidity, and liquids contain minerals that corrode electronic circuits.
- Do not use the phone with a wet hand. Doing so may cause an electric shock to you or damage to the phone.
- Do not use or store the phone in dusty, dirty areas, as its moving parts may be damaged.

## *Health and safety information*

- Do not store the phone in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the phone in cold areas. When the phone warms up to its normal operating temperature, moisture can form inside the phone, which may damage the phone's electronic circuit boards.
- Do not drop, knock, or shake the phone. Rough handling can break internal circuit boards.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the phone. Wipe it with a soft cloth.
- Do not paint the phone. Paint can clog the device's moving parts and prevent proper operation.
- Do not put the phone in or on heating devices, such as a microwave oven, stove, or radiator. The phone may explode when overheated.
- When the phone or battery gets wet, the label indicating water damage inside the phone changes colour. In this case, phone repairs are no longer guaranteed by the manufacturer's warranty, even if the warranty for your phone has not expired.
- If your phone has a flash or light, do not use it too close to the eyes of people or animals. This may cause damage to their eyes.
- Use only the supplied or an approved replacement antenna. Unauthorised antennas or modified accessories may damage the phone and violate regulations governing radio devices.
- If the phone, battery, charger, or any accessory is not working properly, take it to your nearest qualified service facility. The personnel there will assist you, and if necessary, arrange for service.





## Declaration of Conformity (R&TTE)

We, **Samsung Electronics**

declare under our sole responsibility that the product

**GSM Mobile Phone : SGH-G600**

to which this declaration relates, is in conformity with the following standards and/or other normative documents.

<b>SAFETY</b>	<b>EN 60950-1 : 2001 +A11:2004</b>
<b>EMC</b>	<b>EN 301 489-01 V1.5.1 (11-2004)</b> <b>EN 301 489-07 V1.2.1 (08-2002)</b> <b>EN 301 489-17 V1.2.1 (08-2002)</b>
<b>SAR</b>	<b>EN 50360 : 2001</b> <b>EN 62209-1 : 2006</b>
<b>RADIO</b>	<b>EN 301 511 V9.0.2 (03-2003)</b> <b>EN 300 328 V1.6.1 (11-2004)</b>

We hereby declare that [all essential radio test suites have been carried out and that] the above named product is in conformity to all the essential requirements of Directive 1999/5/EC.

The conformity assessment procedure referred to in Article 10 and detailed in Annex[IV] of Directive 1999/5/EC has been followed with the involvement of the following Notified Body(ies):

**BABT, Balfour House, Churchfield Road,  
Walton-on-Thames, Surrey, KT12 2TD, UK<sup>2</sup>**  
Identification mark: 0168

The technical documentation kept at :

Samsung Electronics QA Lab,

**CE 0168**

which will be made available upon request.  
(Representative in the EU)

Samsung Electronics Euro QA Lab,  
Blackbushe Business Park, Saxony Way,  
Yateley, Hampshire, GU46 6GG, UK<sup>2</sup>

2007.07.20

(place and date of issue)

**Yong-Sang Park / S. Manager**

(name and signature of authorised person)

■ It is not the address of Samsung Service Centre. For the address or the phone number of Samsung Service Centre, see the warranty card or contact the retailer where you purchased your phone.

- \* Depending on the software installed or your service provider or country, some of the descriptions in this guide may not match your phone exactly.
- \* Depending on your country, your phone and accessories may appear different from the illustrations in this guide.

**SAMSUNG ELECTRONICS**



World Wide Web  
<http://www.samsungmobile.com>

Printed in Korea  
Code No.:GH68-15425A  
English (EU). 07/2007. Rev. 1.0