



# EVOLIS CERTIFICATION

Technical Training

MUCH MORE THAN CARD PRINTERS



Signature pads



Software



Card printers



Accessories



Services




# PRODUCT INFORMATION

Zenius, Primacy,

# ZENIUS

- Main features:

- “Color Dye sublimation” and “monochrome thermal transfer”
- Feeder and manual feeder
- 300 dpi only
- Ribbon cassette system and auto recognition system (% and type)
- Windows XP(sp3)/Vista/7/8/10 (32/64 bit) – Mac 10.6 to 10.11 – Linux (Debian & Redhat)
- 2-year warranty for printer and print head (Spare parts = 6 months)
- Printer monitoring and user notification software
- Card types: PVC, PVC laminated, ABS, PET,...
- Card format: ISO CR80 (Only)
- Card thickness : from 0.25 to 0.76mm (10 to 30 mil)
- USB port for classic model (USB + Ethernet TCP/IP connection for Expert line)




- Options (only for expert line)

- Encoding options:

- Magnetic encoder ISO7811 or JIS2 – HiCo/LoCo (upgrade possible on site)
    - Contactless encoding coupler(upgrade possible on site)
    - Smart encoding station with/without coupler (upgrade possible on site)

- 3 encoding options can be installed in the same printer (magnetic, smart, contactless)


- No upgrade possible on Classic model.



# PRIMACY

- Main features:


- “Color Dye sublimation” and “monochrome thermal transfer”
- Flip-over (activation on site possible)
- 300 dpi
- Ribbon cassette system and auto recognition system (% and type)
- Windows XP(sp3)/Vista/7/8/10 (32/64 bit) – Mac 10.6 to 10.10 – Linux (Debian & Redhat)
- 3-year warranty for printer and print head (Spare parts = 6 months)
- Printer monitoring and user notification software
- Card types: PVC, PVC laminated, ABS, PET,...
- Card format: ISO CR80 (Only)
- Card thickness : from 0.25 to 1.25mm (10 to 50 mil)
- USB + Ethernet TCP/IP



# PRIMACY

## • Options


- Encoding over IP for smart/contactless communication (factory setting)
- WIFI (factory setting)
- Encoding options (upgrade possible on site)
  - Magnetic encoder ISO7811 or JIS2 – HiCo/LoCo
  - Contactless encoding coupler
  - Smart encoding station with/without coupler
- 3 encoding options can be installed in the same printer (magnetic , smart, contactless)




# USB OVER IP (FACTORY SETTING)

Networking in standard configuration =  
No encoding (except magnetic encoding)


Encoder are connected using internal  
USB HUB of Primacy.



Using the USB over IP emulates a USB connectin trough the network.



# LOW CARD SENSOR



**Do not wait for the input hopper to be empty:  
a message informs you when the card level is low!**

**Be more efficient by anticipating your card consumption**

- A sensor added within the input hopper detects the card level
- When the card level is low, a pop-up is displayed on the computer screen to inform the operator

Configuration depending on the used card thickness:

CARD THICKNESS	REMAINING CARDS IN FEEDER	REMINDING MESSAGE
0,76mm (30mil)	20 cards	2
0,50 mm (20mil)	30 cards	3
0,25mm (10mil)	60 cards	6

- Standard feature on the Primacy printers manufactured starting from Q3 2015
- Cannot be upgraded on the Primacy installed base



# EXTENDED PRINTING RESOLUTION

300 x 600  
300 x 1200  
DPI

**Print now in higher resolution**

**For sharper texts and detailed images**

- Adjustable resolution via the printer driver (from 6. and 1526 firmware Version)
  - Print double or triple pixels down the length of the card
    - 300x600 DPI available for color and monochrome printing
    - 300x1200 DPI available for monochrome printing only
- 
- Available as standard starting from Q3 2015
  - Compatible with the whole Primacy installed base
  - Install the latest printer driver (available from 6.18.0.688 EPS version) and firmware (available from 1526 firmware version) to benefit from this feature

# UPDATE VERIFICATION WIZARD



**Always be up to date!**

**Benefit from the latest enhancements for your printer**


- Easily launch download & installation right thanks to the wizard
  - Not intrusive, you decide:
    - When to check for updates
    - When you install the downloaded files
  - Wizard integrated to the Evolis Premium Suite®
  - Wizard checks for available driver and firmware updates
- Delivered as standard with your printer starting from Q3 2015
- Compatible with Primacy installed base
  - Install the latest printer driver (available from 6.18.0.688 EPS version) to benefit from this feature

# DRIVER/PRINT CENTER/PRINTER MANAGER

## Minimal mode

To access: From any print setup

Printer sharing possible




## Native Driver

Transfer the graphic data into  
Evolis data  
Synchronized with the print  
center

## Supervision mode

To access: Desktop icon or right/left  
click on the Evolis icon from the  
Windows taskbar

Printer sharing not possible  
Can be disabled



## Print center

Printer detection  
Notification server  
Graphic interface of the driver  
Access to Evolis tools




## Standard mode (default)

Printer sharing not possible  
Can be disabled



## Printer manager

Graphic interface service for  
notification popup

-  Job cancelling
-  Help menu
-  Job resuming


# WINDOWS/MAC/LINUX DRIVER

## Driver installation

- Before starting a driver installation, log the computer with the Administrator rights (Windows) / Root rights (Linux)


## Windows (available on CD-ROM or Evolis web site)

- Run the driver Setup **before** connecting the USB cable
- To manage the printer driver:
  - Check user's rights (power user)
  - Check user's permissions from driver properties/Security




## Mac and Linux driver available on Evolis web site

- Connect the USB cable **before** starting the installation
  - All the latest driver release are downloadable on the Evolis web site
  - Elypso, Zenius and Primacy driver update may require the firmware update



# TEST CARD (ZENIUS, PRIMACY, ELYPSO)

Printer model	Model of printer
Code:	Printer Zone
Printer S/N :	Serial number
Firmware Version :	Firmware version
Print Head Kit n° :	Print head kit number ( N° : Number of replacement)
X-Y-Smart Offsets :	X offset value - Y offset value - Smart offset value
Printed Lines L/W :	Vertical printed lines/Horizontal printed lines
Inserted Cards :	Number of inserted cards with the current print head <b>G</b> : Global number of inserted cards
Cleaning Cycles H : <i>With the current print head</i>	Number of cleaning cycles / Maximum number of inserted cards between 2 cleaning cycles
Cleaning Cycles G : <i>Total counter</i>	Number of cleaning cycles / Maximum number of inserted cards between 2 cleaning cycles
Mac address	Printer Mac address
IP address	Printer IP address



# REGULAR CLEANING CYCLE (ZENIUS, PRIMACY, ELYPSO)

## How to perform a regular cleaning cycle

- Remove ribbon from printer (a cover opening must be detected)
- Remove the card(s) from the feeder and set the gauge to the maximum

### To run a cleaning cycle:

1) Use control panel button (press twice quickly)

Or

2) In the **Print center/Properties/Cleaning/Proceed with cleaning**, click on the « **Start Cleaning button**» button (for regular cleaning)

- **On Zenius/Elypso:** When card/ribbon light is flashing, insert the cleaning card inside the manual feeder (sticky side up)
- **On Primacy:** When card/ribbon light is flashing, insert the cleaning card inside the feeder (sticky side up)
  - *Clean also print head ceramic*



# ADVANCED CLEANING CYCLE (ZENIUS, PRIMACY, ELYPSO)

## How to perform an advanced cleaning cycle

- Remove ribbon from printer (a cover opening must be detected)
- Remove the card(s) from the feeder and set the gauge to the maximum

### To run a cleaning cycle:

1) Use control panel button (press twice quickly)

Or

2) In the **Print center/Properties/Cleaning/Proceed with cleaning**, click on the « **Start Cleaning button** » button (for advanced cleaning)

- When card/ribbon light is flashing, insert the T cleaning card inside the card feeder and wait its ejection
- **On Zenius/Elypso:** When card/ribbon light is flashing, insert the adhesive cleaning card inside the manual feeder (sticky side up)
- **On Primacy:** When card/ribbon light is flashing, insert the adhesive cleaning card inside the feeder (sticky side up)

– *Clean also print head ceramic*



# MANUAL CLEANING

This procedure can be used to:

- Prevent feeding/printing/mag encoding issue
- Clean a dirty printer
- Clean the printer after an intervention (spare parts replacement)
  - *The manual cleaning is advised after a standard cleaning cycle*




How to perform a manual cleaning cycle

- Open the cover (keep it opened), remove the ribbon
- Keep pressing on the control panel button and clean manually the running rollers with a pre-saturated cleaning
- Use several cleaning cards if necessary
  - *Clean also the cleaning roller and the print head*



# RIBBON'S SPECIFICATION YMCKO





- Printing process with color ribbon always starts with the yellow panel
- The « Color sensor » detects the Black panel and according to ribbon's type calculates the position of the yellow panel.
- In case of Power ON / Door Open, the system will automatically jump to the next yellow panel to not print with panels ready used.



- Number of prints done per ribbon is for a non stop number of print sides.

# RIBBONS SPECIFICATION (ZENIUS, PRIMACY, ELYPSO)

Monochrome ribbon saving system ([downloadable on Evolis Website](#))



100% layout = 894 cards/roll\*

88% layout = 1,000 cards/roll\*

50% layout = 1,625 cards/roll\*

25% layout = 2,748 cards/roll\*

# RIBBON IDENTIFICATION (ZENIUS, PRIMACY, ELYPSO)


All Evolis Zenius “High Trust” ribbons get an identification & setting system

- This feature is used to detect the zone, type and the remaining %

*(Evolis premium Suite in standard mode only)*

If a non genuine ribbon is detected by the printer:

- A notification pop-up will be displayed by the printer manager (every 10 cards)
- Evolis will not guarantee printing quality and correct color synchronization



R.F ID CHIP

# SENSOR ADJUSTMENT LIST (ZENIUS)



NAME	ADJUSTMENT COMMAND	REQUIREMENT
Rotation	Sa;r	Use any ribbon
Color	Sa;c	Use a color ribbon
Cover	Sa;o	Keep the cover opened before sending command
Card synchronization	Sa;p	Put a card(s) into feeder before sending command
Card feeder	Sa;f	Remove card(s) from feeder before sending command
Up&down	Sa;d	X
Feeder position	Sa;e	X
Manual feeder	Sa;M	x
Contact station position	Sa;H	Contact station presence
Magnetic head position	Sa;h	Magnetic option presence
All	Sa	See procedure

# SENSOR ADJUSTMENT LIST (PRIMACY)



NAME	ADJUSTMENT COMMAND	REQUIREMENT
Rotation	Sa;r	Use any ribbon
Color	Sa;c	Use a color ribbon
Cover	Sa;o	Keep the cover opened before sending command
Card synchronization	Sa;p	Put a card into feeder before sending command
Card feeder	Sa;f	Put a card into feeder before sending command
Up&down	Sa;d	X
Full hopper	Sa;A	Remove card(s) from hopper before sending command
Flip-over	Sa;flip	x
Contact station position	Sa;H	Contact station presence
Magnetic head position	Sa;h	Magnetic option presence
Low-card Sensor	Sa;n	Remove all card(s) from hopper before sending command

# SPARE PART REPLACEMENT (PRINT HEAD)

After the replacement, follow these instructions to set the new print head:

***Use the wizard in The Print Center Interface or ...***


- Print head kit number (You can find it on the sticker)

**Pkn;print\_head\_kit\_number**

*– After sending a new Pkn, a cleaning cycle is requested by the printer.*

- Adjust the offset settings if necessary (not for Tattoo)
- Clean all the rollers with the manual procedure

*– Remember to print the Stt card before its replacement*



# HOW TO INSTALL THE PRINT HEAD KIT NO.

430 is the Resistance No



***How to Perform the command***

***To read the Print Head Sl. No.***

- ***Rkn***

***To Put New Print Head Kit No.***

- ***Pkn;430-E7Y0084***






# OFFSET ADJUSTMENT (ZENIUS, PRIMACY, QUANTUM, SECURION, ELYPSO)

**Prior to start Offset adjustment:**  
**1. Print a technical test card and a full background design before starting the offset adjustment.**

Parameters	Reading command	Setting command
X position	Rx	Px;=;...
Y Position	Ry	Py;=;...
Pnl Number of vertical line	Rnl	Pnl;=;...
Pnw Number of horizontal line	Rnw	Pnw;...
Sequence copy	X	Sc;...



## ADVICES:



- Adjust the X before the Pnl value.
- Do not set the Pnl value to the maximum (1016) but find the correct one.
- A too high or low image position can create wrinkle(s) on the edge(s).
- A low X value may cut the ribbon or eject blank card.
- Values are in dots (12 dots = ~ 1mm).



# CARDPRESSO

- Compatible with XP (SP3), Vista, 7, 8, 10 – Mac OS 10.6 to 10.11
- Compatible with **all** Evolis printers (editions bundled with printer)
- License activation made by USB key / upgrade made with license key
- Technical notes and videos available on Cardpresso web site

more than an application

Zenius	
Primacy	



Start by **XXS Lite** with the basic features for card design and printing using predefined templates, signature acquisition, internal database up to 50 records, barcodes 1D, WIA/TWAIN and DirectShow acquisition as well as magnetic encoding.

**XXS** adds an internal database with unlimited records.

**XS** adds QR codes, .XLS, .XLSX, .CSV and .TXT database connection, database view and link image to DB field.

**XM** adds local MS access connection, photo on database, FaceCrop tool for face recognition and 2D barcodes.

**XL** adds ODBC connection, RFID contactless direct encoding and smartcard plugin, multi-layout card designs, conditional printing, operation logs and much more!

**XXL** adds advanced features like DESFire, Web Print Server and Net License up to 16 PCs.

# evolIS


MUCH MORE THAN CARD PRINTERS



Signature pads



Software



Card printers



Accessories



Services