

Modem (NAMR-C108SR)

User Manual

Author: NURI, Telecom

Customer: Africa

Document Title:	Modem (NAMR-C108SR) User Manual	Date:	2018-11-07
File Name:	Modem (NAMR-C108SR)_User_Manual	Status:	
Version:	1.0	Page:	1 of 12
Owner:	NURI Telecom	Document ID:	

Document Information

This document is published in Korea. And this chapter contains specific information of revised, approved, and distributed history.

Revision History

Ver.	Date	Name	Overview of changes
1.0	Sep. 06, 2018	NURI Telecom	- First Draft

Document Title:	Modem (NAMR-C108SR) User Manual	Date:	2018-11-07
File Name:	Modem (NAMR-C108SR)_User_Manual	Status:	
Version:	1.0	Page:	2 of 12
Owner:	NURI Telecom	Document ID:	

Preface

> Registered Trademark

NURI, AiMiR is a registered trademark of NURI Telecom, Co. Ltd. All third party trademarks mentioned in this document may be trademarks of their respective owners.

> Proprietary Notice

The information contained in this documentation is subject to change without notice.

NURI Telecom reserves the right to make changes in content without obligation on the part of NURI Telecom to provide notification of such changes.

NURI Telecom may make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time.

NURI Telecom expressly disclaims all responsibility and liability for any damage or loss arising out of other use than as specified in this documentation.

The product(s) is owned by NURI Telecom and is protected by patent and copyright laws.

No part of the product (including but not limited to idea(s) for the product, the manual, etc.) may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from NURI Telecom.

> About This Guide

This guide provides detailed information about how to change and install modems.

> Customer Support

Address: NURI Telecom Co.,Ltd, NURI Bld, 750-14, Bangbae-dong, Seocho-gu, Seoul, Korea, 137-060

Tel: +82-2-781-0741

Fax: +82-2-781-0704

E-mail: poweramr@nuritelecom.com

Website: <http://www.nuritelecom.com>

Document Revision R 1.0 EN (Sep. 06, 2018)

Copyright © 2010-2017 NURI Telecom Co., Ltd. All rights reserved.

Document Title:	Modem (NAMR-C108SR) User Manual	Date:	2018-11-07
File Name:	Modem (NAMR-C108SR)_User_Manual	Status:	
Version:	1.0	Page:	3 of 12
Owner:	NURI Telecom	Document ID:	

Safety Information

The following symbols are used to draw your attention to the relevant danger level.



WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



NOTE

Used to address important tips, guidance, or advice.

Safety Regulations

Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents.



WARNING

The following safety regulations must be read and understood for the work to be performed.

- When installing the product, please use the provided or designated connection cables/power cables/adaptors. Using any other cables/adapters could cause a malfunction or a fire.
- Wear protective equipment such as gloves, boots, etc. to prevent electric shock.
- Read this manual carefully before beginning installation.
- Replace the battery only with the same or equivalent type recommended by the manufacturer.
- Do not use this product near water; for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a web basement, or near a swimming pool.

Document Title:	Modem (NAMR-C108SR) User Manual	Date:	2018-11-07
File Name:	Modem (NAMR-C108SR)_User_Manual	Status:	
Version:	1.0	Page:	4 of 12
Owner:	NURI Telecom	Document ID:	

- Never install equipment in wet locations.
- Avoid using equipment during an electrical storm. There may be a risk of electric shock from lightning.
- Installation of the equipment must comply with local and national electrical codes.
- Only trained and qualified personnel should be allowed to install, replace, or service the equipment.

Ultimate disposal of this product should be handled according to all national laws and regulations.

Document Title:	Modem (NAMR-C108SR) User Manual	Date:	2018-11-07
File Name:	Modem (NAMR-C108SR)_User_Manual	Status:	
Version:	1.0	Page:	5 of 12
Owner:	NURI Telecom	Document ID:	

Table of Contents

DOCUMENT INFORMATION II

 Revision History ii

PREFACE III

SAFETY INFORMATION.....IV

 Safety Regulations iv

TABLE OF CONTENTS 6

1 INTRODUCTION..... 7

 1.1 Purpose of this document 7

 1.2 Intended audience 7

 1.3 Acronyms and abbreviations 7

2 DESCRIPTION OF NAMR-P116GP 8

 2.1 Main Features 8

 2.2 Specifications 8

 2.3 Appearance 9

3 CONFIGURATION..... 10

 3.1 Connecting the Modem using a RS-232 cable 10

Document Title:	Modem (NAMR-C108SR) Change and Installation Guide	Date:	2018-11-07
File Name:	Modem (NAMR-C108SR)_User_Manual	Status:	
Version:	1.0	Page:	6 of 12
Owner:	NURI Telecom	Document ID:	

1 Introduction

1.1 Purpose of this document

The purpose of this document is to provide detailed information of NAMR-C108SR modem such as H/W specifications, etc.

1.2 Intended audience

The intended audience is the technical engineers who will install and maintain the equipment.


1.3 Acronyms and abbreviations

Acronyms/Abbreviations	Description
AMI	Advanced Metering Infrastructure
CLI	Command Line Interface
DHCP	Dynamic Host Configuration Protocol
HES	Head-End System
IP	Internet Protocol
LAN	Local Area Network
LED	Light-Emitting Diode
RX	Receive
SNMP	Simple Network Management Protocol
SPI	Serial Peripheral Interface
TX	Transmit
UART	Universal Asynchronous Receiver/Transmitter
USB	Universal Serial Bus

Document Title:	Modem (NAMR-C108SR) User Manual	Date:	2018-11-07
File Name:	Modem (NAMR-C108SR)_User_Manual	Status:	
Version:	1.0	Page:	7 of 12
Owner:	NURI Telecom	Document ID:	

2 Description of NAMR-C108SR

This device uses GPRS to collect and store various data of the smart meter and transfer the data to the DCU.



Name	Modem
Model	NAMR-C108SR
Vendor	NURI Telecom
Origin	South Korea

2.1 Main Features

The equipment provides following features:

- Supports communication security when transmitting/receiving PLC network data
- Based on open, standards-based design
- Provides secure, real-time, advanced metering and smart grid information
- Sends power outage/restoration notification
- Supports wide range of smart meters from leading meter manufacturers

2.2 Specifications


The specifications of equipment are as follows:

Item	Description
Processor	Cortex-M3, EFM32GG230F1024
Memory	CPU Internal Flash 1024KB
External Memory	Serial Flash 8MB
Interface	UART : Metering & Console
Frequency Range	G3-FCC band (154~487KHz)
Operating Temperature / Humidity	-40℃ ~ +70℃ / 10% ~ 95%

Document Title:	Modem (NAMR-C108SR) User Manual	Date:	2018-11-07
File Name:	Modem (NAMR-C108SR)_User_Manual	Status:	
Version:	1.0	Page:	8 of 12
Owner:	NURI Telecom	Document ID:	

storage Temperature / Storage Humidity	-40 °C ~ +85 °C / 10% ~ 95%
Power Consumption @ DC + 12V	2.4 W
RoHS	Comply
Size (mm)	41.85 (L) X 91 (W) X 24 (D)
DC Mains Input	DC +12V

2.3 Appearance



No.	Description
1	Power & Meter Interface PIN Header
2	Status LED
3	PLC Interface Cable
4	Debug port - For checking the modem or firmware update
5	CLI port
6	Bluetooth Module

Document Title:	Modem (NAMR-C108SR) User Manual	Date:	2018-11-07
File Name:	Modem (NAMR-C108SR)_User_Manual	Status:	
Version:	1.0	Page:	9 of 12
Owner:	NURI Telecom	Document ID:	

3 Configuration

Generally, you can manage DCUs in the AiMiR Software. However, if you are not able to connect to the AiMiR server, you need to connect to the modem directly and use CLI (Command Line Interface) commands.

Using the CLI commands, you can see and set various information.



WARNING


- Before installation, please wear the protective equipment to prevent electric shock.
- Installation must be performed by qualified engineers.

3.1 Connecting the Modem using a RS-232 cable

To use the CLI commands, you should connect the modem using a RS-232 cable to your computer.

1. Connect the USB RS-232 cable to the console port at the bottom of the modem.
2. Connect the other side of the USB RS-232 cable to your computer.
3. Check the port information on the Device Manage of Windows.

- [Windows Start] - [Control Panel] - [System] - [Device Manager] -[Ports]




4. Execute a serial terminal program

- You can download the terminal program on the internet.

5. Select the 'Serial' category and enter the serial line information as follows:

Document Title:	Modem (NAMR-C108SR) User Manual	Date:	2018-11-07
File Name:	Modem (NAMR-C108SR)_User_Manual	Status:	
Version:	1.0	Page:	10 of 12
Owner:	NURI Telecom	Document ID:	



- Serial line to connect to: COM# from the step 2.
- Speed (baud): 115200
- Data bits: 8
- Stop bits: 1
- Parity: None
- Flow control: None

6. Click the [Open] button to start the program.

Document Title:	Modem (NAMR-C108SR) User Manual	Date:	2018-11-07
File Name:	Modem (NAMR-C108SR)_User_Manual	Status:	
Version:	1.0	Page:	11 of 12
Owner:	NURI Telecom	Document ID:	

4 Notice

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment should be installed and operated with minimum distance 20 cm (7.8 inches) between the antenna and your body. Users must follow the specific operating instructions for satisfying RF exposure compliance.

Document Title:	Modem (NAMR-C108SR) User Manual	Date:	2018-11-07
File Name:	Modem (NAMR-C108SR)_User_Manual	Status:	
Version:	1.0	Page:	12 of 12
Owner:	NURI Telecom	Document ID:	