




Walkthrough

Simulate Product



Order and Service



Hearing Aid Order

Access to eStore. Utilizes client audiogram and other pertinent information, if available.




Earmold Order

Access to eStore. Utilizes client audiogram and other pertinent information, if available.



Highlights

- 1. Hearing Aid Order: Access eStore to order new hearing aids
- 2. Earmold Order: Access eStore to order earmolds
- 3. Service Request: Initiate repairs, returns and color exchange
- 4. eStore: Requires StarkeyPro Login





Introducing eStore, our new online ordering system

With the eStore, you have easy and fast access to order patient-specific hearing aids, bulk hearing aids for stock, accessories, common supplies and more. In a few simple steps, your order is placed online and sent directly to us.


DON'T HAVE A LOGIN?

Don't worry — you don't have to miss out on the improved online shopping experience! Simply give us a call to set-up your access today!

800-328-8602


and ask for the ProSite team

Hearing Loss Simulator



- 1. Select to show: Patient Audiogram, Normal or Preset Configurations
- 2. Overlays: Common Sounds, Speech Sounds, Speech Spectrum, Articulation Index
- 3. Click on the common sound graphic to play audio file
- 4. Drawing Tools

Get Started (Connect Devices)



- 1. Programmer connected: Automatically chooses programmer
- 2. View programmers: Multiple programmers can be connected at the same time, all will be visible
- 3. Hearing devices: Check box to connect desired hearing devices
- 4. Connection choice: Read Device Settings or Load Previous Session
- 5. Start: Click when ready to connect

Launching Remote Programming

| င်္သာ Last refr | () (? | | | | Starkey Hearing Technologies | Edit List Pre-Fitting | Remote Programming | 🛆 Amy Attorney |
|--------------------|---------------------------------|-----------|----------|----------------|---------------------------------|-----------------------------|---------------------------|-----------------------------|
| | New | Completed | | | | Get Started Connect Devices | | |
| Brar | d Name | | Received | Professional | | Remote Programming | | |
| Solution | Jim Anderson Too Loud | | 2:24 PM | Cassie Billiet | Ŵ | Fitting | Too Loud | Cassie Billiet |
| | | | | | | | Request details: Too Loud | |
| | | | | | | | When: All Voices | |
| | | | | | | | Severity: Annoying | |
| | | | | | | | Ear side: Both | |
| | | | | | | | Memory: Normal | |
| | | | | | | | Message: | |
| | | | | | | | | Open Hearing Care Dashboard |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | Start Fitting | | | Load Cloud Session |


Highlights

NEW! Launch a remote programming session by selecting **Start Fitting** from the **Hearing Care Dashboard**. Inspire will open automatically.

Remote programming can also be launched by:

- Selecting the desired help request in the Hearing Care Dashboard
- Selecting the patient in the database and opening Inspire
- Selecting Remote Programming under Get Started
- Selecting Load Cloud Session

Acoustic Options



Highlights

NEW! Livio AI and Livio 312 RICs support our Smart Snap Fit receivers including the new **107/40 Matrix**. Receiver matrix is backwards compatible with all Snap Fit receiver products.

Auto Path

| Acoustic Options | | Initial Fit | | |
|---|---------------------------------|---|------------------|---|
| Livio AI 2400 • 🜒 Right Binaural Left 🕪 • Livio AI 2400 | | Livio AI 2400 • 🤘 | Right Binaural | Left 🕖 • Livio AI 2400 |
| | | Receiver: Stock Matrix: 115/50 Earpiece: Earbud | | Receiver: Stock Matrix: 115/50 Earpiece: Earbud |
| Receiver Type Stock * Receiver Type | e | Earbud: Open | | Earbud: Open |
| Receiver Matrix 107/40 * • Receiver Mat | trix | (i) Auto Path establishe | s recommended ir | nitial fit settings for the devices. |
| Earpiece Earbud * • Earbud * • Earpiece | | Settings | Results | |
| Earbud Type Open * • Earbud Type | | Initial Fit | Complete Su | ıccessful |
| Initial Fit | | ✓ Feedback Canceller | | 1 |
| 2 Livio AI 2400 • • Right Binaural Left • Livio AI 2400 | 4 Aut | o Path routine is finished! | | |
| Experience with Amplification | | esults | | |
| O Minimal to no experience with amplification | | omplete Successful omplete Gain Margin Measured | | 3 |
| Experience with Starkey | 💙 Reset Data Log C | omplete Reset 7/5/2018 | | Begin Close |
| C Experience with Other manufacturer - | | | | |
| O Prefers Power fit | | | | |
| Next | Go To Integrated Speech Mapping | Close | Restart | |


- 1. Device information: Receiver matrix will read automatically with Smart Snap Fit receivers
- 2. Choose Experience with Amplification
- 3. Start Auto Path: Begin
- 4. Auto Path Results

User Controls

| User Contro | ol Settings | | | | | Print |
|---------------|--------------------------|------------------|---|--|--|-------|
| | Drag | <u> </u> | | Drop | | |
| | Hearing Aid Volume | Memory | | Short Press Memory | Short Press Memory | 5 |
| | Tinnitus Level | Mute | | Ear to Ear -> | ← Ear to Ear 🗸 | |
| | Accessory Start/Stop | Accessory Volume | | Push & Hold Disabled | Push & Hold Disabled | 4 |
| | | | | Ear to Ear | Ear to Ear | |
| | | 2 | 3 | Double Tap Disabled | Double Tap Disabled | |
| | | | | Ear to Ear | Ear to Ear | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| + VC Range a | nd Step Size | | | | | |
| + Tinnitus Ou | tput Range and Step Size | | | | | |
| Additional | Configuration Options | | | | | |

- 1. Updated labels: HA Volume and Tinnitus Level
- 2. NEW! user control options including: Accessory Start/Stop and Accessory Volume
- 3. NEW! Double Tap user control configuration for Livio AI: Accessory Start/Stop
- 4. Push & Hold: HA Volume, Memory, Tinnitus Level, Mute, Accessory Start/Stop or Accessory Volume
- 5. Short Press: Memory, HA Volume, Tinnitus Level or Accessory Volume
- 6. Information icon


User Controls: VC Range and Step Size



Highlights

1. Extended volume control attenuation range

User Controls: Tinnitus Output Range and Step Size



Highlights

1. Extended tinnitus output range

User Control Settings: Additional Configuration Options

| Additional Configuration Options | |
|----------------------------------|-----|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| Reset Levels on Memory Change | (i) |
| | |
| | |
| | |
| | |

- 1. Reset Levels on Memory Change: Reset hearing device volume and tinnitus to preset levels when a memory change occurs
- 2. Default is ON

QuickFit




- 1. Selectable memory options below response window
- 2. Same global gain adjustments as in previous Inspire versions
- 3. Shortcut button to Fine Tuning screen
- 4. Best Fit window with clear descriptions

Fine Tuning – Table View

| + Low | | + Mid | | + Higl | ı | + Ultra | 1 | + Expand A | + Low | | + Mid | | + High | ı | + Ultra | à |
|--------|----------|---------|---------|-----------|-----------|-----------|-----------|------------|---------|----------|---------|---------|-----------|-----------|-----------|-----------|
| 50-500 | 750-1.1K | 1.4к-2к | 2.3K-3K | 3.3к-3.9к | 4.2K-5.2K | 5.6K-6.9K | 7.5к-9.4к | ALL | 150-500 | 750-1.1K | 1.4к-2к | 2.3K-3K | 3.3к-3.9к | 4.2K-5.2K | 5.6K-6.9K | 7.5K-9.4K |
| 6 | 0 | 6 | 14 | 8 | 2 | -1 | -1 | ∽ Loud | 6 | 0 | 6 | 14 | 8 | 2 | -1 | -1 |
| 11 | 0 | 6 | 14 | 8 | 2 | -1 | -1 | ✓ Moderate | 11 | 0 | 6 | 14 | 8 | 2 | -1 | -1 |
| 11 | 0 | 6 | 14 | 11 | 3 | -1 | -1 | 🖰 Soft | 11 | 0 | 6 | 14 | 11 | 3 | -1 | -1 |
| 90 | 98 | 114 | 121 | 121 | 114 | 105 | 99 | MPO | 90 | 98 | 114 | 121 | 121 | 114 | 105 | 99 |

- 1. Collapse/expand left navigation bar
- 2. Two adjustment types: Tables or Sliders
- 3. Two screen options: QuickFit or Fine Tuning
- 4. Expand All: Expands all frequency regions to show every channel
- 5. Two numeric values: MPO or CR

Memories



3

Highlights

- 1. Blue designates selected memory
- 2. **NEW!** View and adjust user's **custom memories**. Link must be established between user and hearing healthcare professional
- 3. Click arrow for Memories Menu

NEW Adjust Custom Memories

Memories: Configure Phone Options


| 4 | M | usic 🔻 | ٢ | Stream Boost |
|-------|---|-------------|-------|-------------------------|
| | | Normal | | |
| | | Meeting | | |
| | | Crowd | | |
| ories | | Restaurant | | |
| | | Car | Phone | e (Monaural) |
| | | Auditorium | Rig | ht Only |
| | 0 | Music | Let | t Only |
| | | Television | Eit | her Left or Right |
| | | Outdoors | Phone | e (Ear to Ear) |
| | | Mute | Rig | ht Sends Signal to Left |
| 1 | | Telephone • | Lei | t Sends Signal to Right |
| | | Autophone 🕨 | | |
| | | Disabled | | |

| 2 | 3 Autophone (Send Sig Receive Signal | • |
|---|---|---|
| | | |
| | Memory 3 | |
| | Receive Signal | _ |
| | Mic Off | • |
| | Mic Off | |
| | Mic On: 0 dB | |
| | Mic On: -3 dB | |
| | Mic On: -6 dB | |
| | Mic On: -9 dB | |

| 3 | 3 Autocoil (Send Signal) Receive Signal | • | | | | | | | | |
|---|--|---|--|--|--|--|--|--|--|--|
| | | | | | | | | | | |
| | Memory 3 | | | | | | | | | |
| | Autocoil (Send Signal) | | | | | | | | | |
| | Mic Off | • | | | | | | | | |
| | Receive Signal | | | | | | | | | |
| | Mic Off | • | | | | | | | | |

- 1. Select Telephone or Autophone and monaural or Ear to Ear option via memory fly out
- 2. Customize Mic Attenuation on receive side for Telephone/Autophone options
- 3. Customize Mic Attenuation on send and receive side for Telecoil/Autocoil options (BTE Only)


Memories: Additional Configuration Options



Highlights

1. **NEW! Include Custom Memory in Rotation:** provides ability to take custom memory out of rotation. Default is checked.

Music Memory






- 1. Two Equalizer adjustments: Loud Music and Soft Music
- 2. Three frequency regions: Bass, Mid and Treble
- 3. Two screen options: QuickFit or Fine Tuning
- 4. QuickFit Controls

Experience Manager




- 1. Enable Auto Experience Manager: Default is OFF
- 2. Binaural syncing status: Days remaining and sync with right or left if wear time is different between devices
- 3. Status indicators: Icon and Curves

Feedback Canceller



- 1. Gain Margins: Gain available before feedback potential
- 2. Initialization status message: Shows initialization status
- 3. Feedback sensitivity: Adaptive High Sensitivity, Adaptive Low Sensitivity or Off


Frequency Lowering



- 1. Green: Source Region
- 2. Yellow: Target Region
- 3. Frequency Lowering Bandwidth Control


- 4. Frequency Lowering Gain Control
- 5. Frequency Lowering and Binaural Sound Enhancement are mutually exclusive. Frequency Lowering will default ON if audiometric criteria are met.


Sound Manager




- 1. NEW! Sound Enhancement controls: Speech in Loud Noise, Speech in Noise and Quiet
- 2. Situational Sound Management controls: Wind, Machine, Auto Music
- 3. Directionality controls
- 4. Access adjustments through details hyperlink
- 5. Adjustment in each memory independently
- 6. Ear-to-Ear controls

Sound Manager: Details






- 1. Sound Enhancement adjustments include: Speech in Loud Noise, Speech in Noise and Quiet
- 2. Situational Sound Management adjustments include: Wind, Machine and Auto Music
- Directionality adjustments include: Adaptive, Dynamic, Directional, Omnidirectional, Immersion Directionality and Directionality Plus
- 4. Demonstrate Sound Enhancement and Situational Sound Management features using Go Live button




Tinnitus




- 1. Indicates tinnitus is active in the selected memory. Click to go to the tinnitus screen
- 2. Adjust tinnitus stimulus on band by band basis
- 3. Enable Tinnitus Stimulus: Disabled by default

- 4. Modulation: Off, Slow, Medium or Fast (disabled by default)
- 5. Additional adjustments: SoundPoint Tinnitus, Target Match Tinnitus and Copy Tinnitus

Accessories






Highlights

NEW! Starkey Hearing Technologies Accessories: TV Streamer, Remote Microphone + and Remote

- 1. Pair within Inspire. Selecting the Pair button puts the hearing devices into pairing mode
- 2. Information icon provides pairing instructions
- 3. View paired accessories: Accessory image will be visible
- 4. Delete accessory pairing

NEW SHT Accessories

Accessories



- 1. Set microphone configuration while streaming: Mic On, Mic Reduced (50% gain) or Mic Off
- 2. Set Favorite Button configuration for Remote: now including Accessory Start/Stop

Indicators

| | | Livio AI 2400 • 🜒 Right Binaural Left 🕟 • Livio AI 2400 | | | | | | |
|---------------------------------|-------------------------------|---|------------------------------------|-------------------------------|---------------------|------------------|------------------------|------|
| Adjustments | | All Indicators | | | | | | |
| Adjust All Indicators | | Tone | = + Reset | | | | | |
| All Indicators | > | Speech | = + Reset | | | | | |
| Adjust Individual Indicators | Enabled | | | | | | | |
| Low Battery | \checkmark \checkmark $>$ | Indicator Language | English - Male 🔻 | | | | | |
| Power-On Sound | \checkmark | Enable automatic indicator level change | \checkmark | | | | | |
| Memory / Home | | | | | | | | |
| Telephone Hearing Aid Volume | | | | | | | | |
| Tinnitus Level | | | | | Livio AI 2400 🔹 🕢 | Right Binaural L | .eft 🕪 🔹 Livio AI 2400 | |
| Accessory Stream | \checkmark \checkmark $>$ | | A divistra anta | | Accessory Stream | | | |
| Mute | \checkmark | | Adjustments | | Accessory stream | | | |
| Comfort Boost | \checkmark \checkmark $>$ | | Adjust All Indicators | | Tone = | + - R | eset | |
| T2 Wake | $ \rightarrow $ | | All Indicators | > | Const | | 3 | |
| | | | Adjust Individual Indicator | Enabled | Speech | + - Reset | | |
| | | | Low Battery | \checkmark \checkmark $>$ | E | nabled | Stimulus | Demo |
| | | | Power-On Sound | \checkmark \checkmark $>$ | Start Stream | | Warble Tone 🔹 | |
| | | | Memory / Home | \checkmark \checkmark $>$ | | | | |
| | | | Telephone | | Accessory Volume Er | nabled | Stimulus | Demo |
| | | | Hearing Aid Volume | | | • • | | |
| | | | Tinnitus Level Accessory Stream | | Max | | 1500 Hz 🔹 | |
| | | | Mute | | Steps | | 1500 Hz 🔹 | |
| | | | Comfort Boost | | | | | |
| | | | T2 Wake | \rightarrow | Min | | 1500 Hz 🔹 | |
| | | | | | | | | |

Highlights

NEW! Indicators now automatically enabled at best fit

- 1. Adjust all indicators: Tone, Speech and choose indicator language
- 2. NEW! Accessory Stream Indicators: Start Stream and Accessory Volume
- 3. Adjust individual indicators: Level, Stimulus and Demo

Fitting Summary

| | | 1 | 2 | 3 | 4 | ۵) |
|---------|------------------------------------|---------------------------|--|----------------|--|---------------------------------------|
| details | s Memory | *Normal, e-STAT | Restaurant | Music | Autophone (Send Signal) Receive Signal | Stream Boost |
| details | s Frequency Lowering | Disabled | Disabled | Disabled | Disabled | Disabled |
| | Directionality | Adaptive | Adaptive | Omni | Omni | Omni |
| | s Immersion Directionality | \checkmark | \checkmark | \checkmark | N/A | Disabled |
| | Directionality Plus | Disabled | Disabled | N/A | N/A | N/A |
| | Speech in Loud Noise | N/A | Off | N/A | N/A | N/A |
| | s Speech in Noise | 3 | 3 | N/A | 3 | Off |
| · | Quiet | 3 | 3 | 3 | 3 | 3 |
| | Wind | 3 | 3 | Off | 3 | Off |
| | s Machine | 3 | 3 | Off | 3 | Off |
| | Auto Music | 3 | Off | N/A | Off | 3 |
| details | etails Tinnitus Off | | Disabled | Disabled | N/A | N/A |
| details | s Indicators | Sta | atus | | details User Controls | |
| | | | eedback Canceller 🔹 🕨 Suc | cessful | Gesture Rig | ht Left |
| | Low Battery Power-On Sound | | xperience Level > 3 emote Programming > Dis | abled | Short Press Men E to E | · · · · · · · · · · · · · · · · · · · |
| | Memory / Home Telephone | \checkmark \checkmark | 5 5 | abled 2 | Push & Hold Tinnitu: E to E | |
| | Hearing Aid Volume | ✓ ✓ P | ower-On Delay Sh | ort 🔻 | Double Tap | |
| | Tinnitus Level Accessory Stream | | | | details Accessories | |
| | Mute Comfort Boost | | | | No Accesso | ories Paired |
| Displa | lay Multicurve Graph | | | Reset Data Log | Fitting Comments | Print Save |

Highlights

- 1. Select details to hyperlink to fitting screens
- 2. **NEW!** Status box includes the ability to enable **Remote Programming**. Default is disabled.

NEW Enable Remote Programming


Enabling Remote Programming

| details Indicators | | | Status | | | | details | User Contro | ols | |
|--------------------------|--------------|--------------|--------------------|---|------------|----------------|---------|--------------|----------------|------------|
| | • | • | Feedback Canceller | • | Successful | | | Gesture | Right | Left |
| Low Battery | \checkmark | \checkmark | Experience Level | • | 3 | | | Short Press | Memory | Memory |
| Power-On Sound | \checkmark | \checkmark | Remote Programming | • | Disabled | | | 511011111255 | E to E 🗸 | E to E 🗸 |
| Memory / Home | \checkmark | \checkmark | | - | | | | Push & Hold | Tinnitus Level | |
| Telephone | \checkmark | \checkmark | T2 On Demand | | Disabled | | | | E to E 🗸 | E to E |
| Hearing Aid Volume | \checkmark | \checkmark | Power-On Delay | | Short ▼ | | | Double Tap | E to E | E to E |
| Tinnitus Level | \checkmark | \checkmark | | | | | | | 2102 | 2102 |
| Accessory Stream | \checkmark | \checkmark | | | | | details | Accessories | ; | |
| Mute | \checkmark | \checkmark | | | | | | | | |
| Comfort Boost | \checkmark | \checkmark | | | | | | No Ac | cessories l | Paired |
| Display Multicurve Graph | | | | | | Reset Data Log | Fitti | ng Comments | Print | Save |

Highlights


- 1. **NEW! Remote Programming** can be enabled in the status box on the fitting summary screen. Click to open remote programming window.
- 2. Check box to enable remote programming. Review the consent with the patient and choose accept. After remote programming has been enabled, click to generate the code. You must be logged into the Dashboard to generate a code.
- 3. You can also generate a code by going to the Tools menu, Generate Remote Programming Code. Enter the code into the Thrive Hearing Control app to establish a link between the patient and professional via cloud services.

*Professional is in control of enabling remote programming. Default is disabled.





Data Log



- 1. Data Log: Summary view
- 2. NEW! Ability to disable data log on the data log screen. Default is ON.
 - This feature is backwards compatible with: 3 Series, Z Series, Muse/Muse iQ, Halo/Halo iQ
 - If data log is set to OFF and a session is retrieved in which it was ON, it will now be ON in the hearing devices as the retrieved session determines the state of the data log
 - "Best Fit" and "Clear Settings" functions will turn data log to default ON
 - When data log is turned ON from a disabled stated, no data will display as it will start logging from that point forward

Ready. Set. Hear.

🔊 Ready. Set. Hear.

Ready. Set. Hear. is a one year triggered email program created to help new patients successfully transition to their new hearing aids.

Most of the emails are sent within the first six weeks (post hearing aid fitting) with tips, instructional videos and aural rehabilitation games designed to encourage your patients to use and get comfortable with their new hearing aids. This program is intended to increase patient satisfaction and help lower return rates over time.

To get started, enter patient email address and let him/her know that they will receive an email asking them to confirm their email address.

| * Patient email | name | name@domain.com | | | | | | | |
|-----------------------|------|-----------------|----|---|------------|---------|--|--|--|
| Patient name | Amy | | | | Attorney | | | | |
| Date of first fitting | 7 | / | 11 | 1 | 2018 | | | | |
| | Su | ıbmit | | | | | | | |
| | | | | | * indicate | recinie | | | |




Highlights

Designed so that new users will receive periodic emails to help them successfully transition to their new hearing aids

1. Enter user's email address, name and date of first fit

How Did We Do?




Highlights

NEW! Provide a satisfaction rating and comments related to the Inspire session

- 1. Rating: Extremely Satisfied, Somewhat Satisfied, Neutral, Slightly Dissatisfied, Not Satisfied
- 2. Comments: If a response is preferred, include contact info

Advanced Tools



Highlights


1. Advanced Tools provides access to several additional tools including Audiometer, Expert Assistant, Hearing Aid Test, SoundPoint, Speech Mapping and Verify Comfort

Audiometer




- 1. Talk to patient: Unmute hearing devices
- 2. Presentation: Decrease/increase test frequency and dB level
- 3. Choose to measure threshold or UCL
- 4. Best Fit or Update Targets: In-situ
- 5. Reset: Reset audiogram

Expert Assistant



- 1. Select complaint to show suggested adjustment
- 2. Can Apply or Undo Last Action

Hearing Aid Test




- 1. Can select Full On Gain, User Gain or Reference Test Gain for testing
- 2. When testing is complete, select Return to User Settings

SoundPoint



3. Available for any enabled memory except for Music


Speech Mapping



- 1. Live Speech Mapping: Default view is Input + Gain
- 2. Capture: Single response (
) or Average response (
)
- 3. Manage captured curves: View or Delete

- 4. Input Monitor: Average input level
- 5. Options for real time display

Verify Comfort



Highlights

1. Functionality remains unchanged