

# **TELES.VoIPBOX BRI**



*Software version 14.0*

<b>Chapter 1 – About this Manual</b> .....	<b>1</b>
1.1 organization .....	1
1.2 conventions .....	1
1.3 Safety Symbols .....	2
<b>Chapter 2 – Safety and Security Precautions</b> .....	<b>3</b>
2.1 Safety Measures .....	3
2.2 Power Supply .....	3
2.2.1 Technical Data .....	3
2.2.2 Symbols .....	4
2.2.3 Instructions for Use .....	4
2.2.4 Safety Precautions .....	5
2.3 Jacks .....	5
2.4 Tips for EMC Protection .....	5
2.5 System Security .....	5
2.5.1 Protecting the Operating System .....	6
2.6 CDR Files .....	6
2.7 Network Security .....	7
<b>Chapter 3 – Overview</b> .....	<b>10</b>
3.1 What’s New in Version 14.0 .....	10
3.2 Features .....	10
3.3 Implementation Scenarios .....	11
<b>Chapter 4 – VoIPBOX BRI Installation</b> .....	<b>13</b>
4.1 Checklist .....	13
4.2 Package Contents .....	13
4.3 VoIPBOX BRI Hardware Description .....	14
4.4 Installation Requirements .....	14
4.4.1 ISDN Wiring .....	14
4.4.2 Ethernet Wiring .....	15
4.5 Preparing for Installation .....	16
4.6 Hardware Connection .....	16
4.7 LED Functionality .....	16
4.8 Startup with Quickstart .....	17
4.8.1 Installing Quickstart .....	18
4.8.2 Configuration with Quickstart .....	19
4.9 Startup via FTP .....	21
4.10 Self Provisioning with NMS .....	22
4.11 Remote Access and Access Security .....	22
4.11.1 GATE Manager .....	23
4.11.2 HTTP User Interface .....	24

4.11.3	FTP	26
4.11.4	Setting a Password for Remote Access	27
<b>Chapter 5 – Configuration Files</b>		<b>28</b>
5.1	<b>Configuration File ip.cfg</b>	<b>29</b>
5.1.1	System Section Configuration	30
5.1.2	Ethernet Interface Configuration	30
5.1.3	Bridge Configuration	30
5.1.4	NAT Configuration	31
5.1.5	PPPoE Configuration	32
5.1.6	Firewall Settings	33
5.1.7	Bandwidth Control	35
5.1.8	DHCP Server Settings	37
5.1.9	PPP Configuration for ISDN Dial-Up	38
5.1.10	VLAN Configuration	40
5.1.11	Examples	40
	Default Configuration	40
	Active Ethernet Bridge	40
	Integrated DSL-Router Scenario for VoIP Traffic with an Active DHCP Server and Firewall	41
	VLAN Scenario	42
5.2	<b>Configuration File pabx.cfg</b>	<b>42</b>
5.2.1	System Settings	42
	Bypass Relay	42
	Log Files	43
	Night Configuration	45
	Controllers	46
	Subscribers	47
	Global Settings	48
5.2.2	SMTP-Client Configuration	51
5.2.3	SNMP Settings	53
5.2.4	Time-Controlled Configuration Settings	53
5.3	<b>Configuration File route.cfg</b>	<b>54</b>
5.3.1	Entries in the Sections [System] and [Night<num>]	54
	Mapping	54
	Restrict	55
	Redirect	56
5.3.2	VoIP Profiles	57
5.3.3	Gatekeeper Profiles	61
5.3.4	Registrar Profiles	63
5.3.5	Radius Profiles	64

<b>Chapter 6 – Routing Examples</b> . . . . .	<b>66</b>
6.1 VoIPBOX BRI as a Second-Generation LCR . . . . .	67
6.2 VoIPBOX BRI in an H.323 Network . . . . .	68
6.3 Work@Home Scenario with Signaling through a SIP Proxy . . . . .	69
6.4 ISDN Dial-Up for Terminating VoIP Calls . . . . .	71
6.5 Backbone Router Using a Backup Gatekeeper . . . . .	72
6.6 Backbone Router with Direct Endpoint Signaling (H.323) . . . . .	74
6.7 IntraSTAR . . . . .	75
6.8 Backbone Router and Authentication and Accounting with a Radius Server . . . . .	76
6.9 VoIP Backup and Automatic Reactivation . . . . .	77
<b>Chapter 7 – System Maintenance and Software Update</b> . . . . .	<b>78</b>
7.1 Configuration Errors . . . . .	78
7.2 Status and Error Messages . . . . .	78
7.3 Software Update . . . . .	84
7.4 Trace . . . . .	86
7.4.1 ISDN Trace Output . . . . .	87
7.4.2 VoIP Trace Output . . . . .	88
Interface IP Network . . . . .	89
RTP/RTCP Output . . . . .	93
Internal Protocol Interface (to ISDN, POTS, Mobile) . . . . .	100
H.245 Messages . . . . .	101
RAS (Registration, Admission, Status) . . . . .	106
ENUM Output . . . . .	111
Examples . . . . .	112
7.4.3 Remote Output . . . . .	116
7.4.4 SMTP Trace Output . . . . .	117
7.4.5 Number Portability Trace Output . . . . .	121
7.4.6 DTMF Tone Trace Output . . . . .	122
<b>Chapter 8 – Signaling and Routing Features</b> . . . . .	<b>124</b>
8.1 IntraSTAR . . . . .	124
8.2 Digit Collection (Enblock/Overlap Receiving) . . . . .	124
8.3 Rejecting Data Calls and Specified Numbers . . . . .	125
8.3.1 Blacklist Routing . . . . .	125
8.3.2 Whitelist Routing . . . . .	125
8.3.3 Rejecting Calls with ISDN Bearer Capability Data . . . . .	126
8.3.4 Specific Routing of Data Calls via VoIP . . . . .	126
8.4 CLIP and CLIR . . . . .	127
8.4.1 Routing CLIP and CLIR Calls . . . . .	127
8.4.2 Setting CLIR . . . . .	127
8.4.3 Setting CLIP . . . . .	128

8.5	Conversion of Call Numbers . . . . .	128
8.6	Setting Number Type in OAD/DAD . . . . .	129
8.7	Setting the Screening Indicator . . . . .	130
8.8	Setting a Default OAD . . . . .	131
8.9	Setting Sending Complete Byte in Setup . . . . .	131
8.10	Miscellaneous Routing Methods . . . . .	132
8.10.1	Routing Calls without a Destination Number . . . . .	132
8.10.2	Routing Calls Based on Existence of Destination Number . . . . .	133
8.10.3	Changing Cause Values . . . . .	133
<b>Chapter 9 – Least Cost Routing . . . . .</b>		<b>135</b>
9.1	Carrier Selection . . . . .	135
9.1.1	Routing Entries . . . . .	135
9.2	Alternative Routing Settings . . . . .	136
9.3	Charge Models . . . . .	137
9.4	Generating Charges with the VoIPBOX BRI . . . . .	138
<b>Chapter 10 – Online Traffic Monitor . . . . .</b>		<b>142</b>
10.1	ASR Calculation and Resetting Statistic Values . . . . .	142
10.2	Generating and Retrieving CDRs . . . . .	143
10.2.1	Call Log . . . . .	144
10.2.2	Missed Calls List . . . . .	145
10.3	Generating Online CDRs via E-Mail . . . . .	146
<b>Chapter 11 – DLA/Callback Services . . . . .</b>		<b>148</b>
11.1	Call Connector and Callback Server . . . . .	148
11.1.1	Special Announcement . . . . .	149
11.1.2	DLA with DTMF . . . . .	149
11.1.3	DLA with Fixed Destination Number . . . . .	150
11.1.4	Callback with DTMF and OAD as Callback Number . . . . .	150
11.1.5	Callback with DTMF and PreConfigured Callback Number . . . . .	151
11.1.6	Callback to OAD and Fixed Second Leg . . . . .	151
11.1.7	DLA with DTMF and PIN for First Leg and Callback for Second Leg . . . . .	152
11.1.8	Using a PIN in Front of the Call Number . . . . .	152
<b>Chapter 12 – Additional VoIP Parameters . . . . .</b>		<b>153</b>
12.1	Signaling Parameters . . . . .	153
12.2	Location Server Parameters . . . . .	158
12.3	Routing Parameters . . . . .	160
12.4	Quality Parameters . . . . .	161
12.5	Compression Parameters . . . . .	168
12.6	Fax/Modem Parameters . . . . .	169

---

12.7	DTMF Parameters .....	171
<b>Chapter 13 – Optional Function Modules .....</b>		<b>172</b>
13.1	Overview .....	172
13.2	Http User Interface .....	173
13.3	iPBX. ....	173
13.4	SNMP Agent .....	173
13.5	DNS Forwarder .....	174
13.6	ipupdate - DynDNS Client .....	175

# 1 ABOUT THIS MANUAL

This manual is set up to guide you through the step-by-step installation of your VoIPBOX BRI, so that you can follow it through from the front to the back. Quick-installation instructions appear in Chapter 4.8, "Startup with TELES.Quickstart". Make sure you familiarize yourself thoroughly with the safety and security precautions detailed in Chapter 2 ⇒ before you begin to install your VoIPBOX BRI. TELES is not liable for any damage or injury resulting from a failure to follow these safety and security instructions!

## 1.1 ORGANIZATION

This manual is organized into the following chapters.

- **Chapter 1, "About this Manual"** introduces the VoIPBOX BRI Systems Manual and how it is set up.
- **Chapter 2, "Safety and Security Precautions"** contains information about security issues relevant to connection with the IP network.
- **Chapter 3, "Overview"** briefly describes the VoIPBOX BRI and its implementation scenarios.
- **Chapter 4, "VoIPBOX BRI Installation"** contains information on how to connect and configure the system so that it is ready for operation.
- **Chapter 5, "Configuration Files"** describes the VoIPBOX BRI's individual configuration files and parameters.
- **Chapter 6, "Routing Examples"** contains useful examples and descriptions of scenario-based configurations in the `route.cfg`.
- **Chapter 7, "System Maintenance and Software Update"** describes system messages that are saved in the protocol file, as well as trace options.
- **Chapter 8, "Signaling and Routing Features"** describes configuration settings in the `route.cfg` used for adjusting signaling and customizing the configuration for specific scenarios.
- **Chapter 9, "Least Cost Routing"** describes configuration options for various routing processes.
- **Chapter 10, "Online Traffic Monitor"** contains the configuration for monitoring the system's statistics and CDRs.
- **Chapter 11, "DLA/Callback Services"** contains money-saving features that expand the functionality of your VoIPBOX BRI to include callback capability and DTMF services.
- **Chapter 12, "Additional VoIP Parameters"** contains additional configuration entries to fine-tune communication with the VoIP peer.
- **Chapter 13, "Optional Function Modules"** contains information on expansion modules.

## 1.2 CONVENTIONS

This document uses the following typographic conventions:

- **Bold** – items from the GUI menu.
- **Halfbold** – items from the GUI and the menu.
- **Code** – file names, variables and constants in configuration files or commands in body text.
- "conventions" on page 1 ⇒ – cross-references can be accessed in the PDF files by a single mouse click.

## SAFETY SYMBOLS

Configuration data or extracts are written in single-column tables with a gray background.

### 1.3 SAFETY SYMBOLS

The following symbols are used to indicate important information and to describe levels of possible danger.

	<b>Note</b> Useful information with no safety implications.
	<b>Attention</b> Information that must be adhered to as it is necessary to ensure that the system functions correctly and to avoid material damage.
	<b>Warning</b> Danger. Could cause personal injury or damage to the system.
	<b>Dangerous voltage</b> Could cause injury by high voltage and/or damage the system.
	<b>Electrostatic discharge</b> Components at risk of discharge must be grounded before being touched.

## 2 SAFETY AND SECURITY PRECAUTIONS

Please be sure and take time to read this section to ensure your personal safety and proper operation of your VoIPBOX BRI.

To avoid personal injury or damage to the system, please follow all safety instructions before you begin working on your VoIPBOX BRI.

VoIPBOX BRIes are CE certified and fulfill all relevant security requirements. The manufacturer assumes no liability for consequential damages or for damages resulting from unauthorized changes.

### 2.1 SAFETY MEASURES

Danger of electric shock - the power supplies run on 230 V. Do not open the VoIPBOX BRI or its power supply.

Make sure to install the VoIPBOX BRI near the power source and that the power source is easily accessible.

Bear in mind that telephone and WAN lines are also energized and can cause electric shocks.

Be sure to respect country-specific regulations, standards or guidelines for accident prevention.

### 2.2 POWER SUPPLY

The included power supply is to be used exclusively for operation of your VoIPBOX BRI.



**Make sure you read this chapter thoroughly and save the instructions for future reference. Use only the power supply GSP-1216TLS/1 included in the package contents of your VoIPBOX BRI.**

#### 2.2.1 TECHNICAL DATA

The following list includes technical information on the power supply:

- Type: GSP-1216TLS/1 for VoIPBOX BRI
- Input voltage: 230V~ +/-15% 50-60Hz; 0.40A
- Output voltage: 12V  $\overline{\text{---}}$ ; 1.6A
- Weight: 96g
- Tested and certified as per EN60950-1

## POWER SUPPLY

## 2.2.2 SYMBOLS

The symbols on the power supply have the following meanings:

**Table 2.1** Power Supply Symbols

Symbol	Meaning
	Certified to conform with European norms.
	Protective insulation provided.
	For indoor use only.
	Not for public disposal. Make sure you dispose of the power supply properly.
	Indicates the output polarity of the power supply.

## 2.2.3 INSTRUCTIONS FOR USE



**Use only the power supply GSP-1216TLS/1 included in the package contents of your VoIPBOX BRI.**

Plug the power supply directly into the outlet. The power supply provides safety-low voltage with limited capacity for your VoIPBOX BRI.

The devices are designed for constant use in dry, indoor locations. However, we recommend that you unplug them if you do not intend to use them for an extended amount of time. Make sure the power outlet is easily accessible at all time.

## JACKS

### 2.2.4 SAFETY PRECAUTIONS

Make sure you follow these safety precautions:

- Electrical devices may not be used by individuals who are not aware of the dangers of electricity and/or incorrect use thereof.
- Make sure you use only the correct input voltage.
- Make sure the installation site is sufficiently ventilated.
- Use the device only in dry, indoor locations, and protect it from humidity.
- Do not subject the device to direct sunlight.
- Unplug the device if you do not intend to use it for an extended amount of time.
- Hold the device by its housing when you unplug it. Wall outlets can become mechanically overloaded; do not pull on the cord.
- The room temperature may not exceed 35°C.
- Do not use the device if it is damaged or if there are signs of malfunction. In this case, send it to TELES Service or dispose of it properly (not with the public trash).

### 2.3 JACKS

The jacks on the VoIPBOX BRI have fulfilled the requirements of the SELVsafety standard.

### 2.4 TIPS FOR EMC PROTECTION



**Use shielded cables.  
Do not remove any housing components. They provide EMC protection.**

### 2.5 SYSTEM SECURITY

This section describes all points crucial to the VoIPBOX BRI's system security.

The VoIPBOX BRI's location must support normal operation according to EN ETS 300 386. Be sure to select the location with the following conditions in mind:



**Location: Make sure you install the system in a clean, dry, dust-free location. If possible, the site should be air-conditioned. The site must be free of strong electrical or magnetic fields, which cause disrupted signals and, in extreme cases, system failure.**

## CDR FILES



**Temperature:** The site must maintain a temperature between 0 and 35°C. Be sure to guard against temperature fluctuations. Resulting condensation can cause short circuiting. The humidity level may not exceed 80%.  
To avoid overheating the system, make sure the site provides adequate ventilation.



**Power:** The site must contain a central emergency switch for the entire power source. The site's fuses must be calculated to provide adequate system security. The electrical facilities must comply with applicable regulations.  
The operating voltage and frequency may not exceed or fall below what is stated on the label.

### Servicing the VoIPBOX BRI

Regular servicing ensures that your VoIPBOX BRI runs trouble-free. Servicing also includes looking after the room in which the system is set up. Ensure that the air-conditioning and its filter system are regularly checked and that the premises are cleaned on a regular basis.

#### 2.5.1 PROTECTING THE OPERATING SYSTEM

Changing configuration data and/or SIM card positions may lead to malfunctions and/or misrouting, as well as possible consequential damage. Make changes at your own risk. TELES is not liable for any possible damage resulting from or in relation to such changes. Please thoroughly check any changes you or a third party have made to your configuration!

Make sure your hard disk or flash disk contains enough storage space. Downloading the log files and deleting them from the VoIPBOX BRI on a regular basis will ensure your VoIPBOX BRI's reliability.

Be careful when deleting files that you do not delete any files necessary for system operation.

#### 2.6 CDR FILES

Call Detail Records are intended for analysis of the VoIPBOX BRI's activity only. They are not designed to be used for billing purposes, as it may occur that the times they record are not exact.



**Inaccuracies in the generation of CDRs may occur for active connections if traffic is flowing on the system while modifications in configuration or routing files are activated.**

## NETWORK SECURITY

### 2.7 NETWORK SECURITY

Every day hackers develop new ways to break into systems through the Internet. While TELES takes great care to ensure the security of its systems, any system with access through the Internet is only as secure as its user makes it. Therefore, to avoid unwanted security breaches and resulting system malfunctions, you must take the following steps to secure your VoIPBOX BRI if you connect it to the Internet:

- Use an application gateway or a packet firewall.
- To limit access to the VoIPBOX BRI to secure remote devices, delete the default route and add individual secure network segments.
- Access to the VoIPBOX BRI via Telnet, FTP or GATE Manager must be password protected. Do not use obvious passwords (anything from `sesame` to your mother-in-laws maiden name). Bear in mind: the password that is easiest to remember is also likely to be easiest to crack.

The firewall must support the following features:

- Protection against IP spoofing
- Logging of all attempts to access the VoIPBOX BRI

The firewall must be able to check the following information and only allow trusted users to access the VoIPBOX BRI:

- IP source address
- IP destination address
- Protocol (whether the packet is TCP, UDP, or ICMP)
- TCP or UDP source port
- TCP or UDP destination port
- ICMP message type

For operation and remote administration of your VoIPBOX BRI, open only the following ports only when the indicated services are used:

**Table 2.2** Default Ports Used for Specific Services

Service	Protocol	Port
For all systems except vGATE		
FTP	TCP	21 (default, can be set)
Telnet (for TELES debug access only)	TCP	23
SMTP	TCP	25
DNS forward	UDP	53
HTTP	TCP	80 (default, can be set)
SNTP	UDP	123
SNMP	UDP	161

## NETWORK SECURITY

Table 2.2 Default Ports Used for Specific Services (continued)

Service	Protocol	Port
H.225 registration, admission, status	UDP	1719 (default, can be set)
H.225 signaling	TCP	1720 (default, can be set)
Radius	UDP	1812 (default, can be set)
Radius accounting	UDP	1813 (default, can be set)
GATE Manager	TCP	4445 (default, can be set)
SIP signaling	UDP / TCP	5060 (default, can be set)
RTP	UDP	29000-29120 (default, can be set)
TELES.vGATE Control Unit	TCP	57343
vGATE tunneling	TCP	4446
For TELES.vGATE Control Unit and iMNP		
FTP	TCP	21
Telnet	TCP	23
MySQL database	TCP	3306
iGATE or VoIPBOX GSM/CDMA 4 FX to vGATE	TCP	57342
vGATE tunneling to iGATE or VoIPBOX GSM/CDMA 4 FX	TCP	4446
iGATE or VoIPBOX GSM/CDMA 4 FX to iMNP	TCP	9003
Remote vGATEDesktop	TCP	57344
Remote vGATEDesktop (read only)	TCP	57345
iMNP	TCP	9003
For vGATE SIM Unit		
TELES.vGATE Control Unit plus iGATE or VoIPBOX GSM/CDMA 4 FX	TCP	51500
For NMS		
FTP	TCP	21
Telnet	TCP	23

## NETWORK SECURITY

**Table 2.2** Default Ports Used for Specific Services (*continued*)

Service	Protocol	Port
MySQL database	TCP	3306
NMS protocol	TCP	5000
NMS update	TCP	5001
NMS task	TCP	5002
NMS task	TCP	5003
NMS Listen	TCP	4444
For vGATE Call Manager		
Radius authentication	UDP	1812
Radius accounting	UDP	1813

## 3 OVERVIEW

The VoIPBOX BRI is a media converter that facilitates the connection of ISDN service equipment with a voice over IP (VoIP) network. It converts line-based transmission on the ISDN side to packet-based transmission in the IP network and vice versa. Incoming traffic arrives at one VoIPBOX BRI, which routes the calls accordingly, depending on the call's destination and attributes.

### 3.1 WHAT'S NEW IN VERSION 14.0

- Enhanced HTTP user interface including Wizard for easy configuration
- New SIP settings:
  - VoipSdpProxy=<mode>: enables transmission of all SDP parameters if a call is from SIP to SIP
  - VoipUseRad=<mode>: different addresses in request header and To field result in redirected ISDN number
  - Customized translation of DSS1 cause values to SIP events
- Supports 3G faxes
- Configurable time interval for echo detection in VoIP
- New configuration settings for VoIP DTMF tone handling
- Expanded functionality of integrated DLA/callback server
- Integrated mail client capable of SMTP authentication
- CDR enhancement with new output for VoIP calls (codec, ptime)

### 3.2 FEATURES

#### VoIP

- 8 media channels
- H.323 v.4 / SIP v.2 signaling (RFC 3261), operating in parallel
- Various audio codecs: G.711, G.723.1, G.726, G.728, G.729, GSM, iLBC, Fax T.38, Data: clear channel
- RTP multiplexing (reduces bandwidth required for RTP data by up to 60%)
- ENUM client
- Echo cancellation G.168–2000
- Silence suppression, comfort noise generation, voice activity detection
- Support for multiple gatekeepers and multiple registrars
- STUN client
- Traffic shaping

#### ISDN

- 2 & 4 BRI ports, TE or NT
- DSS1 (Q.931), Q.SIG-BC; PP or PMP

## IMPLEMENTATION SCENARIOS

**LCR Engine**

- Multiple VoIP-carrier logins
- Multiple PSTN routing methods
- Multilevel alternative routing
- Dynamic fallback to PSTN
- Lifeline functionality on power loss or system failure

**General**


- User-friendly HTTP user interface with easy and advanced mode configuration settings
- Ringtone generation
- Configurable ToS/DivServ
- AOC generation
- Integrated DSL router (PPPoE)
- 2nd separate 10/100 Base-T Ethernet interface
- Status indication via LEDs

**3.3 IMPLEMENTATION SCENARIOS**

These are the most commonly used implementation scenarios:

**VoIP Gateway**

The VoIPBOX BRIles sophisticated routing algorithms allow VoIP communication via SIP server and/or gatekeeper (H.323), as well as multi-destination operation without a SIP Server or gatekeeper. Various voice codecs ensure universal connection to different VoIP destinations. Fax transmission occurs via T.38 or fallback to G.711a. Backup routes can be activated in case of VoIP peer failure. After a defined amount of time, the VoIPBOX BRI resumes its primary route.




## IMPLEMENTATION SCENARIOS

**Least Cost Router 2nd Generation**

The VoIPBOX BRI's sophisticated routing algorithms serve as an LCR between your PBX and the PSTN or VoIP carrier. Internet connection can occur via integrated DSL router. The system reverts to ISDN if there is an IP connection failure.

▪



## CHECKLIST

## 4 VOIPBOX BRI INSTALLATION

This section contains information on basic installation and configuration of your VoIPBOX BRI. Follow the easy instructions to set up your VoIPBOX BRI in a matter of minutes.

Implementation of individual scenarios require adjustments to the appropriate interfaces. Tips for basic settings are described here. Links to relevant chapters are provided for more specific configuration changes.

### 4.1 CHECKLIST

The following checklist provides step-by-step installation instructions.

1. Check the package contents
2. Install the device
3. Connect the BRI lines to the PBX and/or the PSTN
4. Check functionality (using the LEDs)
5. Using Quickstart, set the configuration (IP address and BRI / VoIP configuration)
6. Secure the LAN connection
7. Secure connection with the configuration program


### 4.2 PACKAGE CONTENTS

Your VoIPBOX BRI package contains the following components. Check the contents to make sure everything is complete and undamaged. Immediately report any visible transport damages to customer service. If damage exists, do not attempt operation without customer-service approval:

- 1 VoIPBOX BRI
- 1 power supply
- 4 RJ-45 ISDN cables (black)
- 1 RJ-45 LAN cable with gray connectors

## VOIPBOX BRI HARDWARE DESCRIPTION

## 4.3 VOIPBOX BRI HARDWARE DESCRIPTION



**Figure 4.1** VoIPBOX BRI: Front and Rear View

The VoIPBOX BRI handles traffic on up to 8 media channels. The following pages describe installation of the VoIPBOX BRI.

Figure 4.1 shows the front and rear view of a VoIPBOX BRI.


## 4.4 INSTALLATION REQUIREMENTS

Before installing your VoIPBOX BRI, make sure you have the following connections in place:

- Ethernet connection
- ISDN BRI connection to PBX and/or to the PSTN
- Power

## 4.4.1 ISDN WIRING


Figure 4.2 shows how the VoIPBOX BRI is connected between the PBX and PSTN. The TE ports connect to the PSTN and the NT ports connect to the PBX. You can connect the VoIPBOX BRI to a second ISDN outlet for the second ISDN interface.



**Figure 4.2** VoIPBOX BRI Wiring Scheme

## INSTALLATION REQUIREMENTS

Figure 4.3 shows the standard pin assignment for TE and NT modes. The cables included in the package contents have this pin assignment. You must change the pin assignment if it differs on the connected equipment.




**Abbreviations: TX - Transmit / RX - Receive**

**Figure 4.3** ISDN Wiring Scheme

## 4.4.2 ETHERNET WIRING

To connect the VoIPBOX BRI's Ethernet port to your local network, connect the system to an Ethernet switch or hub in your network. Use the three meter cable with gray connectors.

If you want to connect the VoIPBOX BRI directly to your computer and a connection cannot be established after you plug the cable in, use a cable with the following pin assignment:



**Abbreviations: TX - Transmit / RX - Receive**

**Figure 4.4** Ethernet Wiring Scheme

## PREPARING FOR INSTALLATION

### 4.5 PREPARING FOR INSTALLATION

Each computer that is to communicate with the VoIPBOX BRI requires a network connection. Please have the following information for connection to your network available:

- IP address in your local network for the VoIPBOX BRI to be configured
- Netmask for the VoIPBOX BRI to be configured
- Default gateway for VoIPBOX BRI to be configured
- DNS server address
- NTP server address



**Bear in mind that the preconfigured VoIPBOX BRI's default IP address is 192.168.1.2. If this IP address is already being used in your local network, you must run Quickstart without a connection to your local network. This can occur using a back-to-back Ethernet connection from your computer to the VoIPBOX BRI. If the desired IP address for the VoIPBOX BRI is not in your network, you must assign your computer a temporary IP address from this IP-address range.**

### 4.6 HARDWARE CONNECTION

Connect your computer with the local network

- Connect the VoIPBOX BRI with the local network
- Using the ISDN connection cables included in the package contents, connect the VoIPBOX BRI with your PBX and/or the PSTN according to the required port configuration.
- Connect the VoIPBOX BRI with the power supply.

### 4.7 LED FUNCTIONALITY

Each VoIPBOX BRI has the following status LEDs:

**Table 4.3** VoIPBOX BRI LEDs

LED	Description
Red	On: The VoIPBOX BRI is active. Blinking: The VoIPBOX BRI is in startup mode. Blinking fast: The VoIPBOX BRI is not registered / connected with the SIP-carrier
1st Green	Blinking: Ethernet packets are being sent and received.

## STARTUP WITH QUICKSTART

**Table 4.3** VoIPBOX BRI LEDs (*continued*)

LED	Description
2nd Green	On: Call is being transmitted from ISDN to VoIP.
3rd Green	On: Call is being transmitted from ISDN to ISDN.

**4.8 STARTUP WITH QUICKSTART**

Quickstart is an application that helps you to configure the basic settings of your VoIPBOX BRI quickly and conveniently.

Quickstart can be installed on any of the following operating systems:

- Windows 98 SE
- Windows NT
- Windows ME
- Windows 2000
- Windows XP
- Windows Vista

If you are using any of these operating systems, please follow the instructions in this chapter. If you are using a non-Windows operating system (e.g. Linux) follow the instructions in Chapter 4.9 ⇨.

## STARTUP WITH QUICKSTART

## 4.8.1 INSTALLING QUICKSTART

Make sure the GATE Manager is not running on your computer. To install Quickstart on your computer, insert the CD and select Quickstart from the menu. Follow the Windows instructions to begin installation of the Quickstart. Once installation begins, click **Next** to install Quickstart in the predefined folder. To install it in another location, click **Browse** and select a folder from the browser that appears. Then click **Next**.

The next dialog asks you where you want to install the program's icons. To install them in the folder that appears, click **Next**. If you want to install them in another location, select a folder from the list or enter a new folder name. Then click **Next**.

To start Quickstart immediately following installation, activate the checkbox **I would like to launch Quickstart**. Make sure the checkbox is inactive if you do not want to start the program now. Click **Finish**.




Figure 4.5 Quickstart Installation

## STARTUP WITH QUICKSTART

## 4.8.2 CONFIGURATION WITH QUICKSTART




Figure 4.6 Quickstart

Now you can use Quickstart to set up your VoIPBOX BRI. Open Quickstart .exe. The program will automatically search for your VoIPBOX BRI in the local network. For Quickstart, the source UDP port is 57445. It might be necessary to change the firewall rules on your system.

Click the **Search** button to restart the search. When the program has found your VoIPBOX BRI, it will appear in the main window. As soon as it appears, you can end the search by clicking **Stop**. The window on the right provides a running tally of the system's status.

The system's icon will appear in gray if it is unconfigured. Once it has been configured, it will appear in green. The serial number appears as the system's name.

To change the appearance of the window, select **Large Icons**, **Small Icons** or **Details** from the **View** menu. In the following description, we will use the Details View, which contains the following columns:

Table 4.4 Quickstart Details View Columns

Heading	Definition
Identifier	This column lists the system's serial number.
IP Address	This column lists the system's IP address.
Configured	An X means the system contains the configuration files.
# of VoIP Ctrl's	This column lists the number of VoIP Modules installed in the system. It will always be 1.
VoIP Channels	This column shows the number of VoIP channels per VoIP Module.
Type	Lists the type of system.
Box	An X means the system is a TELES box-based system.
CF Mounted	This column is not relevant for TELES box-based systems.

In the **Options** menu, you can suppress or activate ICMP ping to test the Internet connection.

## STARTUP WITH QUICKSTART

To perform the initial configuration of the system, double-click the icon or right-click and select **Configure**. The **IP Settings** dialog will appear. If you are using a DHCP server, activate the checkbox **DHCP**. This will deactivate the next four lines. Your DHCP server will automatically provide all of the other necessary information. If you do not have a DHCP server, leave the **DHCP** checkbox empty. The default IP address appears in the **IP Address** box. Enter a new IP address. If the address you enter already exists in the network, you will be notified to choose another address at the end of the configuration process. Enter the system's netmask in the **Mask** dialog box. Enter the IP address for the **Default Gateway** and the **Time Server** in the corresponding dialog boxes. Select the **Time Zone** for the location of the system. Click **Next**.




Figure 4.7 Quickstart Configuration: IP Settings



**There is no internal time generation for the system when the power is interrupted. That means the default time is used when the system is restarted or rebooted! Therefore it is important to set the system time with an NTP server.**

In the **VoIP Settings** dialog, select **H323** or **SIP** for the **Signaling** protocol you would like to use for outgoing calls to VoIP. H.323 and SIP are both accepted for incoming calls, regardless of what you select here. If you select SIP, you can enter a **SIP User Name** and a **SIP Password**. If you define a username, a registrar profile will automatically be generated. Enter the **Peer IP Address**. Set a **Mask** for incoming calls, so that calls from all IP addresses in the range entered will be accepted. Select the **Compression** codecs you would like to use. All codecs listed are for voice transmission, except **t38**, which is for fax transmission. Click **Next**.




Figure 4.8 Quickstart Configuration: VoIP Settings

## STARTUP VIA FTP

In the **BRI Settings** window, select the settings for each BRI port. Select **TE** for terminal endpoint or **NT** for network termination. Select **PMP** or **PP** for Point-to-Multipoint or Point-to-Point termination. Click **Next**.




Figure 4.9 Quickstart Configuration: BRI Settings

In the **Routing** window, enter the **Area Code**, where the system has been installed if you are using SIP. Select **Gateway** to send all incoming PSTN calls via VoIP. Select **LCR** if the system is connected between a PBX and the PSTN. Specific numbers or prefixes defined here are routed to VoIP if you select **All to PSTN except** or to PSTN if you select **All to VoIP except**. All other calls to numbers not on the list are routed from the PSTN or VoIP, depending on what you specify. Double-click in the **Route to VoIP/PSTN** dialog box to enter the numbers that are to be routed to VoIP or PSTN.

Now the system is configured; all other processes run automatically.

First the system's IP address will be changed and then the system will start with the new IP address. When the system can be reached at the new IP address, all PSTN ports and routing entries will be set by sending the created configuration files to the system.

If you right-click the system's icon in the main window, you can also choose **Temporarily Configure IP Address**, only the IP address for the system's first Ethernet interface and the netmask will be temporarily changed. This can be helpful if you want to set up local remote access to the system and use other IP settings on the remote device than the system's IP configuration in the network. Bear in mind that the functions on the system's first Ethernet interface work with the new settings.




Figure 4.10 Quickstart Configuration: Routing

## 4.9 STARTUP VIA FTP

If you are using a computer that does not use a Windows operating system, you can preconfigure the system via FTP. The system's default IP address is 192.168.1.2. To configure the system using FTP, you must assign your computer an IP address from network range 192.168.1.0 Class C and then access the system via FTP.

## SELF PROVISIONING WITH NMS

The default user is `teles` and the default password is `tcs-ag`. To configure the system, use the default configuration file example on the CD in the `Configfiles` directory and the following subdirectories:

- **IPconfig**  
This subdirectory contains the file (`ip.cfg`) responsible for configuration of the Ethernet interface
- **4xnt**  
All ISDN ports are configured in NT mode. The VoIPBOX BRI acts only as a VoIP gateway.
- **3xnt1xte**  
The first port is configured in TE mode and the other three in NT mode. The VoIPBOX BRI acts as VoIP LCR.
- **2xnt2xte**  
The first two ports are configured in TE mode and the other two in NT mode. The VoIPBOX BRI acts as VoIP LCR.

To edit the default configuration, follow the directions in Chapter 5 ⇒. Upload the configuration files into the `/boot` directory.

### 4.10 SELF PROVISIONING WITH NMS

With a management connection to the NMS (Network Management System), the VoIPBOX BRI can retrieve its configuration files from the configured NMS. That means that custom configuration of the device occurs automatically when the device is started. The following setting must be made in the `[System]` section of the `pabx.cfg`:

`AlarmCallback=<ip address NMS server>`

`RemoteCallback=<ip address NMS server> <time> <days of week + holiday>`

As soon as the device is started, it connects automatically with the NMS, which uses the device's TAG number to send a prepared configuration. For further information on configuration of the NMS, please refer to the NMS Systems Manual.

### 4.11 REMOTE ACCESS AND ACCESS SECURITY

After the system has been configured and all cables are connected, remote administration and maintenance can occur with the GATE Manager (Chapter 4.11.1 ⇒), the HTTP user interface (Chapter 4.11.2 ⇒), or via FTP (Chapter 4.11.3 ⇒).

## REMOTE ACCESS AND ACCESS SECURITY

## 4.11.1 GATE MANAGER




Figure 4.11 GATE Manager

The GATE Manager administration and maintenance software offers a broad range of functions. The GATE Manager is user friendly and can be customized to suit your needs.

The following maintenance functions are possible:

- Display system information and network element status.
- Retrieve and display configuration files.
- Restart network elements.
- Use of a trace option for checking functions and fault diagnosis. Option to use an external tool, e.g. to display and break down trace data.
- Update the system software (firmware) and configuration tables.
- Retrieve CDRs (Call Detail Records).
- Display the current connections (status).
- Display statistical information for network elements and interfaces.
- Display the status of the interfaces.

Use the CD enclosed in your package contents to install the GATE Manager. For a detailed description of installation and implementation of the GATE Manager, please refer to the GATE Manager and Utilities Programs Manual.

GATE Manager remote access can occur via IP or ISDN. GATE Manager access via IP uses port 4444 as origination TCP port and port 4445 as destination port. The following default value (4445) is configured in the `pabx.cfg` file for the system's port:

```
MoipPort=4445
```

In the default configuration, ISDN access is disabled. To configure the system so that certain data calls are received as remote administration calls, make the following changes in the `pabx.cfg`:

```
RemoteCode=BBB
```

```
MapAll<num>=BBB DATA
```

## REMOTE ACCESS AND ACCESS SECURITY

Make the following entries in the `route.cfg` if the system is to handle all data calls as remote-administration calls:

```
MapAll0=BBB DATA
MapAll1=BBB DATA
MapAll2=BBB DATA
MapAll3=BBB DATA
MapAll4=BBB DATA
MapAll5=BBB DATA
MapAll6=BBB DATA
MapAll7=BBB DATA
MapAll8=BBB DATA
MapAll9=BBB DATA
```

For a detailed description of ISDN configuration, see the TELES Infrastructure Systems Parameters and Hardware Manual.

## 4.11.2 HTTP USER INTERFACE



Figure 4.12 HTTP User Interface

Remote access can occur via the HTTP user interface. Even users with little experience can easily configure standard system settings with this interface. Simply open a browser and enter the system's IP address in the address bar.

The following administrative levels apply:

#### Carrier Mode (Full Access)

User: `teles-carrier`

## REMOTE ACCESS AND ACCESS SECURITY

Password: `tcs-carrier`

All configuration pages can be accessed in this mode.

### Administrator Mode

User: `teles-admin`

Password: `tcs-admin`

This access level is for the user network's administrator. All IP and routing entries, with the exception of VoIP carrier entries, can be set here.

### Read-Only Mode

User: `teles-user`

Password: `tcs-user`

No configuration changes can be made at this level. Only status and statistics can be retrieved.

Of course, these configuration levels correspond with the most important scenarios. The passwords are saved in the `ip.cfg` in encrypted form:

```
PwdCarrier=<crypt>
```

```
PwdAdmin=<crypt>
```

```
PwdUser=<crypt>
```

### Example:

```
[httpd]
PwdUser=k24X0sdc.uMcM
PwdAdmin=k2UMj19qtovzI
PwdCarrier=k2jryo6Xd5vN6
```



**Never copy these entries from one system to another, as the encryption is unique for each system.**

The user interface is divided into the following main sections:

**Table 4.5** HTTP User Interface: Sections

Section	Description
User Data	Here you can change the user passwords and the language for the HTTP interface.

## REMOTE ACCESS AND ACCESS SECURITY

**Table 4.5** HTTP User Interface: Sections (*continued*)

Section	Description
System Settings	IP Settings: Settings for the Ethernet interfaces and related services. ISDN Settings: Settings for the VoIPBOX BRI's BRI interfaces. VoIP Settings: VoIP settings for the SIP or H.323 carrier. Telephony Routing: Routings for telephone numbers.
System Overview	Overview of system information and drivers.
Telephony Routing	VoIP settings for the SIP or H.323 carrier and routings for telephone numbers.
Commands	Here you can activate a configuration or restart the system.

All of the user interface's pages contain **Help** buttons and links to the online help, which provides a detailed description of all of the individual configuration settings.

#### 4.11.3 FTP

Remote access can also occur via FTP. You can use FTP to transfer configuration files. You can also carry out functions and traces with raw commands. Use the username `teles` and the defined password to connect to the system with FTP.

The following entries ensure the security of your FTP access:

**Table 4.6** FTP Security Entries

FTP Security
<p>FtpdPort=&lt;port&gt; Defines the FTP access port (default 21).</p>
<p>RemotePassword=&lt;password&gt; Defines the password for FTP and GATE Manager access. Please refer to Chapter 4.11.4 ⇔ for instructions on how to enter an encrypted password in the <code>pbx.cfg</code>. If you do not define a password, access to the system via GATE Manager occurs without a password, and FTP access occurs with the default password <code>tcs-ag</code>.</p>

Once you have access to the system, you will be in the folder `/home/teles`. To upload or download configuration files change to the directory `/boot`. To download log files, also change to the directory `/boot`.

## REMOTE ACCESS AND ACCESS SECURITY

The following commands can be carried out via FTP access:

**Table 4.7** FTP Commands

Command	Function
SITE xgboot	Boots the entire system.
SITE xgact	Activates the configuration.
SITE xgact 1-19	Activates the <b>Night</b> section corresponding with the number 1-19.
SITE xgtrace 0	Deactivates trace.
SITE xgtrace 1	Activates layer 2 trace.
SITE xgtrace 2	Activates layer 3 trace.

### 4.11.4 SETTING A PASSWORD FOR REMOTE ACCESS

The following entry ensures the security of your remote access. Use the **mkpwd.exe** tool to generate the password. You will find it on the enclosed CD in the directory **pwd**.

Start the program in a command window with the entry **mkpwd <password>**. The output shows the encrypted password. Enter the encrypted password in the configuration file **pabx.cfg**'s parameter line as follows:

```
RemotePassword=<crypt>
```

When the file has been transferred to the system and the configuration has been activated, access to the system can occur only with the password. Don't forget to memorize the password!

If you do not define a password, access to the system via GATE Manager occurs without a password, and FTP access occurs with the default password **tcs-ag**.

## 5 CONFIGURATION FILES

This chapter describes the basic setup and the most commonly used entries for the configuration files. Configuration of VoIPBOX BRIes is managed in the following three files:

**Table 5.8** Configuration Files

File	Function
<code>ip.cfg</code>	This file is for the basic configuration of the Ethernet interfaces.
<code>pabx.cfg</code>	This file is for system-specific and port-specific settings.
<code>route.cfg</code>	This file is for routing entries.



**Changing configuration data may lead to malfunctions and/or misrouting, as well as possible consequential damage. All changes are made at own risk. TELES is not liable for any possible damage out of or in relation to such changes. Please thoroughly check any changes you or a third party have made to your configuration.**

The system comes without the files. The default configuration with the IP address 192.168.1.2 is active when the files are not on the system. You can configure the system using Quickstart, GATE Manager or via FTP (user `teles`, password `tcs-ag`). If you use the HTTP user interface to make configuration changes, the files will be adjusted automatically.

Make sure you secure the system with new passwords following configuration and remember to memorize the passwords!

These configuration files contain all system-specific settings and are used when the system starts. Comments included in these files must begin with a semicolon. They do not need to be at the beginning of a line. Configuration files must end with an empty line.

The configuration files follow these conventions: Individual files are divided into sections. These sections always begin with a line entry in square brackets. The basic required sections are in these files:

**Table 5.9** Required Configuration File Sections

Section	File	Function
[System]	<code>pabx.cfg</code> <code>route.cfg</code> <code>ip.cfg</code>	This section contains the system's basic settings.

## CONFIGURATION FILE IP.CFG

Table 5.9 Required Configuration File Sections (continued)

Section	File	Function
[Night<num>] EXAMPLE: [Night1] [Night2]	pabx.cfg route.cfg	This section contains time dependent entries that only apply for limited times.
[emac0]	ip.cfg	This section contains the IP configuration for the first Ethernet interface.

## 5.1 CONFIGURATION FILE IP.CFG

The basic settings for the two Ethernet interfaces are entered here. One interface usually suffices. The second interface can be used for special requirements, e.g. as a hub port, DSL router or vLAN interface. Generally, these settings are entered once and then left unchanged.

This file contains the following sections, which must appear in the order given:

Table 5.10 Sections in the ip.cfg File

Section	Function
[System] (required)	This section contains entries that define the default gateway and/or special routing entries.
[emac0] (required) [emac1] (optional)	The Ethernet Media Access Controller section(s) define the physical Ethernet interface(s).
[nat] (optional)	This section includes settings for Network Address Translation.
[bridge0] (optional)	These section(s) contain settings for the second Ethernet controller in bridge mode.
[pppoe<x>] (optional)	These sections contain settings for direct connection between the system and the DSLAM when the PPPoE protocol is used. <x> can be 0 or 1.
[firewall] (optional)	This section contains settings for activating the system's firewall.
[altqd] (optional)	This section enables prioritization of VoIP packets in the VoIPBOX BRI through an IP network using bandwidth control.
[dhcpd] (optional)	This sections contains a list of parameters and settings for the DHCP server in the system. It is divided into global settings for the server and parameters for the DHCP subnet.
[vlan<x>] (optional)	These section(s) contain settings for the virtual networks. <x> can be anything from 0 to 9.

## CONFIGURATION FILE IP.CFG

## 5.1.1 SYSTEM SECTION CONFIGURATION

The [System] section contains entries that define the default gateway and/or special routing entries.

To define the standard gateway, use the following entry to set the IP address:

`DefaultGw=<ip addr>`

**Example:**

```
[System]
DefaultGw=192.168.1.254
```

If you must route specific net ranges to gateways other than what is defined in the default route, make the following entries in the [System] section:

`Route=<target range> -netmask <ip mask> <ip gateway>`

**Example:**

```
[System]
DefaultGw=192.168.1.254
Route=10.0.0.0 -netmask 255.0.0.0 192.168.1.1
```

If only certain routes apply, leave the line `DefaultGw` empty.

## 5.1.2 ETHERNET INTERFACE CONFIGURATION

The following settings are possible for the sections [emac0] and [emac1]:

`IpAddress=<ip addr>/<netmask>`

The IP address is entered in decimal notation, followed by a slash (/) and the netmask in bit notation.

**Example:**

```
IpAddress=192.168.1.2/24
```

The following entry is used to allocate an IP address via DHCP:

`IpAddress=dhcp`

The following entry is used in the [emac1] section if operation of the system is occurs in bridge mode.

`IpAddress=up`

## 5.1.3 BRIDGE CONFIGURATION

A bridge can connect two networks with each other. A bridge works like a hub, forwarding traffic from one interface to another. Multicast and broadcast packets are always forwarded to all interfaces that are part of the bridge. This can occur on the Ethernet or VLAN level:

`BrConfig=add <interface-x> add <interface-y> up`

## CONFIGURATION FILE IP.CFG

Activating another Ethernet interface in this way is useful, for example, when the Ethernet switch does not have any more ports available for connection of the system. You can simply unplug a cable and plug it into the system's second Ethernet interface.

**Example:**

```
[bridge0]
BrConfig=add emac0 add emac1 up
```

## 5.1.4 NAT CONFIGURATION

The NAT (Network Address Translation) module translates IP addresses from the local network to an IP address or range on a public interface. All rules are defined in the [nat] section:

**Table 5.11** NAT Configuration

<b>map=&lt;interface&gt; &lt;local network address/mask&gt; -&gt; &lt;public network address/mask&gt; &lt;optional entries&gt;</b>	
This parameter maps the IP address in the local network to the IP address in the public network.	
<b>&lt;interface&gt;</b>	Defines the translated interface or protocol: <b>emac1</b> The system's second Ethernet interface <b>pppoe0</b> Protocol used for DSL connections <b>xppp&lt;0&gt;</b> Protocol used for ISDN dial-up connections
<b>&lt;local network address/mask&gt;</b>	The IP address is entered in decimal notation, followed by a slash (/) and the netmask in bit notation. The entire local network range is configured.
<b>&lt;public network address/mask&gt;</b>	Defines the public network range, with network address and mask (usually exactly one address), into which the local IP addresses are to be translated. The IP address is entered in decimal notation, followed by a slash (/) and the netmask in bit notation.
<b>&lt;optional entries&gt;</b>	Special rules can be defined for some services or protocols. The system can serve as a proxy for FTP: <b>proxy port ftp ftp/tcp</b> Special ports for the public address(es) can be assigned for the protocols TCP and UDP. The range is defined by the start and end ports: <b>portmap tcp/udp &lt;start port&gt;:&lt;end port&gt;</b> If no optional entry is defined, all other addresses will be translated without special rules.
<b>rdr=&lt;interface&gt; &lt;public network address/mask&gt; port &lt;port&gt; -&gt; &lt;local network address/mask&gt; port &lt;port_number&gt; &lt;protocol&gt;</b>	
This parameter redirects packets from one port and IP address to another.	

## CONFIGURATION FILE IP.CFG

Table 5.11 NAT Configuration (continued)

<interface>	Defines the translated interface or protocol: <b>emac1</b> The system's second Ethernet interface <b>pppoe0</b> Protocol used for DSL connections <b>ppp&lt;0&gt;</b> Protocol used for ISDN dial-up connections
<public network address/mask>	Defines the public network range, with network address and mask (usually exactly one address), into which the local IP addresses are to be translated. The IP address is entered in decimal notation, followed by a slash (/) and the netmask in bit notation.
<port>	Defines the port number.
<local network address/mask>	The IP address is entered in decimal notation, followed by a slash (/) and the netmask in bit notation. The entire local network range is configured.
<protocol>	Defines the protocol. <b>tcp</b> and <b>udp</b> are possible.

**Example:** The following NAT settings are for a system in which PPPoE (DSL) is used toward the Internet. The local network range 192.168.1.0 Class C is translated with the following rules:

- The proxy mode is used for FTP.
- All other TCP and UDP packets are mapped to the external ports 40000 to 60000.
- There are no special rules for any other services.
- Incoming requests to port 80 and 443 in the public IP address 192.168.1.100 are redirected to ports 80 and 443 in the local IP address 192.168.1.100.

```
[nat]
map=emac1 192.168.1.0/24 -> 0/32 proxy port ftp ftp/tcp
map=emac1 192.168.1.0/24 -> 0/32 portmap tcp/udp 40000:60000
map=emac1 192.168.1.0/24 -> 0/32
rdr=emac1 0/0 port 80 -> 192.168.1.100 port 80 tcp
rdr=emac1 0/0 port 443 -> 192.168.1.100 port 443 tcp
```

## 5.1.5 PPOE CONFIGURATION

The protocol Point-to-Point over Ethernet is used for DSL communication with the DSLAM. That means the system can connect directly with the carrier network and terminate VoIP traffic directly.

All necessary information for setup of the PPPoE connection is defined in the [pppoe<x>] section. That means username, password and authentication protocol are set here. The Ethernet interface is emac1 and the gateway can also be defined. The parameter PppoeIf defines the physical Ethernet interface used (always emac1). The settings are entered as follows:

```
[pppoe<x>]
PppoeIf=emac1
User=<user>
```

## CONFIGURATION FILE IP.CFG

Pwd=<pwd>  
 AuthProto=<pap | chap>  
 Route=<ip\_gw> (optional)

**Table 5.12** Settings in the [pppoe<x>] Section of the ip.cfg

[pppoe<x>]
PppoeIf=<interface> Enter the Ethernet interface used for the DSL connection (usually emac1).
User=<username> Enter the username used for DSL access.
Pwd=<password> Enter the password used for DSL access.
AuthProto=<protocol> Enter <b>chap</b> or <b>pap</b> for the protocol used for authentication.
Route=<ip-addr> (optional) Enter the target IP address range, e.g. 0.0.0.0 (default route). All packets that are not defined for the local network will be sent through this interface. In this case, the parameter <b>DefaultGW</b> in the <b>System</b> section (Chapter 5.1.1 ⇒) must remain empty. Only network ranges can be routed. The syntax in this case is <b>Route=&lt;target range&gt; -netmask &lt;ip mask&gt;</b> . If several different network ranges are used, you must enter the <b>Route</b> parameter for each range.

Bear in mind that configuration of the firewall, the NAT module and prioritization of the VoIP packets must be considered when routing voice and data through the DSL line.

**Example:** The following entry will create the interface **pppoe0**, with the username **user** and the password **pwd**. The PAP authentication protocol is used. The default route occurs via DSL:

```
[pppoe0]
PppoeIf=emac1
User=user
Pwd=pwd
AuthProto=pap
Route=0.0.0.0
```

### 5.1.6 FIREWALL SETTINGS

The firewall settings provide options for limiting or denying access to and from the system. If you do not configure this section, the firewall is inactive and access is unlimited.

**WARNING:** Make sure you configure the firewall rules carefully. The rules are processed from top to bottom. If you use the option **quick**, you will break the sequence. We recommend that you put the most restrictive rule at the end of the configuration.

## CONFIGURATION FILE IP.CFG

**Example:** In the following example, only port 4445 allows incoming connections from the IP address 192.168.1.10. All others will be blocked.

```
[firewall]
fw=pass in quick on emac0 proto tcp from 192.168.1.10/32 to any port
eq 4445 flags S keepstate keep frags
fw=block in log quick on emac0 all
```

**Table 5.13** Settings in the [firewall] Section of the ip.cfg

<b>[firewall]</b> <b>fw=&lt;mode&gt; &lt;direction&gt; &lt;list&gt;</b>	
<b>&lt;mode&gt;</b>	Two modes are possible for permitting or denying access:: <b>pass</b> permits access <b>block</b> denies access
<b>&lt;direction&gt;</b>	Possible directions are in and out: <b>in</b> external to internal <b>out</b> internal to external
<b>&lt;list&gt;</b>	All other entries specify the other settings for the corresponding firewall rules and are optional. The order in the line is as listed below:
<b>log</b> Records non-matching packets.	
<b>quick</b> Allows short-cut rules in order to speed up the filter or override later rules. If a packet matches a filter rule that is marked as quick, this rule will be the last rule checked, allowing a short-circuit path to avoid processing later rules for this packet. If this option is missing, the rule is taken to be a "fall-through rule, meaning that the result of the match (block/pass) is saved and that processing will continue to see if there are any more matches.	
<b>on &lt;interface&gt;</b> The firewall rule is used only for the defined interface (e.g. emac0, pppoe0).	
<b>from &lt;networkaddress/mask&gt;</b> <b>to &lt;networkaddress/mask&gt;</b> <b>from</b> defines the source IP-address range for incoming packets. <b>to</b> defines the target IP-address range for outgoing packets. The IP address appears in decimal notation, followed by a slash (/) and the netmask in bit notation. <b>any</b> stands for all IP addresses (e.g.: <b>to any</b> ). NOTE: If you use the rule <b>pass in/out</b> in combination with the option <b>from &lt;ip&gt; to &lt;ip&gt;</b> , you must specify a protocol number with <b>proto</b> and a port number. If you not specify the port, the system may not be reachable. EXAMPLE: <b>fw=pass in quick on pppoe0 proto tcp from any to any port eq 4445</b>	

## CONFIGURATION FILE IP.CFG

Table 5.13 Settings in the [ firewall ] Section of the ip . cfg (continued)

<b>[firewall] fw=&lt;mode&gt; &lt;direction&gt; &lt;list&gt;</b>
proto <protocol> defines the protocol, for which the rule is valid (e.g.: proto tcp, proto udp, proto icmp).
port eq <num> <num> defines the port as number (e.g.: port eq 4445).
keep state Ensures that the firewall checks packets from the beginning to the end of a session. This is necessary, as the firewall does not know when a session begins or ends.
flags S Only syn. packets are accepted and recorded in the state table. In conjunction with keep state, packets from sessions that have been inactive will also be routed. The advantage of this entry is that random packets will not be accepted.
keep frags Fragmented packets are also routed.

**Example:**

```
[firewall]
; loopback
fw=pass in quick on emac0 all
fw=pass out quick on emac0 all

; traffic to outgoing
fw=pass out quick on pppoe0 proto tcp all flags S keep state keep frags
fw=pass out quick on pppoe0 proto udp all keep state keep frags
fw=pass out quick on pppoe0 proto icmp all keep state keep frags

; incoming traffic
fw=pass in quick on pppoe0 proto tcp from 10.4.0.0/16 to any port eq 21 flags S keep state keep frags
fw=pass in quick on pppoe0 proto tcp from 10.4.0.0/16 to any port eq 23 flags S keep state keep frags
fw=pass in quick on pppoe0 proto tcp from 10.4.0.0/16 to any port eq 4445 keep state

; icmp traffic
fw=pass in quick on pppoe0 proto icmp all keep state

; other will be blocked
fw=block in log quick on pppoe0 all
fw=block out log quick on pppoe0 all
```

**5.1.7 BANDWIDTH CONTROL**

In many implementation scenarios, the VoIPBOX BRI in router mode (e.g. as DSL router) sends voice and data traffic through a connection with limited bandwidth. This can lead to lost voice packets that arrive too late to be used in the voice stream. To avoid lost packets, this QoS setting prioritizes packet transmission. You must set the priority for voice signaling and for the voice packets. That means you must prioritize SIP/H.323, RTP and RTCP. You will find the ports used in Table 5.22, in the following entries:

## CONFIGURATION FILE IP.CFG

H225Port

SipPort

VoipRtp Port

VoipRtpPortSpacing

Different ports can be used for RTP and RTCP, depending on the configuration.

The parameter `VoipRtpPort` shows the first RTP port used. The corresponding RTCP port is the next one up. The parameter `VoipRtpPortSpacing` shows the next RTP port (RTP port + port spacing).

**Table 5.14** Settings in the `[altqd]` Section of the `ip.cfg`

<b>interface &lt;interface&gt; bandwidth &lt;bw&gt; priq</b>	
Defines the interface for which the rule applies.	
<b>&lt;interface&gt;</b>	Sets the interface for which prioritization applies (e.e. <code>pppoe0</code> ).
<b>&lt;bw&gt;</b>	Sets the bandwidth that is available on the interface in Kbit/s (e.g. 256K).
<b>priq</b>	Priority queueing. A higher priority class is always served first.
<b>class priq &lt;interface&gt; &lt;class&gt; root priority &lt;prio&gt;</b>	
Defines the priority of the filter entries.	
<b>&lt;class&gt;</b>	Two types can be set: <ul style="list-style-type: none"> <li>▪ <code>realtime_class</code> (VoIP packets)</li> <li>▪ <code>regular_class</code> (data packets)</li> </ul>
<b>&lt;prio&gt;</b>	Enter a value between 0 and 15. The higher the value (e.g. 15), the higher the priority.
<b>filter &lt;interface&gt; &lt;class&gt; &lt;values&gt;</b>	
Defines the individual rules.	
<b>&lt;values&gt;</b>	The individual values are divided into the following entries. A 0 can be entered as a wildcard, in which case all values are possible: <ul style="list-style-type: none"> <li>▪ <code>&lt;dest_addr&gt;</code> (can be followed by <code>netmask &lt;mask&gt;</code>)</li> <li>▪ <code>&lt;dest_port&gt;</code></li> <li>▪ <code>&lt;src_addr&gt;</code> (can be followed by <code>netmask &lt;mask&gt;</code>)</li> <li>▪ <code>&lt;src_port&gt;</code></li> <li>▪ <code>&lt;protocol tos value&gt;</code>: <ul style="list-style-type: none"> <li>▪ 6 for TCP</li> <li>▪ 17 for UDP</li> </ul> </li> </ul>

**Example:** In the following example, prioritization is set for an eight-channel VoIP connection. The SIP signaling port 5060 and the RTP/RTCP ports 29000 to 29015 are prioritized at level 7. All other services are set at level 0:

## CONFIGURATION FILE IP.CFG

```
[altqd]
interface pppoe0 bandwidth 256K priq
class priq pppoe0 realtime_class root priority 7
  filter pppoe0 realtime_class 0 5060 0 0 0
  filter pppoe0 realtime_class 0 0 0 5060 0
  filter pppoe0 realtime_class 0 29000 0 0 17
  filter pppoe0 realtime_class 0 0 0 29000 17
  filter pppoe0 realtime_class 0 29001 0 0 17
  filter pppoe0 realtime_class 0 0 0 29001 17
  ....
  filter pppoe0 realtime_class 0 29014 0 0 17
  filter pppoe0 realtime_class 0 0 0 29014 17
  filter pppoe0 realtime_class 0 29015 0 0 17
  filter pppoe0 realtime_class 0 0 0 29015 17
class priq pppoe0 regular_class root priority 0 default
```

## 5.1.8 DHCP SERVER SETTINGS

The DHCP (Dynamic Host Configuration Protocol) server provides a mechanism for allocation of IP addresses to client hosts. The section `[dhcpd]` contains a list of parameters and settings for the DHCP server in the system. It is divided into global settings for the server and parameters for the DHCP subnet.

**Table 5.15** Settings in the `[dhcpd]` Section of the `ip.cfg`

<b>; Global dhcp parameters</b>
allow unknown-clients; All DHCP queries are accepted and the configured settings are transmitted to the clients.
ddns-update-style none; Deactivates dynamic update of the domain name system as per RFC 2136.
<b>; Parameters for the Subnet</b>
subnet <network address> netmask <mask for network range> { <list> }
In <list> you can enter any of the following specific network settings activated by the DHCP server. Each option must begin in a new line and end with a semicolon (;).
range <start IP address> <end IP address>; The DHCP network range is defined by the first and last address in the range. Client assignment begins with the last address.
option broadcast-address <IP address>; Defines the broadcast address for the clients in the subnet..
option domain-name "<string>;" Defines the domain name used in the network.

## CONFIGURATION FILE IP.CFG

Table 5.15 Settings in the [dhcpd] Section of the ip.cfg (continued)

<b>; Global dhcp parameters</b>
<pre>option domain-name-servers &lt;IP address&gt;;</pre> <p>Defines the DNS-server address to be assigned (as per RFC 1035)</p> <p>All of the following optional entries defining server addresses are also transmitted as per RFC 1035. Separate multiple addresses per server with a comma:</p> <pre>... &lt;IP address&gt;, &lt;IP address&gt;;</pre> <p>(this also applies for all other optional entries with IP addresses).</p>
<pre>option netbios-name-servers &lt;IP address&gt;</pre> <p>Defines the WINS-server address to be assigned.</p>
<pre>option ntp-servers &lt;ip address&gt;;</pre> <p>Defines the NTP-server address to be assigned.</p>
<pre>option time-servers &lt;ip address&gt;;</pre> <p>Defines the time-server address to be assigned (RFC 868).</p>
<pre>option routers &lt;IP address&gt;;</pre> <p>Defines the router address to be assigned.</p>
<pre>option subnet-mask &lt;net mask&gt;;</pre> <p>Defines the netmask to be assigned (as per RFC 950).</p>
<pre>option tftp-server-name "&lt;link&gt;";</pre> <p>Defines the TFTP server name (option 66), as per RFC 2132.</p> <p>EXAMPLE: <code>option tftp-server-name "http://192.168.0.9";</code></p>

**Example:**

```
[dhcpd]
; Global dhcp parameters
allow unknown-clients;
ddns-update-style none;

; Parameter for the Subnet
subnet 192.168.1.0 netmask 255.255.255.0 {
  range 192.168.1.3 192.168.1.20;
  option broadcast-address 192.168.1.255;
  option domain-name "company.de";
  option domain-name-servers 192.168.1.100;
  option routers 192.168.1.2;
  option subnet-mask 255.255.255.0;
}
```

**5.1.9 PPP CONFIGURATION FOR ISDN DIAL-UP**

The point-to-point protocol is used for dial-up connection via ISDN lines. That means the system can set up an Internet connection, which can be used for all local users or to transmit VoIP calls via ISDN dial-up. Bear in mind that you must configure the firewall and NAT options accordingly.

## CONFIGURATION FILE IP.CFG

The advantages of VoIP over ISDN can be seen especially in corporate implementation. For example, it is useful when a very high number of connections occurs between subsidiaries and one subsidiary does not have a broadband Internet connection. An ISDN B-channel can be connected to the Internet and up to six voice calls can occur simultaneously over one ISDN line. All necessary information for setup of the PPP connection is defined in the section [xppp<num>].

The settings are entered as follows:

**Table 5.16** Settings in the [xppp] Section of the ip.cfg

[xppp<num>]
Dad=<num> Enter the dial-up number.
User=<username> Enter a username.
Pwd=<password> Enter a password.
Route=<ip-addr> Enter the target IP address range, e.g. 0.0.0.0 (default route).
AuthProto=<protocol> Enter <b>chap</b> (default) or <b>pap</b> for the protocol used for authentication.
IdleTO=<sec> Enter the number of seconds without traffic before the interface tears down the connection.
MTU=<int> Maximum Transfer Unit. We recommend the following default values: 1500 for ISDN dial-up.
Rfc1662=<val> Framing to be use: 0 for ISDN.

**Example:**

```
[xppp0]
Dad=12345
User=user
Pwd=pwd
Route=0.0.0.0
AuthProto=chap
IdleTO=60
MTU=1500
Rfc1662=0
```

## CONFIGURATION FILE IP.CFG

## 5.1.10 VLAN CONFIGURATION

A VLAN (Virtual Local Area Network) is a virtual LAN within a physical network. Each VLAN is assigned a unique number (VLAN ID) and defined in the [vlan<x>] section with

Tag: value between 1 and 4095

Priority: value between 0 and 7 (0 is lowest and 7 is the highest priority)

[vlan0]

IfConfig=vlan <tag>,<priority> vlanif <interface>

**Example:** The following entry will create the interface vlan1, with VLAN tag 10 and priority 7, on the Ethernet interface emac0. Following this configuration, IP addresses (and/or other protocols) can be assigned to the vlan1 interface:

```
[vlan1]
IfConfig=vlan 10,7 vlanif emac0
IpAddress=192.168.199.1
```

## 5.1.11 EXAMPLES

## 5.1.11.1 DEFAULT CONFIGURATION

In the following example, the system's IP address is 192.168.1.1, the netmask is 255.255.255.0, and the standard gateway is 192.168.1.254:

```
[System]
DefaultGw=192.168.1.254

[emac0]
IpAddress=192.168.1.1/24
```

## 5.1.11.2 ACTIVE ETHERNET BRIDGE

In the following example a two-port Ethernet bridge is configured. The system's IP address is 192.168.1.1, the netmask is 255.255.255.0, and the standard gateway is 192.168.1.254,

The emac1 interface is active and both Ethernet interfaces are set to bridge mode in the [bridge0] section:

```
[System]
DefaultGw=192.168.1.254

[emac0]
IpAddress=192.168.1.1/24

[emac1]
IpAddress=up

[bridge0]
BrConfig=add emac0 add emac1 up
```

## CONFIGURATION FILE IP.CFG

## 5.1.11.3 INTEGRATED DSL-ROUTER SCENARIO FOR VOIP TRAFFIC WITH AN ACTIVE DHCP SERVER AND FIREWALL

In the following example, the system is connected to the local IP network through emac0. The DSL modem is connected to the emac1 interface, which enables the system to connect directly to the carrier network without an additional router when the connection is used only for VoIP data. A DHCP server is used for dynamic IP-address allocation:

```
[System]

[emac0]
IpAddress=192.168.0.2/24

[emac1]
IpAddress=up

[pppoe0]
PppoeIf=emac1
User=usertelekom
Pwd=pwd
AuthProto=chap
Route=default

[nat]
map=pppoe0 192.168.0.0/24 -> 0/32 proxy port ftp ftp/tcp
map=pppoe0 192.168.0.0/24 -> 0/32 portmap tcp/udp 40000:60000
map=pppoe0 192.168.0.0/24 -> 0/32

[firewall]
; loopback
fw=pass in quick on emac0 all
fw=pass out quick on emac0 all

; traffic to outgoing
fw=pass out quick on pppoe0 proto tcp all flags S keep state keep frags
fw=pass out quick on pppoe0 proto udp all keep state keep frags
fw=pass out quick on pppoe0 proto icmp all keep state keep frags

; incoming traffic
fw=pass in quick on pppoe0 proto tcp from 10.4.0.0/16 to any port eq 21 flags S keep state keep frags
fw=pass in quick on pppoe0 proto tcp from 10.4.0.0/16 to any port eq 23 flags S keep state keep frags
fw=pass in quick on pppoe0 proto tcp from 10.4.0.0/16 to any port eq 4445 keep state

; icmp traffic
fw=pass in quick on pppoe0 proto icmp all keep state

; other will be blocked
fw=block in log quick on pppoe0 all
fw=block out log quick on pppoe0 all

[dhcpd]
; Global dhcp parameters
allow unknown-clients;
ddns-update-style none;
; Parameter for the Subnet
subnet 192.168.1.0 netmask 255.255.255.0 {
    range 192.168.1.3 192.168.1.20;
    option broadcast-address 192.168.1.255;
    option domain-name "company.de";
    option domain-name-servers 192.168.1.100;
    option routers 192.168.1.2;
    option subnet-mask 255.255.255.0;
```

## CONFIGURATION FILE PABX.CFG

## 5.1.11.4 VLAN SCENARIO

In the following example, the system is connected to the IP backbone through emac0. One Computer is connected to the emac1 interface. You can separate voice and data traffic with two different VLANs (vlan0 with tag 10 for voice, vlan1 with tag 11 for data). All traffic coming from emac1 will be sent to vlan1. Voice and data will not be mixed:

```
[System]
[emac0]
IpAddress=192.168.1.12/16

[emac1]
IpAddress=up

[vlan0]
IfConfig=vlan 10,7 vlanif emac0
IpAddress=10.0.1.2/24

[vlan1]
IfConfig=vlan 11,1 vlanif emac0
IpAddress=172.16.4.5/16

[bridge0]
BrConfig=add vlan1 add emac1 up
```

## 5.2 CONFIGURATION FILE PABX.CFG

The `pabx.cfg` is divided into the `[System]` section and the optional `[Night<num>]`, `[Mail]` and `[Snmpd]` sections.

## 5.2.1 SYSTEM SETTINGS

The `[System]` section is divided into several categories to ensure clarity:

- Hardware
- Bypass relay
- Log files
- Night configuration
- Controllers
- Subscribers
- Global Settings

## 5.2.1.1 BYPASS RELAY

The entry in this category is responsible for the bypass functionality of the BRI port's relay when the system is on. When the system is off, BRI port 1 is connected to BRI port 3, and BRI port 2 is connected to BRI port 4. This means there is a transparent connection between the PBX (or the telephones) and the PSTN. When the system is on, all routing algorithms are active.

**Bypass=ON/OFF**

**ON:** BRI relay is on (system controls both BRI ports).

## CONFIGURATION FILE PABX.CFG

OFF: BRI relay is off (both BRI ports are connected to each other, regardless of whether or not the system is running).



This parameter should always be set to ON.

## 5.2.1.2 LOG FILES

CDRs, unconnected calls, system events, trace output and statistics can be saved into files.

The following entries are necessary to generate log files:

**Table 5.17** pabx.cfg: Log File Entries

Entry	Description
ActionLog=/boot/protocol.log	System events
Log=/boot/cdr.log	CDR entries
RRufLog=/boot/failed.log	Unconnected calls
TraceLog=/boot/trace.log	System trace



The available internal memory is approximately 8 MB. Make sure you monitor the available memory.

You can define how the log files are to be divided. There are two possibilities for saving entries into a new file:

- In increments of time (twice-daily, daily, weekly, monthly)
- Depending on the size of the file

You can also define a maximum number of up to 7 files to be generated.

A dash (-) appears in place of information that is to be ignored.

**Table 5.18** pabx.cfg: Log Parameters

Log=/boot/<file> <saved> <size> <count>	
<file>	The name of the log file is generated as follows: [file]yymmdd[0-9 A-Z].log.

## CONFIGURATION FILE PABX.CFG

Table 5.18 pabx.cfg: Log Parameters (continued)

Log=/boot/<file> <saved> <size> <count>	
<saved>	Refers to the frequency with which the file is saved. The following options are possible: <b>halfdaily</b> Every day at 11:59 and 23:59 <b>daily</b> Every day at 23:59 <b>weekly</b> Sunday at 23:59 <b>monthly</b> The last day of the month at 23:59
<size>	Regardless of the value entered in <day>, the file will be saved when the <size> has been reached. NOTE: We recommend a file size of a multiple of 60kB.
<count>	Refers to the number of files that will be saved in the system (between 5 and 35) before the first file is overwritten. This setting is useful not only for limited file size, but also for files that store events. Normally size can be limited for these files, e.g. 5 files of 1MB each. If the fifth file is full, the first one will automatically be overwritten.



**Bear in mind that file size will be unlimited if no parameters are defined.**

**Example 1** In the following entry, the file `cdr.log` is renamed every day. Up to 35 CDR files will be saved on the system.

```
Log=/boot/cdr.log daily - 35
```

**Example 2** In the following entry, the file `failed.log` is renamed once a week. Up to 10 failed files will be saved on the system.

```
RrufLog=/boot/failed.log weekly - 10
```

**Example 3** In the following entry, the file `protocol.log` is renamed when the file has reached 1MB. Up to five log files will be saved on the system.

```
ActionLog=/boot/protocol.log - 1000 5
```



Please remember to keep track of how much memory is available on the system.

### 5.2.1.3 NIGHT CONFIGURATION

The sections for the time-dependent configuration changes and time-controlled routings are defined here.

A maximum of 19 additional daily configuration zones are possible (**Night1** to **Night19**). The entry **NightResetTime** reactivates the original configuration contained in the **System** section.

The entry will have the following syntax:

**Table 5.19** pabx.cfg: Night Parameters

<b>Night&lt;num&gt;=&lt;time&gt; &lt;day&gt;</b>	
<b>&lt;num&gt;</b>	Enter a value between 1 and 19 to define which configuration is to be loaded.
<b>&lt;time&gt;</b>	If there is a time set with the format <b>hh:mm</b> after this entry, this configuration is loaded daily at that time on the defined day.
<b>&lt;day&gt;</b>	Use a bitmask to set the weekdays on which the configuration applies here. The day-mask appears in the following order: <b>HoSaFrThWeTuMoSu</b> .

**Example:** The configuration section is activated Fridays, Wednesdays and Mondays at noon unless the day in question is a holiday:

```
Night2=12:00 00101010
```

The configuration section switches back to the default configuration (**System** section) every day at 8:00 p.m:

```
NightResetTime=20:00 11111111
```

The configuration section is activated on November 5, December 24, and at noon on Mondays:

```
Night1=12:00 10000010
```

```
Holiday=05.11.
```

```
Holiday=24.12.
```



Any defined **Night** sections must be set in the files **pabx.cfg** and **route.cfg**. If there are no changes in these sections, you must copy them from the **System** section. The complete **Subscriber** section must appear in the **Night** section of the **pabx.cfg** (see Chapter 5.2.4 on page 5-53). The active route(s) (**MapALL**, **Restrict** and **Redirect** entries) must appear in the **Night** section of the **route.cfg** (see Chapter 5.3 on page 5-54).

## CONFIGURATION FILE PABX.CFG

## 5.2.1.4 CONTROLLERS

This category defines the parameters that apply to the ports.

The individual ports are defined with the following parameters:

**Table 5.20** pabx.cfg: Controller Parameters

<b>Controller&lt;port&gt;=&lt;bus&gt; &lt;type&gt; &lt;mode&gt; &lt;line_type&gt; UNIT: VALUE:</b>	
<b>&lt;port&gt;</b>	Defines the running (physical) port number.
<b>&lt;bus&gt;</b>	Defines the configured (virtual) port number. In the default configuration, BRI TE ports are 9 and BRI NT ports are 10. VoIP ports are 40.
<b>&lt;type&gt;</b>	Defines the connection type: <b>TE</b> external (Terminal Endpoint) <b>NT</b> internal (Network Termination) <b>VOIP</b> VoIP module <b>DTMF</b> virtual controller for activating DTMF tone recognition
<b>&lt;mode&gt;</b>	Defines the protocol for BRI lines: <b>DSS1</b>
<b>&lt;line_type&gt;</b>	Defines Point-to-Multipoint or Point-to-Point mode: <b>PMP</b> Point-to-Multipoint <b>PP</b> Point-to-Point
<b>UNIT:</b>	(Optional) Defines the currency for the charges (default EUR). Special charge generation is possible for: France <b>UNIT:&amp;F</b> Spain <b>UNIT:&amp;SP</b> Portugal <b>UNIT:&amp;P</b> Greece <b>UNIT:&amp;G</b> Switzerland <b>UNIT:&amp;CH</b> Netherlands <b>UNIT:&amp;NL</b> Italy <b>UNIT:&amp;I</b> <b>NOTE: The &lt;line_type&gt; must be configured for these entries to work.</b> <b>EXAMPLE:</b> Controller02=10 NT DSS1 PMP UNIT:€ VALUE:0.010 Controller03=10 NT DSS1 PMP UNIT:€ VALUE:0.010
<b>VALUE:</b>	(Optional) Defines the charges that accumulate for each unit (default 12).

## CONFIGURATION FILE PABX.CFG

Ports set to the same type can have the same bus number. In this case they will form a trunk group. If you change this parameter in the configuration, you must restart the system.

**Example:**

```
Controller00=9 TE DSS1 PMP
Controller01=9 TE DSS1 PMP
Controller02=10 NT DSS1 PMP
Controller03=10 NT DSS1 PMP
Controller04=40 VOIP
```

## 5.2.1.5 SUBSCRIBERS

Features for each port can be defined using this entry. Changes become active following a restart:

**Table 5.21** pabx.cfg: Subscriber Parameters

Subscriber<port>=<list>	
<port>	Defines the running (physical) port number.
The <list> variable may contain one or more of the following keywords:	
DEFAULT	The standard configuration will be used.
TRANSPARENT ROUTER	Only the number is sent as caller ID (without the virtual port address).
ALARM	Activates the monitoring mode for the respective port. If a relevant error occurs at the port, a remote call is placed to the number defined in RemoteCallBack.
SWITCH	Changes internal port handling. In the default configuration, the VoIP controller is set to NT. You can use this parameter to change it from NT to TE.
CHMAX[x]	Defines the number of VoIP channels (8) or DTMF channels. A maximum of two concurrent channels are possible for DTMF recognition if the callback platform is used.
DTMF[<sec>,/<dir>/<file>]	Please refer to Chapter 11.1.1 ⇨.

## CONFIGURATION FILE PABX.CFG

## 5.2.1.6 GLOBAL SETTINGS

```
Subscriber00 = TRANSPARENT ROUTER ALARM
Subscriber01 = TRANSPARENT ROUTER ALARM
Subscriber02 = TRANSPARENT ROUTER ALARM
Subscriber03 = TRANSPARENT ROUTER ALARM
Subscriber04 = TRANSPARENT ROUTER SWITCH CHMAX[8] ALARM
```

This category contains the following system parameters:

**Table 5.22** pabx.cfg: IP Configuration System Parameters

System Parameters											
VoipGlobalMaxChan=<count>	Max. number of channels for the entire system.										
VoipRtpPort=<port>	Defines the starting UDP port used to transmit RTP packets (default 29000).										
VoipRtpPortSpacing=<count>	Defines the space between the ports used for individual RTP streams (default 2).										
H225Port=<port>	Endpoint-to-endpoint port (default 1720).										
SipPort=<port>	SIP signaling port (default 5060).										
VoipMaximumBandwidth=<int>	<p>Defines an upper limit for available bandwidth for the VoIP profiles to be configured (see <b>VoipBandwidthRestriction</b> in Table 12.97) if traffic shaping is active for the corresponding VoIP profile. Individual codecs are assigned the following values:</p> <table> <tr> <td>g711a, f711u, trp:</td> <td>8</td> </tr> <tr> <td>g72632, t38:</td> <td>4</td> </tr> <tr> <td>g72624</td> <td>3</td> </tr> <tr> <td>g72616, gsm</td> <td>2</td> </tr> <tr> <td>Other</td> <td>1</td> </tr> </table> <p>You must define the list of codecs to be used in the VoIP profiles, whereby the codec with the highest priority must be defined first. Calls will be set up using the codec with the highest priority as long as the sum of the values for individual calls remains lower than defined here. If the sum is greater, the next call will be set up with, and existing calls will be switched to, a higher compression rate. Bear in mind that the VoIP peer must support this feature.</p>	g711a, f711u, trp:	8	g72632, t38:	4	g72624	3	g72616, gsm	2	Other	1
g711a, f711u, trp:	8										
g72632, t38:	4										
g72624	3										
g72616, gsm	2										
Other	1										
VoipStrictRfc3261=<mode>	If <b>yes</b> is set, the SIP transaction/dialog matching will occur strictly as per RFC3261. You must disable this feature for peers that use RFC2543 (from and to name). Default is <b>yes</b> .										

## CONFIGURATION FILE PABX.CFG

Table 5.22 pabx.cfg: IP Configuration System Parameters (continued)

System Parameters
<p><b>StunServerAddress</b>=&lt;ip addr&gt;</p> <p>When this parameter is active, the VoIPBOX BRI looks for a (NAT) firewall in the network and figures out how to bypass it without requiring changes. All ports for signaling, RTP and RTCP are checked. The parameter <b>VoipGlobalMaxChan</b> defines the number of ports for RTP and RTCP.</p> <p>NOTE: This is not a solution for all firewall types.</p>
<p><b>StunServerPollInterval</b>=&lt;sec&gt;</p> <p>Interval (in seconds) for the stun request at each port (default 600).</p>
<p><b>Radius</b>=&lt;mode&gt;</p> <p><b>On</b> (default) activates the Radius service. If you change <b>Off</b> to <b>On</b>, you must restart the system.</p>
<p><b>RadiusAuthPort</b>=&lt;num&gt;</p> <p>Port used for Radius authentication (default 1812).</p>
<p><b>RadiusAcctPort</b>=&lt;num&gt;</p> <p>Port used for Radius accounting (default 1813).</p>
<p><b>NameServer</b>=&lt;ip addr&gt;</p> <p>IP-address configuration for the DNS server. Enter your network or ISP's DNS server. If you don't know it, you can also enter another DNS server. If you have more than one address, enter this parameter up to three times on different lines.</p>
<p><b>Timezone</b>=&lt;continent/city&gt;</p> <p>Defines the time difference between the VoIPBOX BRI's time zone and time zone 0 (Greenwich Mean Time). Enter the continent and a large city (usually the capital) in the time zone.</p>
<p><b>NtpServer</b>=&lt;ip addr&gt;</p> <p>Sets the IP address at which the VoIPBOX BRI's SNTP server queries the standard time. The query occurs every four hours.</p> <p><b>NOTE: If your system is not attached to an NTP server, you can enter the following configuration to query the time on an attached PBX via a TE port:</b></p> <p><b>Subscriber=...TIME</b></p>
<p><b>MoipPort</b>=&lt;port&gt;</p> <p>Defines the GATE Manager access port (default 4445).</p>
<p><b>FtpdPort</b>=&lt;port&gt;</p> <p>Defines the FTP access port (default 21).</p>
<p><b>TelnetdPort</b>=&lt;port&gt;</p> <p>Defines the TELNET access port (default 23).</p>

## CONFIGURATION FILE PABX.CFG

Table 5.22 pabx.cfg: IP Configuration System Parameters (continued)

System Parameters
<p>TftpdPort=&lt;port&gt; Defines the TFTP access port (default 69).</p>
<p>Ftpd=&lt;mode&gt; Activates (on) or deactivates (off) FTP access. Default on.</p>
<p>Telnetd=&lt;mode&gt; Activates (on) or deactivates (off) TELNET access. Default on.</p>
<p>Tftpd=&lt;mode&gt; Activates (on) or deactivates (off) FTP access. Default off.</p>
<p>RemotePassword=&lt;password&gt; Defines the password for FTP and GATE Manager access. Please refer to Chapter 4.11.4 ⇨ for instructions on how to enter an encrypted password in the <code>pabx.cfg</code>. If you do not define a password, access to the system via GATE Manager occurs without a password, and FTP access occurs with the default password <code>tcs-ag</code>.</p>
<p>DialTone=&lt;country&gt; If the system is used in a corporate settings and attached through a PBX to the PSTN, it may be necessary to generate the carrier's dial tone. It depends on whether the system sends the dialed digits to the PSTN or whether it waits for a routing entry to take the call. The following values can be entered:</p> <ul style="list-style-type: none"> <li>GE</li> <li>DE</li> <li>IR</li> <li>UK</li> <li>US</li> <li>FR</li> <li>IT</li> </ul>

**Example:**

```
VoipGlobalMaxChan=8
H225Port=1720
SipPort=5060
VoipRtpPort=29000
VoipRtpPortSpacing=2
StunServerAddress=172.16.0.1
StunServerPollInterval=600
NameServer=192.168.0.254
Timezone=Europe/Berlin
NtpServer=192.168.0.254
DialTone=GE
```

## CONFIGURATION FILE PABX.CFG



There is no internal time generation for the system when the power is interrupted. That means the default time is used when the system is restarted or rebooted! Therefore it is important to set the system time with an NTP server. If the system is connected via BRI, a clock may come from the network connected to the corresponding port. Enter **TIME** in the `pabx.cfg`'s `Subscriber` line for the BRI port to take the time from the port.

## 5.2.2 SMTP-CLIENT CONFIGURATION

The following entries in the `pabx.cfg`'s `[Mail]` section are used to send e-mail messages from the VoIPBOX BRI. The connection to the SMTP server can be used to send CDR files or alarm messages.



You must restart the system after making changes to activate the settings.

The following features are possible:

- Sending CDRs via e-mail
- Sending alarm messages via e-mail

SmtServer=<ip addr> In <ip addr>, enter the IP address of the destination SMTP server that is to receive the e-mail messages.
MailUserIn=<username> Enter a username for incoming e-mail authentication.
MailUserOut=<username> Enter a username for outgoing e-mail authentication.
MailPwdIn=<password> Enter a password for incoming e-mail authentication.
MailPwdOut=<password> Enter a password for outgoing e-mail authentication.
MailAuthEncr=<type> Enter an encryption method for e-mail authentication (default base64).
MailRcpt=<domain> In <domain>, enter the destination domain, the destination address and an @ sign. If the destination address is already complete (with an @ sign), <domain> is not added.

## CONFIGURATION FILE PABX.CFG

MailFrom=<domain> In <domain>, enter the source domain, the source address and an @ sign. If the source address is already complete (with an @ sign), <domain> is not added.
MailRcvMax=<count> Maximum number of incoming e-mails queued for transmission via SMS or USSD.
MailRcptMax=<count> Number of "RCPT TO" entries in e-mails that come from the LAN (a message is sent to the LCR for each "RCPT TO" entry in each incoming e-mail).
MaxMailsToHost=<count> Maximum number of e-mail messages sent to the LCR simultaneously.
MailToHostDelay=<count> Number of seconds until an e-mail message is sent to the LCR (this timer runs separately for each MaxMailsToHost message).
MailToHostRetries=<count> Number of retries when SMS transmission is not successful. When the limit entered is reached, an error message is sent to the e-mail sender (default 3).
MailSendRetries=<count> Number of times an attempt is made to send an e-mail.
MailMaxIncomingClients=<count> Defines the maximum number of clients that can access the system simultaneously. If 0 is entered, the SMTP port (25) will be blocked for incoming sessions. Default 5.
MailTcpRcvTimeout=<sec> Defines the number of seconds after which a session will be terminated following a possible receiving error in the data stream. Default 0 (immediately).
MailTcpSndTimeout=<sec> Defines the number of seconds after which a session will be terminated following a possible transmission error in the data stream. Default 0 (immediately).
MailAllowedPeers=<ip addr> Defines IP addresses from which incoming SMTP connections will be accepted. Separate IP addresses with a space. If a dash (-) is entered, the SMTP port (25) will be blocked for incoming sessions. If this parameter is left empty (default), incoming connections will be accepted from all IP addresses.
MailPropPort=<num> Enter the port number for a TELES proprietary mail protocol.

## CONFIGURATION FILE PABX.CFG

**Example:**

```
[Mail]
SmtServer=172.16.0.10
MailRcpt=teles.de
MailFrom=172.16.0.100
MailRcvMax=500
MailRcptMax=100
MaxMailsToHost=2
MailToHostDelay=3000
MailToHostRetries=10
MailSendRetries=10
MailAllowedPeers=172.16.0.10
```

**Sending Alarm Messages via E-mail**

With the appropriate configuration, you can send e-mails containing alarm messages that are written into the log file. The sender is given as `alarm` and the system's name appears in the subject box. The text box contains the alarm message.

The following entry in the configuration file activates this function:

```
...
ActionLog=/data/protocol.log daily 1000 5 @<e-mail account>
...
```

**5.2.3 SNMP SETTINGS**

The Simple Network Management Protocol facilitates network management and monitoring of VoIPBOX BRI network devices and their functions. For a detailed description of SNMP configuration, please refer to Chapter 13.4 ⇒.



**You must restart the system after making changes to activate the settings.**

**5.2.4 TIME-CONTROLLED CONFIGURATION SETTINGS**

The `[Night<num>]` section is reserved for prospective time-controlled configuration changes. In the `pabx.cfg` file, the `Night` sections contain all of the system's `Subscriber` entries. Simply copy all `Subscriber` lines into the `Night` Section without making any changes.

## CONFIGURATION FILE ROUTE.CFG

## 5.3 CONFIGURATION FILE ROUTE.CFG

The system's routing information is saved in the `route.cfg`. The file contains the following sections:

- [System]
- [Night<num>]
- [VoIP=<name>]
- [GateKeeper=<name>]
- [Registrar=<name>]
- [Radius=<name>]

## 5.3.1 ENTRIES IN THE SECTIONS [SYSTEM] AND [NIGHT&lt;NUM&gt;]

The sections [System] and [Night<num>] contain the following entries.

## 5.3.1.1 MAPPING

Mapping entries begin with the keyword `MapAll`.

**Table 5.23** route.cfg: Map Parameters

<b>MapAll&lt;direct&gt;=&lt;num&gt; &lt;mode&gt;</b>	
<b>&lt;direct&gt;</b>	Defines the prefix or telephone number for which the entry applies.
<b>&lt;num&gt;</b>	Defines the following in the order given: <ul style="list-style-type: none"> <li>▪ Destination port's controller number</li> <li>▪ Optional VoIP profile name followed by a colon if the call is terminated via VoIP</li> <li>▪ Optional prefix</li> <li>▪ Part of the number on the left that is transmitted</li> </ul> The special symbol <code>?</code> may be used as a wildcard to represent any digit.
<b>&lt;mode&gt;</b>	<b>VOICE</b> Applies for calls with the service indicator <b>voice</b> (default). <b>DATA</b> Applies for calls with the service indicator <b>data</b> .

**Example:** In the following example, all international calls are sent to the VoIP carrier (**40**) with the profile name **DF**. All national calls are sent to the BRI controller with the number **9**:

```
MapAll100=40DF:00
MapAll10=90
```

## CONFIGURATION FILE ROUTE.CFG

## 5.3.1.2 RESTRICT

This entry is for controller-specific routing entries. These entries apply only for a single controller and can be set for an OAD base number or an MSN:

**Table 5.24** route.cfg: Restrict Parameters

<b>Restrict&lt;ns&gt;=&lt;num&gt; &lt;sin&gt;</b>																							
<b>&lt;ns&gt;</b>	Defines the virtual controller number plus an optional base number or a specific calling number. The special symbol ? may be used as a wildcard to represent any digit.																						
<b>&lt;pl&gt;</b>	Stands for a virtual placeholder used for the mapping entry that routes calls for the the <b>Restrict</b> command.																						
<b>&lt;sin&gt;</b>	<p>The service indicator variable <b>sin</b> restricts the command to one service. Without a <b>sin</b>, the <b>Restrict</b> command is valid for all services.</p> <p>Possible service indicator values are:</p> <table> <tbody> <tr><td>01</td><td>Telephony</td></tr> <tr><td>02</td><td>Analog services</td></tr> <tr><td>03</td><td>X.21-services</td></tr> <tr><td>04</td><td>Telefax group 4</td></tr> <tr><td>05</td><td>Videotext (64 kbps)</td></tr> <tr><td>07</td><td>Data transfer 64 kbps</td></tr> <tr><td>08</td><td>X.25-services</td></tr> <tr><td>09</td><td>Teletext 64</td></tr> <tr><td>10</td><td>Mixed mode</td></tr> <tr><td>15</td><td>Videotext (new standard)</td></tr> <tr><td>16</td><td>Video telephone</td></tr> </tbody> </table>	01	Telephony	02	Analog services	03	X.21-services	04	Telefax group 4	05	Videotext (64 kbps)	07	Data transfer 64 kbps	08	X.25-services	09	Teletext 64	10	Mixed mode	15	Videotext (new standard)	16	Video telephone
01	Telephony																						
02	Analog services																						
03	X.21-services																						
04	Telefax group 4																						
05	Videotext (64 kbps)																						
07	Data transfer 64 kbps																						
08	X.25-services																						
09	Teletext 64																						
10	Mixed mode																						
15	Videotext (new standard)																						
16	Video telephone																						

**Example:** In the following example, all calls coming from BRI controller 9 (PSTN) are sent to BRI controller 10 (PBX) without regard to the routing file:

```
Restrict9=pl
MapAllpl=10
```

## CONFIGURATION FILE ROUTE.CFG

## 5.3.1.3 REDIRECT

This entry facilitates alternative routing when the first destination cannot be reached or is busy. A placeholder appears to the right of the equal sign. The routing entry (**MapAll**) can be defined for the redirect using the placeholder entered:

**Table 5.25** route.cfg: Redirect Parameters

<b>Redirect&lt;type&gt;&lt;num&gt;=&lt;redirect&gt; &lt;sin&gt; &lt;time&gt;</b>	
<b>&lt;type&gt;</b>	Enter 2, 3 or 5 to set the following types: 2            call forwarding no answer 3            call forwarding when busy 5            call forwarding when busy and no answer
<b>&lt;num&gt;</b>	Defines the number for which calls will be redirected. The special symbol ? may be used as a wildcard to represent any digit.
<b>&lt;redirect&gt;</b>	Defines the placeholder used in the two-target routing entry and the number to which calls to <x> will be redirected.
<b>&lt;sin&gt;</b>	The service indicator variable sin restricts the command to a service. Without a sin, the <b>Redirect</b> command is valid for all services. Possible service indicator values are: 00           All services 01           Telephony 02           Analog services 03           X.21-services 04           Telefax group 4 05           Videotext (64 kbps) 07           Data transfer 64 kbps 08           X.25-services 09           Teletex 64 10           Mixed mode 15           Videotext (new standard) 16           Video telephone NOTE: Fax forwarding must be set for analog and telephony services because incoming fax calls from the analog network may arrive with either telephony or analog service indicators.
<b>&lt;time&gt;</b>	Optional. For type 2 redirect entries, a timer (in seconds) can be defined after the service indicator entry. NOTE: In the entry is to apply for all service indicators, the value 00 must be defined for <sin>.

## CONFIGURATION FILE ROUTE.CFG

**Example:** In the following example all international calls (beginning with 00) are sent to VoIP controller 40 with the carrier profile DF. If the carrier cannot be reached or is busy, the redirect command activates the second target mapping with the placeholder A and the call is automatically sent to BRI controller 9.

```
MapAll00=40DF:00
Redirect340DF:=A
MapAllA=9
```

### Excluding Busy Calls or Specific Cause Values from Redirect

Defines a hexadecimal cause value according to DSS1. When connections to the destination are rejected because of the reason defined by the cause value, the VoIPBOX BRI sends a busy signal to the attached PBX. Alternative routing is not carried out.

To avoid second-choice routings when the called-party number is busy, set the following parameter in the first-choice port's `Subscriber` line in the `pabx.cfg`:

<b>BUSY[&lt;cause&gt;]</b>	Defines a hexadecimal cause value according to DSS1. When connections to the destination are rejected because of the reason defined by the cause value, the VoIPBOX BRI sends a busy signal to the attached PBX. Alternative routing is not carried out. You can also define a range of consecutive cause values: <code>BUSY[&lt;cause&gt;, &lt;cause&gt;]</code>
----------------------------	--

**Example:** In the following example, all outgoing calls over controller 04 are rejected with the cause value 91 when the called party is busy. Alternative routing is not carried out.

```
Subscriber04=...BUSY[91]
```

## 5.3.2 VOIP PROFILES

This section includes all of the most important parameters for communication with the VoIP peer.

## CONFIGURATION FILE ROUTE.CFG

## Basic Parameters

Table 5.26 route.cfg: VoIP Basic Parameters

VoIP Basic Parameters	
[Voip=<name>]	Name of the routing profile. The name must begin with a letter and should be short and meaningful.
VoipDirection=<mode>	Defines the direction in which VoIP calls can be set up. Possible options: <b>In, Out, IO, None</b> ).
VoipPeerAddress=<ip addr> or <name>	The peer's IP address or name. Default is 0 (if it is not set, the parameter VoipIpMask should be set to 0x00000000).
VoipIpMask=<ip mask>	The subnetmask is used to determine the size of the IP address range for incoming traffic. The syntax is 0x followed by the mask in hexadecimal notation. Example of a Class C mask entry: <b>0xfffff00</b> . Default is 0xffffffff (only incoming traffic is accepted from the defined peer address).
VoipSignalling=<int>	Determines the profile's signaling protocol for outgoing VoIP calls. In the case of incoming calls, autorecognition ensures that each call from the peer is accepted, regardless of the protocol: 0=H.323 (default), 1=SIP udp, 2=SIP tcp.

## CONFIGURATION FILE ROUTE.CFG

Table 5.26 route.cfg: VoIP Basic Parameters (continued)

VoIP Basic Parameters
<p><b>VoipCompression=&lt;list&gt;</b>  The compression to be used, in order of preference. At least one matching codec with the peer must be defined.</p> <p><b>Voice:</b></p> <p><b>g729, g729a, g729b, g729ab</b>  These codecs have a bit rate of 8 kbit/s (compression ratio 1:8). A stands for Annex A and B for Annex B.</p> <p><b>g72616, g72624, g72632</b>  These ADPCM codecs have various bit rates: g72616 = 16kBit/s (compression ratio 1:4), g72624 = 24kBit/s and g72632 = 32kBit/s (compression ratio 1:2).  NOTE: G726 32kBit/s can also be signaled as G.721 by using the entry g721.</p> <p><b>g728</b>  The Codec has a bit rate of 16kBit/s (compression ratio 1:4).</p> <p><b>g711a, g711u</b>  These PCM codecs have a bit rate of 64kBit/s. No voice compression occurs. a stands for a-law and u for <math>\mu</math>-law.</p> <p><b>g723, g723L</b>  These codecs work with 30ms data frames. g723.1 uses a bit rate of 6.3 kbit/s, and g723L uses a bit rate of 5.3 kbit/s to send RTP packets.  NOTE: This has no influence on the compression ratio of incoming RTP packets. Both sides must be able to receive both ratios.</p> <p><b>gsm</b>  GSM-FR (full rate) has a bit rate of 13 kbit/s.  The following codecs are also possible: g721 (SIP only)</p> <p><b>Fax: t38</b>  T.38 (fax over IP) allows the transfer of fax documents in real time between 2 fax machines over IP. Following fax detection during a call, the voice codec will switch to T.38.</p> <p><b>Data: trp</b>  Transparent or clear mode (RFC 4040). Transparent relay of 64 kbit/s data streams.</p> <p><b>gnx64</b>  <b>ccd</b>  Clear-channel signaling (as per RFC3108)</p> <p>Define a special profile for data call origination or destination numbers. Bear in mind that echo cancelation in this VoIP profile might be switched off (<b>VoipECE=no</b>).</p>

## CONFIGURATION FILE ROUTE.CFG

Table 5.26 route.cfg: VoIP Basic Parameters (continued)

VoIP Basic Parameters
<p><b>VoipMaxChan=&lt;count&gt;</b>            Maximum number of channels that can be used with the profile. If this parameter is not defined (default), there will be no limit.            NOTE: For versions 13.0c or lower, we recommend that you also set the parameter <b>VoipDelayDisc</b> to <b>Yes</b> to improve the ASR.</p>
<p><b>VoipSilenceSuppression=&lt;mode&gt;</b>  <b>Yes</b> (default) activates silence suppression, CNG (comfort noise generation) and VAD (voice activity detection). <b>No</b> deactivates silence suppression.            NOTE: In SIP signaling, silence suppression is negotiated as per RFC3555.</p>
<p><b>VoipTxM=&lt;num&gt; or &lt;list&gt; fix</b>            The multiplication factor (1-12) for the frame size for transmission of RTP packets (default is 4). 10ms is the default frame size. A list can be defined if different frame sizes are to be used for different codecs in the VoIP profile. The list must correspond with the list in the parameter <b>VoipCompression</b>.            Normally the peer's frame size will be used if it is smaller than the one defined. If you enter <b>fix</b>, the configured factor will always be used.</p>

Please refer to Chapter 8 ⇨ for information on other possible entries.

## CONFIGURATION FILE ROUTE.CFG

## Management Parameters

Table 5.27 route.cfg: VoIP Management Parameters

VoIP Management Parameters
<p><b>VoipGk=&lt;list&gt;</b> Name of the assigned gatekeeper profile. You can assign a profile to several gatekeepers to define backup gatekeepers for a VoIP profile. In this case, the next gatekeeper will be used if the previous one fails.</p>
<p><b>VoipProxy=&lt;ip addr&gt;</b> Enter the IP address of the SIP server.</p>
<p><b>VoipUser=&lt;username&gt;</b> Define the username for the remote device if authentication is required (SIP only).</p>
<p><b>VoipPwd=&lt;password&gt;</b> Define the password for the remote device if authentication is required (SIP only).</p>
<p><b>VoipRegistrar=&lt;name&gt;</b> Enter the name of a registrar to be used for the VoIP profile.</p>
<p><b>VoipRadiusAuthenticate=&lt;name&gt;</b> Enter the name of the Radius server to activate user authentication.</p>
<p><b>VoipRadiusAccounting=&lt;name&gt;</b> Enter the name of the Radius server to activate accounting.</p>
<p><b>VoipLogging=&lt;mode&gt;</b> Enter Yes to activate recording IP addresses in the CDRs (default is No). The first IP address is the signaling address and the second is the RTP address, followed by the the codec and the frame size used. . The IMSI appears after the IP addresses if the keyword IMSI is defined in the pabx.cfg.</p> <p>Example of a CDR entry: 21.08.07-11:01:42,21.08.07-11:01:58,40,912345,192.168.0.2:192.168.0.2,G729,10,0101,16,10,0</p> <p>Example of a failed log entry: 21.08.07-11:11:30,40,91234,192.168.0.2:192.168.0.2,G729,10,0101,ff,2,1</p>

## 5.3.3 GATEKEEPER PROFILES

Gatekeeper profiles are used to connect the VoIPBOX BRI to several systems by using a gatekeeper if the protocol is H.323. It is possible to configure different gatekeepers for different destinations and to define backup gatekeep-

## CONFIGURATION FILE ROUTE.CFG

ers. These gatekeeper profiles are then assigned to the VoIP profiles:

**Table 5.28** route.cfg: Gatekeeper Parameters

Gatekeeper Parameters	
[Gatekeeper=<name>]	Name of the gatekeeper profile.
RasPort=<port>	Indicates the port the gatekeeper uses (default 1719) for registration, admission and status.
OwnRasPort=<port>	Indicates the port the system uses (default 1719) for registration, admission and status.
RasPrefix=<list>	VoIPBOX BRI's defined prefix(es). Use a space to separate entries.
RasId=<name>	The alias used for gatekeeper registration.
GkId=<name>	The gatekeeper's alias.
GkPwd=<name>	Password to log onto the gatekeeper. If you do not use authentication, leave this entry blank.
GkAdd=<ip addr>	The gatekeeper's IP address.
GkTtl=<sec>	Gatekeeper time to live (default 0 means infinite).
GkMaxChan=<count>	Max. number of channels used for this gatekeeper. If this parameter is not defined (default), there will be no limit.
GkUseStun=<mode>	Enter <b>yes</b> (default) to use the STUN values for the GK profile.
GkTerminalAliasWithPrefix=<mode>	Some gatekeepers may require that prefixes are listed in the Terminal Alias section. Enter <b>Yes</b> to activate this function; default value is <b>No</b> .
GkTerminalTypeWithPrefix=<mode>	Enter <b>no</b> to deactivate sending the Dialed Prefix Information in the Registration Request (default <b>yes</b> ).

## CONFIGURATION FILE ROUTE.CFG

## 5.3.4 REGISTRAR PROFILES

Registrar profiles are used to register the VoIPBOX BRI with a SIP registrar. It is possible to configure different registrars for different destinations and to define backup registrars. These registrar profiles are then assigned to the VoIP profiles:

**Table 5.29** route.cfg: Registrar Parameters

Registrar Parameters	
[Registrar=<name>]	The name of the registrar profile.
RegId=<name or ip addr>	Host name or IP address used in the register's request header. Bear in mind that the DNS service must be active if you enter the host name.
RegOwnId=<name@ip addr/domain>	Typically a host name or telephone number followed by an @ sign and a domain name or IP address. The entry used in the <b>From:</b> field. The default setting is <b>RegUser@RegId</b> .
RegContact=<name or ip addr>	Used in the <b>Contact:</b> field.
RegUser=<name>	Enter a username for authorization.
RegPwd=<password>	Enter a password for authorization.
RegProxy=<ip addr>	Enter an alternative IP address if you want the request to be sent to an address other than the one entered in <b>RegId</b> .
RegExpires=<sec>	Enter the number of seconds registration is to be valid. Default 0 means infinite.
RegPing=<sec>	Interval (in seconds) for the registrar ping. The TELES.VoIPBOX sends an empty UDP packet to the registrar's IP address. The packet is essentially an alive packet to avoid possible firewall problems.

## CONFIGURATION FILE ROUTE.CFG

## 5.3.5 RADIUS PROFILES

Radius profiles are used to connect the VoIPBOX BRI to a Radius server. You can use a Radius server for different destinations and for access and/or accounting. These Radius profiles are then assigned to the VoIP profiles:

**Table 5.30** route.cfg: Radius Parameters

Radius Parameters	
[Radius=<name>]	The name of the Radius server profile assigned to one or more VoIP profiles.
Host=<name or ip addr>	Radius server's host name or IP address. Bear in mind that the DNS service must be active if you enter the host name.
User=<name>	Enter a username for authorization.
Password=<password>	Enter a password for authorization.
Secret=<secret>	Enter the shared secret.
OwnId=<name or ip addr>	Host name or IP address used in the NAS identifier or NAS IP address (Cisco VSA gateway ID).
ServiceType=<num>	As defined in RFC 2865, Chapter 5.6.
RequestTimeout=<sec>	Number of seconds during which the request is repeated if the Radius server does not respond.
RequestRetries=<count>	Number of packet retries sent at one time.
StopOnly=<mode>	When <b>yes</b> is entered, only Accounting Request Messages with the status type <b>stop</b> are transmitted to the Radius server.
AlwaysConnected=<mode>	Enter <b>No</b> (default) to set the value for the field <b>ConnectedTime</b> to that of the field <b>DisconnectedTime</b> in accounting-stop messages when the call was not connected.
CallingStationId=<num>	This parameter is used to set the calling station ID. The default setting is the OAD, but you can define any calling station ID. To define a partial calling station ID, enter a ? for each digit. For example, <b>CallingStationId=???</b> will consist of the first three digits of the OAD.

## CONFIGURATION FILE ROUTE.CFG

Table 5.30 route.cfg: Radius Parameters (continued)

Radius Parameters
<p>CallType=&lt;int&gt;</p> <p>Enter one of the following to define the call type:</p> <ul style="list-style-type: none"> <li>3 = VoIP and telephony</li> <li>2 = VoIP only</li> <li>1 = Telephony only</li> </ul>
<p>FramedProtocol=&lt;int&gt;</p> <p>Enter one of the following to define the framed protocol (see RFC 2865, Chapter 5.7):</p> <ul style="list-style-type: none"> <li>1 = PPP</li> <li>2 = SLIP</li> <li>3 = AppleTalk Remote Access Protocol (ARAP)</li> <li>4 = Gandalf proprietary SingleLink/MultiLink protocol</li> <li>5 = Xylogics proprietary IPX/SLIP</li> <li>6 = X.75 Synchronous</li> </ul>
<p>NasId=&lt;string&gt;</p> <p>The string entered is used as network access server identifier attribute in access requests. If no string is entered, the attribute will not be set (default).</p>

## 6 ROUTING EXAMPLES

The following examples describe possible implementation scenarios for H.323, SIP and connection to a Radius server.

### H.323

- VoIPBOX BRI in an H.323 network (Chapter 6.2 ⇒)
- Backbone router using a backup gatekeeper (Chapter 6.5 ⇒)
- Backbone router with direct endpoint signaling (Chapter 6.6 ⇒)

### SIP

- VoIPBOX BRI as a second-generation LCR and registration with a SIP carrier (Chapter 6.1 ⇒)
- Work@home scenario with signaling through a SIP proxy (Chapter 6.3 ⇒)

Authentication and accounting on a Radius server (Chapter 6.8 ⇒)

VoIP backup and automatic reactivation (Chapter 6.9 ⇒)


## VOIPBOX BRI AS A SECOND-GENERATION LCR

## 6.1 VOIPBOX BRI AS A SECOND-GENERATION LCR

In the following example of a PBX connection, all international calls are terminated to VoIP (40). The VoIP carrier profile DF and the SIP protocol are used. Block dialing is used, and the last digit waits three seconds. National calls are routed through the carrier with the prefix 01078. All other calls are sent to the PSTN unchanged. All calls from the PSTN or from a VoIP carrier are sent directly to the NT controller, to which the PBX is attached.

For the VoIP profile DF, the system uses the registrar reg and registers with myself.home.com, username user and password pwd. SIP UDP is used for signaling.

A maximum of 8 media channels with the G.729 codec can be used. The peer's IP address is 192.168.0.10.



**Bear in mind that emergency calls must be routed to the PSTN.**

```
[system]

DTMFWaitDial=3

MapAll00=|40DF:00<<24
MapAll0=9010780
MapOut?=9?
Restrict9=pl
Restrict40=pl
MapAllpl=10

[Voip=DF]
VoipDirection=I0
VoipPeerAddress=domain.com
VoipIpMask=0x00000000
VoipSignalling=1
VoipCompression=g729 g711a t38
VoipSilenceSuppression=Yes
VoipProxy=192.168.0.150
VoipOwnAddress=user@domain.com
VoipUser=user
VoipPwd=pwd
VoipMaxChan=8
VoipTxM=2
VoipRegistrar=reg

[Registrar=reg]
RegId=domain.com
RegOwnId=user.domain.com
RegUser=user
RegPwd=pwd
RegProxy=192.168.0.150
```

## VOIPBOX BRI IN AN H.323 NETWORK


## 6.2 VOIPBOX BRI IN AN H.323 NETWORK

In the following example all voice calls from the BRI NT lines (10) are routed through VoIP (40) to the VoIP carrier with the profile name DF. All calls from VoIP (40) are routed to the BRI NT controller (10).

H.323 is used as the signaling protocol and a gatekeeper is used in the VoIP network. Because the gatekeeper assigns and authorizes the peer, only one VoIP profile is necessary. Since the peers may use various compression algorithms, you can define several if you so choose.

The codec with the highest priority is G.729. If the peer does not support it, G.72632, G.711a, G.711u and are also possible. Silence suppression is active.

The gatekeeper's IP address is 192.168.0.10. This gatekeeper profile can handle up to 8 simultaneous VoIP calls. The VoIPBOX BRI's alias is VoIPBOX01. The prefix is 0049. The gatekeeper's alias is GK1 and no password is used:



```
[System]

;To BRI
Restrict40=tobri
MapAlltobri=10
;To VoIP
MapAll?=40DF:?


[Voip=DF]
VoipDirection=I0
VoipPeerAddress=0.0.0.0
VoipIpMask=0x00000000
VoipSignalling=0
VoipCompression=g729 g72632 g711a g711u t38
VoipSilenceSuppression=Yes
VoipMaxChan=8
VoipTxM=4
VoipGk=GK1

[Gatekeeper=GK1]
RasPort=1719
OwnRasPort=1719
RasId=VoIPBOX01
RasPrefix=0049
GkId=GK
GkAdd=192.168.0.10
GkPwd=
GkTtl=300
GkMaxChan=8
```

## WORK@HOME SCENARIO WITH SIGNALING THROUGH A SIP PROXY

## 6.3 WORK@HOME SCENARIO WITH SIGNALING THROUGH A SIP PROXY

The following example of a route.cfg file the company has two permanent employees working at home. The extension numbers 1111 and 2222 are assigned to these two users. All calls with these destination numbers that come from the PSTN, the connected SIP carrier profile, and the attached ISDN PBX are routed directly with the two profiles User1 and User2 to the employees. If these SIP phones are not registered, the calls are routed to the company's operator. The symmetric RTP is also activated, which avoids dead-air calls from remote users that are behind a NAT firewall.



**Bear in mind that if names are used instead of IP addresses, the DNS service must be activated.**

```
[System]
;incoming traffic from PSTN and VoIP
Restrict9=pl
Restrict40=pl

;destination number routing for remote users
MapAll1111=40User1:1111
MapAll2222=40User2:2222
MapAllpl1111=40User1:1111
MapAllpl2222=40User2:2222

;redirect of calls in case the phones are not reachable
Redirect340User1:=red
Redirect340User2:=red
MapAllred1111=100
MapAllred2222=100

;all other calls from PSTN or VoIP send to ISDN PBX unchanged
MapAllpl=10

; all calls from ISDN PBX to VoIP carrier except remote users
DTMFWaitDial=5
MapAll0=|40DF:0<<24
MapAll1=|40DF:1<<24
MapAll2=|40DF:2<<24
MapAll3=|40DF:3<<24
MapAll4=|40DF:4<<24
MapAll5=|40DF:5<<24
MapAll6=|40DF:6<<24
MapAll7=|40DF:7<<24
MapAll8=|40DF:8<<24
MapAll9=|40DF:9<<24
MapAll*=|40DF:*<<24
MapAll#=|40DF:#<<24
```

Example continued on next page:

## WORK@HOME SCENARIO WITH SIGNALING THROUGH A SIP PROXY

```

;VoIP profile for remote user
[Voip:User1]
VoipDirection=I0
VoipIpMask=0x00000000
VoipOwnUser=1111
VoipOwnPwd=pwd
VoipAuth=www
VoipExpires=600
VoipCompression=g729 g723 g711a g711u t38
VoipSilenceSuppression=Yes
VoipSignalling=1
VoipMaxChan=2
VoipTxM=2
VoipMediaWaitForConnect=Tone
VoipDtmfTransport=3
VoipRFC2833PayloadType=101
;SBC feature to avoid one way voice for peer systems behind NAT:
VoipAutoRtpAddr=Yes
VoipT303=5

[Voip:User2]
VoipDirection=I0
VoipIpMask=0x00000000
VoipOwnUser=2222
VoipOwnPwd=pwd
VoipAuth=www
VoipExpires=600
VoipCompression=g729 g723 g711a g711u t38
VoipSilenceSuppression=Yes
VoipSignalling=1
VoipMaxChan=2
VoipTxM=2
VoipMediaWaitForConnect=Tone
VoipDtmfTransport=3
VoipRFC2833PayloadType=101
VoipAutoRtpAddr=Yes
VoipT303=5

;VoIP profile to connect with the SIP network:
[Voip=DF]
VoipDirection=I0
VoipPeerAddress=sip-carrier.com
VoipIpMask=0xffffffff
VoipUser=user
VoipPwd=pwd
VoipSignalling=1
VoipCompression=g729 g723 g711a g711u t38
VoipSilenceSuppression=Yes
VoipMaxChan=8
VoipTxM=2
VoipDtmfTransport=3
VoipRFC2833PayloadType=101
VoipRegistrar=Reg

[Registrar=Reg]
RegId=sip-carrier.com
RegUser=user
RegPwd=pwd
RegExpires=3600


```

## ISDN DIAL-UP FOR TERMINATING VOIP CALLS

## 6.4 ISDN DIAL-UP FOR TERMINATING VOIP CALLS

In the following example of the `ip.cfg`, the VoIPBOX BRI's IP address is 192.168.1.2. No default gateway is configured. The standard route is assigned to the ISDN PPP interface. When the packets to be routed (firewall configuration) set up this connection using dial-on-demand, the ISDN dial-up Internet connection with the number 12345 (Dad=) is set up to terminate VoIP calls. the username is `user` and the password is `pwd`.

The firewall settings allow only SIP UDP signaling packets and RTP/RTCP packets for ports 29000-29015 in both directions. This can be used in locations without broadband Internet connection and generally have several simultaneous voice calls. Only one ISDN B-channel connection to the Internet is set up, but up to six simultaneous voice calls can be transmitted (depending on the codec and options used). If no voice call takes place over the dial-up connection for 20 seconds, the connection is torn down:



```
[System]

[emac0]
IpAddress=192.168.1.2/24

[xppp0]
Dad=12345
User=user
Pwd=pwd
Route=0.0.0.0
AuthProto=chap
IdleT0=20
MTU=1500
Rfc1662=0

[firewall]
#localnetwork
fw=pass out quick on emac0 from any to any
fw=pass in quick on emac0 from any to any
#loopback
fw=pass in quick on emac0 all
fw=pass out quick on emac0 all

#outgoing traffic
fw=pass out quick on xppp0 proto udp from any to any port eq 5060 keep state keep frags
fw=pass out quick on xppp0 proto udp from any to any port eq 29000 keep state keep frags
fw=pass out quick on xppp0 proto udp from any to any port eq 29001 keep state keep frags
...
fw=pass out quick on xppp0 proto udp from any to any port eq 29015 keep state keep frags

#incoming traffic
fw=pass in quick on xppp0 proto udp from any to any port eq 5060 keep state keep frags
fw=pass in quick on xppp0 proto udp from any to any port eq 29000 keep state keep frags
fw=pass in quick on xppp0 proto udp from any to any port eq 29001 keep state keep frags
...
fw=pass in quick on xppp0 proto udp from any to any port eq 29015 keep state keep frags

# other will be blocked
fw=block in log quick on xppp0 all
fw=block out log quick on xppp0 all
```

## BACKBONE ROUTER USING A BACKUP GATEKEEPER


## 6.5 BACKBONE ROUTER USING A BACKUP GATEKEEPER

In the following example all voice calls from the BRI PBX line (10) are routed through VoIP (40) to the VoIP carrier with the profile name DF. All calls from VoIP (40) are routed to the BRI NT controller (10).

A backup gatekeeper is used in addition to the gatekeeper. Definition of more than one gatekeeper occurs in individual gatekeeper profiles (GK1 and GK2).

Because the various gatekeepers assign and authorize the peer, only one VoIP profile is necessary. When a gatekeeper ends registration or does not respond, the next gatekeeper on the list is automatically used. Compression G.729 and T.38 (fax) are used. Silence suppression is active.

The gatekeeper's IP addresses are 192.168.0.10 and 192.168.0.12. These gatekeeper profiles can handle up to 8 simultaneous VoIP calls. The VoIPBOX BRI's alias is **VoIPBOX01**. The prefix is 0049. The gatekeepers' aliases are **GK1** and **GK2**. No password is used.



The parameter **VoipUseIpStack** must be set in the VoIP profile.

## BACKBONE ROUTER USING A BACKUP GATEKEEPER

```
[System]
Restrict40=tobri
MapAlltobri=10
MapAll?=40DF:?

[Voip=DF]
VoipDirection=I0
VoipPeerAddress=0.0.0.0
VoipIpMask=0x00000000
VoipSignalling=0
VoipCompression=g729 t38
VoipSilenceSuppression=Yes
VoipMaxChan=8
VoipTxM=4
VoipGk=GK1 GK2

[Gatekeeper=GK1]
RasPort=1719
OwnRasPort=1719
RasId=VoIPBOX01
RasPrefix=0049
GkId=GK
GkAdd=192.168.0.10
GkPwd=
GkTtl=300
GkMaxChan=8

[Gatekeeper=GK2]
RasPort=1719
OwnRasPort=1719
RasId=VoIPBOX01
RasPrefix=0049
GkId=backupGK
GkAdd=192.168.0.12
GkPwd=
GkTtl=300
GkMaxChan=8
```


## BACKBONE ROUTER WITH DIRECT ENDPOINT SIGNALING (H.323)

## 6.6 BACKBONE ROUTER WITH DIRECT ENDPOINT SIGNALING (H.323)

In the following example all voice calls from the VoIP line (40) are routed to the BRI NT controller (10). All calls beginning with 0 coming from the PBX are sent to the first VoIP peer and all calls beginning with 1 are sent to the second VoIP peer.

The first VoIP peer's IP address is 172.16.0.30 (VoIP profile `iG1`). H.323 signaling is used. Only compression G.729 and T.38 (fax) are used. Silence suppression is active. A maximum of 4 VoIP connections can be set up using this profile.

The second VoIP peer's IP address is 172.16.0.40 (VoIP profile `iG2`). H.323 signaling is used. Only compression G.711a is used. A maximum of 4 VoIP connections can be set up using this profile. You can use the IP address in the CDRs to differentiate calls from individual peers.



```
[System]
;To BRI
Restrict40=tobri
MapAlltobri=10

Restrict10=tovoip
MapAlltovoip0=40iG1:0
MapAlltovoip1=40iG1:1

[Voip=iG1]
VoipDirection=IO
VoipPeerAddress=172.16.0.30
VoipIpMask=0xffffffff
VoipSignalling=0
VoipCompression=g729 t38
VoipSilenceSuppression=Yes
VoipMaxChan=4
VoipTxM=4
VoipIpLogging=yes

[Voip=iG2]
VoipDirection=IO
VoipPeerAddress=172.16.0.40
VoipIpMask=0xffffffff
VoipSignalling=0
VoipCompression=g711a
VoipSilenceSuppression=No
VoipMaxChan=4
VoipTxM=4
VoipIpLogging=yes
```

## INTRASTAR

## 6.7 INTRASTAR

In the following example of one of the two IntraSTAR capable devices' `route.cfg`, a one-second interruption in RTP/RTCP transmission from the VoIP peer is considered to be a disruption in the IP connection and results in fallback to ISDN. Another quality criterion is packet loss, whereby a fractionlost ratio of 10% in five seconds also results in fallback to ISDN. Bear in mind that silence suppression must be deactivated. The IntraSTAR call resulting from the fallback to ISDN is sent using the BTX service, and the ISDN controller is labeled with 9:

```
[System]
;-----
DTMFWaitDial=3

;IntraSTAR
MapAllIS=*0500*9

;Areacode 030 (Berlin, Germany)

MapOut110=9110
MapOut112=9112
MapOut0=|40DF:0<<25
MapOut1=|40DF:0301<<25
MapOut2=|40DF:0302<<25
MapOut3=|40DF:0303<<25
MapOut4=|40DF:0304<<25
MapOut5=|40DF:0305<<25
MapOut6=|40DF:0306<<25
MapOut7=|40DF:0307<<25
MapOut8=|40DF:0308<<25
MapOut9=|40DF:0309<<25
Redirect340DF:=pl
MapAllpl=9

MapIn0=100
MapIn1=101
MapIn2=102
MapIn3=103
MapIn4=104
MapIn5=105
MapIn6=106
MapIn7=107
MapIn8=108
MapIn9=109

[Voip:DF]
VoipDirection=IO
VoipPeerAddress=company_sub.de
VoipIpMask=0xffffffff
VoipCompression=g729 t38
VoipSilenceSuppression=No
VoipSignalling=1
VoipMaxChan=8
VoipTxM=2
VoipT303=3
VoipIntrastar=Yes
VoipBrokenDetectionTimeout=1000
VoipQualityCheck=FractionLost 5 10 10
```


## 6.8 BACKBONE ROUTER AND AUTHENTICATION AND ACCOUNTING WITH A RADIUS SERVER

In the following example all voice calls from the BRI PBX line (10) are routed through VoIP (40) to the VoIP carrier with the profile name DF. All calls from VoIP (40) are routed to the BRI NT controllers (10).

In the following example the Radius server rad is used for authentication and accounting and is implemented for the VoIP profile DF. The username is `user`, the password is `pwd` and the secret is `secret`. The system registers on the Radius server (`radiusserver.domain.com`) with the host name `myself.domain.com`. H.323 is used for signaling, with the voice codec G.729.

The peer's IP address is 192.168.0.10. The same Radius server `rad` is used for accounting.

Bear in mind that if names are used instead of IP addresses, the DNS service must be activated.



```

[System]

;BRI
Restrict40=tobri
MapAlltobri=10
;To VoIP
MapAll?=40DF:?


[Voip=DF]
VoipDirection=IO
VoipPeerAddress=192.168.0.10
VoipIpMask=0xffffffff
VoipSignalling=0
VoipCompression=g729 t38
VoipSilenceSuppression=Yes
VoipMaxChan=8
VoipTxM=4
VoipRadiusAuthenticate=rad
VoipRadiusAccounting=rad

[Radius=rad]
Host=radiusserver.domain.com
User=user
Password=pwd
Secret=secret
OwnId=myself.domain.com
ServiceType=1
RequestTimeout=5
  
```

## VOIP BACKUP AND AUTOMATIC REACTIVATION

## 6.9 VOIP BACKUP AND AUTOMATIC REACTIVATION

The following example describes an automatic VoIP peer change when ASR2 values result in a connection that no longer corresponds with the quality standards. Traffic with an ASR2 value of over 30% for the last 30 calls is sent to IP address 172.16.0.80. When the ASR2 falls below 30%, profile `iG2` is used. After one hour has passed, the connection quality at the original peer is automatically tested. If the connection corresponds with the quality standards, this peer is reactivated. Both profiles use H.323 signaling. The voice codec is G.729 and faxes are transmitted with T.38. The frame size is 40ms.



```
[Voip=iG1]
VoipDirection=Out
VoipPeerAddress=172.16.0.80
VoipIpMask=0xffffffff
VoipSignalling=0
VoipCompression=g729 t38
VoipSilenceSuppression=Yes
VoipMaxChan=8
VoipTxM=4
VoipQualityCheck=ASR2 30 30 3600
VoipOverflow=iG2
```

```
[Voip=iG2]
VoipDirection=Out
VoipPeerAddress=172.16.0.90
VoipIpMask=0xffffffff
VoipSignalling=0
VoipCompression=g729 t38
VoipSilenceSuppression=Yes
VoipMaxChan=8
VoipTxM=4
```

## 7 SYSTEM MAINTENANCE AND SOFTWARE UPDATE

### 7.1 CONFIGURATION ERRORS

When typographical errors are made in the configuration files, an entry appears in the `protocol.log` when the configuration is activated. This entry includes the line number and its contents.

### 7.2 STATUS AND ERROR MESSAGES

The `protocol.log` file – assigned as the file for logging the protocol in the configuration file (`ActionLog=file`) – contains information on all activities within the system. In the example below, you can see that all activities are recorded beginning with the date and time. If functions were activated by key combinations from terminal devices you can identify these along with the service ID.

```
16.05.06-11:51:31,[990]Start STATUS - TELES.VoIPBOX V11.7a (007f)
16.05.06-12:10:57,[01A]ERR: Layer1
16.05.06-12:10:58,[000]ERR: OK
16.05.06-12:10:58,[010]ERR: OK
16.05.06-12:12:06,Remote Control from IP 192.168.1.2
16.05.06-12:12:06,Remote Control: OK
16.05.06-12:12:16,Activate Configuration System
16.05.06-12:16:26,Remote Control Terminated
16.05.06-14:00:00,Activate Configuration Night2
16.05.06-14:00:00,Time Switch Operation
16.05.06-18:00:00,Activate Configuration Night3
16.05.06-18:00:00,Time Switch Operation
```

**Table 7.31** Event Log Messages

Message	NMS	Definition
Status Program		
[990] Start STATUS	X	TELES system software and status program have been started.
System Start		
[999] System-Boot	X	System restarted by timer.
[999] Remote Control: Reboot		System restarted by remote administration command.
Configuration Changes		
Activate configuration <num> OK		Configuration <num> successfully loaded. Initiator displayed in next line.
Activate configuration <num> failed [<err>]		Configuration <num> could not be loaded.

## STATUS AND ERROR MESSAGES

Table 7.31 Event Log Messages (continued)

Message	NMS	Definition
Remote Control: Date & Time changed		Date and/or time were changed via remote administration.
Time Switch Operation		The configuration change was made by the timer.
Remote Administration		
Remote Control from <peer>, <Remote-Code>, <service>, 0		Remote administration access from number or IP address.
Remote Control: OK		Successful remote administration access.
[993]Remote Control: wrong password	X	Remote administration access was denied because of a wrong password.
[994]Remote Control: wrong number	X	Remote administration access was denied because the call originated from an unauthorized number (RemoteOrigination).
Remote Control Terminated <start time>, <end time>, <num>, <RemoteCode>, <service>, 0		Remote administration session from <num> ended. Session length is indicated by start time and end time.
Errors Reported by the Status Program		
[<port><i>] ERR: Problem at Port <num>	X	<p>A Layer 1 or Layer 2 error occurred on &lt;num&gt;. &lt;i&gt; indicates error type:</p> <p>A           Layer 1 error ;           Layer 2 error 0           Layer 1&amp;2 operational. 4           RSSI (for mobile only)</p> <p>Should the error persist, a differentiation is possible through 'status of the ports'.</p> <p>If this message appears, status inquiry connections via remote administration are accepted and NMS downloads the <code>protocol.log</code> file.</p> <p>NOTE: If the RSSI falls below the value configured in the <code>pabx.cfg</code>, the port will shut down automatically.</p>
Attention: No Callback-Call <num> Arrived		<p>Callback with DTMF: the Callback Provider &lt;num&gt; did not call back within approx. 20 sec.</p> <p>Direct Line Access with DTMF: the call was accepted but disconnected again within x sec. (as defined by <code>MapCallBack-WaitDisc</code>).</p>

## STATUS AND ERROR MESSAGES

Table 7.31 Event Log Messages (continued)

Message	NMS	Definition
Write error		Access to the disk drive on which the data is to be stored was not possible because it is set for read-only, full or because of faulty hardware or software.
[995] Msg-Memory > 75%	X	This message appears when message memory is over 75% full. If this message appears, status inquiry connections via remote administration are accepted and NMS downloads the <code>protocol.log</code> file.

The following status and error messages appear in the `protocol.log` file when ALARM appears in the VoIP port's subscriber line:

Table 7.32 Protocol Log Status and Error Messages

Message	Definition
System Configuration (a)	
<code>config: &lt;num&gt; duplicate profile</code>	Specified line in <code>pabx.cfg</code> or <code>route.cfg</code> contains duplicate profile.
<code>config: &lt;num&gt; invalid</code>	Specified line in <code>pabx.cfg</code> or <code>route.cfg</code> is invalid.
<code>config: evaluation errcode &lt;num&gt;</code>	Internal error.
Port-Specific Entries	
<code>[&lt;port&gt;]Unblock Port</code>	The <code>&lt;port&gt;</code> has been unblocked. This can occur via remote access for all controller types or automatically via vGATE for mobile channels.
<code>[&lt;port&gt;]Block Port</code>	The <code>&lt;port&gt;</code> has been blocked. This can occur via remote access for all controller types or automatically via vGATE for mobile channels.
<code>[&lt;port&gt;]Restart Port</code>	The <code>&lt;port&gt;</code> has been blocked. This can occur via remote access for all controller types or automatically via vGATE for mobile channels.
Ethernet Interface	
<code>[99d]ERR: emac&lt;num&gt;&lt;state&gt;</code>	The Ethernet controller's status is checked every minute and any change in status is noted. <code>&lt;num&gt;</code> Number of the EMAC interface (0 or 1). <code>&lt;state&gt;</code> up Ethernet link is active down Ethernet link is inactive

## STATUS AND ERROR MESSAGES

Table 7.32 Protocol Log Status and Error Messages (continued)

Message	Definition
!resolve ip-address	ARP request for specified IP address failed.
pingcheck failed	Ping to configured server failed for configured amount of time; host might reboot this port.
Voice Packetizer Task (b)	
[<port>]ERR: OK, <count> devices	The number (<count>) of DSPs were loaded during startup without errors. The first VoIP controller appears in [<port>].
[<port>]ERR: init failed	A DSP could not be loaded. This DSP or the first VoIP controller is defined in [<port>].
VP: <channel> <msg>	Voice-packetizer chips report fatal error on specified channel, with specified message.
VoIP (c)	
GK <name> URC	Successful UnRegister from specified gatekeeper.
GK <name> GRJ <num>	GatekeeperRequest was rejected
GK <name> RCF	Successful RegistrationRequest (RegistrationConfirm).
GK <name> RRJ <num>	RegistrationRequest was rejected.
GK <name> ARJ <dad> <num>	AdmissionRequest was rejected.
GK <name> !ACF dad	AdmissionRequest was not answered.
GK <name> !GCF	GatekeeperRequest was not answered.
no profile for ipaddress	Incoming VoIP call from specified IP address was rejected due to no matching VoIP profile.
registrar <name>: registration done	Successful registration at SIP registrar.
registrar <name>: wrong auth-type <num>	Registrar does not perform MD5 for authentication.
registrar <name>: gives no nonce	Nonce missing in response from registrar (possible error in registrar configuration).
registrar <name>: registration forbidden	Registration with specified registrar is not allowed.
registrar <name> not answering	Specified registrar does not respond.
voipconn oad->dad broken	Voice codec chips report broken RTP connection.

## STATUS AND ERROR MESSAGES

Table 7.32 Protocol Log Status and Error Messages (continued)

Message	Definition
voip FdInitAll failed <cause>	Internal failure.
voip ISDNListen failed	Internal failure.
voipIpSocketInit failed	Internal failure.
!DNS-lookup <hostname>	DNS lookup for specified host name failed (DNS not activated? Missing or invalid DNS server?).
message from <ip addr> not decodable	H323, ASN1 packet cannot be decoded.
vGATE	
[99]ERR: SimUnit !connect	An outgoing connection to the vGATE Sim Unit could not be established.
[99]ERR: ControlUnit <ip addr> !connect	An outgoing connection to the vGATE Control Unit could not be established.
Number Portability	
[99i]ERR: np !connect	Connection to the iMNP could not be established.
[99i]ERR: np connect <ip addr>	Connection to the iMNP reestablished.
System Kernel (e)	
task <name> suspended	specified task was suspended due to internal error; host might reboot this port.
Mail (f)	
cdr !connect <ip addr>	sending CDR: TCP connect to specified IP address failed.
mail !connect <ip addr>	sending e-mail: TCP connect to specified IP address failed.
Radius (g)	
!DNS-lookup <hostname>	DNS lookup for specified host name failed (DNS not activated? Missing or invalid DNS server?).
timeout auth <ip addr>	Authentication request to specified Radius server failed due to timeout.
timeout acct <ip addr>	Accounting request to specified Radius server failed due to timeout.
!rsp-auth <ip addr>	Response authenticator from specified Radius server was invalid (wrong secret/password?).
!auth <ip addr> <num>	Authentication denied by specified Radius server.

## STATUS AND ERROR MESSAGES

Table 7.32 Protocol Log Status and Error Messages (continued)

Message	Definition
Configuration Errors in the ip.cfg	
Error in ip.cfg line <line>: section [<section_name>] unknown	
Error in ip.cfg line <line>: parameter "<parameter_name>" in [<section_name>] unknown	
Error in ip.cfg line <line>: parameter "<parameter_name>" does not belong to any Section	
There is an error in the NAT Configuration The NAT was not loaded, please check the Configuration for mistakes	
There is an error in the DHCPD Configuration The DHCP SERVER was not loaded, please check the Configuration for mistakes	
There is an error in the ALTQD Configuration The ALTQD SERVER was not loaded, please check the Configuration for mistakes	
There is an error in the FIREWALL Configuration The FIREWALL was not loaded, please check the Configuration for mistakes	
Error in <dsl_interface> Connection failed. Please, connect a cable in the <ethernet> port	
Error in <dsl_interface>: Connection Failed. Please, revise your Username/Password configuration	
Error in <dsl_interface>: Connection Failed. Please, revise the DSL Modem	

## SOFTWARE UPDATE

## 7.3 SOFTWARE UPDATE

You may find that you would like to implement features that are only possible with a more recent software version. To update the software on your system, follow these instructions.



**Make sure no traffic is running on the system while updating the system. Do not turn the system off during the update.**

Check the software version running on your system to make sure the one you want to install is newer. The basic software consists of the following files:

```
start
netbsdz
netbsdfs.gz
vbox.tz1
```



**These files form a unit and belong to the same software version. To avoid compatibility conflicts, check with TELES service before you update the software.**



**Upload the new files ONLY via GATE Manager. Do not use any other process (e.g. FTP) to update the software files. This can lead to irreversible damage to the operating system.**

Make sure there is enough available memory for the new version. We recommend that you delete unnecessary log files and back-ups. **Do NOT delete or rename existing software files before updating.**



**If an error message appears during the update process, do NOT restart or turn off the system! Make a note of the error message and the update steps that have been taken and contact TELES service.**

## SOFTWARE UPDATE

Once the files have been completely transferred, check the file size and reboot the system. As soon as you can reach the system via GATE Manager again, check the version number of the running software. An update of the following optional function modules (see Chapter 13 ⇒) occurs in the same way. Make sure the file extension has the same running number as that of the file on the system:

- HTTP User Interface:  
`httpd.tz2`  
`httpd.izg`
- iPBX:  
`ipbx.tz2`  
`ipbx.izg`
- DNS forwarder:  
`dnsmasg.tz2`
- SNMP agent:  
`snmpd.tz0`
- IP update:  
`ipupdate.tz2`

The only exception is that you must shut down the modules that have `*.izg` files before updating. To shut down these modules, change the name of or delete the corresponding `*.tz*` file and restart the system.

Following transfer of the `*.izg` file, you must rename the `*.tz.*` file again and restart the system.


## TRACE

## 7.4 TRACE

During operation, the trace readouts of the VoIPBOX BRI can be saved in a file or transmitted with remote maintenance directly. The trace options must be turned on in the GATE Manager (offline or online trace) or via FTP raw commands (see Chapter 4.11.3 ⇒). Trace results presented here are for BRI and VoIP interfaces, and for the following services in various levels:

**Table 7.33** Trace Options

Option	Definition
Mail	Output for all SMTP packets.
NumberPortability	Output of all packets for communication with the iMNP.
vGATE	Output of all packets for communication with the vGATE.
VoiceCodecs	Output of RTCP information described under VP module.
PPP	Output of PPP connection information.
DTMF	Output for DTMF tone recognition.
Remote	Output for GATE Manager and NMS communication.



**Figure 7.13** GATE Manager: Online Trace Activation Window

VoIPBOX BRIes offer two different types of trace:

- Online - trace information is immediately displayed in the GATE Manager's trace window.
- Offline - trace information is written to a file on the VoIPBOX BRI.

## TRACE

VoIPBOX BRI systems create trace files when the `TraceLog=file` entry is present in the `pabx.cfg`. Traces can be activated via remote administration (GATE Manager or FTP).



Please bear in mind that the volume of trace readouts can grow quite large, so that faulty transmission of the trace data may result with remote maintenance. A trace at full capacity can cause the system to crash.

### Trace Output Format

The following entries appear at the beginning and end of each trace:

- `DD.MM.YY-hh:mm:ss.ss`, Start
- `DD.MM.YY-hh:mm:ss.ss`, End
  - `DD` = day
  - `hh` = hour
  - `MM` = month
  - `mm` = minute
  - `YY` = year
  - `ss.ss` = hundredths of seconds

Traces appear in the following format:

- `[<hh:mm:ss>] <module>[<port>]: <trace>`
- `<module>`
  - `s` = send for PRI/BRI ports
  - `r` = receive for PRI/BRI ports
  - `x` = send to VoIP destinations
  - `y` = receive from VoIP destinations
  - `i` = information messages and internal trace outputs between VoIP and the other interfaces (ISDN)
  - `a` = VoIP controllers RTCP output
  - `m` = mail output
  - `g` = remote output
- `<port>`
  - port number (controller number in the `pabx.cfg`) or 255 if a service is used
- `<trace>`
  - output in the defined syntax for the module

#### 7.4.1 ISDN TRACE OUTPUT

Trace output for DSS1 and SS7 is in hexadecimal notation. You can use the external tool `TraceView.exe` to translate offline trace output. You will find the tool in the **Software** folder on the enclosed CD. The GATE Manager's trace window can also display translated online traces.

## TRACE

**Example:** The following example shows an untranslated DSS1 trace:

```
17.05.06-09:54:40,Start 11.7a (L3)
[09:55:14.58] r[00]: 00 01 02 02 08 02 00 02 05 04 03 80 90 a3 18 03 a1 83 81 6c 02 81 31 70 06 81 31 32 33
34 35 7d 02 91 81
[09:55:14.58] s[00]: 02 01 02 04 08 02 80 02 0d 18 03 a9 83 81
[09:55:14.58] s[01]: 00 01 a8 9a 08 02 00 46 05 04 03 80 90 a3 18 03 a1 83 89 6c 02 81 31 70 06 81 31 32 33
34 35 7d 02 91 81
[09:55:14.58] r[01]: 02 01 9a aa 08 02 80 46 0d 18 03 a9 83 89
[09:55:14.86] r[01]: 02 01 9c aa 08 02 80 46 01
[09:55:14.86] s[00]: 02 01 04 04 08 02 80 02 01
[09:55:16.73] r[01]: 02 01 9e aa 08 02 80 46 07 29 05 05 07 01 09 33 4c 07 01 81 31 32 33 34 35
[09:55:16.73] s[01]: 00 01 aa a0 08 02 00 46 0f
[09:55:16.73] s[00]: 02 01 06 04 08 02 80 02 07 29 05 05 07 01 09 32 4c 07 01 81 31 32 33 34 35
[09:55:16.73] r[00]: 00 01 04 08 08 02 00 02 0f
[09:55:44.30] r[00]: 00 01 06 08 08 02 00 02 45 08 02 80 90
[09:55:44.35] s[01]: 00 01 ac a0 08 02 00 46 45 08 02 80 90
[09:55:46.71] r[01]: 02 01 a0 ae 08 02 80 46 4d
[09:55:46.71] s[01]: 00 01 ae a2 08 02 00 46 5a
[09:55:46.71] s[00]: 02 01 08 08 08 02 80 02 4d
[09:55:46.71] r[00]: 00 01 08 0a 08 02 00 02 5a
17.05.06-09:51:33,End
```

## 7.4.2 VOIP TRACE OUTPUT

As described above in Chapter 7.4 ⇨, there are four modules for VoIP traces. The groups **x** (send), **y** (receive) and **i** (information and internal output) appear when a Layer2 or Layer3 offline or online trace is started. Group **a** (RTCP output) only appears when the module **Voice Codecs** is active.

Particularly in the case of VoIP connections (protocols H.323 and SIP), the trace output is quite extensive and abbreviations make it difficult to keep track of the results. The following list contains a description of H.323 output.

Output for the signaling protocol SIP is transmitted in ASCII and translated for better legibility. Since they are displayed unabridged, no description is necessary. Information and internal output traces correspond with the H.323 output and are described in the following tables. For ENUM, please refer to Chapter 7.4.2.6 ⇨.

In general, the following rules apply for this trace output:

**Table 7.34** H.323 Output

Packet	Description
h225	H.225-protocol messages.
h245	H.245-protocol messages.
pstn	Messages of the internal protocol interface that provides the interface to the other interfaces PRI, BRI and GSM.
rcv	Coming from the IP network or the internal protocol interface; appears with <dir> in the trace lines.
snd	Sending to the IP network or the internal protocol interface; appears with <dir> in the trace lines.

The information is thoroughly analyzed where it is received (all rcv messages).

## TRACE

## 7.4.2.1 INTERFACE IP NETWORK

**Establish H.323 Session**

Usually there is trace output that displays a new H.323 session. The direction is crucial (whether the call is going into or coming out of the IP network).

```
h225connect to <ip address> cr <cr> s <si>
h225accept from <ip address> s <si>
```

**Table 7.35** H.323 Session

Trace Output	Description
connect to	Outgoing VoIP call
accept from	Incoming VoIP call
<ip address>	Peer's IP address
cr <cr>	Call reference (corresponds with the internal protocol interface's PSTN call reference)
s <si>	Session ID

**H.225 Signaling Output**

The following trace results are for a call coming from the IP network. rcv will appear at <dir> and signifies the direction:

```
h225<dir> tpkt msg 0x<mt> h225cr <cr> addr <ip address>
```

**Table 7.36** H.225 Signaling

Trace Output	Description
<mt>	The ETS message type in hexadecimal; can consist of values listed in Table 7.37.
<hcr>	H.225 call reference in hexadecimal (does not have to be unique when calls come from multiple peers).
<ip address>	The peer's IP address.

## TRACE

**Table 7.37** ETS Message Types

Hex Value	Message Type
1	Alerting
2	Call Proceeding
3	Progress
5	Setup
7	Connect
D	Setup Acknowledge
5A	Release Complete
62	Facility
6E	Notify
7B	Information
7D	Status

The following lines show the packet contents in detail:

```
h225 decode rc 0, q931 msg 0x<mt> = 0, len <length>
h225<type> <mt> voipcfg addr <ip address> rc 0 compr <codec>
h225<type> <mt> h225cr <hcr> FS:<bool> (<codec>,<ip address>,<port>) TUNN:<bool>
H245:<bool>(<ip address>,<port>)
h225<type> <mt> h225cr <hcr> cr <cr>
```

**Table 7.38** Incoming VoIP Calls

Trace Output	Description
<mt>	Message type in hexadecimal as per ETS standard (see Table 7.37) or written out as a name.
len <length>	Packet length in bytes.
h225<type>	H.225 rcv or send; received or sent from the IP network.
addr <ip address>	Peer's IP address.
compr <codec>	Peer's compression list (see Table 7.39).
FS<bool>	FastStart offered in the signaling packet or not.

## TRACE

**Table 7.38** Incoming VoIP Calls (*continued*)

Trace Output	Description
( <code>&lt;codec&gt;</code> ,	Lists codecs offered (see Table 7.61).
<code>&lt;ip address&gt;</code> ,	Peer's IP address for RTP data.
<code>&lt;port&gt;</code> )	Peer's port for RTP Data.
<code>Tunn&lt;bool&gt;</code>	Shows whether or not tunneling is offered as a signaling variant.
<code>H245&lt;bool&gt;</code>	Shows an extra H.245 session.
( <code>ip address</code> ,	Peer's IP address.
<code>port</code> )	Peer's port.
<code>h225cr &lt;hcr&gt;</code>	H.225 message's call reference (does not have to be unique when calls come from multiple VoIP peers).
<code>cr &lt;cr&gt;</code>	Internal call reference (always unique for the call).
<code>ALT:&lt;ip address&gt;:&lt;port&gt;,&lt;DAD&gt;</code>	Optional alternative values for IP address port or a new destination number for a facility message with the cause <code>call forwarded</code> .

**Table 7.39** Compression Codecs Used

Synonym	Codec
A	G.711Alaw64k
B	G.711Ulaw64k
C	G.7231
D	G.728
E	G.729
F	gsmFullRate
G	T.38fax
O	G.729A
P	G.72616
Q	G.72624
R	G.72632
S	G.729B

## TRACE

**Table 7.39** Compression Codecs Used (*continued*)

Synonym	Codec
T	G.729AB
U	G.729E
V	G.723L
W	Transparent
X	G.721
Y	iLBC20
Z	iLBC30

When the call is sent in the direction of the IP network, the trace will include only the most important information:

```
h225<type> <mt1> dad <num> cr <cr>
```

**Table 7.40** Calls to the IP Network 1

Trace Output	Description
<mt>	Message type written out; if a decimal number appears here, it will be translated as per Table 7.37.
<num>	Called party number.
<cr>	Call reference.

Or:

```
h225<type> callproc typ <mt> cr <cr>
```

**Table 7.41** Calls to the IP Network 2

Trace Output	Description
<mt>	The ETS message type in hexadecimal.
<cr>	Call reference.

## TRACE

## 7.4.2.2 RTP/RTCP OUTPUT

The RTP/RTCP output displays whether the signaling information corresponds with the contents of the compression chips. The output occurs when a media channel is set up or torn down:

```
rtp start cr <cr> ch <ch> li <li> ri <ri> st <st> fx <fx> cp <comp> tsm <factor>
```

**Table 7.42** RTP/RTCP Output

Trace Output	Description
<cr>	Call reference.
<ch>	The internal media channel used.
<li>	1 appears when the local RTP address (and port) has been defined.
<ri>	1 appears when the remote RTP address (and port) have been established.
<st>	0 appears if the channel's voice packetizer has not yet been started. 1 appears if the voice packetizer can receive, but not send. 2 appears when the voice packetizer can receive and send.
<fx>	1 appears when T.38 (fax) is used, otherwise 0.
<comp>	The codec used, as per Table 7.39.
<factor>	Multiplication factor for default frame size (20ms, 30 ms for G.723).

```
rtp stop cr <cr>1 ch <ch>
```

**Table 7.43** RTP Stop Message

Trace Output	Description
<cr>	Call reference.
<ch>	The internal media channel used.

VP Module

## TRACE

This module's output shows the controller packets for the voice connections. That means that the RTCP packets and relevant information also appear.

The following results occur for a new RTP connection:

```
a[<controller>]: <VoIPcodecChipType> start(val) ch=<ch> local=<port> remote=<ip address:port> agg=<bool>
```

**Table 7.44** RTP/RTCP Output (VP Module)

Trace Output	Description
<controller>	Running number for the VoIP controller.
<VoIPcodecChipType>	Stands for the type designation for the compression chips used (e.g. Ac49x).
<val>	Shows which connection is set up.
<ch>	The internal media channel used.
<port>	RTP port.
<ip address>	Peer's IP address in hexadecimal.
agg=<bool>	1 means an RTP-multiplex connection is used (default 0).

The following output shows the channel's state in the compression chip during a startup or change of codec:

```
a[<controller>]: <VoIPcodecChipType>OpenChannelConfiguration ch=<ch> rc=0
a[<controller>]: <VoIPcodecChipType>T38ChannelConfiguration ch=<ch> rc=0
a[<controller>]: <VoIPcodecChipType>ActivateRegularRtpChannelConfiguration ch=<ch> rc=0
```

The following output shows whether the compression chip starts sending and receiving packets:

```
a[<controller>]: <VoIPcodecChipType> ch <ch> establish
```

Sent and received bytes appear with the following output results:

```
a[<controller>]: <VoIPcodecChipType> ch <ch>: in <byte> out <byte>
```

**Table 7.45** RTP Packet Statistics

Trace Output	Description
<ch>	The internal media channel used.
<byte>	The call's received or sent bytes.

## TRACE

```
a[<controller>]: <VoIPcodecChipType> ch <ch> rtcp<dir> <num> ji <ji> rt <rt> fl <fl> in <byte> out <byte>
```

**Table 7.46** RTCP Packet Statistics

Trace Output	Description
<ch>	The internal media channel used.
rtcp<dir>	R sender report (received) is more interesting, since it comes from the peer. T sender report (transmitted).
<num>	0 ReceiverReport packet 1 SenderReport packet 2 Packet requested by the driver
<ji>	Delay jitter [msec].
<rt>	Round-trip local<->remote, round-trip delay [msec].
<fl>	Fraction lost: Fraction of packets lost [8lsb].
<cl>	Cumulative lost: number of lost packets [24lsb].

The following output shows the jitter buffer status:

```
a[<controller>]: <VoIPcodecChipType> ch <ch> jitter buffer n1 n2 n3n4 n5 n6 n7 n8
```

**Table 7.47** Jitter Buffer Status

Trace Output	Description
n1	SteadyStateDelay in milliseconds
n2	NumberOfVoiceUnderrun
n3	NumberOfVoiceOverrun
n4	NumberOfVoiceDecoderBfi (bfi = bad frame interpolation)
n5	NumberOfVoicePacketsDropped
n6	NumberOfVoiceNetPacketsLost
n7	NumberOflbsOverrun (lbs = in band signaling)

## TRACE

**Table 7.47** Jitter Buffer Status (*continued*)

Trace Output	Description
n8	NumberOfCasOverrun

An RTP connection has ended when the following trace output appears:

```
a[<controller>]: <VoIPcodecChipType> stop ch=<ch>
```

**Table 7.48** RTP Stop Message (VP Module)

Trace Output	Description
<ch>	The internal media channel used.

The following output results when the codec changes for a fax connection:

```
a[<controller>]: ac49x ch <ch> fax/data n1 n2 n3
```

**Table 7.49** Codec Change for Fax

Trace Output	Description
n1	Fax bypass flag: 0           Voice, data bypass or fax relay 1           Fax bypass
n2	Signal detected on decoder output (see Table 7.50)
n3	Signal detected on encoder input (see Table 7.50)

**Table 7.50** faxordatasignalevent

Value	Definition	Description
0	SILENCE_OR_UNKNOWN	Undefined (unknown signal or silence)
1	FAX_CNG	CNG-FAX (calling fax tone, 1100 Hz)

## TRACE

Table 7.50 faxordatasignalevent (continued)

Value	Definition	Description
2	ANS_TONE_2100_FAX_CED_OR_MODEM	FAX-CED or modem-ANS (answer tone, 2100 Hz)
3	ANS_TONE_WITH_REVERSALS	ANS (answer tone with reversals)
4	ANS_TONE_AM	ANSam (AM answer tone)
5	ANS_TONE_AM_REVERSALS	ANSam (AM answer tone with reversals)
6	FAX_V21_PREAMBLE_FLAGS	FAX-V.21 preamble flags
7	FAX_V8_JM_V34	FAX-V.8 JM (fax call function, V.34 fax)
8	VXX_V8_JM_VXX_DATA	V.XX-V.8 JM (data call function, V-series modem)
9	V32_AA	V.32 AA (calling modem tone, 1800 Hz)
10	V22_USB1	V.22 USB1 (V.22(bis) unscrambled binary ones)
11	V8_BIS_INITIATING_DUAL_TONE	V.8bis initiating dual tone (1375 Hz and 2002 Hz)
12	V8_BIS_RESPONDING_DUAL_TONE	V.8bis responding dual tone (1529 Hz and 2225 Hz)
13	VXX_DATA_SESSION	V.XX data session
14	V21_CHANNEL_2	V.21 channel 2 (mark tone, 1650 Hz)
15	V23_FORWARD_CHANNEL	V.23 forward channel (mark tone, 1300 Hz)
16	V21_CHANNEL_1=18	V.21 channel 1 (mark tone, 980 Hz)
17	BELL_103_ANSWER_TONE	Bell 103 answer tone, 2225 Hz
18	TTY	TTY
19	FAX_DCN	FAX-DCN (G.3 fax disconnect signal)

Fax relay is activated for the corresponding channel:

```
a[<controller>]: Ac49xActivateFaxRelayCommand(1) ch <ch> rc <cr>
```

The following output shows various values for fax transmission (see Table 7.51 for a description of the values):

```
a[<controller>]: ac49x ch <ch> faxrelay: n1 n2 n3 n4 n5 n6 n7 n8 n9 n10 n11 n12 n13 n14
```

## TRACE

Table 7.51 Fax Status

Value	Description
n1	UnableToRecoverFlag (0 no, 1 yes)
n2	IllegalHdlcFrameDetectedFlag (...)
n3	FaxExitWithNoMcfFrameFlag
n4	HostTransmitOverRunFlag
n5	HostTransmitUnderRunFlag
n6	InternalErrorFlag
n7	ReceivedBadCommandFlag
n8	TimeOutErrorFlag
n9	TxRxFlag (0 receive, 1 transmit)
n10	T30State 0 FAX_RELAY_T30_STATE__INITIALIZATION 1 FAX_RELAY_T30_STATE__CNG 2 FAX_RELAY_T30_STATE__CED 3 FAX_RELAY_T30_STATE__V21 4 FAX_RELAY_T30_STATE__NSF 5 FAX_RELAY_T30_STATE__NSC 6 FAX_RELAY_T30_STATE__CSI 7 FAX_RELAY_T30_STATE__CIG 8 FAX_RELAY_T30_STATE__DIS 9 FAX_RELAY_T30_STATE__DTC 10 FAX_RELAY_T30_STATE__NSS 11 FAX_RELAY_T30_STATE__TSI 12 FAX_RELAY_T30_STATE__DCS 13 FAX_RELAY_T30_STATE__CTC 14 FAX_RELAY_T30_STATE__CRP 15 FAX_RELAY_T30_STATE__DCN 16 FAX_RELAY_T30_STATE__PRE_MESSAGE_RESPONSE 17 FAX_RELAY_T30_STATE__POST_MESSAGE_RESPONSE 18 FAX_RELAY_T30_STATE__POST_MESSAGE_COMMAND 19 FAX_RELAY_T30_STATE__VXX 20 FAX_RELAY_T30_STATE__TCF 21 FAX_RELAY_T30_STATE__IMAGE

## TRACE

Table 7.51 Fax Status (continued)

Value	Description
n11	NumberOfTransferredPages
n12	BadInputPacketId
n13	BadInputPacketTotalSize
n14	FaxBitRate
	1 FAX_BIT_RATE__300_BPS
	2 FAX_BIT_RATE__2400_BPS
	3 FAX_BIT_RATE__4800_BPS
	4 FAX_BIT_RATE__7200_BPS
	5 FAX_BIT_RATE__9600_BPS
	6 FAX_BIT_RATE__12000_BPS
	7 FAX_BIT_RATE__14400_BPS

The following output appears when the compression chip recognizes DTMF tones:

```
a[<controller>]: ac49x ch <ch> ibs <dtmf> <dir> <mode> <lev> <dur>
```

Table 7.52 DTMF Tone Recognition

Trace Output	Description
<ch>	Media channel
<dtmf>	Recognized DTMF tone in the stream or as per RFC2833
<dir>	Direction
	0 Coming from BRI/analog
	1 Coming from VoIP
<mode>	0 Tone has ended
	1 Tone has been recognized
<lev>	Signal level in -dBm
<dur>	Tone duration

## TRACE

## 7.4.2.3 INTERNAL PROTOCOL INTERFACE (TO ISDN, POTS, MOBILE)

These trace outputs always begin with the keyword `pstn`, followed by the direction and the message type. The message is then either concluded or other information follows:

```
pstn<type> <mt1> dad <num> oad <num> cr <cr> s <si> ch <chan> isdn<icr>
```

**Table 7.53** Internal Protocol Interface

Trace Output	Description
<type>	Direction from (rcv) or to (snd) the internal protocol interface.
<mt1>	Message type written out; if a decimal number appears, it will be translated as per Table 7.37.
<num>	DAD<num> = called party number, OAD<num> = calling party number.
<cr>	Call reference.
<si>	Session ID.
<chan>	Media channel used.
<icr>	Call reference for the internal protocol interface (DSS1).

Output also appears when a call comes from the internal protocol interface and is assigned to a VoIP profile. The characters appear in front of the colon in the routing entry:

```
pstnrcv get_voipcfg <voip profile>
```

**Table 7.54** Received from PSTN 1

Trace Output	Description
<voip profile>	Defines the VoIP profile to be used.

Assignment of media channel used for the internal interface and the ISDN call reference for the VoIP call's appears as follows:

```
pstnrcv bchanind cr <cr> ch <chan> isdn<icr>
```

## TRACE

**Table 7.55** Received from PSTN 2

Trace Output	Description
<cr>	Call reference.
<chan>	Media channel used for the internal protocol interface (DSS1).
<icr>	Call reference for the internal protocol interface (DSS1).

**7.4.2.4 H.245 MESSAGES**

The following trace output is possible:

```
h245<dir>(<tt>) cr <cr>
```

**Table 7.56** H.245 Messages

Trace Output	Description
<dir>	The message's direction; <i>rcv</i> (incoming from the peer) or <i>snd</i> (sent message).
<tt>	H.245 transport type.
<cr>	Internal call reference.

Following this trace output, either a detailed description of the message and its corresponding message type, including negotiating information, or trace output elements that are explained later appear. The most important message types that contain further information elements are as follows:

```
... TerminalCapabilitySet peer=<comp> cfg=<comp>
... TerminalCapabilitySet <comp>
```

**Table 7.57** Codec Used

Trace Output	Description
<comp>	List of compression codecs offered (see Table 7.39), the list of the peer's codecs appears behind <i>peer</i> , and <i>cfg</i> shows which codecs are defined in the VoIP profile

## TRACE

```
... OpenLogicalChannel cn=<cn> cpr=<comp> sessid=<sid> ctrl=<ip address>:<rtcp port>
... OpenLogicalChannelAck cn=<cn> sessid=<sid> media=<ip address>:<rtp port>
```

**Table 7.58** Logical Channel Parameters

Trace Output	Description
<cn>	H.245 channel number per H.225 connection.
<sid>	Session ID.
<comp>	Codec used (see Table 7.39).
<ip address>	Protocol peer IP address.
<rtcp port>	Port used for the protocol RTCP.
<rtp port>	Port used for the protocol RTP.

The trace output is as follows when the message type is not translated or is ignored:

```
h245<dir>(<tt>) cr <cr> unknown msg <hmt> <hmi>
```

**Table 7.59** H.245 Parameters

Trace Output	Description
hmt	The H.245 message type (multimedia system control message type), (Table 7.60).
hmi	The H.245 message ID (see Table 7.61, Table 7.62, Table 7.63, Table 7.64).

**Table 7.60** Multimedia System Control Message Types

ID	Message
0 (Table 7.61)	Request
1 (Table 7.62)	Response
2 (Table 7.63)	Command

## TRACE

**Table 7.60** Multimedia System Control Message Types (*continued*)

ID	Message
3 (Table 7.64)	Indication

Depending on the system control message type, one of the following message IDs appear:

**Table 7.61** Message IDs for Request Message

ID	Message
0	NonStandard
1	MasterSlaveDetermination
2	TerminalCapabilitySet
3	OpenLogicalChannel
4	CloseLogicalChannel
5	RequestChannelClose
6	MultiplexEntrySend
7	RequestMultiplexEntry
8	RequestMode
9	RoundTripDelayRequest
10	MaintenanceLoopRequest
11	CommunicationModeRequest
12	ConferenceRequest
13	MultilinkRequest
14	LogicalChannelRateRequest

**Table 7.62** Message IDs for Response Message

ID	Message
0	NonStandard
1	MasterSlaveDeterminationAck
2	MasterSlaveDeterminationReject

## TRACE

**Table 7.62** Message IDs for Response Message (*continued*)

ID	Message
3	TerminalCapabilitySetAck
4	TerminalCapabilitySetReject
5	OpenLogicalChannelAck
6	OpenLogicalChannelReject
7	CloseLogicalChannelAck
8	RequestChannelCloseAck
9	RequestChannelCloseReject
10	MultiplexEntrySendAck
11	MultiplexEntrySendReject
12	RequestMultiplexEntryAck
13	RequestMultiplexEntryReject
14	RequestModeAck
15	RequestModeReject
16	RoundTripDelayResponse
17	MaintenanceLoopAck
18	MaintenanceLoopReject
19	CommunicationModeResponse
20	ConferenceResponse
21	MultilinkResponse
22	LogicalChannelRateAcknowledge
23	LogicalChannelRateReject

**Table 7.63** Message IDs for Command Message

ID	Message
0	NonStandard
1	MaintenanceLoopOffCommand

## TRACE

**Table 7.63** Message IDs for Command Message (*continued*)

ID	Message
2	SendTerminalCapabilitySet
3	EncryptionCommand
4	FlowControlCommand
5	EndSessionCommand
6	MiscellaneousCommand
7	CommunicationModeCommand
8	ConferenceCommand
9	h223MultiplexReconfiguration
10	NewATMVCCCommand
11	MobileMultilinkReconfigurationCommand

**Table 7.64** Message IDs For Indication Message

ID	Message
0	NonStandard
1	FunctionNotUnderstood
2	MasterSlaveDeterminationRelease
3	TerminalCapabilitySetRelease
4	OpenLogicalChannelConfirm
5	RequestChannelCloseRelease
6	MultiplexEntrySendRelease
7	RequestMultiplexEntryRelease
8	RequestModeRelease
9	MiscellaneousIndication
10	JitterIndication
11	h223SkewIndication
12	NewATMVCIndication

## TRACE

**Table 7.64** Message IDs For Indication Message (*continued*)

ID	Message
13	UserInput
14	h2250MaximumSkewIndication
15	McLocationIndication
16	ConferenceIndication
17	VendorIdentification
18	FunctionNotSupported
19	MultilinkIndication
20	LogicalChannelRateRelease
21	FlowControlIndication
22	MobileMultilinkReconfigurationIndication

**7.4.2.5 RAS (REGISTRATION, ADMISSION, STATUS)**

As a general rule, the most important terminal and gatekeeper messages appear written out with the gatekeeper's IP address (<ip addr>):

```
H225 GatekeeperRequest to <ip addr> (s 131)
H225 GatekeeperConfirm <ip addr>
H225 GatekeeperReject <ip addr> reason <reason>
```

**Table 7.65** RAS

Trace Output	Description
<reason>	Gatekeeper reject reason, see Table 7.69.

```
H225 GkRegistration to <ip addr>
H225 RegistrationConfirm <ip addr>
H225 RegistrationReject <ip addr> reason <reason>
```

## TRACE

Table 7.66 Gatekeeper 1

Trace Output	Description
<reason>	Registration reject reason, see Table 7.70.

```
H225 GkResourcesAvailableIndicate to <ip addr> (<act chan> <max chan>)
H225 ResourcesAvailableConfirm <ip addr>
```

```
H225 GkAdmission cr <cr> to <ip addr>
H225 AdmissionConfirm <ip addr> cr <cr>
H225 AdmissionReject <ip addr> reason <reason>
```

Table 7.67 Gatekeeper 2

Trace Output	Description
<reason>	Admission reject reason, see Table 7.71.

```
H225 GkDisengage cr <cr> to <ip addr>
H225 DisengageConfirm <ip addr>
```

```
H225 UnregistrationRequest <ip addr>
H225 GkUnregistrationConf to <ip addr>
```

All other messages appear as follows:

```
H225 unknown msg from Gk <ip addr>: <code>
```

## TRACE

**Table 7.68** Gatekeeper 3

Trace Output	Description
<code>	Unknown gatekeeper message, see Table 7.72.

**Table 7.69** Gatekeeper Reject Reason

ID	Reject Reason
0	resourceUnavailable
1	terminalExcluded
2	invalidRevision
3	undefinedReason
4	securityDenial
5	genericDataReason
6	neededFeatureNotSupported

**Table 7.70** Registration Reject Reason

ID	Reject Reason
0	DiscoveryRequired
1	InvalidRevision
2	InvalidCallSignalAddress
3	InvalidRASAddress
4	DuplicateAlias
5	InvalidTerminalType
6	UndefinedReason
7	TransportNotSupported
8	TransportQOSNotSupported

## TRACE

**Table 7.70** Registration Reject Reason (*continued*)

ID	Reject Reason
9	ResourceUnavailable
10	InvalidAlias
11	SecurityDenial
12	RullRegistrationRequired
13	AdditiveRegistrationNotSupported
14	InvalidTerminalAliases
15	GenericDataReason
16	NeededFeatureNotSupported

**Table 7.71** Admission Reject Reason

ID	Reject Reason
0	CalledPartyNotRegistered
1	InvalidPermission
2	RequestDenied
3	UndefinedReason
4	CallerNotRegistered
5	RouteCallToGatekeeper
6	InvalidEndpointIdentifier
7	ResourceUnavailable
8	SecurityDenial
9	QosControlNotSupported
10	IncompleteAddress
11	AliasesInconsistent
12	RouteCallToSCN
13	ExceedsCallCapacity
14	CollectDestination

## TRACE

**Table 7.71** Admission Reject Reason (*continued*)

ID	Reject Reason
15	CollectPIN
16	GenericDataReason
17	NeededFeatureNotSupported

**Table 7.72** Unknown Gatekeeper Messages

ID	Message
0	GatekeeperRequest
1	GatekeeperConfirm
2	GatekeeperReject
3	RegistrationRequest
4	RegistrationConfirm
5	RegistrationReject
6	UnregistrationRequest
7	UnregistrationConfirm
8	UnregistrationReject
9	AdmissionRequest
10	AdmissionConfirm
11	AdmissionReject
12	BandwidthRequest
13	BandwidthConfirm
14	BandwidthReject
15	DisengageRequest
16	DisengageConfirm
17	DisengageReject
18	LocationRequest
19	LocationConfirm

## TRACE

**Table 7.72** Unknown Gatekeeper Messages (*continued*)

ID	Message
20	LocationReject
21	InfoRequest
22	InfoRequestResponse
23	NonStandardMessage
24	UnknownMessageResponse
25	RequestInProgress
26	ResourcesAvailableIndicate
27	ResourcesAvailableConfirm
28	InfoRequestAck
29	InfoRequestNak
30	ServiceControlIndication
31	ServiceControlResponse

**7.4.2.6 ENUM OUTPUT**

This output is assigned to group `i` and occurs with Layer2 and Layer3 traces:

```
i[<controller>]: enum_query cr <CR> ch <CH>: <num> -> <length> <<answer pattern>>
```

**Table 7.73** ENUM Output

Trace Output	Description
<cr>	Call reference.
<ch>	Media channel.
<num>	Phone number converted into ENUM domain format.
<length>	Length of the answer field in the DNS response in bytes. 0 appears if the number was not found.
<answer pattern>	Displays the DNS response. 0 appears if the number was not found.

## TRACE

## 7.4.2.7 EXAMPLES

The following examples are offline traces. You can generate them using the GATE Manager or FTP commands. The filename is `trace.log`. The following cases appear in the examples:

- Incoming H323 Call with FastStart (Chapter [⇒](#))
- Outgoing H323 Call with FastStart (Chapter [⇒](#))
- Fax Call (Chapter [⇒](#))

## TRACE

## Incoming H323 Call with FastStart

```

[15:04:09.12] i[04]: h225accept from 172.16.0.100 s 4
[15:04:09.15] y[04]: h225rcv tpkt msg 5 h225scr 8006 addr 172.16.0.100 pt 0
[15:04:09.16] y[04]: h225 decode rc 0, q931 msg 5 (0), len 361
[15:04:09.16] y[04]: h225rcv setup voipcfg addr 172.16.0.100 rc 0 <DF> compr EABG
[15:04:09.16] y[04]: h225rcv faststart <A4B4E4G0>
[15:04:09.16] y[04]: h225rcv setup oad 01 00 <1111> <> dad 01 <321> rad <> bc 038090a3 0101
[15:04:09.16] y[04]: h225rcv setup h225scr 8006 FS:1(E,172.16.0.100,29000) TUNN:1 H245:0(0,0)
[15:04:09.16] y[04]: h225rcv setup h225scr 8006 cr 5
[15:04:09.16] i[04]: pstnsnd setup dad 1 oad 1111 cr 5 s 4
[15:04:09.16] s[02]: 02 ff 03 08 01 02 05 04 03 80 90 a3 18 01 89 6c 06 01 81 31 31 31 31 70 04 81 33 32
31 7d 02 91 81
[15:04:09.16] i[04]: pstnrcv connresp cr 5 acc 5 ch 1
[15:04:09.16] x[04]: h225snd callproc typ d cr 5 pri 0
[15:04:09.50] r[02]: 00 81 20 1a 08 01 82 01 18 01 89
[15:04:09.50] s[02]: 00 81 01 22
[15:04:09.50] i[04]: pstnrcv alert cr 5 cls ff
[15:04:09.50] i[04]: rtp start cr 5 ch 1 li 1 ri 1 st 2 fx 0 cp E txm 2
[15:04:09.50] x[04]: h225snd callproc typ l cr 5 pri 8
[15:04:09.52] a[04]: ac49x start(201) ch=0 local=29000 remote=ac100064:29000 agg=0
[15:04:09.52] a[04]: Ac49xOpenChannelConfiguration ch=0 rc=0
[15:04:09.52] a[04]: Ac49xT38ChannelConfiguration ch=0 rc=0
[15:04:09.52] a[04]: Ac49xActivateRegularRtpChannelConfiguration ch=0 rc=0
[15:04:09.63] a[04]: ac49x ch 0 rtcpR 0 ji -1 rt -1 fl 65535 in 0 out -1
[15:04:09.63] a[04]: ac49x ch 0 establish
[15:04:09.98] a[04]: ac49x ch 0 jitter buffer 75 0 0 0 1 0 0 0
[15:04:10.94] a[04]: ac49x ch 0 jitter buffer 115 5 0 5 1 0 0 0
[15:04:11.79] r[02]: 00 81 22 1a 08 01 82 07 4c 03 00 80 31
[15:04:11.79] s[02]: 02 81 1a 24 08 01 02 0f
[15:04:11.79] i[04]: pstnrcv connresp cr 5 acc 10 ch 255
[15:04:11.79] x[04]: h225snd callproc typ 7 cr 5 pri 0
[15:04:11.89] r[02]: 02 81 01 1c
[15:04:12.49] a[04]: ac49x ch 0 rtcpT 1 ji 201 rt 0 fl 0 in 290 out 394
[15:04:12.49] a[04]: ac49x ch 0: in 1552 out 1646
[15:04:13.50] a[04]: ac49x ch 0 jitter buffer 125 1 0 1 0 0 0 0
[15:04:14.50] a[04]: ac49x ch 0 jitter buffer 145 3 0 3 1 0 0 0
[15:04:15.56] a[04]: ac49x ch 0 jitter buffer 145 0 0 0 1 0 0 0
[15:04:16.23] a[04]: ac49x ch 0 rtcpR 1 ji 196 rt 84 fl 0 in 3236 out 3236
[15:04:17.98] r[02]: 00 81 24 1c 08 01 82 45 08 02 80 90
[15:04:17.98] s[02]: 00 81 01 26
[15:04:17.98] i[04]: pstnrcv terminate connection (3201) cr 5 cau 90 err 0 state 16 ch 1 rsid 1
[15:04:17.98] i[04]: rtp stop cr 5 ch 1
[15:04:17.98] x[04]: h225snd relack cr 5 cau 0x90
[15:04:17.98] i[04]: h225connection s 4 close
[15:04:17.98] i[04]: CloseSysFd 4 (st 22)
[15:04:18.03] s[02]: 02 81 1c 26 08 01 02 4d
[15:04:18.03] a[04]: ac49x ch 0: in 20486 out 21288
[15:04:18.03] a[04]: ac49x stop ch=0
[15:04:18.06] a[04]: ac49x ch 0 rtcpR 2 ji 221 rt 84 fl 0 in 5012 out 5510
[15:04:18.24] r[02]: 02 81 01 1e
[15:04:18.28] r[02]: 00 81 26 1e 08 01 82 5a

```

## TRACE

## Outgoing H323 Call with FastStart

```

[15:25:13.61] r[02]: 00 81 2a 1e 08 01 48 05 04 03 80 90 a3 18 01 83 6c 05 00 80 31 31 31 70 07 81 31 32
33 34 35 36 7d 02 91 81
[15:25:13.61] s[02]: 00 81 01 2c
[15:25:13.61] s[02]: 02 81 1e 2c 08 01 c8 0d 18 01 8a
[15:25:13.61] i[04]: pstnrcv setup dad DF:123456 oad 111 cc 0 id dd006
[15:25:13.61] i[04]: pstnrcv get_voipcfg <DF>
[15:25:13.61] i[04]: h225connect to 172.16.0.100 cr 6
[15:25:13.61] x[04]: h225snd setup dad 123456 cr 6
[15:25:13.69] r[02]: 02 81 01 20
[15:25:13.69] y[04]: h225rcv tpkt msg d h225cr 6 addr 172.16.0.100 pt 8018c000
[15:25:13.69] y[04]: h225 decode rc 0, q931 msg d (11), len 32
[15:25:13.69] y[04]: h225rcv msg d (11) h225cr 6 FS:0(-,0,0) TUNN:1 H245:0(0,0)
[15:25:14.36] y[04]: h225rcv tpkt msg 1 h225cr 6 addr 172.16.0.100 pt 8018c000
[15:25:14.36] y[04]: h225 decode rc 0, q931 msg 1 (3), len 119
[15:25:14.36] y[04]: h225rcv faststart <E4>
[15:25:14.36] y[04]: h225rcv alert h225cr 6 FS:1(E,172.16.0.100,29000) TUNN:1 H245:0(0,0)
[15:25:14.36] i[04]: rtp start cr 6 ch 1 li 1 ri 1 st 2 fx 0 cp E txm 2
[15:25:14.36] s[02]: 02 81 20 2c 08 01 c8 01 1e 02 82 88
[15:25:14.39] a[04]: ac49x start(201) ch=0 local=29000 remote=ac100064:29000 agg=0
[15:25:14.39] a[04]: Ac49xOpenChannelConfiguration ch=0 rc=0
[15:25:14.39] a[04]: Ac49xT38ChannelConfiguration ch=0 rc=0
[15:25:14.39] a[04]: Ac49xActivateRegularRtpChannelConfiguration ch=0 rc=0
[15:25:14.41] r[02]: 02 81 01 22
[15:25:14.50] a[04]: ac49x ch 0 rtcpR 0 ji -1 rt -1 fl 65535 in 0 out -1
[15:25:14.50] a[04]: ac49x ch 0 establish
[15:25:14.71] a[04]: ac49x ch 0 jitter buffer 35 1 0 1 0 0 0 0
[15:25:15.59] y[04]: h225rcv tpkt msg 7 h225cr 6 addr 172.16.0.100 pt 8018c000
[15:25:15.59] y[04]: h225 decode rc 0, q931 msg 7 (2), len 77
[15:25:15.59] y[04]: h225rcv connect h225cr 6 FS:0(-,0,0) TUNN:1 H245:0(0,0)
[15:25:15.59] i[04]: pstnsnd connect cr 6
[15:25:15.59] s[02]: 02 81 22 2c 08 01 c8 07 29 05 06 03 18 0f 19
[15:25:15.62] a[04]: ac49x ch 0 jitter buffer 145 15 0 17 5 2 0 0
[15:25:15.65] r[02]: 02 81 01 24
[15:25:15.93] r[02]: 00 81 2c 24 08 01 48 0f
[15:25:15.93] s[02]: 00 81 01 2e
[15:25:16.98] a[04]: ac49x ch 0 rtcpT 1 ji 158 rt 0 fl 2 in 2316 out 1816
[15:25:16.98] a[04]: ac49x ch 0: in 8836 out 7874
[15:25:17.57] a[04]: ac49x ch 0 jitter buffer 145 0 0 1 0 0 0 0
[15:25:18.60] a[04]: ac49x ch 0 jitter buffer 145 0 0 2 0 0 0 0
[15:25:20.10] a[04]: ac49x ch 0 rtcpT 1 ji 208 rt 0 fl 0 in 5376 out 4634
[15:25:20.10] a[04]: ac49x ch 0: in 20084 out 18802
[15:25:20.21] a[04]: ac49x ch 0 jitter buffer 145 1 0 1 0 0 0 0
[15:25:20.25] a[04]: ac49x ch 0 rtcpR 1 ji 164 rt 147 fl 0 in 5476 out 5496
[15:25:21.21] a[04]: ac49x ch 0 jitter buffer 155 1 0 1 1 0 0 0
[15:25:23.40] a[04]: ac49x ch 0 rtcpR 1 ji 176 rt 36 fl 0 in 8756 out 8776
[15:25:24.71] r[02]: 00 81 2e 24 08 01 48 45 08 02 80 90
[15:25:24.71] s[02]: 00 81 01 30
[15:25:24.71] i[04]: pstnrcv terminate connection (3201) cr 6 cau 90 err 0 state 16 ch 1 rsid 1
[15:25:24.71] i[04]: rtp stop cr 6 ch 1
[15:25:24.71] x[04]: h225snd relack cr 6 cau 0x90
[15:25:24.71] i[04]: h225connection s 4 close
[15:25:24.71] i[04]: CloseSysFd 4 (st 22)
[15:25:24.71] s[02]: 02 81 24 30 08 01 c8 4d
[15:25:24.79] a[04]: ac49x ch 0: in 37858 out 34096
[15:25:24.79] a[04]: ac49x stop ch=0
[15:25:24.83] a[04]: ac49x ch 0 rtcpR 2 ji 194 rt 36 fl 0 in 10116 out 8426
[15:25:24.92] r[02]: 02 81 01 26
[15:25:24.92] r[02]: 00 81 30 26 08 01 48 5a

```

## TRACE

## Fax Call

```

[16:00:33.87] r[02]: 00 81 54 2c 08 01 01 05 04 03 80 90 a3 18 01 83 7d 02 91 81
[16:00:33.87] s[02]: 02 81 2c 56 08 01 81 0d 18 01 89 1e 02 82 88
[16:00:36.99] r[02]: 00 81 56 2e 08 01 01 7b 70 02 81 31
[16:00:37.17] r[02]: 00 81 58 2e 08 01 01 7b 70 02 81 32
[16:00:37.33] r[02]: 00 81 5a 2e 08 01 01 7b 70 02 81 33
[16:00:37.54] r[02]: 00 81 5c 2e 08 01 01 7b 70 02 81 34
[16:00:40.46] s[02]: 02 81 2e 5e 08 01 81 02 1e 02 82 88
[16:00:40.46] i[04]: pstnrcv setup dad DF:1234 oad cc 0 id 11d007
[16:00:40.46] i[04]: pstnrcv get_voipcfg <DF>
[16:00:40.46] i[04]: rtp start cr 7 ch 1 li 1 ri 0 st 1 fx 0 cp E txm 1
[16:00:40.46] i[04]: h225connect to 172.20.0.100 cr 7
[16:00:40.46] x[04]: h225snd setup dad 1234 cr 7
[16:00:40.46] y[04]: h225rcv tpkt msg d h225cr 7 addr 172.20.0.100 pt 800e7000
[16:00:40.46] y[04]: h225 decode rc 0, q931 msg d (11), len 32
[16:00:40.46] y[04]: h225rcv msg d (11) h225cr 7 FS:0(-,0,0) TUNN:1 H245:0(0,0)
[16:00:40.54] a[04]: ac49x start(201) ch=0 local=29000 remote=0:0 agg=0
[16:00:40.54] a[04]: Ac49xOpenChannelConfiguration ch=0 rc=0
[16:00:40.54] a[04]: Ac49xT38ChannelConfiguration ch=0 rc=0
[16:00:40.54] a[04]: Ac49xActivateRegularRtpChannelConfiguration ch=0 rc=0
[16:00:40.69] y[04]: h225rcv tpkt msg 1 h225cr 7 addr 172.20.0.100 pt 800e7000
[16:00:40.69] y[04]: h225 decode rc 0, q931 msg 1 (3), len 119
[16:00:40.69] y[04]: h225rcv faststart <E4>
[16:00:40.69] y[04]: h225rcv alert h225cr 7 FS:1(E,172.20.0.100,29000) TUNN:1 H245:0(0,0)
[16:00:40.69] i[04]: rtp start cr 7 ch 1 li 1 ri 1 st 2 fx 0 cp E txm 1
[16:00:40.69] s[02]: 02 81 30 5e 08 01 81 01 1e 02 82 88
[16:00:40.70] a[04]: ac49x start2 ch=0 remote=ac100064:29000 rc=0
[16:00:40.77] a[04]: ac49x ch 0 rtcpR 0 ji -1 rt -1 fl 65535 in 0 out -1
[16:00:40.77] a[04]: ac49x ch 0 establish
[16:00:40.88] a[04]: ac49x ch 0 jitter buffer 35 1 0 1 0 0 0 0
[16:00:40.91] y[04]: h225rcv tpkt msg 7 h225cr 7 addr 172.20.0.100 pt 800e7000
[16:00:40.91] y[04]: h225 decode rc 0, q931 msg 7 (2), len 77
[16:00:40.91] y[04]: h225rcv connect h225cr 7 FS:0(-,0,0) TUNN:1 H245:0(0,0)
[16:00:40.92] i[04]: pstnsnd connect cr 7
[16:00:40.92] s[02]: 02 81 32 5e 08 01 81 07 29 05 06 03 18 10 00
[16:00:41.91] a[04]: ac49x ch 0 jitter buffer 85 4 0 4 2 0 0 0
[16:00:41.95] a[04]: ac49x ch 0 rtcpT 1 ji 195 rt 0 fl 0 in 272 out 1340
[16:00:41.95] a[04]: ac49x ch 0: in 940 out 7926
[16:00:43.15] a[04]: ac49x ch 0 fax/data 0 0 1
[16:00:43.15] a[04]: ac49x ch 0 fax/data 0 0 0
[16:00:43.30] a[04]: Ac49xActivateFaxRelayCommand(1) ch 0 rc 0
[16:00:43.30] a[04]: ac49x ch 0 fax detected(1)
[16:00:43.30] i[04]: vpinfo fax detected cr 7 ch 1
[16:00:43.30] i[04]: h245snd(1) cr 7 TerminalCapabilitySet <EG>
[16:00:43.30] y[04]: h225rcv tpkt msg 62 h225cr 7 addr 172.20.0.100 pt 800e7000
[16:00:43.30] y[04]: h225 decode rc 0, q931 msg 62 (6), len 63
[16:00:43.30] y[04]: h225rcv facility h225cr 7 FS:0(-,0,0) TUNN:1 H245:0(0,0)
[16:00:43.30] i[04]: h245rcv(1) cr 7 TerminalCapabilitySetAck
[16:00:43.33] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 1 2 0 0 0 0
[16:00:43.50] y[04]: h225rcv tpkt msg 62 h225cr 7 addr 172.20.0.100 pt 800e7000
[16:00:43.50] y[04]: h225 decode rc 0, q931 msg 62 (6), len 147
[16:00:43.50] y[04]: h225rcv facility h225cr 7 FS:0(-,0,0) TUNN:1 H245:0(0,0)
[16:00:43.50] i[04]: h245rcv(1) cr 7 TerminalCapabilitySet peer=<EG> cfg=<EG>
[16:00:43.50] i[04]: h245snd(1) cr 7 TerminalCapabilitySetAck
[16:00:43.50] i[04]: h245snd(1) cr 7 RequestModeT38
[16:00:43.68] y[04]: h225rcv tpkt msg 62 h225cr 7 addr 172.20.0.100 pt 800e7000
[16:00:43.68] y[04]: h225 decode rc 0, q931 msg 62 (6), len 64
[16:00:43.68] y[04]: h225rcv facility h225cr 7 FS:0(-,0,0) TUNN:1 H245:0(0,0)
[16:00:43.68] i[04]: h245rcv(1) cr 7 RequestModeAck
[16:00:43.68] i[04]: h245snd(1) cr 7 CloseLogicalChannel cn=1
[16:00:43.68] i[04]: h245snd(1) cr 7 OpenLogicalChannel cn=1 cpr=G sessid=1 ctrl=172.20.0.200:29001
[16:00:43.69] y[04]: h225rcv tpkt msg 62 h225cr 7 addr 172.20.0.100 pt 800e7000
[16:00:43.69] y[04]: h225 decode rc 0, q931 msg 62 (6), len 68
[16:00:43.69] y[04]: h225rcv facility h225cr 7 FS:0(-,0,0) TUNN:1 H245:0(0,0)
[16:00:43.69] i[04]: h245rcv(1) cr 7 CloseLogicalChannel cn=1 (1)
[16:00:43.69] i[04]: h245snd(1) cr 7 CloseLogicalChannelAck cn=1
[16:00:43.69] y[04]: h225rcv tpkt msg 62 h225cr 7 addr 172.20.0.100 pt 800e7000
[16:00:43.72] y[04]: h225 decode rc 0, q931 msg 62 (6), len 92
[16:00:43.72] y[04]: h225rcv facility h225cr 7 FS:0(-,0,0) TUNN:1 H245:0(0,0)
[16:00:43.72] i[04]: h245rcv(1) cr 7 OpenLogicalChannel cn=1 cpr=G sessid=1 ctrl=172.20.0.100:29001
[16:00:43.72] i[04]: h245snd(1) cr 7 OpenLogicalChannelAck cn=1 sessid=1 media=172.20.0.200:29000

```

## TRACE

```

[16:00:43.72] y[04]: h225rcv tpkt msg 62 h225cr 7 addr 172.20.0.100 pt 800e7000
[16:00:43.72] y[04]: h225 decode rc 0, q931 msg 62 (6), len 64
[16:00:43.72] y[04]: h225rcv facility h225cr 7 FS:0(-,0,0) TUNN:1 H245:0(0,0)
[16:00:43.72] i[04]: h245rcv(1) cr 7 CloseLogicalChannelAck cn=1
[16:00:43.72] y[04]: h225rcv tpkt msg 62 h225cr 7 addr 172.20.0.100 pt 800e7000
[16:00:43.72] y[04]: h225 decode rc 0, q931 msg 62 (6), len 83
[16:00:43.72] y[04]: h225rcv facility h225cr 7 FS:0(-,0,0) TUNN:1 H245:0(0,0)
[16:00:43.72] i[04]: h245rcv(1) cr 7 OpenLogicalChannelAck cn=1 sessid=1 media=172.20.0.100:29000
[16:00:43.72] i[04]: rtp start cr 7 ch 1 li 1 ri 1 st 3 fx 0 cp G txm 1
[16:00:43.72] i[04]: rtp start cr 7 ch 1 li 1 ri 1 st 3 fx 1 cp G txm 1
[16:00:43.79] a[04]: ac49x start2 ch=0 remote=ac100064:29000 rc=0
[16:00:43.79] a[04]: ac49x start fax ch=0 doing fax already
[16:00:46.70] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 1 3 0 0 0 0
[16:00:48.95] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 1 8 0 0 0 0
[16:00:49.60] a[04]: ac49x ch 0 fax/data 0 0 6
[16:00:49.60] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 3 0 0 0 0
[16:00:51.53] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 12 0 0 0 0
[16:00:51.65] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 20 0 0 0 4
[16:00:52.94] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 20 0 0 0 4
[16:00:54.25] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 1 3 0 0 0 0
[16:00:55.73] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 1 16 0 0 0 0
[16:00:56.44] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 21 0 0 0 4
...
[16:01:25.93] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 21 0 0 0 4
[16:01:27.13] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 3 0 0 0 0
[16:01:28.26] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 18 0 0 0 0
[16:01:29.05] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 1 3 0 0 0 0
[16:01:30.56] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 1 17 1 0 0 0
[16:01:31.62] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 3 1 0 0 0
[16:01:32.72] a[04]: ac49x ch 0 faxrelay 0 0 0 0 0 0 0 0 15 1 0 0 0
[16:01:33.13] r[02]: 00 81 5e 34 08 01 01 45 08 02 80 90
[16:01:33.13] i[04]: pstnrcv terminate connection (3201) cr 7 cau 90 err 0 state 16 ch 1 rsid 1
[16:01:33.13] i[04]: rtp stop cr 7 ch 1
[16:01:33.13] x[04]: h225snd relack cr 7 cau 0x90
[16:01:33.13] i[04]: h225connection s 4 close
[16:01:33.13] i[04]: CloseSysFd 4 (st 22)
[16:01:33.16] s[02]: 02 81 34 60 08 01 81 4d
[16:01:33.16] a[04]: ac49x ch 0: in 5714 out 99508
[16:01:33.16] a[04]: ac49x stop ch=0
[16:01:33.21] a[04]: ac49x ch 0 rtcpR 2 ji 234 rt 15139031 fl 0 in 15139047 out 2228
[16:01:33.22] r[02]: 00 81 60 36 08 01 01 5a

```

## 7.4.3 REMOTE OUTPUT

This trace option provides output for communication with the GATE Manager or NMS. To activate this option, activate the section **Remote** in the GATE Manager. You can choose the depth of the trace output: **Error** is limited to error messages; **Debug** provides information; **Detail** provides the entire packet.

Output is defined with a g, and the port number is 99.

The following output shows an established GATE Manager connection:

```
g[99]:moip: accept rc=2 ipad=<ip address> port=<port>
```

**Table 7.74** Remote Output

Trace Output	Description
<ip address>	Remote system's IP address with GATE Manager.

## TRACE

**Table 7.74** Remote Output (*continued*)

Trace Output	Description
<port>	Origination port for the GATE Manager connection.

```
g[99]:moip: <direction> <length>
```

**Table 7.75** Remote Output

Trace Output	Description								
<direction>	<table> <tr> <td>recv</td> <td>Packets received from the remote system</td> </tr> <tr> <td>send</td> <td>Packets sent to the remote system</td> </tr> <tr> <td>write</td> <td>Output for communication with the internal remote interface</td> </tr> <tr> <td>read</td> <td>Output for communication from the internal remote interface</td> </tr> </table>	recv	Packets received from the remote system	send	Packets sent to the remote system	write	Output for communication with the internal remote interface	read	Output for communication from the internal remote interface
recv	Packets received from the remote system								
send	Packets sent to the remote system								
write	Output for communication with the internal remote interface								
read	Output for communication from the internal remote interface								
<length>	Data length in bytes.								

All other trace output appears in detail mode in ASCII and are also translated.

#### 7.4.4 SMTP TRACE OUTPUT

This trace option provides output for communication with the mail server that occurs when status information or files are sent.

To activate this option, activate the section **Mail** in the GATE Manager. You can choose the depth of the trace output: **Error** is limited to error messages; **Debug** provides information; **Detail** provides the entire packet.

Output is defined with a m, and the port number is 99.

#### Sending Files or Status Information

Global message output:

```
m[99]:mail: sendmail (<length>)
```

## TRACE

**Table 7.76** SMTP Output: Sending Files or Status Info

Trace Output	Description
<length>	Data length in bytes.

Detailed message output:

```
m[99]:mail: sendmail: <Faccount> <ip address> <Taccount> <domain> <subject> <content>
```

**Table 7.77** SMTP Output: Sending Files or Status Info

Trace Output	Description
<Faccount>	Sender's e-mail account (cdr, alarm, file, etc.).
<ip address>	SMTP server's IP address.
<Taccount>	Recipient's e-mail account.
<domain>	Recipient's domain.
<subject>	Content of the subject field; serial number of the sender system.
<content>	Content of the message's body.

All other trace output appears in detail mode in ASCII and are also translated.

### Receiving E-Mail Messages and Sending Them as SMS or USSD

The following output displays communication of an incoming SMTP connection:

```
m[99]:mail: accept: ipad=<ip address> port=<port>
```

**Table 7.78** SMTP Output: Receiving E-Mail and Sending as SMS or USSD

Trace Output	Description
<ip address>	The SMTP peer system's IP address.
<port>	The SMTP peer system's origination port.

## TRACE

The following output displays which packets are sent to the SMTP peer:

```
m[99]:mail: mysend <<content>>
```

**Table 7.79** SMTP Output: Receiving E-Mail and Sending as SMS or USSD

Trace Output	Description
<content>	Content of the transmitted packet.

All other trace output appears in detail mode in ASCII and are also translated.

The following output displays which packets are received from the SMTP peer:

```
m[99]:mail: rcv (<length>)
```

**Table 7.80** SMTP Output: Receiving E-Mail and Sending as SMS or USSD

Trace Output	Description
<length>	Data length in bytes.

All other trace output appears in detail mode in ASCII and are also translated.

**The following output shows that the SMTP connection is being closed:**

```
m[99]:mail: terminate_session
```

The mail module now converts the e-mail message to the internal format and then sent as SMS or USSD. Bulk mail (several recipient entries for the same e-mail) appear as individual messages:

```
m[99]:mail: newMail2Host r=<Taccount> f=<Faccount> s=<subject> d=<content>
```

**Table 7.81** SMTP Output: Receiving E-Mail and Sending as SMS or USSD

Trace Output	Description
<Faccount>	One entry from the sender's To field.

## TRACE

**Table 7.81** SMTP Output: Receiving E-Mail and Sending as SMS or USSD (*continued*)

Trace Output	Description
<Taccount>	Content of the From field.
<subject>	Content of the subject field; usually not used.
<content>	Content of the message's body; is sent as SMS or USSD.

The following output appears when the message has been successfully sent:

```
m[99]:mail: rcvmail <Faccount> -> <Taccount>, done
```

This is converted in the confirmation message, with the subject `sent`. The output in the subsequent communication with the mail server are identical to those described above in "Sending Files or Status Information".

The following output appears when errors occur during transmission of the SMS or USSD message:

Message transmission was faulty and will be repeated:

```
m[99]:mail: rcvmail <Faccount> -> <Taccount>, failed, will retry (<num>)
```

**Table 7.82** SMTP Output: Transmission Error

Trace Output	Description
<num>	Current number of retries.

Retried message transmission was also faulty, and an e-mail will be generated:

```
m[99]:mail: rcvmail <Faccount> -> <Taccount>, failed <num> times
```

The output in the subsequent communication with the mail server are identical to those described above in "Sending Files or Status Information".

### Receiving SMS or USSD and Sending as E-Mail

The following output shows the internal format when an SMS or USSD message is sent to the mail module. This output is generated when transmission of the SMS or USSD message was not possible:

```
m[99]:mail: DATA_IND (<length>)
```

All other trace output appears in detail mode in ASCII and are also translated. The output in the subsequent communication with the mail server are identical to those described above in "Sending Files or Status Information".

## TRACE

## 7.4.5 NUMBER PORTABILITY TRACE OUTPUT

This trace option provides output for the communication with the iMNP database. To activate this option, activate the section **Number Portability** in the GATE Manager. Output is defined with an n, and the port number is 99.

The following output appears when the system sets up a TCP session with the iMNP is being set up:

```
n[99]:np: connecting to <ip addr>
```

**Table 7.83** Number Portability Output: Connection with iMNP

Trace Output	Description
<ip address>	The iMNP system's IP address.

The following output shows that the connection has been established:

```
n[99]:np: connect to <ip addr> ok
```

The following output shows that the connection attempt failed:

```
n[99]:np: connect to <ip addr> failed
```

The following output shows a keep alive packet from the iMNP to keep the TCP session open:

```
n[99]:np: recv <>
```

Response to a number portability request that results in the call's routing:

```
n[99]:np: recv <N<num>>
```

**Table 7.84** Number Portability Output: Response

Trace Output	Description
<num>	Ported or unported number provided by the database.

## TRACE

## 7.4.6 DTMF TONE TRACE OUTPUT

Output about the setup of connections with the DTMF module and DTMF tone recognition are debugged. The output differentiates between the groups `err` and `inf`. Output is defined with a `d`, and the port number is that of the virtual DTMF controller:

The following output shows incoming call setup to the DTMF module:

```
d[<ctrl>]: dtmf: msg <call state>, unknown id <id>, from 14
```

**Table 7.85** DTMF Output: Incoming Call Setup

Trace Output	Description
<ctrl>	The virtual controller's running number.
<call state>	3101 Incoming setup 3201 Disconnect request
<id>	Call identification number.

The following output shows transmitted signaling messages depending on the call state:

```
d[<ctrl>]: dtmf <message type> <id> <call state> 0
```

**Table 7.86** DTMF Output: Signaling Messages

Trace Output	Description
<message type>	Send_d_connect For setup acknowledge and connect. send_alert_ind For alert. send_disconnect For disconnect
<id>	Call identification number.
<call state>	3110 Incoming setup 3102 Disconnect request 3804 Alert 3202 Disconnect confirmation

## TRACE

The following output shows that the media channel has been designated for DTMF tone recognition:

```
d[<ctrl>]: dtmf send_alloc <b_chan id_unset> <ctrl>/<b_chan>
```

**Table 7.87** DTMF Output: Media Channel Designation

Trace Output	Description
<b_chan>	Internal media channel used.
<b_chan id_unset>	Media channel identification (in unset state).

```
d[<ctrl>]: dtmf: msg <msg>, id <b_chan id>, from 1, id <id>/<b_chan id_unset>
```

**Table 7.88** DTMF Output: Media Channel Designation

Trace Output	Description
<msg>	502      Media channel confirmation 102      Connect confirmation 602      Media channel free confirmation

The following output shows the output for negotiated DTMF tones:

```
d[<ctrl>]: dtmf send_info_ind <id> <<dtmf tone>>
```

## 8 SIGNALING AND ROUTING FEATURES

### 8.1 INTRASTAR

This feature uses Intranet/Internet (packet-based networks) and the ISDN network (line-based network) to transmit voice calls. It ensures uninterrupted voice transmission when voice quality over the Intranet/Internet becomes unsupported. How the voice data arrives at the peer is irrelevant.

Automatic fallback to ISDN occurs in the following situation:

- During call setup (when the target number cannot be reached through the Intranet/Internet).
- During the call (when the voice quality no longer corresponds with the customer's requirements).

If the voice quality improves to the defined level during the call, transmission of the voice data will automatically revert to the Intranet/Internet, and the IntraSTAR ISDN connection will be torn down.

Bear in mind that both devices that handle the connections via VoIP or ISDN must be IntraSTAR capable for this feature to work.

To activate this feature, configure the following entries in the `route.cfg`:

```
MapAllIS=*<service type>*<port>
```

The keyword `IS` activates IntraSTAR routing.

The type of service appears first on the right side of the equal sign, followed by the ISDN port to which the IntraSTAR setup will be sent. The following type of service values are possible:

- `0500` (BTX)
- `0700` (data)

The following parameters must be set in the corresponding VoIP profile:

- `VoipIntrastar=yes`
- `VoipBrokenDetectionTimeout=<ms>`
- `VoipQualityCheck=<type minsamples limit recovertime>`

For an example of the IntraSTAR function, please see Chapter 6.7 ⇒.

### 8.2 DIGIT COLLECTION (ENBLOCK/OVERLAP RECEIVING)

This function makes it possible to collect digits and transmit calls when a specific number of digits has been dialed. The entire call number is required for the call to be set up with a mobile phone or the mobile gateway. Since most numbers have a uniform number of digits, the mobile gateway can collect digits when calls enter the gateway in overlap mode. Digit collection occurs through the following mapping command:

```
MapAll<direct>=|<num><<<digits>
```

The `|` (pipe) signifies that the following digits will be collected before they are transmitted, and `<digits>` is the total number of the port digits and the digits of the called party number. This figure can range between 00 and 24 and must be entered in double digits. The parameter `DTMFWaitDial` defines the number of seconds the system waits between the individual digits (default 5). Please bear in mind that you can configure a maximum of 11 digits in the first part of the command and 19 (including a special character, e.g. `#`) in the second. The call will be forwarded as soon as the specified number of digits has been dialed or a time-out limit has been reached.

## REJECTING DATA CALLS AND SPECIFIED NUMBERS

The following example shows a call with the prefix 01555. The | (pipe) signifies that the following digits will be collected before they are transmitted. The 14 at the end is the sum of the port digits and the digits of the called party number (e.g. |#20=3, 01555899666=11, 3+11=14).

```
...
MapAll01555=|#2001555<<14
...
DTMFWaitDial=5
...
```

### 8.3 REJECTING DATA CALLS AND SPECIFIED NUMBERS

This chapter describes the configuration options for exclusion of data calls, prefixes, or call numbers from the routing process.

#### 8.3.1 BLACKLIST ROUTING

The system will reject all calls directly if the MapAll entry contains the keyword & followed by the two-digit cause value (see ETS 300 102-1).

MapAll<direct>=&<cause>



**A maximum of 5000 MapAll entries per time zone can be defined. For more than 5000 entries, please use the Teles iMNP.**

**Example:** In the following example, all calls to the number 004915551234 and all service calls with the prefix 0180 are rejected with a busy signal. All other calls are sent to the VoIP profile DF:

```
MapAll015551234=&91
MapAll004915551234=&91
MapAll0180=&91
MapAll0=40DF:0
...
MapAll9=40DF:9
```

#### 8.3.2 WHITELIST ROUTING

The following entries enable exclusion of specific OADs or trunk groups:

Restrict<ns>=<pl>

MapAll<pl>=&<cause>

NS refers to the internal controller number and the call's origination address.



**A maximum of 1000 Restrict entries per time zone can be defined.**

**Example:** In the following example, the numbers 12345 and 12346 connected to the PBX at port 10 can-

## REJECTING DATA CALLS AND SPECIFIED NUMBERS

not make any international calls. All national calls are sent to the VoIP profile DF and all local calls are sent to the PSTN:

```
Restrict1012346=int
MapAllint00=&91
MapAllint0=40DF:0
MapAllint1=91
...
MapAllint9=90
```

## 8.3.3 REJECTING CALLS WITH ISDN BEARER CAPABILITY DATA

ISDN data calls can be handled differently from voice calls depending on the configuration of the call types DATA or VOICE. This setting is especially interesting for VoIP or GSM calls:

MapAll<direct>=&<cause> <mode>



Analog modem connections are not included in this configuration, as they generally do not have a specified bearer capability.

**Example:** In the following example, all ISDN data calls are rejected with the cause value AA (switching equipment congestion). All calls with the prefix 0170 are routed to the mobile trunk group 26211 and all other calls are routed through VoIP:

```
MapAll0=&aa DATA
...
MapAll9=&aa DATA
...
MapAll0170=262110170
MapAll0=40DF:0
...
MapAll9=40DF:9
```

## 8.3.4 SPECIFIC ROUTING OF DATA CALLS VIA VOIP

In the ISDN network, data calls have a special service type. When an ISDN PBX is connected to a VoIP network, it must continue to work without any problems (e.g. PBX remote maintenance calls or ISDN terminal adapter). In the case of VoIP, a specific RTP payload type is used: trp, ccd or gn64.

**Example:** In the following example, two VoIP profiles are configured, so that all calls are routed, regardless of whether they are data calls or voice over IP calls. The first one is for outgoing voice calls and all calls from VoIP to ISDN. The second profile is exclusively for outgoing data calls, so that sig-

## CLIP AND CLIR

nalng consists solely of clear mode in SDP:

```
MapAll0=40DATA:0 DATA
...
MapAll9=40DATA:9 DATA
MapAll0=|40DF:0<<24
...
MapAll9=|40DF:9<<24
Restrict40=In
MapAllIn=10
[Voip:DF]
VoipDirection=IO
...
VoipCompression=g711a g729 trp t38
...
[Voip:DATA]
VoipDirection=Out
...
VoipCompression=trp
VoipECE=No
...
```

## 8.4 CLIP AND CLIR

## 8.4.1 ROUTING CLIP AND CLIR CALLS

This function allows you to route calls with Calling Line Identification Presentation (CLIP) differently from calls with Calling Line Identification Restriction (CLIR). For example, all CLIP calls can be rejected, so that only calls that do not present the calling number or calls without a calling party number (e.g. analog) are transmitted through the VoIPBOX BRI.

Use the following configuration to define the various routing methods:

```
...
InsertCLIR=0n
...
Restrict9=OK 01
Restrict|9=OK 01
Restrict90=FAIL 01
...
MapInOK00491555=2200491555
MapInFAIL=&aa
...
```

`InsertCLIR=0n` activates this mode. `01` is the service indicator for telephony (analog and ISDN) and is used to differentiate these calls from remote administration calls. `Restrict9=OK 01` means that all telephony calls without a calling number are put through. `Restrict|9=OK 01` means that all CLIR telephony calls are put through. `Restrict90=FAIL 01` means that all CLIP telephony calls are rejected with **No Channel Available** as rejection cause when they are mapped to `MapInFAIL=&aa`.

## 8.4.2 SETTING CLIR

Setting a hash (#) in front of a call number makes it possible to suppress the presentation of the origination number of calls regardless of how the call comes into the system.

The following syntax is used: `MapAll<num>=#<port><num>`

**Example:** The following example shows an appropriate configuration. With this entry, all calls beginning

## CONVERSION OF CALL NUMBERS

with 00491555 are sent to the port with the address 22 and the presentation of the number is restricted:

```
MapAll00491555=#2200491555
```

### 8.4.3 SETTING CLIP

Setting an exclamation point (!) in front of a call number makes it possible to force the presentation of the origination number of calls regardless of how the call comes into the system.

The following syntax is used: `MapAll<num>=!<port><num>`

**Example:** The following example shows an appropriate configuration. With this entry, all calls beginning with 004930 are sent to the port with the address 9 and the presentation of the origination number is allowed.:

```
MapAll004930=!9004930
```

### 8.5 CONVERSION OF CALL NUMBERS

The conversion of call numbers makes it possible, for example, to implement number portability or to redirect calls when the user can be reached at another number. In the following mapping command, the call number 015550123456 is changed to 015559876543 (`MapAll...=9..`):

#### Example 1

```
...
MapAll015550123456=9015559876543
```

Example 2 presents an alternative, in which the routing file is searched through again after conversion of the call number to determine the route for the prefix 01555. Please bear in mind that you can configure a maximum of 5000 mapping entries with no more than 11 digits in the first part of the command and 19 in the second.

#### Example 2

```
...
MapAll015550123451=$Reception
MapAll015550123452=$Reception
MapAll015550123453=$Reception
MapAllReception=015559876543
```

## SETTING NUMBER TYPE IN OAD/DAD

## 8.6 SETTING NUMBER TYPE IN OAD/DAD

In some cases it may be necessary to set a specific number type for the OAD or DAD. There are different methods for the various interfaces. The following number types can be set:

**Table 8.89** Number Types

Type	Definition
u	Unknown
s	Subscriber number
n	National number
i	International number

### OAD

Use the following entry to set a specific number type in the OAD:

```
Restrict<port><num>=<type> 15
```

For the national and international types, remove the 0(s) at the beginning of the number:

```
Restrict<port>0=n 15
```

```
Restrict<port>00=i 15
```

**Example:** In the following example, the bit is set in the caller's origination number for a call via BRI controller 01:

```
Restrict90=n 15
Restrict900=i 15
```

### Example:

You can set a u (unknown type of number) in the `Restrict` entry to change transmission of the national/international bit to 0 or 00 at the beginning of the OAD. As in a mapping entry, the national/international bit will always appear left of the equal sign as 0 or 00.

```
Restrict<port>0=u0 15
```

```
Restrict<port>00=u00 15
```

In the following example, the area code 030 with a 0 at the beginning of the OAD of the PBX's extension is set as a digit and transmitted along with the number:

```
Restrict10555=u030555 15
```



**Restrict entries are handled from general to specific from top to bottom.**

## SETTING THE SCREENING INDICATOR

## DAD

Enter one of the four specific number types in the DAD as follows:

```
MapAll<num>=<port><type><num>
```

In the case of a VoIP controller, enter the following:

```
MapAll<num>=<port><voip profile>:<type><num>
```

The number type will then be defined at the port. For the national and international types, remove the 0(s) at the beginning of the number:

**Example:** In the following example, the international bit is set for all calls to Italy (0039) and the number is transmitted with 39. For the area code 012, the national bit is set and the number is transmitted with 12:

```
MapAll0039=40iG1:i39 VOICE
MapAll012=40iG1:n12 VOICE
```

## 8.7 SETTING THE SCREENING INDICATOR

You can set the screening indicator to define whether the calling-party number sent is specified as **user provided verified and passed** or **network provided**:

User provided verified and passed: v

**Example:** In the following **Restrict** example, the calling party number sent is specified as **user provided verified and passed**:

```
Restrict10=v 15
```

Network provided: p

**Example:** In the following **Restrict** example, the calling party number sent is specified as **network provided**:

```
Restrict10=p 15
```

If you also want to define a number type (see Chapter 8.6 ⇨), it must appear in front of the screening indicator:

**Example:** In the following **Restrict** example, the screening indicator is specified as **network provided**, and the number type is **international**:

```
Restrict10=ip 15
```



Please bear in mind that this entry will not work if you set a minus sign (-) behind `Voip0ad=<num>`.

## SETTING A DEFAULT OAD

## General Example

**Example:** In the following example, a 1:1 routing entry for the individual BRI controllers to VoIP appears in addition to the international flag from BRI to VoIP. A placeholder routing entry is used (**bla** or **blu**), in which the BRI ports are directly assigned to a mapping. Traffic at BRI port 9 is sent directly to VoIP port 40 with the VoIP profile **iG1**. Traffic from BRI port 10 is sent to VoIP port 40 with the profile **iG2**:

```
restrict9=bla
restrict900=i 15
restrict10=blu
restrict1000=i 15

MapAllbla00=40iG1:i
MapAllblu00=40iG2:i
```



The **Restrict** entries for the individual ports must appear in the following order: placeholder, OAD international flag, DAD routing with international flag.

## 8.8 SETTING A DEFAULT OAD

Use the **Restrict** command to set a default origination number (**\*<oad> 15**) when the OAD is restricted (**<num>**):

```
Restrict<port><oad>=*<num> 15
```

**Example:** In the following example, 12345 replaces the original OAD. When the destination number begins with 030, the call is sent through controller 10:

```
Restrict9=*12345 15
MapAll030=10030
```

Use the entry **Restrict<port><oad>=<num> 15** if digits at the beginning of the OAD are the only ones to be restricted.

**Example:** In the following example, the digits 004930 are replaced with 030 followed by the remaining digits. The destination number begins with 030 and is sent through port 10.

```
Restrict9004930=030 15
MapAll030=10030
```

## 8.9 SETTING SENDING COMPLETE BYTE IN SETUP

In some cases the ISDN or H323 peer system may require this byte for routing, or the byte may disrupt signaling.

## Setting Sending Complete

The following entry ensures that the Setup includes a Sending Complete:

## MISCELLANEOUS ROUTING METHODS

**MapAll<direct>=<num>**

The ) causes inclusion of Sending Complete in the ISDN Setup or in the H323 Setup.

**Example:** In the following example, all calls beginning with 0 are sent with a Setup Complete to controller 9:

```
MapAll0=)90
```

### Removing Sending Complete

The following entry ensures that the Setup never includes a Sending Complete:

**MapAll<direct>=(<num>**

The ( causes removal of Sending Complete in the ISDN Setup or in the H323 Setup.

**Example:** In the following example, all calls beginning with 0 are sent without a Setup Complete to VoIP controller 40. The VoIP profile is DF:

```
MapAll0=(40DF:0
```

## 8.10 MISCELLANEOUS ROUTING METHODS

In the following scenarios it may occur that some call numbers must be routed with differing lengths or that some call numbers may require additional number conversion:

- Calls without a destination number
- Connection to a PBX with an extension prefix
- Routing based on the length of the destination number

### 8.10.1 ROUTING CALLS WITHOUT A DESTINATION NUMBER

Enter the following configuration in the `route.cfg` if the VoIPBOX BRI must route calls that come in without a destination number:

```
Restrict<port>=<pl>
```

```
MapAll<pl><num>=<port><num>
```

```
MapAll<pl>=<port>
```

Incoming calls from the configured port will be assigned a placeholder and then all calls beginning with the placeholder will be routed to the placeholder's placeholder's mapping.

**Example:** In the following example, all calls from controller 9 are routed to controller 10, regardless of whether a destination number appears in the setup:

```
Restrict9=pl
MapAllpl=10
```

## MISCELLANEOUS ROUTING METHODS

## 8.10.2 ROUTING CALLS BASED ON EXISTENCE OF DESTINATION NUMBER

To route calls with a DAD differently from those without a DAD, you must activate the block feature in the `pabx.cfg` and restart the system:

```
Block=1
```

Set all other parameters in the `route.cfg`. First define the port from which the incoming calls are to be routed. Incoming calls from the configured port will be assigned a placeholder and then digit collection will occur for all calls beginning with the placeholder. The `$` in the mapping entry, followed by the defined placeholder (`MMM`), causes a second search of the routing file when the number is complete:

```
DTMFWaitDial=<sec>
```

```
Restrict<port>=<pl>
```

```
MapAll<pl>=|$MMM<<98
```

The second routing-file search is based on the routing entry with the leading placeholder (`MMM`):

```
MapAllMMM<digits>=<dest><digits>
```

**Example:** In the following example, digit collection is activated for all calls that come into port 9. Calls with the destination number 2222 are sent to the VoIP controller with the profile `DF` and the destination number is replaced with the SIP account `Betty`. Calls with the number 3333 are sent to VoIP with the SIP account `Al`. All other calls with a destination number are sent to controller 10. Calls without a destination number are sent to the number 12345 at port 10:

```
DTMFWaitDial=5
Restrict9=pl
MapAllpl=|$MMM<<98
MapAllMMM2222=40DF:Betty
MapAllMMM3333=40DF:Al
MapAllMMM0=100
MapAllMMM1=101
MapAllMMM2=102
MapAllMMM3=103
MapAllMMM4=104
MapAllMMM5=105
MapAllMMM6=106
MapAllMMM7=107
MapAllMMM8=108
MapAllMMM9=109
MapAllMMM=1012345
```

## 8.10.3 CHANGING CAUSE VALUES

It is possible to group cause values together into a single defined cause value so that rejected calls can be handled in a specified manner by the PBX sending the call to the VoIPBOX BRI. The following cause value groups can be defined in the `pabx.cfg`:

**Group 0 Cause Values**

All connections that are rejected with a group 0 cause value (`0x80-0x8f`) can be mapped to a single cause value by entering `TranslateG0Cause=<cau>`, whereby `<cau>` represents a cause value in hexadecimal form.

## MISCELLANEOUS ROUTING METHODS

**Group 1 Cause Values**

All connections that are rejected with a group 1 cause value (0x90 - 0x9f) can be mapped to a single cause value by entering `TranslateG1Cause=<cau>`, whereby <cau> represents a cause value in hexadecimal form.

**Group 2 Cause Values**

All connections that are rejected with a group 2 cause value (0xa0 - 0xaf) can be mapped to a single cause value by entering `TranslateG2Cause=<cau>`, whereby <cau> represents a cause value in hexadecimal form.

**Group 3 Cause Values**

All connections that are rejected with a group 3 cause value (0xb0 - 0xbf) can be mapped to a single cause value by entering `TranslateG3Cause=<cau>`, whereby <cau> represents a cause value in hexadecimal form.

**Translating Individual Cause Values**

The following parameter allows you to translate any of these cause values to any other one: `Translate<cause>=<cause>`. The values entered must be in hexadecimal notation between 00 and 7f.

**Translating SIP Causes to ISDN and Vice Versa**

You can define a specific translation from SIP responses (4xx - 6xx) to ISDN cause values and vice versa. If nothing is set, the translation occurs as described in `draft-kotar-sipping-dss1-sip-iw-01.txt`

Use the following parameter to translate a cause from ISDN to a specific SIP response:

`SipCause<ISDN cause>=<SIP Response>`

Repeat the entry to initiate an additional translation.

Use the following parameter to translate a cause from SIP to ISDN:

`SipEvent<SIP Response>=<ISDN Cause>`

The following range of values applies:

400<= <SIP Cause> <=699 (defined in RFC 3261)

0<= <ISDN Cause> <=127 (DSS1 decimal cause number)

## 9 LEAST COST ROUTING

VoIPBOX BRIs are connected between the customer's private branch exchange (PBX) and the public telephone network (PSTN) and/or VoIP. The customer saves connection charges and can effortlessly and automatically connect to the carrier as needed using one of the following six ISDN routing methods:

- Carrier selection
- Dedicated lines
- Direct line access with subaddressing
- Direct line access with DTMF
- Callback with DTMF

This manual contains information only on carrier selection. If you would like to configure any other variation, please contact TELES or refer to the TELES Infrastructure Systems Manual Version 4.5, Chapter 3.

Calls are routed transparently for the PBX and its users. VoIPBOX BRIs can generate charges and route calls using alternate settings in case of network failures.

The following additional services are supported by this feature package:

- Generation of charges
- Time-controlled configuration
- Alternative routing

### 9.1 CARRIER SELECTION

Carrier selection is currently one of the most commonly used routing methods supported by the VoIPBOX BRI. In the VoIPBOX BRI, this routing process also includes calls into the GSM network or through a VoIP network. That means the system is a full-fledged second generation LCR.

#### 9.1.1 ROUTING ENTRIES

Use the **MapAll** command to route calls using Carrier Selection.

- a) Use the following syntax for connections routed via the provider:  
**MapAll<AreaCode>=9<CarrierSelection><AreaCode>**  
 where **<AreaCode>** is the number or number range to be routed and **<CarrierSelection>** is the access number required to reach the provider's network.
- b) For unrouted connections (placed via the public telephone network), use:  
**MapAll<AreaCode>=9<AreaCode>**
- c) To block undesired carrier selection prefixes use:  
**MapAll<CarrierSelection>=&91;(Busy signal)**

In the following example, calls to international destinations are terminated through the VoIP interface. The profile names iG1 and iG2 in the routing entries refer to different VoIP carriers. All other national long distance and local calls are routed through an alternative carrier (01019). All calls from the PSTN or VoIP to the PBX are put through transparently.

## ALTERNATIVE ROUTING SETTINGS

**Example:**

```

MapAll001=40iG1:001
MapAll0044=40iG2:0044
...
MapAll01=90101901
MapAll02=90101902
...
MapAll09=90101909

MapAll1=9010191
MapAll2=9010192
...
MapAll9=9010199

Restrict9=10
Restrict40=10

```



Be sure to enter phone numbers in the routing file in ascending order.

## 9.2 ALTERNATIVE ROUTING SETTINGS

*Alternative routing* refers to the ability to establish connections using a different (alternative) network in case of provider failure (e.g. the VoIP connection has been disrupted). Alternative routing ensures uninterrupted operation of the attached PBX. In such cases, connections are often made via the public network using the `Redirect` command:

```
MapAll<num>=<port><num>
```

```
Redirect3<port><num>=<placeholder>
```

```
MapAll<placeholder>=<alt port><num>
```

**Example:**

```

MapAll001=40iG1:001
Redirect340iG1:=A
MapAllA=9

```

## CHARGE MODELS

## 9.3 CHARGE MODELS

VoIPBOX BRIs can either generate charge information or transmit received charges from the public or corporate networks to the attached PBX. Charge simulation on the VoIPBOX BRI is achieved using variables, which ensure a great degree of flexibility for the implementation of many different charge models including:

- Charge units per time unit
- Flat rate (initial charge without time interval)
- Initial charge plus time interval
- Initial charge plus time interval after delay
- Time interval and/or flat rate plus received charges
- Received charges only or no charge information
- Initial toll-free period with retroactive charge generation afterwards
- Price-per-minute (with whole second accuracy)

In this chapter, **unit** means that charge information is transmitted as a whole-numbered value, and **currency** means that the charge information is sent as a currency amount (e.g. EUR 3.45). The charge impulse generation options can be set for each mapping by adding charge-specific arguments to the `MapAll` commands as shown below. The use of each variable is explained in Table 9.90.

```
MapAllsrc=dst mode time start/wait and
MapCallBackOutprovsrc=dst mode time start/wait.
```

**Table 9.90** Charge Variables

Variable	Purpose
time	Determines the length of each time interval (how long each unit lasts). The value is entered in seconds and hundredths or thousandths of a second (the maximum value accepted is 655.35 seconds, 65.535 if thousandths are entered). If time is set to zero or not present, no charges are generated. External charge information is passed through if received.
start	Sets the initial unit level. Enter a value between 0 and 127 whole units. If you want to use a flat rate, set the desired number of units here and set the wait to 255 to turn off the time interval.
wait	Determines the delay after which charge generation begins. Once this time has elapsed, charge impulses are sent in the interval determined with time. Enter a value between 0 and 254 seconds. 255 deactivates the charge pulse. In this case, the time variable is ignored.

Any external charges can be added to the generated charges by adding 128 to the *start* value. (The value range for the initial unit level is still set from 0 to 127). The maximum supported number of units per connection is 32767 units.



**Charges can be generated only for NT ports.**

## GENERATING CHARGES WITH THE VOIPBOX BRI

Additional adjustments may be made to allow for the implementation of new charge models.

- When charge information is sent as Currency, values can be expressed in thousandths for greater precision in charge calculation.

For the internal Layer 3 protocols, charges can be specified to the third decimal place (thousandth) using the `/Value` option (Example: `/Value:1.056`). In this fashion, charges can be generated for units of currency requiring accuracy to the third decimal place or for fractions such as tenths of a cent. This allows for greater flexibility in the transmission of charges to terminal devices. In order to make use of this option, connected devices must support "AOC-D Currency".

- A multiplication factor can be specified for received or generated charges.

During the charge generation process, each charge unit is multiplied by a preset factor. This factor appears in the mapping entry after the *time* and *start/wait* variables (`MapAllsrc=dst mode time start/wait*factor`).

Each unit, for example, can be converted to 12 cents. The following example illustrates the use of this feature:

```
...
MapAll=91 1 128/255*12
...
```

In the above example, all received charge units are multiplied by 12 and passed on. If AOC-Currency is set on the internal port, each unit appears as 12 cents.

The multiplication factor is also used to implement two new charge models:

- If the factor value exceeds 128, this marks the use of an initial toll-free phase followed by retroactive charge generation.
- If the multiplication factor is set to 255, a "minute price" is used in place of the *time* variable.

These charge models are explained on page 9-139.

### 9.4 GENERATING CHARGES WITH THE VOIPBOX BRI

To generate charges for the attached PBX, add the charge variables described in Table 9.90 to the `MapAll` commands according to the necessities of the corporate network environment.

**Example 1**     `MapAll0172=9123450172 1.65 131/0`  
                   (*time*=1.65, *start*=131, *wait*=0)

In the mapping example above, 3 initial tariff units (131-128) are transmitted upon connection and a new unit is generated every 1.65 seconds and transmitted the next full second. Charges received from the public network for the connection to the corporate network dial-in node are added and transmitted (because 128 has been added to the start variable's value).

**Example 2**     `MapAll0172=9123450172 1.65 131/10`  
                   (*time*=1.65, *start*=131, *wait*=10)

Upon connection establishment, 3 initial tariff units (131-128) are transmitted. Then a 10-second delay (*wait*=10) elapses before charge impulses are generated according to the *time* variable (a new unit is generated every 1.65 seconds and transmitted the next full second). Charges received from the public network for the connection to the corporate network dial-in node are added and transmitted (because 128 has been added to the start variable's value).

## GENERATING CHARGES WITH THE VOIPBOX BRI

New charge models can be implemented by taking advantage of the multiplication factor in conjunction with the *time* and *start/wait* variables.

- Retroactive charge generation after initial toll-free period  
The charge generation process has been expanded to allow for the implementation of this new charge model. In this scenario, an initial period is free of charge, but after this period charges are calculated for the entire

## GENERATING CHARGES WITH THE VOIPBOX BRI

call. For example: the first minute is free, but as soon as the second minute begins, charges are incurred for the first minute as well.

The multiplication factor is set to a base value of 128. If the value exceeds this base, the remaining value represents the number of units charged with each *time* interval. The following configuration generates one unit (129-128) per minute (*time*=60 seconds) retroactively after the first minute (*wait*=60 sec.):

```
...
MapAll1030=901019030 60 0/60*129
...
```

- Price per minute

A price per minute charge model can be configured to assign one thousandth ( $1/1000$ ) of a currency unit (€0.001 or  $1/10$  of a cent) to each charge unit in one of two ways:

- either the attached PBX supports Advice of Charges as *Currency*
- or if not, the PBX can be configured to assign one thousandth ( $1/1000$ ) of a currency unit (€0.001 or  $1/10$  of a cent) to each charge unit.



**If thousandths are defined, a maximum value of 65.535 is possible. If tenths are defined, a maximum value of 6553.5 is possible.**

This model does not always guarantee whole second accuracy (depending on the rates), but it is significantly more precise than the standard charge generation method.

If the attached PBX supports Advice of Charges as *Currency*, include the following line in the VoIPBOX BRI's `pabx.cfg`:

```
...
Controller01=10 NT DSS1 UNIT:€ VALUE:0.001
...
```

If the PBX does not support this AOC model, but allows for the assignment of one thousandth ( $1/1000$ ) of a currency unit (€0.001 or  $1/10$  of a cent) for each charge unit, the above entry need not be present. The configuration entries must make use of the multiplication factor for a single unit as shown below:

```
...
MapAll102=90103002 1.00 0/0*4 ; each second costs €0.004 (€0.24 / minute)
MapAll109=90108809 1.00 0/0*5 ; each second costs €0.005 (€0.30 / minute)
...
```

If the minute price does not allow generated charges to “fit” evenly into a second (such as 20 cents per minute or *0.33 cents per second*), the system can be configured to generate 10 “points” every 3 seconds (€0.01 or 1 cent):

```
...
MapAll102=90101302 3.00 0/0*10 ; 3 seconds cost €0.01 (€0.20 / minute)
MapAll109=90105009 2.00 0/0*3 ; 2 seconds cost €0.003 (€0.09 / minute)
...
```

The “points” method allows for a more precise calculation of smaller intervals.

## GENERATING CHARGES WITH THE VOIPBOX BRI

The price per minute can also be explicitly specified in each routing entry by setting the multiplication factor to 255, to signalize to the system that a minute price is being used instead of the interval usually specified with the *time* variable. The attached PBX must support Advice of Charges as *Currency*, and the appropriate settings must be made in the VoIPBOX BRI's `pabx.cfg` as described on page 9-140. The examples below show sample entries with rates of 18 and 9 cents per minute:

```
...
MapAll902=0101302 0.18 0/0*255 ; €0.18 / minute
MapAll909=0105009 0.09 0/0*255 ; €0.09 / minute
...
```

and

```
...
Controller01=10 NT DSS1 UNIT:€ VALUE:0.010
...
```

If greater precision is desired ( $1/1000$  of a currency unit – \$0.001 or  $1/10$  of a cent), use settings such as the following:

```
...
MapAll902=0101302 1.80 0/0*255 ; €0.18 / minute
MapAll909=0105009 0.90 0/0*255 ; €0.09 / minute
...
```

and

```
...
Controller01=10 NT DSS1 UNIT:€ VALUE:0.001
...
```

## 10 ONLINE TRAFFIC MONITOR

The Online Traffic Monitor allows you to collect and monitor statistics and call detail records (CDRs). The following functions are possible with this feature package:

- ASR calculation
- Generation of CDRs
- Generation of online CDRs using e-mail

### 10.1 ASR CALCULATION AND RESETTING STATISTIC VALUES

When this function is configured in the `pabx.cfg` file, statistical values, such as the number of minutes, number of calls, ASR, etc., are calculated for the entire system at a defined time. These statistics are then copied into a specified file and reset at 0.

This information can also be sent to an e-mail recipient. The following syntax must be used:

```
StatisticTime=<file> <hh:mm> <day> @<account>
```



Bear in mind that the mail server must be configured in the [Mail] section of the `pabx.cfg`, as described in Chapter 5.2.2 ↗.

**Example:** In the following example, the system's statistic values are saved daily into the file `stati.log` and sent to an e-mail account.

```
StatisticTime=stati.log 00:00 11111111 @<account>
```

**Example:** If ?? appears instead of a specified hour, the ASR is written into the `stati.log` file once every hour. The values are reset to zero in the twenty-third hour:

```
StatisticTimeReset=stati.log ??:00
```

**Example:** The next example shows how the statistics appear in the file into which they are copied. The following information is listed in the following order: day and time of the entry, followed by the system name. Calls: connected calls followed by the total number of calls in parentheses. The total number of minutes terminated by the system, followed by the ASR1 value, the external ASR for the traffic source (ext) and the internal ASR for the VoIPBOX BRI (int). These values can differ if a significant number of calls cannot be routed through the VoIPBOX BRI or an insufficient number of channels is available for a prefix. Finally, the average call duration (ACD) appears in the entry:

```
26.10.05-00:00:00,BoIPBOX: Calls: 19351 (29716) - Minutes: 46647 - ASR1: 65.12% - ASR(ext): 65.12% - ASR(int): 65.30% - ACD: 144.63s
```

`StatisticTimeReset=<file> <hh:mm> <day>` performs the same function as the `StatisticTime` parameter, but also resets the counters (A-F).

## GENERATING AND RETRIEVING CDRS

**Example:** In the following example, the system's statistic values are saved on the 15th of every month into the file `reset.log`.

```
StatisticTimeReset=reset.log 00:00 15.
```



It is not possible to configure both `StatisticTimeReset` and `StatisticTime`. ASR values reset to 0 when the SIM card is changed using the GATE Manager.

## 10.2 GENERATING AND RETRIEVING CDRS

With the `Log` and `RrufLog` commands, you save CDRs and unconnected calls in the VoIPBOX BRI.

For these parameters (`Log` and `RrufLog`), a folder and file name must always be specified after the equal sign. The function is not active (no data is recorded) until a file name is specified.

**Example:**

```
Log=/boot/cdr.log
RRufLog=/boot/failed.log
```



With recording of files, system maintenance increases. You have to be sure to download or delete files and ensure that there is enough disk space left on the hard drive.

The service indicator listed in the call log and missed calls list describes the type of connection as a four digit hexadecimal number. The coding is conducted according to the 1TR6 standard. A few frequently used values are listed below:

**Table 10.91** 1TR6 Service Indicators

Service Indicator	Definition
0101	ISDN-telephony 3.1 kHz
0102	analog telephony
0103	ISDN-telephony 7 kHz
0200	Fax group 2
0202	Fax group 3
0203	Data via modem

## GENERATING AND RETRIEVING CDRS

Table 10.91 1TR6 Service Indicators (continued)

Service Indicator	Definition
0400	Telefax group 4
0500	SMS or BTX (64 kbps)
0700	Data transfer 64 kbps
07...	Bit rate adaptation
1001	Video telephone – audio 3.1 kHz
1002	Video telephone – audio 7 kHz
1003	Video telephone – video

For detailed information on how to automatically divide the files (e.g. on a daily basis), please refer to the Chapter 5.2.1.2 ⇒.

## 10.2.1 CALL LOG

The following entry in the `pabx.cfg` configuration file activates the capability to generate CDRs in the VoIPBOX BRI:

```
Log=/boot/cdr.log
```

The `cdr.log` file is stored in the `data` directory. New entries are always added to the end of the file. The file is open only during editing.

Each line represents an outgoing call:

```
DD.MM.YY-hh:mm:ss[Start],DD.MM.YY-hh:mm:ss[End],src,dst,service,dur,cause,charge_publine,[charge_sys]
```

DD – Day	hh – Hour	src – source/extension	dur – duration
MM – Month	mm – Minute	dst – destination	cause – reason for teardown
YY – Year	ss – Seconds	service – service indicator	charge_publine – from the public line
			charge_sys – generated by the system

The charge is specified in units. The service indicator listed will be one of the values shown on Table 10.91. The example below shows a sample log file.

```
28.01.05-19:38:51,28.01.05-19:44:51,10611,9010193333333,0101,360,90,10
28.01.05-19:43:55,28.01.05-19:44:55,10610,2621201555111111,0101,60,90,3
28.01.05-19:32:54,28.01.05-19:44:55,10612,40iG2:004498989898,0101,721,90,15
28.01.05-19:41:34,28.01.05-19:45:34,10616,9010190123456,0101,240,90,4
28.01.05-19:44:19,28.01.05-19:45:49,10615,26212015553333333,0101,90,90,5
28.01.05-19:44:58,28.01.05-19:45:58,10610,26213015562222222,0101,60,90,3
28.01.05-19:46:01,28.01.05-19:47:12,10610,9010194444444,0101,71,90,5
28.01.05-19:46:18,28.01.05-19:47:48,10615,40iG1:0012323232323,0101,90,90,4
28.01.05-19:47:03,28.01.05-19:48:07,10610,9010195555555,0101,64,90,4
28.01.05-19:48:07,28.01.05-19:49:07,10610,901019030666666,0101,60,90,3
```

## GENERATING AND RETRIEVING CDRS

To differentiate between ports with the same number in the CDRs, a specific node number must be defined. You can expand the `subscriber` configuration line with the keyword `NODE[<no.>]` for this purpose. <no.> can be a string of between 1 and 15 characters:

```
Subscriber<xx>=... NODE[<num>]
```

The following entry shows the `pabx.cfg` configuration file changed according to the formula:

```
...
Subscriber00=TRANSPARENT ROUTER ALARM NODE[0000]
...
```

**Example:** In the following CDR entry, <num> consists of a four-digit number (0000) that is included in the CDR.

```
29.08.05-09:45:24,29.08.05-09:46:33,923456789,[0000:01]01771111111,0101,69,0
```

To generate a VoIP-call CDR entry that includes IP addresses for the remote device's signaling and voice data, audio codec and frame size, the entry `VoipIpLogging=Yes` must be included in the VoIP profile.

The following entry shows the `route.cfg` configuration file changed according to the formula:

```
[Voip=Default]
VoipDirection=IO
VoipPeerAddress=192.168.0.2
VoipIpMask=0xffffffff
VoipCompression=g729 t38
VoipMaxChan=30
VoipSilenceSuppression=Yes
VoipSignalling=0
VoipTxM=4
VoipIPLogging=Yes
```

**Example:** The following CDR entry includes IP addresses for signaling and voice data, audio codec and frame size.

```
21.08.07-11:54:09,21.08.07-11:54:14,40501,172.20.25.210:172.20.25.210,6729,20,0101,5,90,0
```

In the case of CDR entries for DLA/Callback calls, the beginning and ending times for the first call leg is always used as the call time. The call time in seconds appears first for the first leg, followed by a slash and the connection time for the second leg.

**Example:**

```
20.10.05-15:27:36,20.10.05-15:30:36,2621201555555555,DLA1234567890,0101,180/168,10,0
```

## 10.2.2 MISSED CALLS LIST

All incoming calls that are not connected can be recorded in a list to facilitate return calls. Recording is activated using the `RRufLog=<name>` entry in the `pabx.cfg`. Specify a file name, e.g. `RRufLog=failed.log`. Once this setting is made, recording begins at once.

A new line of the following format is created for each incoming call that is not accepted:

## GENERATING ONLINE CDRS VIA E-MAIL

*DD.MM.YY-hh:mm:ss,src,dst,cause,dur,att*

DD – Day	hh – Hour	src – source/extension	cause – reason for tear down
MM – Month	mm – Minute	dst – destination	dur – duration of call attempt
YY – Year	ss – Seconds	service – service indicator	att – number of attempts

```
16.01.05-13:58:52,9030399281679,10111,0101,ff,0,1
16.01.05-14:04:06,9030399281679,10111,0101,91,0,1
16.01.05-14:04:15,9,10111,0101,91,0,1
16.01.05-14:04:39,9030399281679,10111,0101,ff,0,1
16.01.05-14:04:50,903039904983,100,0101,ff,0,1
16.01.05-14:05:02,9030399281679,10111,0101,ff,0,1
16.01.05-14:05:03,9,100,0101,ff,0,1
16.01.05-14:05:14,903039904983,100,0101,91,0,1
20.04.05-16:21:10,[4545]981776,2->10200,0101,ff,0,1
20.04.05-16:21:20,[4545]981776,1->10120,0101,ff,0,1
```

The reason the connection could not be established is specified using DSS1 codes:

91 – (user busy)

ff – call not answered (disconnected by calling party)

When callback with DTMF is configured and no connection is established to the B subscriber, an entry recording the A subscriber's connection time is generated in the `failed.log` file:

```
20.02.05-10:47:52,[0004:01]00491721234567,[0005:01]DLA0307654321,0101,ff,34,1
```

The CDR contains the IP addresses for signaling and voice data. The first IP address is the signaling address and the second one is the RTP address. The IMSI is written behind the IP addresses if the keyword `IMSI` is defined in the `pabx.cfg`:

#### Example:

```
12.05.05-10:25:51,40,991783,172.20.25.110:172.20.25.110,0101,ff,8,1
```

In the case of missed-call entries for DLA/Callback calls, *dur* is the connection time for the first leg.

#### Example:

```
20.10.05-15:00:06,9004930555555,DLA262121111111,0101,92,24,1
```

### 10.3 GENERATING ONLINE CDRS VIA E-MAIL

With an appropriate configuration, you can send corresponding CDRs of outgoing and incoming calls as e-mail. Bear in mind that the mail server must be configured in the `[Mail]` section of the `pabx.cfg`, as described in Chapter 5.2.2 ⇒. The sender is given as `cdr` and the system's name appears in the subject box. The text box contains the CDR information according to the format for the entry in `Log=/data/cdr.log @<account>`

## GENERATING ONLINE CDRS VIA E-MAIL

@<domain>. A space must appear between `cdr.log` and @<account>; @<domain> is optional. You can also send CDR entries via e-mail to an e-mail recipient. Each CDR entry generated is sent as e-mail. The following entry in the configuration file activates this function:

```
...  
Log=/data/cdr.log @<e-mail account>@<domain>  
...
```

## 11 DLA/CALLBACK SERVICES

This chapter describes money-saving features that expand the functionality of your VoIPBOX BRI to include callback capability and DTMF services. It is particularly useful for companies with employees who travel often, because it eliminates expensive roaming fees.

### 11.1 CALL CONNECTOR AND CALLBACK SERVER

Various intelligent solutions as a call server are possible. The most important scenarios and properties are described here. The scenarios can also be combined to suit your needs.

- Special announcement
- DLA with DTMF
- DLA with fixed destination number
- Callback with DTMF for the second leg number (known OAD or fixed callback number)
- Callback with DTMF and OAD as callback number
- Callback with DTMF and pre-configured callback number
- Callback for a fixed second leg
- DLA with DTMF and PIN for the first leg and callback for the second leg
- Using a PIN in front of the call number
- Callback via SMS
- Callback via HTTP

Numbers transmitted using DTMF tones can be ended by entering a # sign. Otherwise, a 5-second timer is set, after which DTMF transmission will automatically end.



**CDR entries for calls routed as Callback with DTMF include the connection times for the A and B subscribers. The times are separated by a slash (/). If no connection is established to the B subscriber, an entry recording the A subscriber's connection time is generated in the `failed.log` file.**

#### Activating DTMF Tone Recognition

The VoIPBOX BRI can recognize DTMF tones and initiate calls with these tones. In the `pabx.cfg`, enter a virtual DTMF controller, as described in Table 5.20. The corresponding `Subscriber` entry contains the options:

```
TRANSPARENT ROUTER CHMAX[2]
```

The 2 refers to the maximum number of simultaneous channels used for DTMF recognition.

Example:

```
...
Controller09 = 41 DTMF
...
Subscriber09 = TRANSPARENT ROUTER CHMAX[2]
...
```



The VoIPBOX BRI must be restarted to activate this configuration.

### 11.1.1 SPECIAL ANNOUNCEMENT

An announcement can be played immediately after the connection has been established. The announcement can be defined in the virtual DTMF controller's `Subscriber` line using the following entry:

In the `pabx.cfg` file:

```
DTMF [<sec>, /<dir>/<file>]
```

<sec> refers to the maximum number of seconds that may pass before the next DTMF tone is entered, <dir> refers to the directory, in which the announcement file is saved. `boot` or `data` are possible. The file extension must be `711`.



The file's sound format must be PCM!

**Example:** In this example, a maximum of 2 channels can recognize DTMF tones and change them into dialing data. The announcement is named `DTMF.711` and is saved in the `boot` directory:

```
Subscriber09 = TRANSPARENT ROUTER DTMF[30,/boot/DTMF.711] CHMAX[2]
```

### 11.1.2 DLA WITH DTMF

The user dials a number in the system that is connected with the DTMF platform. She then enters the number with which she would like to be connected.

Make the following entries in `pabx.cfg` to connect a call directly:

```
MapAll<number>=<DTMFport>DTMF
```

```
MapAllDLA=<port>
```

**Example:** In the following example, the call from the number 123 is connected to the DTMF platform and the call that comes in as DTMF tones is directed to the VoIP port and the VoIP profile `DF`:

```
MapAll123=41DTMF
MapAllDLA=40DF:
```



This feature applies only for calls that come from GSM or VoIP. Analog calls are not supported.

## CALL CONNECTOR AND CALLBACK SERVER

## 11.1.3 DLA WITH FIXED DESTINATION NUMBER

The user dials a number in the system that is connected directly with a fixed external number (e.g. international subsidiary number). Make the following entry in the `route.cfg`:

`MapAll<num>=<port><fixed num>`

**Example:** In the following example, the call comes into the number 123456 and is connected to the number 004311111 at the VoIP port and the VoIP profile DF:

```
MapAll123456=40DF:004311111
```

## 11.1.4 CALLBACK WITH DTMF AND OAD AS CALLBACK NUMBER

The user calls a number that is defined so that the user will be called back based on his OAD. An alerting occurs. The user hangs up and is called back. After the user has taken the call, the destination number is entered using DTMF tones. When he has finished dialing, the connection to the destination number is established.



Callback is not possible for VoIP calls.

The following entries in `route.cfg` will initiate callback to the calling party's number:

`MapAllDTMF=<DTMFport>DTMF`

`MapAllDLA=<port>`

`MapAll<number>=CALLB`

`MapAllCB=<port>`

**Example:** In this example, the call with the number 123 is connected with the OAD and the number that comes in as DTMF is directed to the VoIP port and the VoIP profile DF:

```
MapAllDTMF=41DTMF
MapAll123=CALLB
MapAllCB=10
MapAllDLA=40DF:
```



Please configure only one ISDN port 10, as callback to ISDN occurs only through the first configured port number (in the example :10).

## CALL CONNECTOR AND CALLBACK SERVER

## 11.1.5 CALLBACK WITH DTMF AND PRECONFIGURED CALLBACK NUMBER

The user calls a predefined number that is mapped to a defined callback number. An alerting occurs. The user hangs up and is called back at a fixed number. After the user has accepted the call, she must enter the destination number via DTMF. The connection is set up when she finishes dialing.



Callback is not possible for VoIP calls.

Make the following entries in `route.cfg` to initiate callback to a fixed number:

```
MapAllDTMF=<DTMFport>DTMF
MapAllDLA=<port>
MapAll<number>=CALL<callbacknumber>
```

**Example:** In the following example, the call with the number 123 is connected with the number 03012345. The number that comes in as DTMF is directed to the VoIP port and the VoIP profile DF:

```
MapAllDTMF=41DTMF
MAPAllDLA=40DF:
MapAll123=CALL903012345
```

## 11.1.6 CALLBACK TO OAD AND FIXED SECOND LEG

The user calls a predefined number in the system. An alerting occurs. The user hangs up and is called back based on her OAD. After the user accepts the call, she is connected to a fixed, preconfigured number (e.g. operator or corporate central office).



Callback is not possible for VoIP calls.

Make the following entries in `route.cfg`:

```
MapAllDTMF=<port><num>
MapAll<num>=CALLB
MapAllCB=<port>
```

**Example:** In the following example, the caller dials 123456 and her OAD is called back through the ISDN port 10. She is then connected with 501 via the VoIP port and the VoIP profile DF.

```
MapAllDTMF=40DF:501
MAPAll123456=CALLB
MapAllCB=10
```



Please configure only one ISDN port 10, as callback to ISDN occurs only through the first configured port number (in the example :10).

### 11.1.7 DLA WITH DTMF AND PIN FOR FIRST LEG AND CALLBACK FOR SECOND LEG

The user dials a number in the system that is connected to the DTMF platform. He then enters a predefined PIN that maps him to a predefined fixed number that is to be called back. He then hangs up. After he takes the callback, he can enter the second leg number using DTMF tones.

Make the following entries in `route.cfg`:

```
MapAllDTMF=<DTMFport>DTMF
MapAll<num>=<DTMFport>DTMF VOICE
MapAllDLA<num>=CALL<num> VOICE
MapAllDLA=<port> VOICE
```

**Example:** The number 123456 is dialed and the PIN 123# is entered. The call is then connected to the number 004930123456. The destination number can now be transmitted through the VoIP port and the VoIP profile DF using DTMF tones:

```
MapAllDTMF=41DTMF
MAPAll123456=41DTMF VOICE
MapAllDLA123=CALL9004930123456 VOICE
MapAllDLA=40DF: VOICE
```



The user must enter a # following the PIN. Otherwise the callback to the predefined number will not occur. This feature applies only for calls that come from GSM or VoIP. Analog calls are not supported.

### 11.1.8 USING A PIN IN FRONT OF THE CALL NUMBER

To prevent abuse, the following entry can be made to configure a PIN in front of the actual call number:

```
MapAllDLA=$PIN
MapAllPIN<pin>=<port>
```

**Example:** In the following example, the DTMF tones are analyzed, whereby the first 4 (1111) corresponds with the PIN. The call to subscriber B is initiated when the PIN has been entered correctly. All other DTMF tones are directed to the VoIP port and the VoIP profile DF:

```
MapAllDLA=$PIN
MapAllPIN1111=40DF:
```

## 12 ADDITIONAL VOIP PARAMETERS

You can enter the following additional parameters in the `route.cfg` to adjust the configuration for improved communication with the VoIP peer.

### 12.1 SIGNALING PARAMETERS

**Table 12.92** Customized Parameters: Protocol-Independent VoIP Signaling

Protocol-Independent VoIP Signaling Parameters
<p><b>VoipDad=&lt;num&gt;</b></p> <p>The digits/numbers defined here will appear in front of the original DAD. If the parameter is to be valid in only one direction, you must set another profile without this parameter for the other direction.</p>
<p><b>VoipOad=&lt;num&gt;</b></p> <p>The digits/numbers defined here will be transmitted in front of the original OAD. If a minus (-) is entered, the original OAD will not appear. Only the digits entered in front of the minus sign will be displayed. If the parameter is to be valid in only one direction, you must set another profile without this parameter for the other direction.</p> <p>To limit this feature to OADs consisting of a certain number of digits, enter a !, followed by the number of digits, at the end of the entry. In the following example, the digits 567 will appear only if the OAD has at least 6 digits:</p> <p>EXAMPLE: <code>VoipOad=567!6</code></p> <p>To modify the original OAD, enter <code>randomx</code>, whereby x represents a number of random digits that will appear in the OAD.</p> <p>EXAMPLE: <code>VoipOad=567random2-</code></p>
<p><b>VoipProgress=&lt;int&gt;</b></p> <p>For H.323: 0=progress indicator is not transmitted. 1 (default)=progress indicator is transmitted. 2=address complete message is transmitted. 3=call proceeding message type changed in alerting message type.</p> <p>For SIP: 0=183 response ignored and not sent. 1=183 response changed to a progress message with inband-info-available at the ISDN interface (default). 2=183 response changed to an address complete message at the ISDN interface. 3=183 response changed to an alerting at the ISDN interface.</p>
<p><b>VoipComprMaster=&lt;mode&gt;</b></p> <p>This parameter defines which side the first matching codec comes from:</p> <p><b>Yes:</b> Default. Priority is determined by the order of the system's parameter list.</p> <p><b>No:</b> Priority is determined by the peer.</p>

## SIGNALING PARAMETERS

Table 12.92 Customized Parameters: Protocol-Independent VoIP Signaling (continued)

Protocol-Independent VoIP Signaling Parameters
<p><b>VoipHideOadByRemove=&lt;mode&gt;</b></p> <p>If <b>Yes</b> is configured and call setup is to VoIP, the OAD will be removed from signaling if <b>presentation restricted</b> or <b>user-provided</b>, not <b>screened</b> is set in the calling party's presentation or screening indicator. <b>No</b> (default) means no change will occur.</p> <p>NOTE: If the SIP protocol is used, Anonymous will always appear as the account in the From field. Transmission of the OAD can occur in the P-asserted header.</p>
<p><b>VoipSignalCLIR=&lt;string&gt;</b></p> <p>When the configured string appears at the beginning of the OAD and the parameter <b>VoipHideOadByRemove</b> is set, the OAD is removed from signaling, regardless of the presentation bits in the calling party field. If the parameter <b>VoipHideOadByRemove</b> is not set (default), the presentation bits are set at <b>presentation restricted</b> (CLIR) if <b>&lt;string&gt;</b> is -. If the string matches the first digits of the OAD and it comes in with CLIP, the call will be sent to VoIP using CLIR. If the call comes in with CLIR, the string will be added to the beginning of the OAD and CLIR will be removed in the signaling.</p>
<p><b>VoipSingleTcpSession=&lt;mode&gt;</b></p> <p>Enter <b>Yes</b> to send all outgoing VoIP connections in a single TCP session. Enter <b>No</b> (default) for an extra TCP session for each VoIP connection.</p>
<p><b>VoipIgnoreDADType=&lt;mode&gt;</b></p> <p>Enter <b>yes</b> to change the DAD type to unknown, e.g. from international. The type is lost, e.g. the leading 00 bit is removed. Default <b>no</b>.</p>
<p><b>VoipSuppressInbandInfoAvailableIndicatorInCallProceeding=&lt;mode&gt;</b></p> <p>Enter <b>yes</b> to send or receive the Progress Indicator in the Q.931 Call Proceeding message. Default <b>no</b>.</p>
<p><b>VoipG72616PayloadType=&lt;num&gt;</b></p> <p>Changes the SIP payload type for G.726 16 b/s. Default is 35. A common value is 102.</p>
<p><b>VoipG72624PayloadType=&lt;num&gt;</b></p> <p>Changes the SIP payload type for G.726 24 b/s. Default is 36. A common value is 99.</p>
<p><b>VoipTrpPayloadType=&lt;num&gt;</b></p> <p>Defines the payload type for data calls when trp (transparent/clear mode) is used as codec in <b>VoipCompression=&lt;list&gt;</b>. Default is 56. A common value is 102.</p>
<p><b>VoipDataBypassPayloadType=&lt;num&gt;</b></p> <p>Defines the payload type for the RTP packets when the call is sent as a data call. Default 96.</p>
<p><b>VoipMinDigitOnTime=&lt;ms&gt;</b></p> <p>Defines the minimum length of DTMF tones, to ensure DTMF tone detection. Default 0.</p>
<p><b>VoipMinInterDigitTime=&lt;ms&gt;</b></p> <p>Sets a time interval for DTMF tone detection. Default 0.</p>

## SIGNALING PARAMETERS

Table 12.93 Customized Parameters: H.323 Signaling

H.323 Signaling Parameters
<p><b>VoipService=0x&lt;service indicator&gt;</b></p> <p>This parameter sets the barrier capability. For example, it can be used for calls coming from VoIP with the barrier capability data. You can define the service indicator as it is in the 1TR6 code:</p> <ul style="list-style-type: none"> <li>101 - ISDN 3,1kHz</li> <li>102 - analog</li> <li>103 - ISDN 7kHz</li> <li>201 - Fax 2</li> <li>202 - Fax 3</li> <li>203 - Fax 4</li> <li>700 - Data</li> </ul> <p>Normally 101 is used. You can send another value to a switch that wants to handle VoIP calls differently from PSTN calls.</p> <p>EXAMPLE:</p> <p><b>VoipService=0x101</b></p>
<p><b>VoipMapAddressType=&lt;mode&gt;</b></p> <p>For calls from PSTN to VoIP only. Enter <b>yes</b> to change the 00 at the beginning of a number to international and 0 to national.</p>
<p><b>VoipSetupAck=&lt;int&gt;</b></p> <p>1=setup acknowledge is transmitted; 0= setup acknowledge is not transmitted; 2 (default) =transmitted with H.323 information.</p>
<p><b>VoipH245Transport=&lt;int&gt;</b></p> <p>This option determines the H.245 offer. 0 (default)=all signaling variants are offered; 1=FastStart only; 2=H.245 tunneling only; 3=extra session.</p>
<p><b>VoipCanOverlapSend=&lt;mode&gt;</b></p> <p>Enter <b>off</b> to deactivate overlap sending during setup (default on).</p>
<p><b>VoipRestrictTCS=&lt;mode&gt;</b></p> <p>If <b>Yes</b> is entered, the response in the H.323 tunneling terminal capability set contains only the codecs offered by the peer and not those configured in the system. Default <b>No</b>.</p>

## SIGNALING PARAMETERS

Table 12.94 Customized Parameters: SIP Signaling

SIP Signaling Parameters
<p><b>VoipOwnAddress</b>=&lt;account@domain&gt;</p> <p>Used for the <b>From</b> field in Sip-Invite and Sip-Response messages. If only the domain is entered, the origination address (e.g. from ISDN) followed by an @ sign will automatically be set at the beginning.</p>
<p><b>VoipOwnDisplay</b>=&lt;string&gt;</p> <p>The entry is sent as Display Name in the <b>From</b> Field in SIP transmissions. The keyword <b>MSN</b> causes the calling telephone's MSN to be transmitted as Display Name.</p> <p>Example: From: "John" &lt;sip:49301111@teles.de&gt;</p>
<p><b>VoipContact</b>=&lt;account@domain&gt;</p> <p>Used for the <b>Contact</b> field in Sip-Invite and Sip-Response messages.</p>
<p><b>VoipP-Preferred-Identity</b>=&lt;string&gt;</p> <p>Sets the P-Preferred-Identity field in the SIP invite message. The following settings are possible toward SIP:</p> <ul style="list-style-type: none"> <li>* The OAD coming from ISDN/POTS is transmitted.</li> </ul> <p>&lt;string&gt; The defined string is transmitted</p> <p>A combination of both is possible.</p> <p>Examples: 030* or tel:* or sip:user@carrier.de</p>
<p><b>VoipP-Asserted-Identity</b>=&lt;string&gt;</p> <p>Sets the P-Asserted-Identity field in the SIP invite message. The following settings are possible toward SIP:</p> <ul style="list-style-type: none"> <li>* The OAD coming from ISDN is transmitted.</li> </ul> <p>&lt;string&gt; The defined string is transmitted</p> <p>A combination of both is possible.</p> <p>Examples: 030* or tel:* or sip:user@carrier.de</p>
<p><b>VoipOadSource</b>=&lt;int&gt;</p> <p>SIP only: defines the field from which field the calling party number coming from SIP is to be taken:</p> <ul style="list-style-type: none"> <li>0 = From: field (default)</li> <li>1 = Remote-Party-ID</li> <li>2 = P-Preferred-Identity</li> <li>4 = P-Asserted-Identity</li> </ul> <p>NOTE: If 2 or 4 are entered, the number in the field must begin with <b>tel:</b></p> <p>Going to SIP, the OAD is written in the following field:</p> <ul style="list-style-type: none"> <li>0 = From: field (default)</li> <li>1 = Remote-Party-ID (if <b>VoipOwnAddress</b> is not set)</li> </ul> <p>for the fields P-Preferred-Identity and P-Asserted-Identity, please check the corresponding parameters.</p>

## SIGNALING PARAMETERS

Table 12.94 Customized Parameters: SIP Signaling (continued)

SIP Signaling Parameters
<p><b>VoipDadSource=&lt;int&gt;</b>  SIP only: defines the field from which field the called party number coming from SIP is to be taken:  0 = URL  1 = To: field  2 = Remote-Party-ID with party = called</p>
<p><b>VoipUseMaxPTime=&lt;mode&gt;</b>  SIP only. Enter <b>yes</b> to set the field <b>mptime</b> (max packet time) with the values set in <b>VoipTxm (ptime)</b>.  Default <b>no</b>.</p>
<p><b>VoipUseMPTime=&lt;int&gt;</b>  This parameter is used to configure packet time signaling in SDP:  0 = set attribute ptime with each individual codec description (default).  1 = set attribute ptime once as the first attribute after the m- line (media type).  2 = set attribute mptime (multiple ptime) once as the first attribute with the list of the codecs' corresponding ptimes.  3 = remove attribute ptime or mptime in SDP signaling.  The parameter <b>VoipUseMaxPTime</b> is used when <b>VoipUseMPTime</b> is 0, 1 or 2.</p>
<p><b>VoipPrack=&lt;mode&gt;</b>  SIP only: Enter <b>yes</b> to activate Provisional Response Messages in the signaling, as per RFC 3262 "Reliability of Provisional Responses in the Session Initiation Protocol (SIP)". Default is <b>no</b>.</p>
<p><b>VoipOverlap=&lt;mode&gt;</b>  SIP only. Enter <b>yes</b> to activate signaling with overlap sending, as per draft-zhang-sipping-overlap-01.txt. That means digit collection is no longer necessary in the routing when the digets come from ISDN/POTS with overlap sending. When this parameter is active, <b>VoipPrack</b> is automatically set to <b>yes</b>. Default is <b>no</b>.</p>
<p><b>VoipSdpProxy=&lt;mode&gt;</b>  SIP only. Enter <b>yes</b> to activate proxy mode for SDP signaling for SIP to SIP calls. The parameters for RTP signaling will be forwarded from one leg to the next and RTP is not handled by the system. Default is <b>no</b>.</p>
<p><b>VoipInfoSamOnly=&lt;mode&gt;</b>  This parameter determines the behavior in the case of overlap sending (<b>VoipOverlap</b> must also be set). <b>Yes</b> means that the contents of the <b>SubsequentNumber</b> field in info method will be attached to the URI's available digits or to the invite message's <b>To</b> field. <b>No</b> (default) means that the digit contents of the <b>SubsequentNumber</b> field will be used.</p>

## LOCATION SERVER PARAMETERS

Table 12.94 Customized Parameters: SIP Signaling (continued)

SIP Signaling Parameters
<p><b>VoipAllow=&lt;list&gt;</b>            The <b>allow</b> header shows the supported methods and can be set here.  <b>EXAMPLE: VoipAllow=INVITE, BYE</b>            The default setting includes the following:  <b>INVITE, ACK, CANCEL, BYE, UPDATE, REGISTER, PRACK, INFO, NOTIFY, REFER</b>            It may be necessary to remove some of these entries for some peers.</p>
<p><b>VoipDelayDisc=&lt;mode&gt;</b>  <b>Yes</b> (default) delays confirmation transmission during call teardown. That means the release tone is audible when the peer tears down the call.  <b>NOTE:</b> For versions 13.0c or lower: To improve ASR, we recommend that you set this parameter to <b>Yes</b> if you use the parameter <b>VoipMaxChan</b>.</p>

## 12.2 LOCATION SERVER PARAMETERS

The following parameters can be used in the VoIP profile when the SIP agent wants to register with the VoIPBOX BRI.

Table 12.95 Customized Parameters: Location Server

Location Server Parameters
<p><b>VoipOwnUser=&lt;string&gt;</b>            Defines the username the agent uses to register.</p>
<p><b>VoipOwnPwd=&lt;string&gt;</b>            Defines the password the agent uses to register.</p>
<p><b>VoipExpires=&lt;sec&gt;</b>            Defines the maximum number of seconds the agent's registration applies (default 3600).</p>
<p><b>VoipAuth=&lt;mode&gt;</b>            Defines the authentication procedure <b>www</b> (default) or <b>proxy</b>.</p>

**Example:** The following example creates an account for a user agent with the username 130 and password

## LOCATION SERVER PARAMETERS

test130. Authentication occurs with the procedure www:

```
MapAll130=40U1:130
[Voip:U1]
VoipDirection=I0
VoipIpMask=0x00000000
VoipOwnUser=130
VoipOwnPwd=test130
VoipExpires=300
VoipAuth=www
VoipCompression=g711a g711u g729 g729a g729b g729ab
VoipSilenceSuppression=no
VoipSignalling=1
VoipMaxChan=8
VoipTxM=2
VoipDtmfTransport=0
VoipRFC2833PayloadType=101
VoipMediaWaitForConnect=Tone
```

## ROUTING PARAMETERS

## 12.3 ROUTING PARAMETERS

Table 12.96 Customized Parameters: VoIP Routing

VoIP Basic Parameters
<p>VoipOadMask=&lt;num&gt; VoipDadMask=&lt;num&gt;</p> <p>It is also possible to define the profile by destination or origination number (and not only by the IP address). That means you can use different parameters not only for different IP addresses, but also for different numbers (e.g. other codec, <code>WaitForConnect</code>, etc.). For example, you can define a number for the head of the company, so that her MSN always uses G.711.</p> <p>It is possible to configure a list of numbers for a total of up to 80 characters per line. You must define the entry again if you need more numbers. You can also use a wildcard * at the end of the number to match all calls with OADs or DADs beginning with the digits entered. Use a coma to separate the numbers. Example:</p> <pre>VoipDadMask=123, 345*, 567, ..... VoipDadMask=912, 913*, 914, ..... .....</pre> <p>Bear in mind that you must enter numbers from specific to global (as for normal routing in the <code>route.cfg</code>). That means you must enter a profile with more specific numbers above a profile with more global numbers.</p>
<p>VoipUseIpStack=&lt;mode&gt;</p> <p>Enter <b>Yes</b> to facilitate direct use of an xDSL or dial-up connection if the corresponding profile is defined. Default is <b>No</b>.</p>
<p>VoipUseEnum=&lt;mode&gt;</p> <p>Enter <b>yes</b> (default <b>no</b>) to activate an ENUM query to the called number before the call is set up via VoIP or PSTN. Using a standard DNS query, ENUM changes telephone numbers into Internet addresses. If a number is found, the call is set up via VoIP. If not, call setup occurs via PSTN or with another VoIP profile.</p> <p>NOTE: The query must include country and area codes.</p>
<p>VoipEnumDomain=&lt;string&gt;</p> <p>Use this parameter to modify the domain name for the enum query (default is <code>e164.arpa</code>).</p>
<p>VoipUseStun=&lt;mode&gt;</p> <p>Enter <b>yes</b> (default <b>yes</b>) to use the STUN values for the VoIP profile.</p>
<p>VoIPOwnIpAddress=&lt;ip addr&gt;</p> <p>If the system is behind a NAT firewall that does not translate H.323 or SIP, the NAT firewall's public IP address is transmitted as own IP address in the H.323 or SIP protocol stack (not the private IP address). In this case, the public IP address must be defined. Bear in mind that the NAT firewall transmits the ports for signaling and voice data to the VoIPBOX BRI's private IP address.</p>

## QUALITY PARAMETERS

## 12.4 QUALITY PARAMETERS

Table 12.97 Customized Parameters: VoIP Quality

VoIP Quality Parameters
<p><b>VoipSilenceSuppression=&lt;mode&gt;</b>            Activates silence suppression (see Table 5.26).</p>
<p><b>VoipBandwidthRestriction=&lt;mode&gt;</b>            Enter <b>Yes</b> to include the VoIP profile in traffic shaping. Default is <b>No</b>. For a description of the functionality, please refer to <b>VoipMaximumBandwidth</b> in Table 5.22.</p>
<p><b>VoipMediaWaitForConnect=&lt;mode&gt;</b>            This parameter allows you to influence the system's behavior in relation to voice channel negotiation (RTP stream).            The following settings are possible:  <b>No</b> (default): RTP data is transmitted immediately after negotiation for RTP. SIP: Early Media is activated; SDP is sent with 183 or 180.  <b>Yes</b>: The negotiation of RTP data is sent only after the connection has been established. SIP: SDP is sent only with 200 and ack.  <b>Tone</b>: The VoIP peer or the connected PBX requires generation of inband signaling tones (alert, busy, release).            NOTE: If <b>Tone</b> is entered, the tones are not played in the direction of the PBX if RTP is already exchanged before connect (inband is switched through).            Bear in mind that the parameter <b>SWITCH</b> in the VoIP controller's <b>Subscriber</b> line must be removed if the tones are played for the PBX.            If <b>Tone</b> is entered and the tones are played to VoIP, the VoIP media channel cannot be released following an ISDN call disconnect as long as the tones are being transmitted. This can result in CDR errors on the peer side.</p>
<p><b>VoipRtpTos=&lt;num&gt;</b>            Enter a value between 0 and 255 to set the TOS (type of service) field in the RTP packet IP header. Possible values are described in Table 12.98. If your IP network uses differentiated services, you can also define the DSCP (differentiated services codepoint) for the RTP packets. The DSCP is the first six bits in the TOS octet.            NOTE: <b>VoipUseIpStack</b> must be 0 (default).</p>
<p><b>VoipRtcpTos=&lt;num&gt;</b>            Enter a value between 0 and 255 to set the TOS (type of service) field in the RTCP packet IP header. Possible values are described in Table 12.98. If your IP network uses differentiated services, you can also define the DSCP (differentiated services codepoint) for the RTCP packets. The DSCP is the first six bits in the TOS octet.            NOTE: <b>VoipUseIpStack</b> must be 0 (default).</p>

## QUALITY PARAMETERS

Table 12.97 Customized Parameters: VoIP Quality (continued)

VoIP Quality Parameters
<p><b>VoipPCMPacketInterval=&lt;int&gt;</b>            This parameter changes the default interval for PCM codecs (G.711, G.726). That means the <b>VoipTxm</b> factor is multiplied using this interval:            0 = 10ms (default)            1 = 5 ms            2 = 10 ms            3 = 20 ms</p>
<p><b>VoipCallGroup=&lt;name&gt;</b>            All outgoing VoIP calls for VoIP profiles with the same <b>VoipCallGroup</b> name are distributed cyclically to these profiles.</p>
<p><b>VoipOverflow=&lt;name&gt;</b>            When the value entered in <b>VoipMaxChan</b> is reached, all overflow calls will be sent to the profile defined here. An alternative VoIP profile can also be used if the default profile can no longer be used as a result of poor quality.</p>
<p><b>VoipDJBufMinDelay=&lt;count&gt;</b>            Enter a value in milliseconds (0-320) to set a minimum jitter buffer limit (default 35). For fax transmission (t.38) it is fixed to 200ms.            NOTE: <b>VoipDJBufMaxDelay</b> must be greater than <b>VoipDJBufMinDelay</b>.</p>
<p><b>VoipDJBufMaxDelay=&lt;count&gt;</b>            Enter a value in milliseconds (0-320) to set a maximum jitter buffer limit (default 150). For fax transmission (t.38) it is fixed to 200ms.            NOTE: <b>VoipDJBufMaxDelay</b> must be greater than <b>VoipDJBufMinDelay</b>.</p>
<p><b>VoipDJBufOptFactor=&lt;count&gt;</b>            Enter a value between 0 and 13 to set the balance between low frame erasure rates and low delay (default 7).</p>
<p><b>VoipConnBrokenTimeout=&lt;sec&gt;</b>            An entry is generated in the <b>protocol.log</b> file and the connection is terminated after a connection broken exists for the number of seconds entered (default 90). If 0 is entered, no entry will be generated and the connection will not be terminated.</p>
<p><b>VoipTcpKeepAlive=&lt;mode&gt;</b>            Enter <b>yes</b> (default) to send the <b>RoundTripDelayRequest</b> message every 10 seconds (necessary for long calls with firewalls using TCP aging).</p>
<p><b>VoipIntrastar=&lt;mode&gt;</b>            Enter <b>Yes</b> to activate the IntraSTAR feature. When the IP connection results in poor quality, an ISDN call is sent to the peer and the voice data is automatically transmitted via ISDN.</p>

## QUALITY PARAMETERS

**Table 12.97** Customized Parameters: VoIP Quality (*continued*)

<b>VoIP Quality Parameters</b>
<p>VoipBrokenDetectionTimeout=&lt;ms&gt;</p> <p>When this parameter is set, the system recognizes an interruption in the transmission of RTP/RTCP data in the VoIP connection following the set number of milliseconds. This parameter is necessary to set up an IntraSTAR call immediately when the IP connection is disrupted. Bear in mind that <b>VoipSilenceSuppression=No</b> must appear in the VoIP profile. For a description of IntraSTAR, see Chapter 8.1 ➔. For an example, see Chapter 6.7 ➔.</p>
<p>VoipAutoRtpAddr=&lt;mode&gt;</p> <p>Some application scenarios require automatic RTP IP address and port recognition for VoIP calls, for example if a firewall or NAT changes the IP address of incoming RTP data. Enter <b>Yes</b> to activate automatic recognition (default <b>No</b>).</p>

## QUALITY PARAMETERS

Table 12.97 Customized Parameters: VoIP Quality (continued)

VoIP Quality Parameters
<p>VoipAGC=&lt;x y z&gt;</p> <p>This parameter allows automatic gain control of input signals from PSTN or IP. Enabling this feature compensates for near-far gain differences:</p> <p>x - direction (0 for signals from TDM, 1 for signals from IP)</p> <p>y - gain slope (controls gain changing ratio in -dBm/sec, values 0 to 31, default 0)</p> <p>z - target energy (determines attempted signal energy value in -dBm, values 0 to 63, default 19)</p> <p>Gain Slope:</p> <p>0 - 00.25dB  1 - 00.50dB  2 - 00.75dB  3 - 01.00dB  4 - 01.25dB  5 - 01.50dB  6 - 01.75dB  7 - 02.00dB  8 - 02.50dB  9 - 03.00dB  10 - 03.50dB  11 - 04.00dB  12 - 04.50dB  13 - 05.00dB  14 - 05.50dB  15 - 06.00dB  16 - 07.00dB  17 - 08.00dB  18 - 09.00dB  19 - 10.00dB  20 - 11.00dB  21 - 12.00dB  22 - 13.00dB  23 - 14.00dB  24 - 15.00dB  25 - 20.00dB  26 - 25.00dB  27 - 30.00dB  28 - 35.00dB  29 - 40.00dB  30 - 50.00dB  31 - 70.00dB</p>

## QUALITY PARAMETERS

**Table 12.97** Customized Parameters: VoIP Quality (*continued*)

<b>VoIP Quality Parameters</b>
VoipVoiceVolume=<num> The volume of VoIP calls coming from the Ethernet. The range is 0-63. The default value of 32 is 0 dB.
VoipInputGain=<num> The volume of VoIP calls coming from ISDN,POTS or mobile. The range is 0-63. The default value of 32 is 0 dB.

## QUALITY PARAMETERS

Table 12.97 Customized Parameters: VoIP Quality (continued)

VoIP Quality Parameters
<p>VoipQualityCheck=&lt;type minsamples limit recovertime&gt;</p> <p><b>type</b> Enter one of the following: ASR1, ASR2, RoundTripDelay, Jitter or FractionLost</p> <p><b>When type is ASR1 or ASR2:</b></p> <p><b>minsamples</b> Minimum number of calls for which ASR shall be calculated with:</p> <p><b>limit</b> A value between 0 and 100</p> <p><b>recovertime</b> Seconds to block the profile.</p> <p><b>When type is RoundTripDelay:</b></p> <p><b>minsamples</b> Minimum number of seconds RTD must be above:</p> <p><b>limit</b> The highest acceptable value for RTD (in milliseconds)</p> <p><b>recovertime</b> Seconds to block the profile.</p> <p><b>When type is Jitter:</b></p> <p><b>minsamples</b> Minimum number of seconds jitter must be above:</p> <p><b>limit</b> The highest acceptable value for jitter (in milliseconds)</p> <p><b>recovertime</b> Seconds to block the profile.</p> <p><b>When type is FractionLost:</b></p> <p><b>minsamples</b> Minimum number of seconds FL must be above:</p> <p><b>limit</b> The highest acceptable value for FL (percentage between 0 and 100)</p> <p><b>recovertime</b> Seconds to block the profile</p> <p>NOTE: If you base VoipQualityCheck on the ASR values: During setup, calls are calculated as not connected, which lowers the number of connected calls. Example: If minsamples is set at 20, with a limit of 80%, 4 calls in the setup phase will lower the ASR of the previous 20 calls to 80% and the profile will be blocked.</p>
<p>VoipECE=&lt;mode&gt;</p> <p>Enter yes (default) to set ITU G. 168 echo cancellation. Enter no to disable echo cancellation.</p>

## QUALITY PARAMETERS

**Table 12.97** Customized Parameters: VoIP Quality (*continued*)

VoIP Quality Parameters	
=<ms>	This parameter defines the required tail length for echo cancelation. The following values in ms are possible: 32 64 (default) 128
VoipT301=<sec>	An outgoing VoIP calls will be canceled in the state of Alerting (for H323) or Ringing (for SIP) if the number of seconds entered has passed and there is no response from the IP or VoIP carrier.
VoipT303=<sec>	If this parameter is entered in a SIP profile, transmission of the INVITE is canceled after the number of seconds entered has passed. The call can then be redirected, for example to PSTN. This improves the reliability of the system when an IP or VoIP carrier's service fails.  EXAMPLE: Redirect340DF:=A MapAllA=9 [Voip:DF] ..... VoipT303=5
VoipT304=<sec>	An outgoing VoIP calls will be canceled in the state of Setup Acknowledge (for H323) or Trying (for SIP) if the number of seconds entered has passed and there is no response from the IP or VoIP carrier.
VoipT310=<sec>	An outgoing VoIP calls will be canceled in the state of Call Proceeding (for H323) or Session Progress (for SIP) if the number of seconds entered has passed and there is no response from the IP or VoIP carrier.

The following specifications for Quality of Service correspond with RFC791 and RFC1349.

**Table 12.98** Quality of Service Values

Bit Distribution	0	1	2	3	4	5	6	7
	Precedence			TOS				MBZ
Bit	Description							
0-2	Precedence							
3	TOS: 0=normal delay, 1=low delay							
4	TOS: 0=normal throughput, 1=high throughput							
5	TOS: 0=normal reliability, 1=high reliability							

## COMPRESSION PARAMETERS

**Table 12.98** Quality of Service Values (*continued*)

6	TOS: 0=normal service, 1=minimize monetary cost
7	MBZ: must be 0 (currently not used)
Precedence	Description
111	Network control
110	Internetwork control
101	CRITIC/ECP
100	Flash override
011	Flash
010	Immediate
001	Priority
000	Routine

## 12.5 COMPRESSION PARAMETERS

The following parameters are for RTP multiplexing, which aggregates RTP packets (voice user data) for individual VoIP calls into a packet. The header (for Ethernet, IP, UDP and RTP) is sent only once for all calls instead of for each individual call. The relationship between header and payload benefits the payload when several calls occur simultaneously. This compression does not result in any loss in voice quality.

This feature is possible with a Teles peer and requires the following entries in the VoIP profile:

**Table 12.99** Customized Parameters: VoIP Compression

VoIP Compression Parameters
VoipAggRemoteRtpPort=<port> Enter the port for the VoIP peer that is the first RTP port. The next port is always the corresponding RTCP port. The port that is two numbers higher will be used for the next VoIP channel. Default 29000.
VoipAggRemoteDataPort=<port> <b>VoipAggRemoteDataPort=29500</b> Enter the port for the VoIP peer that is used for aggregated packets (compressed data). Default: 29500.
VoipAggOwnDataPort=<port> <b>VoipAggOwnDataPort=29500</b> Enter the own port number used for aggregated packets. Default: 29500.
VoipAggRemoteRtpPortSpacing=<count> Defines the space between the ports used for the peer's individual RTP streams (default 2).

## FAX/MODEM PARAMETERS

## 12.6 FAX/MODEM PARAMETERS

Table 12.100 Customized Parameters: VoIP Fax

VoIP Fax/Modem Parameters
<p><b>VoipFaxTransport=&lt;int&gt;</b>  Enter 2 and signaling will switch to G.711a (framesize 40ms) when the peer cannot handle fax transmission with T.38. The codec will change when the system detects a fax or modem connection on the channel. 0 = disabled (default); 1 = relay. T.38 is always used.  NOTE: Bear in mind that if T.38 is defined in the <b>VoipCompression=</b> line of the VoIP profile, the system will switch only when it detects a modem connection. Fax calls will still be transmitted using T.38.</p>
<p><b>VoipFaxBypassPayloadType=&lt;num&gt;</b>  Defined the payload type for a fax's RTP packets when T.38 is not used (default 102).</p>
<p><b>VoipFaxMaxRate=&lt;num&gt;</b>  If the peer does not support auto negotiation or has a fixed transmission rate, you can define the fixed rate:  0 - 2400 Bit/sec  1 - 4800  2 - 7200  3 - 9600  4 - 12000  5 - 14400 (default)  EXAMPLE:  <b>VoipFaxMaxRate=5</b></p>
<p><b>VoipFaxECM=&lt;mode&gt;</b>  You can use this parameter to disable the error correction mode for fax transmission: <b>yes=enabled</b> (default), <b>no=disabled</b>.</p>
<p><b>VoipFaxProtocol=&lt;int&gt;</b>  Defines the protocol used:  0 = TCP  1 = FRF.11  2 = UDP, datarate management 1  3 = UDP, datarate management 2 (default)</p>
<p><b>VoipT38ErrorCorrectionMode=&lt;int&gt;</b>  Sets the error-correction mode:  0 = Redundancy (default)  1 = Forward error correction</p>

## FAX/MODEM PARAMETERS

Table 12.100 Customized Parameters: VoIP Fax (continued)

VoIP Fax/Modem Parameters
<p>VoipT38CtrlDataRedundancy=&lt;int&gt;            Defines the redundancy level for control packets:            0 = Disable (default)            1-7 = Sets level</p>
<p>VoipT38ImageDataRedundancy=&lt;int&gt;            Defines the redundancy level for fax content:            0 = Disable (default)            1-3 = Sets level</p>
<p>The following parameters are responsible to set the modem transport method if a modem connection is detected.</p>
<p>VoipV21Transport=&lt;mode&gt;            0=disabled (must be set to 0).</p>
<p>VoipV22Transport=&lt;mode&gt;            0=disabled, 2=bypass (default).</p>
<p>VoipV23Transport=&lt;mode&gt;            0=disabled, 2=bypass (default).</p>
<p>VoipV32Transport=&lt;mode&gt;            0=disabled, 1=relay (default), 2=bypass .</p>
<p>VoipV34Transport=&lt;mode&gt;            0=disabled, 1=fallback to v32, 2= bypass (default).</p>

## DTMF PARAMETERS

## 12.7 DTMF PARAMETERS

Table 12.101 Customized Parameters: VoIP DTMF

VoIP DTMF Parameters
<p><b>VoipIBSDetectDir=&lt;int&gt;</b>  Enter 1 and DTMF tones (and all other inband signaling) will be detected from the Ethernet side. Enter 0 for DTMF tones to be detected from the PCM side (default). DTMF tones from the Ethernet side are transmitted to the host as ISDN dialing information only if 1 is entered. In this case, <b>VoipDtmfTransport</b> should be 1 or 3.</p>
<p><b>VoipDtmfTransport=&lt;int&gt;</b>  0 (H323) = DTMF relayed with H.225 signaling information.  0 (SIP) = DTMF relayed with SIP INFO.  1 = DTMF and MF taken from audio stream and relayed to remote.  2 (default) = DTMF and MF kept in audio stream and not relayed.  3 = DTMF and MF taken from audio stream and relayed to remote as per RFC2833.  4 (SIP only) = SIP INFO messages will be relayed as DTMF and MF.</p>
<p><b>VoipDtmfFallback=&lt;int&gt;</b>  If <b>VoipDtmfTransport=3</b> is set and the peer does not support DTMF transmission according to RFC 2833, the following settings apply:  2 = automatic fallback to inband  0 = automatic fallback to signaling messages (default)</p>
<p><b>VoipRFC2833PayloadType=&lt;num&gt;</b>  This parameter changes the DTMF payload type. The default value is 96, a common value is 101.</p>
<p><b>VoipMinDigitOnTime=&lt;ms&gt;</b>  Defines the minimum length of DTMF tones, to ensure DTMF tone detection. Default 0.</p>
<p><b>VoipMinInterDigitTime=&lt;ms&gt;</b>  Sets a time interval for DTMF tone detection. Default 0.</p>

## 13 OPTIONAL FUNCTION MODULES

This chapter contains a description of modules that expand the functionality of the VoIPBOX BRI, such as:

- HTTP User Interface
- iPBX
- SNMP agent
- DNS forwarder
- ipupdate - DynDNS client

Since these features are only required in individual cases, they are not part of the default software packet. They can be installed as stand-alone modules for the desired function. The description of the functionality of individual modules appears in their respective chapters.

### 13.1 OVERVIEW

The modules can be downloaded using FTP. The access data for each module is as follows:

- Http User Interface  
ftp://195.4.12.80  
user: httpd  
password: httpd
- iPBX  
ftp://195.4.12.80  
user: ipbx  
password: ipbx
- DNS Forwarder  
ftp://195.4.12.80  
user: dnsmasq  
password: dnsmasq
- snmp agent  
ftp://195.4.12.80  
user: snmp  
password: snmp
- ipupdate  
ftp://195.4.12.80  
user: ipupdate  
password: ipupdate

Install the respective software package on the VoIPBOX BRI using TELES.GATE Manager. For a description of how to update the software, please refer to Chapter 7.3 ⇨ . Make sure the module's file ending is correct before installation. The number in the file ending shows the starting order of the modules. Do NOT change this number if it is 0! All other modules can simply be numbered in ascending order.

For instance, the ending for the optional function module will be tz2 or higher:

- tz2
- tz3

## HTTP USER INTERFACE

Following completion of transmission, you must adjust the module's configuration and restart the VoIPBOX BRI. Once you have restarted the system, you can use the required features.

### 13.2 HTTP USER INTERFACE

The HTTP user interface is a user-friendly tool that can be used by carriers, administrators and individual users to configure the VoIPBOX BRI. For a detailed description of the HTTP user interface, please see Chapter 4.11.2 [⇒](#).

### 13.3 IPBX

The iPBX is a soft PBX that runs as an add-on application on TELES CPE devices. These include VoIPBOX BRIes (BRI or analog). It is used to connect local IP telephones and soft phones, as well as traditional line-based PBX extensions and telephones. The connection to the public telephone network can occur via VoIP, through the traditional PSTN network, or a combination of both. Both analog and ISDN (BRI) lines can be connected as PSTN. Connection to the carrier can occur using SIP, H.323, or a combination of both. Multiple VoIP destinations can be mapped through the routing process. The iPBX can be used to add local or remote IP extensions (work@home) to an existing PBX without requiring changes to the existing PBX, or you can implement the iPBX to completely replace your old PBX. For further information, please refer to the iPBX Systems Manual, which can also be found on the FTP server.

#### Features

- Caller ID
- Call forward/transfer
- Call parking/retrieve
- Conference calling
- DND (Do Not Disturb)
- Music on hold
- Direct inward dial access
- Direct outward dial
- Different dial plans
- Hunt groups
- Push to talk
- Dial by name
- Fax support
- Voicemail
- IVR

### 13.4 SNMP AGENT

This module allows you to connect the systems and their functions to an SNMP-based network monitoring system. With this module, SNMP requests are answered and alarm messages (E.g. Layer 1 errors on E1 lines) and error recovery messages are sent via SNMP trap.

## DNS FORWARDER

Traps are generated for all line or mobile ports. The running number in the trap corresponds with the port. The module also monitors whether the voice codec chips are functioning correctly.

The traps for the IP interfaces are also generated in ascending order according to the following list:

**Table 13.102** Traps for IP Interfaces

Trap Number	Interface
0	Ethernet 1
1	Ethernet 2
2	Loopback
3	xppp= (if used)
4	pppoe= (if used)

Bear in mind that the keyword **ALARM** must be entered in the appropriate BRI port's **Subscriber** line in the `pabx.cfg`. The MIBs (Management Information Bases) are included on the product CD in the folder **MIB**. The module name `snmpd.tz0` must have the ending `tz0`!

The following settings are possible in the section `[snmpd]`:

**Table 13.103** Settings in the Section `[snmpd]`

Parameter	Definition
<code>Port=&lt;port&gt;</code>	Defines the target port for the trap server (default 161).
<code>TrapServer=&lt;ip addr&gt;</code>	Enter the SNMP trap server's IP address. Example for listing more than one: <code>TrapServer=192.168.0.10 192.168.0.12</code>
<code>Community=&lt;password&gt;</code>	Enter a password for a community (group). The default password is <code>public</code> .

## 13.5 DNS FORWARDER

With this module, the system can function as a DNS server for the clients in the local network. The system in the local network sent the DNS query to the VoIPBOX BRI, which forwards the queries to a known DNS server address if no valid entry for the query is known.

The advantage is that the clients always enter the VoIPBOX BRI's address as DNS server address, so that no public DNS server address is required. The VoIPBOX BRI functions in this scenario as a router.

## IPUPDATE - DYNDNS CLIENT

Of course, the DNS server's address can also be transmitted to the clients using the integrated DHCP server. If the VoIPBOX BRI is used as a DSL router or if it sets up a dial-up connection, no entry is required in the `pabx.cfg` for the parameter `NameServer`. The DNS server's address that is negotiated through this connection will be used.

## 13.6 IPUPDATE - DYNDNS CLIENT

This function allows you to assign a defined hostname to an IP address that changes dynamically. That means that you can always reach a device or service through the public IP network, even if, for example, it is a common DSL connection with dynamic IP address allocation. Several providers support this service.

Make the following entries in the system's `ip.cfg`, in the `[DynDNS]` section:

**Table 13.104** pabx.cfg: DynDNS

DynDNS Parameters	
<code>service=&lt;type&gt;</code>	Specifies which provider is used. The following providers are supported:
<code>dhs</code>	<code>http://www.dhs.org</code>
<code>dyndns</code>	<code>http://www.dyndns.org</code>
<code>dyndns-static</code>	
<code>dyns</code>	<code>http://www.dyns.cx</code>
<code>ezip</code>	<code>http://www.ez-ip.net</code>
<code>easydns</code>	<code>http://www.easydns.com</code>
<code>easydns-partner</code>	
<code>gnudip</code>	<code>http://www.gnudip.cheapnet.net</code>
<code>heipv6tb</code>	
<code>hn</code>	<code>http://www.hn.org</code>
<code>pgpow</code>	<code>http://www.justlinux.com</code>
<code>ods</code>	<code>http://ods.org</code>
<code>tzo</code>	<code>http://www.tzo.com</code>
<code>zoneedit</code>	<code>http://zoneedit.com</code>
<code>user=&lt;username:password&gt;</code>	Defines the username and password for the DNS service provider.
<code>host=&lt;domain_name_of_dns_service&gt;</code>	Enter the domain name that is used.
<code>interface=&lt;If&gt;</code>	Defines the interface to be used. Possible entries are <code>emac0</code> , <code>emac1</code> , <code>pppoe0</code> . The dynamic IP address for this interface is transmitted to the service provider.

## IPUPDATE - DYNDNS CLIENT

Table 13.104 pabx.cfg: DynDNS (continued)

DynDNS Parameters
<p><code>max-interval=&lt;sec&gt;</code></p> <p>Defines the value in seconds in which actualization of the name in the DNS database must occur. 2073600 seconds (24 days) is the default value. The shortest interval allowed is 60 seconds. Bear in mind that this setting may cause the provider to block the domain name, since multiple registrations in short intervals are often not allowed. You must clear this with your provider.</p>

**Example:** In the following example, the DynDNS service is used and the domain name is `host.domain.de`; the username is `user` and the password is `pwd`. The VoIPBOX BRI works as DSL router and the dynamically allocated IP address of the PPPoE interface is used:

```
[DynDNS]
service=dyndns
user=user:pwd
host=host.domain.de
interface=pppoe0
max-interval=2073600
```

Included in the possible uses for this feature is remote access to the VoIPBOX BRI when the IP connection does not have a fixed IP address. In this case, you can access the system, for example with the TELES.GATE Manager, if the host name is used in the Remote Number dialog. Example entry in the Remote Number dialog:  
**IP:host.domain.de**



TELES AG  
Communication Systems Division  
Ernst-Reuter-Platz 8  
10587 Berlin, Germany  
Phone: +49 30 399 28-00  
Fax: +49 30 399 28-01  
E-mail: sales@teles.com

<http://www.teles.com/tcs/>