



HP Advanced Wireless Docking Station

User Guide

© Copyright 2014, 2015 Hewlett-Packard
Development Company, L.P.

Intel is a trademark of Intel Corporation in the
U.S. and other countries. Windows and
Windows Vista are trademarks of the Microsoft
Group of companies.

The information contained herein is subject to
change without notice. The only warranties for
HP products and services are set forth in the
express warranty statements accompanying
such products and services. Nothing herein
should be construed as constituting an
additional warranty. HP shall not be liable for
technical or editorial errors or omissions
contained herein.

Second Edition: June 2015

First Edition: October 2014

Document Part Number: 796829-002

Table of contents


1 Getting started	1
Identifying components	1
Top and front components	1
Rear components	2
Left components	3
Right components	4
Labels	5
Setting up the wireless dock	6
Step 1: Connecting to AC power	6
Step 2: Connecting to an external display device	7
Step 3: Pairing with the wireless dock	8
Configuring the external display device	9
2 Using the wireless dock	11
Wireless dock guidelines	11
Connecting to a network	11
Connecting USB devices	11
Connecting to a DisplayPort device	11
Connecting to a VGA display device	11
Connecting audio	12
Connecting analog audio devices	12
Connecting a microphone	12
Connecting an optional security cable	13
3 Dock Management	14
Information	14
Permissions	14
Signal Preferences	14
Security	15
4 Connection procedures	16
Individual: Allow automatic connections	16
Active device	16
Device in standby mode	16
Shared: Require Manual Connections	16
Public: Require pairing for all connections	17

Mandatory updates	17
5 Troubleshooting	18
Solving common problems	18
General use and connection problems	18
Audio problems	18
Video problems	19
Contacting support	19
Index	21


1 Getting started

Identifying components

This chapter identifies the visible hardware features of the HP Advanced Wireless Docking Station and provides setup instructions for the wireless dock.

 **NOTE:** Some features of the HP Advanced Wireless Docking Station may not be available on your computer.






Top and front components



	Components	Description
(1)	Antennas (2)	Send and receive wireless signals to communicate with WiGig networks. NOTE: Each antenna has a range of 120 degrees. Your HP notebook or tablet antenna must be in range of at least one of the dock antennas to pair.
(2)	Pairing button/Wireless dock light	Press button to complete pairing if necessary. Wireless dock light status: <ul style="list-style-type: none">• Solid amber—Wireless dock is on and not paired to a device.• Pulsing white—Wireless dock is pairing to a device.• Solid white—Wireless dock is paired.• Flashing amber—There is a hardware error.• Flashing amber and white—There is a firmware upgrade.



Rear components



	Component	Description
	Power button	Slide to turn the wireless dock on and off.
RESET	Reset button	Press to restore default settings.
	USB 3.0 ports (3)	Connect optional USB devices, such as a keyboard, mouse, external drive, printer, scanner or USB hub.
	Dual-Mode DisplayPorts (2)	Connect optional digital display devices, such as a high-performance monitor or projector.
	RJ-45 (network) jack	Connects a network cable.
	External monitor port	Connects an external VGA monitor or projector.




Left components



	Component	Description
	Power connector	Connects an AC adapter.
	Security cable slot	Attaches an optional security cable to the wireless dock. NOTE: The security cable is designed to act as a deterrent, but it may not prevent the wireless dock from being mishandled or stolen.

Right components



	Component	Description
	USB 3.0 charging (powered) port	<p>Connects an optional USB device, such as a keyboard, mouse, external drive, printer, scanner or USB hub. Standard USB ports will not charge all USB devices or will charge using a low current. Some USB devices require power and require you to use a powered port.</p> <p>NOTE: USB charging ports can also charge select models of cell phones and MP3 players, even when the computer is off.</p>
	Audio-out (headphone) jack	<p>Connects optional powered stereo speakers, headphones, earbuds, a headset, or a television audio cable.</p> <p>WARNING! To reduce the risk of personal injury, adjust the volume before putting on headphones, earbuds, or a headset. For additional safety information, see the <i>Regulatory, Safety, and Environmental Notices</i>. To access this guide, from the Start screen on your HP notebook or tablet, type <code>support</code>, and then select the HP Support Assistant app.</p> <p>NOTE: When an HP notebook or tablet is connected to the wireless dock, audio functions are controlled by the wireless dock. You can change these settings using the Windows settings.</p>
	Audio-in (microphone) jack	<p>Connects an optional computer headset microphone, stereo array microphone, or monaural microphone.</p> <p>NOTE: When an HP notebook or tablet is connected to the wireless dock, audio functions are controlled by the wireless dock. You can change these settings using the Windows settings.</p>

Labels

There will be a label resembling the following example on the bottom of your wireless dock. This label provides information you might need when you troubleshoot system problems or pair to the wireless dock for the first time.



Component	
(1)	MAC address
(2)	Serial number
(3)	Product number
(4)	Warranty period

Setting up the wireless dock

Step 1: Connecting to AC power

⚠ WARNING! To reduce the risk of electric shock or damage to your equipment:


Plug the power cord into a grounded (earthed) outlet that is easily accessible at all times.

Disconnect power from the equipment by unplugging the power cord from the electrical outlet.

Do not disable the power cord grounding plug. The grounding plug is an important safety feature.

To ensure the correct performance of all wireless dock features, connect the wireless dock to an AC power source using the wireless dock power cord.

1. Connect the AC adapter to the power-in connector on the wireless dock **(1)**.
2. Connect one end of the power cord to the AC adapter **(2)**, and connect the other end of the power cord to an electrical outlet **(3)**.
3. Turn the dock on **(4)**.




The wireless dock light is solid amber when the dock is on but no notebooks or tablets are connected to it.

Step 2: Connecting to an external display device


To physically connect an external display device to the wireless dock:

- ▲ Connect the external display device cable to the correct port on the wireless dock. The wireless dock supports Dual-Mode DisplayPort and VGA connections.



When the dock and the external display device are connected, the device screen displays wireless pairing instructions.


Step 3: Pairing with the wireless dock

 **NOTE:** The following procedure is used to pair your HP notebook or tablet with the dock for the first time. See [Connection procedures on page 16](#) for other connection procedures. See your device documentation to determine whether your device is WiGig compatible.


To pair your HP notebook or tablet with the wireless dock:

1. Position your WiGig-compatible notebook or tablet within 1.2 m (4 ft) of the wireless dock, and with no obstruction in the line of sight. The wireless dock antennas have a range of 120 degrees.


 **IMPORTANT:** Be sure that you have enabled WiGig on your device. See your device documentation for instructions.



2. On a device running Windows[®] 7 or Windows 8, open **Intel[®] Dock Manager**.
On a device running Windows 10, select **Action Center** and then select **Connect**.

 **NOTE:** Intel Dock Manager and Action Center can be found in the notification area of the taskbar or on the Start menu.

3. Select your dock name from the list.

 **NOTE:** By default, the dock name is the last four digits of the dock MAC address. The MAC address can be found on a label on the bottom of the dock.

If no dock names appear on the list, press the button on top of the wireless dock. If that does not resolve the issue, confirm that no other HP notebooks or tablets are already connected to the wireless dock. A wireless dock can be connected to only one device at a time; therefore, wireless docks that are currently connected do not appear on the list.


4. Press the button on top of the dock.



The wireless dock light pulses white while the dock is pairing. It turns solid white when the pairing is successful.

After the pairing is complete, you can select **Dock Management** in Intel Dock Manager to configure options for future connections. See [Dock Management on page 14](#). Select **Disconnect** to disconnect manually. To disconnect automatically, move your device out of the wireless dock range.

Configuring the external display device

 **NOTE:** By default, the external display device is in duplicate mode after the initial pairing.

To configure the display of an external monitor connected to the wireless dock, first open the configuration settings.

- ▲ On Windows 8.1, swipe from the upper-right corner of the screen, and then select **Devices**.

On Windows 8, press the [Windows](#) key.

On Windows 7, right-click on the desktop.

On Windows Vista®, right-click on the desktop, and then select **Personalize**.

You can then configure the display resolution, set the external monitor as an extension of the primary monitor, or set the external monitor as a copy of the primary monitor.

To configure the display resolution:

- ▲ On Windows 8.1, select **Second screen**.

On Windows 8, press [p](#).

On Windows 7, select **Screen Resolution**.

On Windows Vista®, select **Display Settings**.

To set the external monitor as the primary monitor:

- ▲ On Windows 8 or 8.1, select **Second screen only**.
- On Windows 7, select **Make this my main display**.
- On Windows Vista, select **This is my main monitor**.

To set the external monitor as an extension of the primary monitor:

- ▲ On Windows 8 or 8.1, select **Extend**.
- On Windows 7, select **Extend these displays**.
- On Windows Vista, select **Extend the desktop onto this monitor**.

To set the external monitor as a copy of the primary monitor:


- ▲ On Windows 8 or 8.1, select **Duplicate**.
- On Windows 7, select **Duplicate these displays**.
- On Windows Vista, select **This is my main monitor**.

In addition to the display properties described above, Windows operating systems starting with Windows 7 allow you to configure some additional display settings. Press the [Windows](#) key + **p** on the keyboard to configure settings that allow display on the computer only, duplicate display, or extended display.

2 Using the wireless dock

Wireless dock guidelines

- **Operating systems**—For optimal performance, pair the wireless dock with an HP notebook or tablet running Windows 8.1, Windows 8, Windows 7, or Windows Vista operating systems. See your device documentation to determine whether your device supports Intel WiGig.

 **NOTE:** HP Advanced Wireless Docking is compatible with the HP Elite x2 1011 G1 with an optional installed Intel Tri-Band Wireless-AC with WiGig Combo card.

- **Power**—To use the wireless dock features, AC power must be connected to the wireless dock.
- **External devices**—When the wireless dock is paired with a device, external devices can be connected to the ports on the wireless dock or to the ports on the HP notebook or tablet.


Connecting to a network

You can connect your HP notebook or tablet to a network through the wireless dock. This requires an Ethernet cable (purchased separately).

1. Pair the device with the wireless dock.
2. Connect one end of the Ethernet cable to the RJ-45 (network) jack on the wireless dock and connect the other end to an RJ-45 wall jack or router.

Connecting USB devices

The wireless dock has four USB 3.0 ports: three USB ports on the rear panel and one USB port on the right panel. Use the USB ports to connect optional external USB devices, such as a keyboard and mouse.

 **NOTE:** Be sure that the external device is compliant with the wireless dock power specifications. Using a noncompliant device might disable the port to which the device is attached. To reset the port, see [Troubleshooting on page 18](#).

Connecting to a DisplayPort device


The wireless dock can also be connected to an external DisplayPort device, such as a monitor or a projector, through either of the two DisplayPorts on the rear panel. The wireless dock supports video connections to a Dual-Mode DisplayPort and the VGA port simultaneously.


Connecting to a VGA display device


The wireless dock can also be connected to an external VGA display device, such as a monitor or a projector, through the VGA port on the rear panel.

To connect an external VGA display device:

1. Connect the VGA device cable to the VGA port on the rear panel of the wireless dock.
2. If you are using Windows 7, press **fn+f4** or **f4**, depending on your computer, one or more times to switch the screen image to the external display device.

 **NOTE:** If you are not using Windows 7, the computer will automatically detect the external device. See Help and Support for more information.


 **NOTE:** To use extended display, see the operating system display settings of the computer.


 **NOTE:** If your computer lid switch is set to initiate Sleep when the display is closed, do not close the computer display while the computer is connected to an external display device. You can modify lid switch settings through the Power Options page.

 **NOTE:** The wireless dock does not support viewing Blu-ray or other protected content on a display device connected to the VGA port on the wireless dock.

Connecting audio

You can connect headphones or speakers directly into the headphone jack on the wireless dock. You can also connect analog audio devices.

 **NOTE:** Do not connect more than one audio device to the wireless dock.

 **NOTE:** When an HP notebook or tablet is connected to the wireless dock, audio functions are controlled by the wireless dock. You can change these settings using the Windows settings.


Connecting analog audio devices

To connect analog audio:

1. Using an audio Y-cable (purchased separately), connect the single-connector end of the cable to the headphone jack on the wireless dock.
2. Connect the red and white connectors on the other end of the cable to the matching audio-in jacks on your television or stereo equipment. See your television or stereo equipment user guide for the jack names and locations.

Connecting a microphone

You can connect a microphone directly to the microphone jack on the wireless dock.

 **NOTE:** When an HP notebook or tablet is connected to the wireless dock, audio functions are controlled by the wireless dock. You can change these settings using the Windows settings.

Connecting an optional security cable



NOTE: The security cable is designed to act as a deterrent, but it might not prevent the wireless dock from being mishandled or stolen.

To install a security cable:

1. Loop the security cable around a secured object.
2. Insert the key into the cable lock.
3. Insert the cable lock into the security cable slot on the wireless dock, and then turn the key.
4. Remove the key.

3 Dock Management

To configure the dock name, permissions, signal preferences, and security:

1. Pair an HP notebook or tablet to the wireless dock.
2. In Intel Dock Manager, select **Dock Management**.

Information


The Information section lists the dock name and software version number.

To change the dock name:

1. Enter the desired name in the **Name** box.
2. Select **Save Changes**.

To update the software manually:

1. Select the version number. It links to a manual update.


 **TIP:** The version number can also be used for troubleshooting.

2. Select **Save Changes**.

Permissions

The Permissions section provides the following configuration options:

- **Individual: Allow automatic connections**—Enables the wireless dock to save previously paired HP notebooks or tablets and automatically connect with them when one of them is in range.

 **NOTE:** The wireless dock can connect to only one device at a time. If two devices enter the wireless dock range at the same time, the dock connects to the first device that attempts to connect.

- **Shared: Require Manual Connections**—Enables the wireless dock to save previously paired HP notebooks or tablets, but requires you to select the dock in Intel Dock Manager to complete a reconnection.
- **Public: Require pairing for all connections**—Disables the wireless dock from remembering previously paired HP notebooks or tablets.

To change the **Permissions** setting:

1. Select the desired setting.
2. Select **Save Changes**.

Signal Preferences

Select your **Preferred Radio Channel** and optimize the signal strength for the number of wireless docks in your area.



NOTE: Selections might vary depending on your deployment. HP recommends using the default **Preferred Radio Channel**.

Security

The Security section enables you to require the entry of a password before a device can manage the connection with the wireless dock.

To set a password:

1. Next to **Require a password to manage this dock**, select **YES**.
2. Enter a password in the **Password** box.
3. Enter the same password in the **Verify** box.
4. Select **Save Changes**.


4 Connection procedures

Individual: Allow automatic connections


Active device

To connect a previously paired, active HP notebook or tablet to a wireless dock that allows automatic connections:

- ▲ Move the previously paired device into the wireless dock range, with the device antenna facing at least one of the wireless dock antennas.

 **NOTE:** If two devices are configured to automatically connect to the same wireless dock and move into range at the same time, the wireless dock connects to the first device that attempts to connect.

When the device connects successfully, the Intel Dock Manager icon displays a connection notification, the wireless dock light is solid white, and the external display device exits standby mode.


 **NOTE:** If you manually disconnect your device, it does not attempt to connect to the wireless dock again until you remove it from the wireless dock range and then bring it back into range. If another previously paired device is configured to connect to the wireless dock and is in range, it connects to the dock when you manually disconnect the first device.

Device in standby mode

Standby mode is enabled by default in Windows 8.1. Using standby mode when connected to the wireless dock saves power.


To connect a previously paired HP notebook or tablet in standby mode to a wireless dock that allows automatic connections:

1. Move the previously paired device into the wireless dock range, with the device antenna facing at least one of the wireless dock antennas.

 **NOTE:** If two devices are configured to automatically connect to the same wireless dock and move into range at the same time, the wireless dock connects to the first device that attempts to connect.

2. Press the button on top of the wireless dock to wake your device.


When the device connects successfully, the Intel Dock Manager icon displays a connection notification, the wireless dock light is solid white, and the external display device exits standby mode.

 **NOTE:** If you manually disconnect your device, it does not attempt to connect to the wireless dock again until you remove it from the wireless dock range and then bring it back into range. If another previously paired device is configured to connect to the wireless dock and is in range, it connects to the dock when you manually disconnect the first device.

Shared: Require Manual Connections

To connect a previously paired HP notebook or tablet to a wireless dock that requires manual confirmation:

1. Move the previously paired device into the wireless dock range, with the device antenna facing at least one of the wireless dock antennas.
2. Open **Intel Dock Manager**, and select your dock number from the list.

 **NOTE:** Previously paired dock numbers appear on the list in a different color.


If no dock names appear on the list, press the button on top of the wireless dock. If that does not resolve the issue, confirm that no other HP notebooks or tablets are already connected to the wireless dock. A wireless dock can be connected to only one device at a time; therefore, wireless docks that are currently connected do not appear on the list.

– or –

Right-click the **Intel Dock Manager** icon, and then select **Connect to Dock XXXX** or **View available docks**.

3. If this is the first time you are reconnecting after changing the Permissions setting, press the button on top of the wireless dock.


When the device connects successfully, the Intel Dock Manager icon displays a connection notification, the wireless dock light is solid white, and the external display device exits standby mode.

 **NOTE:** If you manually disconnect your device, it does not attempt to connect to the wireless dock again until you remove it from the wireless dock range and then bring it back into range. If another previously paired device is configured to connect to the wireless dock and is in range, it connects to the dock when you manually disconnect the first device.

Public: Require pairing for all connections

To connect a previously paired HP notebook or tablet to a wireless dock that requires pairing for all connections, use the procedure in [Step 3: Pairing with the wireless dock on page 8](#).


When the device connects successfully, the Intel Dock Manager icon displays a connection notification, the wireless dock light is solid white, and the external display device exits standby mode.

 **NOTE:** If you manually disconnect your device, it does not attempt to connect to the wireless dock again until you remove it from the wireless dock range and then bring it back into range. If another previously paired device is configured to connect to the wireless dock and is in range, it connects to the dock when you manually disconnect the first device.

Mandatory updates

If there is a mandatory update to the wireless dock, Intel Dock Manager opens and displays a message after your HP notebook or tablet successfully pairs with the wireless dock.

- ▲ To update the wireless dock, select **Yes**.

 **NOTE:** You cannot connect to the wireless dock until you update it.

The device connects to the wireless dock automatically after the update is complete.

5 Troubleshooting

Solving common problems

The following tables list possible problems and the recommended solutions.

General use and connection problems

Problem	Possible cause	Solution
The ports or jacks on the wireless dock are not working.	The wireless dock is not connected to AC power.	Connect the power cord to the wireless dock and to an AC outlet.
	The wireless dock is not paired to your HP notebook or tablet correctly.	Disconnect from the wireless dock, and then pair your device again.
A USB port on the wireless dock is not functioning.	The USB device attached to the port may not be compliant with the wireless dock power specifications and is using too much power.	Reset the port: <ol style="list-style-type: none">1. Disconnect the device that disabled the port.2. Disconnect the power cord from the wireless dock, and then reconnect it. <p>– or –</p> Disconnect from the wireless dock, and then pair your HP notebook or tablet again.

Audio problems

Problem	Possible cause	Solution
Headphones or other audio device connected to your HP notebook or tablet do not produce sound.	When your device is connected to the wireless dock, audio functions are controlled from the wireless dock.	Use the audio device connected to the wireless dock instead, or change the audio settings using the Windows settings.
	More than one audio device is connected to the wireless dock.	Be sure that only one audio device is connected to the wireless dock.
A microphone connected to your HP notebook or tablet does not work.	When your device is connected to the wireless dock, audio functions are controlled from the wireless dock.	Either use the microphone connected to the wireless dock instead, or change the audio settings using the Windows settings.
A connected home entertainment system does not have audio.	Audio is not connected properly.	Be sure that the wireless dock is properly connected to the home entertainment system.

Video problems

Problem	Possible cause	Solution
The screen resolution of an external monitor connected to the DisplayPort cannot be changed.	The wireless dock is connected with a DP-to-DVI adapter to a dual-link DVI monitor.	Use a single-link DVI monitor, or a DP-to-DL DVI ACTIVE adapter (powered over USB). – or – Use a DisplayPort monitor.
Fonts and other characters on the external monitor appear large.	The external monitor screen resolution is higher than the maximum limits of 2560 x 1600 at 60 Hz when using one display or 1920 x 1200 when using two displays.	Set the screen resolution equal to or lower than the maximum limits.
The external monitor cannot be set as the primary monitor when using some Intel graphics applications.	Older Intel graphics applications do not support setting the external monitor as the primary monitor.	Download the latest Intel drivers from http://www.hp.com/support .
A video device connected to the VGA port displays a black screen when playing Blu-ray or other protected content.	The wireless dock does not support viewing Blu-ray or other protected content on an external display device connected to the VGA port on the wireless dock.	Connect the external display device directly to your HP notebook or tablet. You might need to use a VGA-to-HDMI adapter.
The external display device stops displaying your HP notebook or tablet screen.	The HP notebook or tablet has been removed from the wireless device range or the antennas are blocked.	Ensure that your device is in range and no objects have been placed between the device and the wireless dock.

Contacting support

If you cannot solve a problem using the troubleshooting tips in this chapter, you might need to contact support.

For the fastest possible resolution of your problem, have the following information available when you contact support:



NOTE: The serial number and other information for the wireless dock can be found on the service label located on the bottom of the wireless dock.

- Model name and number for your HP notebook or tablet and for the wireless dock
- Serial numbers for the your HP notebook or tablet and for the wireless dock
- Dates your HP notebook or tablet and the wireless dock were purchased
- Conditions under which the problem occurred
- Error messages that have been displayed
- Hardware and software you are using
- The manufacturer and model of components connected to your HP notebook or tablet and the wireless dock

To contact support using your HP computer, select **Start** and then select **Help and Support**. Click **Contact support** to start a chat session with a support specialist.

For U.S. support, go to <http://www.hp.com/go/contactHP>. For worldwide support, go to http://welcome.hp.com/country/us/en/wwcontact_us.html.

Choose from the following types of support:

- Chat online with an HP technician.



NOTE: When chat is not available in a particular language, it is available in English.

- Find HP support worldwide telephone numbers.
- Locate an HP service center.

Index

A

analog audio 12
audio connection, analog 12
audio, connecting 12
audio-in (microphone) jack 12
audio-out (headphone) jack 12

B

buttons
 pairing 1
 power 2
 reset 2

C

connector, power 3

D

DisplayPort device, connecting 11
DisplayPort, identifying 2

E

external devices 11
external display device, connecting 7
external monitor port 2

H

headphone (audio-out) jack 4

J

jacks
 audio-in (microphone) 4, 12
 audio-out (headphone) 4, 12
 RJ-45 (network) 2, 11

L

labels 5
lock, security cable 13

M

microphone (audio-in) jack,
 identifying 4

N

network (RJ-45) jack 2, 11

O

operating systems supported 11

P

pairing 8
ports
 DisplayPort 2
 external monitor 2
 USB 11
 USB 3.0 charging (powered) 4
power
 guidelines 11
 wireless dock, connecting 6
power button, identifying 2
power connector 6
power connector, identifying 3

R

RJ-45 (network) jack 2, 11

S

security cable slot 3, 13
security cable, connecting 13
slots, security cable 3
support, contacting 19

T

Troubleshooting 18

U

USB 3.0 charging (powered),
 identifying 4
USB 3.0 port 2
USB devices, connecting 11
USB ports, identifying 2

V

VGA display device, connecting 11