

Intel[®] Server Chassis SC5600 Service Guide

A Guide for Technically Qualified Assemblers of Intel[®] identified Subassemblies/Products

Order Number: E39533-003

Revision 1.1

Disclaimer

Disclaimer

Information in this document is provided in connection with Intel® products. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document. Except as provided in Intel's Terms and Conditions of Sale for such products, Intel assumes no liability whatsoever, and Intel disclaims any express or implied warranty, relating to sale and/or use of Intel products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right. Intel products are not designed, intended or authorized for use in any medical, life saving, or life sustaining applications or for any other application in which the failure of the Intel product could create a situation where personal injury or death may occur. Intel may make changes to specifications and product descriptions at any time, without notice.

Intel server boards contain a number of high-density VLSI and power delivery components that need adequate airflow for cooling. Intel's own chassis are designed and tested to meet the intended thermal requirements of these components when the fully integrated system is used together. It is the responsibility of the system integrator that chooses not to use Intel developed server building blocks to consult vendor datasheets and operating parameters to determine the amount of airflow required for their specific application and environmental conditions. Intel Corporation can not be held responsible if components fail or the server board does not operate correctly when used outside any of their published operating or non-operating limits.

Intel, Intel Pentium, and Intel Xeon are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

* Other names and brands may be claimed as the property of others.

Copyright © 2010, Intel Corporation. All Rights Reserved

Safety Information

Important Safety Instructions

Read all caution and safety statements in this document before performing any of the instructions. See also Intel Server Boards and Server Chassis Safety Information on the Intel® Server Deployment Toolkit 3.0 CD and/or at:

<http://support.intel.com/support/motherboards/server/sb/cs-010770.htm>

Wichtige Sicherheitshinweise

Lesen Sie zunächst sämtliche Warn- und Sicherheitshinweise in diesem Dokument, bevor Sie eine der Anweisungen ausführen. Beachten Sie hierzu auch die Sicherheitshinweise zu Intel-Serverplatinen und Servergehäusen auf der Intel® Server Deployment Toolkit 3.0 CD oder unter:

<http://support.intel.com/support/motherboards/server/sb/cs-010770.htm>

Consignes de sécurité

Lisez attention toutes les consignes de sécurité et les mises en garde indiquées dans ce document avant de suivre toute instruction. Consultez Intel Server Boards and Server Chassis Safety Information sur le Intel® Server Deployment Toolkit 3.0 CD ou bien rendez-vous sur le site:

<http://support.intel.com/support/motherboards/server/sb/cs-010770.htm>

Instrucciones de seguridad importantes

Lea todas las declaraciones de seguridad y precaución de este documento antes de realizar cualquiera de las instrucciones. Vea Intel Server Boards and Server Chassis Safety Information en el Intel® Server Deployment Toolkit 3.0 CD y/o en:

<http://support.intel.com/support/motherboards/server/sb/cs-010770.htm>

重要安全指导

在执行任何指令之前，请阅读本文件中的所有注意事项及安全声明。并参阅 <http://support.intel.com/support/motherboards/server/sb/cs-010770.htm> 上的 Intel® Server boards and Server Chassis Safety Information（《Intel 服务器主板与服务器机箱安全信息》）

Warnings

Heed safety instructions: Before working with your server product, whether you are using this guide or any other resource as a reference, pay close attention to the safety instructions. You must adhere to the assembly instructions in this guide to ensure and maintain compliance with existing product certifications and approvals. Use only the described, regulated components specified in this guide. Use of other products/components will void the UL listing and other regulatory approvals of the product and will most likely result in noncompliance with product regulations in the region(s) in which the product is sold.

System power on/off: The power button DOES NOT turn off the system AC power. To remove power from the system, you must unplug the AC power cord from the wall outlet. Make sure the AC power cord is unplugged before you open the chassis, add, or remove any components.

Hazardous conditions, devices and cables: Hazardous electrical conditions may be present on power, telephone, and communication cables. Turn off the server and disconnect the power cord, telecommunications systems, networks, and modems attached to the server before opening it. Otherwise, personal injury or equipment damage can result.

Electrostatic discharge (ESD) and ESD protection: ESD can damage disk drives, boards, and other parts. We recommend that you perform all procedures in this chapter only at an ESD workstation. If one is not available, provide some ESD protection by wearing an antistatic wrist strap attached to chassis ground—any unpainted metal surface—on your server when handling parts.

ESD and handling boards: Always handle boards carefully. They can be extremely sensitive to ESD. Hold boards only by their edges. After removing a board from its protective wrapper or from the server, place the board component side up on a grounded, static free surface. Use a conductive foam pad if available but not the board wrapper. Do not slide board over any surface.

Installing or removing jumpers: A jumper is a small plastic encased conductor that slips over two jumper pins. Some jumpers have a small tab on top that you can grip with your fingertips or with a pair of fine needle nosed pliers. If your jumpers do not have such a tab, take care when using needle nosed pliers to remove or install a jumper; grip the narrow sides of the jumper with the pliers, never the wide sides. Gripping the wide sides can damage the contacts inside the jumper, causing intermittent problems with the function controlled by that jumper. Take care to grip with, but not squeeze, the pliers or other tool you use to remove a jumper, or you may bend or break the pins on the board.

Preface

About this Manual

Thank you for purchasing and using the Intel® Server Chassis SC5600.

This manual is written for system technicians responsible for troubleshooting, upgrading, and repairing this server chassis. This document provides a brief overview of the features of the board/chassis, list of accessories or other components you may need, troubleshooting information, and instructions on how to add and replace components on the Intel® Server Chassis SC5600. For the latest version of this manual, refer to: <http://support.intel.com/support/motherboards/server/chassis/SC5600/>

Manual Organization

Chapter 1 provides a brief overview of the Intel® Server Chassis SC5600. In this chapter, you will find a list of the server chassis features, photos of the product, and product diagrams to help you identify components and their locations.

Chapter 2 provides instructions on adding and replacing components. Use this chapter for step-by-step instructions and diagrams for installing or replacing components such as the memory, processor, front panel board, and battery, among other components.

Chapter 3 provides technical reference information on cable routing, power supply specifications, and system environment requirements.

At the back of this document, you will find appendices on safety, regulatory, “Getting Help”, and warranty information.

Product Accessories, Order Options, and Accessories

The Intel® Server Chassis SC5600 family provides three SKUs: SC5600Base, SC5600BRP, and SC5600LX. When a feature varies from each SKU, the difference is noted in this document. Unless specified, features apply to all the three chassis SKUs.

The Intel® Server Chassis SC5600Base is compatible with the following Intel® Server Boards and workstation Boards:

- Intel® Server Board S5520HC
- Intel® Server Board S5520HCT
- Intel® Server Board S5500HCV
- Intel® Workstation Board S5520SC

The Intel® Server Chassis SC5600BRP and SC5600LX are compatible with the following Intel® Server Boards:

- Intel® Server Board S5520HC
- Intel® Server Board S5520HCT
- Intel® Server Board S5500HCV

NOTE

When installing either the Intel® Server Board S5520HC or S5500HCV in the Intel® Server Chassis SC5600LX, a passive processor heat sink (FXXRGTHSINK) is required.

The Intel® Server Chassis SC5600 family is compatible with the following Intel® hot-swap hard disk drive backplane assemblies:

- AXX6DRV3GR
- AXX4DRV3GR
- AXX6DRV3GEXP
- AXX4DRV3GEXP

Your Intel® Server Chassis SC5600 ships with the following items:

- Single fixed 670-W power supply installed in the chassis (SC5600Base), or (1+1) Hot-swap redundant 750-W power supply installed in the chassis (SC5600BRP and SC5600LX)
- Three fixed fans installed in the chassis (Intel® Server Chassis SC5600Base, Intel® Server Chassis SC5600BRP), or four hot-swap fans with fan cables installed in the chassis (Intel® Server Chassis SC5600LX)
- Front control panel board and front control panel cable installed in the chassis
- Front USB Panel and Front USB Panel cable installed in the chassis
- Air duct installed in the chassis
- Five rubber bumpers that support Intel® server/workstation board
- COM2 cable
- Twenty (20) 6-32 screws for securing server/workstation board
- Four M3 optical drive screws
- Four cable ties
- One cable clip
- Four server/workstation board standoff spares

In addition, you may need or want to purchase one or more of the following accessory items for your server:

- Processor
- Memory DIMMs
- Hard drive
- CD-ROM or DVD-ROM drive
- RAID controller
- Operating system

For information about compatible accessories, memory, processors, and third-party hardware and ordering information for Intel products, see:

<http://support.intel.com/support/motherboards/server/chassis/SC5600/compat.htm>

Additional Information and Software

If you need more information about this product or information about the accessories you can use with this server chassis, use the following resources. You can find these files at:

<http://support.intel.com/support/motherboards/server/chassis/SC5600/>

Unless otherwise indicated in the following table, once on this web page, type the document or software name in the search field at the left side of the screen and select the option to search "This Product".

For this information or software	Use this Document or Software
For in-depth technical information about this product	Intel® Server Chassis SC5600 Technical Product Specification See the section on the web page titled, "Technical Specifications".
If you just received this product and need to install it	Intel® Server Chassis SC5600 Quick Start User's Guide See the section on the web page titled, "Installation and Use".
Accessories or other Intel® server products	Spares and Configuration Guide See the section on the web page titled, "Installation and Use".
To quickly and efficiently select compatible components to design a complete system	Intel® Server Configurator tool A link to the Intel® Server Configurator tool is available under "Other Resources" at the right side of the web page screen.
Hardware (peripheral boards, adapter cards, and so on) and operating systems tested with this product	Intel® Server Configurator tool A link to the Intel® Server Configurator tool is available under "Other Resources" at the right side of the web page screen.
To make sure your system falls within the allowed power budget	Power Budget Analysis Tool See the section on the web page titled, "Installation and Use".
For software to manage your Intel® server	Intel Server Management Software See the section on the web page titled, "Installation and Use".
For firmware and drivers	Firmware and Drivers See the section on the web page titled, "Software and Drivers".

Preface

<This page intentionally left blank.>

Contents

Safety Information	iii
Preface	v
1 Server Chassis Features	1
Component Identification	5
Front Control Panel.....	7
Intel® Local Control Panel.....	8
Back Panel Features	9
Peripheral Devices.....	11
Standard and Optional Hot-swap Drive Bays.....	12
Intel® Remote Management Module 3	12
Rack-mount Systems.....	12
Tower Passive Processor Heat Sink (FXXRGTHSINK)	13
2 Hardware Installations and Upgrades	14
Before You Begin.....	14
Tools and Supplies Needed	14
System Reference	14
Removing and Installing the Chassis Cover	15
Removing the Chassis Cover	15
Installing the Chassis Cover	16
Removing and Installing the Front Bezel.....	16
Removing the Front Bezel Assembly (Pedestal Configuration Only)	16
Installing the Front Bezel (Pedestal Configuration Only)	17
Removing and Installing the Air Duct	18
Removing the Air Duct.....	18
Installing the Air Duct.....	19
Replacing a Fixed Fan (Intel® Server Chassis SC5600Base and SC5400BRP only).....	21
Removing and Installing Hot Swap Fans (Intel® Server Chassis SC5600LX only).....	22
Removing Hot Swap Fans	22
Installing Hot Swap Fans	23
Removing and Installing a DVD- or CD-ROM Drive	24
Removing a DVD- or CD-ROM Drive	24
Installing a DVD- or CD-ROM Drive	25
Removing and Installing Fixed Hard Drive(s).....	27
Removing Fixed Hard Drive(s)	27
Installing Fixed Hard Drive(s)	31
Routing Power Cables to Fixed Drives.....	37
Routing Data Cables to Fixed Drives	38
Removing and Installing Hot Swap Drive(s).....	39
Removing Hot Swap Drive(s)	39
Installing Hot Swap Drive(s)	41
Removing and Installing PCI Add-in Board(s).....	43
Removing PCI Add-in Board(s)	43
Installing PCI Add-in Board(s)	44
Replacing a Hot Swap Power Supply.....	48

Contents

Replacing a Fixed Power Supply.....	49
Replacing the Hot Swap Power Supply Power Distribution Board.....	50
Replacing the Control Panel.....	54
Installing and/or Removing a Server/Workstation Board.....	55
Connecting and Disconnecting Cables to or from Server Workstation Board.....	56
Connecting Cables to Server/Workstation Board.....	56
Removing Cables from Server/Workstation Board.....	56
3 Technical Reference	57
Power Supply Specification.....	57
670-W Single Power Supply Input Voltage.....	57
670-W Single Power Supply Output Voltages.....	57
750-W Hot Swap Power Supply Input Voltages.....	57
750-W Hot Swap Power Supply Input Voltages.....	57
System Environmental Specification.....	58
Current Usage.....	59
Calculation Power Usage.....	59
Appendix A: Regulatory and Compliance Information	61
Product Regulatory Compliance.....	61
Product Safety Compliance.....	61
Product EMC Compliance - Class A Compliance.....	62
Product Regulatory Compliance Markings.....	63
Electromagnetic Compatibility Notices.....	64
FCC Verification Statement (USA).....	64
Industry Canada (ICES-003).....	64
Europe (CE Declaration of Conformity).....	65
VCCI (Japan).....	65
BSMI (Taiwan).....	65
Korean Compliance (RRL).....	65
Regulated Specified Components.....	65
Restriction of Hazardous Substances (RoHS) Compliance.....	66
End of Life/Product Recycling.....	66
Appendix B: Safety Information.....	67
English Server Safety Information.....	67
Safety Warnings and Cautions.....	67
Intended Application Uses.....	68
Site Selection.....	68
Equipment Handling Practices.....	68
Power and Electrical Warnings.....	68
System Access Warnings.....	69
Rack Mount Warnings.....	69
Electrostatic Discharge (ESD).....	69
Other Hazards.....	70
Deutsch.....	71
Sicherheitshinweise für den Server.....	71
Sicherheitshinweise und Vorsichtsmaßnahmen.....	71
Zielbenutzer der Anwendung.....	72
Standortauswahl.....	72
Handhabung von Geräten.....	72

Warnungen zu Netzspannung und Elektrizität	72
Warnhinweise für den Systemzugang	73
Warnhinweise für Racks	73
Elektrostatische Entladungen (ESD)	73
Andere Gefahren	74
Français 74	
Sécurité: avertissements et mises en garde	75
Domaines d'utilisation prévus	76
Sélection d'un emplacement	76
Pratiques de manipulation de l'équipement	76
Alimentation et avertissements en matière d'électricité	76
Avertissements sur le cordon d'alimentation	77
Avertissements sur l'accès au système	77
Avertissements sur le montage en rack	77
Décharges électrostatiques (ESD)	78
Autres risques	78
Español	79
Información de seguridad del servidor	79
Advertencias y precauciones sobre seguridad	79
Aplicaciones y usos previstos	80
Selección de la ubicación	80
Manipulación del equipo	80
Advertencias de alimentación y eléctricas	80
Advertencias sobre el cable de alimentación	81
Advertencias el acceso al sistema	81
Advertencias sobre el montaje en bastidor	81
Descarga electrostática (ESD)	82
Sustitución de la batería	82
Enfriamiento y circulación de aire	82
Periféricos o dispositivos láser	82
Appendix C: Installation/Assembly Safety Instructions	88
English	88
Deutsch	89
Français	91
Español	93
Italiano	95
Appendix D: Getting Help	97
Appendix E: Intel® Server Issue Report Form	98
Appendix F: Warranty	103
Limited Warranty for Intel® Chassis Subassembly Products	103
Extent of Limited Warranty	103
Warranty Limitations and Exclusions	103
Limitations of Liability	104
How to Obtain Warranty Service	104

Figures

Figure 1. Intel® Server Chassis SC5600	1
Figure 2. Intel® Server Chassis SC5600Base Components Location	5
Figure 3. Intel® Server Chassis SC5600LX Components Location	6
Figure 4. Front Control Panel	7
Figure 5. Intel® Local Control Panel Features	9
Figure 6. Server Chassis Back	10
Figure 7. Optional Peripherals	11
Figure 8. Removing the Chassis Cover	15
Figure 9. Installing the Chassis Cover	16
Figure 10. Removing the Front Bezel	17
Figure 11. Installing the Front Bezel	18
Figure 12. Removing the Air Duct	19
Figure 13. Installing the Air Duct into Intel® Server Chassis SC5600Base and SC5600BRP	20
Figure 14. Installing the Air Duct into Intel® Server Chassis SC5600LX	21
Figure 15. Removing a Fixed Fan	22
Figure 16. Removing Hot Swap Fan	23
Figure 17. Installing Hot Swap Fan	24
Figure 18. Removing DVD or CD-ROM Drive	25
Figure 19. Re-inserting Empty EMI Shield/Slide Assembly	25
Figure 20. Removing EMI Shield/Slide Assembly from Upper Device Bay	26
Figure 21. Attaching Slides to a DVD or CD-ROM Drive	26
Figure 22. Removing Six-drive Fixed Drive Cage from Chassis	27
Figure 23. Unlocking and Opening Upper Door of Fixed Drive Cage	28
Figure 24. Opening Lower Door of Fixed Drive Cage	28
Figure 25. Removing Drive/Slide Assembly from Fixed Drive Cage	29
Figure 26. Inserting Empty Device Slides into Fixed Drive Cage	29
Figure 27. Closing Lower Door of Fixed Drive Cage	30
Figure 28. Closing Upper Door of Fixed Drive Cage	30
Figure 29. Tightening Thumb Screw	31
Figure 30. Removing Six-drive Fixed Drive Cage from Chassis	32
Figure 31. Unlocking and Opening the Upper Door of Fixed Drive Cage	32
Figure 32. Opening Lower Door of Fixed Drive Cage	33
Figure 33. Removing Slides from Fixed Drive Cage	33
Figure 34. Attaching Device Slides to Hard Drive	34
Figure 35. Inserting Drive/Slide Assembly into Drive Cage	34
Figure 36. Closing Lower Door of Fixed Drive Cage	35
Figure 37. Closing Upper Door of Fixed Drive Cage	35
Figure 38. Tightening Thumb Screw	36
Figure 39. Routing Power Cables to Fixed Drives	37
Figure 40. Routing SAS/SATA Data Cables	38
Figure 41. Removing Drive Carrier from Hot Swap Cage	39
Figure 42. Removing Hard Drive from Drive Carrier	39
Figure 43. Securing Plastic Air Baffle in Drive Carrier	40
Figure 44. Inserting Drive Carrier into Hot Swap Cage	40
Figure 45. Removing Drive Carrier from Hot Swap Cage	41
Figure 46. Removing Plastic Air Baffle from Drive Carrier	41
Figure 47. Securing Hard Drive to Drive Carrier	42
Figure 48. Inserting Drive Carrier into Hot Swap Cage	42
Figure 49. Preparing Chassis for Removal of PCI add-in board	43

Figure 50. Preparing Chassis for Addition of PCI add-in board.....	45
Figure 51. Installing PCI Add-in Board.....	46
Figure 52. Reinstalling PCI Add-in Card Retainer	47
Figure 53. Removing Hot Swap Power Supply from Chassis.....	48
Figure 54. Installing Hot Swap Power Supply into Chassis	48
Figure 55. Removing Fixed Power Supply	49
Figure 56. Removing Hot Swap Power Supply from Chassis.....	50
Figure 57. Removing Power Supply Filler Panel from Chassis	51
Figure 58. Removing Screws Securing Hot Swap Power Supply Cage.....	51
Figure 59. Removing Hot Swap Power Supply Cage from Chassis.....	51
Figure 60. Removing Power Distribution Board from Hot Swap Power Supply Cage	52
Figure 61. Attaching Power Distribution Board to Hot Swap Power Supply Cage.....	52
Figure 62. Inserting Hot Swap Power Supply Cage in Chassis.....	53
Figure 63. Securing Hot Swap Power Supply Cage to Chassis	53
Figure 64. Installing Filler Panel board on the Chassis	53
Figure 65. Inserting Hot Swap Power Supplies into Chassis.....	54

Tables

Table 1. Intel® Server Chassis SC5600Base Features.....	1
Table 2. Intel® Server Chassis SC5600BRP Features	2
Table 3. Intel® Server Chassis SC5600LX Features	3
Table 4. Front Control Panel LED Descriptions	8
Table 5. 670-W Power Supply Output Capability.....	57
Table 6. 750-W Hot Swap Power Supply Output Capability.....	58
Table 7. Environmental Specification	58
Table 8. Power Usage Worksheet.....	59
Table 9. Power Usage Worksheet 2.....	60
Table 10. Product Regulatory Compliance Markings.....	63

1 Server Chassis Features

This chapter briefly describes the main features of the Intel® Server Chassis SC5600. This chapter provides a list of the server chassis features and diagrams showing the location of important components and connections on the server chassis.




Figure 1. Intel® Server Chassis SC5600

Table 1 summarizes the features of the Intel® Server Chassis SC5600Base SKU.

Table 1. Intel® Server Chassis SC5600Base Features

Feature	Description
Dimensions	<ul style="list-style-type: none"> ▪ 17 inches high (Rack: 16.6 inches) ▪ 8.6 inches wide ▪ 28.4 inches deep (Rack: 27.4 inches) ▪ 34.6 kilograms
Hard Drives	<ul style="list-style-type: none"> ▪ Supports up to six drives, depending on peripheral choices ▪ One fixed drive bay for up to six fixed SAS or SATA drives ▪ Optional hot-swap drive bays: <ul style="list-style-type: none"> • Six-drive SAS/SATA (AXX6DRV3GR or AXX6DRV3GEXP)
Peripherals	<ul style="list-style-type: none"> ▪ Three multi-mount 5.25-inch peripheral bays
Control Panel (dependent on option)	<ul style="list-style-type: none"> ▪ Front Control Panel

Server Chassis Features

Feature	Description
selected)	<ul style="list-style-type: none"> ▪ Intel® Local Control Panel (Optional)
LEDs and displays (dependent on option selected)	<ul style="list-style-type: none"> ▪ With Front Control Panel <ul style="list-style-type: none"> • NIC1 Activity • NIC2 Activity • Power/Sleep • System Status • System Identification • Hard Drive Activity
Power Supply	<ul style="list-style-type: none"> ▪ One fixed 670-W PFC (Power Factor Correction) Power Supply with an integrated cooling fan
Fans	<ul style="list-style-type: none"> ▪ Three fixed, non-redundant system fans: <ul style="list-style-type: none"> • One 120-mm front fan • One 92-mm front fan • One 120-mm rear fan ▪ One air duct
Processor Cooling	<ul style="list-style-type: none"> ▪ Processor heat sink is not included ▪ Active processor heat sink(s) is required when used with compatible Intel server/workstation board. ▪ Supports up to 95-W processor
USB 2.0	<ul style="list-style-type: none"> ▪ Two front panel USB ports with Front Control Panel ▪ Four back panel USB ports (depending on server/workstation board)
Video	<ul style="list-style-type: none"> ▪ One rear panel video port

Table 2 summarizes the features of the Intel® Server Chassis SC5600BRP SKU.

Table 2. Intel® Server Chassis SC5600BRP Features

Feature	Description
Dimensions	<ul style="list-style-type: none"> ▪ 17 inches high (Rack: 16.6 inches) ▪ 8.6 inches wide ▪ 28.4 inches deep (Rack: 27.4 inches) ▪ 36.2 kilograms
Hard Drives	<ul style="list-style-type: none"> ▪ Supports up to ten drives, depending on peripheral choices ▪ One fixed drive bay for up to six fixed SAS or SATA drives ▪ Optional four-drive fixed drive bay ▪ Optional hot-swap drive bays: <ul style="list-style-type: none"> • 6-drive SAS/SATA (AXX6DRV3GR or AXX6DRV3GEXP) • 4-drive SAS/SATA (AXX4DRV3GR or AXX4DRV3GEXP)
Peripherals	<ul style="list-style-type: none"> ▪ Three multi-mount 5.25 peripheral bays
Control Panel (dependent on option selected)	<ul style="list-style-type: none"> ▪ Front Control Panel ▪ Intel® Local Control Panel (Optional)
LEDs and displays (dependent on option selected)	<ul style="list-style-type: none"> ▪ With Front Control Panel <ul style="list-style-type: none"> • NIC1 Activity • NIC2 Activity • Power/Sleep

Feature	Description
	<ul style="list-style-type: none"> • System Status • System Identification • Hard Drive Activity
Power Supply	<ul style="list-style-type: none"> ▪ (1+1) hot-swap redundant PFC high-efficiency 750-W PMBus-compliant power supply with integrated cooling fans. ▪ Second redundant 750-W module included
Fans	<ul style="list-style-type: none"> ▪ Three fixed, non-redundant system fans: <ul style="list-style-type: none"> • One 120-mm front fan • One 92-mm front fan • One 120-mm rear fan ▪ One air duct
Processor Cooling	<ul style="list-style-type: none"> ▪ Processor Heat Sink is not included ▪ Active processor heat sink(s) is required when using with compatible Intel® server/workstation board. ▪ Supports up to 95-W processor
USB 2.0	<ul style="list-style-type: none"> ▪ Two front panel USB ports with Front Control Panel ▪ Four Back panel USB ports (depending on server/workstation board)
Video	<ul style="list-style-type: none"> ▪ One rear panel video port

Table 3 summarizes the features of the Intel® Server Chassis SC5600LX SKU.


Table 3. Intel® Server Chassis SC5600LX Features

Feature	Description
Dimensions	<ul style="list-style-type: none"> ▪ 17 inches high (Rack: 16.6 inches) ▪ 8.6 inches wide ▪ 28.4 inches deep (Rack: 27.4 inches) ▪ 36.2 kilograms
Hard Drives	<ul style="list-style-type: none"> ▪ Supports up to ten drives, depending on peripheral choices ▪ One fixed drive bay for up to six fixed SAS or SATA drives ▪ Optional four-drive fixed drive bay ▪ Optional hot-swap drive bays: <ul style="list-style-type: none"> • 6-drive SAS/SATA (AXX6DRV3GR or AXX6DRV3GEXP) • 4-drive SAS/SATA (AXX4DRV3GR or AXX4DRV3GEXP)
Peripherals	<ul style="list-style-type: none"> ▪ Three multi-mount 5.25-inch peripheral bays
Control Panel (dependent on option selected)	<ul style="list-style-type: none"> ▪ Front Control Panel ▪ Intel® Local Control Panel (Optional)
LEDs and displays (dependent on option selected)	<ul style="list-style-type: none"> ▪ With Front Control Panel <ul style="list-style-type: none"> • NIC1 Activity • NIC2 Activity • Power/Sleep • System Status • System Identification • Hard Drive Activity
Power Supply	<ul style="list-style-type: none"> ▪ (1+1) hot-swap redundant PFC high-efficiency 750-W PMBus-compliant

Server Chassis Features

	Power Supply with integrated cooling fans, <ul style="list-style-type: none">▪ Second redundant 750-W module included
Fans	<ul style="list-style-type: none">▪ Four hot-swap, redundant chassis fans:<ul style="list-style-type: none">• Two 120-mm front fans• Two 92-mm front fans▪ One air duct
Processor Heat Sink	<ul style="list-style-type: none">▪ Processor heat sink is not included▪ Passive tower processor heat sink(s) (FXXRGTHSINK) is required when used with compatible Intel® server/workstation board▪ Supports up to 95-W processor
USB 2.0	<ul style="list-style-type: none">▪ Two front panel USB ports with Front Control Panel▪ Four back panel USB ports (depending on server/workstation board)
Video	<ul style="list-style-type: none">▪ One rear panel video port


Component Identification



1. Fixed Power Supply	7. Front Control Panel
2. Rear Serial B Connector	8. 5.25-inch Device Bays (optional optical drive shown)
3. PCI Add-in Card Panel	9. Front Panel USB/Serial B
4. Air Duct and Rear Fixed Fan	10. Fixed Drive Cage 4-Drive (accessory)
5. Front Fixed Fans (2)	11. Fixed Drive Cage 6-Drive
6. Hard Disk Drive Cage Release Mechanisms (2)	

Figure 2. Intel® Server Chassis SC5600Base Components Location


Server Chassis Features



1. Hot-swap Power Supply #2	8. Hard Disk Drive Cage Release Mechanism (2)
2. Hot-swap Power Supply #1	9. Front Control Panel
3. Rear Serial B Connector	10. 5.25-inch Device Bays (optional optical drive shown)
4. PCI Add-in Card Panel	11. Front Panel USB/Serial B
5. Air Duct	12. Hot-swap Drive Cage 4-Drive (accessory)
6. Hot-swap Fans – Large (2)	13. Hot-swap Drive Cage 6-Drive (accessory)
7. Hot-swap Fans –Small (2)	

Figure 3. Intel® Server Chassis SC5600LX Components Location

Front Control Panel



A. ID LED Toggle Switch	F. NIC2 Activity LED (green)
B. Reset Button	G. ID LED (blue)
C. NIC1 Activity LED (green)	H. Status LED (bi-color)
D. Power Button	I. NMI Button
E. Hard Drive Activity LED (green)	

Figure 4. Front Control Panel

Server Chassis Features

Descriptions of the front control panel LEDs are listed in the following table. See your server/workstation documentation for functionality of the buttons.

Table 4. Front Control Panel LED Descriptions


LED Name	Color	Condition	Description
Power LED	Green	On	Power on
		Off	Power off
System Status LED	Green	On	System booted and ready
		Blink	System ready, but degraded: some CPU fault, DIMM killed, and so forth
	Amber	On	Critical alarm: Critical power module failure, critical fan failure, voltage (power supply), voltage, thermal fault, and so forth
		Blink	Non-critical failure: Redundant fan failure, redundant power failure, non-critical power and voltage, and so forth
	Off	Off	AC Power off;
		Off	Powered Down (DC-off state or S5), and no degraded, non-critical, critical conditions exist*
Hard Drive Activity	Green	Blink	Hard drive activity
NIC1 Activity	Green	On	Linked
		Blink	LAN activity
		Off	Idle
NIC2 Activity	Green	On	Linked
		Blink	LAN activity
		Off	Idle
ID LED	Blue	Blink	Server identification; toggled by ID button or software
		On	Server identification; toggled by ID button or software

* When the server is powered down (transitions to the DC-off state or S5), the BMC is still on standby power and retains the sensor and front panel status LED state established before the power-down event. If the system status is normal when the system is powered down (the LED is in a solid green state), the system status LED will be off.

Intel® Local Control Panel

The optional Intel® Local Control Panel provides enhanced system control by using a LCD display, which provides additional controls and indicators beyond the standard control panel.

The following figure shows the features available on the Intel® Local Control Panel.




AF000955

Callout	Function
A	LCD display (variable content)
B	LCD up navigation button
C	LCD down navigation button
D	LCD backup level navigation button
E	LCD command enter button

Figure 5. Intel® Local Control Panel Features

Back Panel Features



Server Chassis Features

Callout	Function
A	Fixed Power Supply
B	I/O Ports
C	PCI Add-in Card Slots
D	PCI Card Latch
E	Rear Serial B Connector (optional)
F	AC Power Connector


NOTE

I/O ports vary, depending on the server/workstation board installed. See your server board documentation for port identification.

Figure 6. Server Chassis Back

Peripheral Devices

The chassis provides locations and hardware for installing hard drives, CD-ROM drive, DVD-ROM drive, or a tape drive. You must purchase the drives separately. The following figure shows the available options.



Callout	Function
A.	DVD-ROM drive/CD-ROM drive (Optional)
B.	Front USB ports (2)
C.	4-Bay hot-swap hard disk drive bay (optional)
D.	6-Bay hot-swap hard disk drive bay (optional)

Figure 7. Optional Peripherals

Standard and Optional Hot-swap Drive Bays

One bay supporting six cabled drives ships with the standard chassis. Optional hot-swap drive bays may replace the 6-drive fixed drive bay. An optional 4-drive fixed drive bay (for cabled drives) is available. No tools are required to replace the fixed drive bays.

Optional 4-drive and 6-drive SAS/SATA are available.

For instructions on installing hard drives, see “Removing and Installing Hot Swap Drive(s)” on page 55.

NOTE

Drives can consume up to 17 W or higher of power each. Drives must be specified to run a maximum ambient temperature of 45° Celsius.

The Intel® Server Chassis SC5600 does not support all SAS/SATA hard drives. See “Additional Information and Software” on page vii for an Internal link to a list of supported hardware.

See “*Drive Cage Upgrade Kit Installation Guide: Intel® Server Chassis SC5400 and SC5600*” for installing hot-swap hard drive bays.

Intel® Remote Management Module 3

The Intel® Remote Management Module 3 (Intel® RMM3) plugs into the connector on the server board and acts as a component of the server board, and provides a way to view and operate the server remotely in real-time. Keyboard, video, and mouse control (KVM) is redirected to a managing system. This provides remote control. USB media redirection allows you to use a USB device anywhere on the network as if it was installed on the management server with RMM3 installed. For example, you can insert a CD-ROM disk in a workstation CD-ROM drive and the managed server will view it as its own, local CD-ROM drive.

For installation instructions on installing the Intel® Remote Management Module 3, see the instructions provided with the module.

Rack-mount Systems

You can mount your Intel® Server chassis SC5600 into a rack. Intel provides a tool-less rail kit and a cable management arm to mount this server chassis into a rack. When installing the chassis into a rack, Intel recommends you install systems from the bottom of the rack to the top. In other words, install the first system in the rack into the bottom position of the rack; the second system in the second position from the bottom; and so on. Instructions for installing your chassis into a rack are included in the rail kit.

The order numbers are as follows:

Order Code	Description
ARIGRACK	Pedestal to rack conversion kit for Intel® Server Chassis SC5600.
AXXCMA3U7U	Universal 3U through 7U Rack Mode Cable Management Arm (CMA). Requires ARIGRACK.
ARIGRACKCVR	Optional unpainted removable side (top) cover for Intel® Server Chassis SC5600. If unpainted top cover is needed, you can use in rack conversion mode.

Tower Passive Processor Heat Sink (FXXRGTHSINK)

This tower passive heat sink (FXXRGTHSINK) is required when installing the Intel® Server Board S5520HC/S5500HCV into the Intel® Server Chassis SC5600LX. Two tower heat sinks are required for dual-processor installation.

This tower passive heat sink is NOT required for other Intel® Server Chassis in the Intel® Server Chassis SC5600 families.

2 Hardware Installations and Upgrades

Before You Begin

Before working with your server product, pay close attention to “Appendix B: Safety Information.”

This document provides instructions for adding and replacing chassis components. For instructions on replacing components on the server board, such as the processor and memory DIMMs, see the instructions provided with the server/workstation board.

Tools and Supplies Needed

- Phillips* (cross head) screwdriver (#1 bit and #2 bit)
- Needle nosed pliers
- Anti-static wrist strap and conductive foam pad (recommended)

System Reference

All references to the left, right, front, top, and bottom assume the reader is facing the front of the chassis as it would be positioned for normal operation.

Removing and Installing the Chassis Cover


Removing the Chassis Cover

You must operate the Intel® Server Chassis SC5600 with the top cover in place to ensure proper cooling. You must remove the top cover to add or replace components inside of the platform. Before removing the top cover, power down the server and unplug all peripheral devices and the AC power cable.

NOTE

A non-skid surface or a stop behind the chassis may be needed to prevent the chassis from sliding on your work surface.

1. Observe the safety and ESD precautions at the beginning of this book. See "Appendix B: Safety Information".
2. Turn off all peripheral devices connected to the server. Turn off the server.
3. Disconnect the AC power cord.
4. If it is installed, remove the access cover screw (see letter "A" in the following figure). While holding in the blue button at the top of the chassis (see letter "B"), slide the top cover back until it stops. Lift the cover outward to remove it.




AF000555

Figure 8. Removing the Chassis Cover

Installing the Chassis Cover

1. Slide the chassis cover on the chassis.
2. Latch the cover securely to the chassis.
3. If the chassis will be re-shipped, secure the chassis cover to the chassis with the access cover screw (see letter "A" in the following figure).



AF000572

Figure 9. Installing the Chassis Cover

Removing and Installing the Front Bezel

Removing the Front Bezel Assembly (Pedestal Configuration Only)



CAUTION

Do not rotate the bezel assembly more than 40° or you will damage the bezel assembly.




NOTE

The bezel assembly consists of two components: a front door and a sub-bezel.

1. Observe the safety and ESD precautions at the beginning of this book.
2. Power down the server and unplug all peripheral devices and the AC power cable.

3. Remove the chassis cover. For instructions, see “Removing the Chassis Cover.”
4. Release the two plastic tabs (see letter “A” in the following figure) on the left side of the bezel assembly to disengage the tabs.
5. Rotate the bezel assembly (see letter “B”) no more than 40° outward.
6. At a 40° angle, push the bezel assembly away from the chassis (see letter “C”).
7. If the bezel assembly does not immediately disconnect from the chassis, tap the left- side of the bezel assembly to disengage the bezel hooks on the right side of the chassis.



AF000557

Figure 10. Removing the Front Bezel

Installing the Front Bezel (Pedestal Configuration Only)




CAUTION

This step applies to a pedestal configuration chassis only. For instructions on installing a bezel in a rack-mount configuration, refer to the Rack Conversion Kit Installation Guide: Intel® Server Chassis SC5400 and SC5600.

1. Open the outer bezel door of the bezel assembly (see letter “A” in the following figure).
2. Remove the filler panels that correspond to the installed devices (see letter “B”).
3. Close the outer bezel door (see letter “C”).

Hardware Installations and Upgrades

4. Fit the right edge of the bezel assembly against the right side of the chassis.
5. Engage the plastic bezel hooks (see letter "D") into the raised metal slots at the chassis edge.
6. Rotate the bezel assembly toward the chassis.
7. Latch the two plastic tabs (see letter "E") on the left side of the bezel assembly to the chassis.



AF000558

Figure 11. Installing the Front Bezel

Removing and Installing the Air Duct

Always operate your server chassis with the air duct in place. The air duct is required for proper airflow within the chassis.

For instructions on adding or replacing a processor, first remove the air duct, and then see your server board user guide for instructions on processor installations and removals. Return to these instructions to reinstall the air duct after installing your processor and heat sink.

Removing the Air Duct

1. Observe the safety and ESD precautions at the beginning of this book. See "Appendix B: Safety Information".
2. Power down the server and unplug all peripheral devices and the AC power cable.
3. Remove the chassis cover. For instructions, see "Removing the Chassis Cover" on page 26.

4. Unlatch the air duct from the chassis by pressing the tab at the rear of the air duct located on the rear system fan bracket (See letter "A").
5. Grasp the air duct and remove (see letter "B").




Figure 12. Removing the Air Duct

Installing the Air Duct

Installing the Air Duct in Intel® Server Chassis SC5600Base and SC5600BRP

1. If your system has two processors, remove the inner plastic inlet filler board from the inside of the air duct (see the following figure for inlet filler board removal details).



CAUTION

This step only applies to systems with two processors. If your server board has only one processor installed, leave the inner air baffle in place and proceed to Step 2.

2. Install the air duct. Make sure aligning the air duct and chassis rear fan bracket (see letter "D" in Figure 13) alignment rails (see letter "C" in Figure 13) before inserting air duct tabs (see letter "B" in Figure 13) into the chassis rear fan bracket slots (see letter "A" in Figure 13).




Figure 13. Installing the Air Duct into Intel® Server Chassis SC5600Base and SC5600BRP

NOTE

Use care to avoid pinching the cables.

Installing the Air Duct in the Intel® Server Chassis SC5600LX

1. Install the air duct. Make sure to align the air duct and chassis rear fan bracket alignment rails (see letter "E" in Figure 14) before inserting air duct tabs (see letters "B", "C", and "F" in Figure 14) into the matching chassis slots (see letters "A", "D", and "F" in Figure 14).




Figure 14. Installing the Air Duct into Intel® Server Chassis SC5600LX

NOTE

Use care to avoid pinching the cables.

Replacing a Fixed Fan (Intel® Server Chassis SC5600Base and SC5400BRP only)

NOTE

This procedure applies only to the Intel® Server Chassis SC5600Base and Intel® Server Chassis SC5600BRP configurations.

1. Observe the safety and ESD precautions at the beginning of this book.
2. Power down the server and unplug all peripheral devices and the AC power cable.
3. Remove the chassis cover. For instructions, see “Removing the Chassis Cover.”
4. Disconnect the appropriate fan power cable from the server board.
5. To replace the rear chassis fan, remove the air duct. For instructions, see “Removing the Air Duct.”
6. Remove the 92-mm (see letter “A” in the following figure) or 120-mm (see letters “B” and “C”) fixed fan from its snap-in bracket.




Figure 15. Removing a Fixed Fan

7. Install a new 92-mm or 120-mm fixed fan.
8. Connect the fan power cable to the server/workstation board. See the *Quick Start User's Guide* or *Service Guide* provided with your Intel® server/workstation board for the appropriate connection location.
9. Install the air duct if it was removed in a previous step. For instructions, see "Installing the Air Duct."
10. Plug all peripheral devices and the AC power cable into the server and then power up the server.

Removing and Installing Hot Swap Fans (Intel® Server Chassis SC5600LX only)

Removing Hot Swap Fans


NOTE

This procedure applies only to the Intel® Server Chassis SC5600LX configurations. The Intel® Server Chassis SC5600Base and Intel® Server Chassis SC5400BRP configurations ship with fixed fans.

You cannot use the hot-swap fans from the Intel® Server Chassis SC5400LX or SC5400LXi in the Intel® Server Chassis SC5600LX.

1. Observe the safety and ESD precautions at the beginning of this book.

2. Remove the chassis cover. For instructions, see “Removing the Chassis Cover.”
3. Press the latch on the fan (see letter “A” in Figure 16) and pull on the handle to remove the hot swap fan from the chassis.
4. For removal of the remaining hot swap fans, repeat Step 3.



AF000573

Figure 16. Removing Hot Swap Fan


Installing Hot Swap Fans

NOTE

This procedure applies only to the Intel® Server Chassis SC5600LX configurations. The Intel® Server Chassis SC5600Base and Intel® Server Chassis SC5400BRP configurations ship with fixed fans.

You cannot use the hot-swap fans from the Intel® Server Chassis SC5400LX or SC5400LXi in the Intel® Server Chassis SC5600LX.

1. Observe the safety and ESD precautions at the beginning of this book.
2. Remove the chassis cover if it was not removed in a previous step. For instructions, see “Removing the Chassis Cover.”
3. Insert the hot swap fan into the chassis until it latches into place.
4. For insertion of the remaining hot swap fans, repeat Step 3.




AF000574

Figure 17. Installing Hot Swap Fan

Removing and Installing a DVD- or CD-ROM Drive

Removing a DVD- or CD-ROM Drive


1. Observe the safety and ESD precautions at the beginning of this book.
2. Power down the server and unplug all peripheral devices and the AC power cable.
3. Remove the chassis cover. For instructions, see “Removing the Chassis Cover.”
4. If it is installed, remove the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
5. Disconnect the power and data cables to the DVD/CD-ROM drive.
6. Remove the DVD/CD-ROM drive/slide assembly from the chassis by pressing in on the slide release latches (see letter “A” in Figure 18). Remove the slides from the DVD or CD-ROM drive by pulling the slides away from the drive (see letter “B”). A gentle pull should release the slide from the side dimple on the drive.



AF000575

Figure 18. Removing DVD or CD-ROM Drive

7. If you are not replacing with another drive, re-attach a pair of slides to an EMI shield and reinsert the EMI shield/slide assembly into the chassis for proper airflow.




AF000605

Figure 19. Re-inserting Empty EMI Shield/Slide Assembly

8. Install the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
9. Install the chassis cover. For instructions, see “Installing the Chassis Cover.”
10. Plug all peripheral devices and the AC power cable into the server.
11. Power up the server.

Installing a DVD- or CD-ROM Drive


1. Observe the safety and ESD precautions at the beginning of this book.
2. Power down the server and unplug all peripheral devices and the AC power cable.
3. Remove the chassis cover. For instructions, see “Removing the Chassis Cover.”
4. If it is installed, remove the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
5. Remove an EMI shield/slide assembly from the upper device bay by pressing the two slide assembly latches inward (see letter “A” in Figure 20). Remove the slides from the EMI shield by pulling the slides away from the EMI shield to release them from the EMI shield (see letter “B”).



AF000945

Figure 20. Removing EMI Shield/Slide Assembly from Upper Device Bay

6. Attach slides to the DVD or CD-ROM drive by pressing the slides firmly into the side dimples on the DVD- or CD-ROM drive.



AF000576

Figure 21. Attaching Slides to a DVD or CD-ROM Drive

7. Insert the drive/slide assembly into the upper device bay until the slides lock into place.
8. Connect power and data cables.
9. Install the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
10. Install the chassis cover. For instructions, see “Installing the Chassis Cover.”
11. Plug all peripheral devices and the AC power cable into the server.
12. Power up the server.


Removing and Installing Fixed Hard Drive(s)

Removing Fixed Hard Drive(s)

1. Observe the safety and ESD precautions at the beginning of this book.
2. Power down the server and unplug all peripheral devices and the AC power cable.
3. Remove the chassis cover. For instructions, see “Removing the Chassis Cover.”
4. If it is installed, remove the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
5. Push the blue plastic release mechanism upward to release the fixed drive cage (see letter “A” in Figure 22).
6. Remove power and data cables from the hard drive connectors.
7. Pull the drive cage out about two inches (see letter “B”) so it is partially exposed from the drive bay slot in the chassis. Partially exposing the drive cage makes it easier to open the upper door of the drive cage.

NOTE

As an alternative, you may also fully remove the drive cage from its drive bay slot in the chassis. Take care, however, to position the drive cage horizontally before opening the drive cage doors or the drive rails will spill out.




TP00906

Figure 22. Removing Six-drive Fixed Drive Cage from Chassis

Hardware Installations and Upgrades


- Loosen the thumb screw (see letter “A” in Figure 23). Open the upper door of the drive cage (see letter “B”).



AF000579

Figure 23. Unlocking and Opening Upper Door of Fixed Drive Cage


- Open the lower door.



AF000580

Figure 24. Opening Lower Door of Fixed Drive Cage


- Remove the drive/slide assembly from the drive cage.



AF000588

Figure 25. Removing Drive/Slide Assembly from Fixed Drive Cage


11. Remove the device slides from the hard drive. If not replacing the hard drive, insert the empty device slides into the drive cage.



AF000947

Figure 26. Inserting Empty Device Slides into Fixed Drive Cage


12. Close the lower door of the drive cage.



AF000948

Figure 27. Closing Lower Door of Fixed Drive Cage


13. Close the upper door.



AF000949

Figure 28. Closing Upper Door of Fixed Drive Cage

14. Tighten the captive screw.



AF000586

Figure 29. Tightening Thumb Screw


15. Reinstall the fixed hard drive into the chassis.
16. If other hard drives remain in the drive cage, reconnect the power and data cables.
17. Install the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
18. Install the chassis cover. For instructions, see “Installing the Chassis Cover.”
19. Plug all peripheral devices and the AC power cable into the server.
20. Power up the server.

Installing Fixed Hard Drive(s)

1. Observe the safety and ESD precautions at the beginning of this book.
2. Power down the server and unplug all peripheral devices and the AC power cable.
3. Remove the chassis cover. For instructions, see “Removing the Chassis Cover.”
4. If it is installed, remove the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
5. Push the blue plastic release mechanism upward to release the fixed drive cage (see letter “A” Figure 30). Pull the drive cage out about two inches (see letter “B”) so it is partially exposed from the drive bay slot in the chassis. Partially exposing the drive cage makes it easier to open the upper door of the drive cage.

NOTE


As an alternative, you may also fully remove the drive cage from its drive bay slot in the chassis. Take care, however, to position the drive cage horizontally before opening the drive cage doors or the drive rails will spill out.



TP00906

Figure 30. Removing Six-drive Fixed Drive Cage from Chassis


6. Loosen the captive screw (see letter “A” in Figure 31). Open the upper door (see letter “B”).



AF000579

Figure 31. Unlocking and Opening the Upper Door of Fixed Drive Cage


7. Open the lower door.



AF000580

Figure 32. Opening Lower Door of Fixed Drive Cage

8. Remove a pair of device slides from the drive cage.



AF000581

Figure 33. Removing Slides from Fixed Drive Cage

9. Attach the device slides to the hard drive. This is a tool-less operation. Insert pins on device slides into mounting holes on the hard drive. Press firmly to secure device slides to the hard drive. Ensure the metal tabs on the device slides are facing the front of the hard drive and facing towards each other.

Hardware Installations and Upgrades




Figure 34. Attaching Device Slides to Hard Drive

10. Insert the drive/slide assembly into the drive cage. Make sure the cable connector end of the hard drive faces towards the rear of the drive cage.





Figure 35. Inserting Drive/Slide Assembly into Drive Cage


11. For installation of additional hard drives into the drive cage, repeat the previous steps.
12. Close the lower door of the drive cage.



AF000584

Figure 36. Closing Lower Door of Fixed Drive Cage

13. Close the upper door.




AF000585

Figure 37. Closing Upper Door of Fixed Drive Cage

14. Tighten the captive screw.

Hardware Installations and Upgrades



AF000586

Figure 38. Tightening Thumb Screw

15. Re-install the fixed drive cage into the chassis.
16. Connect the power and data cables to the connectors on the hard drive(s).
17. Install the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
18. Install the chassis cover. For instructions, see “Installing the Chassis Cover” on page 27.
19. Plug all peripheral devices and the AC power cable into the server.
20. Power up the server.

Routing Power Cables to Fixed Drives

Route the longest power cables to the 6-drive bay and shorter cables to the 4-drive bay and upper device bay.




Figure 39. Routing Power Cables to Fixed Drives

Routing Data Cables to Fixed Drives

NOTE

Front panel, USB cables are pre-routed by the factory. SAS or SATA cables are supplied with the server board and hot-swap drive accessory kits. No cables are supplied with the fixed drive bay kit.

- Route SAS/SATA data cables through the chassis openings located near the bottom of the drive cage.
- Connect data cables to the respective fixed drive and to the appropriate connector on the server board.





Figure 40. Routing SAS/SATA Data Cables

Removing and Installing Hot Swap Drive(s)

Removing Hot Swap Drive(s)

1. Press in on the green latch (see letter "A" in Figure 41) at the end of the drive carrier to disengage it from the hot swap drive cage. Pull out on the black lever (see letter "B") to fully open the drive carrier. When the lever reaches a fully opened position, it will push the drive carrier out from the hot swap drive cage. Slide the drive carrier out of the drive cage (see letter "C").



AF000589

Figure 41. Removing Drive Carrier from Hot Swap Cage

2. Remove the four screws securing the hard drive to the drive carrier. Remove the hard drive from the drive carrier.





Figure 42. Removing Hard Drive from Drive Carrier

Hardware Installations and Upgrades

3. If not replacing with another hard drive, re-install the plastic air baffle into the empty drive carrier. Secure the plastic air baffle to the drive carrier using the four screws previously attached to the hard drive.

NOTE


Plastic air baffles are necessary in all empty drive carriers to ensure proper airflow within the chassis.



AF000950

Figure 43. Securing Plastic Air Baffle in Drive Carrier

4. With the black lever open, insert the drive carrier into the drive cage. Once inserted, rotate the black lever upwards to latch the drive carrier into position.




AF000592

Figure 44. Inserting Drive Carrier into Hot Swap Cage

Installing Hot Swap Drive(s)


1. Press in on the green latch (see letter "A" in Figure 45) at the end of the drive carrier to disengage it from the hot swap drive cage. Pull out on the black lever (see letter "B") to fully open the drive carrier. When the lever reaches a fully opened position, it will push the drive carrier out from the hot swap drive cage. Slide the drive carrier out of the drive cage (see letter "C").



AF000589

Figure 45. Removing Drive Carrier from Hot Swap Cage


2. Remove the four screws that secure the plastic air baffle to the drive carrier. Remove the plastic air baffle.



AF000590

Figure 46. Removing Plastic Air Baffle from Drive Carrier


3. Secure the hard drive to the drive carrier using the four screws previously attached to the plastic air baffle. Ensure the connector end of the hard drive is facing the back of the drive carrier. The label side of the hard drive should be facing up in the drive carrier.



AF000591

Figure 47. Securing Hard Drive to Drive Carrier

4. With the black lever open, insert the drive carrier into the drive cage. Once inserted, rotate the black lever upwards to latch the drive carrier into position.



AF000592

Figure 48. Inserting Drive Carrier into Hot Swap Cage

Removing and Installing PCI Add-in Board(s)

Removing PCI Add-in Board(s)



CAUTIONS

When removing a full-length add-in card, you must pull back the latch on the plastic card guide at the front of the chassis to release the card from the card guide.

1. Observe the safety and ESD precautions at the beginning of this book.
2. Power down the server and unplug all peripheral devices and the AC power cable.
3. Remove the chassis cover. For instructions, see “Removing the Chassis Cover.”
4. If it is installed, remove the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
5. If necessary, remove any cables attached to the add-in card.
6. Remove the PCI add-in card retainer. Press in on the two plastic tabs (see letter “A” in Figure 49) to release the PCI add-in card retainer from the chassis. Open the back panel PCI add-in card retention device (see letter “B”) by pressing open from the inside of the chassis.




Figure 49. Preparing Chassis for Removal of PCI add-in board

Hardware Installations and Upgrades

7. Firmly grab the PCI add-in board by its top edge or outer corners and remove from the expansion slot on the server board. Place the removed PCI add-in board in an anti-static protective wrapper. Close the back panel PCI add-in card retention device.
8. Remove additional PCI add-in boards as necessary. When done, reinstall the PCI add-in card retainer and close the PCI add-in card retention device(s).
9. Install the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
10. Install the chassis cover. For instructions, see “Installing the Chassis Cover.”
11. Plug all peripheral devices and the AC power cable into the server.
12. Power up the server.

Installing PCI Add-in Board(s)



CAUTIONS


Before installing any add-in boards, you may want to install an operating system.

Do not overload the server board by installing add-in boards that draw excessive current.

Add-in boards can be extremely sensitive to ESD and always require careful handling. After removing the board from its protective wrapper, place it component side up on a grounded, static-free surface. Do not slide the board over any surface.

When removing a full-length add-in card, you must pull back on the latch on the plastic card guide at the front of the chassis to release the card from the card guide.


1. Observe the safety and ESD precautions at the beginning of this book.
2. Power down the server and unplug all peripheral devices and the AC power cable.
3. Remove the chassis cover. For instructions, see “Removing the Chassis Cover.”
4. If it is installed, remove the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
5. Press in on the two plastic tabs (see letter “A” in Figure 50) and remove the PCI add-in card retainer. Open the back panel PCI add-in card retention device (see letter “B”) by pressing open from the inside of the chassis. Remove the PCI slot shield (see letter “C”), if it is not already removed, by pushing the shield out from the inside of the chassis.



AF000954

Figure 50. Preparing Chassis for Addition of PCI add-in board


6. Remove the PCI add-in board from its protective wrapper. Be careful not to touch the components or gold edge connectors. Place the add-in board on an anti-static surface. Record the type and serial number of the add-in board in your equipment log. Set the jumpers or switches on the board according to the manufacturer's instructions.
7. Hold the PCI add-in board by its top edge or upper corners. Firmly press the add-in board into an expansion slot on the server board (see letter "A" in the following figure). Close the back panel PCI add-in card retention device (see letter "B").



AF000599

Figure 51. Installing PCI Add-in Board

8. Repeat steps 2 through 10 until all PCI add-in cards are installed.
9. Reinstall the PCI Add-in Card Retainer.



AF000600

Figure 52. Reinstalling PCI Add-in Card Retainer

10. Attach cables if necessary.
11. Install the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
12. Install the chassis cover. For instructions, see “Installing the Chassis Cover.”
13. Plug all peripheral devices and the AC power cable into the server.
14. Power up the server.

Replacing a Hot Swap Power Supply

WARNING

Hazardous voltage, current, and energy levels are present inside the power supply. There are no user-serviceable parts inside it; servicing should be done by technically qualified personnel only.

1. Remove the power cable from the defective hot swap power supply.
2. Press on the green latch on the power supply (see letter “A” in Figure 53) while pulling on the handle (see letter “B” in Figure 53) to remove the power supply from the chassis.




Figure 53. Removing Hot Swap Power Supply from Chassis

3. Push the handle (see letter “A” in Figure 54) to insert the new hot swap power supply into the chassis, and make sure the green latch (see letter “B” in Figure 54) secures the hot swap power supply to the power supply cage.




Figure 54. Installing Hot Swap Power Supply into Chassis


4. Connect the power cable to the replaced power supply.

Replacing a Fixed Power Supply

WARNING

Hazardous voltage, current, and energy levels are present inside the power supply. There are no user-serviceable parts inside it; servicing should be done by technically qualified personnel only.

1. Observe the safety and ESD precautions at the beginning of this book.
2. Power down the server and unplug all peripheral devices and the AC power cable.
3. Remove the chassis cover. For instructions, see “Removing the Chassis Cover.”
4. Remove the chassis air duct. For instructions, see “Removing the Air Duct.”
5. Disconnect all internal power cables from the chassis components and server board.
6. Remove the eight screws securing the fixed power supply shield to the chassis (see letter “A” in Figure 55). Remove the fixed power supply (see letter “B”).



AF000957

Figure 55. Removing Fixed Power Supply

7. Insert the new fixed power supply.
8. Secure the fixed power supply shield to the chassis with the eight screws.
9. Connect the P1, P2, P3, and P4 cables to the server/workstation board. See the *Intel® server/workstation board Quick Start User's Guide or User Guide* for connection locations.
10. Reconnect the power cables to other chassis components as appropriate.
11. Re-install the chassis air duct. For instructions, see “Installing the Air Duct.”
12. Install the chassis cover. For instructions, see “Installing the Chassis Cover.”
13. Plug all peripheral devices and the AC power cable into the server.
14. Power up the server.

Replacing the Hot Swap Power Supply Power Distribution Board

WARNING

Hazardous voltage, current, and energy levels are present inside the power supply. There are no user-serviceable parts inside it; servicing should be done by technically qualified personnel.

1. Observe the safety and ESD precautions at the beginning of this book.
2. Power down the server and unplug all peripheral devices and the AC power cable.
3. Remove the chassis cover. For instructions, see “Removing the Chassis Cover.”
4. Remove the air duct. For instructions, see “Removing the Air Duct.”
5. Press on the green latch on the power supply (see letter “A” in Figure 56) while pulling on the handle (see letter “B” in Figure 56) to remove the power supply from the chassis. Repeat this step for the second power supply.




Figure 56. Removing Hot Swap Power Supply from Chassis

6. Disconnect all internal power cables from the chassis components and server/workstation board. See the *Quick Start User's Guide* or *Service Guide* provided with your Intel server/workstation board for the appropriate connection location.
7. Remove the screws (see letters “A” and “B” in the following figure) securing the filler panel to the chassis, and remove the power supply filler panel from the chassis.




Figure 57. Removing Power Supply Filler Panel from Chassis

8. Remove the screws (see letters “A”, “B”, “C”, “D”, and “E” in Figure 58) securing the power supply cage to the chassis.




Figure 58. Removing Screws Securing Hot Swap Power Supply Cage

9. Remove the power supply cage from the chassis. You may have to feed the power cables through the chassis power supply bay while removing the hot swap power supply cage.





Figure 59. Removing Hot Swap Power Supply Cage from Chassis


10. Remove the screws (see letter “A” and “B” in the following figure) securing the power distribution board to the hot swap supply cage, and detach the distribution board from the hot swap power supply cage.



NOTE Cables on the back of the power distribution board are not shown to clarify the removal process.

Figure 60. Removing Power Distribution Board from Hot Swap Power Supply Cage

11. Attach the new power distribution board to the hot swap power supply cage, position the power distribution board screw holes to the matching power supply cage mounting holes (see letter “A” and “B” in Figure 61), and secure the screws.



NOTE Cables on the back of the power distribution board are not shown to clarify the installation process.

Figure 61. Attaching Power Distribution Board to Hot Swap Power Supply Cage

12. Re-insert the hot swap power supply cage into the chassis power supply bay. Try to route the power cables to the appropriate area at the time of insertion (see Step 13).




Figure 62. Inserting Hot Swap Power Supply Cage in Chassis

13. Tighten screws to secure the power supply cage to the chassis (see letters “A”, “B”, “C”, “D” and “E” in Figure 63).




Figure 63. Securing Hot Swap Power Supply Cage to Chassis

14. Reinstall the filler panel board, and install the screws to secure the filler panel board to the chassis (see letters “A” and “B” in Figure 64).




Figure 64. Installing Filler Panel board on the Chassis

15. Insert the hot swap power supplies into the chassis (see Figure 65).




Figure 65. Inserting Hot Swap Power Supplies into Chassis

16. Re-install the air duct. For instructions, see “Installing the Air Duct.”
17. Re-install the chassis cover. For instructions, see “Installing the Chassis Cover.”
18. Plug all peripheral devices and the AC power cable into the server.
19. Power up the server.

Replacing the Control Panel

The steps for replacing the front control panel and the Intel® Local Control Panel are nearly identical. Use the following steps for both varieties of the control panel. Where necessary, differences between the two control panels are noted.

You must operate your server with a control panel installed.



CAUTION

The control panel is NOT hot-swappable. Before removing or replacing the control panel, you must first take the server out of service, turn off all peripheral devices connected to the system, turn off the system by pressing the power button, and unplug the AC power cord from the system or wall outlet.

1. Observe the safety and ESD precautions at the beginning of this book.
2. Power down the server and unplug all peripheral devices and the AC power cable.
3. Remove the chassis cover. For instructions, see “Removing the Chassis Cover.”
4. If it is installed, remove the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
5. Press the latch at the back of the control panel.
6. Slide the control panel out through the front of the chassis far enough so you can reach the front panel and USB cable connectors at the rear of the control panel.

7. Disconnect the cables.
8. Install the control panel module into the chassis.
9. Reconnect the cables.
10. (Optional) Install the front bezel. For instructions, see “Removing and Installing the Front Bezel.”
11. Install the chassis cover. For instructions, see “Installing the Chassis Cover.”
12. Plug all peripheral devices and the AC power cable into the server.
13. Power up the server.

Installing and/or Removing a Server/Workstation Board

/ NOTE

The server/Workstation board you can install in your chassis depends upon the chassis model.


To install or remove a server board, do the following:


1. Observe the safety and ESD precautions at the beginning of this book.
2. Power down the server and unplug all peripheral devices and the AC power cable.
3. Remove the chassis cover. For instructions, see “Removing the Chassis Cover.”
4. If it is installed, remove the front bezel assembly. For instructions, see “Removing the Bezel Assembly (Pedestal Only).”
5. Remove any PCI add-in boards that are present. For instructions, see “Removing PCI Add-in Board(s).”
6. Remove the air duct. For instructions, see “Removing the Air Duct.”
7. If installing a server board, refer to the *Service Guide* and/or *Quick Start User's Guide* that shipped with your Intel® server/workstation board for installation instructions. Use the mounting screws, bumpers, and standoffs (if necessary) that came with your chassis to secure the server/workstation board to the chassis. Make sure the server/workstation board is properly seated and then tighten the screws firmly, starting with the screws at the center of the server/workstation board. Make cable connections per the instructions in the Intel® server/workstation board *Service Guide* and/or *Quick Start User's Guide*.
8. If removing a server board, disconnect all cables connected to the server board.
9. Remove the mounting screws, starting with the screws at the center of the server/workstation board. Remove the server board.
10. Re-install the air duct. For instructions, see “Installing the Air Duct” on page 32.
11. If needed, install any PCI Add-in boards. For instructions, see “Installing PCI Add-in Board(s).”
12. Re-install the front bezel assembly. For instructions, see “Installing the Front Bezel (Pedestal Only).”
13. Re-install the chassis cover. For instructions, see “Installing the Chassis Cover.”
14. Plug all peripheral devices and the AC power cable into the server.
15. Power up the server.

Connecting and Disconnecting Cables to or from Server Workstation Board

CAUTION

Use caution when routing cables to ensure that cables do not obstruct fan airflow.

 See your *Intel® Server/Workstation Board Service Guide* or *Quick Start User's Guide* for cable connection locations.

 If your server has a hot swap power supply, secure the cables (that route toward the server/workstation board) to the chassis.

Connecting Cables to Server/Workstation Board

1. If your server has a hot swap power supply, connect the cables (that route toward the server/workstation board) to the chassis.
2. See your *Intel® Server/Workstation Board Service Guide* or *Quick Start User's Guide* for cable connection locations.

Removing Cables from Server/Workstation Board

1. If your server has a hot swap power supply, remove the cables (that route toward the server/workstation board) to the chassis.
2. See your *Intel® Server/Workstation Board Service Guide* or *Quick Start User's Guide* for cable connection locations.

3 Technical Reference

Power Supply Specification

670-W Single Power Supply Input Voltage

- 100-127 V at 50/60 Hz; 12 A max.
- 200-240 V at 50/60 Hz; 7 A max.

670-W Single Power Supply Output Voltages

The following table lists the total wattage available from the power subsystem for each voltage. Ensure your loads do not exceed the combined total wattage of 670 W. For information about calculating the power usage for your configuration, see “Calculating Power Usage.”

Table 5. 670-W Power Supply Output Capability

Voltage	Maximum Current
+ 3.3 V	24 A
+5 V	30 A
+12 V1	16 A
+12 V2	16 A
+12 V3	16 A
+12 V4	16 A
-12 V	0.5 A
+5 VSB	3.0 A



WARNING

Do not exceed a combined power output of 170 W for the +5 V and +3.3 V outputs. Exceeding a combined 170 W will overload the power subsystem and may cause the power supplies to overheat and malfunction.

The expansion slots on the server board are rated for no more than 25 W for any one slot. The average current usage per slot should not exceed 13 W.

750-W Hot Swap Power Supply Input Voltages

- 100-127V at 50/60 Hz; 12 A max.
- 200-240 V at 50/60 Hz; 6 A max.

750-W Hot Swap Power Supply Input Voltages

The following table lists the total wattage available from the power subsystem for each voltage. If you configure your system heavily, ensure your loads do not exceed the combined total wattage of 725 Watts. For information about calculating the power usage for your configuration, see “Calculating Power Usage.”

Table 6. 750-W Hot Swap Power Supply Output Capability

Voltage	Maximum Current
+ 3.3 V	24 A
+5 V	30 A
+12 V1	24 A
+12 V2	24 A
+12 V3	16 A
+12 V4	16 A
-12 V	0.5 A
+5 VSB	3.0 A

⚠ WARNING

Do not exceed a combined power output of 170 W for the +5 V and +3.3 V outputs. Exceeding a combined 170 W will overload the power subsystem and may cause the power supplies to overheat and malfunction.

The expansion slots on the server board are rated for no more than 25 W for any one slot. The average current usage per slot should not exceed 13 W.

System Environmental Specification

Table 7. Environmental Specification

Temperature	Non-operating: -40 ° to 70 °C Operating: 10 ° to 35 °C; derated 0.5 °C for every 1000 ft. (305 m) to a maximum of 10,000 feet
Humidity	Non-operating: 90% relative humidity (non-condensing) at 30 °C.
Shock	Operating: 2.0 g, 11 msec, 1/2 sine Packaged: Operational after an 18-inch free fall.
Acoustic Noise	Base, BRP, and LX configurations - 5.8 BA LWA idle; 6.0 BA LWA typical operating
Electrostatic Discharge (ESD)	Tested to 15 kilovolts (kV); no component damage

Current Usage

Calculation Power Usage

The total combined wattage for your configuration **must be less than the wattage rating for your power supply**. Use the two worksheets in this section to calculate the total used by your configuration. For current and voltage requirements of add-in boards and peripherals, see your vendor documents.

Worksheet, Calculating DC Power Usage

Table 8. Power Usage Worksheet

Device	Current (maximum) at voltage level					
	+3.3 V	+5 V	-5 V	+12 V	-12 V	5 V Standby
Baseboard, Front Panel						
Board and Fans						
Processor(s)						
Memory						
3.5-inch Diskette Drive						
CD-ROM Drive						
Second 5.25-inch Device						
Third 5.25-inch Device						
1st Hard Drive						
2nd Hard Drive						
3rd Hard Drive						
4th Hard Drive						
5th Hard Drive						
6th Hard Drive						
Expansion Board 1						
Expansion Board 2						
Expansion Board 3						
Expansion Board 4						
Expansion Board 5						
Expansion Board 6						
Intel® Remote Management Module						

Technical Reference

Device	Current (maximum) at voltage level					
	+3.3 V	+5 V	-5 V	+12 V	-12 V	5 V Standby
Control Panel						
Total Current						

Worksheet, Total Combined Power Used by the Server

- From the previous worksheet, enter the total current for each column.
- Multiply the voltage by the total current to get the total wattage for each voltage level.

Add the total wattage for each voltage level to arrive at the total combined power usage for the power subsystem.

Table 9. Power Usage Worksheet 2

Voltage level and total current (V X A = W)	Total watts for each voltage level
(+3.3 V) X (_____ A)	_____ W
(+5 V) X (_____ A)	_____ W
(+12 V) X (_____ A)	_____ W
(-12 V) X (_____ A)	_____ W
(5 V standby) X (_____ A)	_____ W
Total Combined Wattage	_____ W

CAUTION

Do not exceed a combined power output of 170 W for the +5 V and +3.3 V outputs. Exceeding a combined 170 W will overload the power subsystem and may cause the power supplies to overheat and malfunction.

Appendix A: Regulatory and Compliance Information

Product Regulatory Compliance

Warning: To ensure regulatory compliance, you must adhere to the assembly instructions in this guide to ensure and maintain compliance with existing product certifications and approvals. Use only the described, regulated components specified in this guide. Use of other products/components will void the UL listing and other regulatory approvals of the product and will most likely result in noncompliance with product regulations in the region(s) in which the product is sold.

To help ensure EMC compliance with your local regional rules and regulations, before computer integration, make sure that the chassis, power supply, and other modules have passed EMC testing using a server board with a microprocessor from the same family (or higher) and operating at the same (or higher) speed as the microprocessor used on this server board. The final configuration of your end system product may require additional EMC compliance testing. For more information, please contact your local Intel representative.

This is an FCC Class A device. Integration of it into a Class B chassis does not result in a Class B device.

Product Safety Compliance

This server chassis product, when correctly integrated per this guide, complies with the following safety and electromagnetic compatibility (EMC) regulations.

Intended Application

This product was evaluated as Information Technology Equipment (ITE), which may be installed in offices, schools, computer rooms, and similar commercial type locations. The suitability of this product for other product categories and environments (such as: medical, industrial, telecommunications, NEBS, residential, alarm systems, test equipment, etc.), other than an ITE application, may require further evaluation.

Product Safety Compliance

The server chassis complies with the following product safety requirements:

- UL60950 - CSA 60950 (USA/Canada)
- EN60950 (Europe)
- IEC60950 (International)
- CB Certificate & Report, IEC60950 (report to include all country national deviations) GS License (Germany)
- GOST R 50377-92 - License (Russia)
- Belarus License (Belarus)
- Ukraine License (Ukraine)
- CE - Low Voltage Directive 73/23/EEE (Europe)
- IRAM Certification (Argentina)

Appendix A: Regulatory and Compliance Information

Product EMC Compliance - Class A Compliance

This server chassis has been tested and verified to comply with the following electromagnetic compatibility (EMC) regulations when installed in a compatible Intel® host system. For information on compatible host system(s), refer to Intel's Server Builder Web site or contact your local Intel representative.

- FCC /ICES-003 - Emissions (USA/Canada) Verification
- CISPR 22 - Emissions (International)
- EN55022 - Emissions (Europe)
- EN55024 - Immunity (Europe)
- EN61000-3-2 - Harmonics (Europe)
- EN61000-3-3 - Voltage Flicker (Europe)
- CE - EMC Directive 89/336/EEC (Europe)
- VCCI Emissions (Japan)
- AS/NZS 3548 Emissions (Australia/New Zealand)
- BSMI CNS13438 Emissions (Taiwan)
- GOST R 29216-91 Emissions (Russia)
- GOST R 50628-95 Immunity (Russia)
- Belarus License (Belarus)
- Ukraine License (Ukraine)
- RRL MIC Notice No. 1997-41 (EMC) & 1997-42 (EMI) (Korea)

Certifications/Registrations/Declarations

- UL Certification (US/Canada)
- CE Declaration of Conformity (CENELEC Europe)
- FCC/ICES-003 Class A Attestation (USA/Canada)
- VCCI Certification (Japan)
- C-Tick Declaration of Conformity (Australia)
- MED Declaration of Conformity (New Zealand)
- BSMI Certification (Taiwan)
- GOST R Certification/License (Russia)
- Belarus Certification/License (Belarus)
- RRL Certification (Korea)
- IRAM Certification (Argentina)
- Ecology Declaration (International)

Product Regulatory Compliance Markings

This Intel® server chassis product bears the following regulatory marks.

Table 10. Product Regulatory Compliance Markings

Regulatory Compliance	Region	Marking
cULus Listing Marks	USA/Canada	
GS Mark	Germany	
CE Mark	Europe	
FCC Marking (Class A)	USA	This device complies with Part 15 of the FCC Rules. Operation of this device is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Manufactured by Intel Corporation
EMC Marking (Class A)	Canada	CANADA ICES-003 CLASS A CANADA NMB-003 CLASSE A
VCCI Marking (Class A)	Japan	この装置は、クラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。VCCI-A
BSMI Certification Number and Class A Warning	Taiwan	 警告使用者： 這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策
GOST R Marking	Russia	

Appendix A: Regulatory and Compliance Information

Regulatory Compliance	Region	Marking
RRL KCC Mark	Korea	 방송통신위원회

Electromagnetic Compatibility Notices

FCC Verification Statement (USA)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For questions related to the EMC performance of this product, contact:

Intel Corporation
5200 N.E. Elam Young Parkway
Hillsboro, OR 97124-6497
1-800-628-8686

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit other than the one to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment. The customer is responsible for ensuring compliance of the modified product.

Only peripherals (computer input/output devices, terminals, printers, etc.) that comply with FCC Class A or B limits may be attached to this computer product. Operation with noncompliant peripherals is likely to result in interference to radio and TV reception.

All cables used to connect to peripherals must be shielded and grounded. Operation with cables, connected to peripherals that are not shielded and grounded may result in interference to radio and TV reception.

Industry Canada (ICES-003)

Cet appareil numérique respecte les limites bruits radioélectriques applicables aux appareils numériques de Classe A prescrites dans la norme sur le matériel brouilleur:

"Appareils Numériques", NMB-003 édictée par le Ministre Canadien des Communications.

English translation of the notice above:

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the interference-causing equipment standard entitled: "Digital Apparatus," ICES-003 of the Canadian Department of Communications.

Europe (CE Declaration of Conformity)

This product has been tested in accordance to, and complies with the Low Voltage Directive (73/23/EEC) and EMC Directive (89/336/EEC). The product has been marked with the CE Mark to illustrate its compliance.

VCCI (Japan)

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

English translation of the preceding notice:

This is a Class A product based on the standard of the Voluntary Control Council for Interference (VCCI) from Information Technology Equipment. If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

BSMI (Taiwan)

警告使用者：
這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策

The BSMI Certification Marking and EMC warning is located on the outside rear area of the product.

Korean Compliance (RRL)

Following is the RRL certification information for Korea.



방송통신위원회

Regulated Specified Components

To maintain the UL listing and compliance to other regulatory certifications and/or declarations, the following regulated components must be used and conditions adhered to.

Interchanging or use of other components will void the UL listing and other product certifications and approvals. Updated product information for configurations can be found on the Intel Server Builder Web site at the following URL:

<http://channel.intel.com/go/serverbuilder>

If you do not have access to Intel's Web address, please contact your local Intel representative.

- **Server Chassis:** (base chassis is provided with power supply and fans) - UL listed.

Appendix A: Regulatory and Compliance Information

- **Server board:** you must use an Intel server board - UL recognized.
- **Add-in boards:** must have a printed wiring board flammability rating of minimum UL94V-1. Add-in boards containing external power connectors and/or lithium batteries must be UL recognized or UL listed. Any add-in board containing modem telecommunication circuitry must be UL listed. In addition, the modem must have the appropriate telecommunications, safety, and EMC approvals for the region in which it is sold.
- **Peripheral Storage Devices:** must be a UL recognized or UL listed accessory and TUV or VDE licensed. Maximum power rating of any one device is 19 watts. Total server configuration is not to exceed the maximum loading conditions of the power supply.

Restriction of Hazardous Substances (RoHS) Compliance

Intel has a system in place to restrict the use of banned substances in accordance with the European Directive 2002/95/EC. Compliance is based on declaration that materials banned in the RoHS Directive are either (1) below all applicable substance threshold limits or (2) an approved/pending RoHS exemption applies.

Note: *RoHS implementing details are not fully defined and may change.*

Threshold limits and banned substances are noted as follows:

- Quantity limit of 0.1% by mass (1000 PPM) for:
 - Lead
 - Mercury
 - Hexavalent chromium
 - Polybrominated biphenyls diphenyl ethers (PBDE)
- Quantity limit of 0.01% by mass (100 PPM) for:
 - Cadmium

End of Life/Product Recycling

Product recycling and end-of-life take back systems and requirements vary from country to country. Contact the retailer or distributor of this product for information on product recycling and/or take back.

Appendix B: Safety Information

English

Server Safety Information

This document applies to Intel® server boards, Intel® server chassis (pedestal and rackmount), and installed peripherals. To reduce the risk of bodily injury, electrical shock, fire, and equipment damage, read this document and observe all warnings and precautions in this guide before installing or maintaining your Intel® server product.







In the event of a conflict between the information in this document and information provided with the product or on the website for a particular product, the product documentation takes precedence.

Your server should be integrated and serviced only by technically qualified persons.

You must adhere to the guidelines in this guide and the assembly instructions in your server manuals to ensure and maintain compliance with existing product certifications and approvals. Use only the described, regulated components specified in this guide. Use of other products/components will void the UL Listing and other regulatory approvals of the product, and may result in noncompliance with product regulations in the region(s) in which the product is sold.

Safety Warnings and Cautions

To avoid personal injury or property damage, before you begin installing the product, read, observe, and adhere to all of the following safety instructions and information. The following safety symbols may be used throughout the documentation and may be marked on the product and/or the product packaging.

CAUTION	Indicates the presence of a hazard that may cause minor personal injury or property damage if the CAUTION is ignored.
WARNING	Indicates the presence of a hazard that may result in serious personal injury if the WARNING is ignored.
	Indicates potential hazard if indicated information is ignored.
	Indicates shock hazards that result in serious injury or death if safety instructions are not followed.
	Indicates hot components or surfaces.
	Indicates do not touch fan blades, may result in injury.
	Indicates to unplug all AC power cord(s) to disconnect AC power
	Please recycle battery

Intended Application Uses

This product was evaluated as Information Technology Equipment (ITE), which may be installed in offices, schools, computer rooms, and similar commercial type locations. The suitability of this product for other product categories and environments (such as medical, industrial, residential, alarm systems, and test equipment), other than an ITE application, may require further evaluation.

Site Selection

The system is designed to operate in a typical office environment. Choose a site that is:

- Clean, dry, and free of airborne particles (other than normal room dust).
- Well-ventilated and away from sources of heat including direct sunlight and radiators.
- Away from sources of vibration or physical shock.
- Isolated from strong electromagnetic fields produced by electrical devices.
- In regions susceptible to electrical storms, we recommend you plug your system into a surge suppressor and disconnect telecommunication lines to your modem during an electrical storm.
- Provided with a properly grounded wall outlet.
- Provided with sufficient space to access the power supply cord(s), because they serve as the product's main power disconnect.

Equipment Handling Practices

Reduce the risk of personal injury or equipment damage:

- Conform to local occupational health and safety requirements when moving and lifting equipment.
- Use mechanical assistance or other suitable assistance when moving and lifting equipment.
- To reduce the weight for easier handling, remove any easily detachable components.

Power and Electrical Warnings

Caution: The power button, indicated by the stand-by power marking, DOES NOT completely turn off the system AC power, 5V standby power is active whenever the system is plugged in. To remove power from system, you must unplug the AC power cord from the wall outlet. Your system may use more than one AC power cord. Make sure all AC power cords are unplugged. Make sure the AC power cord(s) is/are unplugged before you open the chassis, or add or remove any non hot-plug components.

Do not attempt to modify or use an AC power cord if it is not the exact type required. A separate AC cord is required for each system power supply.

Some power supplies in Intel® servers use Neutral Pole Fusing. To avoid risk of shock use caution when working with power supplies that use Neutral Pole Fusing.

The power supply in this product contains no user-serviceable parts. Do not open the power supply. Hazardous voltage, current and energy levels are present inside the power supply. Return to manufacturer for servicing. When replacing a hot-plug power supply, unplug the power cord to the power supply being replaced before removing it from the server.

To avoid risk of electric shock, turn off the server and disconnect the power cord, telecommunications systems, networks, and modems attached to the server before opening it.

Power Cord Warnings

If an AC power cord was not provided with your product, purchase one that is approved for use in your country.

Caution: To avoid electrical shock or fire, check the power cord(s) that will be used with the product as follows:

- Do not attempt to modify or use the AC power cord(s) if they are not the exact type required to fit into the grounded electrical outlets.
- The power cord(s) must meet the following criteria:
 - The power cord must have an electrical rating that is greater than that of the electrical current rating marked on the product.
 - The power cord must have safety ground pin or contact that is suitable for the electrical outlet.

- The power supply cord(s) is/are the main disconnect device to AC power. The socket outlet(s) must be near the equipment and readily accessible for disconnection.
- The power supply cord(s) must be plugged into socket-outlet(s) that is /are provided with a suitable earth ground.

System Access Warnings

Caution: To avoid personal injury or property damage, the following safety instructions apply whenever accessing the inside of the product:

- Turn off all peripheral devices connected to this product.
- Turn off the system by pressing the power button to off.
- Disconnect the AC power by unplugging all AC power cords from the system or wall outlet. Disconnect all cables and telecommunication lines that are connected to the system.
- Retain all screws or other fasteners when removing access cover(s). Upon completion of accessing inside the product, refasten access cover with original screws or fasteners.
- Do not access the inside of the power supply. There are no serviceable parts in the power supply. Return to manufacturer for servicing.
- Power down the server and disconnect all power cords before adding or replacing any non hot-plug component.
- When replacing a hot-plug power supply, unplug the power cord to the power supply being replaced before removing the power supply from the server.

Caution: If the server has been running, any installed processor(s) and heat sink(s) may be hot. Unless you are adding or removing a hot-plug component, allow the system to cool before opening the covers. To avoid the possibility of coming into contact with hot component(s) during a hot-plug installation, be careful when removing or installing the hot-plug component(s).

Caution: To avoid injury do not contact moving fan blades. If your system is supplied with a guard over the fan, do not operate the system without the fan guard in place.

Rack Mount Warnings

The equipment rack must be anchored to an unmovable support to prevent it from tipping when a server or piece of equipment is extended from it. The equipment rack must be installed according to the rack manufacturer's instructions.

Install equipment in the rack from the bottom up, with the heaviest equipment at the bottom of the rack.

Extend only one piece of equipment from the rack at a time.

You are responsible for installing a main power disconnect for the entire rack unit. This main disconnect must be readily accessible, and it must be labeled as controlling power to the entire unit, not just to the server(s). To avoid risk of potential electric shock, you must implement a proper safety ground for the rack and each piece of equipment installed in it.

Electrostatic Discharge (ESD)

Caution: ESD can damage disk drives, boards, and other parts. We recommend that you perform all procedures at an ESD workstation. If one is not available, provide some ESD protection by wearing an antistatic wrist strap attached to chassis ground -- any unpainted metal surface -- on your server when handling parts.

Always handle boards carefully. They can be extremely sensitive to ESD. Hold boards only by their edges. After removing a board from its protective wrapper or from the server, place the board component side up on a grounded, static free surface. Use a conductive foam pad if available but not the board wrapper. Do not slide board over any surface.

Other Hazards

Battery Replacement

Caution: There is the danger of explosion if the battery is incorrectly replaced. When replacing the battery, use only the battery recommended by the equipment manufacturer.

Dispose of batteries according to local ordinances and regulations.

Do not attempt to recharge a battery.

Do not attempt to disassemble, puncture, or otherwise damage a battery.

Cooling and Airflow

Caution: Carefully route cables as directed to minimize airflow blockage and cooling problems.

For proper cooling and airflow, operate the system only with the chassis covers installed. Operating the system without the covers in place can damage system parts. To install the covers:

- Check first to make sure you have not left loose tools or parts inside the system.
- Check that cables, add-in boards, and other components are properly installed.
- Attach the covers to the chassis according to the product instructions.

Laser Peripherals or Devices

Caution: To avoid risk of radiation exposure and/or personal injury:

- Do not open the enclosure of any laser peripheral or device.
- Laser peripherals or devices are not user serviceable.
- Return to manufacturer for servicing.

Deutsch

Sicherheitshinweise für den Server

Das vorliegende Dokument bezieht sich auf Intel® Serverplatinen, Intel® Servergehäuse (Standfuß und Rack) sowie installierte Peripheriegeräte. Es enthält Warnungen und Vorsichtsmaßnahmen zur Vermeidung von Gefahren durch Verletzung, Stromschlag, Feuer und Beschädigungen von Geräten. Lesen Sie diese Dokument daher sorgfältig, bevor Sie Ihr Intel® Serverprodukt installieren oder warten.







Bei Widersprüchen zwischen den hier vorliegenden Angaben und den Informationen im Lieferumfang des Produkts oder auf der Website des betreffenden Produkts hat die Produktdokumentation Vorrang.

Die Integration und Wartung des Servers darf nur durch technisch qualifizierte Personen erfolgen.

Um die Einhaltung der vorhandenen Zulassungen und Genehmigungen für das Produkt zu gewährleisten, sind die Richtlinien in diesem Handbuch sowie die Montageanleitungen in den Serverhandbüchern zu beachten. Verwenden Sie nur die beschriebenen, zugelassenen Komponenten, die im vorliegenden Handbuch angegeben werden. Die Verwendung anderer Produkte oder Komponenten führt zum Erlöschen der UL-Zulassung und anderer Genehmigungen für das Produkt. Dadurch kann das Produkt gegen Produktbestimmungen verstoßen, die im Verkaufsland gelten.

Sicherheitshinweise und Vorsichtsmaßnahmen

Um Verletzungen und Beschädigungen zu vermeiden, sollten Sie vor dem Beginn der Produktinstallation die nachfolgend aufgeführten Sicherheitshinweise und –informationen sorgfältig lesen und befolgen. In dem vorliegenden Handbuch sowie auf dem Produkt und auf der Verpackung werden folgende Sicherheitssymbole verwendet:

VORSICHT	Weist auf eine Gefahrenquelle hin, die bei Nichtbeachtung des VORSICHTSHINWEISES zu leichteren Verletzungen bzw. Sachbeschädigungen führen kann.
WARNUNG	Weist auf eine Gefahrenquelle hin, die bei Nichtbeachtung der WARNUNG zu ernststen Verletzungen führen kann.
	Weist auf potentielle Gefahr bei Nichtbeachtung der angezeigten Informationen hin.
	Weist auf die Gefahr eines Stromschlags hin, der bei Nichtbeachtung der Sicherheitshinweise zu schweren oder tödlichen Verletzungen führen kann.
	Weist auf Verbrennungsgefahr an heißen Bauteilen bzw. Oberflächen hin.
	Weist darauf hin, daß das Anfassen des Gebläses zu Verletzungen führen kann.
	Bedeutet, alle Netzkabel abzuziehen und das Gerät von der Netzspannung zu trennen.
	Bereiten Sie bitte Batterie auf.

Zielbenutzer der Anwendung

Dieses Produkt wurde in seiner Eigenschaft als IT-Gerät getestet, das in Büros, Schulen, Computerräumen und ähnlichen öffentlichen Räumlichkeiten installiert werden kann. Die Eignung dieses Produkts für andere Einsatzbereiche als IT (z. B. Medizin, Industrie, Alarmsysteme oder Prüfgeräte) kann u. U. weitere Tests erfordern.

Standortauswahl

Das System ist für den Betrieb innerhalb normaler Büroumgebungen geeignet. Wählen Sie einen Standort, der folgenden Kriterien entspricht:

- Sauber, trocken und frei von Partikeln in der Luft (außer dem normalen Raumstaub).
- Gut belüftet, nicht in der Nähe von Wärmequellen und keiner direkten Sonnenbestrahlung ausgesetzt.
- Nicht in der Nähe von Vibrations- oder Erschütterungsquellen.
- Abgeschirmt von starken elektromagnetischen Feldern, die durch elektrische Geräte erzeugt werden.
- In gewittergefährdeten Gebieten sollten Sie das System an einen Überspannungsschutz anschließen und bei einem Gewitter die Telekommunikationskabel zum Modem abziehen.
- Eine ordnungsgemäß geerdete Wandsteckdose muß vorhanden sein.
- Ausreichender Freiraum für den Zugang zu den Netzkabeln, da diese die Hauptvorrichtung zum Trennen des Produkts von der Stromversorgung sind.

Handhabung von Geräten

Beachten Sie zur Vermeidung von Verletzungen oder Beschädigungen an den Geräten die folgenden Hinweise:

- Halten Sie beim Transportieren und Anheben von Geräten die örtlichen Gesundheits- und Sicherheitsvorschriften ein.
- Verwenden Sie mechanische oder andere geeignete Hilfsmittel zum Transportieren oder Anheben von Geräten.
- Entfernen Sie alle Komponenten, die sich leicht abnehmen lassen, um das Gewicht zu reduzieren und die Handhabung zu erleichtern.

Warnungen zu Netzspannung und Elektrizität

Vorsicht: *Durch Betätigen der mit dem Standby-Symbol gekennzeichneten Netztaaste wird das System NICHT vollständig vom Netz getrennt. Es sind weiterhin 5 V aktiv, solange das System eingesteckt ist. Um das System vollständig vom Strom zu trennen, muß das Netzkabel aus der Steckdose abgezogen werden. Das System verfügt möglicherweise über mehrere Netzkabel. Vergewissern Sie sich in diesem Fall, daß alle Netzkabel abgezogen sind. Wenn Sie Komponenten ein- oder ausbauen möchten, die nicht hot-plug-fähig sind, stellen Sie sicher, daß zuvor alle Netzkabel abgezogen sind.*

Nehmen Sie keine Änderungen am Netzkabel vor, und verwenden Sie kein Kabel, das nicht genau dem geforderten Typ entspricht. Jedes Netzteil im System muß über ein eigenes Netzkabel angeschlossen werden.

Einige Netzteile von Intel Servern verwenden Nulleitersicherungen. Vorsicht ist geboten im Umgang mit Netzteilen, welche Nulleitersicherungen verwenden, um das Risiko eines elektrischen Schlages zu vermeiden

Das Netzteil in diesem Produkt enthält keine Teile, die vom Benutzer gewartet werden können. Öffnen Sie das Netzteil nicht. Im Netzteil bestehen gefährliche Spannungen, Ströme und Energiequellen. Schicken Sie das Gerät für Wartungsarbeiten an den Hersteller zurück.

Wenn Sie ein hot-plug-fähiges Netzteil austauschen, ziehen Sie dessen Netzkabel ab, bevor Sie es aus dem Server ausbauen.

Zur Vermeidung von Stromschlägen schalten Sie den Server aus, und trennen Sie vor dem Öffnen des Geräts das Netzkabel sowie alle an den Server angeschlossene Telekommunikationssysteme, Netzwerke und Modems.

Hinweis für Netzkabel

Wenn kein Netzkabel mit dem Produkt geliefert wurde, kaufen Sie ein Kabel, das für die

Vorsicht: Prüfen Sie zur Vermeidung von Stromschlag- oder Feuergefahr die mit dem Produkt zu verwendenden Netzkabel wie folgt:

- Nehmen Sie keine Änderungen an einem Netzkabel vor, und benutzen sie es nicht, wenn es nicht genau in die geerdeten Netzsteckdosen paßt.
- Netzkabel müssen die folgenden Anforderungen erfüllen:
- Die Nennbelastbarkeit des Netzkabels muß mindestens so hoch sein wie die am Produkt angegebenen Nennstromaufnahme.
- Das Netzkabel muß einen zur Netzsteckdose passenden Schutzkontakt besitzen.
- Die Netzkabel sind die Hauptvorrichtung zum Trennen des Geräts vom Stromnetz.
- Die Steckdose muß in der Nähe der Anlage angebracht und gut erreichbar sein.
- Netzkabel müssen an eine ordnungsgemäß geerdete Steckdose angeschlossen sein.

Warnhinweise für den Systemzugang

Vorsicht: Um Verletzungen und Beschädigungen zu vermeiden, sollten Sie vor Arbeiten im Produktinneren folgende Sicherheitsanweisungen beachten:

- Schalten Sie alle am Produkt angeschlossenen Peripheriegeräte aus.
- Schalten Sie das System mit dem Netzschalter aus.
- Trennen Sie das Gerät von der Stromquelle, indem Sie alle Netzkabel vom System bzw. aus der Steckdose ziehen.
- Ziehen Sie alle Kabel und alle an das System angeschlossenen Telekommunikationsleitungen ab.
- Bewahren Sie alle Schrauben und anderen Befestigungselemente gut auf, nachdem Sie die Gehäuseabdeckung entfernt haben. Wenn Sie Ihre Arbeiten im Systeminneren beendet haben, befestigen Sie die Gehäuseabdeckung mit den Originalschrauben bzw.-befestigungselementen.
- Führen Sie keine Arbeiten im Netzteil aus. Das Netzteil enthält keine für den Benutzer wartungsbedürftigen Teile. Schicken Sie das Gerät für Wartungsarbeiten an den Hersteller zurück.
- Schalten Sie den Server aus, und ziehen Sie alle Netzkabel ab, bevor Sie Komponenten ein- oder ausbauen, die nicht hot-plug-fähig sind.
- Wenn Sie ein hot-plug-fähiges Netzteil austauschen, ziehen Sie dessen Netzkabel ab, bevor Sie es aus dem Server ausbauen.

Vorsicht: War Ihr Server in Betrieb, können die installierten Prozessoren und Kühlkörper heiß sein. Sofern Sie keine Hot-Plug-Komponenten ein- oder ausbauen, warten Sie mit dem Abnehmen der Abdeckungen, bis das System abgekühlt ist. Gehen Sie beim Aus- oder Einbauen von Hot-Plug-Komponenten sorgfältig vor, um nicht mit heißen Komponenten in Berührung zu kommen.

Vorsicht: Berühren Sie nicht die rotierenden Lüfterflügel, um Verletzungen zu vermeiden. Falls Ihr System mit eine Lüfterabdeckung besitzt, darf es nicht ohne diese Abdeckung betrieben werden.

Warnhinweise für Racks

Das Geräte-Rack muß auf einer geeigneten, festen Unterlage verankert werden, um ein Umkippen zu vermeiden, wenn ein Server oder andere Geräte herausgezogen werden. Bei der Installation des Racks müssen die Anweisungen des Rack-Herstellers beachtet werden.

Gehen Sie bei der Installation von Geräten im Rack immer von unten nach oben vor, und bauen Sie das schwerste Gerät an der untersten Position im Rack ein. Ziehen Sie jeweils immer nur ein Gerät aus dem Rack heraus.

Sie müssen für die gesamte Rack-Einheit einen Netztrennschalter einrichten. Dieser Netztrennschalter muß leicht zugänglich sein und über eine Kennzeichnung verfügen, die besagt, daß er die Stromzufuhr zur gesamten Einheit steuert und nicht nur zu den Servern.

Zur Vermeidung von Stromschlaggefahr müssen das Rack selbst und alle darin eingebauten Geräte ordnungsgemäß geerdet sein.

Elektrostatische Entladungen (ESD)

Vorsicht: Elektrostatische Entladungen können zur Beschädigung von Festplatten, Platinen und anderen Komponenten führen. Daher sollten Sie alle Arbeiten an einer ESD-Workstation ausführen. Steht ein solcher

Appendix B: Safety Information

Arbeitsplatz nicht zur Verfügung, erzielen Sie einen gewissen Schutz vor elektrostatischen Entladungen durch Tragen einer Antistatik-Manschette, die Sie während der Arbeit zur Erdung an einem beliebigen unlackierten Metallteil des Computergehäuses befestigen.

Gehen Sie bei der Handhabung von Platinen immer mit größter Vorsicht vor. Sie können äußerst empfindlich gegenüber elektrostatischer Entladung sein. Halten Sie Platinen nur an den Kanten fest. Legen Sie die Platinen nach dem Auspacken aus der Schutzhülle oder nach dem Ausbau aus dem Server mit der Bauelementseite nach oben auf eine geerdete, statisch entladene Unterlage. Verwenden Sie dazu, sofern verfügbar, eine leitfähige Schaumstoffunterlage, aber nicht die Schutzhülle der Platine. Ziehen Sie die Platine nicht über eine Fläche.

Andere Gefahren

Batterieaustausch

Vorsicht: Wird die Batterie unsachgemäß ausgetauscht, besteht Explosionsgefahr. Verwenden Sie als Ersatz nur die vom Gerätehersteller empfohlene Batterie.

Beachten Sie bei der Entsorgung von Batterien die gültigen Bestimmungen.

Versuchen Sie nicht, eine Batterie aufzuladen.

Versuchen Sie nicht, eine Batterie zu öffnen oder sonstwie zu beschädigen.

Kühlung und Luftstrom

Vorsicht: Verlegen Sie Kabel sorgfältig entsprechend der Anleitung, um Störungen des Luftstroms und Kühlungsprobleme zu vermeiden.

Zur Gewährleistung des ordnungsgemäßen Kühlungs- und Luftstromverhaltens darf das System nur mit angebrachten Gehäuseabdeckungen betrieben werden. Die Inbetriebnahme des Systems ohne Abdeckung kann zur Beschädigung von Systemkomponenten führen. So bringen Sie die Abdeckung wieder an:

- Vergewissern Sie sich zunächst, daß Sie keine Werkzeuge oder Teile im Gehäuse vergessen haben.
- Prüfen Sie, ob Kabel, Erweiterungskarten sowie weitere Komponenten ordnungsgemäß angebracht sind.
- Befestigen Sie die Abdeckungen am Gehäuse des Produkts, wie in dessen Anleitung beschrieben.

Laser-Peripheriegeräte oder -Komponenten

Vorsicht: Beachten Sie zur Vermeidung von Strahlung und Verletzungen die folgenden Hinweise:

- Öffnen Sie keinesfalls das Gehäuse von Laser-Peripheriegeräten oder Laser-Komponenten.
- Laser-Peripheriegeräte oder -Komponenten besitzen keine für den Benutzer wartungsbedürftigen Teile.
- Schicken Sie das Gerät für Wartungsarbeiten an den Hersteller zurück.

Français

Consignes de sécurité sur le serveur

Ce document s'applique aux cartes serveur Intel[®], au châssis de serveur Intel[®] (sur pieds et sur rack) et aux périphériques installés. Pour réduire les risques de dommages corporels, d'électrocution, d'incendie et de dommages matériels, lisez ce document et respectez tous les avertissements et précautions mentionnés dans ce guide avant d'installer ou de mettre à jour votre produit serveur Intel[®].







En cas de conflit entre les informations fournies dans ce document et celles livrées avec le produit ou publiées sur le site Web pour un produit particulier, la documentation du produit prime.

Votre serveur doit être intégré et entretenu uniquement par des techniciens qualifiés.

Vous devez suivre les informations de ce guide et les instructions d'assemblage des manuels de serveur pour vérifier et maintenir la conformité avec les certifications et approbations de produit existantes. Utilisez uniquement les composants décrits et réglementés spécifiés dans ce guide. L'utilisation d'autres produits/composants annulera la liste UL et les autres approbations réglementaires du produit, et le produit peut ne pas être conforme aux autres lois et réglementations locales applicables au produit.

Sécurité: avertissements et mises en garde

Pour éviter de vous blesser ou d'endommager votre équipement, lisez et respectez toutes les informations et consignes de sécurité avant de commencer l'installation du produit. Les symboles de sécurité suivants peuvent être utilisés tout au long de cette documentation et peuvent figurer sur le produit ou sur son emballage.

ATTENTION	Indique la présence d'un risque pouvant entraîner des blessures physiques mineures ou endommager légèrement le matériel si la mise en garde n'est pas prise en compte.
AVERTISSEMENT	Indique la présence d'un risque pouvant entraîner des blessures corporelles graves si l'avertissement n'est pas pris en compte.
	Indique un risque potentiel si les informations signalées ne sont pas prises en compte.
	Indique des risques d'électrocution pouvant entraîner des blessures corporelles graves ou mortelles si les consignes de sécurité ne sont pas respectées.
	Signale des composants ou des surfaces soumis à des températures élevées.
	Indique de ne pas toucher aux pales de ventilateur, car cela peut entraîner des blessures.
	Indique de débrancher tous les cordons d'alimentation secteur pour déconnecter l'alimentation.
	Veuillez réutiliser la batterie

Domaines d'utilisation prévus

Ce produit a été testé comme équipement informatique (ITE) et peut être installé dans des bureaux, des écoles, des salles informatiques et des endroits commerciaux similaires. L'utilisation du présent produit dans des catégories et environnements de produits et domaines d'application (par exemple, le domaine médical, industriel, résidentiel, les systèmes d'alarme et les appareils de contrôle) autres qu'ITE doit faire l'objet d'évaluations supplémentaires.

Sélection d'un emplacement

Le système est conçu pour fonctionner dans un environnement standard de bureau. Choisissez un emplacement respectant les conditions suivantes:

- Propre, sec et exempt de particules en suspension (autres que la poussière normale d'une pièce).
- Bien ventilé et à l'écart des sources de chaleur telles que la lumière directe du soleil et les radiateurs.
- À l'écart des sources de vibration ou des chocs physiques.
- Isolé des champs électromagnétiques importants produits par des appareils électriques.
- Dans les régions sujettes aux orages magnétiques, nous vous recommandons de brancher votre système à un suppresseur de surtension et de déconnecter les lignes de télécommunication de votre modem pendant les orages.
- Équipé d'une prise murale reliée à la terre.
- Équipé d'un espace suffisant pour accéder aux cordons d'alimentation secteur, car ils servent de disjoncteur principal d'alimentation du produit.

Pratiques de manipulation de l'équipement

Réduisez le risque de dommages personnels ou matériels :

- Conformez-vous aux exigences de médecine du travail et de sécurité lorsque vous déplacez et soulevez le matériel.
- Utilisez l'assistance mécanique ou toute autre assistance appropriée lorsque vous déplacez et soulevez le matériel.
- Pour réduire le poids en vue de faciliter la manipulation, retirez tout composant amovible.

Alimentation et avertissements en matière d'électricité

Attention: Le bouton d'alimentation, indiqué par le symbole de mise en veille, NE COUPE PAS complètement l'alimentation secteur du système car le courant de veille 5 V reste actif lorsque le système est sous tension. Pour couper l'alimentation du système, vous devez débrancher le cordon d'alimentation secteur de la prise murale. Votre système peut utiliser plusieurs cordons d'alimentation secteur. Assurez-vous que tous les cordons d'alimentation sont débranchés. Vous devez les débrancher avant d'ouvrir le châssis, d'ajouter ou de supprimer un composant non connectable à chaud.

Les alimentations de certains serveurs Intel sont munies de doubles fusibles pôle/neutre: veuillez observer les précautions d'usage afin d'éviter tout risque d'électrocution.

N'essayez pas de modifier ou d'utiliser un cordon d'alimentation secteur s'il ne s'agit pas du type exact requis. Un cordon secteur est requis pour chaque alimentation système.

Le bloc d'alimentation de ce produit ne contient aucun composant réparable par l'utilisateur. N'ouvrez pas le bloc d'alimentation. L'intérieur de celui-ci est soumis à des niveaux dangereux de tension, de courant et d'énergie. Renvoyez-le au fabricant en cas de problème.

Lorsque vous remplacez un bloc d'alimentation à chaud, débranchez le cordon du bloc d'alimentation en cours de remplacement avant de le retirer du serveur.

Pour éviter tout risque d'électrocution, mettez le système hors tension et débranchez les cordons d'alimentation ainsi que les systèmes de télécommunication, réseaux et modems reliés au système avant d'ouvrir ce dernier.

Avertissements sur le cordon d'alimentation

Si aucun cordon d'alimentation secteur n'a été fourni avec votre produit, vous devez vous en procurer un qui soit approuvé pour une utilisation dans votre pays.

Attention: Pour éviter tout risque d'électrocution ou d'incendie, vérifiez les cordons d'alimentation qui seront utilisés avec le produit comme suit:

- N'essayez pas d'utiliser ou de modifier les cordons d'alimentation en CA s'ils ne correspondent pas exactement au type requis pour les prises électriques reliées à la terre.
- Les cordons d'alimentation doivent répondre aux critères suivants:
- Le cordon d'alimentation doit supporter une intensité supérieure à celle indiquée sur le produit.
- Le cordon d'alimentation doit posséder une broche ou un contact de mise à la terre approprié à la prise électrique.
- Les cordons d'alimentation électrique représentent le principal dispositif de déconnexion raccordé à l'alimentation secteur. Les prises de courant doivent se trouver à proximité de l'équipement et être facilement accessibles pour une déconnexion.
- Les cordons d'alimentation doivent être branchés sur des prises électriques correctement reliées à la terre.

Avertissements sur l'accès au système

Attention: Pour éviter de vous blesser ou d'endommager votre équipement, les consignes de sécurité suivantes s'appliquent chaque fois que vous accédez à l'intérieur du produit:

- Mettez hors tension tous les périphériques connectés à ce produit.
- Éteignez le système en appuyant sur le bouton d'alimentation.
- Déconnectez l'alimentation secteur en débranchant tous les cordons d'alimentation secteur du système ou de la prise murale.
- Déconnectez l'ensemble des câbles et lignes de télécommunication qui sont connectés au système.
- Mettez toutes les vis ou autres attaches de côté lorsque vous retirez les panneaux d'accès. Une fois que vous avez terminé d'accéder à l'intérieur du produit, refixez le panneau d'accès avec les vis ou attaches d'origine.
- N'essayez pas d'accéder à l'intérieur du bloc d'alimentation. Il ne contient aucune pièce réparable. Renvoyez-le au fabricant en cas de problème.
- Mettez le serveur hors tension et débranchez tous les cordons d'alimentation avant d'ajouter ou de remplacer tout composant non connectable à chaud.
- Lorsque vous remplacez le bloc d'alimentation à chaud, débranchez le cordon du bloc d'alimentation en cours de remplacement avant de retirer le bloc du serveur.

Attention: Si le serveur a été utilisé, les processeurs et dissipateurs de chaleur installés peuvent être chauds. À moins que vous n'ajoutiez ou ne retiriez un composant connectable à chaud, laissez le système refroidir avant d'ouvrir les panneaux. Pour éviter tout risque d'entrer en contact avec un composant chaud lors d'une installation à chaud, prenez toutes les précautions nécessaires lorsque vous retirez ou installez des composants connectables à chaud.

Attention: Pour éviter de vous blesser, ne touchez pas les pales de ventilateur en mouvement. Si votre système est fourni avec une protection sur le ventilateur, ne mettez pas le système en route sans la protection en place.

Avertissements sur le montage en rack

Le rack doit être fixé à un support inamovible pour éviter qu'il ne bascule lors de l'extension d'un serveur ou d'un élément de l'équipement. Le rack doit être installé conformément aux instructions du fabricant.

Installez les équipements dans le rack en partant du bas, en plaçant le plus lourd en bas du rack.

N'étendez qu'un seul élément de l'équipement à partir du rack à la fois.

Vous êtes responsable de l'installation d'un disjoncteur principal d'alimentation pour la totalité du rack. Ce disjoncteur principal doit être rapidement accessible et doit être étiqueté comme contrôlant toute l'unité, et pas uniquement le ou les serveurs.

Appendix B: Safety Information

Pour éviter tout risque d'électrocution, le rack et chaque élément de l'équipement installé dans le rack doivent être correctement reliés à la terre.

Décharges électrostatiques (ESD)

Attention: Les décharges électrostatiques (ESD) peuvent endommager les lecteurs de disque dur, les cartes et d'autres pièces. Il est fortement conseillé d'effectuer l'ensemble des procédures décrites à un poste de travail protégé contre les ESD. Au cas où aucun poste de ce type ne serait disponible, protégez-vous contre les ESD en portant un bracelet antistatique relié à la masse du châssis (n'importe quelle surface métallique non peinte) de votre serveur lorsque que vous manipulez les pièces.

Manipulez toujours les cartes avec précaution. Elles peuvent être extrêmement sensibles aux ESD. Ne tenez les cartes que par leurs bords. Après avoir retiré une carte de son emballage de protection ou du serveur, placez-la sur une surface reliée à la terre, exempte de charge statique, composants orientés vers le haut. Utilisez si possible un tapi de mousse conducteru, mais pas l'emballage de la carte. Veillez à ce que la carte ne glisse sur aucune surface.

Autres risques

Remplacement de la pile

Attention: Il existe un risque d'explosion si la pile n'est pas correctement remplacée. Lors du remplacement de la pile, utilisez uniquement celle recommandée par le fabricant du matériel.

Mettez la pile au rebut en vous conformant aux réglementations locales.

N'essayez pas de recharger une pile.

N'essayez pas de démonter, de percer ou d'endommager la pile d'une quelconque façon.

Refroidissement et ventilation

Attention: Routez les câbles avec précaution comme indiqué pour minimiser les blocages de circulation d'air et les problèmes de refroidissement.

Afin de permettre une ventilation et un refroidissement corrects, ne mettez le système en marche que lorsque les panneaux du châssis sont en place. L'utilisation du système sans les panneaux peut endommager les composants système. Pour installer les panneaux :

- Vérifiez tout d'abord que vous n'avez pas oublié d'outils ou de composants détachés à l'intérieur du système.
- Vérifiez que les câbles, les cartes d'extension et les autres composants sont correctement installés.
- Fixez les panneaux au châssis en suivant les instructions du produit.

Périphériques laser

Attention: Pour éviter tout risque d'exposition aux rayonnements et/ou de dommage personnel:

- N'ouvrez pas l'enceinte d'un périphérique laser.
- Les périphériques laser ne sont pas réparables par l'utilisateur.
- Retournez-les au fabricant en cas de problème.

Español

Información de seguridad del servidor

Este documento se aplica a las tarjetas de servidor de Intel®, las carcasas de servidor de Intel® (montaje en bastidor y en pedestal) y los dispositivos periféricos. Para reducir el riesgo de daños corporales, descargas eléctricas, fuego y en el equipo, lea este documento y preste atención a todos las advertencias y precauciones de esta guía antes de instalar o mantener el producto de servidor de Intel®.







En el caso de que haya diferencias entre la información para un producto en particular contenida en este documento y la información proporcionada con dicho producto o en el sitio Web, la documentación del producto es la que prevalece.

Sólo personal técnico cualificado debe montar y prestar los servicios para el servidor.

Debe ceñirse a las directrices de esta guía y a las instrucciones de montaje de los manuales del servidor para asegurar y mantener el cumplimiento con las certificaciones y homologaciones existentes de los productos. Utilice sólo los componentes descritos y homologados que se especifican en esta guía. El uso de otros productos o componentes anulará la homologación UL y otras certificaciones oficiales del producto, pudiendo dejar de ser compatible con las normativas locales de los países en los que se comercializa.

Advertencias y precauciones sobre seguridad

Para reducir la posibilidad de que se produzcan lesiones personales o daños en la propiedad, antes de empezar a instalar el producto, lea, observe y cumpla toda la información e instrucciones de seguridad siguientes. Puede que se utilicen los siguientes símbolos de seguridad en la documentación y es posible que aparezcan en el producto o en su embalaje.

PRECAUCIÓN	Indica la existencia de un riesgo que podría causar lesiones personales o daños en la propiedad leves si no se tiene en cuenta la PRECAUCIÓN.
ADVERTENCIA	Indica la existencia de un riesgo que podría causar lesiones personales graves si no se tiene en cuenta la ADVERTENCIA.
	Indica un riesgo potencial si no se tiene en cuenta la información indicada.
	Indica riesgo de descargas eléctricas que podrían causar lesiones graves o la muerte si no se siguen las instrucciones de seguridad.
	Indica componentes o superficies calientes.
	Indica que no se deben tocar las aspas de los ventiladores, ya que de lo contrario se podrían producir lesiones.
	Indica que es necesario desenchufar los cables de alimentación de CA para desconectar la alimentación de CA
	Recicle por favor la batería

Aplicaciones y usos previstos

Este producto ha sido evaluado como equipo de tecnología informática (ITE) que puede instalarse en oficinas, escuelas, salas de equipos informáticos o lugares de ámbito comercial similares. Es posible que sea necesario llevar a cabo una evaluación adicional para comprobar si este producto es apropiado para otras categorías de productos y entornos además de las aplicaciones informáticas (por ejemplo, soluciones médicas, industriales, residenciales, sistemas de alarma y equipos de pruebas).

Selección de la ubicación

El sistema se ha diseñado para funcionar en un entorno normal de oficinas. Seleccione una ubicación que esté:

- Limpia, seca y libre de macropartículas en suspensión en el aire (que no sean el polvo habitual de la habitación).
- Bien ventilada y alejada de fuentes de calor, incluida la luz solar directa y los radiadores.
- Alejada de fuentes de vibración o de golpes físicos.
- Aislada de campos electromagnéticos producidos por dispositivos eléctricos.
- En zonas propensas a tormentas eléctricas, se recomienda que conecte el servidor a un supresor de sobretensiones y desconecte las líneas de telecomunicaciones al módem durante una tormenta eléctrica.
- Provista de una toma de corriente alterna correctamente conectada a tierra.
- Provista de espacio suficiente para acceder a los cables de la fuente de alimentación ya que constituyen la desconexión principal de la alimentación.

Manipulación del equipo

Reduzca el riesgo de daños personales o en el equipo:

- Respete los requisitos de sanidad y seguridad laborales de su país cuando traslade y levante el equipo.
- Utilice medios mecánicos u otros que sean adecuados al trasladar o levantar el equipo.
- Para que el peso sea menor para manipularlo con más facilidad, extraiga los componentes que sean de fácil extracción.

Advertencias de alimentación y eléctricas

Precaución: El botón de encendido, indicado con la marca del modo de reposo o stand-by, NO DESCONECTA completamente la alimentación de CA del sistema, ya que el modo de reposo de 5 V sigue activo mientras el sistema está enchufado. Para desconectar el sistema debe desenchufar el cable de alimentación de CA de la toma de la pared. Puede usar más de un cable de alimentación de CA con el sistema. Asegúrese de que todos los cables de alimentación de CA están desenchufados. Asegúrese de que los cables de alimentación de CA estén desenchufado antes de abrir la carcasa, agregar o extraer cualquier componente que no es de conexión en funcionamiento.

Algunas fuentes de alimentación de electricidad de los servidores de Intel utilizan el polo neutral del fuselaje. Para evitar riesgos de choques eléctricos use precauciones al trabajar con las fuentes de alimentación que utilizan el polo neutral de fuselaje.

No intente modificar ni utilizar un cable de alimentación de CA si no es del tipo exacto requerido. Se necesita un cable de CA para cada fuente de alimentación del sistema.

La fuente de alimentación de este producto no contiene piezas que puedan ser reparadas por el usuario. No abra la fuente de alimentación. Dentro de la fuente de alimentación puede haber niveles de tensión, corriente y energía peligrosos. Devuélvala al fabricante para repararla.

Al reemplazar una fuente de alimentación de conexión en funcionamiento, desenchufe el cable de alimentación de la fuente de alimentación que va a reemplazar antes de extraerla del servidor.

Para evitar el riesgo de descargas eléctricas, antes de abrir el servidor, apáguelo, desconecte el cable de alimentación, los sistemas de telecomunicaciones, las redes y los módems conectados al mismo.

Advertencias sobre el cable de alimentación

Si no se ha proporcionado con el producto ningún cable de alimentación de CA, adquiera alguno cuyo uso esté aprobado en su país.

Precaución: Para evitar descargas eléctricas o fuego, revise los cables de alimentación que usará con el producto tal y como se describe a continuación:

- No intente modificar ni utilizar los cables de alimentación de CA si no son exactamente del modelo especificado para ajustarse a las tomas de corriente conectadas a tierra
- Los cables de alimentación deben reunir los siguientes requisitos:
- El cable de alimentación debe disponer de una capacidad nominal de corriente eléctrica mayor que la capacidad especificada en el producto.
- El cable de alimentación debe disponer de una patilla o contacto de conexión a tierra que sea apto para la toma de corriente.
- Los cables de la fuente de alimentación son los dispositivos de desconexión principales a la corriente alterna. El enchufe o enchufes de zócalo deben encontrarse cerca del equipo y el acceso a ellos debe poderse efectuar de forma inmediata con el fin de desconectarlos.
- Los cables de la fuente de alimentación deben estar conectados a los enchufes con una toma de tierra adecuada.

Advertencias el acceso al sistema

Precaución: Para evitar lesiones personales o daños en la propiedad, se aplican las siguientes instrucciones de seguridad siempre que se acceda al interior del producto:

- Apague todos los dispositivos periféricos conectados a este producto.
- Pulse el botón de alimentación para apagar el sistema.
- Desconecte la alimentación de CA desenchufando los cables de alimentación de CA del sistema o de la toma de corriente alterna.
- Desconecte todos los cables y líneas de telecomunicación que estén conectados al sistema.
- Guarde todos los tornillos o elementos de fijación cuando retire las cubiertas de acceso. Cuando termine de operar en el interior del producto, vuelva a colocar los tornillos o los elementos de fijación originales de la cubierta de acceso.
- No acceda al interior de la fuente de alimentación. No hay elementos en la fuente de alimentación que usted pueda reparar y utilizar. Devuélvala al fabricante para repararla.
- Apague el servidor y desconecte todos los cables de alimentación antes de agregar o reemplazar cualquier componente que no es de conexión en funcionamiento.
- Al reemplazar una fuente de alimentación de conexión en funcionamiento, desenchufe el cable de alimentación de la fuente de alimentación que va a reemplazar antes de extraerla del servidor.

Precaución: Si el servidor se ha estado ejecutando, los procesadores y disipadores de calor estarán recalentados. A no ser que esté instalando o extrayendo un componente de conexión en funcionamiento, deje que el sistema se enfríe antes de abrir las cubiertas. Para que no llegue a tocar los componentes que estén calientes cuando esté realizando una instalación de conexión en funcionamiento, tenga cuidado al extraer o instalar los componentes de conexión en funcionamiento.

Precaución: Para evitar posibles daños, no toque las aspas en movimiento de los ventiladores. Si el sistema se le ha suministrado con una protección para el ventilador, asegúrese de que cuando esté funcionando el sistema la protección esté en su sitio.

Advertencias sobre el montaje en bastidor

El bastidor del equipo se debe sujetar con un soporte fijo para evitar que se caiga cuando se extraiga un servidor o una pieza del mismo. El bastidor del equipo debe instalarse siguiendo las instrucciones del fabricante del bastidor.

Instale el equipo en el bastidor comenzando desde la parte de abajo, con el equipo más pesado en la parte inferior del bastidor.

Extraiga las piezas del equipo del bastidor de una a una.

Appendix B: Safety Information

El usuario es el responsable de la instalación de un dispositivo de desconexión de la alimentación principal para toda la unidad del bastidor. El acceso a este dispositivo de desconexión deberá ser de fácil acceso y deberán incluirse indicaciones que lo identifiquen como el control de alimentación eléctrica de toda la unidad, no sólo de los servidores.

Para evitar el riesgo de descargas eléctricas, deberá instalar una conexión a tierra apropiada para el bastidor y para cada pieza del equipo instalada en el mismo.

Descarga electrostática (ESD)

Precaución: Las descargas electrostáticas pueden dañar las unidades de disco, las tarjetas y otros componentes. Recomendamos que realice todos los procedimientos en una estación de trabajo protegida contra descargas electrostáticas. En caso de que no haya una disponible, protéjase de alguna forma contra las descargas llevando un brazalete antiestático conectado a la toma de tierra de la carcasa (cualquier superficie de metal que no esté pintada) del servidor cuando manipule las piezas.

Manipule siempre las tarjetas con el máximo cuidado. Pueden ser sumamente sensibles a las descargas electrostáticas. Sujételas sólo por los bordes. Una vez extraída la tarjeta de su envoltorio de protección o del servidor, colóquela con el lado de los componentes hacia arriba sobre una superficie con toma de tierra y sin carga estática. Utilice una almohadilla de espuma conductora si dispone de ella, pero nunca el envoltorio de la tarjeta. No deslice la tarjeta sobre ninguna superficie.

Sustitución de la batería

Precaución: Existe el peligro de explosión si la batería no se reemplaza correctamente. Al reemplazar la batería, utilice sólo la batería recomendada por el fabricante del equipo.

Deseche las baterías respetando la normativa local.

No intente recargar la batería.

No intente desmontar, pinchar o causar cualquier otro desperfecto a una batería.

Enfriamiento y circulación de aire

Precaución: El tendido de los cables debe realizarse cuidadosamente tal y como se le indica para reducir al mínimo los problemas de obstrucción de la ventilación y de refrigeración.

Para conseguir una refrigeración y corriente de aire adecuadas, compruebe que cuando sistema esté funcionando, las cubiertas de la carcasa están instaladas. Si utiliza el sistema sin las cubiertas, podría dañar sus componentes. Para instalar las cubiertas:

- Compruebe primero que no ha dejado herramientas o piezas sueltas dentro del sistema.
- Compruebe que los cables, tarjetas adicionales y otros componentes están instalados correctamente.
- Sujete las cubiertas a la carcasa siguiendo las instrucciones del producto.

Periféricos o dispositivos láser

Precaución: Para evitar el riesgo de la exposición a radiaciones o de daños personales:

- No abra la caja de ningún periférico o dispositivo láser
- Los periféricos o dispositivos láser no pueden ser reparados por el usuario
- Haga que el fabricante los repare.

简体中文






服务器安全信息

本文档适用于 Intel® 服务器主板、Intel® 服务器机箱（基座和机架固定件）和已安装的外设。为减少人身伤害、电击、火灾以及设备毁坏的危險，请在安装或维护 Intel® 服务器产品之前阅读本文档并遵循本指南中的所有警告和预防措施。如果本文档中的信息与特定产品的随附信息或 Web 站点信息之间存在不一致，请以产品文档为准。服务器须由合格的技术人员进行集成和维护。必须遵守本指南的规定和服务器手册的装配指导，以确保符合现有的产品认证和审批。仅使用本指南中描述和规定的指定组件。使用其他产品/组件将使产品的 UL 认证和其他管理审批无效，并可能导致产品不符合销售地的产品法规。

安全警告与注意事项

为避免人身伤害与财产损失，安装本产品之前，请阅读以下所有安全指导和信息。下面所列的安全符号可能在整个文档中使用并可能标注于产品和 / 或产品包装之上。

注意

注意	表示如果无视此项轻微人身伤害或财产损失的危險
警告	表示如果无视此严重人身伤害的危險
	表示如果无视所示信息，即存在潜在的危險
	表示如果不遵守安全指导，存在可导致严重伤害或死亡的电击危險
	表示灼热组件或表面
	表示请勿触摸风机叶片，否则可能致伤
	表示拔下所有交流电线，断开交流电源

预期应用使用

根据评估，本产品为信息技术设备 (ITE)，可安装在办公室、学校、计算机房和类似的商业场所。本产品对于非 ITE 应用的其他产品种类和环境（如医疗、工业、住宅、报警系统和测试设备）的适用性尚有待进一步的评估。

场地选择

本系统专为在典型办公环境运行而设计。请选择符合以下条件的地点：

- 清洁、干燥，无气载微粒（而非一般的室内尘埃）。
- 通风良好，远离热源（包括直接日晒和散热器）。
- 远离振动源或物理震动。
- 与电气设备产生的强大电磁场隔离。
- 在易受闪电袭击的地区，我们建议将系统插入电涌抑制器并在闪电期间断开通信线路与调制解调器之间的连接。
- 提供正确接地的墙壁插座。
- 提供足够的空间，以便拿取电源供应线，因为这是本产品的主要电源断开器。

设备操作规范

减少人身伤害或设备受损的危险：

- 移举设备时遵守当地的职业健康与安全要求。
- 借助机械手段或其他合适的手段移举设备。
- 拆除一切易分离组件，以降低重量并方便操作。

电源与电气警告

注意事项

电源按钮（如待机电源标记所示）并不能完全关闭系统的交流电源，只要系统已接通电源，就存在 5V

待机电源。要从系统切断电源，须从墙壁电源插座中拔下交流电线。您的系统可能不止使用一根交流电线。请确保所有的交流电线都已拔下。打开机箱或增加或删除任何热插拔组件之前，确保交流电线已拔下。

若非所需的确切类型，请勿尝试修改或使用交流电线。系统的每个电源供应设备都需要一根单独的交流电线。

本产品的电源供应设备包含非用户维修部件。请勿打开电源供应设备。电源供应设备包含非常危险的电压级、电流级和能量级。请与生产商联系维修事宜。

替换热插拔电源供应设备时，请先拔下需替换的电源供应设备上的电源线，再将其从服务器上移除。

为避免电击，请在打开服务器之前，关闭服务器并断开服务器上连接的电源线、电信系统、网络 and 调制解调器。

电源线警告

如果产品未提供交流电线，请购买一根您所在国家批准使用的交流电线。

注意事项

为避免电击或火灾危险，请按如下所述对产品所用的电源线进行检查：

- 若非所需的符合接地插座的确切类型，请勿尝试修改或使用交流电源线。
- 电源线须符合以下标准：
 - 电源线的电气额定值须大于产品上标注的电流额定值。
 - 电源线须拥有适合插座的安全接地插头或触点。
 - 电源线为交流电源的主要断开设备。插座须靠近设备并可随时断开。
 - 电源线须插入所提供的拥有合适接地的插座。

系统使用警告

注意事项

为避免人身伤害或财产损失，无论何时检查产品内部，以下安全指导都适用：

- 关闭所有与本产品相连的外设。
- 按下电源按钮至关闭状态，关闭系统。
- 从系统或墙壁插座上拔下所有交流电线，断开交流电源。
- 断开与系统相连的所有线缆和通信线路。
- 卸除舱口盖时，保留所有螺钉及其他紧固件。完成产品内部检查之后，请用螺钉或紧固件重新固定舱口盖。
- 请勿打开电源供应设备。电源供应设备内没有可维修部件。请与生产商联系维修事宜。
- 增加或替换任何非热插拔组件之前，请关闭服务器电源并断开所有电源线。
- 替换热插拔电源供应设备时，请先拔下需替换的电源供应设备上的电源线，然后再从服务器上移除电源供应设备。

注意事项

如果服务器一直在运行，任何已安装的处理器和吸热设备都可能很热。除非要增加或移除热插拔组件，否则请待系统冷却后再开盖。为避免在热插拔组件安装过程中

接触灼热组件，移除或安装热插拔组件时务须小心。

注意事项

为避免受伤，请勿触摸运转的风机叶片。如果系统的风机上配有防护装置，请勿卸下风机防护装置运行系统。

机架固定件警告

设备的机架须固定在稳固的支座上，以防从中安装服务器或设备时倒塌。须按照机架生产商提供的安装说明进行安装。

从下往上将设备安装在机架上，最重的设备安装在机架的最底层。

一次只从机架上安装一件设备。

您须负责安装整个机架装置的主要电源断开设备。此主要断开设备须随时可用，且须标明为控制整个装置（而不仅限于服务器）的电源。

为避免潜在的电击危险，须对机架及其上所安装的每一件设备实行正确的安全接地。

静电放电 (ESD)

注意事项

ESD 会损坏磁盘驱动器、主板及其他部件。我们建议您执行 ESD

工作站的所有步骤。如果没有 ESD

工作站，则采取一些静电放电保护措施，操作部件时，戴上与服务器上的机箱接地或任何未喷漆金属表面连接的防静电腕带。

操作主板时始终保持小心。它们可能对 ESD

非常敏感。拿持主板时只接触边缘。从保护包装中或从服务器上取出主板后，请将主板组件侧面朝上放置在不带电的接地表面上。请使用导电泡沫垫（若有），不要使用主板包装。请勿将主板在任何表面上滑动。

其他危险

替换电池

注意事项

不正确替换电池可能导致爆炸危险。替换电池时，请只使用设备生产商推荐使用的电池。

请按当地法规处置电池。

请勿对电池充电。

请勿拆卸、刺穿或以其他方式损坏电池。

冷却和气流

注意事项

按照说明小心布置线缆，尽量减少气流阻塞和冷却问题。

为保证适当的冷却和气流，运行系统时请确保机箱盖已安装。未安装机箱盖即运行系统可能导致系统部件受损。安装机箱盖的步骤如下：

- 首先检查并确保系统内没有遗留的未固定工具或部件。
- 检查线缆、内插板和其他组件已正确安装。
- 按产品说明安装机箱盖。

激光外设或激光设备

注意事项







为避免幅射暴露和/或人身伤害：

- 请勿打开任何激光外设或激光设备的外壳
- 激光外设或激光设备为非用户维修设备




请与生产商联系维修事宜

Appendix C: Installation/Assembly Safety Instructions





English

	<p>The power supply in this product contains no user-serviceable parts. Refer servicing only to qualified personnel.</p>
	<p>Do not attempt to modify or use the supplied AC power cord if it is not the exact type required. A product with more than one power supply will have a separate AC power cord for each supply.</p>
	<p>The power button on the system does not turn off system AC power. To remove AC power from the system, you must unplug each AC power cord from the wall outlet or power supply. The power cord(s) is considered the disconnect device to the main (AC) power. The socket outlet that the system plugs into shall be installed near the equipment and shall be easily accessible.</p>
	<p>SAFETY STEPS: Whenever you remove the chassis covers to access the inside of the system, follow these steps:</p> <ol style="list-style-type: none"> 1. Turn off all peripheral devices connected to the system. 2. Turn off the system by pressing the power button. 3. Unplug all AC power cords from the system or from wall outlets. 4. Label and disconnect all cables connected to I/O connectors or ports on the back of the system. 5. Provide some electrostatic discharge (ESD) protection by wearing an antistatic wrist strap attached to chassis ground of the system-any unpainted metal surface-when handling components. 6. Do not operate the system with the chassis covers removed.
	<p>After you have completed the six SAFETY steps above, you can remove the system covers. To do this:</p> <ol style="list-style-type: none"> 1. Unlock and remove the padlock from the back of the system if a padlock has been installed. 2. Remove and save all screws from the covers. 3. Remove the cover(s).
	<p>For proper cooling and airflow, always reinstall the chassis covers before turning on the system. Operating the system without the covers in place can damage system parts. To install the covers:</p> <ol style="list-style-type: none"> 1. Check first to make sure you have not left loose tools or parts inside the system. 2. Check that cables, add-in boards, and other components are properly installed. 3. Attach the covers to the chassis with the screws removed earlier, and tighten them firmly. 4. Insert and lock the padlock to the system to prevent unauthorized access inside the system. 5. Connect all external cables and the AC power cord(s) to the system.






Appendix C: Installation/Assembly Safety Instructions

	<p>A microprocessor and heat sink may be hot if the system has been running. Also, there may be sharp pins and edges on some board and chassis parts. Contact should be made with care. Consider wearing protective gloves.</p>
	<p>Danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the equipment manufacturer. Dispose of used batteries according to manufacturer's instructions.</p>
	<p>The system is designed to operate in a typical office environment. Choose a site that is:</p> <ul style="list-style-type: none"> • Clean and free of airborne particles (other than normal room dust). • Well ventilated and away from sources of heat including direct sunlight. • Away from sources of vibration or physical shock. • Isolated from strong electromagnetic fields produced by electrical devices. • In regions that are susceptible to electrical storms, we recommend you plug your system into a surge suppressor and disconnect telecommunication lines to your modem during an electrical storm. • Provided with a properly grounded wall outlet. • Provided with sufficient space to access the power supply cord(s), because they serve as the product's main power disconnect.








Deutsch

	<p>Benutzer können am Netzgerät dieses Produkts keine Reparaturen vornehmen. Das Produkt enthält möglicherweise mehrere Netzgeräte. Wartungsarbeiten müssen von qualifizierten Technikern ausgeführt werden.</p>
	<p>Versuchen Sie nicht, das mitgelieferte Netzkabel zu ändern oder zu verwenden, wenn es sich nicht genau um den erforderlichen Typ handelt. Ein Produkt mit mehreren Netzgeräten hat für jedes Netzgerät ein eigenes Netzkabel.</p>
	<p>Der Wechselstrom des Systems wird durch den Ein-/Aus-Schalter für Gleichstrom nicht ausgeschaltet. Ziehen Sie jedes Wechselstrom-Netzkabel aus der Steckdose bzw. dem Netzgerät, um den Stromanschluß des Systems zu unterbrechen.</p>
	<p>SICHERHEISSMASSNAHMEN: Immer wenn Sie die Gehäuseabdeckung abnehmen um an das Systeminnere zu gelangen, sollten Sie folgende Schritte beachten:</p> <ol style="list-style-type: none"> 1. Schalten Sie alle an Ihr System angeschlossenen Peripheriegeräte aus. 2. Schalten Sie das System mit dem Hauptschalter aus. 3. Ziehen Sie den Stromanschlußstecker Ihres Systems aus der Steckdose. 4. Auf der Rückseite des Systems beschriftet und ziehen Sie alle Anschlußkabel von den I/O Anschlüssen oder Ports ab. 5. Tragen Sie ein geerdetes Antistatik Gelenkband, um elektrostatische Ladungen (ESD) über blanke Metallstellen bei der Handhabung der Komponenten zu vermeiden. 6. Schalten Sie das System niemals ohne ordnungsgemäß montiertes Gehäuse ein.



Appendix C: Installation/Assembly Safety Instructions

	<p>SICHERHEISSMASSNAHMEN: Immer wenn Sie die Gehäuseabdeckung abnehmen um an das Systeminnere zu gelangen, sollten Sie folgende Schritte beachten:</p> <ol style="list-style-type: none"> 1. Schalten Sie alle an Ihr System angeschlossenen Peripheriegeräte aus. 2. Schalten Sie das System mit dem Hauptschalter aus. 3. Ziehen Sie den Stromanschlußstecker Ihres Systems aus der Steckdose. 4. Auf der Rückseite des Systems beschrifteten und ziehen Sie alle Anschlußkabel von den I/O Anschlüssen oder Ports ab. 5. Tragen Sie ein geerdetes Antistatik Gelenkband, um elektrostatische Ladungen (ESD) über blanke Metallstellen bei der Handhabung der Komponenten zu vermeiden. 6. Schalten Sie das System niemals ohne ordnungsgemäß montiertes Gehäuse ein.
	<p>Zur ordnungsgemäßen Kühlung und Lüftung muß die Gehäuseabdeckung immer wieder vor dem Einschalten installiert werden. Ein Betrieb des Systems ohne angebrachte Abdeckung kann Ihrem System oder Teile darin beschädigen. Um die Abdeckung wieder anzubringen:</p> <ol style="list-style-type: none"> 1. Vergewissern Sie sich, daß Sie keine Werkzeuge oder Teile im Innern des Systems zurückgelassen haben. 2. Überprüfen Sie alle Kabel, Zusatzkarten und andere Komponenten auf ordnungsgemäßen Sitz und Installation. 3. Bringen Sie die Abdeckungen wieder am Gehäuse an, indem Sie die zuvor gelösten Schrauben wieder anbringen. Ziehen Sie diese gut an. 4. Bringen Sie die Verschlusseinrichtung (Padlock) wieder an und schließen Sie diese, um ein unerlaubtes Öffnen des Systems zu verhindern. 5. Schließen Sie alle externen Kabel und den AC Stromanschlußstecker Ihres Systems wieder an.
	<p>Der Mikroprozessor und der Kühler sind möglicherweise erhitzt, wenn das System in Betrieb ist. Außerdem können einige Platinen und Gehäuseteile scharfe Spitzen und Kanten aufweisen. Arbeiten an Platinen und Gehäuse sollten vorsichtig ausgeführt werden. Sie sollten Schutzhandschuhe tragen.</p>
	<p>Bei falschem Einsetzen einer neuen Batterie besteht Explosionsgefahr. Die Batterie darf nur durch denselben oder einen entsprechenden, vom Hersteller empfohlenen Batterietyp ersetzt werden. Entsorgen Sie verbrauchte Batterien den Anweisungen des Herstellers entsprechend.</p>
	<p>Das System wurde für den Betrieb in einer normalen Büroumgebung entwickelt. Der Standort sollte:</p> <ul style="list-style-type: none"> • "sauber und staubfrei sein (Hausstaub ausgenommen); • "gut gelüftet und keinen Heizquellen ausgesetzt sein (einschließlich direkter Sonneneinstrahlung); • "keinen Erschütterungen ausgesetzt sein; • "keine starken, von elektrischen Geräten erzeugten elektromagnetischen Felder aufweisen; • "in Regionen, in denen elektrische Stürme auftreten, mit einem Überspannungsschutzgerät verbunden sein; während eines elektrischen Sturms sollte keine Verbindung der Telekommunikationsleitungen mit dem Modem bestehen; • "mit einer geerdeten Wechselstromsteckdose ausgerüstet sein; • "über ausreichend Platz verfügen, um Zugang zu den Netzkabeln zu gewährleisten, da der Stromanschluß des Produkts hauptsächlich über die Kabel unterbrochen wird








Français

	<p>Le bloc d'alimentation de ce produit ne contient aucune pièce pouvant être réparée par l'utilisateur. Ce produit peut contenir plus d'un bloc d'alimentation. Veuillez contacter un technicien qualifié en cas de problème.</p>
	<p>Ne pas essayer d'utiliser ni modifier le câble d'alimentation CA fourni, s'il ne correspond pas exactement au type requis. Le nombre de câbles d'alimentation CA fournis correspond au nombre de blocs d'alimentation du produit.</p>
	<p>Notez que le commutateur CC de mise sous tension /hors tension du panneau avant n'éteint pas l'alimentation CA du système. Pour mettre le système hors tension, vous devez débrancher chaque câble d'alimentation de sa prise.</p>
	<p>CONSIGNES DE SÉCURITÉ -Lorsque vous ouvrez le boîtier pour accéder à l'intérieur du système, suivez les consignes suivantes:</p> <ol style="list-style-type: none"> 1. Mettez hors tension tous les périphériques connectés au système. 2. Mettez le système hors tension en mettant l'interrupteur général en position OFF (bouton-poussoir). 3. Débranchez tous les cordons d'alimentation c.a. du système et des prises murales. 4. Identifiez et débranchez tous les câbles reliés aux connecteurs d'E-S ou aux accès derrière le système. 5. Pour prévenir les décharges électrostatiques lorsque vous touchez aux composants, portez une bande antistatique pour poignet et reliez-la à la masse du système (toute surface métallique non peinte du boîtier). 6. Ne faites pas fonctionner le système tandis que le boîtier est ouvert.
	<p>Une fois TOUTES les étapes précédentes accomplies, vous pouvez retirer les panneaux du système. Procédez comme suit:</p> <ol style="list-style-type: none"> 1. Si un cadenas a été installé sur à l'arrière du système, déverrouillez-le et retirez-le. 2. Retirez toutes les vis des panneaux et mettez-les dans un endroit sûr. 3. Retirez les panneaux.
	<p>Afin de permettre le refroidissement et l'aération du système, réinstallez toujours les panneaux du boîtier avant de mettre le système sous tension. Le fonctionnement du système en l'absence des panneaux risque d'endommager ses pièces. Pour installer les panneaux, procédez comme suit:</p> <ol style="list-style-type: none"> 1. Assurez-vous de ne pas avoir oublié d'outils ou de pièces démontées dans le système. 2. Assurez-vous que les câbles, les cartes d'extension et les autres composants sont bien installés. 3. Revissez solidement les panneaux du boîtier avec les vis retirées plus tôt. 4. Remettez le cadenas en place et verrouillez-le afin de prévenir tout accès non autorisé à l'intérieur du système. 5. Rebranchez tous les cordons d'alimentation c. a. et câbles externes au système.
	<p>Le microprocesseur et le dissipateur de chaleur peuvent être chauds si le système a été sous tension. Faites également attention aux broches aiguës des cartes et aux bords tranchants du capot. Nous vous recommandons l'usage de gants de protection.</p>



Appendix C: Installation/Assembly Safety Instructions

	<p>Danger d'explosion si la batterie n'est pas remontée correctement. Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le fabricant. Disposez des piles usées selon les instructions du fabricant.</p>
	<p>Le système a été conçu pour fonctionner dans un cadre de travail normal. L'emplacement choisi doit être:</p> <ul style="list-style-type: none">• "Propre et dépourvu de poussière en suspension (sauf la poussière normale).• "Bien aéré et loin des sources de chaleur, y compris du soleil direct.• "A l'abri des chocs et des sources de vibrations.• "Isolé de forts champs électromagnétiques géenérés par des appareils électriques.• "Dans les régions sujettes aux orages magnétiques il est recomandé de brancher votre système à un supresseur de surtension, et de débrancher toutes les lignes de télécommunications de votre modem durant un orage.• "Muni d'une prise murale correctement mise à la terre.• "Suffisamment spacieux pour vous permettre d'accéder aux câbles d'alimentation (ceux-ci étant le seul moyen de mettre le système hors tension).








Español

	<p>El usuario debe abstenerse de manipular los componentes de la fuente de alimentación de este producto, cuya reparación debe dejarse exclusivamente en manos de personal técnico especializado. Puede que este producto disponga de más de una fuente de alimentación</p>
	<p>No intente modificar ni usar el cable de alimentación de corriente alterna, si no corresponde exactamente con el tipo requerido.</p> <p>El número de cables suministrados se corresponden con el número de fuentes de alimentación de corriente alterna que tenga el producto</p>
	<p>Nótese que el interruptor activado/desactivado en el panel frontal no desconecta la corriente alterna del sistema. Para desconectarla, deberá desenchufar todos los cables de corriente alterna de la pared o desconectar la fuente de alimentación.</p>
	<p>INSTRUCCIONES DE SEGURIDAD: Cuando extraiga la tapa del chasis para acceder al interior del sistema, siga las siguientes instrucciones:</p> <ol style="list-style-type: none"> 1. Apague todos los dispositivos periféricos conectados al sistema. 2. Apague el sistema presionando el interruptor encendido/ apagado. 3. Desconecte todos los cables de alimentación CA del sistema o de las tomas de corriente alterna. 4. Identifique y desconecte todos los cables enchufados a los conectores E/S o a los puertos situados en la parte posterior del sistema. 5. Cuando manipule los componentes, es importante protegerse contra la descarga electrostática (ESD). Puede hacerlo si utiliza una muñequera antiestática sujeta a la toma de tierra del chasis - o a cualquier tipo de superficie de metal sin pintar. 6. No ponga en marcha el sistema si se han extraído las tapas del chasis.
	<p>Después de completar las seis instrucciones de SEGURIDAD mencionadas, ya puede extraer las tapas del sistema. Para ello:</p> <ol style="list-style-type: none"> 1. Desbloquee y extraiga el bloqueo de seguridad de la parte posterior del sistema, si se ha instalado uno. 2. Extraiga y guarde todos los tornillos de las tapas.Extraiga las tapas.
	<p>Para obtener un enfriamiento y un flujo de aire adecuados, reinstale siempre las tapas del chasis antes de poner en marcha el sistema. Si pone en funcionamiento el sistema sin las tapas bien colocadas puede dañar los componentes del sistema. Para instalar las tapas:</p> <ol style="list-style-type: none"> 1. Asegúrese primero de no haber dejado herramientas o componentes sueltos dentro del sistema. 2. Compruebe que los cables, las placas adicionales y otros componentes se hayan instalado correctamente. 3. Incorpore las tapas al chasis mediante los tornillos extraídos anteriormente, tensándolos firmemente. 4. Inserte el bloqueo de seguridad en el sistema y bloquéelo para impedir que pueda accederse al mismo sin autorización. 5. Conecte todos los cables externos y los cables de alimentación CA al sistema.
	<p>Si el sistema ha estado en funcionamiento, el microprocesador y el disipador de calor pueden estar aún calientes. También conviene tener en cuenta que en el chasis o en el tablero puede haber piezas cortantes o punzantes. Por ello, se recomienda precaución y el uso de guantes protectores.</p>



Appendix C: Installation/Assembly Safety Instructions

	<p>Existe peligro de explosión si la pila no se cambia de forma adecuada. Utilice solamente pilas iguales o del mismo tipo que las recomendadas por el fabricante del equipo. Para deshacerse de las pilas usadas, siga igualmente las instrucciones del fabricante.</p>
	<p>El sistema está diseñado para funcionar en un entorno de trabajo normal. escoja un lugar:</p> <ul style="list-style-type: none">• "Limpio y libre de partículas en suspensión (salvo el polvo normal).• "Bien ventilado y alejado de fuentes de calor, incluida la luz solar directa.• "Alejado de fuentes de vibración.• "Aislado de campos electromagnéticos fuertes producidos por dispositivos eléctricos.• "En regiones con frecuentes tormentas eléctricas, se recomienda conectar su sistema a un eliminador de sobrevoltage y desconectar el módem de las líneas de telecomunicación durante las tormentas.• "Provisto de una toma de tierra correctamente instalada.• "Provisto de espacio suficiente como para acceder a los cables de alimentación, ya que éstos hacen de medio principal de desconexión del sistema.

Italiano

	Rivolgersi ad un tecnico specializzato per la riparazione dei componenti dell'alimentazione di questo prodotto. È possibile che il prodotto disponga di più fonti di alimentazione.
	Non modificare o utilizzare il cavo di alimentazione in c.a. fornito dal produttore, se non corrisponde esattamente al tipo richiesto. Ad ogni fonte di alimentazione corrisponde un cavo di alimentazione in c.a. separato.
	L'interruttore attivato/disattivato nel pannello anteriore non interrompe l'alimentazione in c.a. del sistema. Per interromperla, è necessario scollegare tutti i cavi di alimentazione in c.a. dalle prese a muro o dall'alimentazione di corrente.
	<p>PASSI DI SICUREZZA: Qualora si rimuovano le coperture del telaio per accedere all'interno del sistema, seguire i seguenti passi:</p> <ol style="list-style-type: none"> 1. Spegner tutti i dispositivi periferici collegati al sistema. 2. Spegner il sistema, usando il pulsante spento/acceso dell'interruttore del sistema. 3. Togliere tutte le spine dei cavi del sistema dalle prese elettriche. 4. Identificare e sconnettere tutti i cavi attaccati ai collegamenti I/O od alle prese installate sul retro del sistema. 5. Qualora si tocchino i componenti, proteggersi dallo scarico elettrostatico (SES), portando un cinghia anti-statica da polso che è attaccata alla presa a terra del telaio del sistema - qualsiasi superficie non dipinta. 6. Non far operare il sistema quando il telaio è senza le coperture.
	<p>Dopo aver seguito i sei passi di SICUREZZA sopracitati, togliere le coperture del telaio del sistema come segue:</p> <ol style="list-style-type: none"> 1. Aprire e rimuovere il lucchetto dal retro del sistema qualora ve ne fosse uno installato. 2. Togliere e mettere in un posto sicuro tutte le viti delle coperture. 3. Togliere le coperture.
	<p>Per il giusto flusso dell'aria e raffreddamento del sistema, rimettere sempre le coperture del telaio prima di riaccendere il sistema. Operare il sistema senza le coperture al loro proprio posto potrebbe danneggiare i componenti del sistema. Per rimettere le coperture del telaio:</p> <ol style="list-style-type: none"> 1. Controllare prima che non si siano lasciati degli attrezzi o dei componenti dentro il sistema. 2. Controllare che i cavi, dei supporti aggiuntivi ed altri componenti siano stati installati appropriatamente. 3. Attaccare le coperture al telaio con le viti tolte in precedenza e avvitarle strettamente. 4. Inserire e chiudere a chiave il lucchetto sul retro del sistema per impedire l'accesso non autorizzato al sistema. 5. Ricollegare tutti i cavi esterni e le prolungh AC del sistema.
	Se il sistema è stato a lungo in funzione, il microprocessore e il dissipatore di calore potrebbero essere surriscaldati. Fare attenzione alla presenza di piedini appuntiti e parti taglienti sulle schede e sul telaio. È consigliabile l'uso di guanti di protezione.

Appendix C: Installation/Assembly Safety Instructions

	<p>Esiste il pericolo di un'esplosione se la pila non viene sostituita in modo corretto. Utilizzare solo pile uguali o di tipo equivalente a quelle consigliate dal produttore. Per disfarsi delle pile usate, seguire le istruzioni del produttore.</p>
	<p>Il sistema è progettato per funzionare in un ambiente di lavoro tipo. Scegliere una postazione che sia:</p> <ul style="list-style-type: none">• "Pulita e libera da particelle in sospensione (a parte la normale polvere presente nell'ambiente).• "Ben ventilata e lontana da fonti di calore, compresa la luce solare diretta.• "Al riparo da urti e lontana da fonti di vibrazione.• "Isolata dai forti campi magnetici prodotti da dispositivi elettrici.• "In aree soggette a temporali, è consigliabile collegare il sistema ad un limitatore di corrente. In caso di temporali, scollegare le linee di comunicazione dal modem.• "Dotata di una presa a muro correttamente installata.• "Dotata di spazio sufficiente ad accedere ai cavi di alimentazione, i quali rappresentano il mezzo principale di scollegamento del sistema.

Appendix D: Getting Help

World Wide Web

<http://support.intel.com/support/motherboards/server/chassis/SC5600/>

If you encounter an issue with your server platform, please follow these steps to obtain support on your product.

1. Get connected to our [support web page](#) for 24x7 support when you need it to get the latest and most complete technical support information on all Intel Enterprise Server and Storage Platforms. Information available at the support site includes:
 - Latest BIOS, firmware, drivers and utilities
 - Product documentation, installation and quick start guides
 - Full product specifications, technical advisories and errata
 - Compatibility documentation for memory, hardware add-in cards, chassis support matrix, and operating systems
 - Server and chassis accessory parts list for ordering upgrades or spare parts
 - A searchable knowledgebase to search for product information throughout the support site
2. Send an email to Intel's technical support center using the following online form if you still cannot obtain a solution to your issue.
3. Lastly, you can contact an Intel support representative using one of the following support phone numbers. Charges may apply. Intel customer support suggests filling out the [issue report form](#) to better service the issue.

Intel now offers Channel Program members around-the-clock [24x7 technical phone support+](#) on Intel® server boards, server chassis, server RAID controller cards, and Intel® Server Management.

Warranty Information

Connect to Intel's website to obtain warranty information.

+ Requires login to the Reseller Site to obtain the 24x7 Number.

Appendix E: Intel® Server Issue Report Form

Issue Report Form (Rev 3.5)

NOTE: Filling out this form completely is required for any escalation.

Note: An online/automatic submission version of this form is available at <http://support.intel.com/support/motherboards/server/chassis/sc5600/>. For the fastest service, please submit your form via the Internet.

Customer Contact Information:

Customer Support Case#:

Intel® Server Board or System:

(Example: S55200HC, S5520SC)

Server Chassis:

(Example SC5600. If third-party chassis is used, indicate make and model.)

Base Board Information: (You can find some information by accessing the BIOS and going through the Server Management menu -> System Information)

Baseboard PBA/TA/AA # (Example: 123456-789):

- You can find this on the white sticker label on the baseboard.

System BIOS Version:

Intel® Remote Management Module Firmware Version (if applicable):

Intel® Management Module BMC Revision (if applicable):

BMC/mBMC Version:

FRU/SDR Version:

HSC Version:

Has the latest BIOS been tried? (Yes/No):

Has the latest BMC/mBMC been tried? (Yes/No):

Has the latest IMM BMC been tried? (Yes/No):

Has the latest RMM Firmware been tried? (Yes/No):

Has the latest FRU/SDR been tried? (Yes/No):

Has the latest HSC been tried? (Yes/No):

Processor information:

	Type	Speed	sSpec	Thermal Solution
Processor 1				
Processor 2				
Processor 3				
Processor 4				

Thermal solution (Heat sink) examples:

(1U, Passive w/air ducting, Active w/fan, and so on)

Memory:

Manufacturer	Part Number	DRAM Part Number	On Intel tested list?

Add-in adapters (Example: NICs, Management Adapters, Serial Expansion Cards, PCI-Express* Adapters, RAID Controllers, SCSI Controllers, and so on):

Type	Slot	Manufacturer	Model	Firmware

Appendix E: Intel® Server Issue Report Form

Other third-party hardware (Example: Example: KVM, Chassis, and so on):

Description/Use	Manufacturer	Model	Firmware

Storage Devices (Example: SCSI, SATA, SAS, USB, Tape, and so on):

Manufacturer	Model	Type	Size	Firmware	In Hot Swap Bay?

Operating System Information (Example: Red Hat* Enterprise Linux, Microsoft Windows Server 2003*, Service pack 1, OEM CD):

Manufacturer:

Version:

Language version (English, Arabic, Chinese (Simplified)):

Service Pack Level or Kernel Revision:

Distribution (OEM/Retail):

Intel® RAID Controller: (Example SRCU42E)

RAID controller part number (PBA number):

RAID controller firmware version:

Has the latest RAID firmware been tried? (Yes/No):

RAID driver version:

Has the latest RAID driver been tried? (Yes/No):

RAID volumes configuration (disks & RAID level):

RAID volume use (Boot device/Data Volume):

Is BBU (Battery Backup Unit) installed? (Yes/No):

BBU part number:

Detailed description of issue:

Troubleshooting tried:

Steps to replicate the issue:

Issue impact statements:

Do you have any potential Intel system, or component purchases that this issue is holding up? If yes, please provide a brief description below.

Do you have systems already purchased that are not being delivered to your customers because of this issue? If yes, please provide a brief description below.

Have you returned systems or components to your place of purchase because of this issue? If yes, please provide a brief description below.

*All other brands and names are property of their respective owners.

Appendix F: Warranty

Limited Warranty for Intel® Chassis Subassembly Products

Intel warrants that the Products (defined herein as the Intel® chassis subassembly and all of its various components and software delivered with or as part of the Products) to be delivered hereunder, if properly used and installed, will be free from defects in material and workmanship and will substantially conform to Intel's publicly available specifications for a period of three (3) years after the date the Product was purchased from an Intel authorized distributor. Software of any kind delivered with or as part of products is expressly provided "as is" unless specifically provided for otherwise in any software license accompanying the software.

If any Product furnished by Intel which is the subject of this Limited Warranty fails during the warranty period for reasons covered by this Limited Warranty, Intel, at its option, will:

- REPAIR the Product by means of hardware and/or software; OR
- REPLACE the Product with another Product; OR
- REFUND the then-current value of the Product if Intel is unable to repair or replace the Product.

If such Product is defective, transportation charges for the return of Product to buyer within the USA will be paid by Intel. For all other locations, the warranty excludes all costs of shipping, customs clearance, and other related charges. Intel will have a reasonable time to make repairs or to replace Product or to refund the then-current value of the Product.

In no event will Intel be liable for any other costs associated with the replacement or repair of Product, including labor, installation or other costs incurred by buyer and in particular, any costs relating to the removal or replacement of any product soldered or otherwise permanently affixed to any printed circuit board.

This Limited Warranty, and any implied warranties that may exist under state law, apply only to the original purchaser of the Product.

Extent of Limited Warranty

Intel does not warrant that Products to be delivered hereunder, whether delivered standalone or integrated with other Products, including without limitation semiconductor components, will be free from design defects or errors known as "errata." Current characterized errata are available upon request.

This Limited Warranty does not cover damages due to external causes, including accident, problems with electrical power, usage not in accordance with product instructions, misuse, neglect, alteration, repair, improper installation, or improper testing.

Warranty Limitations and Exclusions

These warranties replace all other warranties, expressed or implied including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Intel makes no expressed warranties beyond those stated here. Intel disclaims all other warranties, expressed or implied including, without limitation, implied warranties of merchantability and fitness for a particular purpose. Some jurisdictions do not allow the exclusion of implied warranties, so this limitation may not apply.

All expressed and implied warranties are limited in duration to the limited warranty period. No warranties apply after that period. Some jurisdictions do not allow limitations on how long an implied warranty lasts, so this limitation may not apply to you.

Limitations of Liability

Intel's responsibility under this, or any other warranty, implied or expressed, is limited to repair, replacement, or refund, as set forth above. These remedies are the sole and exclusive remedies for any breach of warranty. Intel is not responsible for direct, special, incidental, or consequential damages resulting from any breach of warranty under another legal theory including, but not limited to, lost profits, downtime, goodwill, damage to or replacement of equipment and property, and any costs of recovering, reprogramming, or reproducing any program or data stored in or used with a system containing this product. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

This limited warranty gives you specific legal rights, and you may also have other rights that vary from jurisdiction to jurisdiction.

Any and all disputes arising under or related to this Limited Warranty shall be adjudicated in the following forums and governed by the following laws: for the United States of America, Canada, North America, and South America, the forum shall be Santa Clara, California, USA, and the applicable law shall be that of the State of California, USA; for the Asia Pacific region, the forum shall be Singapore and the applicable law shall be that of Singapore; for Europe and the rest of the world, the forum shall be London and the applicable law shall be that of the United Kingdom.

In the event of any conflict between the English language version and any other translated version(s) of this Limited Warranty, the English language version shall control.

How to Obtain Warranty Service

To obtain warranty service for this Product, you may contact Intel or your authorized distributor.

- North America and Latin America: To obtain warranty repair for the product, please go to the following Web site to obtain instructions: <http://support.intel.com/support/motherboards/draform.htm>
- In Europe and in Asia: Contact your original authorized distributor for warranty service.

Any replacement Product is warranted under this written warranty and is subject to the same limitations and exclusions for the remainder of the original warranty period.

Telephone Support

If you cannot find the information you need on Intel's World Wide Web site (<http://www.intel.com/>), call your local distributor or an Intel Customer Support representative. See "Getting Help" for telephone numbers.

Returning a Defective Product

Before returning any product, call your authorized dealer/distribution authority.