



VessJBOD
1730, 1740,
1830, 1830+, 1840, 1840+
Product Manual

Version 2.0

Copyright

© 2011 PROMISE Technology, Inc. All Rights Reserved. PROMISE, the PROMISE logo, VTrak, SmartStor, SuperTrak, FastTrak, VessRAID, Vess, PerfectPATH, PerfectRAID, SATA150, ULTRA133 VTrak S3000, BackTrak, HyperCache, HyperCache-R, HyperCache-W, DeltaScan and GreenRAID are registered or pending trademarks of PROMISE Technology, Inc. in the U.S. and other countries. All other trademarks are the property of their respective owners. Information regarding products, services and offerings may be superseded by subsequent documents and are subject to change without notice. For the latest information and specifications regarding PROMISE Technology, Inc. and any of its offerings or services, please contact your local PROMISE office or the corporate headquarters. Visit www.PROMISE.com for more information on PROMISE products.

Important data protection information

You should back up all data before installing any drive controller or storage peripheral. PROMISE Technology is not responsible for any loss of data resulting from the use, disuse or misuse of this or any other PROMISE Technology product.

Notice

Although PROMISE Technology has attempted to ensure the accuracy of the content of this manual, it is possible that this document may contain technical inaccuracies, typographical, or other errors. PROMISE Technology assumes no liability for any error in this publication, and for damages, whether direct, indirect, incidental, consequential or otherwise, that may result from such error, including, but not limited to loss of data or profits.

PROMISE Technology provides this publication “as is” without warranty of any kind, either express or implied, including, but not limited to implied warranties of merchantability or fitness for a particular purpose.

The published information in the manual is subject to change without notice. PROMISE Technology reserves the right to make changes in the product design, layout, and driver revisions without notification to its users.

This version of the *Product Manual* supersedes all previous versions.

Recommendations

In this *Product Manual*, the appearance of products made by other companies, including but not limited to software, servers, and disk drives, is for the purpose of illustration and explanation only. PROMISE Technology does not recommend, endorse, prefer, or support any product made by another manufacturer.

Contents

Chapter 1: Introduction to VessJBOD	1
About This Manual	1
VessRAID Model Line-up	2
Features	3
Specifications	4
Power Supply	4
Current (maximum)	4
Power Consumption	4
Temperature	5
Relative Humidity	5
Vibration	5
Dimensions (H x W x D)	5
Net Weight	5
Carton Dimensions (H x W x D)	5
Carton Weight	5
Safety	6
Environmental	6
Warranty and Support	6
CE Statement	6
FCC Statement	6
KCC Statement	6
Chapter 2: VessJBOD Installation	7
Unpacking the VessJBOD	7
Mounting VessJBOD in a Rack	8
Installing Disk Drives	11
Drive Slot Numbering	11
Installing Your Disk Drives	11
Making Data and Management Connections	13
JBOD Expansion to a VessRAID Subsystem	13
Drive Enclosures for a SuperTrak RAID Controller	15
Setting Up Serial Cable Connections	17
Connecting the Power	18
Front Panel LEDs	18
I/O Module LEDs	18
Disk Drive LEDs	19
Setting up the Serial Connection	20

Chapter 3: Management21
LEDs21
Front Panel LEDs21
I/O Module LEDs22
Disk Drive LEDs23
CLI Command Set25
Cable Command25
Enclosure Command26
Factory Default Command29
Help Command30
Link Command30
Route Command34
Uptime Command35
VPDR Command36
? Command36
Chapter 4: Maintenance37
Updating the Firmware37
Downloading the Firmware Image File37
Updating Firmware in WebPAM PROe37
Updating Firmware with the JBOD Flash Utility39
Replacing a Power Supply41
VessJBOD 1730 and 174041
VessJBOD 1830, 1830+, 1840, and 1840+41
Replacing an I/O Module42
Removing the old I/O module42
Installing the new I/O module43
Replacing a Cooling Fan43
Original Models43
Plus Models45
Chapter 5: Support47
Frequently Asked Questions47
Contacting Technical Support48
Limited Warranty51
Returning the Product For Repair53
Index55

Chapter 1: Introduction to VessJBOD

This chapter covers the following topics:

- About This Manual (below)
 - VessRAID Model Line-up (page 2)
 - Features (page 3)
 - Specifications (page 4)
-

About This Manual

This *Product Manual* describes how to setup, use, and maintain the VessJBOD 1730, 1740, 1830, 1830+, 1840, and 1840+ expansion units. It also describes how to use the built-in command-line interface (CLI).

This manual includes a full table of contents, index, chapter task lists, and numerous cross-references to help you find the specific information you are looking for.

Also included are four levels of notices:



Note

A *Note* provides helpful information such as hints or alternative ways of doing a task.



Important

An *Important* calls attention to an essential step or point required to complete a task. Important items include things often missed.



Caution

A *Caution* informs you of possible equipment damage or loss of data and how to avoid them.



Warning

A *Warning* notifies you of probable equipment damage or loss of data, or the possibility of physical injury, and how to avoid them.

VessRAID Model Line-up

Model	Interface	Number of Drives	Drive Carriers	Power Supplies	Controller Fans
1840+	SAS	16	plus	2	external
1840	SAS	16	original	2	internal
1830+	SAS	12	plus	2	external
1830	SAS	12	original	2	internal
1740	SAS	16	original	1	internal
1730	SAS	12	original	1	internal

Figure 1. 12-bay VessJBOD with the “original” drive carrier design




Figure 2. 12-bay VessJBOD with the “plus” drive carrier design







Figure 3. VessJBOD 1730 rear view**Figure 4. VessJBOD 1830 rear view****Figure 5. VessJBOD 1830+ rear view**

Features

- 3.5" x 1" SAS 3 Gb/s drives
- 3.5" x 1" SATA 3 Gb/s drives
- Any combination of SAS and SATA drives in the same system.
- Hot-swappable drive bays.
- Staggered physical drive spin-up.

- Redundant, hot-swappable power supplies on 1830, 1830+, 1840, and 1840+ models.
- Command Line Interface via RJ-11 Serial Port.
- Three years complete system limited warranty includes 24 x 7 email and phone support with highly experienced technical support technicians and an advanced replacements program.
- Compatible with leading SAS hard drives, host bus adapters, and RAID controllers.
- OS support:
 - Windows 2008 Server, 2003 Server
 - Red Hat Linux, SuSE Linux
 - FreeBSD, VMware ESX 4.0
- Supports all background activities running on VessRAID subsystem

Specifications

Power Supply

1840+, 1840: 450W, Dual hot-swappable and redundant, 100-240 VAC auto-ranging, 50-60 Hz, with PFC

1830+, 1830: 350W, Dual hot-swappable and redundant, 100-240 VAC auto-ranging, 50-60 Hz, with PFC

1740: 450W, Single, 100-240 VAC auto-ranging, 50-60 Hz, with PFC and 80PLUS certification

1730: 350W, Single, 100-240 VAC auto-ranging, 50-60 Hz, with PFC and 80PLUS certification

Current (maximum)

1840 and 1840+: 8 A @ 100 VAC or 4 A @ 240 VAC current rating with two power cords

1830 and 1830+: 6A @ 100 VAC or 3 A @ 240 VAC Current rating with two power cords

1740: 7A @ 100 VAC or 3.5 A @ 240 VAC Current rating with one power cord

1730: 6A @ 100 VAC or 3 A @ 240 VAC Current rating with one power cord

Power Consumption

1840+, 1840, 1740: without disk drives, 72.2 W; with disk drives, 242.3 W

1830+, 1830, 1730: without disk drives, 80.3 W; with disk drives, 233.4 W

Temperature

Normal conditions:

5° to 40°C operational (-40° to 60°C non-operational)

Conditions of running SAS disk drives with one failed cooling fan:

5° to 35°C operational (-40° to 60°C non-operational)

Relative Humidity

95 percent maximum

Vibration

Random, 0.21 grms, 5-500 Hz, 30 Mins, X, Y, Z axis.

Dimensions (H x W x D)

1840+, 1840, 1740: 13 x 45 x 46 cm (5.1 x 17.7 x 18.1 in)

1830+, 1830, 1730: 8.8 x 45 x 46 cm (3.5 x 17.7 x 18.1 in)

Net Weight

1840+: 16.6 kg (36.1 lb) without drives, 24.6 kg (53.5 lb) with 16 drives*

1840: 15.8 kg (34.8 lb) without drives, 23.8 kg (52.5 lb) with 16 drives*

1830+: 13.4 kg (29.2 lb) without drives, 19.4 kg (42.3 lb) with 12 drives*

1830: 12.6 kg (27.8 lb) without drives, 18.6 kg (41.0 lb) with 12 drives*

1740: 13.8 kg (30.4 lb) without drives, 21.8 kg (48.1 lb) with 16 drives*

1730: 10.8 kg (23.5 lb) without drives, 16.8 kg (37.1 lb) with 12 drives*

* Assuming 0.5 kg (1.1 lb) per drive.

Carton Dimensions (H x W x D)

All models: 28.5 x 57.2 x 75.2 cm (11.2 x 22.5 x 29.6 in)

Carton Weight

1840+: 21.6 kg (47.6 lb)

1840: 20.8 kg (45.9 lb)

1830+: 18.8 kg (41.4 lb)

1830: 18.0 kg (38.8 lb)

1740: 19.2 kg (42.3 lb)

1730: 16.2 kg (35.7 lb)

Safety

BSMI, CB, CCC, CE, FCC Class A, MIC, VCCI, UL, cUL, TUV.

Environmental

RoHS, China RoHS.

Warranty and Support

Warranty: Three year limited warranty on all components except the optional battery backup unit, which has a one-year warranty.

Support: 24x7 email and phone support (English only). 24x7 access to PROMISE support site for drivers, firmware, and compatibility.

CE Statement

Warning: This is a class B product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

KCC Statement

A급 기기 (업무용 정보통신기기)

이 기기는 업무용으로 전자파적합등록을 한 기기이오니 판매자 또는 사용자는 이 점을 주의하시기 바라며, 만약 잘못판매 또는 구입하였을 때에는 가정용으로 교환하시기 바랍니다.

Chapter 2: VessJBOD Installation

This chapter covers the following topics:

- Unpacking the VessJBOD (below)
 - Mounting VessJBOD in a Rack (page 8)
 - Installing Disk Drives (page 11)
 - Making Data and Management Connections (page 13)
 - Setting Up Serial Cable Connections (page 17)
 - Connecting the Power (page 18)
 - Setting up the Serial Connection (page 20)
-

Unpacking the VessJBOD

The VessJBOD box contains the following items:

- VessJBOD Unit
- *Quick Start Guide* printed
- RJ11-to-DB9 serial data cable
- Screws for disk drives (70 pieces for 16-bay, 50 pieces for 12-bay)
- 1.5m (4.9 ft) Power cords (1700 models, 1; 1800 models, 2)
- CD with *Product Manual* and *Quick Start Guide* in PDF format



Warning

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.



Warning

The electronic components within the VessJBOD enclosure are sensitive to damage from Electro-Static Discharge (ESD). Observe appropriate precautions at all times when handling the VessJBOD or its subassemblies.

Mounting VessJBOD in a Rack



Cautions

- At least two persons are required to safely lift, place, and attach the VessJBOD unit into a rack system.
 - Do not lift or move the VessJBOD unit by the handles, power supplies or the controller units. Hold the subsystem itself.
 - Do not install the VessJBOD unit into a rack without rails to support the subsystem.
 - Only a qualified technician who is familiar with the installation procedure should mount and install the VessJBOD unit.
 - Be sure all switches are OFF before installing the VessJBOD unit or exchanging components.
 - Mount the rails to the rack using the appropriate screws and flange nuts, fully tightened, at each end of the rail.
 - Do not load the rails unless they are installed with screws as instructed.
 - The rails available for the PROMISE VessJBOD unit are designed to safely support that PROMISE VessJBOD unit when properly installed. Additional loading on the rails is at the customer's risk.
 - PROMISE Technology, Inc. cannot guarantee that the mounting rails will support your PROMISE VessJBOD unit unless you install them as instructed.
-




Note

To lighten the VessJBOD enclosure, remove the power supplies. Replace the power supplies after the VessJBOD unit is mounted in your rack.

The VessJBOD subsystem installs to the rack using the available mounting rails. You can also use your existing rails.


Figure 1. A 16-bay VessJBOD mounted in a rack with the available rails



To install the VessJBOD unit into a rack with the available mounting rails:

1. Check the fit of the mounting rails in your rack system.
See page 10, Figure 2.
2. Adjust the length of the mounting rails as needed.
The rear rail slides inside the front rail. The rail halves are riveted together and use no adjustment screws.
3. Attach the mounting rail assemblies to the outside of the rack posts, using the attaching screws and flange nuts from your rack system.
Be sure the front rail support is on the bottom facing inward.
The alignment pins fit into the rack holes above and below the attaching screws.
Use the attaching screws and flange nuts from your rack system. Tighten the screws and flange nuts according to your rack system instructions.
4. Place the VessJBOD unit onto the rails.
5. Secure the VessJBOD unit to the rack.
One screw each side, in the upper hole only. Use the attaching screws and flange nuts from your rack system. Tighten the screws and flange nuts according to your rack system instructions.

Figure 2. Rack mount assembly diagram



This completes rack mounting. Go to "Installing Disk Drives" on page 11.

Installing Disk Drives

The VessRAID subsystems and VessJBOD expansion units support:

- SAS and SATA hard disk drives
- 3.5-inch hard disk drives

For a list of supported physical drives, download the latest compatibility list from the PROMISE [support web site](#).

Drive Slot Numbering

You can install any suitable disk drive into any slot in the enclosure. The diagram below shows how VessJBOD's drive slots are numbered. Whether you have the original or plus carriers, the slots are numbered the same.

Slot numbering is reflected in the WebPAM PROe and CLU user interfaces. See Figures 8 and 9.

Figure 3. 16-bay VessJBOD drive slot numbering




Figure 4. 12-bay VessJBOD drive slot numbering




Install all of the drive carriers into the VessJBOD enclosure to ensure proper airflow, even if you do not populate all the carriers with disk drives.

Installing Your Disk Drives

1. Remove a disk drive carrier.
2. Carefully lay the disk drive into the drive carrier at the front, so that the screw holes on the sides line up.

3. Insert the screws through the holes in the drive carrier and into the sides of the disk drive.
 - Install only the counter-sink screws supplied with the VessJBOD.
 - Install four screws per drive.
 - Snug each screw. Be careful not to over-tighten.
 4. Reinstall the drive carrier into the VessJBOD enclosure.
- Repeat steps 1 through 3 until all of your disk drives are installed.

Figure 5. Disk drive mounted in a drive carrier



Caution

VessJBOD supports disk drive hot-swapping. To avoid hand contact with an electrical hazard, do not remove more than one drive carrier a time.

This completes disk drive installation. Go to “Making Data and Management Connections” on page 13.

Making Data and Management Connections

You can configure your VessJBOD as:

- JBOD Expansion to a VessRAID subsystem
- Drive enclosures for a SuperTrak RAID controller

JBOD Expansion to a VessRAID Subsystem

Configuring a Data Path

To establish the data path:

1. Connect the SAS HBA card in the Host PC to the SAS IN ports on the VessRAID controller. See page 14, Figure 6.
2. Connect the SAS Expansion port of the VessRAID controller to the SAS IN port on the I/O module of the first VessJBOD.
3. Connect the SAS OUT port of the VessJBOD I/O module of the first VessJBOD to the SAS IN port on the I/O module of the second VessJBOD.
4. Connect the remaining VessJBOD units in the same manner.

All SAS ports have SFF-8088 connectors.

Configuring a Management Path

VessRAID subsystems have one RAID controller. The controller has an Ethernet (RJ45) Management Port connector that enables you to monitor the VessJBOD subsystems over your network using the WebPAM PROe software.


To establish the management path:

1. Connect the Management port on each VessRAID controller to your network switch. See page 14, Figure 6.
2. Connect the Host PC's or Server's NIC to your network switch.

Direct Management of VessJBOD

A management connection directly to the VessJBOD uses a serial connection to the Host PC. See "Chapter 3: Management" on page 21 for more information.

Figure 6. Data and management connections with VessRAID



This completes data and management connections. Go to “Setting Up Serial Cable Connections” on page 17.

Drive Enclosures for a SuperTrak RAID Controller

Configuring a Data Path

To establish the data path:

1. Connect the SuperTrak RAID Controller in the Host PC to the SAS IN port on the I/O module of the first VessJBOD. See page 16, Figure 7.
2. Connect the SAS OUT port of the I/O module of the first VessJBOD to the SAS IN port on the I/O module of the second VessJBOD.
3. Connect the remaining VessJBOD units in the same manner.

All SAS ports have SFF-8088 connectors.

Configuring a Management Path


The SuperTrak RAID Controller installs in the Host PC, therefore it does not require a separate network management connection.

You can monitor the VessJBOD subsystems using the WebPAM PRO software installed on the Host PC.

Direct Management of VessJBOD

A management connection directly to the VessJBOD uses a serial connection to the Host PC. See “Chapter 3: Management” on page 21 for more information.

Figure 7. Data connections with SuperTrak




This completes data and management connections. Go to “Setting Up Serial Cable Connections” on page 17.

Setting Up Serial Cable Connections

Serial communication enables the Command Line Interface (CLI) on your PC to monitor and control the VessJBOD. The VessJBOD package includes a RJ11-to-DB9 serial data cable.

The CLI is explained in “Chapter 3: Management” on page 21.

Figure 8. The serial connector on the back of the VessJBOD



To set up a serial cable connection:

1. Attach the RJ11 end of the serial data cable to the RJ11 serial connector on the controller.
2. Attach the DB9 end of the serial data cable to a serial port on the Host PC or Server.

This completes the serial cable connection. Go to “Connecting the Power” on page 18.

Connecting the Power

Plug-in the power cord on the power supply on the back of the VessJBOD enclosure and switch on the power supply. If you have a VessJBOD 1830, 1830+, 1840, or 1840, plug-in and turn on both power supplies.

When the power is switched on, the LEDs light up.



Caution


After you turn the power supply switches off, you must wait at least 10 seconds before you turn the power switches on again.

Front Panel LEDs

When boot-up is finished and the VessJBOD subsystem is functioning normally:

- Power and Global Enclosure Status LEDs display green continuously.
- I/O Module Activity LED flashes green when there is controller activity.
- System Heartbeat LED blinks green once per second.


Figure 9. VessJBOD front panel LED display



I/O Module LEDs


When boot-up is finished and the VessJBOD subsystem is functioning normally:

- Fan LEDs display green continuously.
- SAS port LEDs flash green when there is activity.

Figure 10. VessJBOD I/O Module LEDs

Disk Drive LEDs

There are two LEDs on each drive carrier. They report the presence of a disk drive, activity of the drive, and the drive's current condition.

Figure 11. VessJBOD drive carrier LEDs

If there is a disk drive in the carrier, the Power/Activity LED displays green. If not, the Power/Activity LED remains dark. The Power/Activity LED flashes during drive activity.

The Disk Status LED displays green when a drive is configured.

This completes the power and start-up. Go to "Setting up the Serial Connection" on page 20.

Setting up the Serial Connection

VessJBOD has a Command Line Interface (CLI) to manage all of its functions via your PC's terminal emulation program, such as Microsoft HyperTerminal. This procedure uses the serial cable connection you made on page 17.

You must use the serial connection to run the CLI for direct management of the VessJBOD unit. See "Chapter 3: Management" on page 21.

To set up a serial connection:

1. Change your terminal emulation program settings to match the following specifications:
 - Bits per second: 115200
 - Data bits: 8
 - Parity: None
 - Stop bits: 1
 - Flow control: none
2. Start your PC's terminal VT100 or ANSI emulation program.
3. Press Enter once to launch the CLI.

When connected and ready, the CLI screen displays:

```
*****  
          Promise SAS Expander v2.00.0000.xx  
*****  
  
cli>
```

The **cli>** prompt on your screen indicates that you have a connection and the CLI is ready to accept commands.

Chapter 3: Management

This chapter covers the following topics:

- LEDs (below)
- CLI Command Set (page 25)

When attached to a VessRAID subsystem, you can manage the VessJBOD expansion unit using WebPAM PROe or the Command Line Utility (CLU). See the *VessRAID Product Manual* for more information.

This chapter describes monitoring and management functions directly from the VessJBOD expansion unit through its Command Line Interface (CLI).


LEDs

Front Panel LEDs

When boot-up is finished and the VessJBOD expansion unit is functioning normally:

- Power and Global Enclosure Status LEDs display green continuously.
- I/O Module Activity LED flashes green when there is controller activity.
- System Heartbeat LED blinks green once per second.

Figure 1. VessJBOD front panel LED display



See the table on the next page.

LEDs	State				
	Dark	Steady Green	Flashing Green	Amber	Red
Power	System Off	Normal	—	—	—
Global Enclosure Status	System Off	Normal	Locating the Enclosure	Fan, power supply, temperature, or voltage problem*	
I/O Module Activity	System Off or no SAS ports connected	One or more SAS ports connected	Activity	—	—
Controller Heartbeat	System Off	—	Normal**	—	—


* Check the I/O Module LEDs on the back of the enclosure. See page 22.
 ** Blinks green once per second.

I/O Module LEDs

When boot-up is finished and the VessJBOD subsystem is functioning normally. These LEDs give the status of individual components:

- Fan LEDs display green continuously.
- SAS port LEDs flash green when there is activity.

Figure 2. VessJBOD I/O Module LEDs




See the table on the next page.

LEDs	State				
	Dark	Green	Amber	Red	Blinking
Fan	Not detected	OK	One fan turning too slowly	Multiple fans turning too slowly	—
SAS Ports	No connection	Port connected	—	—	Green: Activity

Disk Drive LEDs

There are two LEDs on each drive carrier. They report the presence of a disk drive, activity of the drive, and the drive's current condition.

Figure 3. VessJBOD drive carrier LEDs



If there is a disk drive in the carrier, the Power/Activity LED displays green. If not, the Power/Activity LED remains dark. The Power/Activity LED flashes during drive activity.

The Disk Status LED displays green when a drive is configured.

If there is a disk drive in the carrier, the Power/Activity LED displays green. If not, the Power/Activity LED remains dark.

The Power/Activity LED flashes during drive activity.

The RAID subsystem controls the Disk Status LED behavior. With a VessRAID, the Disk Status LED displays green when a drive is configured.

See the table on the next page.

LEDs	State				
	Dark	Steady Green	Flashing Green	Amber	Red
Power/ Activity	No Drive	Drive Present	Activity	—	—
Status*	No Drive or Unconfigured	Drive OK	Locating the Drive	Drive Rebuilding	Array Drive Offline
* The RAID subsystem controls Disk Status LED behavior. The pattern described here is from a VessRAID.					

CLI Command Set

The CLI uses the following set of commands:

- **cable** – Specifies the length of cable for optimal signal quality. See page 25.
- **enclosure** – Displays full information on the VessJBOD enclosure and its components. See page 26.
- **factorydefault** – Restores factory default settings. See page 29.
- **help** – Use alone to see the list of commands. Use with a command to see a list of options. Examples: **enclosure -help** or **enclosure -h**. See page 30.
- **link** – Displays the current status of the PHYs (links), error counter, expander and attached SAS addresses. See page 30.
- **route** – Displays addresses of components through a downstream (expansion) connection. See page 34.
- **uptime** – Displays the number of days, hours, minutes and seconds since the firmware was loaded (since the VessJBOD was started or restarted). See page 35.
- **vpdr** – Displays vital product data on field replaceable units. See page 36.
- **?** – Use alone to see the list of commands. Use with a command to see a list of options. Example: **enclosure -?** See page 36.




Note

Command options are NOT case-sensitive.

Cable Command

The Cable command displays the current cable length settings for the two SAS ports. The I/O module supports cables from 1 to 8 meters in length.

Figure 4. VessJBOD SAS ports



CN#1 refers to the SAS IN port and CN#2 refers to the SAS OUT port on the I/O module. See above, Figure 4.

To view the current settings:

At the cli> prompt, type **cable** and press Enter.

The system returns:

```
CN#1 Cable Length = 1 meter
```

```
CN#2 Cable Length = 1 meter
```

To set Expansion connector CN2 for a 3-meter cable:

At the cli> prompt, type **cable -a mod -s "cn2=3"** and press Enter.

The system returns:

```
Cable length of connector 2 is set to 3 meter
```

Enclosure Command

The Enclosure command:

- Enables you to reboot the VessJBOD enclosure (below)
- Displays information about the VessJBOD enclosure (page 27)
- Enables you to make enclosure settings (page 28)

Rebooting the Controller



Caution

A controller reboot does NOT meet the system restart requirements for a firmware upgrade.


You can reboot just the controller (I/O module). This action might be needed to help with setting changes on the VessJBOD.

To reboot the only the controller:

1. Verify that no data I/O activity is in progress.
2. At the cli> prompt, type **enclosure -a mod -s "reboot=1"** and press Enter.
When the cli> prompt reappears, the controller has rebooted.

To reboot the entire JBOD expansion unit:

1. Verify that no data I/O activity is in progress.
2. Turn the power supply switch (switches) OFF.
3. Wait 10 seconds.
4. Turn the power supply switch (switches) ON.
See page 27, Figure 5.

Figure 5. VessJBOD power supply switches

Viewing Information

To view enclosure information:

At the cli> prompt, type **enclosure** and press Enter.

The system returns:

```
-----
Time since system powerup: 1 day 9 hours 46 minutes 36 seconds
Enclosure       : SAS JBOD 3U-16 Bay
Serial Number   : Cx20j-12345
I/O Module ID   : 1           Max I/O Module Cnt   : 1
Firmware Version : 02.00.0000.xx I/O Module Role   : Primary
Max HDD Slots    : 16           Max Connectors    : 2
Max PSU Cnt     : 2             Max Fan Cnt       : 2
Max Temp Sensor Cnt : 8         Max Voltage Sensor Cnt : 2
=====
CU      Status      Fan1Speed      Fan2Speed
=====
1       Operational  4735 rpm      4037 rpm
=====
ID      Location      Temp Reading
=====
1       I/O Module      27C/80F
=====
Thermal Management      : Enabled
Allows to shut down the system when
critical temperature is reached : Yes
Current minimum fan speed (1-4) : Level 1
```

Controller temperature threshold : 71C/159F (critical)
 61C/141F (warning)

```

=====
ID                Location          Voltage
=====
1                 I/O Module      4.825V
2                 I/O Module      12.360V
-----
    
```

Enclosure Settings List

The Enclosure command enables you to make settings for the enclosure.

- **Enclosure Warning Temperature** – Measured at the backplane. Fan speed increases until temperature falls below the threshold.
- **Enclosure Critical Temperature** – Measured at the backplane. Temperature value for automatic shutdown.
- **Controller Warning Temperature** – Measured inside the I/O module. Fan speed increases until temperature falls below the threshold.
- **Controller Critical Temperature** – Measured inside the I/O module. Temperature value for automatic shutdown.
- **Thermal Management** – Monitors enclosure temperature, adjusts fan speeds, displays red LED on cooling unit when a fan fails
- **Automatic Shutdown** – Shuts down the VessJBOD 30 seconds after the enclosure or controller reaches critical temperature.
- **Minimum Fan Speed** – Specifies the minimum fan speed when the VessJBOD reaches enclosure or controller warning temperature.

Making Enclosure Settings

To set the enclosure warning temperature to 51°C (141°F):

At the cli> prompt, type **enclosure -a mod -s "enc_warning=51"** and press Enter.

Warning temperature range is 10° to 51°C (50° to 123°F)

To set the enclosure critical temperature to 61°C (141°F):

At the cli> prompt, type **enclosure -a mod -s "enc_critical=61"** and press Enter.

Critical temperature range is 51° to 61°C (123° to 141°F)

To set the controller warning temperature to 51°C (141°F):

At the cli> prompt, type **enclosure -a mod -s "ctrl_warning=75"** and press Enter.

Warning temperature range is 10° to 75°C (50° to 172°F)

To set the controller critical temperature to 61°C (141°F):

At the cli> prompt, type **enclosure -a mod -s "ctrl_critical=90"** and press Enter.

Critical temperature range is 75° to 90°C (172° to 194°F)

To enable Thermal Management:

At the cli> prompt, type **enclosure -a mod -s "thermalmanager=1"** and press Enter.

For this command, a **1** enables and a **0** disables.

To enable Automatic Shutdown:

At the cli> prompt, type **enclosure -a mod -s "allowshutdown=1"** and press Enter.

For this command, a **1** enables and a **0** disables.



Caution

Promise recommends that you keep Automatic Shutdown enabled at all times.

To set the minimum fan speed to medium high:

At the cli> prompt, type **enclosure -a mod -s "minfanspeed=3"** and press Enter.

For this command:

- **1** means low
- **2** means medium-low
- **3** means medium-high
- **4** means high

The actual speed depends on the fan manufacturer.

Factory Default Command

The factory default command enables you to restore factory default settings in the VessJBOD enclosure.

To restore the enclosure to the default settings:

At the cli> prompt, type **factorydefault -a mod -s "default=1"** and press Enter.

Or, at the cli> prompt, type **factorydefaults** and press Enter.

When the cli> prompt appears again, all settings have been restored to the default values.

Help Command

The VessJBOD CLI uses the standard Unix online help system.

To access general help:

At the cli> prompt, type **help** and press Enter.

To access help with a specific function:

At the cli> prompt, type **help** followed by the name of the function and press Enter.

Or, at the cli> prompt, type the name of the function followed by **-h** and press Enter.


See “CLI Command Set” on page 25 for a list of supported functions.

Link Command

The Link command displays information about VessJBOD links, including:

- Link Status (page 30)
- Link Statistics (page 32)
- Clearing Statistics (page 33)
- Expander SAS Addresses (page 33)
- Attached SAS Addresses (page 33)

Figure 6. VessJBOD drive slot numbering



Viewing Link Status

To view link status:

At the cli> prompt, type **link** and press Enter.

The system returns:

Link Status:

```

=====
Phy    Port      Type   Rate   Init   Dev    Link   PRdy
=====
 0    DSK01     SAS    3.0G   OK     End    ----   Rdy
 1    DSK02     SAS    3.0G   OK     End    ----   Rdy
 2    DSK03     SAS    3.0G   OK     End    ----   Rdy
 3    DSK04     SAS    3.0G   OK     End    ----   Rdy
 4    DSK05     SAS    3.0G   OK     End    ----   Rdy
 5    DSK06     SAS    3.0G   OK     End    ----   Rdy
 6    DSK07     SAS    3.0G   OK     End    ----   Rdy
 7    DSK08     SAS    3.0G   OK     End    ----   Rdy
 8    DSK09     SAS    3.0G   OK     End    ----   Rdy
 9    DSK10     SAS    3.0G   OK     End    ----   Rdy
10    DSK11     SAS    3.0G   OK     End    ----   Rdy
11    DSK12     SAS    3.0G   OK     End    ----   Rdy
12    DSK13     SAS    3.0G   OK     End    ----   Rdy
13    DSK14     SAS    3.0G   OK     End    ----   Rdy
14    DSK15     SAS    3.0G   OK     End    ----   Rdy
15    DSK16     SAS    3.0G   OK     End    ----   Rdy
16    CN#1      ----   ----   ----   ----   ----   ----
17    CN#1      ----   ----   ----   ----   ----   ----
18    CN#1      ----   ----   ----   ----   ----   ----
19    CN#1      ----   ----   ----   ----   ----   ----
20    CN#2     SAS    3.0G   OK     End    ----   Rdy
21    CN#2     SAS    3.0G   OK     End    ----   Rdy
22    CN#2     SAS    3.0G   OK     End    ----   Rdy
23    CN#2     SAS    3.0G   OK     End    ----   Rdy
Phy : PHY ID          Port: Port Id        Type: SAS or SATA
Rate: Rate 3G/6G     Init: Init Passed    Dev : Device Type
Link: Link Connected PRdy: Phy Ready
=====

```

The following items are reported in the table above:

- **Phy** – Each link is a PHY, numbered 0 through 23
- **Port** – DSK01 through DSK16 represent drive slots. Each slot has one PHY. See page 30, Figure 6.

CN#1 refers to the SAS IN port and CN#2 refers to the SAS OUT port on the I/O module. Each port has four PHYs. See page 25, Figure 4.

- **Type** – Physical drive type, SAS or SATA

- **Rate** – Physical drive data rate, 3.0 Gb/s
- **Dev** – Device type. End means an end device. Exp means an expansion device
- **Link** – Normally, ---- is displayed. If there is a connection at the moment the link command runs, it displays CONN
- **PRdy** – PHY Ready Status. If the port is ready, it displays Rdy

Viewing Link Statistics

To view link status:

1. At the cli> prompt, type **link** and press Enter.
2. Scroll down to Link Statistics.

The screen displays:

Link Statistics:

```

=====
Phy  Type  InDW  DsEr  DwLo  PhRe  CoVi  PhCh
=====
 0  DSK01  -----  -----  -----  -----  -----  0x11
 1  DSK01  -----  -----  -----  -----  -----  0x61
 2  DSK01  -----  -----  -----  -----  -----  0x0D
 3  DSK01  -----  -----  -----  -----  -----  0x0D
 4  DSK01  -----  -----  -----  -----  -----  0x01
 5  DSK01  -----  -----  -----  -----  -----  0x61
 6  DSK01  -----  -----  -----  -----  -----  0x11
 7  DSK01  -----  -----  -----  -----  -----  0x0D
 8  DSK01  -----  -----  -----  -----  -----  0x0D
 9  DSK01  -----  -----  -----  -----  -----  0x01
10  DSK01  -----  -----  -----  -----  -----  0x0D
11  DSK01  -----  -----  -----  -----  -----  0x0D
12  DSK01  -----  -----  -----  -----  -----  0x01
13  DSK01  -----  -----  -----  -----  -----  0x5D
14  DSK01  -----  -----  -----  -----  -----  0x0D
15  DSK01  -----  -----  -----  -----  -----  0x09
16  CN#1   -----  -----  -----  -----  -----  ----
17  CN#1   -----  -----  -----  -----  -----  ----
18  CN#1   -----  -----  -----  -----  -----  ----
19  CN#1   -----  -----  -----  -----  -----  ---
20  CN#2   -----  -----  -----  -----  -----  0x8F
21  CN#2   -----  -----  -----  -----  -----  0x8F
=====

```

22	CN#2	-----	-----	-----	-----	-----	0x8F
23	CN#2	-----	-----	-----	-----	-----	0x8F

The following items are reported in the table above. All counts are hexadecimal:

- **Phy** – Each link is a PHY, numbered 0 through 23
- **Port** – DSK01 through DSK16 represent drive slots. Each slot has one PHY. See page 30, Figure 6.

CN#1 refers to the SAS IN port and CN#2 refers to the SAS OUT port on the I/O module. Each port has four PHYs. See page 25, Figure 4.

- **InDW** – Invalid D-word Count
- **DsER** – Disparity Error Count
- **DwLo** – Dword Sync Loss Count
- **PhRe** – PHY Reset Problem Count
- **CoVi** – Code Violation Count
- **PhCh** – PHY Change Count

If the count is zero, the counter shows dashes (-----).

The fact that errors occur does not necessarily indicate a problem or that the VessJBOD unit is malfunctioning.

An individual error count that increments regularly indicates a possible problem and requires further investigation.

Clearing Statistics

To clear the link error statistics:

At the **cli>** prompt, type **link -a clear -c "stats"** and press Enter.

Viewing SAS Addresses

To view SAS addresses:

1. At the **cli>** prompt, type **link** and press Enter.
2. Scroll down to Expander SAS Addresses or Attached SAS Addresses.

The screen displays:

Expander SAS Addresses:

```

=====
Type                SAS Address
=====
Base                50 00 15 5D 21 12 22 00
SSP                 50 00 15 5D 21 12 22 3E
SMP                 50 00 15 5D 21 12 22 3F

```

Attached SAS Addresses:

```

=====
Port                SAS Address
=====
DSK01              50 00 15 E0 11 4E 5E B2
DSK02              50 00 15 E0 11 4E 80 C2
DSK03              50 00 15 E0 11 4C 22 02
DSK04              50 00 15 E0 11 4D E2 22
DSK05              50 00 15 E0 11 4D 8F B2
DSK06              50 00 15 E0 11 4D D0 62
DSK07              50 00 15 E0 11 4D DE E2
DSK08              50 00 15 E0 11 4D 8E F2
DSK09              50 00 15 E0 11 4C 97 62
DSK10              50 00 15 E0 11 4C 36 62
DSK11              50 00 00 E0 11 4F 18 E2
DSK12              50 00 00 E0 11 4F 18 D2
DSK13              50 00 00 E0 11 4D 8E 52
DSK14              50 00 00 E0 11 4D E2 22
DSK15              50 00 00 E0 11 4E 49 C2
DSK16              50 00 00 E0 11 4D DC F2
CN#1               No Device Attached
CN#2               50 00 15 5F FF C0 22 3F
=====

```

The following items are reported in the table above:

- **Port** – DSK01 through DSK16 represent drive slots. Each slot has one PHY. See page 30, Figure 6.
 CN#1 refers to the SAS IN port and CN#2 refers to the SAS OUT port on the I/O module. Each port has four PHYs. See page 25, Figure 4.
- **SAS Address** – The SAS address of the drive slot or the port.

Route Command

To view the SAS addresses of the devices in your domain:

At the cli> prompt, type **route -a list** and press Enter.

The system returns:

Routing Table Mapping:

```

Entry#           SAS Address           CnID
-----
0159             500000E0114D8FB2     CN#2

```

0163	500000E0114C2252	CN#2
0202	500000E0120B3562	CN#2
0238	500000E01212F582	CN#2
0287	500000E0120B26B2	CN#2
0365	5000155FFFC0223E	CN#2
0462	500000E0114F18F2	CN#2
0468	500000E01205B472	CN#2
0542	500000E01122C5B2	CN#2
0624	500000E0114E4A32	CN#2
0639	500000E0114D8E32	CN#2
0700	500000E0120B2A62	CN#2
0721	500000E0114DE7A2	CN#2
0751	500000E0114E5EA2	CN#2
0764	500000E0120B28F2	CN2
0765	500000E0114C2342	CN#2
0977	500000E0120A2472	CN#2
1023	5000155FFFC02408	CN#2

The route command displays SAS addresses that are attached to the SAS ports of the VessJBOD unit. Three items are reported:

- **Entry#** – Arbitrary numbers, listed in sequence
- **SAS Address** – Of the disk drive or other component
- **CnID** – External SAS port connector

CN#1 refers to the SAS IN port and CN#2 refers to the SAS OUT port on the I/O module. Each port has four PHYs. See page 25, Figure 4.

Route Troubleshooting

If your system returns:

```
No SAS Routing Entry Exists
```

...it indicates that no downstream devices are found.

Uptime Command

The uptime command informs you of the elapsed period of time since the VessJBOD unit was powered on.

To display uptime:

At the cli> prompt, type **uptime** and press Enter.

The system returns:

System has been running 1 day 9 hours 46 minutes 36 seconds

VPDR Command

The `vpdr` command displays vital product data on the major components of the VessJBOD enclosure.

To display vital product data:

At the cli> prompt, type **vpdr -i** and the number of the component, and press Enter.

For this command:

- **1** – Controller (I/O module)
- **6** – Backplane

For example, **vpdr -i 1** returns:

```
Board ID           :0
OEM Name           :PROMISE
OEM Model          :Cx20s-Jbod
Mfg Part           :IOC-C620s-01
Mfg SN             :B17D07138400004
Mfg Rev            :A1R1.0
Mfg Date           :2009:02:15
WWN                 :20 00 01 01 55 FF FC 0D
```

? Command

The VTrak CLI uses the standard Unix online help system.

To access help with a specific function, do one of the following actions:

- At the cli> prompt, type **?** followed by the name of the function and press Enter.
- At the cli> prompt, type the name of the function followed by **-?** and press Enter.

See “CLI Command Set” on page 25 for a list of supported functions.

Chapter 4: Maintenance

This chapter covers the following topics:

- Updating the Firmware (below)
 - Replacing a Power Supply (page 41)
 - Replacing an I/O Module (page 42)
 - Replacing a Cooling Fan (page 43)
-

Updating the Firmware

There are two ways to update the VessJBOD's firmware.

- Through a VessRAID subsystem using WebPAM PROe
- With the JBOD Flash Utility

Downloading the Firmware Image File

Go to the Promise web site at http://www.promise.com/support/support_eng.asp and download the latest firmware image (.img) file to your TFTP server or your Host PC. The firmware image file includes all of the files to update the VessJBOD.

Updating Firmware in WebPAM PROe

You can use this procedure if your VessJBOD expansion unit is managed by a VessRAID subsystem. This procedure updates the firmware on the VessRAID and any attached VessJBOD expansion units through WebPAM PROe.

For more information on WebPAM PROe, see “Chapter 4: Management with WebPAM PROe” and “Chapter 8: Maintenance” in the *VessRAID Product Manual*.




Warning

Do not restart the VessJBOD during a firmware upgrade procedure. Wait until you see the *Flash image completed* message.

To update the firmware:

1. Click the Subsystem  icon.
2. Click the Software Management  icon.
3. Click the **Firmware Update** tab.
4. Do one of the following actions:

- Click the *Download Flash File from TFTP Server* option, then click the **Next** button.
 - Click the *Download Flash File from Local File through HTTP* option, then click the **Next** button.
5. For the TFTP Server option:
- Enter the hostname or IP address of your TFTP server in the field provided.
 - Enter the port number of your TFTP server in the field provided (69 is the default).
 - Enter the filename of the Firmware Update file in the field provided. The filename is similar to *exp.fw.2.03.0000.00.bin*.
 - Click the **Submit** button.
- For the Local File option:
- Click the **Browse** button.
 - Navigate to the Firmware Update file. The filename is similar to *exp.fw.2.03.0000.00.bin*.
 - Click the file, then click the **Open** button.
 - Click the **Submit** button.
6. When the download is completed, click the **Next** button.
A popup message appears warning you not to reboot the VessRAID during the firmware update procedure.
7. In the popup message, click the **OK** button.
The update progress displays. Then a popup message appears to tell you to reboot the VessRAID.
8. In the popup message, click the **OK** button.
9. Restart the VessRAIDs and VessJBODs:
- Shut down the VessRAID subsystems. See the *VessRAID Product Manual*.
 - On the VessJBOD expansion units, turn OFF the power supply switches. See page 39, Figure 1.
 - Wait 30 seconds, then turn ON the VessJBOD power supply switches.
 - Wait 30 additional seconds, then turn ON the VessRAID power supply switches.

Figure 1. VessJBOD power supply switches

To verify the firmware update:

At the cli> prompt, type **enclosure** and press Enter.

For more information, see “Enclosure Command” on page 26.



Note

After you click the **Submit** button, if WebPAM PROe displays this message: *error transferring image*, you entered an incorrect file name or an incorrect location. Check the information and try again.

Updating Firmware with the JBOD Flash Utility

The download firmware image (.img) file package includes a Windows-based utility to update the firmware on the VessJBOD. The JBOD utility:

- Updates firmware on VessJBOD subsystems only
- Updates one VessJBOD at a time
- Runs on Windows PCs over a RS232 serial connection
- Works with any RAID system configuration

Preparing the Utility

To prepare the utility:

1. Verify that your serial connection from your PC to the VessJBOD is online. See “Setting up the Serial Connection” on page 20.
2. Unzip the firmware download, locate and open the *expfwdlutil* folder.

The utility file is **expfwdlutil_<version number>.exe**.

By default, the utility connects to the VessJBOD through the Host PC's COM1 port.

If you are using a different COM port, you must change the port setting in the configuration file.

To access the configuration file and change the COM port setting:

1. Double click the **expfwdlutil_<version number>.exe** file to start the utility.
2. In the Flash Utility dialog box, click the **Quit** button. In the Warning box, click the **Yes** button.

When the utility opened, it created a **fwdl.ini** file in the same directory.

3. Open the **fwdl.ini** configuration file in a text editor and change the *comport* number as required.

```
[settings]
file=
comport=1
```

The *file* value fills in automatically when you run the utility.

Save and close the **fwdl.ini** file.

Updating the Firmware



Warning

Do not restart the VessJBOD during a firmware upgrade procedure. Wait until you see the *Firmware download finished successfully* message.

To update the firmware:

1. Double click the **expfwdlutil_<version number>.exe** file.
The Flash Utility dialog box appears.
2. Click the **Browse** button and navigate to the Firmware Update file in the *firmware* folder.

The firmware file is **exp.fw.<version number>.bin**.

3. Click the file, then click the **Open** button.
4. Click the **Start** button.

The update begins. You can monitor progress on the Progress bar. The operation takes about four minutes.

5. When you see the message:

Firmware download finished successfully.

Please power cycle the system for the new firmware to take effect.

Click the **Quit** button. In the Warning box, click the **Yes** button.

6. Restart the VessJBOD:
 - Turn OFF the power supply switch (switches). See page 39, Figure 1.

- Wait 30 seconds, then turn ON the power supply switch (switches).

To verify the firmware update:

At the cli> prompt, type **enclosure** and press Enter.

For more information, see “Enclosure Command” on page 26.

Replacing a Power Supply

VessJBOD 1730 and 1740


The power supply on the VessJBOD 1730 and 1740 was not designed for onsite replacement. If you need to replace the power supply, contact Technical Support and make arrangements to return the subsystem to Promise for service. See page 48.

VessJBOD 1830, 1830+, 1840, and 1840+

The redundant power supplies on the VessJBOD 1830 and 1840 are designed as field-replaceable units. You can replace a power supply without removing the VessJBOD from the rack.

The redundant power supplies on the VessRAID 1800 Series are designed as field-replaceable units. You can replace a power supply without removing the VessRAID from the rack.

Figure 2. Replacing a Power Supply



A 1840 Series power supply is shown. The 1830 Series is similar.

Removing the old power supply

To remove the power supply:

1. Verify that the power supply LED is amber or red.
2. Switch off the power to the power supply you plan to replace.
3. Unplug the power cord.
4. Loosen and remove the retaining screw on the left side of the power supply.
5. Pull the power supply out of the VessRAID enclosure.

Installing the new power supply

To install the power supply:

1. Carefully slide the power supply into the enclosure.
2. Install and tighten the retaining screw on the left side of the power supply.
3. Plug in the power cord.
4. Switch on the power supply.
5. Verify that the new power supply LED is green.

This completes the power supply replacement procedure.

Replacing an I/O Module

The I/O module monitors and manages the logical drives. When the I/O module is replaced, all of your logical drive data and configurations remain intact because this logical drive information is stored on the disk drives.

I/O modules rarely fail. But you might have to remove and reinstall the same I/O module in order to replace a cooling fan as described in this chapter.




Caution

-
- Do not replace the I/O module based on LED colors alone. Only replace the I/O module when directed to do so by Promise Technical Support. See page 48.
 - Only a qualified technician should perform this procedure.
 - You must shut down the VessJBOD expansion unit before you can perform this procedure.
-

Removing the old I/O module

To replace the I/O module:

1. Shut down the VessJBOD. Turn OFF the power supply switch (switches). See page 39, Figure 1.
2. Disconnect the SAS, serial, and power cables.
3. On the I/O module, loosen the thumbscrew, swing the latch to the right and pull the I/O module out of the enclosure. See Figure 3.

Figure 3. Removing the I/O module

Installing the new I/O module

1. Carefully slide the new I/O module into the enclosure.
2. Swing the latch to the left and secure it with the thumbscrew.
3. Reconnect the SAS, serial, and power cables.
4. Switch on the power.

Turn ON the power supply switch (switches).

For more information about VessJBOD's start-up behavior, see "Connecting the Power" on page 18.

This completes the I/O module replacement procedure.

Replacing a Cooling Fan

Original Models

Original models include VessJBOD 1730, 1740, 1830, and 1840.




Cautions

- Only a qualified technician should perform this procedure.
- You must shut down the VessJBOD subsystem before you can perform this procedure.

To replace a fan:


1. Verify that the Fan LED on the I/O module is amber or red. See Figure 4.

Figure 4. Fan LEDs




2. Shut down the VessJBOD and remove the I/O module.
See "Replacing an I/O Module" on page 42.
3. Lay the I/O module on a non-static surface and remove the cover attaching screws, one on each side, then remove the cover.
See page 44, Figure 5.

Figure 5. I/O module cover and attaching screw. 3U model shown



4. Remove the four attaching screws. See Figure 6.
5. Detach the fan's power connector and lift the old fan out of the I/O module.

Figure 6. I/O module cooling fan. 3U model shown

6. Place a new fan in the I/O module, attach the power connector, and install the four attaching screws.
7. Attach the I/O module cover and install the two attaching screws.
See Figure 5.
8. Reinstall the I/O module.
See “Replacing an I/O Module” on page 42.

This completes the fan replacement procedure.

Plus Models

Plus models include the VessJBOD 1830+ and 1840+.



Cautions


Only a qualified technician should perform this procedure.

The VessJBOD Plus models have externally mounted fans that are replaceable without shutting down the expansion unit.

To replace a fan:

1. Verify that the Fan LED on the I/O module is amber or red. See page 46, Figure 7.

Figure 7. Fan LEDs and mounting screws



2. Remove the two fan mounting screws.
 3. Draw the fan away from the I/O module and unplug the fan's power wire.
 4. Connect the new fan's power wire.
 5. Place the new fan onto the I/O module and install the two mounting screws.
- This completes the fan replacement procedure.

Chapter 5: Support

This chapter covers the following topics:

- Frequently Asked Questions (below)
 - Contacting Technical Support (page 48)
 - Limited Warranty (page 51)
 - Returning the Product For Repair (page 53)
-

Frequently Asked Questions

What kind of disk drives can I use with VessJBOD?

The VessJBOD supports 3.0 GB/s Serial ATA disk drives and 3.0 Gb/s SAS drives.

VessJBOD does not support Parallel ATA (PATA) disk drives.

Can I take the disk drives from my Promise VTrak, put them into the VessJBOD, and keep my disk array or logical drive intact?

Yes. Like VessJBOD, the newer VTrak subsystems use the industry-standard DDF method of disk metadata, stored in the reserve sector of each physical drive. Use the Transport function to prepare your disk drives before moving them. See “Preparing the Disk Array for Transport” in the *VessRAID Product Manual*.

Early VTrak subsystems used a proprietary method of disk metadata. VessRAID subsystems have a metadata-to-DDF conversion feature that converts disk drives in attached VessJBOD enclosures. To use the conversion feature, you must restart the VessRAID and VessJBOD after installing disk drives from an older VTrak subsystem.

Note that if you move your disk drives from the VessJBOD to an early VTrak, the older subsystem will not recognize your disk array or logical drive.

How can I tell when the VessJBOD has fully booted?

When the VessJBOD unit is fully booted up, the Power and FRU LEDs will light up green. The heartbeat LED blinks green once a second.

What happens if a disk drive fails?

Depending on the nature of the failure, the failed drive the drive might not appear in the CLI – or the failed drive might appear with some errors – when you run the **link** command. See page 30.

Can I hot-swap a failed drive with a new one?

Yes. Disk drives are hot-swappable on the VessJBOD.

Can a VessJBOD 1840 run using just one power supply?

Yes, it is possible to run the VessJBOD 1840 on a single power supply. There are two power supplies so that the 1840 will continue running if one of the power supply fails. But deliberately leaving one power supply off negates this advantage.

In addition, leaving one power supply off reduces air flow through the VessRAID enclosure and can contribute to overheating. Always switch on both power supplies.

Contacting Technical Support

Promise Technical Support provides several support options for Promise users to access information and updates. We encourage you to use one of our electronic services, which provide product information updates for the most efficient service and support.

If you decide to contact us, please have the following information available:

- Product model and serial number
- BIOS, firmware, and driver version numbers
- A description of the problem / situation
- System configuration information, including: motherboard and CPU type, hard drive model(s), SAS/SATA/ATA/ATAPI drives & devices, and other controllers.

Technical Support Services

PROMISE Online™ Web Site	http://www.PROMISE.com/support/support_eng.asp (technical documents, drivers, utilities, etc.)
--------------------------	--

United States

E-mail Support	e-Support On-Line
Fax Support	+1 408 228 1100 Attn: Technical Support
Phone Support	+1 408 228 1400 option 4
If you wish to write us for support:	PROMISE Technology, Inc. 580 Cottonwood Drive Milpitas, CA 95035, USA

The Netherlands

E-mail Support	e-Support On-Line
Fax Support	+31 0 40 256 9463 Attn: Technical Support
Phone Support	+31 0 40 235 2600
If you wish to write us for support:	PROMISE Technology Europe B.V. Science Park Eindhoven 5542 5692 EL Son, The Netherlands

Germany

E-mail Support	e-Support On-Line
Fax Technical Support	+49 0 2 31 56 76 48 29 Attn: Technical Support
Phone Technical Support	+49 0 2 31 56 76 48 10
If you wish to write us for support:	PROMISE Technology Germany Europaplatz 9 44269 Dortmund, Germany

Italy

E-mail Support	e-Support On-Line
Fax Support	+39 0 6 367 124 00 Attn: Technical Support
Phone Support	+39 0 6 367 126 26
If you wish to write us for support:	PROMISE Technology Italy Piazza del Popolo 18 00187 Roma, Italia

Taiwan

E-mail Support	e-Support On-Line
Fax Support	+886 3 578 2390 Attn: Technical Support
Phone Support	+886 3 578 2395 ext. 8822 or 8823
If you wish to write us for support:	PROMISE Technology, Inc. 2F, No. 30, Industry E. Rd. IX Science-based Industrial Park Hsin-Chu 30075, Taiwan (R.O.C.)

China

E-mail Support	e-Support On-Line
Fax Support	+86 10 8857 8015 Attn: Technical Support
Phone Support	+86 10 8857 8085 or 8095
If you wish to write us for support:	PROMISE Technology China – Beijing Room 1108, West Wing Shi Chuang Plaza, Shangdi IT Park 22 Information Road Haidian District, Beijing 100085, China

E-mail Support	e-Support On-Line
Fax Support	+86 21 6249 4627 Attn: Technical Support
Phone Support	+86 21 6249 4192, 4193, or 4199
If you wish to write us for support:	PROMISE Technology China – Shanghai Room 508, Leader Tower 1189 West Wu Ding Road Jing An District, Shanghai 200042, China

Limited Warranty

PROMISE Technology, Inc. ("PROMISE") warrants that this product, from the time of the delivery of the product to the original end user:

- a) all components, except the cache backup battery, for a period of three (3) years;
- b) the cache backup battery, for a period of one (1) year;
- c) will conform to PROMISE's specifications;
- d) will be free from defects in material and workmanship under normal use and service.

This warranty:

- a) applies only to products which are new and in cartons on the date of purchase;
- b) is not transferable;
- c) is valid only when accompanied by a copy of the original purchase invoice.
- d) Is not valid on spare parts.

This warranty shall not apply to defects resulting from:

- a) improper or inadequate maintenance, or unauthorized modification(s), performed by the end user;
- b) operation outside the environmental specifications for the product;
- c) accident, misuse, negligence, misapplication, abuse, natural or personal disaster, or maintenance by anyone other than a PROMISE or a PROMISE-authorized service center.

Disclaimer of other warranties

This warranty covers only parts and labor, and excludes coverage on software items as expressly set above.

Except as expressly set forth above, PROMISE DISCLAIMS any warranties, expressed or implied, by statute or otherwise, regarding the product, including, without limitation, any warranties for fitness for any purpose, quality, merchantability, non-infringement, or otherwise. PROMISE makes no warranty or representation concerning the suitability of any product for use with any other item. You assume full responsibility for selecting products and for ensuring that the products selected are compatible and appropriate for use with other goods with which they will be used.

PROMISE DOES NOT WARRANT that any product is free from errors or that it will interface without problems with your computer system. It is your responsibility to back up or otherwise save important data before installing any product and continue to back up your important data regularly.

No other document, statement or representation may be relied on to vary the terms of this limited warranty.

PROMISE's sole responsibility with respect to any product is to do one of the following:

- a) replace the product with a conforming unit of the same or superior product;
- b) repair the product.

PROMISE shall not be liable for the cost of procuring substitute goods, services, lost profits, unrealized savings, equipment damage, costs of recovering, reprogramming, or reproducing of programs or data stored in or used with the products, or for any other general, special, consequential, indirect, incidental, or punitive damages, whether in contract, tort, or otherwise, notwithstanding the failure of the essential purpose of the foregoing remedy and regardless of whether PROMISE has been advised of the possibility of such damages. PROMISE is not an insurer. If you desire insurance against such damage, you must obtain insurance from another party.

Some states do not allow the exclusion or limitation of incidental or consequential damages for consumer products, so the above limitation may not apply to you.

This warranty gives specific legal rights, and you may also have other rights that vary from state to state. This limited warranty is governed by the State of California.

Your Responsibilities

You are responsible for determining whether the product is appropriate for your use and will interface with your equipment without malfunction or damage. You are also responsible for backing up your data before installing any product and for regularly backing up your data after installing the product. PROMISE is not liable for any damage to equipment or data loss resulting from the use of any product.

Returning the Product For Repair

If you suspect a product is not working properly, or if you have any questions about your product, contact our Technical Support Staff through one of our Technical Services, making sure to provide the following information:

- Product model and serial number (required)
- Return shipping address
- Daytime phone number
- Description of the problem
- Copy of the original purchase invoice

The technician will assist you in determining whether the product requires repair. If the product needs repair, the Technical Support Department will issue an RMA (Return Merchandise Authorization) number.



Important

Obtain an RMA number from Technical Support *before* you return the product and write the RMA number on the label. The RMA number is essential for tracking your product and providing the proper service.

Return **ONLY** the specific product covered by the warranty (do not ship cables, manuals, diskettes, etc.), with a copy of your proof of purchase to:

USA and Canada: PROMISE Technology, Inc.
Customer Service Dept.
Attn.: RMA # _____
47654 Kato Road
Fremont, CA 94538

Other Countries: Return the product to your dealer
or retailer.
Contact them for instructions
before shipping the product.

You must follow the packaging guidelines for returning products:

- Use the original shipping carton and packaging
- Include a summary of the product's problem
- Write an attention line on the box with the RMA number
- Include a copy of proof of purchase

You are responsible for the cost of insurance and shipment of the product to PROMISE. Note that damage incurred due to improper transport or packaging is not covered under the Limited Warranty.

When repairing returned products, PROMISE may replace defective parts with new or reconditioned parts, or replace the entire unit with a new or reconditioned unit. In the event of a replacement, the replacement unit will be under warranty for the remainder of the original warranty term from purchase date, or 30 days, whichever is longer.

PROMISE will pay for standard return shipping charges only. You will be required to pay for any additional shipping options (such as express shipping).

Index

Symbols

? command 36

A

about this manual 1
automatic shutdown 29

C

cable
 command 25
 RJ11-to-DB9 17
CE statement 6
clear statistics 33
Command
 ? 36
 cable 25
 CLI 25
 enclosure 26
 factory default 29
 help 30
 link 30, 47
 route 34
 set 25
 uptime 35
 vpdr 36
component data 36
connection
 power 18
 serial 17
controller
 activity LED 18, 21
 critical temp 29
 reboot 26
 warning temp 28

D

disk drive LEDs 19, 23
Disk drives
 install 11
disk drives
 from VTrak subsystem 47
 hot-swappable 47
 LEDs 23
 supported 47
download firmware image file 37
downstream devices 34

E

enclosure
 automatic shutdown 29
 command 26
 critical temp 28
 fan speed 29
 global status LED 18, 21
 information 27
 settings 28
 thermal management 29
 warning temp 28
error counts 33

F

factory default command 29
fan
 replace, original models 43
 replace, plus models 45
 speed 29
FCC statement 6
firmware update 37

H

I

- I/O module
 - reboot 26
 - replace 42
- information, view 27

K

- KCC statement 6

L

LED

- controller activity 18, 21
- disk drive activity 23
- disk drive power 23
- disk drive power, activity, status 19, 23
- disk drive status 23
- drive carrier 19, 23
- enclosure global status 18, 21
- front panel 18, 21
- power 18, 21
- system heartbeat 18, 21

link

- command 30, 47
- statistics 32
- status 30

M

- mapping, routing table 34

P

- PHY 31-??
- power
 - connection 18
 - LED 18, 21
- power supply, replace 41

R

- reboot
 - controller 26
 - I/O module 26
- regulatory statements 6
- replace
 - blower 43
 - fan 43
 - fan, original models 43
 - fan, plus models 45
 - I/O module 42
 - power supply 41
- returning product for repair 53
- RJ11-to-DB9 cable 17
- route command 34
- routing table mapping 34

S

SAS

- address 33, 34
- expander 33

- screws, counter-sink 12

settings

- default 29
- enclosure 28

- specifications, VessJBOD 4

statistics

- clear 33
- link 32

- status, link 30

subsystem

- heartbeat LED 18, 21
- maintenance 37
- management 21

T

- Technical Support, contact 48

temperature
 controller
 critical 29
 warning 28
 enclosure
 critical 28
 warning 28
thermal management 29
troubleshoot SAS routing 35

U

uptime command 35

V

VessJBOD
 features 3
 specifications 4
VessRAID
 models 2
 warranty 6, 51
VessRAID subsystem 37
vital product data 36
vpdr command 36

W

warranty on VessRAID 51
WebPAM PROe 37

