



X13QEH+

USER'S MANUAL

Revision 1.0a

The information in this user's manual has been carefully reviewed and is believed to be accurate. The manufacturer assumes no responsibility for any inaccuracies that may be contained in this document, and makes no commitment to update or to keep current the information in this manual, or to notify any person or organization of the updates. **Please Note: For the most up-to-date version of this manual, please see our website at www.supermicro.com.**


Super Micro Computer, Inc. ("Supermicro") reserves the right to make changes to the product described in this manual at any time and without notice. This product, including software and documentation, is the property of Supermicro and/or its licensors, and is supplied only under a license. Any use or reproduction of this product is not allowed, except as expressly permitted by the terms of said license.

IN NO EVENT WILL SUPER MICRO COMPUTER, INC. BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, SPECULATIVE, OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OR INABILITY TO USE THIS PRODUCT OR DOCUMENTATION EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN PARTICULAR, SUPER MICRO COMPUTER, INC. SHALL NOT HAVE LIABILITY FOR ANY HARDWARE, SOFTWARE, OR DATA STORED OR USED WITH THE PRODUCT, INCLUDING THE COSTS OF REPAIRING, REPLACING, INTEGRATING, INSTALLING, OR RECOVERING SUCH HARDWARE, SOFTWARE, OR DATA.

Any disputes arising between the manufacturer and customer shall be governed by the laws of Santa Clara County in the State of California, USA. The State of California, County of Santa Clara shall be the exclusive venue for the resolution of any such disputes. Supermicro's total liability for all claims will not exceed the price paid for the hardware product.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in an industrial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the manufacturer's instruction manual, may cause harmful interference with radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case you will be required to correct the interference at your own expense.

California Best Management Practices Regulations for Perchlorate Materials: This Perchlorate warning applies only to products containing CR (Manganese Dioxide) Lithium coin cells. "Perchlorate Material-special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate".



The products sold by Supermicro are not intended for and will not be used in life support systems, medical equipment, nuclear facilities or systems, aircraft, aircraft devices, aircraft/emergency communication devices or other critical systems whose failure to perform be reasonably expected to result in significant injury or loss of life or catastrophic property damage. Accordingly, Supermicro disclaims any and all liability, and should buyer use or sell such products for use in such ultra-hazardous applications, it does so entirely at its own risk. Furthermore, buyer agrees to fully indemnify, defend and hold Supermicro harmless for and against any and all claims, demands, actions, litigation, and proceedings of any kind arising out of or related to such ultra-hazardous use or sale.

Manual Revision 1.0a

Release Date: December 26, 2023

Unless you request and receive written permission from Super Micro Computer, Inc., you may not copy any part of this document. Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

Copyright © 2023 by Super Micro Computer, Inc.
All rights reserved.

Printed in the United States of America

Preface

About This Manual

This manual is written for system integrators, IT technicians, and knowledgeable end users. It provides information for the installation and use of the X13QEH+ motherboard in a system.

About This Motherboard

Supermicro X13QEH+ supports up to four 4th Gen Intel® Xeon® Scalable processors which offers up to 56 cores per CPU and a thermal design power (TDP) up to 350W. Built with the Intel C741 chipset, the X13QEH+ supports up to 16TB 3DS RDIMM/RDIMM DDR5 ECC memory with speeds up to 4800MT/s in 64 DIMM slots (**Note 1** below). This motherboard offers superior I/O expandability and flexibility, which features six PCIe 5.0 x16/x8 slots for add-on cards, two PCIe 3.0 x2/x4 M.2 connectors, 24x native NVMe SSDs from 17x MCIO (PCIe 5.0 x8) for hybrid riser cards, and two AIOM (Advanced I/O modules) for networking connections. It also boasts of the most advanced data protection capability that provides hardware RoT (Root of Trust) and TPM (Trusted Platform Module) support (**Note 2** below). The X13QEH+ is optimized for Virtualization, High Performance Computing (HPC), and high-density data storage. It is ideal for use in Google/Microsoft enterprise cloud servers, Oracle/SAP database servers, Softlayer/IBM/TSMC data center computing node, Fortinet/Fiberhome security node, and Fujitsu channel/SAP applications. Please note that this motherboard is intended to be installed and serviced by professional technicians only. For processor/memory updates, please refer to our website at <https://www.supermicro.com/en/products/motherboards>.



Note 1: Memory speed support depends on the processors used in the system.

Note 2: For TPM support, an optional part is needed. Contact Supermicro Technical Support for more information.

Conventions Used in the Manual

Special attention should be given to the following symbols for proper installation and for protection against possible component damage or bodily injury:



Important: Important information is given to ensure proper system installation or to relay safety precautions.



Warning! Important information is given to prevent component/system damage or personal injury.



Warning! Indicates that you may encounter high voltage when performing a task.



Note: Additional Information is given to provide information for proper system setup.

Contacting Supermicro

Headquarters

Address: Super Micro Computer, Inc.
980 Rock Ave.
San Jose, CA 95131 U.S.A.

Tel: +1 (408) 503-8000

Fax: +1 (408) 503-8008

Email: Marketing@supermicro.com (General Information)
Sales-USA@supermicro.com (Sales Inquiry: Non-Government)
Government_Sales-USA@supermicro.com (Sales Inquiry: Government)
Support@supermicro.com (Technical Support)
RMA@supermicro.com (RMA Support)

Website: www.supermicro.com

Europe

Address: Super Micro Computer B.V.
Het Sterrenbeeld 28, 5215 ML
's-Hertogenbosch, The Netherlands

Tel: +31 (0) 73-6400390

Fax: +31 (0) 73-6416525

Email: Sales_Europe@supermicro.com (General Information)
Support_Europe@supermicro.com (Technical Support)
RMA_Europe@supermicro.com (RMA Support)

Website: www.supermicro.nl

Asia-Pacific

Address: Super Micro Computer, Inc.
3F, No. 150, Jian 1st Rd.
Zhonghe Dist., New Taipei City 235
Taiwan (R.O.C)

Tel: +886-(2) 8226-3990

Fax: +886-(2) 8226-3992

Email: Sales-Asia@supermicro.com.tw (Sales Inquiry)
Support@supermicro.com.tw (Technical Support)
RMA@supermicro.com.tw (RMA Support)

Website: www.supermicro.com.tw

Table of Contents

Chapter 1 Introduction

1.1 X13QEH+ System Board Overview	7
1.2 Processor and Chipset Support	17
1.3 Special Features	18
1.4 System Health Monitoring	18
1.5 ACPI Features	18
1.6 Power Supply	19
1.7 Serial Port.....	19

Chapter 2 Installation

2.1 Static-Sensitive Devices.....	20
2.2 Processor and Heatsink Installation.....	21
The 4th Gen Intel Xeon Scalable Processor	21
Overview of the CPU Socket	25
Overview of the Processor Carrier Assembly	26
Overview of the Processor Heatsink Module (PHM)	27
Creating the Processor Carrier Assembly.....	29
Creating the PHM	33
Preparing the CPU Socket for Installation	36
Preparing to Install the PHM into the CPU Socket.....	37
Installing the PHM into the CPU Socket.....	40
Removing the PHM from the CPU Socket	42
Removing the Processor Carrier Assembly from the PHM	44
Removing the Processor from the Processor Carrier Assembly	46
2.3 Motherboard Installation.....	47
2.4 Memory Support and Installation	49
2.5 Rear I/O Connectors/Ports.....	53
2.6 Front Control Panels	57
2.7 Connectors and Headers	66
2.8 Jumper Settings	74
2.9 LED Indicators.....	81

Chapter 3 Troubleshooting

3.1 Troubleshooting Procedures	84
3.2 Technical Support Procedures	87
3.3 Frequently Asked Questions	88
3.4 Battery Removal and Installation	89
3.5 Returning Merchandise for Service.....	90

Chapter 4 UEFI BIOS

4.1 Introduction.....	91
4.2 Main Setup	92
4.3 Advanced Setup Configurations.....	94
4.4 Event Logs	143
4.5 BMC.....	145
4.6 Security.....	149
4.7 Boot	156
4.8 Save & Exit.....	158

Appendix A BIOS POST Codes

A.1 BIOS POST Codes.....	160
--------------------------	-----

Appendix B Software

B.1 Microsoft Windows OS Installation.....	161
B.2 Driver Installation.....	163
B.3 BMC.....	164
B.4 Logging into the BMC (Baseboard Management Controller).....	164

Appendix C Standardized Warning Statements

Chapter 1

Introduction

Congratulations on purchasing your computer motherboard from an industry leader. Supermicro motherboards are designed to provide you with the highest standards in quality and performance.

This motherboard is intended to be used in a Supermicro 4-way server as an integrated solution. It will not be sold as an independent product; no shipping package will be provided.

1.1 X13QEH+ System Board Overview

This chapter provides detailed information on the components installed on the X13QEH+ system board as well as specifications and features supported by your 4-way system.


Important Links

For your motherboard to work properly, please follow the links below to download all necessary drivers/utilities and the user's manual for your computer.

- Supermicro product manuals: <http://www.supermicro.com/support/manuals/>
- Product drivers and utilities: <https://www.supermicro.com/wdl/driver>
- Product safety info: <https://www.supermicro.com/en/about/policies/safety-information>
- A secure data deletion tool designed to fully erase all data from storage devices can be found at our website: https://www.supermicro.com/about/policies/disclaimer.cfm?url=/wdl/utility/Lot9_Secure_Data_Deletion_Utility/
- Firmware-related and AOC user's guides: <http://www.supermicro.com/support/manuals/>
- If you have any questions, please contact our support team at: support@supermicro.com


This manual may be periodically updated without notice. Please check the Supermicro website for possible updates to the manual revision level.

X13QEH+ Motherboard Image




Note: All graphics shown in this manual were based upon the latest PCB revision available at the time of publication of the manual. The motherboard you received may or may not look exactly the same as the graphics shown in this manual.

X13QE+ Motherboard Layout (not drawn to scale)



Note: Components not documented are for internal testing only.

Quick Reference



Notes:

- See [Chapter 2](#) for detailed information on jumpers, I/O ports, and FP1/FP2 front panel connections.
- "■" indicates the location of pin 1. Jumpers/LED indicators not indicated are used for testing only.
- Use only the correct type of onboard CMOS battery as specified by the manufacturer. Do not install the onboard battery upside down to avoid a possible explosion.


Quick Reference Table

Jumper	Description	Default Setting
J34	VRM Programming Write Protection	Pins 1/2: Normal
J145/J146	HDD Backpanel (BP) ID	Closed/Closed: 4 x 2 HDD
JBR1	ADR Complete	Pins 1/2: Normal
JBR2	BIOS Recovery	Pins 1/2: Normal
JBT1	Clear CMOS	Open (Normal)
JPG1	Video Display Enable	Pins 1/2: Video Display Enabled
JPME1	ME Recovery	Pins 1/2: Normal
JRU1	UID LED/BMC Reset	Closed: Normal (UID LED)
JSPD1	Memory SPD Remote	Open: BMC
JWD1	Watch Dog Timer Enable	Pins 1/2: Reset

LED	Description	Status
LED1 (UID-LED)	Unit Identifier (UID) LED	Solid Blue: Unit Identified
LED2 (LEDPWR)	Power LED	LED On: Onboard Power On
LED3	BMC Heartbeat LED	Blinking Green: BMC Normal (Active), Solid Green: (During BMC Reset or during a Cold Reboot)
LED4	CPU1 Power Status LED	Solid Red: Power Failure
LED5	CPU2 Power Status LED	Solid Red: Power Failure
LED6	CPU3 Power Status LED	Solid Red: Power Failure
LED7	CPU4 Power Statu LED	Solid Red: Power Failure

Connector	Description
BT1 (JBAT1)	Onboard battery
BMC_LAN (JUSBRJ45)	Dedicated BMC LAN on the rear I/O panel
COM1 (JCOM1)	COM/serial port on the rear I/O panel
DP1 (JDP1)	I/O device display port on the rear I/O panel
FAN1~4, FAN5~8	4-pin fan headers
FAN9~FAN12	6-pin cooling fan headers
FAN_PMB (JFAN1)	Fan for I ² C temperature sensor
FP1 (JF1)	Front Control Panel header with I ² C
FP2	Front Control Panel header with USB and VGA support
IPMB (JIPMB1)	4-pin BMC external I ² C header
I-SATA1 0~3 (JS1)	SATA header with four SATA connections (SATA1 0~3) from Intel PCH (with RAID 0, RAID 1, RAID 5, and RAID 10 supported)
I-SATA3 0~3 (JS2)	SATA 3.0 header with four SATA 3.0 connections (SATA3 0~3) from Intel PCH (with RAID 0, RAID 1, RAID 5, and RAID 10 supported)
JL1	Chassis Intrusion header
JMD1	M.2-H SATA2:0/PCIe 3.0 x4 hybrid slot 1 (with support of M-Key 2280, and 22110)
JMD2	M.2-H SATA2:4/PCIe 3.0 x2 hybrid slot 2 (with support of M-Key 2280, and 22110)
JPGW1/JPGW2	8-pin GPU power Connector 1/Connector 2

JPWR4 (BP_PWR5)/ JPWR5 (BP_PWR4)	4-pin power headers for backplane devices
JPWR7 (BP_PWR3)	8-pin backplane power Connector 3
JPWR8(BP_PWR1)	8-pin backplane power Connector 1
JPWR9 (BP_PWR2)	8-pin backplane power Connector 2
JTPM1	Trusted Platform Module/Port 80 connector (See Note 1 below.)
P1_PClE1A_VPP	PCIe 5.0 x8 by CPU1 (J140)
P1_PClE2A/2B	PCIe 5.0 x8 by CPU1 (J51)/(J50)
P2_PClE1A/1B	PCIe 5.0 x8 by CPU2 (J52/J53)
P3_PClE1A_VPP/1B_VPP	PCIe 5.0 x8 by CPU3 (J19/J18)
P3_PClE2A/2B	PCIe 5.0 x8 by CPU3 (J20/J21)
P3_PClE3A/3B	PCIe 5.0 x8 by CPU3 (J17/J16)
P4_PClE1A_VPP/1B_VPP	PCIe 5.0 x8 by CPU4 (J12/J13)
P4_PClE2A/2B	PCIe 5.0 x8 by CPU4 (J11/J10)
P4_PClE3A_VPP/3B_VPP	PCIe 5.0 x8 by CPU4 (J14/J15)
P1_AIOM PCIe 5.0 x8	Advanced I/O Module (AIOM) PCIe 5.0 x8 slot supported by CPU1 (J139)
P2_AIOM PCIe 5.0 x16	Advanced I/O Module (AIOM) PCIe 5.0 x16 slot supported by CPU2 (J7)
P1_HIO_R1 PCIe 5.0 x16 (J1)	PCIe 5.0 x16 hybrid slot for right riser card supported by CPU1
P2_HIO_L1 PCIe 5.0 x16 (J3)	PCIe 5.0 x16 hybrid slot for left riser card supported by CPU2
P2_PClE1A (J52)	PCIe 5.0 x8 MCIO connector supported by CPU2
PDB_SB1 (J47)	SMB I ² C for 4U power distribution board
PDB_SB2 (J26)	SMB I ² C for 4U power distribution board
PSU1/PSU2	Supermicro proprietary power supply units 1/2 for system use
UID (JUIDB1)	UID (Unit Identifier)/BMC Reset switch
USB0/1 (JUSBRJ45)	USB 3.0 ports 0/1 on rear I/O panel
USB2 (3.0) (JUSB1)	Type A USB 3.0 connector (USB2) for front access
VROC RAID Key (JRK1)	Intel VROC key header for NVMe RAID support (See Note 2 below.)


 **Note 1:** For TPM support, an optional note is needed. Contact Supermicro Tech Support for more information.

Note 2: For detailed instructions on how to configure VROC RAID settings, please refer to the VROC RAID Configuration User's Guide posted on the web page under the link: <http://www.supermicro.com/support/manuals/>.




Memory Slots

X13QE+ supports 16TB of DDR5 memory in 64 slots. Please refer to the drawing below for the locations of DIMM slots:

DIMMs by CPU1	DIMMs by CPU2	DIMMs by CPU3	DIMMs by CPU4
P1-DIMMA1	P2-DIMMA1	P3-DIMMA1	P4-DIMMA1
P1-DIMMA2	P2-DIMMA2	P3-DIMMA2	P4-DIMMA2
P1-DIMMB1	P2-DIMMB1	P3-DIMMB1	P4-DIMMB1
P1-DIMMB2	P2-DIMMB2	P3-DIMMB2	P4-DIMMB2
P1-DIMMC1	P2-DIMMC1	P3-DIMMC1	P4-DIMMC1
P1-DIMMC2	P2-DIMMC2	P3-DIMMC2	P4-DIMMC2
P1-DIMMD1	P2-DIMMD1	P3-DIMMD1	P4-DIMMD1
P1-DIMMD2	P2-DIMMD2	P3-DIMMD2	P4-DIMMD2
P1-DIMME1	P2-DIMME1	P3-DIMME1	P4-DIMME1
P1-DIMME2	P2-DIMME2	P3-DIMME2	P4-DIMME2
P1-DIMMF1	P2-DIMMF1	P3-DIMMF1	P4-DIMMF1
P1-DIMMF2	P2-DIMMF2	P3-DIMMF2	P4-DIMMF2
P1-DIMMG1	P2-DIMMG1	P3-DIMMG1	P4-DIMMG1
P1-DIMMG2	P2-DIMMG2	P3-DIMMG2	P4-DIMMG2
P1-DIMMH1	P2-DIMMH1	P3-DIMMH1	P4-DIMMH1
P1-DIMMH2	P2-DIMMH2	P3-DIMMH2	P4-DIMMH2



Motherboard Features

Motherboard Features	
CPU	<ul style="list-style-type: none"> Supports dual 4th Gen Intel® Xeon® Scalable (in Socket E LGA 4677) with three UPIs (16GT/s max.) and a thermal design power (TDP) up to 350W <p> Note: Three UPIs are supported by the CPU; however, only three UPIs are used on the motherboard.</p>
Memory	<ul style="list-style-type: none"> Supports up to 16TB 3DS RDIMM/RDIMM DDR5 (288-pin) ECC memory with speeds up to 4800MT/s in 64 DIMM slots <p> Note: Memory speed and capacity support depends on the processors used in the system.</p>
DIMM Size	<ul style="list-style-type: none"> Up to 512GB <p> Note: For the latest CPU/memory updates, please refer to our website at http://www.supermicro.com/products/motherboard.</p>
Chipset	<ul style="list-style-type: none"> Intel PCH C741
Expansion Slots	<ul style="list-style-type: none"> Two PCIe 5.0 x16 riser card slots One PCIe 5.0 x16 AOM connector and one PCIe 5.0 x8 AOM connector Seventeen MCIO PCIe 5.0 x8 connectors for 24 NVMe SSDs with support of PCIe slots on riser cards Two NVMe PCIe 3.0 x4/SATA2.0 Hybrid M.2 ports (with M-Key 2280 and 22110 support) Eight SATA 3.0 or twenty-four NVMe SSDs (via 12 x MCIO PCIe 3.0 x8)
Baseboard Management Controller (BMC)/Network	<ul style="list-style-type: none"> ASPEED AST2600 BMC One dedicated BMC LAN/VGA (via AST2600 BMC HW RoT)
Graphics	<ul style="list-style-type: none"> Graphics controller and VGA support via ASPEED AST2600 BMC
I/O Devices	<ul style="list-style-type: none"> One VGA connection header (FP2): used for dedicated VGA via BMC and for front accessible VGA connection One COM port on the rear I/O panel One BMC_LAN/USB0/1 (3.0) (JUSBRJ45) on the rear panel
Peripheral Devices	<ul style="list-style-type: none"> Three USB 3.0 (5Gbps) connections (2 rear: USB0/1, 1 Type A for front access: USB2) One I/O device display port on the rear I/O panel (DP1)
BIOS	<ul style="list-style-type: none"> AMI SPI BIOS EFI GUI, SPI dual/quad speed control, riser card auto detection support, IPMIView, SMCIPMITOOL, IPMI CFG, Redundant power supply unit detection, SPM, SUM-OOB/InBand

Power Management

- ACPI power management
- S1, S4, S5 support
- Power button override mechanism
- Power-on mode for AC power recovery
- Wake-on-LAN
- Power supply monitoring

System Health Monitoring

- Onboard voltage monitoring for +12V, +5V/+5V standby, +3.3V, and +3.3V standby, Vcore, Vmem
- Onboard temperature monitoring for CPU, VRM, LAN, PCH, system, and memory
- 7+1 CPU switch phase voltage regulator
- CPU thermal trip support
- Platform Environment Control Interface (PECI)

Fan Control

- Fan status monitoring via BMC connections
- Single cooling zone
- Low-noise fan speed control
- Eight 6-pin proprietary fan headers and two 4-pin fan headers

System Management

- Chassis intrusion header and detection
- Server platform service

Firmware Integrity/System Security


- TPM (Trusted Platform Module) support
- RoT (Root of Trust) support to protect firmware security by detecting critical data corruption, and restoring platform integrity

LED Indicators

- Power LED
- UID/remote UID
- LAN activity LED
- BMC/CPLD firmware LED

Dimensions

- 16.80" (W) x 22.87" (L) E-ATX (426.72 mm x 580.90 mm)

 **Note 1:** The CPU maximum thermal design power (TDP) is subject to motherboard SKU, chassis, and heatsink cooling restrictions. For proper thermal management, please check the chassis and heatsink specifications.

Note 2: For BMC configuration instructions, please refer to the Embedded BMC Configuration User's Guide available at <http://www.supermicro.com/support/manuals/>.




Figure 1-3.
System Block Diagram

Note 1: This is a general block diagram and may not exactly represent the features on your motherboard. See the previous pages for the actual specifications of your motherboard.

Note 2: Four UPIs are supported by the CPU; however, only three UPIs are used on the motherboard.

1.2 Processor and Chipset Support

Built upon the functionality and capability of the 4th Gen Intel® Xeon® Scalable (Socket E) and the Intel C741 PCH, the X13QEH+ motherboard offers critical, pivotal technological breakthroughs that unleash unprecedented computing capabilities and provides a scalable platform optimized for applications used in Artificial Intelligence (AI) Acceleration, Deep Learning Boost, Network Interconnectivity, and Platform Manageability technologies. The key features supported by the platform include the following:

Processor Features Supported

- Increased, scalable performance with substantial advancements, including UPI speed improvement, memory speed/capacity/utilization enhancement, hardware-based security innovations for virtualization, and platform interconnectivity optimization
- Integrated accelerators optimized for workload enhancement including Advanced Matrix Extensions (IntelAMX), In-Memory Analytics Accelerator (IAX), Data Streaming Accelerator (IntelDSA), and QuickAssist Technology (Intel QAT)
- Breakthroughs in memory and I/O support, including DDR5 (4800 MHz max.), PCIe 5.0 (80 lanes max.), and CXL 1.1 (4 devices per CPU)
- Increased operational and performance efficiency with substantial enhancements in virtualization, network security, and telemetry and power management
- Integrated AI accelerators with support of 3rd Gen Intel® Deep Learning Boost and new Tile Matrix Multiply (AMX/MUL)
- Enhanced Intel® Security Boost Software Guard Extensions with Integrity Platform Firmware Resilience support
- Intel® Ultra Path Interconnect (Intel® UPI) up to 4 links per processor at 16GT/s (*Note below)
- New Computer Express Link (CXL) and Intel® Speed Select Technology
- CPU with 52 physical address/57 virtual address support

PCH Features Supported

- Flexible I/O at 20 lanes for PCIe 3.0, and x4 DMI3 at PCIe 3.0



Note: Four UPIs are supported by the CPU; however, only three UPIs are used on the motherboard.

1.3 Special Features

Recovery from AC Power Loss

The Basic I/O System (BIOS) provides a setting that determines how the system will respond when AC power is lost and then restored to the system. You can choose for the system to remain powered off (in which case you must press the power switch to turn it back on), or for it to automatically return to the power-on state. See the Advanced BIOS Setup section for this setting. The default setting is **Last State**.

1.4 System Health Monitoring

Onboard Voltage Monitors


An onboard voltage monitor will scan the voltages of the onboard chipset, memory, and CPU continuously. Once a voltage becomes unstable, a warning is given, or an error message is sent to the screen.

Fan Status Monitor with Firmware Control

The system health monitor embedded in the BMC chip can check the RPM status of the cooling fans. The CPU and chassis fans are controlled via IPMI.

Environmental Temperature Control

System Health sensors monitor temperatures and voltage settings of onboard processors and the system in real time via the BMC interface. Whenever the temperature of the CPU or the system exceeds Supermicro's pre-defined threshold, the system and CPU cooling fan speed will increase to prevent the CPU or system from overheating.

 **Note:** To avoid possible system overheating, please be sure to provide adequate air-flow to your system.

1.5 ACPI Features

ACPI stands for Advanced Configuration and Power Interface. The ACPI specification defines a flexible and abstract hardware interface that provides a standard way to integrate power management features throughout a computer system, including its hardware, operating system and application software. This enables the system to automatically turn on and off peripherals such as network cards, hard disk drives and printers.

In addition to enabling operating system-directed power management, ACPI also provides a generic system event mechanism for Plug and Play, and an operating system-independent interface for configuration control. ACPI leverages the Plug and Play BIOS data structures,

while providing a processor architecture-independent implementation that is compatible with appropriate Windows operating systems. For detailed information regarding OS support, please refer to the Supermicro website.

1.6 Power Supply

As with all computer products, a stable power source is necessary for proper and reliable operation. It is even more important for processors that have high CPU clock rates where noisy power transmission is present.

The X13QEH+ motherboard accommodates two Supermicro proprietary power supply units (PSU1/PSU2), two 8-pin GPU power connectors (JPGW1/JPGW2), two 4-pin backplane power connectors (JPWR4/JPWR5), and three 8-pin backplane power connectors located at (JPWR7-JPWR9). Although most power supplies generally meet the specifications required by the CPU, some are inadequate. All these power connections are also required to ensure adequate power supply to the system.

Warning! To avoid damaging the power supply or the motherboard, be sure to use a power supply that accommodates two power supply units. Be sure to also connect the power supplies to the GPU power connectors located at JPGW1/JPGW2, the 4-pin backplane power connectors located at JPWR4/JPWR5, and the 8-pin backplane power connectors located at JPWR7-JPWR9 on the motherboard. Failure in doing so may void the manufacturer warranty on your power supply and motherboard.

It is strongly recommended that you use a high quality power supply that meets ATX power supply Specification 2.02 or above. It must also be SSI compliant.

1.7 Serial Port

The X13QEH+ motherboard supports one COM port on the rear IO panel. COM Port 1 is used for input/output. The UART provides legacy speeds with a baud rate of up to 115.2 Kbps.

Chapter 2

Installation

2.1 Static-Sensitive Devices

Electrostatic Discharge (ESD) can damage electronic components. To avoid damaging your motherboard, it is important to handle it very carefully. The following measures are generally sufficient to protect your equipment from ESD.

Precautions

- Use a grounded wrist strap designed to prevent static discharge.
- Touch a grounded metal object before removing the motherboard from the antistatic bag.
- Handle the motherboard by its edges only; do not touch its components, peripheral chips, memory modules or gold contacts.
- When handling chips or modules, avoid touching their pins.
- Put the motherboard and peripherals back into their antistatic bags when not in use.
- For grounding purposes, make sure that your computer chassis provides excellent conductivity between the power supply, the case, the mounting fasteners, and the motherboard.
- Use only the correct type of onboard CMOS battery. Do not install the onboard battery upside down to avoid a possible battery explosion.

Unpacking


The motherboard is shipped in antistatic packaging to avoid static damage. When unpacking the motherboard, make sure that the person handling it is static protected.

2.2 Processor and Heatsink Installation


The processor (CPU) and processor carrier should be assembled together first to form the processor carrier assembly. This assembly will be then attached to the heatsink to form the processor heatsink module (PHM) before being installed into the CPU socket. Before installation, be sure to perform the following steps below:

- Please carefully follow the instructions given on the previous page to avoid ESD-related damages.
- Unplug the AC power cords from all power supplies after shutting down the system.
- Check that the plastic protective cover is on the CPU socket, and none of the socket pins are bent. If they are, contact your retailer.
- When handling the processor, avoid touching or placing direct pressure on the LGA lands (gold contacts). Improper installation or socket misalignment can cause serious damage to the processor or CPU socket, which may require manufacturer repairs.
- When installing the processor and heatsink, ensure a torque driver set to the correct force is used for each screw.
- Thermal grease is pre-applied on a new heatsink. No additional thermal grease is needed.
- Refer to the Supermicro website for updates on processor and memory support.
- All graphics in this manual are for illustrations only. Your components may look different.

The 4th Gen Intel Xeon Scalable Processor



SP XCC Series




SP MCC Series

Processor Top View




1. The 4th Gen Intel Xeon Scalable Processor

Processor Top View




Processor Top View


2. The Processor Carrier



Carrier Top View



Carrier E1A




Carrier E1B


Carrier Bottom View

Note: This motherboard supports two CPU SKUs: SP XCC Series and SP MCC Series processors, and each SKU supports a specific carrier. The SP XCC Series CPU supports Carrier E1A, and SP MCC Series, Carrier E1B.


3. Heatsink



1.5U Heatsink




2U Heatsink

 **Note:** Exercise extreme care when handling the heatsink. Pay attention to the edges of heatsink fins, which can be sharp! To avoid damaging the heatsink, please do not apply excessive force on the fins.

Overview of the CPU Socket

The CPU socket is protected by a plastic protective cover.

Plastic Protective Cover




CPU Socket

Overview of the Processor Carrier Assembly


The processor carrier assembly contains a 4th Gen Intel Xeon Scalable processor and a processor carrier. Carefully follow the instructions given in the installation section to place a processor into the carrier to create a processor carrier.

The processor carrier assembly includes a processor and a carrier as shown below:


1. The 4th Gen Intel Xeon Scalable Processor (Component Side)



2. CPU Carrier (Top View)



3. Processor Carrier Assembly




Overview of the Processor Heatsink Module (PHM)


The Processor Heatsink Module (PHM) contains a heatsink, a processor carrier, and a 4th Gen Intel Xeon Scalable processor.

1. Heatsink (Bottom View Shown Below)



1.5U Heatsink





2U Heatsink




2. Processor Carrier E1A (for SP XCC CPU)




3. The 4th Gen Intel Xeon Scalable Processor (SP XCC) (Component Side Shown Below)



4. Processor Heatsink Module (PHM) (Bottom View Shown Below)




1.5U Heatsink




2U Heatsink

1. Heatsink (Bottom View Shown Below)



1.5U Heatsink





2U Heatsink




2. CPU Carrier E1B (for SP MCC CPU)




3. The 4th Gen Intel Xeon Scalable Processor (MCC CPU) (Component Side Shown Below)



4. Processor Heatsink Module (PHM) (Bottom View Shown Below)



1.5U Heatsink




2U Heatsink


Creating the Processor Carrier Assembly

The processor carrier assembly contains a 4th Gen Intel Xeon Scalable processor and a processor carrier.

To create the processor carrier assembly, please follow the steps below:



 **Note:** Before installation, be sure to follow the instructions given on pages 1 and 2 of this chapter to properly prepare for installation.

1. Hold the processor with the component side (including the gold contacts) facing down. Locate the small, gold triangle at the corner of the processor and the corresponding hollowed triangle on the processor carrier as shown in the graphics below. Please note that the triangle indicates the Pin 1 location.




The Processor with its Matching Carrier


2. First, turn over the processor carrier and locate Pin 1 on the CPU and Pin 1 on the carrier. Then, turn the processor over with component side (including the gold contacts) facing up and locate CPU keys on the processor. Finally, locate the CPU keys and four latches on the carrier as shown below.




3. Locate the lever on the CPU socket and press it down as shown below.




4. Using Pin 1 as a guide, carefully align the CPU keys (A and B) on the processor against the CPU keys on the carrier (a and b) as shown in the drawing below.
5. Once they are properly aligned, carefully insert the CPU into the carrier, making sure that the CPU is properly secured by latches 1, 2, 3, and 4.



6. After the processor is placed inside the carrier, examine the four sides of the processor, making sure that the processor is properly seated on the carrier.




CPU Carrier Assembly



CPU Carrier Assembly

Creating the PHM



After creating the processor carrier assembly, please follow the instructions below to mount the processor carrier into the heatsink to form the PHM.

 **Note:** If this is a new heatsink, the thermal grease has been pre-applied on the underside. Otherwise, apply the proper amount of thermal grease.

1. Turn the heatsink over with the thermal grease, which is on the reverse side of the heatsink, facing up. Pay attention to the two triangle cutouts (A, B) located at the diagonal corners of the heatsink as shown in the drawing below.
2. Hold the processor carrier component side facing up, and locate the triangle on the CPU and the triangle on the carrier. (Triangle indicates Pin 1.)
3. Using Pin 1 as a guide, turn the processor carrier assembly over with the gold contacts facing up. Locate Pin 1 (A) on the processor and Pin 1 (a) on the processor carrier assembly.
4. Align the corner marked a on the processor carrier assembly against the triangle cutout A on the heatsink, and align the corners marked b, c, and d on the processor assembly against the corners marked B, C, and D on the heatsinks.
5. Once they are properly aligned, place the corners marked a, b, c, and d on the processor carrier assembly into the corners of the heatsink marked A, B, C, and D making sure that all plastic clips are properly attached to the heatsink.

CPU Carrier Assembly (for 1.5U Heatsink)



(CPU Component Side and Heatsink Bottom Side)



1.5U Heatsink

CPU Carrier Assembly (for 2U Heatsink)

(CPU Component Side and Heatsink Bottom Side)




2U Heatsink


Preparing the CPU Socket for Installation

This motherboard comes with a plastic protective cover installed on the CPU socket. Remove it from the socket by following the instructions below:

1. Press the tabs inward.




2. Pull up the protective cover from the socket.




Preparing to Install the PHM into the CPU Socket

After assembling the Processor Heatsink Module, you are ready to install it into the CPU socket. To ensure the proper installation, please follow the procedures below:


1. Locate four threaded fasteners (a, b, c, d) on the CPU socket.



2. Locate four PEEK nuts (A, B, C, D) and four rotating wires (1, 2, 3, 4) on the heatsink as shown in the graphics below.





1.5U Heatsink




2U Heatsink

3. Check the rotating wires (1, 2, 3, 4) to make sure that they are at unlatched positions as shown in the drawing below before installing the PHM into the CPU socket.




Installing the PHM into the CPU Socket

1. Align PEEK nut A, which is next to the triangle (Pin 1) on the heatsink, against threaded fastener a on the CPU socket. Then align PEEK nuts B, C, and D on the heatsink against threaded fasteners b, c, and d on the CPU socket, making sure that all PEEK nuts on the heatsink are properly aligned with the correspondent threaded fasteners on the CPU socket.
2. Once they are aligned, gently place the heatsink on top the CPU socket, making sure that each PEEK nut is properly attached to its corresponding threaded fastener.



3. Press all four rotating wires outwards and make sure that the heatsink is securely latched onto the CPU socket.




4. With a T30 bit torque driver set to a force of 8.0 in-lbf (0.904 N-m), tighten all PEEK nuts in the sequence of A, B, C, and D with even pressure. To avoid damaging the processor or socket, do not use excessive force when tightening the PEEK nuts.




Important: Do not use a force greater than 8.0 in-lbf (0.904 N-m). Exceeding this force may over-torque the screw, causing damage to the processor, heatsink, and screw.

5. Examine all corners of the heatsink to ensure that the PHM is firmly attached to the CPU socket.



1.5U Heatsink




2U Heatsink


Removing the PHM from the CPU Socket

Before removing the PHM from the motherboard, be sure to shut down the system and unplug the power cables from the power supply. Then follow the steps below:

1. Use a T30 driver to loosen the four PEEK nuts on the heatsink in the sequence of A, B, C, and D.




1.5U Heatsink




2U Heatsink

2. Once the PEEK nuts are loosened from the CPU socket, press the rotating wires inwards to unlatch the PHM from the socket as shown in the drawings below.




1.5U Heatsink




2U Heatsink

3. Gently pull the PHM upwards to remove it from the CPU socket.



1.5U Heatsink




2U Heatsink

Removing the Processor Carrier Assembly from the PHM


To remove the processor carrier assembly from the PHM, please follow the steps below:

1. Detach the four plastic clips (marked a, b, c, d) on the processor carrier assembly from the four corners of the heatsink (marked A, B, C, D) as shown in the drawings below.

1.5U Heatsink (View of Component Side and Heatsink Bottom Side)




SP XCC Series




SP MCC Series

2U Heatsink (View of Component Side and Heatsink Bottom Side)



SP XCC Series




SP MCC Series


Heatsink (Bottom View)

- When all plastic clips are detached from the heatsink, remove the processor carrier assembly from the heatsink.

1.5U Heatsink (View of Component Side and Heatsink Bottom Side)




SP XCC Series




SP MCC Series

2U Heatsink (View of Component Side and Heatsink Bottom Side)



SP XCC Series





SP MCC Series

Removing the Processor from the Processor Carrier Assembly

Once you have removed the processor carrier assembly from the PHM, you are ready to remove the processor from the processor carrier by following the steps below.


1. Unlock the lever from its locked position and push the lever upwards to disengage the processor from the processor carrier as shown in the drawing on the right below.




2. Once the processor is loosened from the carrier, carefully remove the processor from the processor carrier.



Note: Please handle the processor with care to avoid damaging the processor and its pins.



SP XCC Series




SP MCC Series

2.3 Motherboard Installation

All motherboards have standard mounting holes to fit different types of chassis. Make sure that the locations of all the mounting holes for both the motherboard and the chassis match. Although a chassis may have both plastic and metal mounting fasteners, metal ones are highly recommended because they ground the motherboard to the chassis. Make sure that the metal standoffs click in or are screwed in tightly.

Tools Needed




Torque driver (1)



Phillips Screws (12)



Standoffs (12)
(Only if Needed)



Location of Mounting Holes




Note 1: Do not use a force greater than 8 lbf-in (0.904 N-m) on each mounting screw during motherboard installation. Exceeding this force may over-torque the screw, causing damage to the motherboard and screw.

Note 2: Some components are very close to the mounting holes. Please take precautionary measures to avoid damaging these components when installing the motherboard to the chassis.


Installing the Motherboard

1. Install the I/O shield into the back of the chassis, if applicable.


2. Locate the mounting holes on the motherboard. See the previous page for the location.



3. Locate the matching mounting holes on the chassis. Align the mounting holes on the motherboard against the mounting holes on the chassis.



4. Install standoffs in the chassis as needed.
5. Install the motherboard into the chassis carefully to avoid damaging other motherboard components.
6. Using the Phillips screwdriver, insert a pan head #6 screw into a mounting hole on the motherboard and its matching mounting hole on the chassis.
7. Repeat Step 5 to insert #6 screws into all mounting holes.
8. Make sure that the motherboard is securely placed in the chassis.

 **Note:** Images displayed are for illustration only. Your chassis or components might look different from those shown in this manual.

2.4 Memory Support and Installation



Note: Check the Supermicro website for recommended memory modules.



Important: Exercise extreme care when installing or removing memory modules to prevent any possible damage.

Memory Support

This motherboard supports up to 16TB 3DS RDIMM/RDIMM DDR5 ECC memory with speeds up to 4800MT/s in 64 DIMM slots.



Note: Memory speed and capacity support depends on the processors used in the system.

DDR5 Memory Support for 4th Gen Intel Xeon Scalable Processors

DDR5 Memory Support for the 4th Gen Intel Xeon Scalable Processors					
Type	Ranks Per DIMM & Data Width (Stack)	DIMM Capacity (GB)		Speed (MT/s); Voltage (V); DIMM Per Channel (DPC)	
		Memory Density 16Gb	Memory Density 24 Gb	1DPC (Note)	2DPC
				1.1V	
RDIMM	SRx8 (RC D)	16GB	24 GB	4800	4400
	SRx4 (RC C)	32GB	48 GB		
	SRx4 (RC F) 9x4	32GB	N/A		
	DRx8 (RC E)	32GB	48 GB		
	DRx4 (RC A))	64GB	96 GB		
	DRx4 (RC B) 9x4	64GB	N/A		
RDIMM 3DS	(4R/8R) x4 (RC A)	2H-128GB 4H-256GB	N/A		
LRDIMM/LRDIMM-3DS	N/A	N/A		Not Supported	Not Supported



Note 1: 1DPC applies to 1SPC or 2SPC implementations (SPC – sockets per channel).

Note 2: 24 Gb XCC only with limited configs: 1DPC all DIMM types, 2DPC 96 GB only. Only 8 and 16 DIMM configs, no fallbacks.


Note 3: Memory speed will be 4800 MT/s 1DPC and 4400 MT/s 2DPC.

Note 4: Mixing DRAM Density (16 Gb/24 Gb) and/or Frequency is not allowed.

Memory Population Table for the X13QEH+ (with Half Memory Configuration and 64 DIMM Slots Supported)



DDR5 Memory Population Table for X13QEH+ (with 64-DIMM Slots Supported)	
1 CPU:	Memory Population Sequence
1 CPU & 1 DIMM	P1-DIMMA1
1 CPU & 2 DIMMs	P1-DIMMA1/P1-DIMMG1
1 CPU & 4 DIMMs	P1-DIMMA1/P1-DIMMC1/P1-DIMME1/P1-DIMMG1
1 CPU & 6 DIMMs	P1-DIMMA1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMMF1/P1-DIMMG1
1 CPU & 8 DIMMs	P1-DIMMA1/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMMF1/P1-DIMMG1/P1-DIMMH1
1 CPU & 12 DIMMs	P1-DIMMA1/P1-DIMMA2/P1-DIMMB1/P1-DIMMC1/P1-DIMMC2/P1-DIMMD1/P1-DIMME1/P1-DIMME2/P1-DIMMF1/P1-DIMMG1/P1-DIMMG2/P1-DIMMH1
1 CPU & 16 DIMMs	P1-DIMMA1/P1-DIMMA2/P1-DIMMB1/P1-DIMMB2/P1-DIMMC1/P1-DIMMC2/P1-DIMMD1/P1-DIMMD2/P1-DIMME1/P1-DIMME2/P1-DIMMF1/P1-DIMMF2/P1-DIMMG1/P1-DIMMG2/P1-DIMMH1/P1-DIMMH2
2 CPUs:	Memory Population Sequence
2 CPUs & 2 DIMMs	CPU1: P1-DIMMA1 CPU2: P2-DIMMA1
2 CPUs & 4 DIMMs	CPU1: P1-DIMMA1/P1-DIMMG1 CPU2: P2-DIMMA1/P2-DIMMG1
2 CPUs & 6 DIMMs	CPU1: P1-DIMMA1/P1-DIMMC1/P1-DIMME1/P1-DIMMG1 CPU2: P2-DIMMA1/P2-DIMMG1
2 CPUs & 8 DIMMs	CPU1: P1-DIMMA1/P1-DIMMC1/P1-DIMME1/P1-DIMMG1 CPU2: P2-DIMMA1/P2-DIMMC1/P2-DIMME1/P2-DIMMG1
2 CPUs & 10 DIMMs	CPU1: P1-DIMMA1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMMF1/P1-DIMMG1 CPU2: P2-DIMMA1/P2-DIMMC1/P2-DIMME1/P2-DIMMG1
2 CPUs & 12 DIMMs	CPU1: P1-DIMMA1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMMF1/P1-DIMMG1 CPU2: P2-DIMMA1/P2-DIMMC1/P2-DIMMD1/P2-DIMME1/P2-DIMMF1/P2-DIMMG1
2 CPUs & 14 DIMMs	CPU1: P1-DIMMA1/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMMF1/P1-DIMMG1/P1-DIMMH1 CPU2: P2-DIMMA1/P2-DIMMC1/P2-DIMMD1/P2-DIMME1/P2-DIMMF1/P2-DIMMG1
2 CPUs & 16 DIMMs	CPU1: P1-DIMMA1/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMMF1/P1-DIMMG1/P1-DIMMH1 CPU2: P2-DIMMA1/P2-DIMMB1/P2-DIMMC1/P2-DIMMD1/P2-DIMME1/P2-DIMMF1/P2-DIMMG1/P2-DIMMH1
2 CPUs & 18 DIMMs	CPU1: P1-DIMMA1/P1-DIMM2/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMME2/P1-DIMMF1/P1-DIMMG1/P1-DIMMH1 CPU2: P2-DIMMA1/P2-DIMMB1/P2-DIMMC1/P2-DIMMD1/P2-DIMME1/P2-DIMMF1/P2-DIMMG1/P2-DIMMH1
2 CPUs & 20 DIMMs	CPU1: P1-DIMMA1/P1-DIMM2/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMME2/P1-DIMMF1/P1-DIMMG1/P1-DIMMH1 CPU2: P2-DIMMA1/P2-DIMMA2/P2-DIMMB1/P2-DIMMC1/P2-DIMMD1/P2-DIMME1/P2-DIMME2/P2-DIMMF1/P2-DIMMG1/P2-DIMMH1
2 CPUs & 22 DIMMs	CPU1: P1-DIMMA1/P1-DIMM2/P1-DIMMB1/P1-DIMMC1/P1-DIMMC2/P1-DIMMD1/P1-DIMME1/P1-DIMME2/P1-DIMMF1/P1-DIMMG1/P1-DIMMG2/P1-DIMMH1 CPU2: P2-DIMMA1/P2-DIMMA2/P2-DIMMB1/P2-DIMMC1/P2-DIMMD1/P2-DIMME1/P2-DIMME2/P2-DIMMF1/P2-DIMMG1/P2-DIMMH1
2 CPUs & 24 DIMMs	CPU1: P1-DIMMA1/P1-DIMMA2/P1-DIMMB1/P1-DIMMC1/P1-DIMMC2/P1-DIMMD1/P1-DIMME1/P1-DIMME2/P1-DIMMF1/P1-DIMMG1/P1-DIMMG2/P1-DIMMH1 CPU2: P2-DIMMA1/P2-DIMMA2/P2-DIMMB1/P2-DIMMC1/P2-DIMMC2/P2-DIMMD1/P2-DIMME1/P2-DIMME2/P2-DIMMF1/P2-DIMMG1/P2-DIMMG2/P2-DIMMH1
2 CPUs & 32 DIMMs	CPU1: P1-DIMMA1/P1-DIMMA2/P1-DIMMB1/P1-DIMMB2/P1-DIMMC1/P1-DIMMC2/P1-DIMMD1/P1-DIMMD2/P1-DIMME1/P1-DIMME2/P1-DIMMF1/P1-DIMMF2/P1-DIMMG1/P1-DIMMG2/P1-DIMMH1/P1-DIMMH2 CPU2: P2-DIMMA1/P2-DIMMA2/P2-DIMMB1/P2-DIMMB2/P2-DIMMC1/P2-DIMMC2/P2-DIMMD1/P2-DIMMD2/P2-DIMME1/P2-DIMME2/P2-DIMMF1/P2-DIMMF2/P2-DIMMG1/P2-DIMMG2/P2-DIMMH1/P2-DIMMH2
4 CPUs:	Memory Population Sequence
4 CPUs & 4 DIMMs	CPU1: P1-DIMMA1 CPU2: P2-DIMMA1 CPU3: P3-DIMMA1 CPU4: P4-DIMMA1

4 CPUs & 8 DIMMs	CPU1: P1-DIMMA1/P1-DIMMG1 CPU2: P2-DIMMA1/P2-DIMMG1 CPU3: P3-DIMMA1/P3-DIMMG1 CPU4: P4-DIMMA1/P4-DIMMG1
4 CPUs & 12 DIMMs	CPU1: P1-DIMMA1/P1-DIMMC1/P1-DIMME1/P1-DIMMG1 CPU2: P2-DIMMA1/P2-DIMMG1 CPU3: P3-DIMMA1/P3-DIMMC1/P3-DIMME1/P3-DIMMG1 CPU4: P4-DIMMA1/P4-DIMMG1
4 CPUs & 16 DIMMs	CPU1: P1-DIMMA1/P1-DIMMC1/P1-DIMME1/P1-DIMMG1 CPU2: P2-DIMMA1/P2-DIMMC1/P2-DIMME1/P2-DIMMG1 CPU3: P3-DIMMA1/P3-DIMMC1/P3-DIMME1/P3-DIMMG1 CPU4: P4-DIMMA1/P4-DIMMC1/P4-DIMME1/P4-DIMMG1
4 CPUs & 20 DIMMs	CPU1: P1-DIMMA1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMMF1/P1-DIMMG1 CPU2: P2-DIMMA1/P2-DIMMC1/P2-DIMME1/P2-DIMMG1 CPU3: P3-DIMMA1/P3-DIMMC1/P3-DIMMD1/P3-DIMME1/P3-DIMMF1/P3-DIMMG1 CPU4: P4-DIMMA1/P4-DIMMC1/P4-DIMME1/P4-DIMMG1
4 CPUs & 24 DIMMs	CPU1: P1-DIMMA1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMMF1/P1-DIMMG1 CPU2: P2-DIMMA1/P2-DIMMC1/P2-DIMMD1/P2-DIMME1/P2-DIMMF1/P2-DIMMG1 CPU3: P3-DIMMA1/P3-DIMMC1/P3-DIMMD1/P3-DIMME1/P3-DIMMF1/P3-DIMMG1 CPU4: P4-DIMMA1/P4-DIMMC1/P4-DIMMD1/P4-DIMME1/P4-DIMMF1/P4-DIMMG1
4 CPUs & 28 DIMMs	CPU1: P1-DIMMA1/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMMF1/P1-DIMMG1/P1-DIMMH1 CPU2: P2-DIMMA1/P2-DIMMC1/P2-DIMMD1/P2-DIMME1/P2-DIMMF1/P2-DIMMG1 CPU3: P3-DIMMA1/P3-DIMMB1/P3-DIMMC1/P3-DIMMD1/P3-DIMME1/P3-DIMMF1/P3-DIMMG1/P3-DIMMH1 CPU4: P4-DIMMA1/P4-DIMMC1/P4-DIMMD1/P4-DIMME1/P4-DIMMF1/P4-DIMMG1
4 CPUs & 32 DIMMs	CPU1: P1-DIMMA1/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMMF1/P1-DIMMG1/P1-DIMMH1 CPU2: P2-DIMMA1/P2-DIMMB1/P2-DIMMC1/P2-DIMMD1/P2-DIMME1/P2-DIMMF1/P2-DIMMG1/P2-DIMMH1 CPU3: P3-DIMMA1/P3-DIMMB1/P3-DIMMC1/P3-DIMMD1/P3-DIMME1/P3-DIMMF1/P3-DIMMG1/P3-DIMMH1 CPU4: P4-DIMMA1/P4-DIMMB1/P4-DIMMC1/P4-DIMMD1/P4-DIMME1/P4-DIMMF1/P4-DIMMG1/P4-DIMMH1
4 CPUs & 36 DIMMs	CPU1: P1-DIMMA1/P1-DIMM2/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMME2/P1-DIMMF1/P1-DIMMG1/P1-DIMMH1 CPU2: P2-DIMMA1/P2-DIMMB1/P2-DIMMC1/P2-DIMMD1/P2-DIMME1/P2-DIMMF1/P2-DIMMG1/P2-DIMMH1 CPU3: P3-DIMMA1/P3-DIMM2/P3-DIMMB1/P3-DIMMC1/P3-DIMMD1/P3-DIMME1/P3-DIMME2/P3-DIMMF1/P3-DIMMG1/P3-DIMMH1 CPU4: P4-DIMMA1/P4-DIMMB1/P4-DIMMC1/P4-DIMMD1/P4-DIMME1/P4-DIMMF1/P4-DIMMG1/P4-DIMMH1
4 CPUs & 40 DIMMs	CPU1: P1-DIMMA1/P1-DIMM2/P1-DIMMB1/P1-DIMMC1/P1-DIMMD1/P1-DIMME1/P1-DIMME2/P1-DIMMF1/P1-DIMMG1/P1-DIMMH1 CPU2: P2-DIMMA1/P2-DIMMA2/P2-DIMMB1/P2-DIMMC1/P2-DIMMD1/P2-DIMME1/P2-DIMME2/P2-DIMMF1/P2-DIMMG1/P2-DIMMH1 CPU3: P3-DIMMA1/P3-DIMM2/P3-DIMMB1/P3-DIMMC1/P3-DIMMD1/P3-DIMME1/P3-DIMME2/P3-DIMMF1/P3-DIMMG1/P3-DIMMH1 CPU4: P4-DIMMA1/P4-DIMMA2/P4-DIMMB1/P4-DIMMC1/P4-DIMMD1/P4-DIMME1/P4-DIMME2/P4-DIMMF1/P4-DIMMG1/P4-DIMMH1
4 CPUs & 44 DIMMs	CPU1: P1-DIMMA1/P1-DIMM2/P1-DIMMB1/P1-DIMMC1/P1-DIMMC2/P1-DIMMD1/P1-DIMME1/P1-DIMME2/P1-DIMMF1/P1-DIMMG1/P1-DIMMG2/P1-DIMMH1 CPU2: P2-DIMMA1/P2-DIMMA2/P2-DIMMB1/P2-DIMMC1/P2-DIMMD1/P2-DIMME1/P2-DIMME2/P2-DIMMF1/P2-DIMMG1/P2-DIMMG2/P2-DIMMH1 CPU3: P3-DIMMA1/P3-DIMM2/P3-DIMMB1/P3-DIMMC1/P3-DIMMC2/P3-DIMMD1/P3-DIMME1/P3-DIMME2/P3-DIMMF1/P3-DIMMG1/P3-DIMMG2/P3-DIMMH1 CPU4: P4-DIMMA1/P4-DIMMA2/P4-DIMMB1/P4-DIMMC1/P4-DIMMD1/P4-DIMME1/P4-DIMME2/P4-DIMMF1/P4-DIMMG1/P4-DIMMG2/P4-DIMMH1
4 CPUs & 48 DIMMs	CPU1: P1-DIMMA1/P1-DIMMA2/P1-DIMMB1/P1-DIMMC1/P1-DIMMC2/P1-DIMMD1/P1-DIMME1/P1-DIMME2/P1-DIMMF1/P1-DIMMG1/P1-DIMMG2/P1-DIMMH1 CPU2: P2-DIMMA1/P2-DIMMA2/P2-DIMMB1/P2-DIMMC1/P2-DIMMC2/P2-DIMMD1/P2-DIMME1/P2-DIMME2/P2-DIMMF1/P2-DIMMG1/P2-DIMMG2/P2-DIMMH1 CPU3: P3-DIMMA1/P3-DIMMA2/P3-DIMMB1/P3-DIMMC1/P3-DIMMC2/P3-DIMMD1/P3-DIMME1/P3-DIMME2/P3-DIMMF1/P3-DIMMG1/P3-DIMMG2/P3-DIMMH1 CPU4: P4-DIMMA1/P4-DIMMA2/P4-DIMMB1/P4-DIMMC1/P4-DIMMC2/P4-DIMMD1/P4-DIMME1/P4-DIMME2/P4-DIMMF1/P4-DIMMG1/P4-DIMMG2/P4-DIMMH1
4 CPUs & 64 DIMMs	CPU1: P1-DIMMA1/P1-DIMMA2/P1-DIMMB1/P1-DIMMB2/P1-DIMMC1/P1-DIMMC2/P1-DIMMD1/P1-DIMMD2/P1-DIMME1/P1-DIMME2/P1-DIMMF1/P1-DIMMF2/P1-DIMMG1/P1-DIMMG2/P1-DIMMH1/P1-DIMMH2 CPU2: P2-DIMMA1/P2-DIMMA2/P2-DIMMB1/P2-DIMMB2/P2-DIMMC1/P2-DIMMC2/P2-DIMMD1/P2-DIMMD2/P2-DIMME1/P2-DIMME2/P2-DIMMF1/P2-DIMMF2/P2-DIMMG1/P2-DIMMG2/P2-DIMMH1/P2-DIMMH2 CPU3: P3-DIMMA1/P3-DIMMA2/P3-DIMMB1/P3-DIMMB2/P3-DIMMC1/P3-DIMMC2/P3-DIMMD1/P3-DIMMD2/P3-DIMME1/P3-DIMME2/P3-DIMMF1/P3-DIMMF2/P3-DIMMG1/P3-DIMMG2/P3-DIMMH1/P3-DIMMH2 CPU4: P4-DIMMA1/P4-DIMMA2/P4-DIMMB1/P4-DIMMB2/P4-DIMMC1/P4-DIMMC2/P4-DIMMD1/P4-DIMMD2/P4-DIMME1/P4-DIMME2/P4-DIMMF1/P4-DIMMF2/P4-DIMMG1/P4-DIMMG2/P4-DIMMH1/P4-DIMMH2


 **Note:** This memory configuration is recommended by Supermicro for optimal memory performance. Please use this configuration to maximize your memory performance.

DIMM Installation


1. Insert the desired number of DIMMs into the memory slots based on the recommended DIMM population tables in the previous section. Locate DIMM memory slots on the motherboard as shown on the right.
2. Push the release tabs outwards on both ends of the DIMM slot to unlock it.




3. Align the key of the memory module with the receptive point on the memory slot.



4. Align the notches on both ends of the module against the receptive points on the ends of the slot.




5. Push both ends of the module straight down into the slot until the module snaps into place.
6. Press the release tabs to the lock positions to secure the memory module into the slot.



DIMM Removal

Press both release tabs on the ends of the memory module to unlock it. Once the memory module has been loosened, remove it from the memory slot.



Warning! Please do not use excessive force when pressing the release tabs on the ends of the DIMM socket to avoid causing any damage to the memory module or the DIMM socket. Please handle memory modules with care. Carefully follow all the instructions given on page 1 of this chapter to avoid ESD-related damages done to your memory modules or components.

2.5 Rear I/O Connectors/Ports

UID (Unit Identification)/BMC Reset Switch and LED Indicators

A UID LED/BMC Reset switch (JUIDB1) is located on the rear side of the motherboard. This switch has dual functions. It can be used to identify a system unit that is in need of service, and it can also be used to reset the BMC settings.

When functioning as a BMC reset switch, JUIDB1 will trigger a cold reboot when the user presses and holds the switch for 6 seconds. It will also restore the BMC to the manufacturer's default setting when the user presses and holds the switch for 12 seconds.


When functioning as a UID LED switch, JUIDB1 will turn both rear UID LED (LED1) and front UID LED (Pin 2 of FP1) on and off when the user presses the switch on/off.

To achieve these dual purposes, the UID LED/BMC Reset switch works in conjunction with the BMC Heartbeat LED (LED3) and front/rear UID LEDs. Please note that UID can also be triggered via BMC on the motherboard. For details on the UID LEDs and BMC LEDs, refer to the tables below. Also, refer to the BMC User's Guide posted on our website at <http://www.supermicro.com> for more information on BMC.

UID/BMC Reset Switch (JUIDB1) Features & Settings					
When Used as a UID LED Switch			When Used as a BMC Reset Switch		
Work w/Rear UID LED (LED1) & Front UID LED (FP1: Pin 2)			Work with BMC Heartbeat LED (LED3)		
Rear UID LED	LED1	Blue: Unit identified	BMC Heartbeat LED	LED3	Green Blinking: BMC Normal
Front UID LED	Pin 2 of FP1	Blue: Unit identified	BMC Reset: Press & hold the switch (JUIDB1) 6 seconds	LED3: Solid green: during reboot Triggering a cold reboot; LED: solid green on during cold reboot	
Press the switch (JUIDB1) to turn both rear and front UID LED indicators on and off;			BMC Reset: Press & hold the switch (JUIDB1) 12 seconds	LED3: Solid green: during BMC reset	
				BMC: Reset to the manufacturer's default; LED solid on during BMC Reset	

UID/BMC Reset Switch (JUIDB1) Pin Definitions	
Pin#	Definition
1	Ground
2	Ground
3	Button In
4	Button In

1. UID LED/BMC Reset Switch
2. Rear UID LED (LED1)
3. Front UID LED (Pin 2 of FP1)
4. BMC Heartbeat LED (LED3)




Front Control Panel	
1	Power Button
2	Reset/UID Button
3	UID LED_N
4	Fail LED_N (OH/FF/FPF)
5	LAN-2 Activity LED
6	LAN-1 Activity LED (Aggregate all LAN)
7	HDD Activity LED
8	Standby LED_N
9	Power/RoT LED_N
10	P3V3_STBY
11	Ground
12	I2C Data
13	I2C Clock
14	Ground
15	Power Fail LED_P
16	PSV_USB
17	PSV_USB
18	PSV_USB
19	Power Fail LED_N
20	Ground

COM Port


A COM (communication) port that supports serial link interface is on the motherboard. COM1 (JCOM1) is located on the rear I/O panel. Refer to the layout below for the location of COM1.

I/O Device Display Port

An I/O Device Display Port (DP) is located at JDP1 on the rear I/O panel. This display port provides visual display support for your I/O devices installed on the rear I/O panel. Refer to the layout below for the location of JDP1.



- 1. COM1
- 2. DP1




Universal Serial Bus (USB) Ports and Headers


There are two USB 3.0 ports (USB0/1), located at JUSB RJ45, on the rear I/O panel. A Type A USB 3.0 connector (USB 2) is located at JUSB1 for front access. These USB connections can be used for USB support via USB cables (not included).

Rear I/O Panel USB 2/3 (3.0) Pin Definitions			
Pin#	Definition	Pin#	Definition
A1	VBUS	B1	Power
A2	D-	B2	USB_N
A3	D+	B3	USB_P
A4	GND	B4	GND
A5	Stda_SSRX-	B5	USB3_RN
A6	Stda_SSRX+	B6	USB3_RP
A7	GND	B7	GND
A8	Stda_SSTX-	B8	USB3_TN
A9	Stda_SSTX+	B9	USB3_TP

Type A USB 6 (3.0) Pin Definitions			
Pin#	Definition	Pin#	Definition
1	VBUS	5	SSRX-
2	USB_N	6	SSRX+
3	USB_P	7	GND
4	Ground	8	SSTX-
		9	SSTX+




1. USB0 (3.0) on rear I/O panel
2. USB1 (3.0) on rear I/O panel
3. USB2 (Type A USB 3.0) for front access




BMC LAN

A dedicated BMC LAN (BMC LAN) is located on the rear I/O panel. This dedicated BMC LAN, located below USB Ports, provides Ethernet LAN support for the BMC (Baseboard Management Controller). Connect an RJ45 cable to JUSBRJ45 on the I/O rear panel for BMC LAN support. Please refer to the LED Indicator section for LAN LED information.



1. BMC LAN (IPMI LAN)



2.6 Front Control Panels

There are two Front Control Panel headers located on this motherboard. Front Control Panel Header 1, located at FP1, contains header pins for various buttons and LED indications with I²C support for front access. Front Control Panel Header 2, located at FP2, provides additional functions, including USB and VGA support to the system. These Front Control Panel headers are designed specifically for use with Supermicro chassis. See the layout drawing below for the locations of FP1 and FP2.




Figure 2-1. Locations of Front Control Panel Headers (FP1/FP2)

Front Control Panel Headers:

1. Front Control Panel Header 1: FP1 (JF1)
2. Front Control Panel Header 2: FP2

1. Front Control Panel Header with I²C (FP1)

Pin Definitions of FP1 (JF1)

Front Control Panel		
1	○	Power Button
2	○	Reset/UID Button
3	○	UID LED_N
4	○	Fail LED_N (OH/FF/PF)
5	○	LAN-2 Activity LED
6	○	LAN-1 Activity LED (Aggregate all LAN)
7	○	HDD Activity LED
8	○	Standby LED_N
9	○	Power/RoT LED_N
10	○	P3V3_STBY
11	○	Ground
12	○	I2C Data
13	○	I2C Clock
14	○	Ground
15	○	Power Fail LED_P
16	○	P5V_USB
17	○	P5V_USB
18	○	P5V_USB
19	○	Power Fail LED_N
20	○	Ground

Figure 2-2. FP1 (JF1) Header Pins

Power On and BMC/BIOS Status LED Button

The Power On and BMC/BIOS Status LED button is located on Pin 1 of Front Control Panel Header 1 (FP1). Momentarily contacting Pin 1 of FP1 will power on/off the system or display BMC/BIOS status. Refer to the table below for more information.

Power Button BMC/BIOS Status LED Indicator	
Status	Event
Green: solid on	System power on
BMC/BIOS blinking green at 4Hz	BMC/BIOS checking
BIOS blinking green at 4Hz	BIOS recovery/update in progress
BMC blinking red x2 (2 blinks red) at 4Hz, 1 pause at 2Hz (on-on-off-off)	BMC recovery/update in progress
BMC/BIOS blinking green at 1Hz	Flash not detected or golden image checking failure

BMC Reset Button/Front UID Switch

The BMC Reset button/Front UID switch connection is located on Pin 2 of FP1, which is used in conjunction with the Reset Button/UID Switch Select jumper located at JRU1. To configure Pin 2 of FP1 for front UID switch use in a chassis that supports front UID connection, close Pin 1 and Pin 2 of jumper JRU1. To set Pin 2 of FP1 for BMC Reset, close Pin 3 and Pin 4 of jumper JRU1. Please refer to the jumper section for more information on JRU1. Also see the layout below for the location of JRU1.


Front Control Panel

1	<input type="radio"/>	Power Button	1
2	<input type="radio"/>	Reset/UID Button	2
3	<input type="radio"/>	UID LED_N	
4	<input type="radio"/>	Fail LED_N (OH/FF/PF)	
5	<input type="radio"/>	LAN-2 Activity LED	
6	<input type="radio"/>	LAN-1 Activity LED (Aggregate all LAN)	
7	<input type="radio"/>	HDD Activity LED	
8	<input type="radio"/>	Standby LED_N	
9	<input type="radio"/>	Power/RoT LED_N	
10	<input type="radio"/>	P3V3_STBY	
11	<input type="radio"/>	Ground	
12	<input type="radio"/>	I2C Data	
13	<input type="radio"/>	I2C Clock	
14	<input type="radio"/>	Ground	
15	<input type="radio"/>	Power Fail LED_P	
16	<input type="radio"/>	P5V_USB	
17	<input type="radio"/>	P5V_USB	
18	<input type="radio"/>	P5V_USB	
19	<input type="radio"/>	Power Fail LED_N	
20	<input type="radio"/>	Ground	

Front UID Switch/Reset Button Select Jumper (JRU1) Jumper Settings

State	Description
Close Pin 1 and Pin 2 of JRU1	Pin 2 of FP1: used for front UID switch support
Close Pin 3 and Pin 4 of JRU1	Pin 2 of FP1: used for BMC Reset support

1. Power On and BMC/BIOS Status LED Button
2. Reset Button/UID Switch Connection
3. JRU1 Jumper (UID Switch/Reset Button Select)



UID LED

The unit identifier LED connection is located on Pin 3 of FP1. See the figure below for FP1 pin definitions.

Failure LED (Information LED for OH/FF/PF)

The Failure LED (Information LED for OH/Fan Fail/PWR Fail) connection is located on Pin 4 of FP1. This LED provides warnings of overheating, power failure, or fan failure. See the figure below for FP1 pin definitions.

Fail LED (Information LED) (OH/Fan Fail/PWR Fail) LED States	
Status	Description
Solid red (on)	An overheat condition has occurred.
Blinking red (1Hz)	Fan failure: check for an inoperative fan.
Blinking red (0.25Hz)	Power failure: check for a non-operational power supply
Blinking red (10Hz) (FP red LED)	CPLD recovery mode error(s)
Solid blue	UID has been activated locally. Use this function to locate a unit in a rack mount environment that might be in need of service.
Blinking blue (1Hz)	Local UID has been activated locally on. Use this function to identify a unit that might be in need of service.
BIOS/BMC blinking blue (10Hz)	BIOS/BMC: recovery and/or update in progress
Red Info LED blinking (10Hz) and MB UID LED blue blinking (10Hz)	CPLD: recovery and/or update in progress

Front Control Panel

1	<input type="radio"/>	Power Button	
2	<input type="radio"/>	Reset/UID Button	
3	<input type="radio"/>	UID LED_N	1
4	<input type="radio"/>	Fail LED_N (OH/FF/PF)	2
5	<input type="radio"/>	LAN-2 Activity LED	
6	<input type="radio"/>	LAN-1 Activity LED (Aggregate all LAN)	
7	<input type="radio"/>	HDD Activity LED	
8	<input type="radio"/>	Standby LED_N	
9	<input type="radio"/>	Power/RoT LED_N	
10	<input type="radio"/>	P3V3_STBY	
11	<input type="radio"/>	Ground	
12	<input type="radio"/>	I2C Data	
13	<input type="radio"/>	I2C Clock	
14	<input type="radio"/>	Ground	
15	<input type="radio"/>	Power Fail LED_P	
16	<input type="radio"/>	P5V_USB	
17	<input type="radio"/>	P5V_USB	
18	<input type="radio"/>	P5V_USB	
19	<input type="radio"/>	Power Fail LED_N	
20	<input type="radio"/>	Ground	

1. UID LED Indicator
2. Fail LED (Information LED for OH/FF/PF)

LAN1/LAN2 (NIC1/NIC2)

The NIC (Network Interface Controller) LED connection for LAN Port 1 is located on Pin 6 of FP1, and LAN Port 2 is on Pin 5. See the figure below for FP1 pin definitions.

LAN1/LAN2 LED LED States	
Color	State
NIC 2: Blinking green	LAN 2: Active
NIC 1: Blinking green	LAN 1: Active

HDD Activity LED

The HDD activity LED connection is located on Pin 7 of FP1. When this LED is blinking green, it indicates HDD activity. Refer to the table below.

HDD LED LED State	
Color	State
Blinking Green	HDD Active

Front Control Panel

1	<input type="radio"/>	Power Button	
2	<input type="radio"/>	Reset/UID Button	
3	<input type="radio"/>	UID LED_N	
4	<input type="radio"/>	Fail LED_N (OH/FF/PF)	
5	<input type="radio"/>	LAN-2 Activity LED	1
6	<input type="radio"/>	LAN-1 Activity LED (Aggregate all LAN)	2
7	<input type="radio"/>	HDD Activity LED	3
8	<input type="radio"/>	Standby LED_N	
9	<input type="radio"/>	Power/RoT LED_N	
10	<input type="radio"/>	P3V3_STBY	
11	<input type="radio"/>	Ground	
12	<input type="radio"/>	I2C Data	
13	<input type="radio"/>	I2C Clock	
14	<input type="radio"/>	Ground	
15	<input type="radio"/>	Power Fail LED_P	
16	<input type="radio"/>	P5V_USB	
17	<input type="radio"/>	P5V_USB	
18	<input type="radio"/>	P5V_USB	
19	<input type="radio"/>	Power Fail LED_N	
20	<input type="radio"/>	Ground	

1. LAN 2 Activity LED
2. LAN 1 Activity LED
3. HDD Activity LED

Standby Power LED

The LED indicator for standby power is located on Pin 8 of FP1. If this LED is on, standby power is on.

RoT (Root of Trust) Power LED

The Power LED for RoT (Root of Trust) connection is located on Pin 9 of FP1. If this LED is on, power for the RoT chip is on.

Front Control Panel

1	<input type="radio"/>	Power Button	
2	<input type="radio"/>	Reset/UID Button	
3	<input type="radio"/>	UID LED_N	
4	<input type="radio"/>	Fail LED_N (OH/FF/PF)	
5	<input type="radio"/>	LAN-2 Activity LED	
6	<input type="radio"/>	LAN-1 Activity LED (Aggregate all LAN)	
7	<input type="radio"/>	HDD Acitivity LED	
8	<input type="radio"/>	Standby LED_N	1
9	<input type="radio"/>	Power/RoT LED_N	2
10	<input type="radio"/>	P3V3_STBY	
11	<input type="radio"/>	Ground	
12	<input type="radio"/>	I2C Data	
13	<input type="radio"/>	I2C Clock	
14	<input type="radio"/>	Ground	
15	<input type="radio"/>	Power Fail LED_P	
16	<input type="radio"/>	P5V_USB	
17	<input type="radio"/>	P5V_USB	
18	<input type="radio"/>	P5V_USB	
19	<input type="radio"/>	Power Fail LED_N	
20	<input type="radio"/>	Ground	

1. Standby Power LED
2. RoT Power LED

Standby Power

A Standby Power (I²C) connection is located on Pin 10 ~ Pin14 of FP1 to provide power to the system when it is in standby mode. Refer to the table below for pin definitions.

3.3V Standby PWR Pin Definitions	
Pin#	Definition
10	P3V3 Standby
11	Ground
12	I ² C Data
13	I ² C Clock
14	Ground

Power Fail LED Indicators

Power Failure LED Indicators are located on Pin 15 and Pin 19 of FP1. Refer to the table below for pin definitions.

FP Power LED Pin Definitions (FP1)	
Pin#	Definition
15	PWR Failure LED-Positive
19	PWR Failure LED-Negative

Front Control Panel

1	<input type="radio"/>	Power Button
2	<input type="radio"/>	Reset/UID Button
3	<input type="radio"/>	UID LED_N
4	<input type="radio"/>	Fail LED_N (OH/FF/PF)
5	<input type="radio"/>	LAN-2 Activity LED
6	<input type="radio"/>	LAN-1 Activity LED (Aggregate all LAN)
7	<input type="radio"/>	HDD Activity LED
8	<input type="radio"/>	Standby LED_N
9	<input type="radio"/>	Power/RoT LED_N
10	<input type="radio"/>	P3V3_STBY
11	<input type="radio"/>	Ground
12	<input type="radio"/>	I2C Data
13	<input type="radio"/>	I2C Clock
14	<input type="radio"/>	Ground
15	<input type="radio"/>	Power Fail LED_P
16	<input type="radio"/>	P5V_USB
17	<input type="radio"/>	P5V_USB
18	<input type="radio"/>	P5V_USB
19	<input type="radio"/>	Power Fail LED_N
20	<input type="radio"/>	Ground

1. (3.3V) Standby Power
2. PWR Fail LED (Positive)
3. PWR Fail LED (Negative)

FP USB Power

Front Panel USB power connections are located on Pin 16 ~ Pin 18 of FP1 to provide power to front USB devices. Refer to the table below for pin definitions.

FP USB PWR Pin Definitions	
Pin#	Definition
16	+5V USB PWR
17	
18	

Front Control Panel

1	○	Power Button
2	○	Reset/UID Button
3	○	UID LED_N
4	○	Fail LED_N (OH/FF/PF)
5	○	LAN-2 Activity LED
6	○	LAN-1 Activity LED (Aggregate all LAN)
7	○	HDD Activity LED
8	○	Standby LED_N
9	○	Power/RoT LED_N
10	○	P3V3_STBY
11	○	Ground
12	○	I2C Data
13	○	I2C Clock
14	○	Ground
15	○	Power Fail LED_P
16	○	P5V_USB
17	○	P5V_USB
18	○	P5V_USB
19	○	Power Fail LED_N
20	○	Ground

1

1. FP USB Power

2. Front Control Panel Header (FP2)

In addition to Front Control Panel header 1 (FP1), another Front Control Panel header, located at FP2, supports a VGA connector and two USB 2.0 ports (USB 3/4). See the layout below for the location of FP2.

Front Control Panel Header 2 (FP2)




Figure 2-3. Location of FP2 Header

2.7 Connectors and Headers

Power Connections

Power Supply Connectors

Two Supermicro proprietary power supply units (PSU1/PSU2) provide main power to your system. Two 8-pin power connectors (JPGW1/JPGW2) are used for GPU devices, and additional three 8-pin connectors (JPWR7~JPWR9) are used to provide power to backplane devices. In addition, two 4-pin power connectors (JPWR4/JPWR5) are also used for backplane devices. All these power connectors meet the ATX SSI EPS 12V specification and must be connected to your power supply to provide adequate power to your system.




Important: To provide adequate power to your system, be sure to connect the main power supplies (PSU1/PSU2), five 8-pin PWR connectors (JPGW1/JPGW2/JPWR7/JPWR8/JPWR9), and the 4-pin power connectors (JPWR4/JPWR5) to the power supply. Failure to do so may void the manufacturer warranty on your power supply and motherboard.

12V 8-pin Power Pin Definitions	
Pin#	Definition
1 - 4	Ground
5 - 8	+12V

Required Connection


1. PSU1: Main PWR Supply Unit 1
2. PSU2: Main PWR Supply Unit 2
3. JPGW1: 8-pin GPU PWR Connector
4. JPGW2: 8-pin GPU PWR Connector
5. JPWR7: 8-pin BP PWR Connector 3
6. JPWR8: 8-pin BP PWR Connector 1
7. JPWR9: 8-pin BP PWR Connector 2
8. JPWR4: 4-pin BP PWR Connector 5
9. JPWR5: 4-Ppin BP PWR Connector 4



Headers

Fan Headers

There are eight 4-pin fan headers (FAN1 ~ FAN8) used for your system cooling fans. Additionally, four 6-pin fan headers (FAN9 ~ FAN 12), located at the rear side of the chassis, provide cooling to backplane components. In addition, an Fan_PMB header used for I²C temperature sensor cooling is located at JFAN1. Fan speed control for these fans is supported by Thermal Management via BMC interface. Refer to the layout below for the locations of the fan headers.




TPM/Port 80 Header

The JTPM1 header is used to connect a Trusted Platform Module (TPM)/Port 80, which is available from Supermicro (optional). A TPM/Port 80 connector is a security device that supports encryption and authentication in hard drives. It allows the motherboard to deny access if the TPM, which is associated with the hard drive, is not installed in the system. See the layout below for the location of the TPM header. Please go to the following link for more information on the TPM: <http://www.supermicro.com/manuals/other/TPM.pdf>.

Note: For TPM support, an optional part is needed. Contact Supermicro Tech Support for more information.


Trusted Platform Module Header Pin Definitions			
Pin#	Definition	Pin#	Definition
1	+3.3V	2	SPI_CS#
3	RESET#	4	SPI_MISO
5	SPI_CLK	6	GND
7	SPI_MOSI	8	NC
9	+3.3V Stdbby	10	SPI_IRQ#

1. TPM Header




VROC RAID Key Header


An Intel VROC RAID Key header is located at JRK1 on the motherboard. Install a VROC RAID Key on JRK1 for NVMe RAID support as shown in the illustration below. Please refer to the layout below for the location of JRK1.

 **Note:** For detailed instructions on how to configure VROC RAID settings, please refer to the VROC RAID Configuration User's Guide posted on the web page under the link: <http://www.supermicro.com/support/manuals/>.

Intel VROC Key Pin Definitions	
Pin#	Definition
1	Ground
2	3.3V Standby
3	Ground
4	PCH RAID Key



1. VROC RAID Key (JRK1)




BMC SMB I²C Header

A System Management Bus I²C header for the BMC is located at JIPMB1. Connect the appropriate cable here to use the 4-pin BMC external I²C connection on your system. Refer to the layout for the location of JIPMB1.

SMB I²C for 4U Power Distribution Board (PDB) Headers

Two System Management Bus I²C headers for 4U Power Distribution Board headers are located at J47 (PBD_SB1) and J26 (PBD_SB2). Connect a cable to J47 for Power Distribution Board 1 support, and connect a cable to J26 for Power Distribution Board 2 support. Refer to the layout for the locations of J47 and J26.




1. BMC External Header
2. J47 (PBD_SB1)
3. J26 (PBD_SB2)

Chassis Intrusion

A Chassis Intrusion header is located at JL1 on the motherboard. Attach the appropriate cable from the chassis to inform you when the chassis is opened. Refer to the table below for pin definitions.


Chassis Intrusion Pin Definitions	
Pin#	Definition
1	Intrusion Input
2	Ground



1. Chassis Intrusion (JL1)


JMD1/JMD2 Slots (for NVMe Only)

Two hybrid M.2 slots are located at JMD1 and JMD2. JMD1 supports M.2 SATA 2:0/PCIe 3.0 x4 hybrid slot, and JMD2 supports M.2 SATA 2:4/PCIe 3.0 x2 hybrid slot. Both JMD1 and JMD2 slots support PCIe 3.0 devices in the 2280/22110 form factors. M.2 allows for a variety of card sizes, increased functionality, and spatial efficiency. Refer to the layout below for the locations of JMD1 and JMD2 slots.



SATA 1.0 and SATA 3.0 Ports

Two SATA headers, supported by Intel PCH, are located at JS1 and JS2 on the motherboard. JS1 supports I-SATA 1.0 Port 0~Port 3, and JS2 supports I-SATA 3.0 Port 0~Port 3. Connect proper SATA cables to JS1 and JS2 to use SATA 1.0 and 3.0 connections. Refer the layout below for JS1/JS2 locations.




1. JS1: I-SATA1 Port0/Port1/Port2/Port3
2. JS2: I-SATA3 Port0/Port1/Port2/Port3

2.8 Jumper Settings

How Jumpers Work

To modify the operation of the motherboard, jumpers can be used to choose between optional settings. Jumpers create shorts between two pins to change the function of the connector. Pin 1 is identified with a square solder pad on the printed circuit board. See the diagram below for an example of closing Pin 1 and Pin 2 of the jumper. Refer to the motherboard layout page for jumper locations.




Note: On two-pin jumpers, "Closed" means the jumper is on and "Open" means the jumper is off the pins.

Watch Dog Timer Enable

JWD1 controls the Watch Dog function. Watch Dog is a monitor that can reboot the system when a software application hangs. Jumping pins 1-2 will cause Watch Dog to reset the system if an application hangs. Jumping pins 2-3 will generate a non-maskable interrupt signal for the application that hangs. Watch Dog must also be enabled in the BIOS. The default setting is Reset.

Note: When Watch Dog is enabled, the user needs to write their own application software to disable it.

1. JWD1 (Watch Dog Timer Enable)



Clear CMOS

JBT1 is used to clear CMOS, which will also clear any passwords. Instead of pins, this jumper consists of contact pads to prevent accidentally clearing the contents of CMOS.

To Clear CMOS




1. First power down the system and unplug the power cord(s).
2. Remove the cover of the chassis to access the motherboard and remove the battery from the motherboard.
3. Short the CMOS pads, JBT1, with a metal object such as a small screwdriver for at least four seconds.
4. Remove the screwdriver (or shorting device).
5. Replace the cover, reconnect the power cord(s), and power on the system.



Note 1: Clearing CMOS will also clear all passwords.

Note 2: Do not use the PW_ON connector to clear CMOS.


1. Clear CMOS



Power Button and Front UID Button Select Jumper

Jumper JRU1 is used to configure Pin 2 of Front Control Panel header 1 (FP1) to function as a Power button or as the Front UID button. To set Pin 2 of FP1 for Front UID use in a chassis that supports front UID connection, close Pin 1 and Pin 2 of Jumper JRU1. To set Pin 2 of FP1 for Power Signal use, keep jumper JRU1 open. Please refer to the figure below for FP1 pin definitions, and refer to the table below for JRU1 settings.

Front UID Button/Power Button Select Jumper (JRU1) Jumper Settings	
State	Description
Close Pin 1 and Pin 2 of JRU1	Pin 2 of FP1: used for Front UID button (Default)
Keep Pin 1 and Pin 2 of JRU1 Open	Pin 2 of FP1: used for Power button



1. JRU1 (PWR Button/Front UID Button Select Jumper)
2. Pin 2 of FP1 (Front Control Panel 1)

Front Control Panel


- | | | |
|----|----------------------------------|--|
| 1 | <input type="radio"/> | Power Button |
| 2 | <input checked="" type="radio"/> | Reset/UID Button 2 |
| 3 | <input type="radio"/> | UID LED_N |
| 4 | <input type="radio"/> | Fail LED_N (OH/FF/PF) |
| 5 | <input type="radio"/> | LAN-2 Activity LED |
| 6 | <input type="radio"/> | LAN-1 Activity LED (Aggregate all LAN) |
| 7 | <input type="radio"/> | HDD Activity LED |
| 8 | <input type="radio"/> | Standby LED_N |
| 9 | <input type="radio"/> | Power/RoT LED_N |
| 10 | <input type="radio"/> | P3V3_STBY |
| 11 | <input type="radio"/> | Ground |
| 12 | <input type="radio"/> | I2C Data |
| 13 | <input type="radio"/> | I2C Clock |
| 14 | <input type="radio"/> | Ground |
| 15 | <input type="radio"/> | Power Fail LED_P |
| 16 | <input type="radio"/> | P5V_USB |
| 17 | <input type="radio"/> | P5V_USB |
| 18 | <input type="radio"/> | P5V_USB |
| 19 | <input type="radio"/> | Power Fail LED_N |
| 20 | <input type="radio"/> | Ground |

ME Recovery

JPME1 is used for ME Firmware Recovery mode, which will limit system resource for essential function use only without putting restrictions on power use. In the single operation mode, online upgrade will be available via Recovery mode. See the table below for pin definitions.

ME Recovery Jumper Settings	
Jumper Setting	Definition
Pins 1-2	Normal (Default)
Pins 2-3	ME Recovery

1. ME Recovery




Video Display Enable

Jumper JPG1 is used to enable or disable the onboard VGA connector. The default setting is 1-2 to enable the connection. See the table below for jumper settings.

Video Display Enable Jumper Settings (JPG1)	
Jumper Setting	Definition
Pins 1-2	Video Display Enabled (Default)
Pins 2-3	Video Display Disabled

1. Video Display Enable




BIOS Recovery

Use Jumpers JBR1 and JBR2 to reset the BIOS settings. Resetting BIOS settings is not recommended unless you are experiencing difficulties with BIOS settings. See the table below for jumper settings.

BIOS Reset Jumpers (JBR1/JBR2) Jumper Settings	
Jumper Setting	Definition
Pins 1-2	Normal (Default)
Pins 2-3	BIOS Reset


1. JBR1
2. JBR2



HDD Backplane (BP) ID Jumpers

Two HDD Backplane ID jumpers (J145/J146) allows the user to change the HDD backplane settings for different HDD device support. When both J145 and J146 are closed, the backplane supports 4 x2 HDD devices (default). Refer to the table for more information.

HDD Backplane (BP) ID Jumpers (J145/J146) Jumper Settings		
J145	J146	HDD Backplane
Open	Open	1 x24 HDD
Open	Closed	Reserve
Closed	Open	Reserve
Closed	Closed	4 x2 HDD (Default)



1. J145


2. J146

2.9 LED Indicators

BMC LAN LEDs


A dedicated BMC LAN connection is provided on rear I/O panel of the motherboard. The LED on the right side of the BMC LAN indicates activity, and the LED on the left indicates the speed of the connection. Refer to the table below for more information.

BMC LAN LEDs LED Status		
	Color/State	Definition
Link (left)	Green: Solid	100 Mbps
	Amber: Solid	1Gbps
Activity (Right)	Amber: Blinking	Active



Unit ID LED

The front UID-LED indicator is located at (LED1). This UID indicator provides easy identification of a system that may need service.



Onboard Power LED


The Onboard Power LED (LEDPWR) is located at LED2 on the motherboard. When this LED is on, the system power is on. Be sure to turn off the system power and unplug the power cords before removing or installing components. Refer to the table below for more information.

Onboard Power LED Indicator (LED2) LED Status	
LED Color	Definition
Off	System Power Off (power cable not connected)
Green	System Power On

BMC Heartbeat LED

A BMC Heartbeat LED is located at LED3 on the motherboard. When LED3 is blinking green, the BMC is functioning normally. Refer to the layout below for the location of LED3.

BMC Heartbeat LED Indicator (LED3) LED Status	
LED Color	Definition
Green: Blinking	BMC Normal




1. LED2: Power LED (LEDPWR)
2. LED3: BMC Heartbeat LED

CPU Power Status LED Indicators

CPU Power Status LED indicators are located at LED4, LED5, LED6, and LED7. When a CPU power supply fails, the corresponding Power Status LED will turn solid red. Refer to the table below for more details

CPU Power Status LED Indicators (LED4, LED5, LED6, LED7) LED Status		
LED#	Color	Definition
LED4	Solid Red	CPU1 Power Failure
LED5	Solid Red	CPU2 Power Failure
LED6	Solid Red	CPU3 Power Failure
LED7	Solid Red	CPU4 Power Failure



1. LED4: CPU1 Power Failure
2. LED5: CPU2 Power Failure
3. LED6: CPU3 Power Failure
4. LED7: CPU4 Power Failure

Chapter 3

Troubleshooting

3.1 Troubleshooting Procedures

Use the following procedures to troubleshoot your system. If you have followed all of the procedures below and still need assistance, refer to the 'Technical Support Procedures' and/or 'Returning Merchandise for Service' section(s) in this chapter. Always disconnect the AC power cord before adding, changing or installing any non-hot_swap hardware components.

Before Power On

1. Make sure that there are no short circuits between the motherboard and chassis.
2. Disconnect all ribbon/wire cables from the motherboard, including those for the keyboard and mouse.
3. Remove all add-on cards.
4. Install the CPU (making sure it is fully seated) and connect the front panel connectors to the motherboard.

No Power

1. Make sure that there are no short circuits between the motherboard and the chassis.
2. The battery on your motherboard may be old. Check to verify that it still supplies ~3VDC. If it does not, replace it with a new one.

No Video

1. If the power is on, but you do not have video, remove all add-on cards and cables.
2. Remove all memory modules and turn on the system (if the alarm is on, check the specs of memory modules, reset the memory, or try a different one).

System Boot Failure

If the system does not display POST (Power-On-Self-Test) or does not respond after the power is turned on, check the following:

1. Remove all components from the motherboard, especially the DIMM modules. Power on the system and check if the power-on LED (LED2) and the BMC Heartbeat LED (LED3) are on, and system fans are spinning.
2. Turn on the system with only one DIMM module installed. If the system boots, check for bad DIMM modules or slots by following the Memory Errors Troubleshooting procedure in this chapter.

Memory Errors

1. Make sure that the memory modules are compatible with the system and are properly installed. See Chapter 2 for installation instructions. (For memory compatibility, refer to the "Tested Memory List" link on the motherboard's product page to see a list of supported memory.)
2. Check if different speeds of DIMMs have been installed. It is strongly recommended that you use the same RAM type and speed for all DIMM modules in the system.
3. Make sure that you are using the correct type of ECC DDR5 modules recommended by the manufacturer.
4. Check for bad DIMM modules or slots by swapping a single module among all memory slots and check the results.

Losing the System's Setup Configuration

1. Make sure that you are using a high-quality power supply. A poor-quality power supply may cause the system to lose the CMOS setup information. Refer to Chapter 1 for details on recommended power supplies.
2. The battery on your motherboard may be old. Check to verify that it still supplies ~3VDC. If it does not, replace it with a new one.

When the System Becomes Unstable

A. If the system becomes unstable during or after OS installation, check the following:

1. CPU/BIOS support: Make sure that your CPU is supported and that you have the latest BIOS installed in your system.

2. Memory support: Make sure that the memory modules are supported by testing the modules using memtest86 or a similar utility.



Note: Click on the "Tested Memory List" link on the motherboard's product page to see a list of supported memory.

3. HDD support: Make sure that all hard disk drives (HDDs) work properly. Replace the bad HDDs with good ones.
4. System cooling: Check the system cooling to make sure that all heatsink fans and CPU/system fans, etc., work properly. Check the hardware monitoring settings in the BMC to make sure that the CPU and system temperatures are within the normal range. Also check the front panel Overheat LED and make sure that it is not on.
5. Adequate power supply: Make sure that the power supply provides adequate power to the system. Make sure that all power connectors are connected. Please refer to our website for more information on the minimum power requirements.
6. Proper software support: Make sure that the correct drivers are used.

B. If the system becomes unstable before or during OS installation, check the following:

1. Source of installation: Make sure that the devices used for installation are working properly, including boot devices such as CD/media drive.
2. Cable connection: Check to make sure that all cables are connected and working properly.
3. Using the minimum configuration for troubleshooting: Remove all unnecessary components (starting with add-on cards first), and use the minimum configuration (but with the CPU and a memory module installed) to identify the trouble areas. Refer to the steps listed in Section A above for proper troubleshooting procedures.
4. Identifying bad components by isolating them: If necessary, remove a component in question from the chassis, and test it in isolation to make sure that it works properly. Replace a bad component with a good one.
5. Check and change one component at a time instead of changing several items at the same time. This will help isolate and identify the problem.
6. To find out if a component is good, swap this component with a new one to see if the system will work properly. If so, then the old component is bad. You can also install the component in question in another system. If the new system works, the component is good and the old system has problems.

3.2 Technical Support Procedures

Before contacting Technical Support, please take the following steps. Also, please note that as a motherboard manufacturer, Supermicro also sells motherboards through its channels, so it is best to first check with your distributor or reseller for troubleshooting services. They should know of any possible problems with the specific system configuration that was sold to you.

1. Please go through the Troubleshooting Procedures and Frequently Asked Questions (FAQ) sections in this chapter or see the FAQs on our website (<http://www.supermicro.com/FAQ/index.php>) before contacting Technical Support.
2. BIOS upgrades can be downloaded from our website (https://www.supermicro.com/support/resources/bios_ipmi.php).
3. If you still cannot resolve the problem, include the following information when contacting Supermicro for technical support:
 - Motherboard model and PCB revision number
 - BIOS release date/version (This can be seen on the initial display when your system first boots up.)
 - System configuration
4. An example of a Technical Support form is on our website at <http://www.supermicro.com/RmaForm/>.
5. Distributors: For immediate assistance, please have your account number ready when placing a call to our Technical Support department. We can be reached by email at support@supermicro.com.


3.3 Frequently Asked Questions

Question: What type of memory does my motherboard support?

Answer: This motherboard supports up to 16TB 3DS RDIMM/RDIMM DDR5 (288-pin) DDR5 memory with speeds up to 4800MT/s in 64 DIMM slots. To enhance memory performance, do not mix memory modules of different speeds and sizes. Please follow all memory installation instructions given on Section 2-4 in Chapter 2.

Question: How do I update my BIOS?

Answer: We do not recommend that you upgrade your BIOS if you are not experiencing any problems with your system. Updated BIOS files are located on our website at https://www.supermicro.com/support/resources/bios_ipmi.php. Please check our BIOS warning message and the information on how to update your BIOS on our website. Select your motherboard model and download the BIOS file to your computer. Also, check the current BIOS revision to make sure that it is newer than your BIOS before downloading.

 **Note 1:** The SPI BIOS chip used on this motherboard cannot be removed. Send your motherboard back to our RMA Department at Supermicro for repair.

Note 2: For BIOS Update and Recovery instructions, please refer to the Firmware Update and Recovery Instructions for Supermicro's X13 Motherboards User's Guide posted at <http://www.supermicro.com/support/manuals/>.

3.4 Battery Removal and Installation

Battery Removal

To remove the onboard battery, follow the steps below:

1. Power off your system and unplug your power cable.
2. Locate the onboard battery as shown below.
3. Using a tool such as a pen or a small screwdriver, push the battery lock outwards to unlock it. Once unlocked, the battery will pop out from the holder.
4. Remove the battery.

Proper Battery Disposal


Warning: Please handle used batteries carefully. Do not damage the battery in any way; a damaged battery may release hazardous materials into the environment. Do not discard a used battery in the garbage or a public landfill. Please comply with the regulations set up by your local hazardous waste management agency to dispose of your used battery properly.

Battery Installation

To install an onboard battery, follow the steps below:

1. Power off your system and unplug your power cable.
2. Locate the onboard battery as shown below
3. Identify the battery's polarity. The positive (+) side should be facing up.
4. Insert the battery into the battery holder and push it down until you hear a click to ensure that the battery is securely locked.

Warning: When replacing a battery, be sure to only replace it with the same type.



3.5 Returning Merchandise for Service

A receipt or copy of your invoice marked with the date of purchase is required before any warranty service will be rendered. You can obtain service by calling your vendor for a Returned Merchandise Authorization (RMA) number. When returning the motherboard to the manufacturer, the RMA number should be prominently displayed on the outside of the shipping carton, and the shipping package is mailed prepaid or hand-carried. Shipping and handling charges will be applied for all orders that must be mailed when service is complete. For faster service, you can also request a RMA authorization online (<http://www.supermicro.com/RmaForm/>).

This warranty only covers normal consumer use and does not cover damages incurred in shipping or from failure due to the alternation, misuse, abuse or improper maintenance of products.

During the warranty period, contact your distributor first for any product problems.

Chapter 4

UEFI BIOS

4.1 Introduction

This chapter describes the AMIBIOS™ Setup utility for the X13QEH+ motherboard. The BIOS is stored on a chip and can be easily upgraded using the BMC WebUI or the SUM utility.



Note: Due to periodic changes to the BIOS, some settings may have been added or deleted and might not yet be recorded in this manual. Please refer to the Manual Download area of our website for any changes to the BIOS that may not be reflected in this manual.

Starting the Setup Utility

To enter the BIOS Setup utility, press the <Delete> key while the system is booting up. In most cases, the <Delete> key is used to invoke the BIOS Setup screen; however, in other cases, other hot keys, such as <F1>, <F2>, may be used for this purpose. Each main BIOS menu option is described in this manual.

The Main BIOS screen has two main frames. The left frame displays all the options that can be configured. “Grayed-out” options cannot be configured. The right frame displays the key legend. Above the key legend is an area reserved for a text message. When an option is selected in the left frame, it is highlighted in white, and often a text message will accompany it. Please note that BIOS has default text messages built in, and we retain the option to include, omit, or change any of these text messages. Settings printed in **Bold** are the default values. A "▶" indicates a submenu. Highlighting such an item and pressing the <Enter> key will open the list of settings within that submenu.

The BIOS Setup utility uses a key-based navigation system called hot keys. Most of these hot keys (<F1>, <F2>, <F3>, <F4>, <Enter>, <ESC>, <Arrow> keys, etc.) can be used at any time during the setup navigation process.

4.2 Main Setup

When you first enter the AMI BIOS Setup utility, you will see the Main setup screen. You can always return to the Main setup screen by selecting the Main tab on the top of the screen. The Main BIOS Setup screen is shown below.




System Date

This feature displays the current date of the system in operation. The system date is displayed in "Day MM/DD/YYYY" format, which includes the day of the week (Day), the month of the year (in two digits: "MM"), the day of the month (in two digits: "DD"), and the year (in four digits: "YYYY").

System Time

This feature displays the current time of the system in operation, which is based on the RTC (Real Time Clock) of the system. The system time is displayed in "HH:MM:SS" format.

 **Note:** The time is in the 24-hour format. For example, 5:30 P.M. appears as 17:30:00. The date's default value is the BIOS build date after the RTC (Real Time Clock) reset.

Supermicro X13QEH+

BIOS Version

This feature displays the version of the BIOS ROM used in the system.

Build Date

This feature displays the date when the version of the BIOS ROM used in the system was built.

CPLD Version

This feature displays the version of the Complex-Programmable Logical Device (CPLD) used in the system.


Memory Information

Total Memory

This feature displays the total size of memory available in the system.

4.3 Advanced Setup Configurations

Use the arrow keys to select the Advanced submenu and press <Enter> to access the submenu items:




Warning: Take caution when changing the Advanced settings. An incorrect value, an improper DRAM frequency, or a wrong BIOS timing setting may cause the system to malfunction. When this occurs, restore the setting to the manufacturer default setting.

▶ Boot Feature

Quiet Boot

Use this feature to select the screen between displaying Power-on Self Test (POST) messages or the OEM logo at bootup. Select Disabled to display the POST messages. Select Enabled to display the OEM logo instead of the normal POST messages. The options are **Enabled** and Disabled.

 **Note:** BIOS POST messages are always displayed regardless of the setting for this feature.

Option ROM Messages

Use this feature to set the display mode for the Option ROM. Select Keep Current to use the current AddOn ROM display settings. Select Force BIOS to use the Option ROM display mode set by the system BIOS. The options are **Force BIOS** and Keep Current.

Bootup NumLock State

Use this feature to set the Power-on state for the Numlock key. The options are **On** and Off.

Wait For "F1" If Error

Select Enabled to force the system to wait until the <F1> key is pressed if an error occurs. The options are **Disabled** and Enabled.

INT19 Trap Response

Interrupt 19 is the software interrupt that handles the boot disk function. If this feature is set to Immediate, the ROM BIOS of the host adaptors will "capture" Interrupt 19 at bootup immediately and allow the drives that are attached to these host adaptors to function as bootable disks. If this feature is set to Postponed, the ROM BIOS of the host adaptors will not capture Interrupt 19 immediately to allow the drives attached to these adaptors to function as bootable devices at bootup. The options are **Immediate** and Postponed.

Re-try Boot

When EFI (Extensible Firmware Interface) Boot is selected, the system BIOS will automatically reboot the system from an EFI boot device after an initial boot failure. Select Legacy Boot to allow the BIOS to automatically reboot the system from a Legacy boot device after an initial boot failure. The options are **Disabled**, Legacy Boot, and EFI Boot.

Power Configuration**Watch Dog Function**

Select Enabled to allow the Watch Dog timer to reboot the system when it is inactive for more than five minutes. The options are **Disabled** and Enabled.

If this feature is set to Enabled, the following feature will display:

Watch Dog Action (Available when the feature "Watch Dog Function" is enabled)

Use this feature to configure the Watch Dog Time_out setting. The options are **Reset** and NMI.

Front USB Port(s) (Available only when DCMS key is activated)

Select Enabled to allow the specific type of USB devices to be used in the front USB ports. Select Enabled (Dynamic) to allow or disallow this particular type of USB devices to be used in the front USB ports without rebooting the system. The options are **Enabled**, Disabled, and Enabled (Dynamic).



Note: To fully utilize the functionality and features supported by Supermicro Management software and utilities, please use the Supermicro DataCenter Management Suite per Node License Key (SFT-DCMS-SINGLE), which is the license to the Supermicro Data Center Management Suite. To obtain a license key, please contact Supermicro at www.supermicro.com.

Rear USB Port(s) (Available when DCMS key is activated)

Select Enabled to allow the specific type of USB devices to be used in the rear USB ports. Select Enabled (Dynamic) to allow or disallow this particular type of USB devices to be used in the rear USB ports without rebooting the system. The options are **Enabled**, Disabled, and Enabled (Dynamic).

Restore on AC Power Loss


Use this feature to set the power state after a power outage. Select Stay Off for the system power to remain off after a power loss. Select Power On for the system power to be turned on after a power loss. Select Last State to allow the system to resume its last power state before a power loss. The options are Stay Off, Power On, and **Last State**.

Power Button Function

This feature controls how the system shuts down when the power button is pressed. Select 4 Seconds Override to power off the system after the user pressing and holding the power button for four seconds or longer. Select Instant Off to instantly power off the system as soon as the user presses the power button. The options are **Instant Off** and 4 Seconds Override.

► CPU Configuration

Warning: Setting the wrong values for the features included in the following sections may cause the system to malfunction.



Processor Configuration

The following CPU information is displayed for every CPU that is detected by the BIOS:

- Processor BSP Revision
- Processor Socket
- Processor ID
- Processor Frequency
- Processor Max Ratio
- Processor Min Ratio
- Microcode Revision
- L1 Cache RAM (Per Core)
- L2 Cache RAM (Per Core)
- L3 Cache RAM (Per Package)
- Processor 0 Version
- Processor 1 Version

► Advanced Power Management Configuration

Power Technology

Select Energy Efficient to support power-saving mode. Select Custom to customize system power settings. Select Disabled to disable power-saving settings. The options are Disable, Energy Efficient, and **Custom**.

Power Performance Tuning (Available when "Power Technology" is set to Custom)

Select BIOS to allow the system BIOS to configure the Power-Performance Tuning Bias setting. The options are **OS Controls EPB** and BIOS Controls EPB.

ENERGY_PERF_BIAS_CFG Mode (ENERGY PERFORMANCE BIAS CONFIGURATION Mode) (Available when "Power Performance Tuning" is set to BIOS Controls EPB)

Use this feature to configure the proper operation setting for your machine by achieving the desired system performance level and energy saving (efficiency) level at the same time. Select Performance to enhance system performance; however, this may consume more power than Balance Performance setting as energy is needed to fuel the processors for operation. The options are Performance, **Balanced Performance**, Balanced Power,

and Power. (Please note that the options of "Extreme Performance" and "Max Power Efficient" will be available when supported by the motherboard.)

► CPU P State Control

This feature allows you to configure the following CPU power settings:

AVX P1 (Available when "SpeedStep (P-States)" is set to Enable)

Use this feature to set the appropriate TDP (Thermal Design Power) level for the system. The Intel Advanced Vector Extensions (Intel AVX) P1 feature allows you to set the base P1 ratio for Streaming SIMD Extensions (SSE) and AVX workloads. Each P1 ratio has the corresponding AVX Impressed Current Cathodic Protection (ICCP) pre-grant license level, which refers to the selection between different AVX ICCP transition levels. Select Normal for the Intel® AVX feature to operate normally, which will provide a set of instructions to allow Single-Instruction Multiple-Data (SIMD) operations to be performed in Intel processors by adding MMX and SSE support. The options are **Nominal**, Level 1, and Level 2.

SpeedStep (P-States)

Enhanced Intel SpeedStep Technology (EIST) allows the system to automatically adjust processor voltage and core frequency in an effort to reduce power consumption and heat dissipation. Refer to Intel's website for details. The options are Disable and **Enable**.

EIST PSD Function (Available when "SpeedStep (P-States)" is set to Enable)

This feature reduces the latency that occurs when one P-state changes to another, thus allowing the transitions to occur more frequently. This will allow for more demand-based P-state switching to occur based on the real-time energy needs of applications so that the power-to-performance balance can be optimized for energy efficiency. The options are **HW_ALL** and **SW_ALL**.

Turbo Mode (Available when "SpeedStep (P-States)" is set to Enable)

Select Enable to allow the CPU to operate at the manufacturer-defined turbo speed by increasing CPU clock frequency. This feature is available when it is supported by the processors used in the system. The options are Disable and **Enable**.

CPU Flex Ratio Override (Available when "SpeedStep (P-States)" is set to Enable and when your CPU supports this feature)

Select Enable to override the CPU Flex-Ratio setting, which is the minimum multiplier that allows the computer to clock. The options are **Disable** and Enable.

CPU Core Flex Ratio (Available when "CPU Flex Ratio Override" is set to Enable and when your CPU supports this feature)

Use this feature to configure the Core Ratio Multiplier settings for processors in non-Turbo mode. The default setting is **23**.

▶ Hardware PM State Control

Hardware P-States

If this feature is set to Disable, system hardware will choose a P-state setting for the system based on an OS request. If this feature is set to Native Mode, hardware will choose a P-state setting based on the OS guidance. If this feature is set to Native Mode with No Legacy Support, system hardware will choose a P-state setting independently without OS guidance. The options are **Disable**, Native Mode, Out of Band Mode, and Native Mode with No Legacy Support.

▶ Frequency Prioritization

SST-CP

For Intel Speed Select Technology (Intel SST-CP), surplus frequency is allocated based on the cores' weights. The weight for each core is assigned by the OS or the Virtual Machine Manager (VMM). The options are Enable and **Disable**.

▶ CPU C State Control

Enable Monitor MWAIT

Select Enable to support Monitor and Mwait, which are two instructions in Streaming SIMD Extension 3 (SSE3), to improve synchronization between multiple threads for CPU performance enhancement. The options are Disable, Auto, and **Enable**.

CPU C1 Auto Demotion

Select Enable to allow the processor to be automatically demoted to C1 power state. The options are Disable and **Enable**.

CPU C6 Report

Select Enable to allow the BIOS to report the CPU C6 State (ACPI C3) to the OS. During the CPU C6 State, the power to all cache is turned off. The options are Disable, Enable, and **Auto**.

Enhanced Halt State (C1E)

Select Enable to enable "Enhanced Halt State" support, which will significantly reduce the CPU's power consumption by minimizing CPU's clock cycles and reduce voltage during a "Halt State". The options are Disable and **Enable**.

► Package C State Control

Package C State

Use this feature to optimize and reduce CPU package power consumption in the idle mode. Please note that the changes you've made in this setting will have affect on all CPU cores or the circuits of the entire system. The options are C0/C1 state, C2 state, C6 (non Retention) state, C6 (Retention) state, No Limit, and **Auto**.

► CPU1 Core Disable Bitmap / CPU2 Core Disable Bitmap / CPU3 Core Disable Bitmap / CPU4 Core Disable Bitmap

Available Bitmap:

This feature displays the available bitmap.

Disable Bitmap

Enter 0 to enable this feature for all CPU cores. Enter FFFFFFFFFF: to disable this feature for all CPU cores. Please note that at least one core per CPU must be enabled. Disabling all cores is not allowed. The default setting is **0**.

Hyper-Threading [ALL]

Select Enable to use Intel Hyper-Threading Technology to enhance CPU performance. The options are **Enable** and Disable.

Hardware Prefetcher

If this feature is set to Enable, the hardware prefetcher will prefectch data from the main system memory to Level 2 cache to help expedite data transaction to enhance memory performance. The options are Disable and **Enable**.

Adjacent Cache Prefetch

Select Enable for the CPU to prefetch both cache lines for 128 bytes as comprised. Select Disable for the CPU to prefetch both cache lines for 64 bytes. The options are Disable and **Enable**.

DCU Streamer Prefetcher

If this feature is set to Enable, the Data Cache Unit (DCU) streamer prefetcher will prefetch data streams from the cache memory to the DCU to speed up data accessing and processing to enhance CPU performance. The options are Disable and **Enable**.

DCU IP Prefetcher

This feature allows the system to use the sequential load history, which is based on the instruction pointer of previous loads, to determine whether the system will prefetch additional lines. The options are **Enable** and Disable.

LLC Prefetch

If this feature is set to Enable, LLC (hardware cache) prefetching on all threads will be supported. The options are **Disable** and Enable.

Extended APIC (Extended Advanced Programmable Interrupt Controller)

Based on the Intel Hyper-Threading technology, each logical processor (thread) is assigned 256 APIC IDs (APIDs) in 8-bit bandwidth. If this feature is set to Enable, the APIC ID will be expanded from 8 bits to 16 bits to provide 512 APIDs to each thread to enhance CPU performance. The options are Disable and **Enable**.

Intel Virtualization Technology

Select Enable to enable the Intel Vanderpool Technology for Virtualization platform support, which will allow multiple operating systems to run simultaneously on the same computer to maximize system resources for performance enhancement. The options are Disable and **Enable**.



Note: Please reboot the system for any change of the setting to take effect.

Enable SMX

Select Enable to support Safer Mode Extensions (SMX) which provides a programming interface for system software to establish a controlled environment to support the trusted platform configured by the end user and to verify a virtual machine monitor before it is allowed to run. The options are **Disable** and Enable.

PPIN Control

Select Unlock/Enable to use the Protected Processor Inventory Number (PPIN) in the system. The PPIN is a unique number set for tracking a given Intel Xeon server processor. The options are **Lock/Disable** and Unlock/Enable.

AES-NI

Select Enable to use the Intel Advanced Encryption Standard (AES) New Instructions (NI) to ensure data security. The options are Disable and **Enable**.

Limit CPU PA to 46 Bits

Select Enable to limit CPU physical address to 46 bits to support the older Hyper-v CPU platform. The options are Disable and **Enable**.

TME, TME-MT, TDX

Memory Encryption (TME) (Available when your CPU supports Intel TME)

Select Enabled for Intel Total Memory Encryption (TME) support to enhance memory data security. The options are **Disabled** and Enabled.

Total Memory Encryption (TME) Bypass (Available when "Memory Encryption (TME)" is set to Enabled)

Use this feature to disable/enable the TME function for physical memory protection. The options are **Auto**, **Disabled**, and **Enabled**.

Total Memory Encryption Multi-Tenant (TME-MT) (Available when "Memory Encryption (TME)" is set to Enabled and when "Limit CPU PA to 46 Bits" is set to Disable)

Use this feature to support tenant-provided (SW-provided) keys. The options are **Disabled** and **Enabled**.

Memory Integrity (Available when both "Memory Encryption (TME)" and "Total Memory Encryption Multi-Tenant (TME-MT)" are set to Enabled and when "Limit CPU PA to 46 Bits" is set to Disable)

Use this feature to enable TME-MT memory integrity protection for memory transactions. The options are **Disabled** and **Enabled**.

Key stock amount (Available when "Memory Encryption (TME)" is set to Enabled)

Use this feature to set the number of unique keys per system, which also indicates the number of tenants per platform. The default setting is **63**.

TME-MT key ID bits (Available when "Memory Encryption (TME)" is set to Enabled)

Use this feature to set the number of bits for each key ID. The default setting is **6**.

Trust Domain Extension (TDX) (Available when your CPU supports Intel TDX)

Use this feature to enable Intel Trust Domain Extension (TDX) technology support to enhance control of data security. The options are **Disabled** and **Enabled**.

TDX Secure Arbitration Mode Loader (SEAM Loader) (Available when your CPU supports Intel TDX)

The SEAM Loader (SEAMLDR) is used to load and update Intel TDX modules into the SEAM memory range by verifying the digital signature. The options are **Disabled** and **Enabled**.

Software Guard Extension (SGX)

***The following SGX features are available when "Memory Encryption (TME)" is set to Enabled and when your CPU supports Intel SGX.**



Note: Each memory channel must have at least one DIMM populated on the motherboard to support the Intel SGX features.

SGX Factory Reset

Use this feature to perform an SGX factory reset to delete all registration data and force an Initial Platform Establishment flow. Reboot the system for the changes to take effect. The options are **Disabled** and **Enabled**.

SW Guard Extensions (SGX)

Select Enabled to enable Intel Software Guard Extensions (SGX) support. Intel SGX is a set of extensions that increases the security of application code and data by using enclaves in memory to protect sensitive information. The options are **Disabled** and Enabled.

SGX Package Info In-Band Access

Setting this feature to Enabled is required before the BIOS provides software with the key blobs, which are generated for each CPU package. The options are **Disabled** and Enabled.

SGX PRM Size (Available when "SW Guard Extensions (SGX)" is set to Enabled)

Use this feature to set the Processor Reserved Memory Range Register (PRMRR) size. The options are **256M**, 512M, 1G, 2G, 4G, 8G, 16G, 32G, 64G, 128G, 256G, and 512G.

SGX QoS (Available when "SW Guard Extensions (SGX)" is set to Enabled)

Use this feature to enable Intel SGX Quality of Service (QoS) support. QoS can enhance network performance by prioritizing network traffic. The options are Disabled and **Enabled**.

Select Owner EPOCH Input type (Available when "SW Guard Extensions (SGX)" is set to Enabled)

Owner EPOCH is used as a parameter to allow you to add personal entropy into the key derivation process. A correct Owner EPOCH is required to have access to personal data previously sealed by other platform users. There are two Owner EPOCH modes. One is New Random Owner EPOCH , and the other is manually entered by the user. Each EPOCH is 64-bit. The options are Change to New Random Owner EPOCHs and **Manual User Defined Owner EPOCHs**.



Note: Changing the Owner EPOCH value will cause data loss in enclaves.

Software Guard Extensions Epoch 0 (Available when "SW Guard Extensions (SGX)" is set to Enabled and "Select Owner EPOCH input type" is set to Manual User Defined Owner EPOCHs)

Use this feature to enter the EPOCH value. The default is **0**.

Software Guard Extensions Epoch 1 (Available when "SW Guard Extensions (SGX)" is set to Enabled and "Select Owner EPOCH input type" is set to Manual User Defined Owner EPOCHs)

Use this feature to enter the EPOCH value. The default is **0**.

SGXLEPUBKEYHASHx Write Enable (Available when "SW Guard Extensions (SGX)" is set to Enabled)

If this feature is enabled, "write to SGXLEPUBKEYHASH[3..0] from OS/SW" will be supported. The options are Disabled and **Enabled**. Only those CPUs that support Intel SGX Flexible Launch Control (FLC) feature have SGXLEPUBKEYHASH, which contains the hash of the public key for the SGX Launch Enclave (LE) to be signed with.

SGXLEPUBKEYHASH0 (Available when both "SW Guard Extensions (SGX)" and "SGXLEPUBKEYHASHx Write Enable" are set to Enabled)

Use this feature to enter the bytes 0-7 of SGX Launch Enclave Public Key Hash.

SGXLEPUBKEYHASH1 (Available when both "SW Guard Extensions (SGX)" and "SGXLEPUBKEYHASHx Write Enable" are set to Enabled)

Use this feature to enter the bytes 8-15 of SGX Launch Enclave Public Key Hash.

SGXLEPUBKEYHASH2 (Available when both "SW Guard Extensions (SGX)" and "SGXLEPUBKEYHASHx Write Enable" are set to Enabled)

Use this feature to enter the bytes 16-23 of SGX Launch Enclave Public Key Hash.

SGXLEPUBKEYHASH3 (Available when both "SW Guard Extensions (SGX)" and "SGXLEPUBKEYHASHx Write Enable" are set to Enabled)

Use this feature to enter the bytes 24-31 of SGX Launch Enclave Public Key Hash.

SGX Auto MP Registration (Available when "SW Guard Extensions (SGX)" is set to Enabled)

If this feature is set to Enabled, SGX Auto Multi-Package Registration Agent (MPA) will run automatically at boot time. The options are **Disabled** and Enabled.

► Chipset Configuration

Warning: Setting the wrong values in the following features may cause the system to malfunction.

► North Bridge

This feature allows you to configure the following North Bridge settings.

► Uncore Configuration

The following information is displayed.


- Number of CPU
- Current UPI Link Speed
- Current UPI Link Frequency
- Global MMIO Low Base / Limit
- Global MMIO High Base / Limit
- PCIe Configuration Base / Size

Degrade Precedence

Use this feature to select the degrading precedence option for Ultra Path Interconnect (UPI) connections. Select Topology Precedent to degrade UPI features if system options are in conflict. Select Feature Precedent to degrade UPI topology if system options are in conflict. The options are **Topology Precedence** and Feature Precedence.


Link L0p Enable

Select Enable for the system BIOS to enable Link L0p support which will allow the CPU to reduce the UPI links from full width to half width in the event when the CPU's workload is low in an attempt to save power. This feature is available for the system that uses Intel processors with UPI technology support. The options are Disable, Enable, and **Auto**.

 **Note:** You can change the performance settings for non-standard applications by using this parameter. It is recommended that the default settings be used for standard applications.

Link L1 Enable

Select Enable for the BIOS to activate Link L1 support which will power down the UPI links to save power when the system is idle. This feature is available for the system that uses Intel processors with UPI technology support. The options are Disable, Enable, and **Auto**.

 **Note:** Link L1 is an excellent feature for an idle system. L1 is used during Package C-States when its latency is hidden by other components during a wakeup.

KTI Prefetch

Use this feature to configure the Prefetch setting supported by Keizer Technology Interconnect (KTI), also known as Intel Ultra Path Interconnect (UPI) Technology. Select Enable for the KTI prefetcher to preload the L1 cache with data deemed relevant, which will allow the memory read to start earlier on a DDR bus in an effort to reduce latency. Select Auto for the KTI prefetcher to automatically preload the L1 cache with relevant data whenever is needed. The options are Disable, Enable, and **Auto**.

Local/Remote Threshold

Use this feature to set the threshold for the Interrupt Request (IRQ) signals while handling hardware interrupts. The options are Disable, **Auto**, Low, Medium, and High.

IO Directory Cache (IODC)

Select Enable for the IODC to generate snoops instead of generating memory lockups for remote IIO (InvlToM) and/or WCiLF (Cores). Select Auto for the IODC to generate snoops (instead of memory lockups) for WCiLF (Cores). The options are Disable, **Auto**, Enable for Remote InvltoM Hybrid Push, InvltoM AllocFlow, Enable for Remote InvltoM Hybrid AllocNonAlloc, and Enable for Remote InvltoM and Remote WViLF.

SNC

Sub NUMA Clustering (SNC) is a feature that breaks up the Last Level Cache (LLC) into clusters based on the address range. Each cluster is connected to a subset of the memory controller. Enable this feature to improve average latency and reduce memory access congestion for higher performance. The options are **Auto**, Disable, Enable SNC2 (2-clusters), and Enable SNC4 (4-clusters).

Stale AtoS (A to S)

The in-memory directory has three states: I, A, and S states. The I (-invalid) state indicates that the data is clean and does not exist in the cache of any other sockets. The A (-snoop All) state indicates that the data may exist in another socket in an exclusive or modified state. The S state (-Shared) indicates that the data is clean and may be shared in the caches across one or more sockets. When the system is performing "read" on the memory and if the directory line is in A state, we must snoop all other sockets because another socket may have the line in a modified state. If this is the case, a "snoop" will return the modified data. However, it may be the case that a line "reads" in an A state, and all the snoops come back with a "miss". This can happen if another socket reads the line earlier and then has silently dropped it from its cache without modifying it. If "Stale AtoS" is enabled, a line will transition to the S state when the line in the A state returns only snoop misses. That way, subsequent reads to the line will encounter it in the S state and will not have to snoop, saving the latency and snoop bandwidth. Stale "AtoS" may be beneficial in a workload where there are many cross-socket reads. The options are Disable, Enable, and **Auto**.

LLC Dead Line Alloc

Select Enable to opportunistically fill the deadlines in the LLC. The options are Disable, **Enable**, and Auto.

UPI3

Select Enable to enable the 4th Intel® UPI (Ultra Path Interconnect) link. The options are Disable and **Enable**.

► Memory Configuration

This feature allows you to configure the Integrated Memory Controller (iMC) settings.

Enforce DDR Memory Frequency POR

Select POR to enforce Plan of Record (POR) restrictions for DDR memory frequency and voltage programming. The options are **POR** and Disable.

Memory Frequency

Use this feature to set the maximum memory frequency for onboard memory modules. The options are **Auto**, 3200, 3600, 4000, 4400, 4800, 5200, and 5600. (Please note that the available options are CPU-dependent.)

Data Scrambling for DDR5

Select Enable to enable data scrambling for DDR5 modules to enhance memory data security. The options are Disable and **Enable**.

Enable fADR

Select Enable for Fast Asynchronous DRAM Refresh (fADR) support to enhance memory performance on Intel Persistent Memory. With the support of fADR feature, the ADR safe domain (flush domain) includes CPU caches, I/O caches, and Write Pending Queue (WPQ). The implementation of fADR can lower flush time and reduce flush times. The support of fADR is based on your motherboard hardware features. The options are **Disable** and Enable.

Enable ADR (Available when "Enable fADR" is set to Disable)

Select Enable for Asynchronous DRAM Refresh (ADR) support to enhance memory performance. The options are Disable and **Enable**.

Legacy ADR Mode (Available when "Enable fADR" is set to Disable and "Enable ADR" is set to Enable)

Use this feature to support the Legacy ADR mode to enhance memory performance. In the Legacy ADR mode, the ADR safe domain (flush domain) includes the WPQ in memory controllers. The options are Disable, Enable, and **Auto**.

► fADR Configuration (Available when "Enable fADR" is set to Enable)

Number of Cores

Use this feature to set the number of CPU cores to be involved in the fADR event. The options are 1 Core, 4 Cores, and **All Cores**.

Core Ratio

Use this feature to set the CPU core ratio to be involved in the fADR event. The options are **Auto** and Manual.

Core Ratio Value (Available when "Core Ratio" is set to Manual)

Use this feature to enter the core ratio value.

Mesh Ratio

Use this feature to set the mesh ratio to be involved in the fADR event. The mesh ratio determines the frequency of data access between CPU cores and caches. The options are **Auto** and Manual.

Mesh Ratio Value (Available when "Mesh Ratio" is set to Manual)

Use this feature to enter the mesh ratio value.

Flush Timeout

Use this feature to set the timeout setting when the data in the CPU cache memory will be flushed by the applications to persistent memory in the absence of system power. The options are **Auto** and Manual.

Flush Timeout Value (Available when "Flush Timeout" is set to Manual)

Use this feature to enter the flush timeout value. The default value is FFF.

DDR 2X Refresh Enable

Select Enable for memory 2X refresh support to enhance memory performance. The options are **Auto**, Disable, and Enable.

►Memory Topology

This feature displays the information of onboard memory modules as detected by the BIOS, for example:

P1-DIMMA1: 4400MT/s Hynix DRx8 32GB RDIMM/ P1-DIMMA2: 4400MT/s Hynix DRx8 32GB RDIMM ~ P1-DIMMH1: 4400MT/s Hynix DRx8 32GB RDIMM / P1-DIMMH2: 4800MT/s Hynix DRx8 32GB RDIMM

P2-DIMMA1: 4400MT/s Hynix DRx8 32GB RDIMM/ P2-DIMMA2: 4400MT/s Hynix DRx8 32GB RDIMM ~ P2-DIMMH1: 4400MT/s Hynix DRx8 32GB RDIMM / P2-DIMMH2: 4800MT/s Hynix DRx8 32GB RDIMM

►Memory RAS Configuration

Use this submenu to configure the following Memory Reliability_Availability_Serviceability (RAS) settings.

Mirror Mode (Available when "ADDDC Sparing" is set to Disabled)

Use this feature to configure the mirror mode settings for all 1LM/2LM memory modules in the system which will create a duplicate copy of data stored in the memory to increase memory security, but it will reduce the memory capacity into half. The options are **Disabled**, Full Mirror Mode, and Partial Mirror Mode.

UEFI ARM Mirror (Available when "ADDDC Sparing" is set to Disabled and "Mirror Mode" is set to Disabled)

If this feature is set to Enable, mirror mode configuration settings for UEFI-based Address Range memory will be enabled upon system boot. This will create a duplicate

copy of data stored in the memory to increase memory security, but it will reduce the memory capacity into half. The options are **Disabled** and **Enabled**.

ARM Mirror Percentage (Available when "UEFI ARM Mirror" is set to Enabled)

Use this feature to set the percentage of memory space to be used for UEFI ARM mirroring for memory security enhancement. The default setting is **0**.

Correctable Error Threshold

Use this feature to specify the threshold value for correctable memory-error logging, which sets a limit on the maximum number of events that can be logged in the memory error log at a given time. The default setting is **512**.

Leaky Bucket Low Bit

Use this feature to set the Low Bit value for the Leaky Bucket algorithm which is used to check the data transmissions between CPU sockets and the memory controller. The default setting is **11**.

Leaky Bucket High Bit

Use this feature to set the High Bit value for the Leaky Bucket algorithm which is used to check the data transmissions between CPU sockets and the memory controller. The default setting is **14**.

ADDDC Sparing (Available when populating 1Rx4, 2Rx4, and 4Rx4 DIMM)

Select **Enabled** for Adaptive Double Device Data Correction (ADDDC) support, which will not only provide memory error checking and correction but will also prevent the system from issuing a performance penalty before a device fails. Please note that virtual lockstep mode will only start to work for ADDDC after a faulty DRAM module is spared. The options are **Disabled** and **Enabled**.

Patrol Scrub

Patrol Scrubbing is a process that allows the CPU to correct correctable memory errors detected in a memory module and send the corrections to the requestor (the original source). If this feature is set to **Enable**, the IO hub will read and write back one cache line every 16K cycles if there is no delay caused by internal processing. By using this method, roughly 64 GB of memory behind the IO hub will be scrubbed every day. The options are **Disabled** and **Enable at End of POST** (Power_On Self Test) upon system boot.

DDR PPR Type

Post Package Repair (PPR) is a new feature available for the DDR4/DDR5 technology. PPR provides additional spare capacity within a DDR4/DDR5 DRAM module that is used to replace faulty cell areas detected during system boot. PPR offers two types of memory repairs. Soft Post Package Repair (sPPR) provides a quick, temporary fix on a raw element in a bank group of a DDR4/DDR5 DRAM device, while hard Post Package Repair (hPPR) will take a longer time to provide a permanent repair on a raw element. The options are **PPR Disabled**, **Hard PPR**, and **Soft PPR**.

Enhanced PPR

Use this feature to set advanced memory test for PPR enhancement. Select Enabled to always execute for every boot. Select Once to execute only one time. The options are **Disabled**, Enabled, and Once.

Memory PFA Support (Available when the DCMS key is activated)

Select Enabled to enable memory Predictive Failure Analysis (PFA) support. PFA can be used to avoid uncorrectable faults on the same memory page. The options are **Disabled** and Enabled.

► IIO Configuration**► CPU1 Configuration / CPU2 Configuration / CPU3 Configuration / CPU4 Configuration (Available when the CPU specified is detected by the BIOS)****IOU0 (IIO PCIe Port 1)**

This feature is CPU-dependent. Use this feature to configure the PCIe Bifurcation setting for a PCIe port specified by the user. The options are **Auto**, x4x4x4x4, x4x4x8, x8x4x4, x8x8, and x16 .

IOU1 (IIO PCIe Port 2)

This feature is CPU-dependent. Use this feature to configure the PCIe Bifurcation setting for a PCIe port specified by the user. The options are **Auto**, x4x4x4x4, x4x4x8, x8x4x4, x8x8, and x16.

IOU2 (IIO PCIe Port 3)

This feature is CPU-dependent. Use this feature to configure the PCIe Bifurcation setting for a PCIe port specified by the user. The options are **Auto**, x4x4x4x4, x4x4x8, x8x4x4, x8x8, and x16.


IOU3 (IIO PCIe Port 4)

This feature is CPU-dependent. Use this feature to configure the PCIe Bifurcation setting for a PCIe port specified by the user. The options are **Auto**, x4x4x4x4, x4x4x8, x8x4x4, x8x8, and x16.

IOU4 (IIO PCIe Port 5)

This feature is CPU-dependent. Use this feature to configure the PCIe Bifurcation setting for a PCIe port specified by the user. The options are **Auto**, x4x4x4x4, x4x4x8, x8x4x4, x8x8, and x16.

▶ Socket0 Port DMI

 **Note:** The number of slots and the slot naming vary based on the features supported by your motherboard.

Link Speed

Use this feature to select the link speed for the PCIe port specified by the user. The options are **Auto**, Gen 1 (2.5 GT/s), Gen 2 (5 GT/s), Gen 3 (8 GT/s), and Gen 4 (16 GT/s).

The following information is displayed:

PCIe Port Link Status

PCIe Port Link Max

PCIe Port Link Speed

Data Link Feature Exchange

Use this feature to enable/disable the PCIe port to enter PCIe 4.0 DL_Feature negotiation state. The options are Disable and **Enable**.

DMI (Direct Media Interface) Port MPSS

Use this feature to set the maximum payload size supported in the DMI device capability register for the device installed in the PCIe port specified by the user. The options are 128B, 256B, and **Auto**.

▶ IOAT Configuration

Relaxed Ordering

Select Yes to allow certain transactions to be processed and completed before other transactions that have already been enqueued. The options are **No** and Yes.

▶ Intel® VT for Directed I/O (VT-d)

Intel® VT for Directed I/O (VT-d)

Select Enable to use Intel Virtualization Technology for Direct I/O VT-d support by reporting the I/O device assignments to the Virtual Machine Monitor (VMM) through the DMAR ACPI tables. This feature offers fully-protected I/O resource sharing across Intel platforms, providing greater reliability, security and availability in networking and data-sharing. The options are **Enable** and Disable.

Pre-boot DMA Protection (Available when "Intel® VT for Directed I/O (VT-d)" is set to Enable)

If this feature is set to Enable, the DMA_CTRL_PLATFORM_OPT_IN flag setting will be enabled in the DMAR table in the ACPI (Advanced Configuration and Power Interface section). The options are **Disable** and Enable.

Interrupt Remapping (Available when "Intel® VT for Directed I/O (VT-d)" is set to Enable)

Select Enable to support I/O DMA transfer remapping and device-generated interrupts. The options are **Auto**, Enable, and Disable.

PCIe ACSCTL (Available when "Intel® VT for Directed I/O (VT-d)" is set to Enable)

Select Enable to program ACS control to Chipset PCIe Root Port bridges. Select Disable to program ACS control to all PCIe Root Port bridges. The options are Enable and **Disable**.

▶ **Intel® VMD Technology**

This section describes the configuration settings for the Intel VMD technology.



Note 1: After you've enabled VMD in the BIOS on a PCIe slot, this PCIe slot will be dedicated for VMD use only, and it will no longer support any PCIe device. To re-activate this slot for PCIe use, please disable VMD in the BIOS.

Note 2: The number of PCIe slots and the slot naming can differ depending on the PCIe devices connected to your motherboard.

NVMe Mode Switch

If this feature is set to Auto, VMD support will be automatically enabled when a VROC key is detected by the BIOS. The options are Manual, VMD, and **Auto**.

If this feature is set to Manual, the following items will display:

▶ **Intel® VMD for Volume Management Device on Socket 0 (CPU1) (Available when "NVMe Mode Switch" is set to Manual)**

VMD Configuration for PCH Ports

Enable/Disable VMD

Select Enable to enable the Intel VMD technology support for the root port specified. The options are **Disable** and Enable. When this option is set to Enable, the following items will display.

PCH Root Port 4 / PCH Root Port 8 (Available when the device is detected by the BIOS and the setting "Enable/Disable VMD" is set to Enable)

This feature allows the user to configure the VMD settings for the device specified by the user.

Hot Plug Capable

Select Enable to enable Hot Plug support for the root ports specified, which allows you to change the devices on those root ports without shutting down the system. The options are **Disable** and Enable.

VMD Config for IOU 0 / VMD Config for IOU 1 / VMD Config for IOU 2 / VMD Config for IOU 3 / VMD Config for IOU 4 (Available when the device is detected by the BIOS and the setting "Enable/Disable VMD" is set to Enable)

Enable/Disable VMD

Select Enable to enable the Intel VMD technology support for the root port specified. The options are **Disable** and Enable. When this option is set to Enable, the following items will display.

Socket0 IOU0~IOU4 VMD Port A / Socket0 IOU0~IOU4 VMD Port C / Socket0 IOU0~IOU4 VMD Port E / Socket0 IOU0~ IOU4 VMD Port G (Available when the device is detected by the BIOS and the setting "Enable/Disable VMD" is set to Enable)

This feature allows the user to configure the VMD settings for the device specified by the user.

Hot Plug Capable

Select Enable to enable Hot Plug support for the root ports specified, which allows you to change the devices on those root ports without shutting down the system. The options are **Disable** and Enable.

**▶Intel® VMD for Volume Management Device on Socket 1 (CPU2)
(Available when "NVMe Mode Switch" is set to Manual)**

VMD Config for IOU 0 / VMD Config for IOU 1 / VMD Config for IOU 2 / VMD Config for IOU 3 / VMD Config for IOU 4 (Available when the device is detected by the BIOS and the setting "Enable/Disable VMD" is set to Enable)

Enable/Disable VMD

Select Enable to enable the Intel VMD technology support for the root port specified. The options are **Disable** and Enable. When this option is set to Enable, the following items will display.

Socket1 IOU0~IOU4 VMD Port A / Socket1 IOU0~IOU4 VMD Port C / Socket1 IOU0~IOU4 VMD Port E / Socket1 IOU0~ IOU4 VMD Port G (Available when the device is detected by the BIOS and the setting "Enable/Disable VMD" is set to Enable)

This feature allows the user to configure the VMD settings for the device specified by the user.

Hot Plug Capable

Select Enable to enable Hot Plug support for the root ports specified, which allows you to change the devices on those root ports without shutting down the system. The options are **Disable** and Enable.

► Intel® VMD for Volume Management Device on Socket 2 (CPU3) (Available when "NVMe Mode Switch" is set to Manual)

VMD Config for IOU 0 / VMD Config for IOU 1 / VMD Config for IOU 2 / VMD Config for IOU 3 / VMD Config for IOU 4 (Available when the device is detected by the BIOS and the setting "Enable/Disable VMD" is set to Enable)

Enable/Disable VMD

Select Enable to enable the Intel VMD technology support for the root port specified. The options are **Disable** and Enable. When this option is set to Enable, the following items will display.

Socket2 IOU0~IOU4 VMD Port A / Socket2 IOU0~IOU4 VMD Port C / Socket2 IOU0~IOU4 VMD Port E / Socket2 IOU0~ IOU4 VMD Port G (Available when the device is detected by the BIOS and the setting "Enable/Disable VMD" is set to Enable)

This feature allows the user to configure the VMD settings for the device specified by the user.

Hot Plug Capable

Select Enable to enable Hot Plug support for the root ports specified, which allows you to change the devices on those root ports without shutting down the system. The options are **Disable** and Enable.

► Intel® VMD for Volume Management Device on Socket 3 (CPU4) (Available when "NVMe Mode Switch" is set to Manual)

VMD Config for IOU 0 / VMD Config for IOU 1 / VMD Config for IOU 2 / VMD Config for IOU 3 / VMD Config for IOU 4 (Available when the device is detected by the BIOS and the setting "Enable/Disable VMD" is set to Enable)

Enable/Disable VMD

Select Enable to enable the Intel VMD technology support for the root port specified. The options are **Disable** and Enable. When this option is set to Enable, the following items will display.

Socket3 IOU0~IOU4 VMD Port A / Socket3 IOU0~IOU4 VMD Port C / Socket3 IOU0~IOU4 VMD Port E / Socket3 IOU0~ IOU4 VMD Port G (Available when the device is detected by the BIOS and the setting "Enable/Disable VMD" is set to Enable)

This feature allows the user to configure the VMD settings for the device specified by the user.

Hot Plug Capable

Select Enable to enable Hot Plug support for the root ports specified, which allows you to change the devices on those root ports without shutting down the system. The options are **Disable** and Enable.

IIO-PCIE Express Global Options
-----**PCIe ASPM Support (Global)**

Select Enabled to enable ASPM (Active State Power Management) support for a device installed in a PCIe drive specified by the user. The options are **Disable** and Auto.

IIO eDPC Support (Available when your system supports this feature)

Use this feature to configure the setting for IIO Enhanced Downstream Port Containment (eDPC) support for your system in an effort to improve the error containment capacity within the PCIe subsystem when an uncorrected error is detected either at the root port or at the switch downstream port. Select Disable to disable IIO eDPC support. Select On Fatal Error to enable IIO eDPC support in your system when a fatal error occurs. Select On Fatal and Non-Fatal Error to enable IIO eDPC support when an error, fatal or non-fatal, has occurred. The options are **Disable**, On Fatal Error, and On Fatal and Non-Fatal Errors.

► South Bridge

The following information is displayed:

- USB Module Version
- USB Devices:

Legacy USB Support

Select Enabled to support onboard legacy USB devices. Select Auto to disable legacy support if there are no legacy USB devices present. Select Disabled to have all USB devices available for EFI applications only. The options are **Enabled**, Disabled, and Auto.

XHCI Hand-off

This is a work-around solution for the operating systems that do not support Extensible Host Controller Interface (XHCI) hand-off. The XHCI ownership change should be claimed by the XHCI driver. The options are **Enabled** and Disabled.

Port 60/64 Emulation

Select Enabled for I/O port 60h/64h emulation support, which in turn, provides complete legacy USB keyboard support for the operating systems that do not support legacy USB devices. The options are **Disabled** and Enabled.

► Server ME Information

The following information is displayed:

- General ME Configuration
- Oper. Firmware Version
 - Current State
 - Error Code

► PCH SATA0 Configuration / ► PCH SATA1 Configuration / ► PCH SATA2 Configuration (Available when related components are installed and detected by the BIOS)

When this submenu is selected, the AMI BIOS automatically detects the presence of the SATA devices that are supported by the Intel PCH chip and displays the following features.

SATA Controller(s)

This feature enables or disables the onboard SATA controller(s) supported by the Intel PCH chip. The options are Disabled and **Enabled**.

SATA Mode Selection (Available when "SATA Controller(s)" is set to Enabled)

Use this feature to select the mode of installed SATA drives. The options are **AHCI** and RAID.



Note 1: The option of RAID is unavailable when "Boot Mode Select" is set to Legacy.

Note 2: Refer to Boot submenu in the BIOS Setup main menu to set "Boot Mode Select".

Support Aggressive Link Power Management (Available when "SATA Controller(s)" is set to Enabled)

If this feature is set to Enabled, the SATA AHCI controller manages the power use of the SATA link. The controller will put the link in a low power mode during an extended period of I/O inactivity, and will return the link to an active state when I/O activity resumes. The options are **Disabled** and Enabled.

SATA SGPIO Mode (Available when "SATA Controller(s)" is set to Enabled)

Select Enabled for Serial_Link General Purpose I/O (SGPIO) Mode support. The options are LED and **SGPIO**.

SATA Port 0 - SATA Port 7 (Available when "SATA Controller(s)" is set to Enabled)



Note: The SATA port naming may vary based on the related configuration.

Hot Plug

Select Enabled to support Hot-plugging for the device installed on a selected SATA port to allow you to replace the device installed in the slot without shutting down the system. The options are Disabled and **Enabled**.

Spin Up Device

Select Enabled for Staggered Spin Up support to allow the SATA devices specified by the user to spin up one at a time at boot up in an effort to prevent all hard drive disks from spinning up at the same time, causing a power surge. The options are **Disabled** and Enabled.

SATA Device Type

Use this feature to specify if the device installed on the SATA port specified by the user should be connected to a Solid State drive or a Hard Disk Drive. The options are **Hard Disk Drive** and Solid State Drive.

► Super IO Configuration (Available when your system supports this feature)

The following information is displayed.

- Super IO Chip

► Serial Port 1 Configuration

Serial Port 1

Select Enabled to enable serial port 1. The options are Disabled and **Enabled**.

Device Settings (Available when "Serial Port 1" is set to Enabled)

This feature displays the base I/O port address and the Interrupt Request address of serial port 1.

Change Settings (Available when "Serial Port 1" is set to Enabled)

This feature specifies the base I/O port address and the Interrupt Request address of serial port 1. Select Auto for the BIOS to automatically assign the base I/O and IRQ address to serial port 1. The options are **Auto**, (IO=3F8h; IRQ=4;), (IO=2F8h; IRQ=4;), (IO=3E8h; IRQ=4;), and (IO=2E8h; IRQ=4;).

► Serial Port 2 Configuration



Note: It can be "Serial Port 2 Configuration" or "SOL Configuration" based on your system support.

Serial Port 2 ("SOL" or "Serial Port 2" based on your system support)

Select Enabled to enable SOL or Serial port 2. The options are Disabled and **Enabled**.

Device Settings (Available when "SOL/Serial Port 2" is set to Enabled)

This feature displays the base I/O port address and the Interrupt Request address of Serial Port 2 or SOL port.

Change Settings (Available when "SOL/Serial Port 2 is set to Enabled)

This feature specifies the base I/O port address and the Interrupt Request address of serial port 2. Select Auto for the BIOS to automatically assign the base I/O and IRQ address to serial port 2. The options are **Auto**, (IO=2F8h; IRQ=3;), (IO=3F8h; IRQ=3;), (IO=3E8h; IRQ=3;), and (IO=2E8h; IRQ=3;).

Serial Port 2 Attribute (Available for Serial Port 2 only)

Select SOL to use serial port 2 as a Serial Over LAN (SOL) port for console redirection. The options are **SOL** and COM.

► Serial Port Console Redirection

COM1 (Available when your system supports serial port of COM1)

Console Redirection

Select Enabled to enable COM port 1 for Console Redirection, which allows a client machine to be connected to a host machine at a remote site for networking. The options are **Disabled** and Enabled.



Note: This feature will be set to Enabled if there is no BMC support.

► Console Redirection Settings (Available when "Console Redirection" above is set to Enabled)

Terminal Type

Use this feature to select the target terminal emulation type for Console Redirection. Select VT100 to use the ASCII Character set. Select VT100+ to add color and function key support. Select ANSI to use the Extended ASCII Character Set. Select VT-UTF8 to use UTF8 encoding to map Unicode characters into one or more bytes. The options are VT100, **VT100+**, VT-UTF8, and ANSI.

Bits Per Second

Use this feature to set the transmission speed for a serial port used in Console Redirection. Make sure that the same speed is used in the host computer and the client computer. A lower transmission speed may be required for long and busy lines. The options are 9600, 19200, 38400, 57600, and **115200** (bits per second).

Data Bits

Use this feature to set the data transmission size for Console Redirection. The options are 7 and **8** (bits).

Parity

A parity bit can be sent along with regular data bits to detect data transmission errors. Select Even if the parity bit is set to 0, and the number of 1's in data bits is even. Select Odd if the parity bit is set to 0, and the number of 1's in data bits is odd. Select None if you do not want to send a parity bit with your data bits in transmission. Select Mark to add a mark as a parity bit to be sent along with the data bits. Select Space to add a Space as a parity bit to be sent with your data bits. The options are **None**, Even, Odd, Mark, and Space.

Stop Bits

A stop bit indicates the end of a serial data packet. Select 1 Stop Bit for standard serial data communication. Select 2 Stop Bits if slower devices are used. The options are **1** and 2.

Flow Control

Use this feature to set the flow control for Console Redirection to prevent data loss caused by buffer overflow. Send a "Stop" signal to stop sending data when the receiving buffer is full. Send a "Start" signal to start sending data when the receiving buffer is empty. The options are **None** and Hardware RTS/CTS.

VT-UTF8 Combo Key Support

Select Enabled to enable VT-UTF8 Combination Key support for ANSI/VT100 terminals. The options are Disabled and **Enabled**.

Recorder Mode

Select Enabled to capture the data displayed on a terminal and send it as text messages to a remote server. The options are **Disabled** and Enabled.


Resolution 100x31

Select Enabled for extended-terminal resolution support. The options are Disabled and **Enabled**.

Putty KeyPad

This feature selects Function Keys and KeyPad settings for Putty, which is a terminal emulator designed for the Windows OS. The options are **VT100**, LINUX, XTERMR6, SCO, ESCN, and VT400.

SOL/COM2

 **Note:** This feature is available when your system supports serial port of COM2 and/or SOL. The "SOL" here indicates a shared serial port, and SOL is used as the default.

Console Redirection

Select Enabled to use the SOL/COM2 port for Console Redirection. The options are Disabled and **Enabled**.

► Console Redirection Settings (Available when "Console Redirection" above is set to Enabled)

Use this feature to specify how the host computer will exchange data with the client computer.

Terminal Type

Use this feature to select the target terminal emulation type for Console Redirection. Select VT100 to use the ASCII Character set. Select VT100+ to add color and function key support. Select ANSI to use the Extended ASCII Character Set. Select VT-UTF8 to use UTF8 encoding to map Unicode characters into one or more bytes. The options are VT100, **VT100+**, VT-UTF8, and ANSI.

Bits Per Second

Use this feature to set the transmission speed for a serial port used in Console Redirection. Make sure that the same speed is used in the host computer and the client computer. A lower transmission speed may be required for long and busy lines. The options are 9600, 19200, 38400, 57600, and **115200** (bits per second).

Data Bits

Use this feature to set the data transmission size for Console Redirection. The options are 7 and **8** (bits).

Parity

A parity bit can be sent along with regular data bits to detect data transmission errors. Select Even if the parity bit is set to 0, and the number of 1's in data bits is even. Select Odd if the parity bit is set to 0, and the number of 1's in data bits is odd. Select None if you do not want to send a parity bit with your data bits in transmission. Select Mark to add a mark as a parity bit to be sent along with the data bits. Select Space to add a Space as a parity bit to be sent with your data bits. The options are **None**, Even, Odd, Mark, and Space.

Stop Bits

A stop bit indicates the end of a serial data packet. Select 1 Stop Bit for standard serial data communication. Select 2 Stop Bits if slower devices are used. The options are **1** and 2.

Flow Control

Use this feature to set the flow control for Console Redirection to prevent data loss caused by buffer overflow. Send a "Stop" signal to stop sending data when the receiving buffer is full. Send a "Start" signal to start sending data when the receiving buffer is empty. The options are **None** and Hardware RTS/CTS.

VT-UTF8 Combo Key Support

Select Enabled to enable VT-UTF8 Combination Key support for ANSI/VT100 terminals. The options are Disabled and **Enabled**.

Recorder Mode

Select Enabled to capture the data displayed on a terminal and send it as text messages to a remote server. The options are **Disabled** and Enabled.

Resolution 100x31

Select Enabled for extended-terminal resolution support. The options are Disabled and **Enabled**.

Putty KeyPad

This feature selects Function Keys and KeyPad settings for Putty, which is a terminal emulator designed for the Windows OS. The options are **VT100**, LINUX, XTERMR6, SCO, ESCN, and VT400.

Legacy Console Redirection

► Legacy Console Redirection Settings

Legacy Serial Redirection Port

Use this feature to select a Serial port to display redirection of Legacy OS and Legacy OPRM messages. The options are **COM1** and SOL/COM2. Please note that the available options are based on your motherboard features.

Resolution

Use this feature to select the numbers of rows and columns used in Console Redirection for Legacy OS support. The options are 80x24 and **80x25**.

Redirect After BIOS POST

Use this feature to enable or disable legacy console redirection after BIOS POST. When the option - BootLoader is selected, legacy console redirection is disabled before booting the OS. When the option - Always Enable is selected, legacy console redirection remains enabled upon OS bootup. The options are **Always Enable** and BootLoader.

Serial Port for Out-of-Band Management/Windows Emergency Management Services (EMS)

The feature allows you to configure Console Redirection settings to support Out-of-Band Serial Port management.

Console Redirection EMS

Select Enabled to use the SOL/COM2 port for Console Redirection for Microsoft Emergency Services. The options are **Disabled** and Enabled.

► Console Redirection Settings (Available when "Console Redirection EMS" above is set to Enabled)

Out-of-Band Mgmt (Management) Port

The feature selects a serial port in a client server to be used by the Microsoft Windows Emergency Management Services (EMS) to communicate with a remote host server. The options are **COM1** and SOL/COM2. Please note that the option of SOL/COM2 indicates a shared serial port. SOL/COM2 is available with BMC support.

Terminal Type EMS

Use this feature to select the target terminal emulation type for Console Redirection. Select VT100 to use the ASCII character set. Select VT100+ to add color and function key support. Select ANSI to use the extended ASCII character set. Select VT-UTF8 to use UTF8 encoding to map Unicode characters into one or more bytes. The options are VT100, VT100+, **VT-UTF8**, and, ANSI.

Bits Per Second EMS

This feature sets the transmission speed for a serial port used in Console Redirection. Make sure that the same speed is used in the host computer and the client computer. A lower transmission speed may be required for long and busy lines. The options are 9600, 19200, 57600, and **115200** (bits per second).

Flow Control EMS

Use this feature to set the flow control for Console Redirection to prevent data loss caused by buffer overflow. Send a "Stop" signal to stop sending data when the receiving buffer is full. Send a "Start" signal to start sending data when the receiving buffer is empty. The options are **None**, Hardware RTS/CTS, and Software Xon/Xoff.

The following information is displayed:

Data Bits EMS / Parity EMS / Stop Bits EMS

► Network Configuration

Network Stack

Select Enabled to enable Preboot Execution Environment (PXE) or Unified Extensible Firmware Interface (UEFI) for network stack support. The options are Disabled and **Enabled**.

IPv4 PXE Support (Available when "Network Stack" is set to Enabled)

Select Enabled to enable IPv4 PXE boot support. If this feature is disabled, it will not create the IPv4 PXE boot option. The options are Disabled and **Enabled**.

IPv4 HTTP Support (Available when "Network Stack" is set to Enabled)

Select Enabled to enable IPv4 HTTP boot support. If this feature is disabled, it will not create the IPv4 HTTP boot option. The options are **Disabled** and Enabled.

IPv6 PXE Support (Available when "Network Stack" is set to Enabled)

Select Enabled to enable IPv6 PXE boot support. If this feature is disabled, it will not create the IPv6 PXE boot option. The options are **Disabled** and Enabled.

IPv6 HTTP Support (Available when "Network Stack" is set to Enabled)

Select Enabled to enable IPv6 HTTP boot support. If this feature is disabled, it will not create the IPv6 HTTP boot option. The options are **Disabled** and Enabled.

PXE Boot Wait Time (Available when "Network Stack" is set to Enabled)

Use this feature to set the wait time (in seconds) upon which the system BIOS will wait for the user to press the <ESC> key to abort PXE boot instead of proceeding with PXE boot by connecting to a network server immediately. Press "+" or "-" on your keyboard to change the value. The default setting is **0**.

Media Detect Count

Use this feature to select the wait time (in seconds) for the BIOS ROM to detect the presence of a LAN media either via the Internet connection or via a LAN port. Press "+" or "-" on your keyboard to change the value. The default setting is **1**.

▶ MAC:(MAC address)-IPv6 Network Configuration

▶ Enter Configuration Menu

The following items are displayed:

- Interface Name
- Interface Type
- MAC address
- Host address
- Route Table
- Gateway addresses
- DNS addresses

Interface ID

Use this feature to change/enter the 64-bit alternative interface ID for the device. The string format is colon separated. The default setting is the MAC address above.

DAD Transmit Count

This feature displays the number of times that Duplicate Address Detection (DAD) has been performed. DAD is a procedure used to verify whether an IPv6 address is unique on the LAN before it is assigned for physical interface; only a unique IP address will be used for real-time interface. The default setting is **1**.

Policy

Use this feature to select how the policy is to be configured. The options are **automatic** and **manual**.

► **Advanced Configuration (Available when "Policy" is set to manual)**

New IPv6 address

Use this feature to enter the IPv6 address for the local machine.

New Gateway addresses

Use this feature to set the gateway address for the local machine.

New DNS address

Use this feature to set the DNS server address for the local machine.

Commit Changes and Exit

Press <Enter> to save changes and exit. The options are **Yes** and No.

Discard Changes and Exit

Press <Enter> to discard changes and exit. The options are **Yes** and No.

Save Changes and Exit

Press <Enter> to save changes and exit. The options are **Yes** and No.

► **MAC:(MAC address)-IPv4 Network Configuration**

Configured

Select Enabled to show whether the network address has been successfully configured. The options are **Disabled** and Enabled.

Enable DHCP (Available when "Configured" is set to Enabled)

Select Enabled to support Dynamic Host Configuration Protocol (DHCP) which allows the BIOS to search for a DHCP server attached to the network and request the next available IP address for this computer. The options are **Disabled** and Enabled.

Local IP Address (Available when "Configured" is set to Enabled and "Enabled DHCP" is set to Disabled)

Use this feature to enter an IP address for the local machine.

Local NetMask (Available when "Configured" is set to Enabled and "Enabled DHCP" is set to Disabled)

Use this feature to set the netmask for the local machine.

Local Gateway (Available when "Configured" is set to Enabled and "Enabled DHCP" is set to Disabled)

Use this feature to set the gateway address for the local machine.

Local DNS Servers (Available when "Configured" is set to Enabled and "Enabled DHCP" is set to Disabled)

Use this feature to set the Domain Name System (DNS) server address for the local machine.

Save Changes and Exit

Press <Enter> to save changes and exit. The options are **Yes** and No.

► PCIe/PCI/PnP Configuration

The following information is displayed:

- PCI Bus Driver Version

PCI Devices Common Settings:

Above 4G Decoding (Available when the system supports 64-bit PCI decoding)

Select Enabled to decode a PCI device that supports 64-bit in the space above 4G Address. The options are Disabled and **Enabled**.

MMCFG Base

This feature determines how the lowest Memory Mapped Configuration (MMCFG) base is assigned to onboard PCI devices. The options are 1G, 1.5G, 1.75G, 2G, 2.25G, 3G, and **Auto**.

MMCFG Size

Use this feature to set the MMCFG size. The options are 256M, 512M, 1G, 2G, and **Auto**. Please note that the MMCFG size is based on the memory populated.

MMIO High Base

Use this feature to select the high base memory size according to memory-address mapping for the IO hub. The options are 56T, 40T, **32T**, 24T, 16T, 4T, 2T, 1T, and 512G.

MMIO High Granularity Size

Use this feature to select the high memory size according to memory-address mapping for the IO hub. The options are 1G, 4G, 16G, **64G**, 256G, and 1024G.

SR-IOV Support

Select Enabled for Single-Root IO Virtualization support. The options are Disabled and **Enabled**.

Bus Master Enable

If this feature is set to Enabled, the PCI Bus Driver will enable the Bus Master Attribute for DMA transactions. If it is set to Disabled, the PCI Bus Driver will disable the Bus Master Attribute for Pre-Boot DMA protection. The options are Disabled and **Enabled**.

ARI Support

Select Enabled for Alternative Routing-ID Interpretation (ARI) support. The options are Disabled and **Enabled**.


NVMe Firmware Source

Use this feature to select the type of NVMe firmware to support system boot. The options are **Vendor Defined Firmware** and AMI Native Support. The default option, **Vendor Defined Firmware**, is pre-installed on the drive and may resolve errata or enable innovative functions for the drive. The other option, AMI Native Support, is offered by the AMI BIOS with a generic method.

VGA Priority

Use this feature to select the graphics device to be used as the primary video display for system boot. The options are **Onboard** and Offboard.

For the following features, please note that:

 **Note 1:** The number of slots and slot naming of the slots vary based on your motherboard features.


Note 2: The option of Legacy is available when "Boot Mode Select" is set to Dual or Legacy.

Note 3: Refer to Boot submenu in the BIOS Setup main menu to set "Boot Mode Select".

Onboard Video Option ROM

Select EFI to allow you to boot the computer using the Extensible Firmware Interface (EFI) device installed on the onboard video port. The options are Disabled and **EFI**.

PCI Devices Option ROM Setting

 **Note:** The number of slots and the naming of the slots will vary based on your motherboard configuration settings. The following information listed below is for reference only. The naming of the slots displayed on your BIOS screen will differ depending on the devices installed in your system.

RSC-S2R-668G5 SLOT1 PCIe 5.0 X8 OPROM / RSC-S2R-668G5 SLOT2 PCIe 5.0 X16 OPROM / RSC-S2R-668G5 SLOT3 PCIe 5.0 X16 OPROM / RSC-D2-666G5 SLOT1 PCIe 5.0 X16 OPROM / RSC-D2-666G5 SLOT2 PCIe 5.0 X16 OPROM / RSC-D2-666G5 SLOT3 PCIe 5.0 X16 OPROM / P1_AIOM PCIe 5.0 x8 OPROM / P2_AIOM PCIe 5.0 x16 OPROM (Available when a device installed on a slot specified by the user is detected by the BIOS)

Select EFI to allow you to boot the computer using the EFI device installed on the PCIe slot specified. The options are Disabled and **EFI**.

►ACPI Settings

NUMA

Use this feature to enable Non-Uniform Memory Access (NUMA) to enhance system performance. The options are Disabled and **Enabled**.

UMA-Based Clustering

If this feature is set to Hemisphere, Uniform Memory Access (UMA)-based clustering will support 2-cluster configuration for system performance enhancement. The options are Disabled (All2All), Hemisphere (2-clusters), and **Quadrant (4-clusters)**.

WHEA Support

Select Enabled to support the Windows Hardware Error Architecture (WHEA) platform and provide a common infrastructure for the system to handle hardware errors within the Windows OS environment to reduce system crashes and to enhance system recovery and health monitoring. The options are Disabled and **Enabled**.

High Precision Event Timer

Select Enabled to activate the High Precision Event Timer (HPET) that produces periodic interrupts at a much higher frequency than a Real-time Clock (RTC) does in synchronizing multimedia streams, providing smooth playback and reducing the dependency on other timestamp calculation devices, such as an x86 RDTSC Instruction embedded in the CPU. The HPET is used to replace the 8254 Programmable Interval Timer. The options are Disabled and **Enabled**.

► Trusted Computing (Available when a TPM device is installed and detected by the BIOS)



When a Trusted-Platform Module (TPM) device is detected by your system, the following information is displayed:

- TPM 2.0 Device Found
- Firmware Version:
- Vendor:

Security Device Support

Select Enable to enable BIOS support for onboard security devices, which are not displayed in the OS. If this feature is set to Enable, TCG EFI protocol and INT1A interface will not be available. The options are Disable and **Enable**.

*When "Security Device Support" is set to Enable, the following information is displayed:

- Active PCR banks
- Available PCR banks

SHA256 PCR Bank (Available when "Security Device Support" is set to Enable)

Select Enabled to enable SHA256 PCR Bank support to enhance system integrity and data security. The options are **Enabled** and Disabled.

Pending Operation (Available when "Security Device Support" is set to Enable)

Use this feature to schedule a TPM-related operation to be performed by a security (TPM) device at the next system boot to enhance system data integrity. The options are **None** and TPM Clear.



Note: Your system will reboot to carry out a pending TPM operation.

Platform Hierarchy (Available when "Security Device Support" is set to Enable) (for TPM version 2.0 and above)

Select Enabled for TPM Platform Hierarchy support which allows the manufacturer to utilize the cryptographic algorithm to define a constant key or a fixed set of keys to be used for initial system boot. These early boot codes are shipped with the platform and are included in the list of "public keys". During system boot, the platform firmware uses the trusted public keys to verify a digital signature in an attempt to manage and control the security of the platform firmware used in a host system via a TPM device. The options are Disabled and **Enabled**.

Storage Hierarchy (Available when "Security Device Support" is set to Enable)

Select Enabled for TPM Storage Hierarchy support that is intended to be used for non-privacy-sensitive operations by a platform owner such as an IT professional or the end user. Storage Hierarchy has an owner policy and an authorization value, both of which can be set and are held constant (-rarely changed) through reboots. This hierarchy can be cleared or changed independently of the other hierarchies. The options are Disabled and **Enabled**.

Endorsement Hierarchy (Available when "Security Device Support" is set to Enable)

Select Enabled for Endorsement Hierarchy support, which contains separate controls to address the user's privacy concerns because the primary keys in the hierarchy are certified by the TPM key or by a manufacturer with restrictions on how an authentic TPM device that is attached to an authentic platform can be accessed and used. A primary key can be encrypted and certified with a certificate created by using TPM2_ ActivateCredential, which allows the user to independently enable "flag, policy, and authorization values" without involving other hierarchies. A user with privacy concerns can disable the endorsement hierarchy while still using the storage hierarchy for TPM applications, permitting the platform software to use the TPM. The options are Disabled and **Enabled**.

PH Randomization (for TPM version 2.0 and above)

Select Enabled for Platform Hierarchy (PH) Randomization support, which is used only during the platform developmental stage. This feature cannot be enabled in the production platforms. The options are **Disabled** and Enabled.

Device Select (Available when your motherboard supports NVMe)

Select TPM 1.2 to support TPM 1.2 - compliant devices. Select TPM 2.0 for TPM 2.0 - compliant device support. Select Auto to support both TPM 1.2 and TPM 2.0 devices. The options are **Auto**, TPM 1.2 and TPM 2.0.

Disable Block Sid (Available when your motherboard supports NVMe)

Select Enabled to allow SID authentication be performed in TCG Storage devices. The options are **Disabled** and Enabled.

Supermicro BIOS-Based TPM Provision Support

If this feature is set to Enabled, Supermicro BIOS-based TPM provision will be supported. The options are Disabled and **Enabled**.



Note: Enabling this feature will lock your TPM on the production platform, and you will not be able to delete the NV indexes.

Provision Support

TXT Support

Select Enabled to enable Intel Trusted Execution Technology (TXT) support to enhance system integrity and data security. The options are **Disabled** and Enabled.



Note 1: If this feature is set to Enabled, be sure to disable Device Function On-Hide (EV DFX) support when it is present in the BIOS for the system to work properly.

Note 2: For more information on TPM, please refer to the TPM manual at <http://www.supermicro.com/manuals/other/TPM.pdf>.

► Supermicro KMS Server Configuration

Supermicro KMS Server IP address

Use this feature to enter the Supermicro Key Management Service (KMS) server IPv4 address in dotted-decimal notation.

Second Supermicro KMS Server IP address

Use this feature to enter the second Supermicro KMS server IPv4 address in dotted-decimal notation.

Supermicro KMS TCP Port number

Use this feature to enter the Supermicro KMS TCP port number. The valid range is 100 - 9999. The default setting is **5696**.

KMS Time Out

Use this feature to enter the KMS server connecting timeout (in seconds). The default setting is **5** (seconds).

Supermicro KMS Server Retry Count

Use this feature to specify how many times of attempts should this system make trying to connect to the KMS server. The valid range is 0 - 10. Press "+" or "-" on your keyboard to change the value. The default setting is **2** (retrying twice).

TimeZone

Use this feature to enter the correct time zone. The default setting is **0** (not specified).

TCG Nvme KMS Policy

Use this feature to select the TCG NVMe KMS policy. The options are Normal Unlock, **Do Nothing**, Reset All Devices, and Delete Key Id (ID) List.

Client UserName

Press <Enter> to set the client identity (UserName). The maximum length is 63 characters.

Client Password

Press <Enter> to set the client identity (Password). The maximum length is 31 characters.

KMS TLS Certificate / Size

This feature displays the Transport Layer Security (TLS) certificate and the size for CA Certificate, Client Certificate, and Client Private Key

▶ CA Certificate

For the CA certificate, use this feature to enroll factory defaults or load the KMS TLS certificates from the file. The options are **Update**, Delete, and Export.

▶ Client Certificate

For the client certificate, use this feature to enroll factory defaults or load the KMS TLS certificates from the file. The options are **Update**, Delete, and Export.

▶ Client Private Key

For the client private key, use this feature to enroll factory defaults or load the KMS TLS certificates from the file. The options are **Update**, Delete, and Export.

Private Key Password (Available when "Private Key Password" has been set)

Use this feature to change the private key password.

► Super-Guardians Configuration

Super-Guardians Protection Policy

Select Storage to apply the Super-Guardian Protection policy to the data stored in the storage devices to enhance data security and integrity. The options are **Storage**, System, and System and Storage.

KMS Security Policy

When is feature is set to Enabled, the system and storage devices installed in the system will be password-protected. Without entering a correct password, the system or a storage device will not be unlocked. The options are **Disabled**, and Enabled.

KMS Server Retry Count

This feature allows user to determine how many times that a client machine can try to connect to the host (key) server. Enter a number between 0 to 10. If the value is set to 0, the client machine can try to connect to the host (main) server infinitely. The default value is **5**.

TPM Security Policy

When is feature is set to Enabled, the system and storage devices installed in the system will be password-protected. Without entering a correct password, the system or a storage device will not be unlocked. The options are **Disabled**, and Enabled.

Load Authentication-Key

Select Enabled for the BIOS to load the authentication key that is pre-installed under the file name: *TPMAuth.bin* by the manufacturer from the USB storage device to the system upon next boot. The options are **Disabled** and Enabled

USB Security Policy

When is feature is set to Enabled, the system and storage devices installed in the system will be password-protected. Without entering a correct password, the system or a storage device will not be unlocked. The options are **Disabled**, and Enabled.

▶ HTTP Boot Configuration

HTTP Boot Policy

Use this feature to set the HTTP boot policy. The options are Apply to all LANs, **Apply to each LAN**, and Boot Priority #1 instantly.

HTTPS Boot Checks Hostname

Enable this feature for HTTPS boot to check the hostname of the TLS certificates to see if it matches the host name provided by the remote server. The options are **Enabled** and Disabled (WARNING: Security Risk!!).

Priority of HTTP Boot

Instance of Priority 1 / Instance of Priority 2 / Instance of Priority 3 / Instance of Priority 4 (Available when your motherboard supports this feature and Devices needed are detected by the BIOS)

This feature sets the rank target port. The default setting is **1**.

Select IPv4 or IPv6

This feature specifies which connection the target LAN port should boot from. The options are **IPv4** and IPv6.

Boot Description

Use this feature to enter a boot description, which cannot be longer than 75 characters. Please be sure to enter a boot description; otherwise, the boot option for the URI cannot be created.

Boot URI

Enter a Boot Uniform Resource Identifier (URI) with 128 characters or shorter. This Boot URI determines how IPv4 Boot Option and IPv6 Boot Option will be created. This feature is only supported on Dual or EFI Boot Mode.

▶ Intel(R) Ethernet Controller (Ethernet controller) -(MAC address)



Note 1: This feature is available when "Onboard LAN Option ROM Type" is set to EFI.

Note 2: The Ethernet controller and MAC addresses shown above are based on your system features.

▶ Firmware Image Properties

The following information is displayed:

- Option ROM Version
- Unique NVM/EEPROM ID
- NVM Version

▶ NIC Configuration

Link Speed

Use this feature to set the connection speed of a LAN port specified. The options are **Auto Negotiated**, 10 Mbps Half, 10 Mbps Full, 100 Mbps Half, and 100 Mbps Full.

Wake On LAN

If this feature is set to Enabled, the LAN port specified will be enabled when the system is powered on. The options are Disabled and **Enabled**.

Blink LEDs

Use this feature to identify the physical network port by blinking the associated LED indicators. The default setting is **0** (up to 15 seconds).

The following information is displayed:

- UEFI Driver
- Adapter PBA
- Device Name
- Chip Type
- PCI Device ID
- PCI Address
- Link Status
- MAC Address

- Virtual MAC Address

▶ TLS Authenticate Configuration

This submenu allows you to configure Transport Layer Security (TLS) settings.

▶ Server CA Configuration

This feature allows you to configure the client certificate that is to be used by the server.

▶ Enroll Certification

This feature allows you to enroll the certificate in the system.

▶ Enroll Certification Using File

This feature allows you to enroll the security certificate in the system by using a file.

Certification GUID

Press <Enter> and input the certification Global Unique Identifier (GUID).

▶ Commit Changes and Exit

Use this feature to save all changes and exit TLS settings.

▶ Discard Changes and Exit

Use this feature to discard all changes and exit TLS settings.

▶ Delete Certification

This feature is used to delete the certificate if a certificate has been enrolled in the system. The options are **Disabled** and **Enabled**.

▶ Client Certification Configuration

This feature allows you to configure the client certificate to be used by the server.

▶ Enroll Certification

This feature allows you to enroll the certificate in the system.

▶ Enroll Certification Using File

This feature allows you to enroll the security certificate in the system by using a file.

Certification GUID

Press <Enter> and input the certification GUID.

▶ Commit Changes and Exit

Use this feature to save all changes and exit TLS settings.

▶ Discard Changes and Exit

Use this feature to discard all changes and exit TLS settings.

▶ Delete Certification

This feature is used to delete the certificate if a certificate has been enrolled in the system.

▶ VLAN Configuration (Available when a LAN device is installed on a the slot specified by the user and detected by the BIOS)**▶ Enter Configuration Menu**

The submenu allows the user to configure the following settings for the LAN devices detected by the BIOS.

Create New VLAN

This feature allows the user to create a new VLAN and configure its settings.

VLAN ID

This feature allows the user to enter a new VLAN ID from 0 ~ 4094.

Priority

This feature allows the user to specify the priority sequences of the VLANs that have been created. Enter a number from 0 ~ 7 with 0 being the one signifying the highest in priority.

Add VLAN

Use this feature to add a new VLAN to the system.

Configured VLAN List

Use this feature to enable or disable the VLAN specified by the user.

VLAN ID: Enter the ID of the VLAN that you want to configure the setting to.

Priority: Enter the priority sequence of the VLAN that you want to configure the setting to.

Select Enabled to enable the VLAN you've specified above. Select Disabled to disable the VLAN you've specified. The options are **Disabled** and Enabled.

Remove VLAN

This feature allows the user to remove a VLAN from the system.

► Generic NVMe PCIe Storage Device Configuration Data (Available when an SSC device is installed on a the slot specified by the user and detected by the BIOS)

► View Physical Device Properties

The submenu displays the properties of a physical device installed on a slot specified by the user.

► Generic SAS Configuration Utility (Available when an SAS Configuration Utility specified by the user is detected by the BIOS)

► View Physical Device Properties

This feature allows the user to view the properties and configure the settings for a 3rd party utility installed in the system using the generic tools provided by the vendor.

► Driver Health

This feature displays the health information of the drivers installed in your system, including LAN controllers, as detected by the BIOS. Select one and press <Enter> to see the details.



Note: This section is provided for reference only, for the driver health status will differ depending on the drivers installed in your system. It's also based on your system configuration and the environment that your system is operating in.

► Intel(R) VROC SATA Controller



Note 1: This section is based on your system features and related device(s) installed.

Note 2: This section is available when "SATA Mode Selection" is set to RAID.

Note 3: Refer to PCH SATA0 Configuration, PCH SATA1 Configuration, and PCH SATA2 Configuration submenus in the BIOS Setup main menu to set "SATA Mode Selection".

The following information is displayed.

- Intel VROC SATA driver version

► Create RAID Volume

Name:

This feature allows you to enter the unique name of RAID volume.

RAID Level:

This feature allows you to select the RAID level. The options are **RAID0(Stripe)**, RAID1(Mirror), RAID5(Parity), and RAID10(RAID0+1).

Select Disks:

Select the desired RAID disks one by one by setting them to **X**. The options are (not selected) and **X (selected)**.

Strip Size:

Use this feature to select the RAID strip size. The options are 4KB, 8KB, 16KB, 32KB, 64KB, and **128KB**. The available options are based on the setting of "RAID Level:" above.

Capacity (GB):

This feature allows you to enter the desired RAID capacity (in GB).

► Create RAID Volume

Use this feature to create a RAID volume with the settings above. The options are **Yes** and **No**.

Non-RAID Physical Disks:

This feature displays the information of non-RAID physical disk(s).

RAID Volumes:

This feature displays the information of RAID volumes that have been created earlier.

► Intel(R) VROC sSATA Controller



Note 1: This section is based on your system features and related device(s) installed.

Note 2: This section is available when "SATA Mode Selection" is set to RAID.

Note 3: Refer to PCH SATA0 Configuration, PCH SATA1 Configuration, and PCH SATA2 Configuration submenus in the BIOS Setup main menu to set "SATA Mode Selection".

The following information is displayed.

- Intel VROC sSATA driver version

► Create RAID Volume

Name:

This feature allows you to enter the unique name of RAID volume.

RAID Level:

This feature allows you to select the RAID level. The options are **RAID0(Stripe)**, RAID1(Mirror), RAID5(Parity), and RAID10(RAID0+1).

Select Disks:

Select the desired RAID disks one by one by setting them to **X**. The options are (not selected) and **X (selected)**.

Strip Size:

Use this feature to select the RAID strip size. The options are 4KB, 8KB, 16KB, 32KB, 64KB, and **128KB**. The available options are based on the setting of "RAID Level:" above.

Capacity (GB):

This feature allows you to enter the desired RAID capacity (in GB).

► Create RAID Volume

Use this feature to create a RAID volume with the settings above. The options are **Yes** and **No**.

Non-RAID Physical Disks:

This feature displays the information of non-RAID physical disk(s).

RAID Volumes:

This feature displays the information of RAID volumes that have been created earlier.

► Intel(R) VROC tSATA Controller



Note 1: This section is based on your system features and related device(s) installed.

Note 2: This section is available when "SATA Mode Selection" is set to RAID.

Note 3: Refer to PCH SATA0 Configuration, PCH SATA1 Configuration, and PCH SATA2 Configuration submenus in the BIOS Setup main menu to set "SATA Mode Selection".

The following information is displayed.

- Intel VROC tSATA driver version

▶ Create RAID Volume

Name:

This feature allows you to enter the unique name of RAID volume.

RAID Level:

This feature allows you to select the RAID level. The options are **RAID0(Stripe)**, RAID1(Mirror), RAID5(Parity), and RAID10(RAID0+1).

Select Disks:

Select the desired RAID disks one by one by setting them to **X**. The options are (not selected) and **X (selected)**.

Strip Size:

Use this feature to select the RAID strip size. The options are 4KB, 8KB, 16KB, 32KB, 64KB, and **128KB**. The available options are based on the setting of "RAID Level:" above.

Capacity (GB):

This feature allows you to enter the desired RAID capacity (in GB).

▶ Create RAID Volume

Use this feature to create a RAID volume with the settings above. The options are **Yes** and No.

Non-RAID Physical Disks:

This feature displays the information of non-RAID physical disk(s).

RAID Volumes:

This feature displays the information of RAID volumes that have been created earlier.

▶ Intel(R) Virtual RAID on CPU



Note: It is available when your system supports this feature and when "Enable/Disable VMD" is set to Enable.

The following information is displayed:

- Intel(R) VROC with VMD Technology x.x.x.xxxx
- Upgrade key:
- Intel VROC Managed Controllers:

► Driver Health


This feature displays the health information of the drivers installed in your system, including LAN controllers, as detected by the BIOS. Select one and press <Enter> to see the details.



Note: This section is provided for reference only, for the driver health status will differ depending on the drivers installed in your system. It's also based on your system configuration and the environment that your system is operating in.

4.4 Event Logs

Use this feature to configure Event Logs settings.

 **Note:** After you've made any changes in this section, please be sure to reboot the system for the changes to take effect.



► Change SMBIOS Event Log Settings

Enabling/Disabling Options

SMBIOS Event Log

Select Enabled to enable System Management BIOS (SMBIOS) Event Logging during system boot. The options are Disabled and **Enabled**.

Erasing Settings

Erase Event Log (Available when "SMBIOS Event Log" is set to Enabled)

Select No to keep the event log without erasing it upon next system bootup. Select Yes, Next reset to erase the event log upon next system reboot. The options are **No**, [Yes, Next reset], and [Yes, Every reset].

When Log is Full (Available when "SMBIOS Event Log" is set to Enabled)

Select Erase Immediately to immediately erase all errors in the SMBIOS event log when the event log is full. Select Do Nothing for the system to do nothing when the SMBIOS event log is full. The options are **Do Nothing** and Erase Immediately.

SMBIOS Event Log Standard Settings

Log System Boot Event (Available when "SMBIOS Event Log" is set to Enabled)

Select Enabled to log system boot events. The options are Enabled and **Disabled**.

MECI (Multiple Event Count Increment) (Available when "SMBIOS Event Log" is set to Enabled)

Enter the increment value for the multiple event counter. Enter a number between 1 to 255. The default setting is **1**.

METW (Multiple Event Count Time Window) (Available when "SMBIOS Event Log" is set to Enabled)

This feature is used to determine how long (in minutes) should the multiple event counter wait before generating a new event log. Enter a number between 0 to 99. The default setting is **60**.

►View SMBIOS Event Log

This feature allows you to view the event in the system event log. Select this feature and press <Enter> to view the status of an event in the log. The following categories is displayed: DATE / TIME / ERROR CODE / SEVERITY.

4.5 BMC

Use this feature to configure BMC settings.



BMC Firmware Revision

This feature indicates the BMC firmware revision used in your system.

BMC STATUS

This feature indicates the status of the BMC firmware installed in your system.

▶ System Event Log

Enabling/Disabling Options

SEL Components

Select Enabled to enable all system event logging upon system boot. The options are Disabled and **Enabled**.

Erasing Settings

Erase SEL

Select [Yes, On next reset] to erase all system event logs upon next system boot. Select [Yes, On every reset] to erase all system event logs upon each system reboot. Select No to keep all system event logs after each system reboot. The options are **No**, [Yes, On next reset], and [Yes, On every reset].

When SEL is Full

This feature allows you to determine what the BIOS should do when the system event log is full. Select Erase Immediately to erase all events in the log when the system event log is full. The options are **Do Nothing** and Erase Immediately.



Note: After making changes on a setting, be sure to reboot the system for the changes to take effect.

► BMC Network Configuration

Update BMC LAN Configuration

Select Yes for the BIOS to implement all IP/MAC address changes upon next system boot. The options are **No** and Yes.

Configure IPv4 Support

BMC LAN Selection

Use this feature to select the type of the BMC LAN. The default setting is **Failover**.

BMC Network Link Status:

This feature displays the status of the BMC network link for this system. The default setting is **Dedicated LAN**.

Configuration Address Source (Available when "Update BMC LAN Configuration" is set to Yes)

Use this feature to select the source of the IPv4 connection. If Static is selected, you will need to know the IP address of IPv4 connection and enter it to the system manually in the field. If DHCP is selected, the BIOS will search for a Dynamic Host Configuration Protocol (DHCP) server in the network that is attached to and request the next available IP address for this computer. The options are Static and **DHCP**.

Station IP Address (Available when "Configuration Address Source" is set to Static)

This feature displays the Station IP address in decimal and in dotted quad form (i.e., 172.29.176.131).

Subnet Mask (Available when "Configuration Address Source" is set to Static)

This feature displays the sub-network that this computer belongs to. The value of each three-digit number separated by dots should not exceed 255.

Station MAC Address (Available when "Configuration Address Source" is set to Static)

This feature displays the Station MAC address for this computer. Mac addresses are six two-digit hexadecimal numbers.

Gateway IP Address (Available when "Configuration Address Source" is set to Static)

This feature displays the Gateway IP address for this computer. This should be in decimal and in dotted quad form (i.e., 172.29.0.1).

VLAN (Available when "Update BMC LAN Configuration" is set to Yes)

This feature displays the status of VLAN support. The options are **Disable** and **Enable**.

VLAN ID (Available when "VLAN" is set to Enable)

Use this feature to create a new LAN ID by using an existing VLAN or creating a new VLAN ID. Enter a valid value between 0 - 4094.

Configure IPv6 Support

IPv6 Address Status

This feature displays the status of the IPv6 address.

IPv6 Support

Use this feature to enable IPv6 support. The options are **Enabled** and **Disabled**.

Configuration Address Source (Available when "IPv6 Support" is set to Enabled)

Use this feature to select the source of the IPv6 connection. If Static Configuration is selected, you will need to know the IP address of IPv6 connection and enter it to the system manually in the field. If the other two options are selected, the BIOS will search for a DHCP server in the network that is attached to and request the next available IP address for this computer. The options are Static Configuration, **DHCPv6 Stateless**, and **DHCPv6 Stateful**.

IPv6 Address (DHCPv6 Stateless) (Available when "Configuration Address Source" is set to Static Configuration)

This feature displays the station IPv6 address. Press <Enter> to change the setting.

Prefix Length (Available when "Configuration Address Source" is set to Static Configuration)

This feature displays the prefix length. Press <Enter> to change the setting.

Gateway IP (Available when "Configuration Address Source" is set to Static Configuration)

Use this feature to enter the IPv6 gateway IP address. Press <Enter> to change the setting.

Advanced Settings (Available when "Configuration Address Source" is set to Static Configuration)

Use this feature to set the DNS server IP. The options are **Auto obtain DNS server IP** and **Manually obtain DNS server IP**.

Preferred DNS server IP (Available when "Advanced Settings" above is set to Manually obtain DNS server IP)


This feature allows you to set the preferred DNS server IP.

Alternative DNS server IP (Available when "Advanced Settings" above is set to Manually obtain DNS server IP)

This feature allows you to set the alternative DNS server IP.

4.6 Security

This feature allows you to configure the following security settings for the system.



The following information is displayed:

- Administrator Password
- User Password
- Password Description

Administrator Password


This feature indicates if an administrator password has been installed. It also allows you to set the administrator password which is required to enter the BIOS Setup utility. The length of the password should be from three characters to 20 characters long.

User Password (Available when "Administrator Password" has been set)

This feature indicates if a user password has been installed. It also allows you to set the user password which is required to enter the BIOS Setup utility. The length of the password should be from three characters to 20 characters long.

Password Check


Select Setup for the system to check for a password at Setup. Select Always for the system to check for a password at bootup and upon entering the BIOS Setup utility. The options are **Setup** and Always.

 **Note:** For detailed instructions on how to configure Security Boot settings, please refer to the Security Boot Configuration User's Guide posted on the web page under the link: <http://www.supermicro.com/support/manuals/>.

Hard Drive Security Frozen


Select Enabled to freeze the Lock Security feature for HDDs to protect key data in hard drives from being altered. The options are **Disabled** and Enabled.

► Supermicro Security Erase Configuration (Available when a storage device is detected by the BIOS)

 **Note** : To configure Supermicro Security Erase settings, please follow the instructions below to enable Security Erase feature support in the BIOS.

How to Activate Security Erase Configuration submenu for Secure Erase Support for NVMe SSDs Only

1. From the Advanced menu, select PCIe/PCI/PnP and press <Enter> to invoke the PCI Devices Common Settings page.
2. When the PCI Devices Common Settings screen displays, select NVMe Firmware Sources and press <Enter>. The NVMe Firmware Sources pop-up dialogue box will display.
3. From the popup window, select AMI Native Support and press <Enter>. Be sure to save the changes you've made and reboot the system for the new settings to take effect by pressing <F4>.
4. Press at bootup to return to the AMI BIOS Setup Utility.
5. When AMI BIOS screen displays, using arrow keys, select Security from the BIOS menu bar on the top of the screen. The Supermicro Security Erase Configuration submenu will display on the Security menu as shown below.



6. Select Supermicro Security Erase Configuration and press <Enter> to enter the Security Erase configuration page, which will allow you to configure Security Erase settings.

Configuring the settings included in the Supermicro Security Erase Submenu

This section provides instructions on how to configure the Supermicro-proprietary Security Erase settings included in the BIOS setup utility. When this submenu is selected, the following information will display on the screen. Please note that the device information displayed on your screen may vary, depending on the storage devices installed in your system.

- **HDD Name:** This feature displays the vendor and model name of the HDD/SSD device detected by the BIOS.
- **HDD Serial Number:** This feature displays the serial number of the HDD/SSD device detected by the BIOS.
- **Security Mode:** This feature displays the security mode of the HDD/SSD device detected by the BIOS.
- **Estimated Time:** This feature displays the estimate time needed to configure the selected Security Erase features.
- **HDD User Pwd Status:** This feature indicates if a password has been set as a SATA user password which will allow the user to configure Supermicro Security Erase settings on the selected HDD (SATA) device by using this SATA user password.
- **TCG Device Type:** This feature displays the TCG device type detected in the system.
- **Admin Pwd Status:** This feature indicates if a password has been set as a SATA administrator password which will allow the user to configure Supermicro Security Erase settings on the selected HDD (SATA) device by using this SATA administrator password.

Security Function

Select *Set Password* to set an HDD/SSD password which allows the user to configure the security settings of the HDD/SSD device as follows:

- Select *Security Erase - Password* to enter a user password which will allow the user to erase the password and all data stored in the HDD/SSD device.
- Select *Security Erase - PSID (Physical Security ID)* to enter an SED SSD PSID which will allow the user to erase all data stored in this device.
- Select *Security Erase - Without Password* to use the manufacturer default password "11111111" as the user password which will allow you to erase all data stored in the HDD/SSD device by using this default password.

The options are **Disable**, Set Password, Security Erase - Password, Security Erase - PSID, and Security Erase - Without Password.



Note: The option of Security Erase - PSID is based on the storage device support. The section below provides instructions on how to configure the Security Function options.

Password

Use this feature to set the HDD/SATA user password which allows you to configure the Supermicro Security Erase settings by using the HDD/SATA user password.

Lockdown Mode (Available when the DCMS key is activated)

Select Enabled to support Lockdown Mode that will prevent the existing data or keys stored in the system from being altered or changed in an effort to preserve system integrity and security. The options are **Disabled** and Enabled.

HDD Security Configuration:

▶ HDD Devices: (Storage Device Names as Detected by the BIOS)

This section is available when the storage device is detected by the BIOS. Select this device. Press <Enter> and the following information is displayed:

- HDD Password Description:
- HDD PASSWORD CONFIGURATION:
 - Security Supported:
 - Security Enabled:
 - Security Locked:
 - Security Frozen:
 - HDD User Pwd Status:
 - HDD Master Pwd Status:

Set User Password (Available when "Security Frozen:" above is No)

Select Enabled to support Lockdown Mode that will prevent existing data or keys stored in the system from being altered or changed in an effort to preserve system integrity and security. The options are **Disabled** and Enabled.

▶ Secure Boot



Note: For detailed instructions on how to configure Security Boot settings, please refer to the Security Boot Configuration User's Guide posted on the web page under the link: <http://www.supermicro.com/support/manuals/>.

The following information is displayed:

- System Mode
- Vendor Keys (Available when installed in the system and detected by the BIOS)
- Secure Boot

Secure Boot

Select Enabled to configure Secure Boot settings. The options are **Disabled** and Enabled.

Secure Boot Mode

Use this feature to select the desired secure boot mode for the system. The options are Standard and **Custom**.

CSM (Compatibility Support Module) Support

Select Enabled for CSM support, which will allow for system boot from a legacy device. Please make sure that your device is compatible with legacy boot before disabling CSM support. The options are Disabled and **Enabled**.

▶ Key Management (Available when "Secure Boot Mode" is set to Custom)

The following information is displayed.

- Vendor Keys

Provision Factory Defaults

Select Enabled to install provision factory default settings after a platform reset while the system is in the Setup Mode. The options are **Disabled** and Enabled.

▶ Restore Factory Keys (Available when any secure keys have been installed)

Select Yes to restore manufacturer default keys to ensure system security. The options are **Yes** and No. Selecting Yes will reset system to the Deployed mode.

▶ Reset To Setup Mode (Available when any secure keys have been installed)

This feature resets the system to the Setup Mode. The options are **Yes** and No.

▶ Enroll Efi Image

This feature allows the Efi image to run in the secure boot mode, which will enroll the SHA256 Hash certificate of a PE image into the Authorized Signature Database (DB).

▶ Export Secure Boot Variables (Available when any secure keys have been installed)

This feature exports the NVRAM contents of secure boot variables to a storage device. The options are **Yes** and No.

▶ Export Secure Boot Variables

The following information is displayed:

Secure Boot variable / Size / Key# / Key Source

▶ Platform Key(PK)

Use this feature to enter and configure a set of values to be used as platform firmware keys for the system. These values also indicate the sizes, keys numbers, and the sources of the authorized signatures. Select Update to update the platform key. The options are **Details**, Export, Update, and Delete.

▶ Key Exchange Keys

Use this feature to enter and configure a set of values to be used as Key-Exchange-Keys for the system. These values also indicate the sizes, keys numbers, and the sources of the authorized signatures. Select Update to update your "Key Exchange Keys". Select Append to append your "Key Exchange Keys". The options are **Details**, Export, Update, Append, and Delete.

▶ Authorized Signatures

Use this feature to enter and configure a set of values to be used as Authorized Signatures for the system. These values also indicate the sizes, keys numbers, and the sources of the authorized signatures. Select Update to update your "Authorized Signatures". Select Append to append your "Authorized Signatures". The options are **Details**, Export, Update, Append, and Delete.

▶ Forbidden Signatures

Use this feature to enter and configure a set of values to be used as Forbidden Signatures for the system. These values also indicate sizes, key numbers, and key sources of the forbidden signatures. Select Update to update your "Forbidden Signatures". Select Append to append your "Forbidden Signatures". The options are **Details**, Export, Update, Append, and Delete.

▶ Authorized TimeStamps

This feature allows you to set and save the timestamps for the authorized signatures which will indicate the time when these signatures are entered into the system. These values also indicate sizes, keys, and key sources of the authorized timestamps. Select Update to update your "Authorized TimeStamps". Select Append to append your "Authorized TimeStamps". The options are **Details**, Export, Update, Append, and Delete.

▶ OsRecovery Signature

This feature allows you to set and save the authorized signatures used for OS recovery. Select Update to update your "OS Recovery Signatures". These values also indicate sizes, keys, and key sources of the OsRecovery signatures. Select Append to append your "OS Recovery Signatures". The options are **Details**, Export, Update, Append, and Delete.

TCG Storage Security Configuration:

▶ (Storage Device Name) (Available when the storage device is compliant with TCG specifications)

Select this device. Press <Enter> and the following information is displayed:

- TCG Storage Security Password Description:
- PASSWORD CONFIGURATION:
 - Security Subsystem Class:
 - Security Supported:
 - Security Enabled:
 - Security Locked:
 - Security Frozen:
 - Admin Pwd Status:

Set Admin Password


Use this feature to set the administrator password for this storage device.

Device Reset

Use this feature to reset the password configuration for this storage device.

4.7 Boot

Use this feature to configure Boot settings:



Boot Mode Select

Use this feature to select the type of devices from which the system will boot. The options are Legacy, **UEFI**, and Dual.



Note: When "Boot Mode Select" is set to Dual, all OPROM-related features will be set to Legacy.

FIXED BOOT Option Priorities

This feature prioritizes the order of a bootable device from which the system will boot. Press <Enter> on each item sequentially to select devices.

When "Boot Mode Select" is set to Dual, the following features will be displayed for configuration:

- Boot Option #1 ~ Boot Option #17

When "Boot Mode Select" is set to Legacy, the following features will be displayed for configuration:

- Boot Option #1 ~ Boot Option #8

When "Boot Mode Select" is set to UEFI, the following features will be displayed for configuration:

- Boot Option #9 ~ Boot Option #17

▶ Delete Boot Option

This feature allows you to select a boot device to delete from the boot priority list.

Delete Boot Option

This feature allows you to remove an EFI boot option from the boot priority list.

▶ UEFI NETWORK Drive BBS Priorities

Use this feature to set the boot order of UEFI Network devices detected by the BIOS.

▶ UEFI Application Boot Priorities

Use this feature to set the boot order of UEFI Application devices detected by the BIOS.

▶ UEFI USB Key Drive BBS Priorities

Use this feature to set the boot order of UEFI USB devices detected by the BIOS.

▶ UEFI Hard Disk Drive BBS Priorities

Use this feature to set the boot order of UEFI HDD devices detected by the BIOS.

▶ Hard Disk Drive BBS Priorities

Use this feature to set the boot order of HDD devices detected by the BIOS.

▶ USB Key Drive BBS Priorities


Use this feature to set the boot order of USB devices detected by the BIOS.

▶ NETWORK Drive BBS Priorities

Use this feature to set the boot order of Network devices detected by the BIOS.

4.8 Save & Exit

Select Save & Exit from the BIOS Setup screen to configure the settings below.



Save Options

Discard Changes and Exit

Use this feature to exit from the BIOS Setup utility without making any permanent changes to the system configuration and reboot the computer.

Save Changes and Reset

When you have completed the system configuration changes, use this feature to exit the BIOS Setup utility and reboot the computer for the new system configuration parameters to become effective.

Save Changes

When you have completed the system configuration changes, use this feature to save all changes you've made. This will not reset (reboot) the system.

Discard Changes

Select this feature and press <Enter> to discard all the changes you've made and return to the BIOS Setup utility.

Default Options**Restore Optimized Defaults**

Select this feature and press <Enter> to load manufacturer optimized default settings which are intended for maximum system performance but not for maximum stability.

Save as User Defaults

Select this feature and press <Enter> to save the changes specified by the user as "User Default values" in the BIOS Setup utility for future use.

Restore User Defaults

Select this feature and press <Enter> to retrieve user-defined default settings that have been saved previously.

Boot Override

This feature allows you to override the Boot priorities sequence in the Boot menu, and immediately boot the system with a device specified instead of the one specified in the boot list. This is a one-time override.

Appendix A

BIOS POST Codes

A.1 BIOS POST Codes

The AMI BIOS supplies additional checkpoint codes, which are documented online at <http://www.supernmicro.com/support/manuals/> ("AMI BIOS POST Codes User's Guide").

For information on AMI updates, please refer to <http://www.ami.com/products/>.

Appendix B

Software


After the hardware has been installed, you can install the Operating System (OS), configure RAID settings, and install the drivers.

B.1 Microsoft Windows OS Installation


If you will be using RAID, you must configure RAID settings before installing the Windows OS and the RAID driver. Refer to the RAID Configuration User Guides posted on our website at www.supernmicro.com/support/manuals.

Installing the OS

1. Create a method to access the MS Windows installation ISO file. That might be a Media drive, perhaps using an external USB/SATA media drive, or a USB flash drive, or the BMC KVM console.
2. Retrieve the proper RST/RSTe driver. Go to the Supermicro web page for your motherboard and click on "Download the Latest Drivers and Utilities", select the proper driver, and copy it to a USB flash drive.
3. Boot from a bootable device with Windows OS installation. You can see a bootable device list by pressing **F11** during the system startup.



4. During Windows Setup, continue to the dialog box where you select the drives on which to install Windows. If the disk you want to use is not listed, click on “Load driver” link at the bottom left corner.



To load the driver, browse the USB flash drive for the proper driver files.

- For RAID, choose the SATA/sSATA RAID driver indicated and then choose the storage drive on which you want to install it.
 - For non-RAID, choose the SATA/sSATA AHCI driver indicated and then choose the storage drive on which you want to install it.
5. Once all devices are specified, continue with the installation.
 6. After the Windows OS installation has completed, the system will automatically reboot multiple times.


B.2 Driver Installation

The Supermicro website contains drivers and utilities for your system at <https://www.supermicro.com/wdl/driver>. Some of these must be installed, such as the chipset driver.

After accessing the website, go into the CDR_Images (in the parent directory of the above link) and locate the ISO file for your motherboard. Download this file to a USB flash drive or a Media drive. (You may also use a utility to extract the ISO file if preferred.)

Another option is to go to the Supermicro website at <https://www.supermicro.com/en/products/motherboards> Find the product page for your motherboard, and "Download the Latest Drivers and Utilities".

Insert the flash drive or disk, and the screen shot shown below should appear.



Note: Click the icons showing a hand writing on paper to view the readme files for each item. Click the computer icons to the right of these items to install each item (from top to the bottom) one at a time. **After installing each item, you must re-boot the system before moving on to the next item on the list.** The bottom icon with a CD on it allows you to view the entire contents.

B.3 BMC

The X13QEH+ supports the Baseboard Management Controller (BMC). BMC is used to provide remote access, monitoring and management. There are several BIOS settings that are related to BMC.

For general documentation and information on BMC, please visit our website at: <http://www.supermicro.com/products/nfo/BMC.cfm>.

B.4 Logging into the BMC (Baseboard Management Controller)

Supermicro ships standard products with a unique password for the BMC ADMIN user. This password can be found on a label on the motherboard.

When logging in to the BMC for the first time, please use the unique password provided by Supermicro to log in. You can change the unique password to a user name and password of your choice for subsequent logins.

For more information regarding BMC passwords, please visit our website at https://www.supermicro.com/en/support/BMC_Unique_Password.

Appendix C

Standardized Warning Statements

The following statements are industry standard warnings, provided to warn the user of situations which have the potential for bodily injury. Should you have questions or experience difficulty, contact Supermicro's Technical Support department for assistance. Only certified technicians should attempt to install or configure components.

Read this section in its entirety before installing or configuring components.

These warnings may also be found on our website at <https://www.supermicro.com/en/about/policies/safety-information>.

Battery Handling



Warning! There is the danger of explosion if the battery is replaced incorrectly. Replace the battery only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions

電池の取り扱い

電池交換が正しく行われなかった場合、破裂の危険性があります。交換する電池はメーカーが推奨する型、または同等のものを使用下さい。使用済電池は製造元の指示に従って処分して下さい。

警告

電池更換不當會有爆炸危險。請只使用同類電池或制造商推薦的功能相當的電池更換原有電池。請按製造商的說明處理廢舊電池。

警告

電池更換不當會有爆炸危險。請使用製造商建議之相同或功能相當的電池更換原有電池。請按照製造商的說明指示處理廢棄舊電池。

Warnung

Bei Einsetzen einer falschen Batterie besteht Explosionsgefahr. Ersetzen Sie die Batterie nur durch den gleichen oder vom Hersteller empfohlenen Batterietyp. Entsorgen Sie die benutzten Batterien nach den Anweisungen des Herstellers.

Attention

Danger d'explosion si la pile n'est pas remplacée correctement. Ne la remplacer que par une pile de type semblable ou équivalent, recommandée par le fabricant. Jeter les piles usagées conformément aux instructions du fabricant.

¡Advertencia!

Existe peligro de explosión si la batería se reemplaza de manera incorrecta. Reemplazar la batería exclusivamente con el mismo tipo o el equivalente recomendado por el fabricante. Desechar las baterías gastadas según las instrucciones del fabricante.

אזהרה!

קיימת סכנת פיצוץ של הסוללה במידה והוחלפה בדרך לא תקינה. יש להחליף את הסוללה בסוג התואם מחברת יצרן מומלצת. סילוק הסוללות המשומשות יש לבצע לפי הוראות היצרן.

هناك خطر من انفجار في حالة اسبدال البطارية بطريقة غير صحيحة فعلي
اسبدال البطارية فقط بنفس النع أو ما يعادلها مما أوصت به الشركة المصنعة
جخلص من البطاريات المسعملة وفقا لعمليات الشركة الصانعة

경고!

배터리가 올바르게 교체되지 않으면 폭발의 위험이 있습니다. 기존 배터리와 동일하거나 제조사에서 권장하는 동등한 종류의 배터리로만 교체해야 합니다. 제조사의 안내에 따라 사용된 배터리를 처리하여 주십시오.

Waarschuwing

Er is ontploffingsgevaar indien de batterij verkeerd vervangen wordt. Vervang de batterij slechts met hetzelfde of een equivalent type die door de fabrikant aanbevolen wordt. Gebruikte batterijen dienen overeenkomstig fabrieksvoorschriften afgevoerd te worden.

Product Disposal



Warning! Ultimate disposal of this product should be handled according to all national laws and regulations.

製品の廃棄

この製品を廃棄処分する場合、国の関係する全ての法律・条例に従い処理する必要があります。

警告

本产品的废弃处理应根据所有国家的法律和规章进行。

警告

本產品的廢棄處理應根據所有國家的法律和規章進行。

Warnung

Die Entsorgung dieses Produkts sollte gemäß allen Bestimmungen und Gesetzen des Landes erfolgen.

¡Advertencia!

Al deshacerse por completo de este producto debe seguir todas las leyes y reglamentos nacionales.

Attention

La mise au rebut ou le recyclage de ce produit sont généralement soumis à des lois et/ou directives de respect de l'environnement. Renseignez-vous auprès de l'organisme compétent.

סילוק המוצר

אזהרה!

סילוק סופי של מוצר זה חייב להיות בהתאם להנחיות וחוקי המדינה.

عند التخلص النهائي من هذا المنتج ينبغي التعامل معه وفقا لجميع القوانين واللوائح الوطنية

경고!

이 제품은 해당 국가의 관련 법규 및 규정에 따라 폐기되어야 합니다.

Waarschuwing

De uiteindelijke verwijdering van dit product dient te geschieden in overeenstemming met alle nationale wetten en reglementen.