


AVENTICS™

G3 Series
EtherCAT™
Technical Manual
EtherCAT®



AVENTICS™ G3 Series EtherCAT™ Technical Manual

Conditions for use of this product

(1) Aventics G3 Manifold ("the PRODUCT") shall be used in conditions;

i) Where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident.

ii) Where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.

(2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries.

ASCO L.P. shall have no responsibility or liability including but not limited to any and all responsibility or liability based on contract, warranty, tort, product liability for any injury or death to persons, loss or damage to property caused by the product that are operated or used in application not intended or excluded by instructions, precautions or warnings contained in Aventics Technical, User, Instruction, Safety manuals or bulletins.

Safety precautions

Before using this product, please read this manual and the relevant manuals carefully and pay attention to safety and product application. The following symbols are used in the manual to identify important safety, installation and application information.



Caution symbol indicates a possible hazard which may cause injury or equipment damage.



Note symbol indicates important information regarding equipment installation and setup

Electrical installation and operational guidelines

- To be connected to Class 2 power source only
- All Aventics communication nodes should be grounded during the installation process. These grounding guidelines can be found in National Electrical code IEC 60204-1 or EN 60204-1.
- All Aventics G3 Electronics Products to be installed or wired in accordance with Aventics's published instructions and applicable electrical codes.
- MULTIPLE CLASS 2 POWER SOURCES: When interconnects, class 2 sources shall be Listed and rated suitable for parallel interconnection
- Sources shall be Listed and rated suitable for parallel interconnection
- CLASS 2 WIRING: All field wiring shall be suitable for Class 1, Electric Light and Power, or Class 2, 3 wirings are routed separately and secured to maintain separation between 1) Class 2 wiring and all other class wiring, and 2) Limited energy circuit conductors from unlimited energy circuit conductors
- Class 2 Device Wiring Only – Do Not Reclassify and Install as Class 1, 3 or Power and Lighting Wiring
- When using molded connector power cables, Do Not rely on wire colors for Pin-Out. Always use pin number references.
- Wire connections shall be rated suitable for the wire size (lead and building wiring) employed
- MULTIPLE CLASS 2 POWER SOURCES: When interconnects, class 2 sources shall be Listed and rated suitable for parallel interconnection
- Sources shall be Listed and rated suitable for parallel interconnection

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Table of Contents

1.	About EtherCAT	1-6
1.1	Overview	1-6
1.2	G3 EtherCAT™ Features	1-6
2.	G3 Introduction	2-7
2.1	G3 Electronics Modularity.....	2-8
2.2	500 Series Pneumatic Valve Manifold	2-9
2.3	500 Series Manifold Stations	2-10
2.4	500 Series Z-Board™ Connectors.....	2-11
2.5	2000 Series Pneumatic Valve Manifold.....	2-12
2.6	2000 Series Z-Board™ Connectors.....	2-13
2.7	2000 Series Z-Board™ and Ribbon Cable Example	2-14
2.8	2000 Series Z-Board™ with Valve Side Sub-D Example	2-15
3.	Zoned Power	3-16
3.1	503 Series Zoned Power application	3-16
3.2	503 Series Zoned Power example	3-17
4.	Communication Module	4-18
4.1	EtherCAT™ Communication Module (Node)	4-18
4.2	Communication Module Description.....	4-19
4.3	Connector Pin-Outs	4-20
4.4	Electrical Connections.....	4-21
4.5	Ethernet Straight-Through Cabling Diagrams	4-23
4.6	Ground Wiring.....	4-24
4.7	Power Consumption	4-25
4.8	Recommended External Fuses	4-26
4.9	Diagnostics	4-27
4.10	Output Short Circuit Protection.....	4-28
5.	G3 Graphic Display.....	5-29
5.1	Main Menu Structure	5-30
5.2	EtherCAT™ Operating States (Default Display)	5-31
5.3	Station Alias Sub-Menu	5-32
5.4	IP Address	5-33
5.5	Subnet Mask	5-33
5.6	Gateway IP	5-34
5.7	Config Mode.....	5-35
5.8	Web-Server	5-36
5.9	EtherCAT™ communication	5-37
5.10	MAC Address.....	5-38
5.11	Advanced Settings - I/O Diag. Menu	5-39
5.12	Advanced Settings - Diagnostic Word	5-40
5.13	Advanced Settings – Comm. Fault	5-41
5.14	Advanced Settings – Brightness.....	5-42
5.15	Advanced Settings – Flip Display	5-43
5.16	Advanced Settings – Parameters Lock	5-44
5.17	Advanced Settings – Configuration Lock	5-45
5.18	Factory Defaults	5-46
5.19	Diagnostics - Self Test Mode	5-47
5.20	Diagnostics	5-48
5.21	Network and Sub-Network Error Codes.....	5-49
5.22	Error Messages.....	5-50
6.	ARM – Auto Recovery Module (Optional)	6-51
6.1	ARM process flowchart	6-52
7.	Distribution	7-53
7.1	Sub-Bus Distribution Modules.....	7-54
7.2	580 Series Sub-Bus Valve Module	7-58
7.3	Sub-Bus Hub Module.....	7-59
7.4	Sub-Bus Cables	7-60

AVENTICS™ G3 Series EtherCAT™ Technical Manual

7.5	G3 Sub-Bus Field Wiring Directions	7-61
8.	Digital I/O Module	8-62
8.1	Digital I/O Module Usage	8-62
8.2	I/O Module Technical Data	8-63
8.3	I/O Module Descriptions and Menus	8-64
8.4	Digital Input Modules	8-65
8.5	Digital Output Modules	8-73
8.6	Digital Input/Output Modules	8-77
9.	Valve Interface Modules	9-78
9.1	2000 Series & 500 Series Valve Driver	9-78
9.2	Sub-bus Valve Module	9-80
9.3	Sub-bus Valve Module without Distribution	9-82
9.4	Valve Side Output Module	9-84
9.5	500 Series Extended Coil Capability	9-85
9.6	Extended Coil Configuration	9-85
9.7	Extended Coil Valve Driver Mapping	9-88
9.8	501 Series, up to 64 solenoid coils	9-89
9.9	501 Series, up to 128 solenoid coils	9-90
9.10	502 and 503 Series, up to 80 solenoid coils	9-91
10.	Analog I/O Modules	10-92
10.1	Analog I/O Module Rules	10-92
10.2	Analog Graphic Display	10-99
10.3	Analog Module / Self Test Mode	10-102
10.4	Analog Module / Factory Defaults	10-103
11.	Specialty Modules	11-104
11.1	RTD Module	11-104
11.2	Sub-Bus Hub Module	11-115
12.	I/O Module(s) Wiring Diagrams	12-123
12.1	12.1 NPN/PNP Definitions	12-123
13.	G3 EtherCAT™ Web Server	13-125
13.1	Connecting to a G3 Series EtherCAT™ node	13-125
13.2	Connecting to a G3 Series EtherCAT™ Node (Windows 7)	13-126
13.3	Connecting to a G3 Series EtherCAT™ Node (Windows 10)	13-131
13.4	Using the Functionality of the G3 Series EtherCAT™ Web Server	13-136
13.5	IP Address Configuration	13-144
13.6	User Configurable Device Parameters	13-145
13.7	Parameters Lock	13-145
13.8	I/O Configuration Lock	13-145
13.9	Communication Fault Mode Parameter	13-145
14.	G3 EtherCAT™ PLC Configuration	14-147
14.1	Create Aventics G3 EtherCAT™ configuration (Beckhoff PLC)	14-147
14.3	Twincat configuration for IP communication over EtherCAT™ (Beckhoff PLC)	14-152
14.4	Configure IP communication with G3 over EtherCAT™ (Beckhoff PLC)	14-155
14.5	Create Aventics G3 EtherCAT™ configuration (Lenze PLC)	14-156
14.7	Create Aventics G3 EtherCAT™ configuration (Omron PLC)	14-163
15.	EtherCAT™ Mapping	15-167
15.1	I/O Sizes	15-167
15.3	Manifold and I/O Data Sizing Worksheet	15-168
15.4	Bit Mapping Rules	15-169
15.5	I/O Mapped Diagnostic Word	15-178
16.	Appendix	16-180
16.1	System Specifications	16-180
16.2	Factory Default Settings	16-181
16.3	G3 EtherCAT™ Process Data Map	16-182
16.4	Troubleshooting	16-183
16.5	Glossary of Terms	16-184
16.6	Technical Support	16-186

AVENTICS™ G3 Series EtherCAT™ Technical Manual

1. About EtherCAT

EtherCAT™ is a registered trademark and patented technology, licensed by Beckhoff Automation (GmbH, Germany).

1.1 Overview

EtherCAT™ is an Ethernet-based networking solution for automation but has added benefits/features toward manufacturing applications.

The EtherCAT™ Technology Group or ETG develops and promotes EtherCAT™ technology.

G3 EtherCAT™ uses industrial M12 IP67-rated connectors. The protocol transfers data at a fixed speed of 100 Mbps. The maximum network cabling distance is limited to 100m segments at 20° C.

More information about EtherCAT™ can be obtained at the web site <http://www.EtherCAT.org>.

1.2 G3 EtherCAT™ Features

<i>Features</i>	<i>Description</i>
Spec. Supported	Designed by the EtherCAT™ Technology Group (ETG)
Bus Topology	Star, Tree, Ring or Daisy Chain
Baud Rates Supported	100 Mbps
CE	CE Compliant
Duplicate Address Detection	If a duplicate address is detected on power up, duplicates will not progress to run mode
Address Setting	Web Page Configuration, Graphical Display
Conformance Tested	ETG proof of conformity

AVENTICS™ G3 Series EtherCAT™ Technical Manual


2. G3 Introduction

The G3 Series is an electronic product platform that features an integrated graphic display for simple commissioning and displaying of diagnostic information. In addition it has an innovative distribution capability which allows the same I/O components that make up a centralized manifold configuration to be used as the distribution components as well, decreasing the need for duplicate components on centralized and distributed applications. The G3 platform interfaces to a variety of valve series and fieldbus interface protocols and is capable of addressing a total of 1200 I/O points (150 bytes). With proper assembly and termination the G3 modules will have an IP65 rating.

The manifold can be viewed as having two sections to it, the *Valve Side* and the *Discrete I/O Side*. The *Valve Side* supports a maximum of 128 solenoid coils and the *Discrete I/O Side* supports a maximum of 16 modules capable of addressing up to 1200 outputs, 1200 inputs or various combinations.

Various discrete modules with integrated graphic display are available. They include digital I/O, analog I/O, and specialty modules which cover various application needs. Pin-outs for all connectors are labeled on the side of the respective modules and are also detailed in the module section of this document.

This manual details specific information for configuring and commissioning the AVENTICS G3 Series product line. For more information relating to pneumatic valves and valve manifold assemblies, please refer to the AVENTICS website at www.asco.com.




AVENTICS™ G3 Series EtherCAT™ Technical Manual

2.1 G3 Electronics Modularity

Discrete I/O


The G3 Series product line is a completely modular and scalable system. As shown below, all of the G3 electronic modules plug together, via mechanical clips, allowing for easy assembly and field changes.



AVENTICS™ G3 Series EtherCAT™ Technical Manual

2.2 500 Series Pneumatic Valve Manifold

The pneumatic valve manifold with internal circuit board technology is also modular. The valve solenoid coil connections are automatically made using Z-Board™ technology (plug together PC boards), which allow internal connection from solenoid coils to output drivers without the use of wires). This allows easy assembly and field changes.





AVENTICS™ G3 Series EtherCAT™ Technical Manual

2.3 500 Series Manifold Stations

Solenoid Coil Connections using Z-Board™ Technology for 50X valve series

Z-Board™ plug together technology connects all valve solenoids to the valve coil output driver board, located in the valve adapter. There is a maximum of 32 coil outputs available on the complete manifold assemblies. The 32 available outputs are accessed on the 501 series valves utilizing 4 station manifolds and on the 502 and 503 series utilizing 2 station manifolds.




NOTE!

A single solenoid valve's coil is always on the "14" end.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

2.4 500 Series Z-Board™ Connectors


The 501, 502 and 503 valve series utilize 2 different Z-Board™ designs to achieve the single and double solenoid output functions. This yields the possible 32 single, 16 double, or various combinations of valve coil output capabilities.



AVENTICS™ G3 Series EtherCAT™ Technical Manual

2.5 2000 Series Pneumatic Valve Manifold


The pneumatic valve manifold with internal circuit board technology is also modular. The valve solenoid coil connections are automatically made using Z-Board™ technology (plug together PC boards), which allow internal connection from solenoid coils to output drivers without the use of wires). This allows easy assembly and field changes.



AVENTICS™ G3 Series EtherCAT™ Technical Manual

2.6 2000 Series Z-Board™ Connectors

The 2005/2012/2035 valve series utilize 2 different Z-Board™ designs to achieve the single and double solenoid output functions. This yields the possible 32 single, 16 double, or various combinations of valve coil output capabilities.




The 17th solenoid (output group No. 2's first bit) must be accessed via either the valve side Sub-D output module or a ribbon connector type Z-board.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

2.7 2000 Series Z-Board™ and Ribbon Cable Example

If fourteen (14) single solenoid and one (1) double solenoid valves are connected directly to the communication node via their Z-Boards™, and one (1) single solenoid and four (4) double solenoid valves are connected to the communication node via the ribbon cable, the following would be the valve side bit map:

S = Single Solenoid with Single Z-Board™
D = Double Solenoid With Double Z-Board™




Output Word	0															1																				
Output Byte	0				1				2				3																							
Output Bit No.	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31				
Solenoid Coil Output No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	n/a										

AVENTICS™ G3 Series EtherCAT™ Technical Manual

2.8 2000 Series Z-Board™ with Valve Side Sub-D Example

If sixteen (16) single solenoid valves are connected directly to the communication node via Z-Boards™ and a valve side Sub-D connector is connected to the communication node via the output Group No. 2 connector then the following would be the valve side bit map:

S = Single Solenoid with Single Z-Board




Output Word	0								1																							
Output Byte	0				1				2				3																			
Output Bit No.	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Solenoid Coil Output No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

AVENTICS™ G3 Series EtherCAT™ Technical Manual

3. Zoned Power


3.1 503 Series Zoned Power application

The Zoned Power Manifold blocks can be incorporated into a 503 manifold assembly to isolate Power to a number of valve stations, independent from the main power of the manifold. This is achieved by the integral 4 Pin M12 connector along with the modified manifold board. The total number of Zoned Power Manifold blocks is determined by the maximum solenoid outputs as defined by the type of interface (e.g. G3 Electronics, Terminal Strip, D-Sub). For user flexibility, the Zoned Power Manifold blocks are available in both "proprietary" and "ISO" versions and can be ordered with the M12 connector starting at the first or second station.



V Wiring Option

W & V Connector Pin Out



W Wiring Option

Technical Data

Electrical Data:

Voltage: 24 VDC (0 VDC must be common with main power)


Connection: 4 Pin M12 Single Key Male

Environmental: IP65 (with proper connection)

AVENTICS™ G3 Series EtherCAT™ Technical Manual

3.2 503 Series Zoned Power example

In the example shown below there are two Zoned Power Manifold blocks used. One is a "W" wiring option and the other is a "V" wiring option. The first (5) stations of the manifold assembly get their power from the M12 4 Pin connector at station one. The next (5) stations get their power from the M12 4 Pin connector at station six. Each of these "Zones" can be individually switched of if the machine or process requires. This example is considered a manifold with (2) Power Zones. The Main Power (7/8" MINI) cannot be considered or used as a Power Zone; Switched Power (Solenoid/Output Power) **MUST** be present for control to the solenoids.



The 0 VDC reference for the +24 VDC applied to Pin 4 of the M12 connector **MUST** be the same as the one used on G3/580/Terminal Strip/25 or 37 Pin Sub-D/19 or 26 Pin Round Connector. If multiple 24 VDC power supplies are used the 0 VDC references of each supply **MUST** be common.


AVENTICS™ G3 Series EtherCAT™ Technical Manual

4. Communication Module

4.1 EtherCAT™ Communication Module (Node)

This module is the communication interface to the manifold. It contains communication electronics and internal short circuit protection for power. It can be configured via software and via the graphic display.


Communication Module Kit Part Number	
EtherCAT™ Communication module	240-310



AVENTICS™ G3 Series EtherCAT™ Technical Manual

4.2 Communication Module Description

Detail No.	Description
1	"Set" Button – used to navigate through user menus and to set parameters
2	Status LEDs
3	4 Pin M12 D-Coded Female Communication Connectors
4	Mounting Hole
5	"Next" Button – used to navigate through user menus and to set parameters
6	Graphic Display – used to display parameter information
7	Slot for text ID tags
8	Keying for preventing I/O module insertion
9	5 Pin MINI Male Power Connector



AVENTICS™ G3 Series EtherCAT™ Technical Manual

4.3 Connector Pin-Outs


Industry standard connectors are used for communication and auxiliary power.
 The communication connectors are a D-coded keyway 4 pin female M12 connector.
 The Power connector is a single keyway 5 pin male 7/8" MINI connector.

Communication Connector Pin-Out


Pin No.	Function	Description
1	TD+	Positive Transmit Line
2	RD+	Positive Receive Line
3	TD-	Negative Transmit Line
4	RD-	Negative Receive Line

Power Connector Pin-Out

Pin No.	Function	Description
1	0 VDC Common (Valves and Outputs)	0 VDC Voltage used to power outputs (valve coils and discrete outputs) SW
2	0 VDC Common (Node and Inputs)	0 VDC Voltage used to power discrete inputs and node electronics UNSW
3	Earth Ground	Protective Earth
4	+24 VDC (Node and Inputs)	Voltage used to power discrete inputs and node electronics UNSW
5	+24 VDC (Valves and Outputs)	Voltage used to power outputs (valve coils and discrete outputs) SW



PIN 1= TX +
 PIN 2= RX +
 PIN 3= TX -
 PIN 4= RX -



PIN 1= 0 VDC VALVES & OUT (SW)
 PIN 2= 0 VDC NODE & IN (UNSW)
 PIN 3= EARTH GROUND
 PIN 4= +24 VDC NODE & IN (UNSW)
 PIN 5= +24 VDC VALVES & OUT (SW)




- Power common (0 VDC) pins 1 and 2 are isolated from each other to allow separate (isolated) power supply connection if required. However, they can be tied together if a single common, non-isolated, application is preferred.
- The combined draw of the +24VDC Valves and Outputs and +24VDC Node and Inputs pins cannot exceed 8 Amps, at any given moment in time.
- The Node and Inputs pin supplies power to the node electronics. This pin must be powered at all times for communication node to be functional.

AVENTICS™ G3 Series EtherCAT™ Technical Manual


4.4 Electrical Connections

Power Connector Wiring Diagram

Power Supply Example (Non-isolated commons)



Power Supply Example (Isolated commons)



CAUTION

- Please see page 4-26 for external fuse sizing guide.
- When using molded connector power cables, **Do Not** rely on wire colors for Pin-Out. **Always use pin number references.**
- Power common (0 VDC) pins 3 and 4 are isolated from each other to allow separate (isolated) power supply connection if required. However, they can be tied together if a single common, non-isolated, application is preferred.

(Continued Below)

AVENTICS™ G3 Series EtherCAT™ Technical Manual



CAUTION


- *The combined draw of the +24VDC Valves and Outputs and +24VDC Node and Inputs pins cannot exceed 8 Amps, at any given moment in time.*
- *The Node and Inputs pin supplies power to the node electronics. This pin must be powered at all times for communication node to be functional.*
- *Class 2 Device Wiring Only – Do Not Reclassify and Install as Class 1, 3 or Power and Lighting Wiring*
- *Wire connections shall be rated suitable for the wire size (lead and building wiring) employed*
- *Up to a maximum 16 I/O modules (units) can be connected to 1 Communication Module not including any Sub-Bus and Miscellaneous modules, or equivalent*
- *CLASS 2 WIRING: All field wiring shall be suitable for Class 1, Electric Light and Power, or Class 2, 3 wirings are routed separately and secured to maintain separation between 1) Class 2 wiring and all other class wiring, and 2) Limited energy circuit conductors from unlimited energy circuit conductors*
- *MULTIPLE CLASS 2 POWER SOURCES: When interconnects, class 2 sources shall be Listed and rated suitable for parallel interconnection*
- *Sources shall be Listed and rated suitable for parallel interconnection*

AVENTICS™ G3 Series EtherCAT™ Technical Manual

4.5 Ethernet Straight-Through Cabling Diagrams

Straight-Through Ethernet cable is used when connecting an Ethernet node to any component (router, switch, hub, computer, etc.). Here are some basic wiring examples of Straight-Through cabling.

RJ45 to M12 D Coded Cable



M12 D Coded to M12 D Coded Cable



Description			Color		Pin Number	
EtherCAT™	Ethernet		Star Quad	2-Pair	RJ45	M12
TD+	TX+	Transmit Data +	YELLOW	WHITE / ORANGE	1	1
TD-	TX-	Transmit Data -	ORANGE	ORANGE	2	3
RD+	RX+	Receive Data +	WHITE	WHITE / GREEN	3	2
RD-	RX-	Receive Data -	BLUE	GREEN	6	4




- RJ45 shown as T-568B standard.

AVENTICS™ G3 Series EtherCAT™ Technical Manual


4.6 Ground Wiring

All Aventics Inc. communication nodes should be grounded during the installation process. These grounding guidelines can be found in National Electrical code IEC 60204-1 or EN 60204-1.

500 Series



2000 Series



CAUTION

- Proper grounding will prevent many intermittent problems with network communication.
- When grounding to a machine frame, please ensure that the machine frame itself is already properly grounded.
- Better grounding can be achieved when larger diameter (lower gauge) wire is used.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

4.7 Power Consumption

Power Connection

Pin No.	Function	Description
1	0 VDC Common (Valves and Outputs)	0 VDC Voltage used to power outputs (valve coils and discrete outputs) SW
2	0 VDC Common (Node and Inputs)	0 VDC Voltage used to power discrete inputs and node electronics UNSW
3	Earth Ground	Protective Earth
4	+24 VDC (Node and Inputs)	Voltage used to power discrete inputs and node electronics UNSW
5	+24 VDC (Valves and Outputs)	Voltage used to power outputs (valve coils and discrete outputs) SW

Power Rating

- For maximum supply current capability please refer to page 8-63.
- Loads should not draw more than 0.5 Amps of current from any one individual discrete output point (Contact factory for higher current capability requirements).

Component	Voltage	Tolerance	+24VDC (Valves and Outputs) Pins 1 and 4		+24VDC (Node and Inputs) Pins 2 and 3	
			Current	Power	Current	Power
Solenoid Valve Coil 501 (Each)	24 VDC	+10%/-15%	0.03 A	0.80 W	0 A	0 W
Solenoid Valve Coil 502 (Each)	24 VDC	+10%/-15%	0.05 A	1.30 W	0 A	0 W
Solenoid Valve Coil 503 (Each)	24 VDC	+10%/-15%	0.07 A	1.70 W	0 A	0 W
Solenoid Valve Coil 2002 (Each)	24 VDC	+10%/-15%	0.02 A	0.48 W	0 A	0 W
Solenoid Valve Coil 2005 (Each)	24 VDC	+10%/-15%	0.06 A	1.44 W	0 A	0 W
Solenoid Valve Coil 2012 (Each)	24 VDC	+10%/-15%	0.11 A	2.64 W	0 A	0 W
Solenoid Valve Coil 2035 (Each)	24 VDC	+10%/-15%	0.11 A	2.64 W	0 A	0 W
Solenoid Valve Coil ISO 5599/2- SPA	24 VDC	+10%/-15%	0.17 A	4.08 W	0 A	0 W
Valve Adapter (Driver) 2000 series	24 VDC	+/- 10%	0.03A	0.72 W	0.02 A	0.48 W
Valve Adapter (Driver) 500 series	24 VDC	+/- 10%	0.03A	0.72 W	0.02 A	0.48 W
501 Series 32+ valve driver board	24 VDC	+/- 10%	0.03A	0.72 W	0.05 A	1.20 W
502 Series 32+ valve driver board	24 VDC	+/- 10%	0.03A	0.72 W	0.05 A	1.20 W
503 Series 32+ valve driver board	24 VDC	+/- 10%	0.03A	0.72 W	0.05 A	1.20 W
Digital Module (M12 style)	24 VDC	+/- 10%	0.04 A	0.96 W	0.05 A*	1.20 W*
Digital Module (M8 Style)	24 VDC	+/- 10%	0 A	0W	0.19A	4.56 W
Analog Module	24 VDC	+/- 10%	0.01 A	0.24 W	0.08 A*	1.92 W*
Sub-Bus Hub	24 VDC	+/- 10%	0 A	0 W	0.06 A	1.44 W*
RTD Module	24 VDC	+/- 10%	0.01 A	0.24 W	0.06 A	1.44 W*
Communication Module (Node)	24 VDC	+/- 10%	0.04 A	0.9 W	0.10 A*	2.50 W*
Sub-Bus Valve Module	24 VDC	+/- 10%	0.01 A	0.24 W	0.03 A*	0.72 W*
580 Sub-Bus Valve Module	24 VDC	+/- 10%	.034 A	0.8 W	0.04 A*	0.9 W*
Auto Recovery Module (ARM)	24 VDC	+/- 10%	0 A	0 W	0.03 A	0.72 W
ARM-Clip Module	24 VDC	+/- 10%	0 A	0 W	0.03 A	0.72 W

* Current depends on graphic display brightness setting. Max. value shown with high brightness. Values decrease by approx. 5% for Medium and 11% for Low brightness settings.



- Total power consumption for each Discrete I/O point is dependent on the specific current draw of input sensor

AVENTICS™ G3 Series EtherCAT™ Technical Manual

4.8 Recommended External Fuses

External fuses should be chosen based upon the physical manifold configuration. Please refer to the table below for the fuse sizing chart.

External Fuse Sizing Chart

<i>Power Consumption - Power Connector Pin for Valves and Outputs</i>		
<u>Description</u>		<u>Current</u>
Number of Solenoid Valve Coils Energized Simultaneously		
___ X 0.167 A (ISO - SPA Series)	=	_____Amps
___ X 0.105 A (2012 and 2035 Series)	=	_____Amps
___ X 0.056 A (2005 Series)	=	_____Amps
___ X 0.021 A (2002 Series)	=	_____Amps
		+
Total load current drawn by simultaneously energized Discrete Outputs	=	_____Amps
		+
Number of I/O modules installed ___ X 0.023 A	=	_____Amps
		+
Valve Adapters (219-828) installed ___ X 0.134 A	=	_____Amps
		+
Communication Node Power Consumption	=	.006 Amps
		+
Total:		_____Amps
Surge Compensation:	X	1.25
Suggested External +24 VDC (Valves and Outputs) Fuse Value:		_____Amps
<i>Power Consumption – Power Connector Pin for Node and Inputs</i>		
<u>Description</u>		<u>Current</u>
Communication Node Power Consumption	=	.091 Amps
		+
Total load current drawn by Sensor Devices from Discrete Inputs source	=	_____Amps
		+
Number of I/O modules installed ___ X 0.075 A	=	_____Amps
		+
Total:		_____Amps
Surge Compensation:	X	1.25
Suggested External Pin +24 VDC (Node and Inputs) Fuse Value:		_____Amps

*Factory Default Settings




- The Node and Inputs Aux Power pins supply power to the node electronics. These pins must be powered at all times for communication node and Inputs to be functional.
- The internal electronic fuses exist to protect against damage due to catastrophic failure of internal components. External fuses are always recommended for protection against power supply failure and over-current conditions.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

4.9 Diagnostics

Communication Module LED Functions

Upon power up, the LEDs indicate the status of the unit. There are three LEDs on the G3 EtherCAT™ node. These LEDs are described below.



LED Name	Color	Status	Description
RUN	Green	OFF	No Function
		ON	No Function
ERROR	Off	OFF	No Error
	ON	FLASH	EtherCAT™ communication with application controller was lost
L/Ain	Green	OFF	No EtherCAT™ connection is detected
		ON	EtherCAT™ connection established to the application controller
		FLASHING	The LED flashes each time a packet is received or transmitted.
L/Aout	Green	OFF	No EtherCAT™ connection is detected
		ON	EtherCAT™ connection established to downstream node
		FLASHING	The LED flashes each time a packet is received or transmitted.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

4.10 Output Short Circuit Protection


Status Bit Action during Fault Condition

<i>Output Type</i>	<i>Output State</i>	<i>Fault Condition</i>	<i>Status Bit</i>
Valve Solenoid Coil Driver	ON	No Fault	0
		Fault - Short Circuit, Over Temp/Over Current	1
	OFF	No Fault	0
		Fault - Open Load	1
Discrete Outputs	ON	No Fault	0
		Fault - Short Circuit, Over Temp/Over Current	1

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5. G3 Graphic Display

The G3 Communication and I/O modules have an integrated graphic display that may be used to configure the parameters of the modules as well as showing diagnostic information.



The following graphic displays represent the main menu selections of the G3 communication module (node). Use the NEXT button to scroll through the Main menu headings shown below. At this level pressing the SET button allows access the Sub-Menus. Please see the appropriate pages referenced below for further details and descriptions of the Sub-Menus.


NOTE: When a network I/O connection is established manual changes to node parameters are not allowed!

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.1 Main Menu Structure

Use the NEXT button to scroll through the Main menu headings shown below. At this level pressing the SET button allows access the Sub-Menus. Please see the appropriate pages referenced below for further details and descriptions of the Sub-Menus. Note that many of these settings can also be adjusted via software with GSD file parameters.

NOTE: When a network I/O connection is established manual changes to node parameters are not allowed!



•When a network I/O connection is established manual changes to node parameters are not allowed!

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.2 EtherCAT™ Operating States (Default Display)

The default display identifies one of four possible operating states of the EtherCAT™ node. The node state display cannot be modified through the G3 menus.



1. Initialization- After power on the module is ready for communication with the EtherCAT™ master.



2. Pre-Operational- Module parameters are loaded, Communication established process I/O is not executed.



3. Safe Operational- Input data is processed once synchronization is established with the EtherCAT™ master. Disconnecting communication with an operational node will cause the node to change to SAFE-OP.



4. Operational- Normal operating mode, the G3 node is synchronized with the EtherCAT™ master and processing I/O data.



5. EtherCAT™ TCP Only- EtherCAT™ communication disabled by menu configuration Only TCP communication possible.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.3 Station Alias Sub-Menu



Steps to Set Station Alias


1. Press the **SET** button to enter the “Station Alias” sub-menu.



2. Press the **NEXT** button to scroll through the choices for the tens digit of the node address. Press the **SET** button to select the tens digit and move into the ones digit selection.




3. Press the **NEXT** button to scroll through the choices for the ones digit of the node address. Press the **SET** button to select the ones digit.



4. Press the **NEXT** button to select **Yes** or **No** to accept the address shown on the display,
 - a. Selecting **No** will bring you back to the main Address menu.
 - b. Selecting **Yes** will take you to the following SAVE SETTINGS menu.

Press the **SET** button to confirm your choice.



5. Press the **NEXT** button to select either **NOW** or **LATER**.
 - a. Selecting **NOW** will cause the node to reset and apply the new setting.
 - b. Selecting **LATER** will cause the new Address to be saved in temporary memory and allow you to make additional parameter changes before the node is reset. However, you must **ACCEPT** the saved changes before your next power cycle otherwise they will be lost.

Press the **SET** button to confirm your choice.



- Only addresses 1- 192 are valid.
- Address 0 is not valid.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.4 IP Address




IP Address

1. The IP address can only be modified from the module display with EtherCat™ disabled (TCP IP only).



- *Factory default address is 192.168.003.120*

5.5 Subnet Mask



Subnet Mask

1. The Subnet Mask can only be modified from the module display with EtherCat™ disabled (TCP IP only).



- *The ETHERCAT™ Factory default Subnet Mask is 255.255.255.0.*

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.6 Gateway IP



Gateway IP Address


1. The Gateway IP can only be modified from the module display with EtherCat™ disabled (TCP IP only).



- *Factory default gateway IP is 0.0.0.0*

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.7 Config Mode



Steps to Set Coil Configuration

1. Press the **SET** button to enter the CONFIG MODE sub-menu.
2. Press the **SET** button and the **NEXT** button to change the number of coils.
 - a. 64 - allows the node to recognize one additional valve driver.
 - b. 96 - allows the node to recognize two additional valve drivers
 - c. 128 - allows the node to recognize three additional valve drivers
 - d. RETURN – Takes you back to the main menu

Press the **SET** button to confirm your choice.


3. Press the **NEXT** button to select **Yes** or **No** to accept the setting
 - a. Selecting **No** will bring you back to the main CONFIG MODE menu.
 - b. Selecting **Yes** will take you to the following SAVE SETTINGS menu.

Press the **SET** button to confirm your choice

Saved Setting Steps

4. Press the **NEXT** button to select either NOW or LATER.
 - a. Selecting NOW will cause the node to reset and apply the new setting.
 - b. Selecting LATER will cause the setting to be saved in temporary memory to allow you to make additional parameter changes before the node is reset. However, you must ACCEPT the saved changes before your next power cycle otherwise they will be lost.

Press the **SET** button to confirm your choice.




AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.8 Web-Server

This will allow the enabling/disabling of the G3 Web Server.

Web-Server Steps



1. Press the **SET** button to enter the Web-Server sub-menu.



2. Press the **NEXT** button to scroll through the choices to enable or disable the feature.
 - a. ENABLED (Factory Default)
 - b. DISABLED
 - c. RETURN (this will return you to the main menu)

Press the **SET** button to confirm your choice.



3. Press the **NEXT** button to select **Yes** or **No** to accept the selection.
 - a. Selecting **No** will bring you back to the main menu.
 - b. Selecting **Yes** will take you to the following apply changes menu.

Press the **SET** button to confirm your choice.



Apply Changes Steps



4. Press the **NEXT** button to select either **NOW** or **LATER**.
 - a. Selecting **NOW** will cause the node to reset and apply the new setting.
 - b. Selecting **LATER** will cause the new setting to be saved in memory, you must accept the saved changes before your next power cycle otherwise they will be lost.

Press the **SET** button to confirm your choice.



• Factory default setting for WEB-SERVER is enabled.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.9 EtherCAT™ communication

This will disable EtherCAT™ communication to connect to the G3 webserver.

EtherCAT™ Steps




1. Press the **SET** button to enter the EtherCAT™ communication sub-menu.



2. Press the **NEXT** button to scroll through the choices to enable or disable the feature.
 - d. ENABLED (Factory Default)
 - e. DISABLED
 - f. RETURN (this will return you to the main menu)



Press the **SET** button to confirm your choice.



3. Press the **NEXT** button to select **Yes** or **No** to accept the selection.
 - c. Selecting **No** will bring you back to the main menu.
 - d. Selecting **Yes** will take you to the following apply changes menu.

Press the **SET** button to confirm your choice.



Apply Changes Steps



4. Press the **NEXT** button to select either **NOW** or **LATER**.
 - c. Selecting **NOW** will cause the node to reset and apply the new setting.
 - d. Selecting **LATER** will cause the new setting to be saved in memory, you must accept the saved changes before your next power cycle otherwise they will be lost.

Press the **SET** button to confirm your choice.



CAUTION

- *Disabling EtherCAT™ stops all communication with the EtherCAT™ master!*

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.10 MAC Address



MAC (Machine Access Control) Address

1. The MAC Address is a fixed unique value that cannot be edited.

The actual MAC ADDR has an extra leading zero. The actual number in the example shown is 00-15-24-00-06-69



- *The MAC ADDR cannot be modified*
- *Please note that the leading 0 in this number has been left off*

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.11 Advanced Settings - I/O Diag. Menu

This will allow the enabling / disabling of the IO Status bits. The IO status bits include valve coil, discrete output, input short circuit and alarm status bits. The default condition is enabled.

I/O Status Steps

1. Press the **SET** button to enter the ADVANCED SETTINGS sub-menu.
2. Press the **SET** button to enter the ADVANCED MENU / SET STATUS.
3. Press the **SET** button to enter the SET STATUS / I-O STATUS.
4. The current state of the parameter is shown.
5. Press the **SET** button to change this parameter
Use the **NEXT** button to scroll through the choices to enable/disable the Diagnostic status for I/O.
 - a. ENABLED (Factory Default)
 - b. DISABLED
 - c. RETURN (this will return you to the SET STATUS menu)

Press the **SET** button to confirm your choice.
6. Press **NEXT** to confirm the warning message.
7. Press the **NEXT** button to select Yes or No to accept the selection
 - a. Selecting **No** will bring you back to the main SET STATUS menu.
 - b. Selecting **Yes** will take you to the following saved settings menu.

Press the **SET** button to confirm your choice.
8. Press the **NEXT** button to select either NOW or LATER.
 - a. Selecting **NOW** will cause the node to reset and apply the new setting.
 - b. Selecting **LATER** will cause the new I/O STATUS selection to be saved in memory, you must Accept the saved changes before your next power cycle otherwise they will be lost.







Press the **SET** button to confirm your choice.

Save Settings Steps

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.12 Advanced Settings - Diagnostic Word

This will allow the enabling / disabling of the Diagnostic Word Status bits. The Diagnostic word data includes power status and sub-bus related status bits. Detailed information regarding these bits can be found on page 15-178. The Diagnostic Word comes enabled from the factory.



Diag. Word Status Settings

1. Press the **SET** button to enter the ADVANCED SETTINGS menu.
2. Press the **SET** button to enter the ADVANCED MENU /SET STATUS.
3. Press the **NEXT** button to scroll to the SET STATUS / DIAG WORD menu. Press the **SET** button to enter the SET STATUS / DIAG WORD menu.
4. The current state of the parameter is shown.
5. Press the **SET** button to change this parameter. Use the **NEXT** button to scroll through the choices to enable/disable the Diagnostic Word status for.
 - a. ENABLED (Factory Default)
 - b. DISABLED
 - c. RETURN (this will return you to the SET STATUS menu)

Press the **SET** button to confirm your choice.

6. Press **NEXT** to confirm the warning message.
 7. Press the **NEXT** button to select **Yes** or **No** to accept the selection.
 - a. Selecting **No** will bring you back to the main SET STATUS menu.
 - b. Selecting **Yes** will take you to the following saved settings menu.
- Press the **SET** button to confirm your choice.

Save Settings Steps

8. Press the **NEXT** button to select either **NOW** or **LATER**.
 - a. Selecting **NOW** will cause the node to reset and apply the new setting.
 - b. Selecting **LATER** will cause the new NODE DIAG selection to be saved in memory, you must Accept the saved changes before your next power cycle otherwise they will be lost.

Press the **SET** button to confirm your choice.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.13 Advanced Settings – Comm. Fault

This will allow the enabling / disabling of the Fault Action parameter. The Fault Action parameter determines the behavior of the outputs during a communication fault.

Fault Action Settings

-
1. Press the **SET** button to enter the ADVANCED SETTINGS menu.
 2. Press the **NEXT** button to scroll to the ADVANCED MENU / SET FAULT IDLE.
 3. Press the **SET** button to enter the ADVANCED MENU / SET FAULT IDLE.
 4. Press the **SET** button to enter the SET FAULT IDLE / FAULT ACTION menu.
 5. The current state of the parameter is shown
 6. Press the **SET** button to change this parameter
Press the **NEXT** button to scroll the choices for the desired output action during a fault state.
 - a. OFF (Factory Default)
 - b. HOLD LAST STATE
 - c. RETURN (this will return you to the SET FAULT/IDLE menu)

Press the **SET** button to confirm your choice.
 7. Press the **NEXT** button to select **Yes** or **No** to accept the selection
Press the **SET** button to confirm your choice
 - a. Selecting **No** will bring you back to the main SET FAULT/IDLE menu.
 - b. Selecting **Yes** will take you to the following saved settings menu.

Save Settings Steps
 8. Press the **NEXT** button to select either **NOW** or **LATER**.
Press the **SET** button to confirm your choice.
 - a. Selecting **NOW** will cause the node to reset and apply the new setting
 - b. Selecting **LATER** will cause the new FAULT ACTION selection to be saved in memory, you must Accept the saved changes before your next power cycle



- Factory Default is ALL OFF, See page 5-46 for more details.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.14 Advanced Settings – Brightness


Brightness Settings




1. Press the **SET** button to enter the ADVANCED SETTINGS menu.



2. Press the **NEXT** button to scroll to the CONFIG MENU / SET BRIGHTNESS.
Press the **SET** button to enter the CONFIG MENU / SET BRIGHTNESS.



3. The current state of the parameter is shown



4. Press the **SET** button to change this parameter
Press the **NEXT** button to scroll the choices for the desired brightness of the graphic display for all modules on the G3 system.



- a. LOW
- b. MEDIUM
- c. HIGH (Factory Default)



Press the **SET** button to confirm your choice. The changes will take effect immediately.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.15 Advanced Settings – Flip Display

Flip Display Settings



1. Press the **SET** button to enter the ADVANCED SETTINGS menu.



2. Press the **NEXT** button to scroll to the CONFIG MENU / FLIP DISPLAY.

Press the **SET** button to enter the CONFIG MENU / FLIP DISPLAY.



3. The current state of the parameter is shown



4. Press the **NEXT** button to change this parameter

- a. YES
- b. RETURN

Press the **SET** button to confirm your choice.



NOTE!

- This is a global setting that affects all modules
- Each module, however, has its own setting if different settings are required.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.16 Advanced Settings – Parameters Lock

PARAMETER Steps



1. Press the **SET** button to enter the Parameters sub-menu.



2. Press the **NEXT** button to scroll through the choices to enable or disable the feature.
 - g. UNLOCKED (Factory Default)
 - h. LOCKED
 - i. RETURN (this will return you to the main menu)



Press the **SET** button to confirm your choice.



By choosing LOCKED, all settable parameters will be read only via the graphic display. UNLOCKED, the factory default, will allow all parameters to be settable through the graphic display.

Please note that all parameters are read only, regardless of this setting, when an IO connection between the communication module and the controller (PLC) is present



3. Press the **NEXT** button to select **Yes** or **No** to accept the selection.
 - e. Selecting **No** will bring you back to the main menu.
 - f. Selecting **Yes** will take you to the following apply changes menu.



Press the **SET** button to confirm your choice.

Apply Changes Steps





4. Press the **NEXT** button to select either NOW or LATER.
 - e. Selecting NOW will cause the node to reset and apply the new setting.
 - f. Selecting LATER will cause the new setting to be saved in memory, you must accept the saved changes before your next power cycle otherwise they will be lost.

Press the **SET** button to confirm your choice.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.17 Advanced Settings – Configuration Lock



Configuration Lock Settings

1. Press the **SET** button to enter the ADVANCED SETTINGS menu.

2. Press the **NEXT** button to scroll to the CONFIG MENU / CONFIG. LOCK.

Press the **SET** button to enter the CONFIG MENU / CONFIG. LOCK.

3. The current state of the parameter is shown
4. Press the **SET** button to change this parameter
5. Press the **NEXT** button to scroll through the choices to enable or disable the feature.
 - a. UNLOCKED (Factory Default)
 - b. LOCKED
 - c. RETURN (this will return you to the main menu)

Press the **SET** button to confirm your choice.

6. Press the **NEXT** button to select Yes or No to accept the selection.
 - a. Selecting No will bring you back to the main menu.
 - b. Selecting Yes will take you to the following apply changes menu.

Press the **SET** button to confirm your choice.

Apply Changes Steps

7. Press the **NEXT** button to select either NOW or LATER.
 - a. Selecting NOW will cause the node to reset and apply the new setting.
 - b. Selecting LATER will cause the new setting to be saved in memory, you must accept the saved changes before your next power cycle otherwise they will be lost.

Press the **SET** button to confirm your choice.

Note:

By choosing LOCKED, the manifold configurations will be stored in memory and the PHYSICAL manifold configuration cannot be changed. UNLOCKED, the manifold configurations can be changed without errors.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.18 Factory Defaults



Factory Default Settings

1. Press the **SET** button to enter the FACTORY DEFAULTS sub-menu.



2. Press the **SET** button to change this parameter



3. Press the **NEXT** button to select **Yes** or **No**.
 - a. Selecting **No** will bring you back to the main FACTORY DEFAULTS menu.
 - b. Selecting **Yes** will cause the node to reset and return all parameters to the factory default conditions.
 - c. Selecting RETURN will bring you back to the main FACTORY DEFAULTS menu

Press the **SET** button to confirm your choice.

FACTORY DEFAULT SETTINGS	
Description	Default
IP Address	193.168.3.120
Subnet Mask	255.255.255.0
Gateway IP	0.0.0.0
I/O Status	Enabled
Diag. Word	Enabled
Fault Action	Off
Brightness	Medium
Parameters	Unlocked
I/O configuration	Unlocked

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.19 Diagnostics - Self Test Mode


An internal diagnostic tool can be enabled on the communication module (node) using the graphic display. This tool allows the user to confirm that all of the inputs and outputs on the manifold and any of the distributed modules are fully functional without needing a network connection or controller. There are two test modes that the user can choose. The "CYCLE OUTPUTS" test mode tests all the outputs by sequentially turning them ON and OFF for approximately .5 seconds. The "INPUTS" test mode tests the inputs by causing all of the outputs to toggle between even and odd values when any input is made. The Self Test mode on the communication module (node) is a global setting and will test all devices connected on the main manifold as well as any distributed modules and/or manifolds.

Similar "local" self tests are available on all output modules types. This "local" self-test function allows any output module to be tested without affecting any other output module.

NOTE: The number of Valve outputs that are tested are affected by the I/O size settings.


To use the Self Test Mode, the user must first set some initial conditions. Follow these steps to initiate the self-test mode.

- 1) **Disconnect Air and Communication from the manifold!**
- 2) Select the desired test mode using the graphic display. (See example below)
- 3) Starting at the Home Screen, navigate the menus by selecting the NEXT button until the DIAGNOSTICS menu is shown.
- 4) Select the SET button to access the DIAGNOSTICS menu and then again to access the SELF-TEST menu
- 5) Push NEXT to navigate to the desired test mode: CYCLE OUTPUTS or INPUTS
- 6) Push SET to select the desired test mode.
- 7) A message will appear: DISCONNECT AIR HOLD SET BUTTON
- 8) Hold the SET button down for approximately 10 seconds to enable the test. The Display will flash the above message while the button is pushed.
- 9) When the display stops flashing, the self-test mode will run and the Module Status LED will flash Red/Green while the display shows SELF TEST RUNNING.
- 10) The global self-test mode can only be disabled by disconnecting the power to the manifold.



AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.20 Diagnostics



1. All diagnostic information is read only
2. Press the SET button to enter DIAGNOSTICS sub-menu.
3. Press the NEXT button to scroll through the main diagnostic menu choices.
 - a. SET SELF TEST
 - i. - Please see following page for description
 - b. UNSW POWER
 - i. - Displays voltage level of unswitched power (Node & Inputs)
 - c. NETWORK DATA
 - i. - Displays the network diagnostics
 - d. FIRMWARE REVISION
 - i. - For service personnel
 - e. FIRMWARE BUILD
 - i. - For service personnel
 - f. LOAD FIRMWARE
 - i. - For service personnel
 - g. BOOTCODE REVISION
 - i. - For service personnel
 - h. BOOTCODE BUILD
 - i. - For service personnel
 - i. PART NUMBER
 - i. - Displays replacement part number of module
 - j. RETURN TO MAIN MENU



- The UNSW POWER screen indicates the voltage level present on the UNSW (Node & Input) power pins (Pin No. 2 and 3) of the main power connector.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.21 Network and Sub-Network Error Codes

<u>Error Code</u>	<u>Error</u>	<u>Error Description</u>	<u>Module No.</u>
<u>Main Network</u>			
1		Output power not present on communication module	Comm.
2		Node / Input power is below 19VDC	Comm.
4		Error associated with a sub-bus module (see sub-bus error)	Comm.
8		short circuit detected on the sub-bus	Comm.
<u>Sub Network</u>			
22	1	Module did not respond	1
23	1	Module did not respond	2
24	1	Module did not respond	3
25	1	Module did not respond	4
26	1	Module did not respond	5
27	1	Module did not respond	6
28	1	Module did not respond	7
29	1	Module did not respond	8
2A	1	Module did not respond	9
2B	1	Module did not respond	10
2C	1	Module did not respond	11
2D	1	Module did not respond	12
2E	1	Module did not respond	13
2F	1	Module did not respond	14
30	1	Module did not respond	15
31	1	Module did not respond	16
42	2	Switched power is missing	1
43	2	Switched power is missing	2
44	2	Switched power is missing	3
45	2	Switched power is missing	4
46	2	Switched power is missing	5
47	2	Switched power is missing	6
48	2	Switched power is missing	7
49	2	Switched power is missing	8
4A	2	Switched power is missing	9
4B	2	Switched power is missing	10
4C	2	Switched power is missing	11
4D	2	Switched power is missing	12
4E	2	Switched power is missing	13
4F	2	Switched power is missing	14
50	2	Switched power is missing	15
51	2	Switched power is missing	16
62	3	Combination of errors 1 and 2	1
63	3	Combination of errors 1 and 2	2
64	3	Combination of errors 1 and 2	3
65	3	Combination of errors 1 and 2	4
66	3	Combination of errors 1 and 2	5
67	3	Combination of errors 1 and 2	6
68	3	Combination of errors 1 and 2	7
69	3	Combination of errors 1 and 2	8
6A	3	Combination of errors 1 and 2	9
6B	3	Combination of errors 1 and 2	10
6C	3	Combination of errors 1 and 2	11
6D	3	Combination of errors 1 and 2	12
6E	3	Combination of errors 1 and 2	13
6F	3	Combination of errors 1 and 2	14
70	3	Combination of errors 1 and 2	15
71	3	Combination of errors 1 and 2	16

AVENTICS™ G3 Series EtherCAT™ Technical Manual

5.22 Error Messages


The following are automatic error messages that are displayed when specific faults occur during operation:



Displayed when a short circuit condition is detected on the Sub-Bus power lines



Displayed when a short circuit condition is detected on a valve coil



Displayed when a Sub-Bus module that had been previously installed becomes absent from the configuration





Displayed when +24 VDC on Pin No. 1 and No. 4 (Valves and Outputs) is not present or below 22 VDC




Displayed when +24 VDC on Pin No. 2 and No. 3 (Node and Inputs) is below 19 VDC

AVENTICS™ G3 Series EtherCAT™ Technical Manual

6. ARM – Auto Recovery Module (Optional)



ARM Module (Legacy)




ARM-Clip Module

The Auto Recovery Module (ARM) is an optional memory module that is installed between the node and the valve adapter module and is used to preserve the manifold system parameters even during catastrophic failure. During the power-up process it reads the configuration of the manifold, including any user settable parameters of I/O modules, and stores the information in its non-volatile memory. Once the information is stored, it automatically disconnects itself from the power circuits while still mechanically attached to the manifold.

<i>Description</i>	<i>Replacement Part Number</i>
ARM Module (Legacy)	240-182
ARM-Clip Module	240-383


AVENTICS™ G3 Series EtherCAT™ Technical Manual

6.1 ARM process flowchart



7. Distribution

Distribution of I/O capability can be easily achieved with the G3 platform by means of Sub-Bus modules. I/O modules, valve manifolds and/or a combination of both can be simply separated from the main manifold and distributed via a sub-bus communication cable. The G3 platform uses the same I/O modules on the main manifold as on the distribution chain. The main communication module can control up to 16 I/O modules either on the main manifold or as part of the sub-bus connections. To utilize the sub-bus distribution capabilities the Sub-Bus OUT module must be located on the end of the main communication manifold and a Terminator Module must be located at the last sub-bus component.



Detail No.	Description
1	Main Communication Module (Node)
2	Sub-Bus Power Cable (Can be connected to separate power supply for isolated power control)
3	Distributed Sub-Bus Valve Module
4	Sub-Bus IN module
5	Sub-Bus OUT module
6	Sub-Bus Communication Cable
7	I/O Modules
8	Terminator Module (Used to terminate sub-bus)
9	Aux. Power IN (Used to augment Input power and/or supply power to Output modules)
10	Aux. Power OUT (Can be used to supply power to distributed modules)




AVENTICS™ G3 Series EtherCAT™ Technical Manual

7.1 Sub-Bus Distribution Modules

SUB-BUS OUT Module

1. Used only when distributing the Sub-Bus to another assembly is required.
2. SUB-BUS OUT - 5 pin M12 female communication connector.
 - o Used to distribute the Sub-Bus to the next Sub-Bus assembly.
 - o Carries 24 VDC power for electronics of the next module.
3. AUX. POWER OUT - 4 pin M12 female aux. power connector.
 - o Optional connection.
 - o Used as a convenience way to distribute the power connection to the next Sub-Bus assembly.

Description	Replacement Part Number
Sub-Bus OUT Module with Din Rail Mounting	240-244
Sub-Bus OUT module without Din Rail Mounting	240-183






AVENTICS™ G3 Series EtherCAT™ Technical Manual

SUB-BUS IN Modules

- Used to distribute I/O assemblies that do not have valves
 - Must be installed to the right of the I/O modules.
- 4. SUB-BUS IN - 5 pin M12 male communication connector.
 - Must be connected to the Sub-Bus Out connector of the previous assembly
 - Carries 24 VDC power for electronics of module
- 5. AUX. POWER IN - 4 pin M12 male connector.
 - Aux power is required for Output modules. This connection also allows Output power to be interrupted to all Output modules connected to this module.
 - Aux. Power is optional for Inputs. Power from the SUN-BUS IN connection is used to power sensors but can be augmented, if necessary, by adding additional power to this connector.

Description	Part Number
Sub-Bus IN module with Din Rail Mounting	240-246
Sub-Bus IN module without Din Rail Mounting	240-185




AVENTICS™ G3 Series EtherCAT™ Technical Manual

Terminator Module

6. Used to terminate SUB-BUS connections.
 - o Must be installed on the left side of the last Sub-Bus module.

<i>Description</i>	<i>Part Number</i>
Terminator Module with Din Rail Mounting	240-245
Terminator Module without Din Rail Mounting	240-184





- *The terminator module is required to be installed in the G3 system for proper operation*

AVENTICS™ G3 Series EtherCAT™ Technical Manual

G3 Sub-Bus Valve Module

7. COMM - 5 pin M12 male Sub-Bus input communication connector.
 - o Must be connected to the SUB-BUS OUT connector of the previous assembly
 - o Carries 24 VDC power for electronics of module
8. POWER - 4 pin MINI male power connector.
 - o Power is required for Outputs
9. Used to distribute Valves on the Sub-Bus.
 - o Can accept discrete I/O module to allow a Sub-Bus Valve manifold with I/O

Description	Part Number
Sub-Bus Valve Module	240-241






• There is a 0.8 VDC drop in power across this module, consider this when distributing Aux. power.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

7.2 580 Series Sub-Bus Valve Module

10. COMM - 5 pin M12 male Sub-Bus communication connector.
 - o Must be connected to the SUB-BUS OUT connector of the previous assembly
 - o Carries 24 VDC power for electronics of module
11. POWER - 4 pin M12 male power connector.
 - o Power is required for Outputs
12. Used to distribute Valves on the Sub-Bus.
 - o Does not allow connection to G3 I/O modules.

Description	Part Number
Sub-Bus Valve Module without I/O	P580AEDS4010A00





AVENTICS™ G3 Series EtherCAT™ Technical Manual

7.3 Sub-Bus Hub Module

The G3 HUB module allows for branch distribution from the I/O side of the G3 System and can be integrated into the existing G3 Series Sub-Bus configuration. Auto Addressing allows for trouble free set up and configuration. Input, Output, as well as Valve manifolds can be attached to the available four Branches on a HUB module. Each G3 System can support up to two HUB modules, allowing for maximum flexibility. The HUB module is transparent to the I/O side of the G3 and does not reserve one of the potential sixteen positions.

13. Used when distributing the Sub-Bus to another assembly.
14. SUB-BUS OUT - 5 pin M12 female communication connector.
 - o Used to distribute the Sub-Bus to the next Sub-Bus assembly.
 - o Carries 24 VDC power (up to 3A) for electronics of the next module.
15. Cannot connect a Hub to a branch of another Hub
16. Each branch of the Hub can accommodate a sub-bus cable length of 30 meters.

Description	Part Number
Sub-Bus Hub Module	240-326



AVENTICS™ G3 Series EtherCAT™ Technical Manual

7.4 Sub-Bus Cables



M12 STRAIGHT 5 PIN MALE TO FEMALE SUB-BUS CABLE - SHIELDED

TA0501MGDTC0571P – 1 Meter

TA0505MGDTC0571P – 5 Meter

TA0510MGDTC0571P – 10 Meter



M12 STRAIGHT 5 PIN FEMALE FIELD WIREABLE CONNECTOR, SPRING CAGE

TC05F200000071V – PG9



M12 STRAIGHT 5 PIN MALE FIELD WIREABLE CONNECTOR, SPRING CAGE

TA05F200000071V – PG9



M12 90° 5 PIN FEMALE FIELD WIREABLE CONNECTOR, SPRING CAGE

TD05F200000071V – PG9



M12 90° 5 PIN MALE FIELD WIREABLE CONNECTOR, SPRING CAGE

TB05F200000071V – PG9



BULK SUB-BUS CABLE

*NOTE

000550MGD0005000 – 50 Meter Length

0005A0MGD0005000 – 100 Meter Length

* Note:

Length of field wired cables should not exceed the maximum length of 30 meters for total sub-bus communications link. See appropriate technical manual for sub-bus length requirements. The cable assemblies and Bulk cable are the only approved cables for the G3 Sub-Bus link. See technical document TDG3SBWD1-0EN for proper installation and wiring of field wireable connectors.

Technical Data

TECHNICAL DATA	CABLE	CONNECTORS	BULK CABLE
Molded Body / Insert	TPU	Zinc - Nickel Plated	N/A
Coupling Nut	Zinc - Nickel Plated	Brass - Nickel Plated	N/A
Cable Jacket Material	PUR	N/A	Gray RAL 7001
Cable O.D.	6.70 mm	N/A	6.70 mm
Voltage Rating (Nominal)	60 Volts	60 Volts	60 Volts
Current Rating	4.0 Amps	4.0 Amps	4.0 Amps
Degree of Protection	IP65 (mated)	IP65 (mated)	IP65 (terminated)
Operating Temperature	-40° C - 80° C	-40° C - 80° C	-20° C - 75° C
Conductor Gauge	24 AWG Signal 22 AWG Power	26-20 AWG	24 AWG Signal 22 AWG Power
Bend Radius	67 mm	N/A	67 mm
No. of Bending Cycles	5 Million	N/A	5 Million

AVENTICS™ G3 Series EtherCAT™ Technical Manual

7.5 G3 Sub-Bus Field Wiring Directions

The purpose of this document is to instruct the end user of the proper wiring techniques required to make a G3 Sub-Bus cable from the available bulk cable and field wireable ends. The effectiveness of the resultant assembly remains on the end user and may have bearing on the proper functionality of the G3 Sub-Bus operation; please follow the manufacturer's Cable Assembly Procedure properly.





Cable Assembly Procedure

- Step No.1 Cut cable to desired length.
- Step No.2 Run cable through Pressure Nut and Housing.
- Step No.3 Strip cable jacket back 28mm (1.10") for straight connectors and 35mm (1.38") for 90° connectors.
- Step No.4 Remove shielding from end of wires back approximately 16mm (.630").
- Step No.5 Apply shielding foil provided, around the shortened end of the shielding.
- Step No.6 Strip individual conductors back approximately 11mm (.433").
- Step No.7 Push stranded wires into appropriate colored terminal.
- Step No.8 Attach the connector body onto the housing and tighten.
- Step No.9 Attach the pressure nut on the back side and tighten
- Step No.10 Confirm Continuity between all pins.



- 1 = Shield Wire (must be connected)
- 2 = Red
- 3 = Black
- 4 = White
- 5 = Blue



AVENTICS™ G3 Series EtherCAT™ Technical Manual

8. Digital I/O Module


8.1 Digital I/O Module Usage

The maximum number of modules that can be used on the Discrete I/O side of the manifold is 16. These modules can be centralized on the main fieldbus manifold, distributed or a combination of both. Modules can be connected in any combination of inputs, outputs and specialty up to the physical limitation of 16 modules.


Input Module Types




Output Module Types



Input/Output Module Types




Valve Side Output Module Types



AVENTICS™ G3 Series EtherCAT™ Technical Manual

8.2 I/O Module Technical Data


Module No.	Description	Connector Type	Current Limitation for Module	Current Limitation for connector	Current Limitation for manifold assy.	
240-203	16 PNP Inputs	Terminal Strip	1.2A	.30A for each +24VDC terminal	4A for +24 Valves and Outputs 4A for +24 Node and Inputs	
240-204	16 NPN Inputs					
240-379	8 PNP Inputs					
240-205	16 PNP Inputs					
240-206	8 PNP Inputs					
240-207	16 PNP Outputs					
240-208	8 PNP Outputs					
240-209	16 NPN Inputs					
240-210	8 NPN Inputs	M12	1.2A	.15A (Pin 1 to Pin 3)	4A for +24 Valves and Outputs 4A for +24 Node and Inputs	
240-211	8 PNP Input and 8 PNP Outputs					
240-212	Analog IO modules					
240-213						
240-214						
240-215						
240-300	8 High Current Outputs	M12	8A (From Aux. Power Conn.)	2.0A / output connector (1.0A Pin 3 to Pin 2) (1.0A Pin 3 to Pin 4)	N/A	
240-307	2 Analog Inputs and 2 High Current Analog Voltage Outputs			4A (From Aux. Power Conn.)	2.0A (Pin 3 to Pin 4)	N/A
240-311	RTD			N/A	N/A	4A for +24 Valves and Outputs 4A for +24 Node and Inputs
240-316	8 PNP Inputs	Terminal Strip	1.2A	.30A for each +24VDC terminal	4A for +24 Valves and Outputs 4A for +24 Node and Inputs	
240-323	16 PNP Inputs					
240-330	16 PNP Outputs					
240-363	4 Analog Inputs and 4 High Current Analog Outputs	M12	8A (From Aux. Power Conn.)	2.0A (Pin 1 to Pin 3)	N/A	



AVENTICS™ G3 Series EtherCAT™ Technical Manual

8.3 I/O Module Descriptions and Menus

Detail No.	Description
1	"Set" Button – used to navigate through user menus and set parameters
2	Module Function (I/O Type)
3	Alignment arrow for SPEEDCON connector
4	Bit Designation for I/O
5	"Next" Button – used to navigate through user menus and set parameters
6	Graphic Display
7	5 Pin M12 female I/O connector
8	Connector designation
9	Metal threads for SPEEDCON connector
10	Slot for text ID tags
11	Dust Cover
12	Mounting hole



• All dust covers must be tightened to a torque of 4-6 in. lbs. to maintain the IP65 integrity.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

8.4 Digital Input Modules


One Digital Input per Connector – M8 Female Modules

Module Part No.	I/O Type		Short Circuit Protection		Short Circuit Protection Status Bits		Input Points	
240-379	PNP (Sourcing)		YES – Visual		YES – Optional		8	
Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Required)	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1	Input 0
Diagnostics								
X (Selectable)	Conn. H SCP Status	Conn. G SCP Status	Conn. F SCP Status	Conn. E SCP Status	Conn. D SCP Status	Conn. C SCP Status	Conn. B SCP Status	Conn. A SCP Status



FEMALE

PIN 1= +24VDC (UNSW)
 PIN 3= 0VDC (UNSW)
 PIN 4= INPUT





An external terminating resistor, p/n: TA05TR000000000, is required when the 240-379 is the last I/O module on the sub-bus.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

One Digital Input per Connector – M12 Female Modules

Module Part No.	I/O Type	Short Circuit Protection	Short Circuit Protection Status Bits	Input Points
240-210	NPN (Sinking)	YES	YES	8
240-206	PNP (Sourcing)			

Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1	Input 0
Diagnostic Telegram								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Conn. H SCP Status	Conn. G SCP Status	Conn. F SCP Status	Conn. E SCP Status	Conn. D SCP Status	Conn. C SCP Status	Conn. B SCP Status	Conn. A SCP Status





AVENTICS™ G3 Series EtherCAT™ Technical Manual

Two Digital Inputs per Connector – M12 Female Modules

Module Part No.	I/O Type	Short Circuit Protection	Short Circuit Protection Status Bits	Input Points
240-209	NPN (Sinking)	YES	YES	16
240-205	PNP (Sourcing)			

Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1	Input 0
X+1	Input 15	Input 14	Input 13	Input 12	Input 11	Input 10	Input 9	Input 8
Diagnostic Telegram								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Conn. H SCP Status	Conn. G SCP Status	Conn. F SCP Status	Conn. E SCP Status	Conn. D SCP Status	Conn. C SCP Status	Conn. B SCP Status	Conn. A SCP Status



AVENTICS™ G3 Series EtherCAT™ Technical Manual



Sixteen Digital Inputs – Terminal Strip Modules

Specifications

- Wire Range: 12 to 24 AWG
- Strip Length: 7mm
- Tightening Torque: 0.5 Nm

Module Part No.	I/O Type	Short Circuit Protection	Short Circuit Protection Status Bits	Input Points
240-203	PNP (Sourcing)	YES	YES	16
240-204	NPN (Sinking)			

Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1	Input 0
X+1	Input 15	Input 14	Input 13	Input 12	Input 11	Input 10	Input 9	Input 8
Diagnostic Telegram								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	D+ SCP Status	C+ SCP Status	B+ SCP Status	A+ SCP Status






AVENTICS™ G3 Series EtherCAT™ Technical Manual

Intrinsically safe [Ex ia] NAMUR Compatible Input Module One Digital Input per Connector – M12 Female

Input module is for use with NAMUR certified intrinsically safe (IS) sensors. The module can be placed in any G3 I/O position available but must be used in conjunction with appropriate clips with partition plates (see picture on page 8-71). This module is for use with (IS) sensors (certified to EN 60947-5-6) where the sensor is placed within the hazardous area, (e.g. ATEX 0-20, 1-21, and 2-22). This [Ex ia] module is part of the G3 electronics platform, which is designed to reside outside of the hazardous environment or in Zone 2-22, inside of a cabinet with appropriate ingress protection. The partition plate clips, used between standard G3 modules and [Ex ia] modules, are required to maintain ATEX approval. The 8.2 V sensor supply for each input connector is short circuit protected.

Part Numbers and Mapping




Module Part No.	I/O Type	Short Circuit /Open Circuit Protection		Short Circuit /Open Circuit Present Status Bits		Input Points		
240-320	NAMUR	YES - Visual		YES - Optional		8		
Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Required)	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1	Input 0
X	Conn. H SC Status	Conn. G SC Status	Conn. F SC Status	Conn. E SC Status	Conn. D SC Status	Conn. C SC Status	Conn. B SC Status	Conn. A SC Status
X + 1	Conn. H Open Status	Conn. G Open Status	Conn. F Open Status	Conn. E Open Status	Conn. D Open Status	Conn. C Open Status	Conn. B Open Status	Conn. A Open Status



AVENTICS™ G3 Series EtherCAT™ Technical Manual

Intrinsically safe [Ex ia] NAMUR Compatible Input terminal strip module


Module Part No.	I/O Type	Short Circuit /Open Circuit Protection		Short Circuit /Open Circuit Present Status Bits		Input Points		
240-322	NAMUR	YES - Visual		YES - Optional		8		
Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Required)	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1	Input 0
X	Conn. H SC Status	Conn. G SC Status	Conn. F SC Status	Conn. E SC Status	Conn. D SC Status	Conn. C SC Status	Conn. B SC Status	Conn. A SC Status
X + 1	Conn. H Open Status	Conn. G Open Status	Conn. F Open Status	Conn. E Open Status	Conn. D Open Status	Conn. C Open Status	Conn. B Open Status	Conn. A Open Status




AVENTICS™ G3 Series EtherCAT™ Technical Manual

Intrinsically safe [Ex ia] Support Modules


Mechanical isolation between standard and [Ex ia] modules is mandatory to fulfill ATEX certification. Clips with Partition Plates are available to achieve the required isolation.



G3 [Ex ia] Clip 240-317



G3 [Ex ia] Sub-Bus Out 240-318



G3 [Ex ia] Sub-Bus In 240-319

AVENTICS™ G3 Series EtherCAT™ Technical Manual


19 Pin M23 Input Module

The 19 Pin M23 Input module is for use with any Input block available from Phoenix Contact, Turck, Brad Harrison, etc. It can also be used with a single ended 19 Pin Cable.

Part Numbers and Mapping


Module Part No.	I/O Type	Short Circuit /Open Circuit Protection	Short Circuit /Open Circuit Present Status Bits	Input Points
240-323	Digital	YES - Visual	YES - Optional	16

Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Required)	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1	Input 0
X	Input 15	Input 14	Input 13	Input 12	Input 11	Input 10	Input 9	Input 8
X + 1	Short Circuit	Short Circuit	Short Circuit	Short Circuit	Short Circuit	Short Circuit	Short Circuit	Short Circuit



Pin Out Information

- | | |
|-------------------|-------------------|
| Pin 1 = Input 14 | Pin 11 = Input 12 |
| Pin 2 = Input 10 | Pin 12 = P.E. |
| Pin 3 = Input 6 | Pin 13 = Input 11 |
| Pin 4 = Input 3 | Pin 14 = Input 7 |
| Pin 5 = Input 2 | Pin 15 = Input 0 |
| Pin 6 = 0 VDC | Pin 16 = Input 4 |
| Pin 7 = Input 1 | Pin 17 = Input 8 |
| Pin 8 = Input 5 | Pin 18 = Input 15 |
| Pin 9 = Input 9 | Pin 19 = + 24 |
| VDC | |
| Pin 10 = Input 13 | |





AVENTICS™ G3 Series EtherCAT™ Technical Manual

8.5 Digital Output Modules

One Digital Output per Connector - M12 Female Modules

Module Part No.	I/O Type	Short Circuit Protection	Short Circuit Protection Status Bits	Output Points
240-208	PNP (Sourcing)	YES	YES	8

Output Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1	Output 0
Diagnostic Telegram								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Output 7 Status	Output 6 Status	Output 5 Status	Output 4 Status	Output 3 Status	Output 2 Status	Output 1 Status	Output 0 Status





AVENTICS™ G3 Series EtherCAT™ Technical Manual

Two Digital Outputs per Connector - M12 Female Modules

Module Part No.	I/O Type	Short Circuit Protection	Short Circuit Protection Status Bits	Output Points
240-207	PNP (Sourcing)	YES	YES	16

Output Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1	Output 0
X+1	Output 15	Output 14	Output 13	Output 12	Output 11	Output 10	Output 9	Output 8

Diagnostic Telegram								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Output 7 Status	Output 6 Status	Output 5 Status	Output 4 Status	Output 3 Status	Output 2 Status	Output 1 Status	Output 0 Status
X+1 (Selectable)	Output 15 Status	Output 14 Status	Output 13 Status	Output 12 Status	Output 11 Status	Output 10 Status	Output 9 Status	Output 8 Status



FEMALE

PIN 1= +24VDC (SW)
 PIN 2= OUTPUT 2
 PIN 3= 0VDC (SW)
 PIN 4= OUTPUT 1

AVENTICS™ G3 Series EtherCAT™ Technical Manual



Sixteen Digital Outputs – Terminal Strip Modules

Specifications

- Wire Range: 12 to 24 AWG
- Strip Length: 7mm
- Tightening Torque: 0.5 Nm

Module Part No.	I/O Type	Short Circuit Protection	Short Circuit Protection Status Bits	Output Points
240-330	PNP (Sourcing)	YES	YES	16

Output Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1	Output 0
X+1	Output 15	Output 14	Output 13	Output 12	Output 11	Output 10	Output 9	Output 8
Diagnostic Telegram								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Output 7 Status	Output 6 Status	Output 5 Status	Output 4 Status	Output 3 Status	Output 2 Status	Output 1 Status	Output 0 Status
X (Selectable)	Output 15 Status	Output 14 Status	Output 13 Status	Output 12 Status	Output 11 Status	Output 10 Status	Output 9 Status	Output 8 Status






AVENTICS™ G3 Series EtherCAT™ Technical Manual

Two Digital High Current Outputs per Connector - M12 Female Modules

The high current output module is to be used with output devices requiring between 0.5 and 1.0 Amps. Each connector incorporates two outputs that are capable of sourcing 1.0 Amp per output.

Module Part No.	I/O Type		Short Circuit Protection		Short Circuit Protection Status Bits		Output Points	
240-300	PNP (Sourcing)		YES		YES		8	
Output Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1	Output 0
Diagnostic Telegram								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Output 7 Status	Output 6 Status	Output 5 Status	Output 4 Status	Output 3 Status	Output 2 Status	Output 1 Status	Output 0 Status




AVENTICS™ G3 Series EtherCAT™ Technical Manual

8.6 Digital Input/Output Modules

Two Digital I/O per Connector – M12 Female Modules

Module Part No.	I/O Type	Short Circuit Protection	Short Circuit Protection Status Bits	Output Points	Input Points
240-211	PNP (Sourcing)	YES	YES	8	8

Output Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1	Output 0
Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1	Input 0
Diagnostic Telegram								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Conn. D SCP Status	Conn. C SCP Status	Conn. B SCP Status	Conn. A SCP Status
X+1 (Selectable)	Output 7 Status	Output 6 Status	Output 5 Status	Output 4 Status	Output 3 Status	Output 2 Status	Output 1 Status	Output 0 Status



CONNECTORS E, F, G, & H	CONNECTORS A, B, C, & D
PIN 1= +24VDC (SW)	PIN 1= +24VDC (UNSW)
PIN 2= OUTPUT 2	PIN 2= INPUT 2
PIN 3= 0VDC (SW)	PIN 3= 0VDC (UNSW)
PIN 4= OUTPUT 1	PIN 4= INPUT 1

9. Valve Interface Modules



9.1 2000 Series & 500 Series Valve Driver

Output Data Mapping

Interface to control valves from a G3 communication module.

Module Part No.	I/O Type	Short Circuit Protection	Short Circuit Protection Status Bits	Output Points
219-828	NPN (Sinking) 2000 Series	YES – Visual	YES (32) – Optional	32
P599AE42518801	NPN (Sinking) 500 Series	YES – Visual	YES (128) – Optional	128

Output Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Required)	Valve Coil No. 7	Valve Coil No. 6	Valve Coil No. 5	Valve Coil No. 4	Valve Coil No. 3	Valve Coil No. 2	Valve Coil No. 1	Valve Coil No. 0
X+1 (Selectable)	Valve Coil No. 15	Valve Coil No. 14	Valve Coil No. 13	Valve Coil No. 12	Valve Coil No. 11	Valve Coil No. 10	Valve Coil No. 9	Valve Coil No. 8
X+2 (Selectable)	Valve Coil No. 23	Valve Coil No. 22	Valve Coil No. 21	Valve Coil No. 20	Valve Coil No. 19	Valve Coil No. 18	Valve Coil No. 17	Valve Coil No. 16
X+3 (Selectable)	Valve Coil No. 31	Valve Coil No. 30	Valve Coil No. 29	Valve Coil No. 28	Valve Coil No. 27	Valve Coil No. 26	Valve Coil No. 25	Valve Coil No. 24
32 additional coils available per each additional 32+ manifold driver board								
X+4 (Selectable)	Valve Coil No. 39	Valve Coil No. 38	Valve Coil No. 37	Valve Coil No. 36	Valve Coil No. 35	Valve Coil No. 34	Valve Coil No. 33	Valve Coil No. 32
X+5 (Selectable)	Valve Coil No. 47	Valve Coil No. 46	Valve Coil No. 45	Valve Coil No. 44	Valve Coil No. 43	Valve Coil No. 42	Valve Coil No. 41	Valve Coil No. 40
X+6 (Selectable)	Valve Coil No. 55	Valve Coil No. 54	Valve Coil No. 53	Valve Coil No. 52	Valve Coil No. 51	Valve Coil No. 50	Valve Coil No. 49	Valve Coil No. 48
X+7 (Selectable)	Valve Coil No. 63	Valve Coil No. 62	Valve Coil No. 61	Valve Coil No. 60	Valve Coil No. 59	Valve Coil No. 58	Valve Coil No. 57	Valve Coil No. 56
32 additional coils available per each additional 32+ manifold driver board								
X+15 (Selectable)	Valve Coil No. 127	Valve Coil No. 126	Valve Coil No. 125	Valve Coil No. 124	Valve Coil No. 123	Valve Coil No. 122	Valve Coil No. 121	Valve Coil No. 120



AVENTICS™ G3 Series EtherCAT™ Technical Manual

Diagnostic Data Mapping

Module Part No.	I/O Type	Short Circuit Protection	Short Circuit Protection Status Bits	Output Points
219-828	NPN (Sinking) 2000 Series	YES – Visual	YES (32) – Optional	32
P599AE42518801	NPN (Sinking) 500 Series	YES – Visual	YES (128) – Optional	128

BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Coil 7 Status	Coil 6 Status	Coil 5 Status	Coil 4 Status	Coil 3 Status	Coil 2 Status	Coil 1 Status	Coil 0 Status
X+1	Coil 15 Status	Coil 14 Status	Coil 13 Status	Coil 12 Status	Coil 11 Status	Coil 10 Status	Coil 9 Status	Coil 8 Status
X+2	Coil 23 Status	Coil 22 Status	Coil 21 Status	Coil 20 Status	Coil 19 Status	Coil 18 Status	Coil 17 Status	Coil 16 Status
X+3	Coil 31 Status	Coil 30 Status	Coil 29 Status	Coil 28 Status	Coil 27 Status	Coil 26 Status	Coil 25 Status	Coil 24 Status
32 additional coil status bits per each additional 32+ manifold driver board								
X+4	Coil 39 Status	Coil 38 Status	Coil 37 Status	Coil 36 Status	Coil 35 Status	Coil 34 Status	Coil 33 Status	Coil 32 Status
X+5	Coil 47 Status	Coil 46 Status	Coil 45 Status	Coil 44 Status	Coil 43 Status	Coil 42 Status	Coil 41 Status	Coil 40 Status
X+6	Coil 55 Status	Coil 54 Status	Coil 53 Status	Coil 52 Status	Coil 51 Status	Coil 50 Status	Coil 49 Status	Coil 48 Status
X+7	Coil 63 Status	Coil 62 Status	Coil 61 Status	Coil 60 Status	Coil 59 Status	Coil 58 Status	Coil 57 Status	Coil 56 Status
128 coil status bits possible								
X+15	Coil 127 Status	Coil 126 Status	Coil 125 Status	Coil 124 Status	Coil 123 Status	Coil 122 Status	Coil 121 Status	Coil 120 Status


AVENTICS™ G3 Series EtherCAT™ Technical Manual

9.2 Sub-bus Valve Module

Output Data Mapping

Used to control a distributed valve manifold through the Sub-Bus.

Module Part No.	I/O Type		Short Circuit Protection		Status Bit Data		Output Points	
240-241	NPN (Sinking)		YES – Visual		YES (128) – Optional		128	
Output Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Required)	Valve Coil No. 7	Valve Coil No. 6	Valve Coil No. 5	Valve Coil No. 4	Valve Coil No. 3	Valve Coil No. 2	Valve Coil No. 1	Valve Coil No. 0
X+1 (Selectable)	Valve Coil No. 15	Valve Coil No. 14	Valve Coil No. 13	Valve Coil No. 12	Valve Coil No. 11	Valve Coil No. 10	Valve Coil No. 9	Valve Coil No. 8
X+2 (Selectable)	Valve Coil No. 23	Valve Coil No. 22	Valve Coil No. 21	Valve Coil No. 20	Valve Coil No. 19	Valve Coil No. 18	Valve Coil No. 17	Valve Coil No. 16
X+3 (Selectable)	Valve Coil No. 31	Valve Coil No. 30	Valve Coil No. 29	Valve Coil No. 28	Valve Coil No. 27	Valve Coil No. 26	Valve Coil No. 25	Valve Coil No. 24
32 additional coils available per each additional 32+ manifold driver board								
X+4 (Selectable)	Valve Coil No. 39	Valve Coil No. 38	Valve Coil No. 37	Valve Coil No. 36	Valve Coil No. 35	Valve Coil No. 34	Valve Coil No. 33	Valve Coil No. 32
X+5 (Selectable)	Valve Coil No. 47	Valve Coil No. 46	Valve Coil No. 45	Valve Coil No. 44	Valve Coil No. 43	Valve Coil No. 42	Valve Coil No. 41	Valve Coil No. 40
X+6 (Selectable)	Valve Coil No. 55	Valve Coil No. 54	Valve Coil No. 53	Valve Coil No. 52	Valve Coil No. 51	Valve Coil No. 50	Valve Coil No. 49	Valve Coil No. 48
X+7 (Selectable)	Valve Coil No. 63	Valve Coil No. 62	Valve Coil No. 61	Valve Coil No. 60	Valve Coil No. 59	Valve Coil No. 58	Valve Coil No. 57	Valve Coil No. 56
128 coils total possible								
X+15 (Selectable)	Valve Coil No. 127	Valve Coil No. 126	Valve Coil No. 125	Valve Coil No. 124	Valve Coil No. 123	Valve Coil No. 122	Valve Coil No. 121	Valve Coil No. 120



AVENTICS™ G3 Series EtherCAT™ Technical Manual

Diagnostic Data Mapping

Module Part No.	I/O Type		Short Circuit Protection		Status Bit Data		Output Points	
240-241	NPN (Sinking)		YES – Visual		YES (128) – Optional		128	
Diagnostics								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Coil 7 Status	Coil 6 Status	Coil 5 Status	Coil 4 Status	Coil 3 Status	Coil 2 Status	Coil 1 Status	Coil 0 Status
X+1	Coil 15 Status	Coil 14 Status	Coil 13 Status	Coil 12 Status	Coil 11 Status	Coil 10 Status	Coil 9 Status	Coil 8 Status
X+2	Coil 23 Status	Coil 22 Status	Coil 21 Status	Coil 20 Status	Coil 19 Status	Coil 18 Status	Coil 17 Status	Coil 16 Status
X+3	Coil 31 Status	Coil 30 Status	Coil 29 Status	Coil 28 Status	Coil 27 Status	Coil 26 Status	Coil 25 Status	Coil 24 Status
32 additional coil status bits per each additional 32+ manifold driver board								
X+4	Coil 39 Status	Coil 38 Status	Coil 37 Status	Coil 36 Status	Coil 35 Status	Coil 34 Status	Coil 33 Status	Coil 32 Status
X+5	Coil 47 Status	Coil 46 Status	Coil 45 Status	Coil 44 Status	Coil 43 Status	Coil 42 Status	Coil 41 Status	Coil 40 Status
X+6	Coil 55 Status	Coil 54 Status	Coil 53 Status	Coil 52 Status	Coil 51 Status	Coil 50 Status	Coil 49 Status	Coil 48 Status
X+7	Coil 63 Status	Coil 62 Status	Coil 61 Status	Coil 60 Status	Coil 59 Status	Coil 58 Status	Coil 57 Status	Coil 56 Status
128 coil status bits possible								
X+15	Coil 127 Status	Coil 126 Status	Coil 125 Status	Coil 124 Status	Coil 123 Status	Coil 122 Status	Coil 121 Status	Coil 120 Status




AVENTICS™ G3 Series EtherCAT™ Technical Manual

9.3 Sub-bus Valve Module without Distribution

Used to control a distributed valve manifold through the Sub-Bus.

Module Part No.	I/O Type	Short Circuit Protection	Status Bit Data	Output Points				
P580AEDS4010A00	NPN (Sinking)	YES – Visual	YES (128) – Optional	128				
Output Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Required)	Valve Coil No. 7	Valve Coil No. 6	Valve Coil No. 5	Valve Coil No. 4	Valve Coil No. 3	Valve Coil No. 2	Valve Coil No. 1	Valve Coil No. 0
X+1 (Selectable)	Valve Coil No. 15	Valve Coil No. 14	Valve Coil No. 13	Valve Coil No. 12	Valve Coil No. 11	Valve Coil No. 10	Valve Coil No. 9	Valve Coil No. 8
X+2 (Selectable)	Valve Coil No. 23	Valve Coil No. 22	Valve Coil No. 21	Valve Coil No. 20	Valve Coil No. 19	Valve Coil No. 18	Valve Coil No. 17	Valve Coil No. 16
X+3 (Selectable)	Valve Coil No. 31	Valve Coil No. 30	Valve Coil No. 29	Valve Coil No. 28	Valve Coil No. 27	Valve Coil No. 26	Valve Coil No. 25	Valve Coil No. 24
32 additional coils available per each additional 32+ manifold driver board								
X+4 (Selectable)	Valve Coil No. 39	Valve Coil No. 38	Valve Coil No. 37	Valve Coil No. 36	Valve Coil No. 35	Valve Coil No. 34	Valve Coil No. 33	Valve Coil No. 32
X+5 (Selectable)	Valve Coil No. 47	Valve Coil No. 46	Valve Coil No. 45	Valve Coil No. 44	Valve Coil No. 43	Valve Coil No. 42	Valve Coil No. 41	Valve Coil No. 40
X+6 (Selectable)	Valve Coil No. 55	Valve Coil No. 54	Valve Coil No. 53	Valve Coil No. 52	Valve Coil No. 51	Valve Coil No. 50	Valve Coil No. 49	Valve Coil No. 48
X+7 (Selectable)	Valve Coil No. 63	Valve Coil No. 62	Valve Coil No. 61	Valve Coil No. 60	Valve Coil No. 59	Valve Coil No. 58	Valve Coil No. 57	Valve Coil No. 56
128 coils total possible								
X+15 (Selectable)	Valve Coil No. 127	Valve Coil No. 126	Valve Coil No. 125	Valve Coil No. 124	Valve Coil No. 123	Valve Coil No. 122	Valve Coil No. 121	Valve Coil No. 120



AVENTICS™ G3 Series EtherCAT™ Technical Manual

Used to control a distributed valve manifold through the Sub-Bus.

Module Part No.	I/O Type		Short Circuit Protection			Status Bit Data		Output Points
P580AEDS4010A00	NPN (Sinking)		YES – Visual			YES (128) – Optional		128
Diagnostics								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Coil 7 Status	Coil 6 Status	Coil 5 Status	Coil 4 Status	Coil 3 Status	Coil 2 Status	Coil 1 Status	Coil 0 Status
X+1	Coil 15 Status	Coil 14 Status	Coil 13 Status	Coil 12 Status	Coil 11 Status	Coil 10 Status	Coil 9 Status	Coil 8 Status
X+2	Coil 23 Status	Coil 22 Status	Coil 21 Status	Coil 20 Status	Coil 19 Status	Coil 18 Status	Coil 17 Status	Coil 16 Status
X+3	Coil 31 Status	Coil 30 Status	Coil 29 Status	Coil 28 Status	Coil 27 Status	Coil 26 Status	Coil 25 Status	Coil 24 Status
32 additional coil status bits per each additional 32+ manifold driver board								
X+4	Coil 39 Status	Coil 38 Status	Coil 37 Status	Coil 36 Status	Coil 35 Status	Coil 34 Status	Coil 33 Status	Coil 32 Status
X+5	Coil 47 Status	Coil 46 Status	Coil 45 Status	Coil 44 Status	Coil 43 Status	Coil 42 Status	Coil 41 Status	Coil 40 Status
X+6	Coil 55 Status	Coil 54 Status	Coil 53 Status	Coil 52 Status	Coil 51 Status	Coil 50 Status	Coil 49 Status	Coil 48 Status
X+7	Coil 63 Status	Coil 62 Status	Coil 61 Status	Coil 60 Status	Coil 59 Status	Coil 58 Status	Coil 57 Status	Coil 56 Status
128 coil status bits possible								
X+14	Coil 127 Status	Coil 126 Status	Coil 125 Status	Coil 124 Status	Coil 123 Status	Coil 122 Status	Coil 121 Status	Coil 120 Status

AVENTICS™ G3 Series EtherCAT™ Technical Manual


9.4 Valve Side Output Module

The valve side output module is used to distribute available valve side output points (i.e. when valves are located away from the rest of the electronics). These modules go to the right of the G3 valve adapter. The 16 bit output module utilizes the last 16 output bits on the valve side of the manifold (bits 16-31).

This module is not available with the 501, 502 or 503 series valves.

Sixteen Outputs per Connector - Sub-D 25 Pin Female Module

Module Part No.	I/O Type	Short Circuit Protection	Internal Status Bits	Output Points	Module Size
239-1713	NPN (Sinking)	Yes	16 – Optional	16	Narrow



AVENTICS™ G3 Series EtherCAT™ Technical Manual

9.5 500 Series Extended Coil Capability

The Extended Coil manifolds must be connected to a G3 Electronics Node to operate. Not all G3 supported protocols will support the Extended Coil Manifolds. Below is a list of the hardware and minimum firmware levels that support the Extended Coil Manifolds.

Extended Solenoid Coil Capability requirements:		
<u>Module</u>	<u>Part Number</u>	<u>Firmware</u>
Communication Module	240-310	Rev 1.01 Build 42509
Valve Driver Module	P599AE508827001	Rev 4.019

Module firmware revision levels can be confirmed in the integrated graphic display and the built-in web browser. See pg. 5-48 for more information.

9.6 Extended Coil Configuration

The Extended Coil Manifold can be configured to control 3 additional extended coil valve driver assemblies; unless already configured from the factory. Modify the configuration with either the graphic display interface as shown on page 5-34 or using the integrated web server configuration page shown on page 9-85.

Valve Series	Number of Extended Coil Valve Drivers	Total number of coils	Configuration Selection	Allocated number of I/O Bytes designated for valves
501	0	3-32	32 coils	4
	1	33-64	64 coils	8
	2	65-96	96 coils	12
	3	97-128	128 coils	16
502/503	0	1-32	32 coils	4
	1	33-48	64 coils	8
	2	49-64	64 coils	8
	3	65-80	96 coils	12

AVENTICS™ G3 Series EtherCAT™ Technical Manual

The following example of the G3 diagnostic webpage “Node Configuration” identifies the details of a manifold configured for 64 possible coils.



Number of Maximum Coils should only be adjusted if 1 or more additional extended coil valve driver(s) has been physically added.

Node Configuration	
(Green selections denote Factory Default settings)	
Station Alias:	<input type="text" value="3"/>
Web Server:	<input type="button" value="Enabled"/> ▼
Max Coils on Manifold (32 = Standard):	<input type="button" value="32"/> ▼
Safety Zones (Only configurable when Max Coils = 32):	<input type="button" value="None"/> ▼
COMM Fault / Idle Mode:	<input type="button" value="Turn OFF All Outputs"/> ▼
Diagnostic Word:	<input type="button" value="Mapped"/> ▼
I/O (Diagnostics) Status:	<input type="button" value="Mapped"/> ▼
Node Configuration Parameters:	<input type="button" value="Unlocked"/> ▼
I/O Configuration:	<input type="button" value="Unlocked"/> ▼
Display Orientation (Global):	<input type="button" value="Normal"/> ▼
Display Brightness (Global):	<input type="button" value="Medium"/> ▼


AVENTICS™ G3 Series EtherCAT™ Technical Manual

The following is an example of the G3 diagnostic webpage “Diagnostics” which identifies the details of the valve driver’s control of 64 possible coils



[Home](#)
[Node Configuration](#)
[Node Password](#)
[Diagnostics](#)
[Quick Start Manual](#)
[Download XML](#)
[Help](#)

Module	Part No.	Description	Details	Export Config and Log	Activity
Node	240-310	EtherCAT Communications Module	<input type="checkbox"/> Show Details		Close all Details ✓
Valve Driver	P599AE42518800x	50X Series Valve Driver Output Module	<input checked="" type="checkbox"/> Show Details		Close all Details ✓

	Firmware Revision:	4.19							
	<input checked="" type="checkbox"/> Show Valve Coils 0-31: Check/Uncheck box to force/un-force valve coil	0 <input type="checkbox"/>	1 <input type="checkbox"/>	2 <input type="checkbox"/>	3 <input type="checkbox"/>	4 <input type="checkbox"/>	5 <input type="checkbox"/>	6 <input type="checkbox"/>	7 <input type="checkbox"/>
		8 <input type="checkbox"/>	9 <input type="checkbox"/>	10 <input type="checkbox"/>	11 <input type="checkbox"/>	12 <input type="checkbox"/>	13 <input type="checkbox"/>	14 <input type="checkbox"/>	15 <input type="checkbox"/>
		16 <input type="checkbox"/>	17 <input type="checkbox"/>	18 <input type="checkbox"/>	19 <input type="checkbox"/>	20 <input type="checkbox"/>	21 <input type="checkbox"/>	22 <input type="checkbox"/>	23 <input type="checkbox"/>
		24 <input type="checkbox"/>	25 <input type="checkbox"/>	26 <input type="checkbox"/>	27 <input type="checkbox"/>	28 <input type="checkbox"/>	29 <input type="checkbox"/>	30 <input type="checkbox"/>	31 <input type="checkbox"/>
	Valve Status: ● = Shorted Coil ● = Open Coil ✕ = No Coil Detected	0 ✕	1 ✕	2 ✕	3 ✕	4 ✕	5 ✕	6 ✕	7 ✕
		8 ✕	9 ✕	10 ✕	11 ✕	12 ✕	13 ✕	14 ✕	15 ✕
		16 ✕	17 ✕	18 ✕	19 ✕	20 ✕	21 ✕	22 ✕	23 ✕
		24 ✕	25 ✕	26 ✕	27 ✕	28 ✕	29 ✕	30 ✕	31 ✕
	<input checked="" type="checkbox"/> Show Valve Coils 32-47: Check/Uncheck box to force/un-force valve coil	32 <input type="checkbox"/>	33 <input type="checkbox"/>	34 <input type="checkbox"/>	35 <input type="checkbox"/>	36 <input type="checkbox"/>	37 <input type="checkbox"/>	38 <input type="checkbox"/>	39 <input type="checkbox"/>
40 <input type="checkbox"/>		41 <input type="checkbox"/>	42 <input type="checkbox"/>	43 <input type="checkbox"/>	44 <input type="checkbox"/>	45 <input type="checkbox"/>	46 <input type="checkbox"/>	47 <input type="checkbox"/>	
32 ●		33 ●	34 ●	35 ●	36 ●	37 ●	38 ●	39 ●	
Valve Status: ● = Shorted Coil ● = Open Coil ✕ = No Coil Detected	40 ●	41 ●	42 ●	43 ●	44 ●	45 ●	46 ●	47 ●	
	<input type="checkbox"/> Show I/O Mappings and Sizes								

<input type="checkbox"/> Show Error/Event Log

AVENTICS™ G3 Series EtherCAT™ Technical Manual

9.7 Extended Coil Valve Driver Mapping

IO Mapping for each additional 501 series 32 coil valve driver added to the manifold assembly

Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Coil 7 Status	Coil 6 Status	Coil 5 Status	Coil 4 Status	Coil 3 Status	Coil 2 Status	Coil 1 Status	Coil 0 Status
X+1	Coil 15 Status	Coil 14 Status	Coil 13 Status	Coil 12 Status	Coil 11 Status	Coil 10 Status	Coil 9 Status	Coil 8 Status
X+2	Coil 23 Status	Coil 22 Status	Coil 21 Status	Coil 20 Status	Coil 19 Status	Coil 18 Status	Coil 17 Status	Coil 16 Status
X+3	Coil 31 Status	Coil 30 Status	Coil 29 Status	Coil 28 Status	Coil 27 Status	Coil 26 Status	Coil 25 Status	Coil 24 Status

Output Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Valve Coil No. 7	Valve Coil No. 6	Valve Coil No. 5	Valve Coil No. 4	Valve Coil No. 3	Valve Coil No. 2	Valve Coil No. 1	Valve Coil No. 0
X+1	Valve Coil No. 15	Valve Coil No. 14	Valve Coil No. 13	Valve Coil No. 12	Valve Coil No. 11	Valve Coil No. 10	Valve Coil No. 9	Valve Coil No. 8
X+2	Valve Coil No. 23	Valve Coil No. 22	Valve Coil No. 21	Valve Coil No. 20	Valve Coil No. 19	Valve Coil No. 18	Valve Coil No. 17	Valve Coil No. 16
X+3	Valve Coil No. 31	Valve Coil No. 30	Valve Coil No. 29	Valve Coil No. 28	Valve Coil No. 27	Valve Coil No. 26	Valve Coil No. 25	Valve Coil No. 24

IO Mapping for each additional 502/503 series 16 coil valve driver added to the manifold assembly

Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Coil 7 Status	Coil 6 Status	Coil 5 Status	Coil 4 Status	Coil 3 Status	Coil 2 Status	Coil 1 Status	Coil 0 Status
X+1	Coil 15 Status	Coil 14 Status	Coil 13 Status	Coil 12 Status	Coil 11 Status	Coil 10 Status	Coil 9 Status	Coil 8 Status



Output Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Valve Coil No. 7	Valve Coil No. 6	Valve Coil No. 5	Valve Coil No. 4	Valve Coil No. 3	Valve Coil No. 2	Valve Coil No. 1	Valve Coil No. 0
X+1	Valve Coil No. 15	Valve Coil No. 14	Valve Coil No. 13	Valve Coil No. 12	Valve Coil No. 11	Valve Coil No. 10	Valve Coil No. 9	Valve Coil No. 8

AVENTICS™ G3 Series EtherCAT™ Technical Manual

9.8 501 Series, up to 64 solenoid coils

501 series, 4 station manifold block with an integrated 32 coil valve driver

- To be used with 501 series valves on valve manifold assemblies with 33-64 coils.
- Only to be used on assemblies where additional power, supply and/or exhaust capacity is not required







AVENTICS™ G3 Series EtherCAT™ Technical Manual

9.9 501 Series, up to 128 solenoid coils

501 series, 8 station manifold with integrated 32 coil valve driver, auxiliary power connector and mid-station supply and exhaust ports

- To be used with 501 series valves on valve manifold assemblies with 33-128 coils.
- Up to 3 of these valve drivers can be used on each assembly
- Required to use on manifold assemblies larger than 64 coils, this manifold block has a M12 power connector to supplement the main power connection on the G3 node and two additional port 1 supply and port 3/5 exhaust ports.
- Aux power is required to be connected to the aux power connector provided on the extended coil valve driver.





AVENTICS™ G3 Series EtherCAT™ Technical Manual

9.10 502 and 503 Series, up to 80 solenoid coils

502 and 503 series, 4 station manifold with integrated 16 coil valve driver, power connector and mid-station supply and exhaust ports

- To be used with 502 and 503 series valves on valve manifold assemblies with 33-80 coils.
- Up to 3 of these valve drivers can be used on each assembly
- Required to use on manifold assemblies larger than 32 coils, this manifold block has a M12 power connector and two additional port 1 supply and port 3/5 exhaust ports.
- Aux power is required and will provide power to the 16 coils available via the extended coil valve driver.



Recommended blank station plates to achieve maximum number of coils with least number of stations

10. Analog I/O Modules

10.1 Analog I/O Module Rules


The analog I/O modules follow the same rules as the digital I/O modules. The maximum total number of modules on the Sub-Bus is 16. The analog boards allow the user to control devices using an analog signal. The analog modules also allow the user to relay analog information from input devices. These modules are available in two analog signal types: 0-10 V and 4-20 mA. These two signal types are offered in two different I/O configurations: 2 analog input channels/ 2 analog outputs channels and 4 analog input channels.

Four I/O - 12mm Female Modules

Specifications

- Input Resolution: 16 bit (65,536 Counts),
- Output Resolution: 16 bit (65,536 Counts)
- Settling Time: 3 ms Max
- Absolute Precision: $\leq 1.0\%$ of Signal
- Voltage Input Impedance: 0-10VDC – 40K Ohms
- Current Input Impedance: 250 Ohms
- Input Cutoff Frequency: 100 Hz

Module Part No.	Signal Type	Input Points	Output Points	Short Circuit Protection
240-212	0 - 10V	4	0	Yes
240-213	0 - 10V	2	2	
240-214	4 - 20mA	4	0	
240-215	4 - 20mA	2	2	
240-307	0 - 10V	2	2	
240-363	4 - 20mA	4	4	



FEMALE

PIN 1= +24VDC (UNSW)
 PIN 2= NOT USED
 PIN 3= 0VDC (UNSW)
 PIN 4= INPUT 1

AVENTICS™ G3 Series EtherCAT™ Technical Manual

One Analog Input per Connector – M12 Female Modules

Module Part No.	Signal Type	Short Circuit Protection	Short Circuit Protection Status Bits	Input Points
240-212	0-10 VDC	YES – Visual	YES (4) – Selectable	4
240-214	4-20 mA			

Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Required)	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1 (LSB)
X+1 (Required)	Input No. 1 (MSB)	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1
X+2 (Required)	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2 (LSB)
X+3 (Required)	Input No. 2 (MSB)	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2
X+4 (Required)	Input No. 3	Input No. 3	Input No. 3	Input No. 3	Input No. 3	Input No. 3	Input No. 3	Input No. 3 (LSB)
X+5 (Required)	Input No. 3 (MSB)	Input No. 3	Input No. 3	Input No. 3	Input No. 3	Input No. 3	Input No. 3	Input No. 3
X+6 (Required)	Input No. 4	Input No. 4	Input No. 4	Input No. 4	Input No. 4	Input No. 4	Input No. 4	Input No. 4 (LSB)
X+7 (Required)	Input No. 4 (MSB)	Input No. 4	Input No. 4	Input No. 4	Input No. 4	Input No. 4	Input No. 4	Input No. 4

Diagnostics								
X	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Power Status for Conn. D	Power Status for Conn. C	Power Status for Conn. B	Power Status for Conn. A
X+1	High Alarm for Conn. D	Low Alarm for Conn. D	High Alarm for Conn. C	Low Alarm for Conn. C	High Alarm for Conn. B	Low Alarm for Conn. B	High Alarm for Conn. A	Low Alarm for Conn. A



FEMALE


PIN 1= +24VDC (UNSW)
 PIN 2= NOT USED
 PIN 3= 0VDC (UNSW)
 PIN 4= INPUT 1

AVENTICS™ G3 Series EtherCAT™ Technical Manual

One Analog I/O per Connector – M12 Female Modules

Module Part No.	Signal Type	Short Circuit Protection	Short Circuit Protection Status Bits	Output Points	Input Points
240-213	0-10 VDC	YES	YES	2	2
240-215	4-20 mA				

Output Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1 (LSB)
X+1	Output No. 1 (MSB)	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1
X+2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2 (LSB)
X+3	Output No. 2 (MSB)	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2
Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1 (LSB)
X+1	Input No. 1 (MSB)	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1
X+2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2 (LSB)
X+3	Input No. 2 (MSB)	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2
Diagnostic Telegram								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	SCP Status for Conn. D	SCP Status for Conn. C	SCP Status for Conn. B	SCP Status for Conn. A
X+1 (Selectable)	High Alarm for Conn. D	Low Alarm for Conn. D	High Alarm for Conn. C	Low Alarm for Conn. C	High Alarm for Conn. B	Low Alarm for Conn. B	High Alarm for Conn. A	Low Alarm for Conn. A



CONNECTORS C & D	CONNECTORS A & B
PIN 1= +24VDC (UNSW)	PIN 1= +24VDC (UNSW)
PIN 2= OUTPUT	PIN 2= NOT USED
PIN 3= 0VDC (UNSW)	PIN 3= 0VDC (UNSW)
PIN 4= INPUT	PIN 4= INPUT

AVENTICS™ G3 Series EtherCAT™ Technical Manual

One High Current Analog I/O per Connector – M12 Female Modules

Module Part No.	Signal Type	Short Circuit Protection	Short Circuit Protection Status Bits	Output Points	Input Points
240-307	0-10 VDC	YES	YES	2	2

Output Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1 (LSB)
X+1	Output No. 1 (MSB)	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1
X+2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2 (LSB)
X+3	Output No. 2 (MSB)	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2

Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1 (LSB)
X+1	Input No. 1 (MSB)	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1
X+2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2 (LSB)
X+3	Input No. 2 (MSB)	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2


Diagnostic Telegram								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Power / Short Status for Conn. D	Power / Short Status for Conn. C	Allocated and Reserved	Allocated and Reserved
X+1 (Selectable)	High Alarm for Conn. D	Low Alarm for Conn. D	High Alarm for Conn. C	Low Alarm for Conn. C	High Alarm for Conn. B	Low Alarm for Conn. B	High Alarm for Conn. A	Low Alarm for Conn. A



Connector A,B
 Pin 1 = +10 VDC
 Pin 2 = Not Used
 Pin 3 = 0 VDC
 Pin 4 = Input
 Pin 5 = Not Used



Connector C,D
 Pin 1 = +24 VDC
 Pin 2 = Output
 Pin 3 = 0 VDC
 Pin 4 = Input
 Pin 5 = Not Used



AUX POWER MALE
 Pin 1 = +24 VDC (For Conn A, B)
 Pin 2 = +24 VDC (For Conn C, D)
 Pin 3 = 0 VDC (For Conn A, B, C, D)
 Pin 4 = 0 VDC (For Conn A, B, C, D)

AVENTICS™ G3 Series EtherCAT™ Technical Manual

One Analog Input + One Analog Output per Connector – M12 Female Modules

Module Part No.	Signal Type	Short Circuit Protection	Short Circuit / Power Present Status Bits	Input Channels	Output Channels
240-363	4-20 mA	YES	YES (4) – Selectable	4	4


Output Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Required)	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1 (LSB)
X + 1 (Required)	Output No. 1 (MSB)	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1	Output No. 1
X + 2 (Required)	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2 (LSB)
X + 3 (Required)	Output No. 2 (MSB)	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2	Output No. 2
X + 4 (Required)	Output No. 3	Output No. 3	Output No. 3	Output No. 3	Output No. 3	Output No. 3	Output No. 3	Output No. 3 (LSB)
X + 5 (Required)	Output No. 3 (MSB)	Output No. 3	Output No. 3	Output No. 3	Output No. 3	Output No. 3	Output No. 3	Output No. 3
X + 6 (Required)	Output No. 4	Output 4	Output No. 4	Output No. 4	Output No. 4	Output No. 4	Output No. 4	Output No. 4 (LSB)
X + 7 (Required)	Output No. 4 (MSB)	Output 4	Output No. 4	Output No. 4	Output No. 4	Output No. 4	Output No. 4	Output No. 4
Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Required)	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1 (LSB)
X + 1 (Required)	Input No. 1 (MSB)	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1
X + 2 (Required)	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2 (LSB)
X + 3 (Required)	Input No. 2 (MSB)	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2
X + 4 (Required)	Input No. 3	Input No. 3	Input No. 3	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1 (LSB)
X + 5 (Required)	Input No. 3 (MSB)	Input No. 3	Input No. 3	Input No. 1	Input No. 1	Input No. 1	Input No. 1	Input No. 1
X + 6 (Required)	Input No. 4	Input No. 4	Input No. 4	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2 (LSB)
X + 7 (Required)	Input No. 4 (MSB)	Input No. 4	Input No. 4	Input No. 2	Input No. 2	Input No. 2	Input No. 2	Input No. 2

AVENTICS™ G3 Series EtherCAT™ Technical Manual


One 4-20ma Analog Input + One 4-20 Analog Output per Connector – M12 Female Modules

Module Part No.	Signal Type	Short Circuit Protection	Short Circuit / Power Present Status Bits	Input Channels	Output Channels
240-363	4-20 mA	YES	YES (4) – Selectable	4	4


Diagnostic Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Selectable)	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Power/ Short Status for Conn. D	Power/ Short Status for Conn. C	Power/ Short Status for Conn. B	Power/ Short Status for Conn. A
X + 1 (Selectable)	High Alarm for Conn. D Input	Low Alarm for Conn. D Input	High Alarm for Conn. C Input	Low Alarm for Conn. C Input	High Alarm for Conn. B Input	Low Alarm for Conn. B Input	High Alarm for Conn. A Input	Low Alarm for Conn. A Input
X + 2 (Selectable)	High Alarm for Conn. D Output	Low Alarm for Conn. D Output	High Alarm for Conn. C Output	Low Alarm for Conn. C Output	High Alarm for Conn. B Output	Low Alarm for Conn. B Output	High Alarm for Conn. A Output	Low Alarm for Conn. A Output



Pin 1 = +24VDC
 Pin 2 = Output
 Pin 3 = 0 VDC
 Pin 4 = Input
 Pin 5 = Not Used



Pin 1 = +24 VDC (For Conn A, B)
 Pin 2 = +24 VDC (For Conn C, D)
 Pin 3 = 0 VDC (For Conn A, B, C, D)
 Pin 4 = 0 VDC (For Conn A, B, C, D)



AVENTICS™ G3 Series EtherCAT™ Technical Manual

Internal or Aux. Power Select (240-363 Only)

Analog devices connected to the 240-363 can be powered from the Aux. Power supply port (Internal Power Disabled) or from the module backplane (Internal Power Enabled). This is selected through the “Internal Power Menu” as shown. Channels A/B and C/D are controlled independently.



Internal Power Settings

1. Press the **SET** button to enter the INTERNAL POWER menu



2. CHANNEL A & B DISABLE



3. Press the **NEXT** button to scroll through the choices to enable or disable the feature.
 - a. ENABLED (Factory Default)
 - b. DISABLED
 - c. RETURN (this will return you to the main menu)

Press the **SET** button to confirm your choice



4. CHANNEL C & D DISABLE



5. Press the **NEXT** button to scroll through the choices to enable or disable the feature.
 - a. ENABLED (Factory Default)
 - b. DISABLED
 - c. RETURN (this will return you to the main menu)

Press the **SET** button to confirm your choice




Power Source	Current Limitation for Module	Current Limitation for connector
Aux Power	8A (From Aux. Power Conn.)	2.0A / output connector (2.0A Pin 1 to Pin 3)
Internal Power	1.2A (from Backplane)	.15A (Pin 1 to Pin 3)

AVENTICS™ G3 Series EtherCAT™ Technical Manual

10.2 Analog Graphic Display


The G3 Analog I/O modules have an integrated graphic display that may be used to configure the parameters of the modules as well as show diagnostic information. Please see the following pages for detailed information regarding these displays.



AVENTICS™ G3 Series EtherCAT™ Technical Manual


Analog Module / I/O Mapping

Displays the starting Input and Output byte address for the module



Analog Module / Module Number

Displays the module number; identifying its position in the G3 I/O system.



Analog Module / Alarm Settings

Allows the setting of low and high alarms for analog inputs and outputs



Alarm Settings Steps

1. Press the **SET** button to enter the Alarm Settings sub-menu.
2. Press the **SET** button to Disable all alarms (default setting)
*Note- Setting the Minimum value for Low alarm and the Maximum value for High alarm (for a channel) disables the alarm for that channel.
3. Press the **NEXT** button to scroll to the appropriate analog channel.
4. Press the **SET** button to set the LO alarm setting
 - a. Push the **SET** button to access the menu and enter the alarm value
5. Press the **NEXT** button to set the HI alarm setting.
 - a. Push the **SET** button to access the menu and enter the alarm value
 - b. Accept the changes by selecting **Y** and pushing **SET**
6. Press the **SET** button while in the RETURN screen to return to the main menu

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Analog Module / Description

Displays the quantity and type of I/O on the module
Ex. 2 analog Inputs and 2 analog outputs



Analog Module / Part number

Displays the replacement part number of the module



Analog Module / Firmware

Displays the firmware revision level for the module



Analog Module / Brightness



Brightness Settings

1. Press the **SET** button to enter the SET BRIGHTNESS menu.
2. Press the **NEXT** button to scroll the choices for the desired brightness of the LCD display for the analog module.
 - a. LOW
 - b. MEDIUM (Factory Default)
 - c. HIGH
 - d. RETURN (this will return you to the main menu)

Press the **SET** button to confirm your choice. The changes will take effect immediately.


AVENTICS™ G3 Series EtherCAT™ Technical Manual

10.3 Analog Module / Self Test Mode

Self test mode is an internal diagnostic tool that can be enabled on the analog module using the graphic display. This tool allows the user to confirm that all of the outputs on the module are fully functional without needing a network connection or controller. The test will cycle the analog outputs. Starting with Output 0 it will increment the analog signal at 10% intervals; once it has reached 100% it will test the next available output. The self-test will continue to run until it is turned off by pressing the SET button.

To use the Self Test Mode, the user must first set some initial conditions. Follow these steps to initiate the self-test mode.

- 1) **Disconnect Air and Communication from the manifold!**
- 2) Starting at the Home Screen, navigate the menus by selecting the NEXT button until the SELF-TEST menu is shown.
- 3) Select the SET button to access the SELF-TEST menu
- 4) A message will appear: DISCONNECT AIR HOLD SET BUTTON
- 5) Hold the SET button down for approximately 10 seconds to enable the test. The Display will flash the above message while the button is pushed.
- 6) When the display stops flashing, the self-test mode will be running
- 7) Push or hold the NEXT button to cycle through the outputs. Holding the NEXT button will allow the analog outputs to cycle through the 10% intervals automatically. Pushing the NEXT button will allow the outputs to manually step through each 10% interval.
- 8) Releasing the NEXT button will keep the output in its current state.
- 9) The self-test mode can only be disabled by pushing the SET button



AVENTICS™ G3 Series EtherCAT™ Technical Manual

10.4 Analog Module / Factory Defaults

Factory Default Settings



1. Press the **SET** button to enter the FACTORY DEFAULTS sub-menu.



2. Press the **NEXT** button to select **Yes** or **No**.
 - a. Selecting **No** will bring you back to the main FACTORY DEFAULTS menu.
 - b. Selecting **Yes** will cause the module to reset and return all parameters to the factory default conditions.

Press the **SET** button to confirm your choice.



<i>FACTORY DEFAULT SETTINGS</i>	
<i>Description</i>	<i>Default</i>
Low Alarm Values	0 V / 4 mA
High Alarm Values	10 V / 20 mA
Brightness	Medium

AVENTICS™ G3 Series EtherCAT™ Technical Manual

11. Specialty Modules

11.1 RTD Module

The G3 RTD Temperature module is used with Resistive Temperature Detectors (RTDs) and can support up to 4 RTD devices simultaneously. This module supports various RTD types including: Pt100, Pt200, Pt500, Pt1000, Ni100 and Ni1000. Standard M12 single key connector types are used; each connector/port supports one RTD device, but four different device types can be used simultaneously. User configuration of parameters include: RTD type, temperature scale (Celsius or Fahrenheit), Hi/Low temperature alarms, and filter times, and can be selected individually for each connector port using the integrated display. The G3 RTD module can be incorporated into any G3 electronic system regardless of the protocol or I/O module position.



FEMALE

PIN 1 = Sensor Current Source (I+)

PIN 2 = Sense Voltage (VIN+)





PIN 3 = Sensor Current Source (I-)

PIN 4 = Sense Voltage (VIN-)

PIN 5 = Not Used

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Sensor Wiring Diagrams



- For maximum accuracy on a 3 wire sensor type make identified jumper connections at the sensor end (see Figure 3). Cable resistance, resulting from cable length, affects measuring error; therefore use cables that are as short as possible.

Electrical Data

Voltage	24 VDC Module Supply (Via G3 System Aux. Power Connection)
Input Type	RTD (Resistive Temperature Detector), 4 per Module
Supported Sensor Types	Pt100, Pt200, Pt500, Pt1000, Ni100, Ni1000
Supported Temperature Coefficients	.00385; .00392;Ω/Ω/°C
Resolution	15 bits, plus sign.
Data Format	Signed Integer; Two's complement.
Calibration	Factory Calibrated. Field Calibration w/ high tolerance (± 0.005%) 100 ohm and 350 ohm resistor.
Input Update (filter) Rate	Adjustable (5-20mS), factory default: 5mS
Accuracy	0.1% of full scale @ 25° C

Mechanical Data

I/O Connector	M12 4 Pin Female (Accepts 5 Pin)
Mass	247g / 8.7 oz

Operating Data

Temperature Range	-10° to 115° F (-23° to 46° C)
Humidity	95% relative humidity: non-condensing
Ingress Protection	IP65 (with appropriate assembly and terminations)

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Part Numbers and Mapping

Module Part No.	I/O Type	Alarms	Diagnostics	Input Points
240-311	RTD	Hi/Low Temp for each Channel	Open/Short, Out of Range	4

Input Mapping								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	RTD Channel 0	RTD Channel 0	RTD Channel 0	RTD Channel 0	RTD Channel 0	RTD Channel 0	RTD Channel 0	RTD Channel 0
X + 1	Sign Bit Channel 0	RTD Channel 0	RTD Channel 0	RTD Channel 0	RTD Channel 0	RTD Channel 0	RTD Channel 0	RTD Channel 0
X + 2	RTD Channel 1	RTD Channel 1	RTD Channel 1	RTD Channel 1	RTD Channel 1	RTD Channel 1	RTD Channel 1	RTD Channel 1
X + 3	Sign Bit Channel 1	RTD Channel 1	RTD Channel 1	RTD Channel 1	RTD Channel 1	RTD Channel 1	RTD Channel 1	RTD Channel 1
X + 4	RTD Channel 2	RTD Channel 2	RTD Channel 2	RTD Channel 2	RTD Channel 2	RTD Channel 2	RTD Channel 2	RTD Channel 2
X + 5	Sign Bit Channel 2	RTD Channel 2	RTD Channel 2	RTD Channel 2	RTD Channel 2	RTD Channel 2	RTD Channel 2	RTD Channel 2
X + 6	RTD Channel 3	RTD Channel 3	RTD Channel 3	RTD Channel 3	RTD Channel 3	RTD Channel 3	RTD Channel 3	RTD Channel 3
X + 7	Sign Bit Channel 3	RTD Channel 3	RTD Channel 3	RTD Channel 3	RTD Channel 3	RTD Channel 3	RTD Channel 3	RTD Channel 3
Diagnostic Telegram								
X + 8	Channel 3 Out of Range	Channel 2 Out of Range	Channel 1 Out of Range	Channel 0 Out of Range	Channel 3 Open/Short	Channel 2 Open/Short	Channel 1 Open/Short	Channel 0 Open/Short
X + 9	Channel 3 High Alarm	Channel 3 Low Alarm	Channel 2 High Alarm	Channel 2 Low Alarm	Channel 1 High Alarm	Channel 1 Low Alarm	Channel 0 High Alarm	Channel 0 Low Alarm




Data is represented by Two's Complement, in tenths of a degree.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

RTD Module Graphic display

RTD Module / Temperature Monitoring



- 1) Press the **NEXT** button to scroll through the Temperature Monitoring display options.

Pressing the **SET** button while in one of the Temperature Monitoring displays, will return the display back to the home screen.

If "DISABLED" is the temperature identified at any channel, advance the display to Sensor Type Select, to choose a sensor/Enable the channel, or press the "SET" button to jump directly to the selection display.

Unused channels should be left "DISABLED".


AVENTICS™ G3 Series EtherCAT™ Technical Manual

RTD Module / Sensor Type Select (Channel Enable)


Allows the sensor type for each channel to be selected, and, enable the channel selected



A) Press the **SET** button to enter the Sensor Type Select sub menu.




B) Press the **NEXT** button to scroll through the channels.



C) Press the **SET** button to select the desired channel. If "DISABLED" is the first selection, the channel is not enabled. Select a sensor type to enable the channel.



D) Press the **NEXT** button to scroll through the available sensor types.



E) Press the **SET** button to select the desired sensor type.




F) Press the **SET** button to load the selected sensor type.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

RTD Module / Temperature Scale

Allows the temperature scale for each channel to be set to Celsius or Fahrenheit.




- A) Press the SET button to enter the Temp Scale sub menu.
- B) Press the NEXT button to scroll through the channels.
- C) Press the SET button to choose the desired channel.
- D) Press the NEXT button to choose the desired scale.
- E) Press the SET button to load the selection.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

RTD Module / Alarm Settings

Allows the Low and High alarms of each RTD Input channel to be set. This parameter generates a visual and logical (bit) when set value is achieved.



- A) Press the **SET** button to enter the Alarm Settings sub-menu.
- B) Press the **NEXT** button to scroll through the RTD Input channels.
- C) Press the **SET** button to enter the alarm setting for the selected Input channel.
- D) Press the **NEXT** button to select the Lo or High setting for the selected channel.
- E) Press the **SET** button to select the change process for the chosen alarm. The first digit/sign will be highlighted.
- F) Press the **NEXT** button to choose the value, or the **SET** button to select and move to the next digit.
- G) Press the **NEXT** button to choose "Y" or "N" Select. Then press the **SET** Button to Accept.



- When alarm values are set to maximum/minimum values, the alarm function is disabled.
- Factory default settings for all alarms are disabled.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

RTD Module / Advanced Setting

Allows the Update Filters for each channel to be set.



A) Press the **SET** button to enter the Advance Settings sub-menu.

B) Press the **NEXT** button to choose the option; Update Filters or Calibrate RTD.

Update Filters



C) Press the **SET** button to choose the Update Filter setting.

D) Press the **NEXT** button to scroll through the filter times.




E) Press the **SET** button to select the desired Update Filter time.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

RTD Module / I/O Mapping Input Byte



RTD Module / Module Number (Position)



RTD Module / Module Description



RTD Module / Part Number



RTD Module / Firmware Revision



AVENTICS™ G3 Series EtherCAT™ Technical Manual

RTD Module / Set Display Brightness

Allows the Brightness of the display to be changed



- A) press the **SET** button to enter the Set Brightness sub menu.
- B) Press the **NEXT** button to scroll through the brightness options
- C) Press the **SET** button to load the selection.

RTD Module / Flip Display

Allows the Display to be flipped 180 degrees.



- A) press the **SET** button to enter the Flip Display sub menu.
- B) Press the **NEXT** button to choose the orientation.
- C) Press the **SET** button to load the selection.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

RTD Module / Factory Defaults

Set all parameter settings to default values.



- A) Press the **SET** button to enter the Factory Defaults sub menu.
- B) Press the **NEXT** button to choose **Yes** or **No**.
- C) Press the **SET** button to confirm.
- D) Press the **SET** button again.




Factory Default Settings	
Alarm – High & Low	Disabled (Set to Min/Max for each chosen sensor)
Input Update Filter	5 mS
Sensor Type	Pt 100 385
Temp Scale	Celsius
Display Brightness	Medium
Flip Display	Normal

AVENTICS™ G3 Series EtherCAT™ Technical Manual


11.2 Sub-Bus Hub Module

The G3 HUB module allows for branch distribution from the I/O side of the G3 System and can be integrated into the existing G3 Series Sub-Bus configuration. Auto Addressing allows for trouble free set up and configuration. Input, Output, as well as Valve manifolds can be attached to the available four Branches on a HUB module. Each G3 System can support up to two HUB modules, allowing for maximum flexibility. The HUB module is transparent to the I/O side of the G3 and does not reserve one of the potential sixteen positions.

Module Part No.	Module Type	Diagnostics	Input Size / Output Size	Branches
240-326	HUB	Sub-Bus Short Circuit	0 / 0 – See Note	4



AVENTICS™ G3 Series EtherCAT™ Technical Manual




The Sub-bus hub module does not produce mapped diagnostics. The data table in this example represents what is physically attached to the HUB module. This will change as modules are added or removed.

Example I/O Mapping of Attached Modules								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X (Required)	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1	Input 0
X + 1 (Required)	Input 15	Input 14	Input 13	Input 12	Input 11	Input 10	Input 9	Input 8
X + 2 (Selectable)	Conn. H SCP Status	Conn. G SCP Status	Conn. F SCP Status	Conn. E SCP Status	Conn. D SCP Status	Conn. C SCP Status	Conn. B SCP Status	Conn. A SCP Status
X + 3 (Required)	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1	Input 0
X + 4 (Required)	Input 15	Input 14	Input 13	Input 12	Input 11	Input 10	Input 9	Input 8
X + 5 (Selectable)	Conn. H SCP Status	Conn. G SCP Status	Conn. F SCP Status	Conn. E SCP Status	Conn. D SCP Status	Conn. C SCP Status	Conn. B SCP Status	Conn. A SCP Status

Where X = starting byte

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Hub Module / Identification



- 1) Identifies HUB module in G3 System.

Hub Module / Description



- 2) Identifies Module type.

Hub Module / Advanced Settings



- 3) Allows the user to set/configure module parameters.

Press the **SET** button to advance to the first parameter/setting.


Brightness



- A) Press the **SET** button to enter the Set Brightness sub-menu and highlight the selection.



- B) Press the **NEXT** button to select the desired Brightness selection, (Low, Medium, High).



- C) Press the **SET** button to select the desired Brightness level.

Screen Jumps to Next Parameter/Selection

Flip Display



- A) Press the **SET** button to enter the Flip Display sub-menu and highlight the selection.




- B) Press the **NEXT** button to select the desired Flip Display selection, (Normal, Flipped).

- C) Press the **SET** button to select the desired display orientation.

- D) Press **NEXT** to advance to the next parameter selection (Branch Reserve)


AVENTICS™ G3 Series EtherCAT™ Technical Manual

Branch Reserve I/O



- A) Press the **SET** button to enter the Branch Reserve IO sub-menu.
- B) Press the **NEXT** button to select the desired Branch to reserve I/O bytes.

I/O data bytes can be reserved on each branch for future expansion within the G3 system. Space is reserved in Byte levels, and populates Input, Output, and Status depending on the protocol and configuration chosen. A maximum of 64 bytes per channel can be reserved.




- C) Press the **SET** button to enter the chosen Branch/Byte Selection screen.
- D) Press the **NEXT** button to select the desired Tens value of reserved bytes.
- E) Press the **SET** button to set the desired Tens value.
- F) The screen will advance to the Ones selection
- G) Press the **NEXT** button to select the desired Ones value for reserved bytes.
- H) Press the **SET** button to set the desired Ones value.

Once the desired byte size is chosen for the selected branch, the screen will jump to the next branch. The same process is performed for the remaining branches, if desired. Press the **NEXT** button to skip over branches that do not require reserving I/O.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Factory Defaults



4) Allows all parameter settings to be set back to default values.

- A) Press the SET button to enter the Factory Defaults sub menu.
- B) Press the NEXT button to choose Yes or No.
- C) Press the SET button to confirm.
- D) Press the SET button again.



<i>Factory Default Settings</i>	
Brightness	Medium
Flip Display	Normal
Reserve I/O	No Reserve (all Branches)

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Diagnostics



Part Number



Firmware Rev.



Branch Connections



5) Allows the user to reference Part No., Firmware Rev., and Branch Connections.

A) Press the **NEXT** button to enter the Diagnostics sub-menu.

The Part Number screen is displayed (reference only).

B) Press the **NEXT** button to advance to the Firmware revision screen (reference only).

C) Press the **NEXT** button to advance to the Branch Connections screen.

D) Press the **SET** button to enter the Branch Connections sub-menu.

E) Press the **NEXT** button to advance through the Branches.

Each Branch screen indicates identifies the module numbers that are currently connected to that Branch.

HELP



6) Directs the user to the Aventics website.



A) Press the **SET** button for website address.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Error/Event Messages

The following are error messages that are displayed when specific faults/events occur during operation:




Displayed when a Sub-Bus module that had been previously installed becomes absent from the configuration




Displayed when a Sub-Bus power short circuit condition is detected

Connector Pin Out




- FEMALE
- PIN 1 = Shield
 - PIN 2 = V+
 - PIN 3 = V-
 - PIN 4 = CAN_H
 - PIN 5 = CAN_L




- Length of molded or field wired Sub-Bus Branch cables should not exceed the maximum length of 30 meters per Sub-Bus Branch communication link.
- The molded cable assemblies and bulk cable are the only approved cables for the G3 Sub-Bus and Branch Link. Please refer to the G3 Electronics catalog, for Sub-Bus cable and connectors options. See Technical Document TDG3SBWD1-0EN for proper installation and wiring of field wire-able connectors.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

HUB Integration - Example




Module	Part No.	Description	Details	Export Config and Log	Activity	
Node	240-325	EtherNet/IP DLR/QC Communications Module	<input type="checkbox"/> Show Details		<input checked="" type="checkbox"/> Close all Details	
ARM	240-182	Auto Recovery Module	<input type="checkbox"/> Show Details		<input checked="" type="checkbox"/> Close all Details	
No. 1	240-205	16 Inputs PNP Digital M12 x 8	<input type="checkbox"/> Show Details		<input checked="" type="checkbox"/> Close all Details	
Hub 1	240-326	Sub-Bus Hub Module	<input checked="" type="checkbox"/> Show Details		<input checked="" type="checkbox"/> Close all Details	
		Firmware Revision:	2 070			
		I/O Reserved (bytes):	Branch 1	Branch 2	Branch 3	Branch 4
		Unused Reserved Input (bytes):	-	-	-	-
		Unused Reserved Diagnostic (Status) Inputs (bytes):	-	-	-	-
		Unused Reserved Output (bytes):	-	-	-	-
		Module No's. on branch:	-	2, 3, 4	-	5, 6
-- Branch 2, Mod. No. 2	240-241	Sub-Bus Valve Driver	<input type="checkbox"/> Show Details		<input checked="" type="checkbox"/> Close all Details	
-- Branch 2, Mod. No. 3	240-205	16 Inputs PNP Digital M12 x 8	<input type="checkbox"/> Show Details		<input checked="" type="checkbox"/> Close all Details	
-- Branch 2, Mod. No. 4	240-205	16 Inputs PNP Digital M12 x 8	<input type="checkbox"/> Show Details		<input checked="" type="checkbox"/> Close all Details	
-- Branch 4, Mod. No. 5	240-205	16 Inputs PNP Digital M12 x 8	<input type="checkbox"/> Show Details		<input checked="" type="checkbox"/> Close all Details	
-- Branch 4, Mod. No. 6	240-205	16 Inputs PNP Digital M12 x 8	<input type="checkbox"/> Show Details		<input checked="" type="checkbox"/> Close all Details	
			<input type="checkbox"/> Show Error/Event Log			

12. I/O Module(s) Wiring Diagrams

12.1 12.1 NPN/PNP Definitions


NPN Descriptions

- Sinking
- Switching Negative
- Positive Common




PNP Descriptions

- Sourcing
- Switching Positive
- Negative Common




NPN (Sinking) Input Connection

Electric Sensor Type




Mechanical Sensor Type




PNP (Sourcing) Input Connection

Electric Sensor Type




Mechanical Sensor Type



AVENTICS™ G3 Series EtherCAT™ Technical Manual

I/O Module(s) Wiring Diagrams Continued

PNP (Sourcing) Output Connection



AVENTICS™ G3 Series EtherCAT™ Technical Manual

13. G3 EtherCAT™ Web Server

13.1 Connecting to a G3 Series EtherCAT™ node

Note: To access the G3 Node's diagnostic Web Page the G3 EtherCAT™ node must be set to EtherCAT™ disabled (TCP ONLY mode).

EtherCAT™ Steps



1. Press the **SET** button to enter the Web-Server sub-menu.



2. Press the **NEXT** button to scroll through the choices to enable or disable the feature.

d. ENABLED (Factory Default)

e. DISABLED

f. RETURN (this will return you to the main menu)

Press the **SET** button to confirm your choice.



The status screen changes to;
ETHERCAT™
TCP ONLY



CAUTION


- *Disabling EtherCAT™ stops all communication with the EtherCAT™ master!*

AVENTICS™ G3 Series EtherCAT™ Technical Manual

13.2 Connecting to a G3 Series EtherCAT™ Node (Windows 7)


This section will discuss how to connect a computer to a G3 Series EtherCAT™ node. There are multiple ways to complete this task, so only two will be discussed.

1. Connect a 24VDC power supply to the valve manifold. The connector pin-out can be found on the side of the EtherCAT™ node or on page 4-20 of this document. (Note: 24VDC only needs to be applied to the "+24VDC (NODE & INPUTS)" pin to power the node.)
2. Connect an Ethernet cable directly from the manifold to the computer -OR- Connect an Ethernet cable from the manifold to a router, hub, or switch. Connect a second Ethernet cable from the computer to the router, hub, or switch. (Network lights should appear on the router, hub, or switch if the correct cables are used).
3. Turn on the computer. Also, make sure the manifold and the router, hub or switch has power.
4. To communicate with an EtherCAT™ manifold the IP address of your computer must be known. To start this process, left click on the "Start" button.
5. Left click on control panel, then left click view network status and tasks




AVENTICS™ G3 Series EtherCAT™ Technical Manual

- The “Network and Sharing Center” window will open. Double click on “Change adapter settings”.




- The “Network Connections” window opens. Double click the “Local Area Connection Icon”




AVENTICS™ G3 Series EtherCAT™ Technical Manual

- Click on “Internet Protocol Version 4 (TCP/IPv4)” the properties window will open



- Choose the option marked “Use the following IP address” and type in an IP address that has the same first three octets as the address as you the manifold you are connected with. For the last octet you may choose any number from 0-255, just make sure that it is not the same number as the IP address that the manifold will have. Make sure your subnet mask is set to “255.255.255.0” (this value can be changed, but this value will be used for demonstration purposes).




AVENTICS™ G3 Series EtherCAT™ Technical Manual


10. Left click “OK” in the “Internet Protocol (TCP/IP) Properties” and “Local Area Connection” windows for the changes to take effect on the computer. Close out of any open windows.

Once the IP address for the computer is known, you can set the IP address of the Aventics manifold using one of the methods described on page 5-33.

11. Click on “Start” then select “All Programs ->Accessories ->Run”



12. Type, “Ping, and then the IP address of the manifold, you can view the address on the graphical display. For example, if the IP address is 192.168.3.120, “ping 192.168.3.120” would be typed. You will get a message stating, “Reply from 192.168.3.120: bytes=32 time<1ms TTL=128”, if the manifold responds.



AVENTICS™ G3 Series EtherCAT™ Technical Manual

13. Open a web browser on the computer and type the IP address of the manifold.
Ex. <http://192.168.3.120>. The Aventics G3 webpage should load after several seconds.




AVENTICS™ G3 Series EtherCAT™ Technical Manual

13.3 Connecting to a G3 Series EtherCAT™ Node (Windows 10)


This section will discuss how to connect a computer to a G3 Series EtherNet/IP™ node. There are multiple ways to complete this task, so only two will be discussed. All computer commands are shown in Windows 10.

1. Connect a 24VDC power supply to the valve manifold. The connector pin-out can be found on the side of the EtherNet/IP™ node or on page 4-20 of this document. (Note: 24VDC only needs to be applied to the "+24VDC (NODE & INPUTS)" pin to power the node.)
2. Connect an Ethernet cable directly from the manifold to the computer -OR- Connect an Ethernet cable from the manifold to a router, hub, or switch. Connect a second Ethernet cable from the computer to the router, hub, or switch. (Network lights should appear on the router, hub, or switch if the correct cables are used).
3. Turn on the computer. Also, make sure the manifold and the router, hub, or switch has power.
4. To communicate with an EtherNet/IP™ manifold the IP address of your computer must be known. To start this process, left click on the "Windows" (Start) button.
5. Left click on Settings (gear icon), then on Network & Internet.




AVENTICS™ G3 Series EtherCAT™ Technical Manual

- Next, left click on “Ethernet” on the left-hand side of the window, and then “Network and Sharing Center”.




- The “Network and Sharing Center” window will open. Double click on “Change adapter settings”.




AVENTICS™ G3 Series EtherCAT™ Technical Manual

8. The “Network Connections” window opens. Double click the “Local Area Connection Icon”




9. Click on “Internet Protocol Version 4 (TCP/IPv4)” the properties window will open



AVENTICS™ G3 Series EtherCAT™ Technical Manual


10. Choose the option marked “Use the following IP address” and type in an IP address that has the same first three octets as the address that you will set the manifold to. For the last octet you may choose any number from 0-255, just make sure that it is not the same number as the IP address that the manifold will have. Make sure your subnet mask is set to “255.255.255.0” (this value can be changed, but this value will be used for demonstration purposes).



11. Left click “OK” in the “Internet Protocol (TCP/IP) Properties” and “Local Area Connection” windows for the changes to take effect on the computer. Close out of any open windows.

Once the IP address for the computer is known, you can set the IP address of the Aventics manifold using one of the methods described on page 5-33 .

12. Click on “start” then select “All Programs->Accessories->Run”.



AVENTICS™ G3 Series EtherCAT™ Technical Manual

13. Type, "Ping, and then the IP address of the manifold, you can view the address on the graphical display. For example, if the IP address is 192.168.3.120, "ping 192.168.3.120" would be typed. You will get a message stating, "Reply from 192.168.3.120: bytes=32 time<1ms TTL=128", if the manifold responds.

```
C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\dwalsh>arp -s 192.168.3.120 00-15-24-00-01-DE
C:\Documents and Settings\dwalsh>ping 192.168.3.120
Pinging 192.168.3.120 with 32 bytes of data:
Reply from 192.168.3.120: bytes=32 time<1ms TTL=128
Reply from 192.168.3.120: bytes=32 time<1ms TTL=128
Reply from 192.168.3.120: bytes=32 time<1ms TTL=128
Reply from 192.168.3.120: bytes=32 time<1ms TTL=128
Ping statistics for 192.168.3.120:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms
```

14. Open a web browser on the computer and type the IP address of the manifold.
Ex. <http://192.168.3.120>. The Aventics G3 webpage should load after several seconds.



AVENTICS™ G3 Series EtherCAT™ Technical Manual

13.4 Using the Functionality of the G3 Series EtherCAT™ Web Server

This section will discuss the functionality of the built in Ethernet server. Every Aventics EtherCAT™ node has this feature. Through this server you can configure the node, force I/O, check diagnostics, etc. Each Aventics' web page will be explained.

Home

To get to the Aventics "Home" page, open a web browser. In the URL line, type in the IP address of the manifold and press "Enter". The Aventics "Home" page will appear. This page shows a picture of the Aventics EtherCAT™ manifold. From this page, the user can navigate the entire built-in web server.



AVENTICS™ G3 Series EtherCAT™ Technical Manual

Node Configuration


The “Node Configuration” window can be used to control different parameters within the manifold. These parameters include, “Station Alias”, “Max Coils”, “Node Configuration Parameters (lock)” and “I/O Configuration (lock)”.



Node Configuration	
(Green selections denote Factory Default settings)	
Station Alias:	<input type="text" value="3"/>
Web Server:	<input type="text" value="Enabled"/> ▼
Max Coils on Manifold (32 = Standard):	<input type="text" value="32"/> ▼
Safety Zones (Only configurable when Max Coils = 32):	<input type="text" value="None"/> ▼
COMM Fault / Idle Mode:	<input type="text" value="Turn OFF All Outputs"/> ▼
Diagnostic Word:	<input type="text" value="Mapped"/> ▼
I/O (Diagnostics) Status:	<input type="text" value="Mapped"/> ▼
Node Configuration Parameters:	<input type="text" value="Unlocked"/> ▼
I/O Configuration:	<input type="text" value="Unlocked"/> ▼
Display Orientation (Global):	<input type="text" value="Normal"/> ▼
Display Brightness (Global):	<input type="text" value="Medium"/> ▼

Update Configuration

Once the changes have been made, left click on the “Update Configuration” button. The “Configuration Successfully Updated” window will appear. The EtherCAT™ node will reset in a few seconds, or the user may cycle power to enable the new configuration.



AVENTICS™ G3 Series EtherCAT™ Technical Manual

Password


The "Password" window allows the user to set a password that will prevent unwanted access to the I/O Force and Test functionality. The password comes disabled from the factory. To set the initial password, leave the "Enter Current Password" field blank and type in the new password in the "Enter New Password" field.



Change Password	
Enter Current Password: (up to 20 characters)	<input type="text"/>
Enter New Password: (up to 20 characters)	<input type="text"/>
Repeat New Password:	<input type="text"/>

This page allows password protection of the [Node Configuration](#) page and the I/O Force & Test features of the [Diagnostic](#) page. To disable password protection, leave the "Enter New password" box empty. If you have forgotten a previously set password please contact Aventics Technical support.

Once a Password has been set, the security check screen will appear when accessing Diagnostic or Node Configuration parameters.



- If the password has been lost or forgotten, go through the process of changing the password. Enter the last 6 digits of the MAC Address in the current password field and then enter the desired password in the new password field.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Diagnostics

The “Diagnostics” window allows the user to monitor different values. These values include, “MAC Address”, “Serial Number”, “Firmware Revision”, and “Valve Diagnostic Table”. The “Valve Diagnostic Table” enables the user to check the status of the valve side outputs.



Actual Configuration of modules with part numbers and descriptions including distributed modules

Module	Part No.	Description	Details	Activity
Node	240-310	EtherCAT Communications Module	<input type="checkbox"/> Show Details	✓
Valve Driver	P599AE42518800x	50X Series Valve Driver Output Module	<input type="checkbox"/> Show Details	✓
ARM	240-383	Auto Recovery Module	<input type="checkbox"/> Show Details	✓
No. 1	240-214	4 Inputs 4-20mA Analog M12 x 4	<input checked="" type="checkbox"/> Show Details	✓
No. 2	240-211	8 Inputs / 8 Outputs PNP Digital M12 x 8	<input type="checkbox"/> Show Details	✓
No. 3	240-207	16 Outputs PNP Digital M12 x 8	<input type="checkbox"/> Show Details	✓
			<input type="checkbox"/> Show Error/Event Log	


Reports module status:

- ✓ = OK
- ! = Attention
- ✗ = Lost comm.

Selects which module details will be shown, more than 1 can be selected simultaneously.

AVENTICS™ G3 Series EtherCAT™ Technical Manual




Module	Part No.	Description	Details	Activity								
Node	240-310	EtherCAT Communications Module	<input checked="" type="checkbox"/> Show Details	<input type="checkbox"/> Close all Details <input checked="" type="checkbox"/>								
	Firmware Revision:		1.1 Build 44022									
	IP Address:		192.168.1.120									
	Subnet Mask:		255.255.255.0									
	Gateway IP Address:		0.0.0.0									
	MAC Address:		00-15-24-00-fa-af									
	Active EtherCAT Connections:		0									
	Node / Input Power:		24.2 VDC									
	Diagnostic Word Status:		OK									
	Diagnostic Word Byte 0:		<table border="1"> <tr> <td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td> </tr> </table>		0	1	2	3	4	5	6	7
	0	1	2	3	4	5	6	7				
Diagnostic Word Byte 1:		<table border="1"> <tr> <td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td> </tr> </table>		0	1	2	3	4	5	6	7	
0	1	2	3	4	5	6	7					

Relevant node information including firmware revision

Graphic of module

"Diagnostic word" data

Valve Driver	P599AE42518800x	50X Series Valve Driver Output Module	<input checked="" type="checkbox"/> Show Details	<input type="checkbox"/> Close all Details <input checked="" type="checkbox"/>																																
	Firmware Revision:		4.19																																	
	Valve Coils 0-31:		<table border="1"> <tr> <td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td> </tr> <tr> <td>8</td><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td> </tr> <tr> <td>16</td><td>17</td><td>18</td><td>19</td><td>20</td><td>21</td><td>22</td><td>23</td> </tr> <tr> <td>24</td><td>25</td><td>26</td><td>27</td><td>28</td><td>29</td><td>30</td><td>31</td> </tr> </table>		0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
	0	1	2	3	4	5	6	7																												
	8	9	10	11	12	13	14	15																												
	16	17	18	19	20	21	22	23																												
	24	25	26	27	28	29	30	31																												
	Valve Status:		<table border="1"> <tr> <td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td> </tr> <tr> <td>8</td><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td> </tr> <tr> <td>16</td><td>17</td><td>18</td><td>19</td><td>20</td><td>21</td><td>22</td><td>23</td> </tr> <tr> <td>24</td><td>25</td><td>26</td><td>27</td><td>28</td><td>29</td><td>30</td><td>31</td> </tr> </table>		0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
	0	1	2	3	4	5	6	7																												
	8	9	10	11	12	13	14	15																												
	16	17	18	19	20	21	22	23																												
24	25	26	27	28	29	30	31																													
<ul style="list-style-type: none"> ● = Shorted Coil ● = Open Coil ✘ = No Coil Detected 																																				
<input type="checkbox"/> Show I/O Mappings and Sizes																																				


Valve coil forcing capability. Can be disabled with password

Shows diagnostic status of whether coils are shorted or open.

*Note
The G3 node must be switched to Pre-Operational mode via the Twincat system manager software to allow forcing output states from the G3 webpage. See next page


AVENTICS™ G3 Series EtherCAT™ Technical Manual

Show Details:

No. 2	240-211	8 Inputs / 8 Outputs PNP Digital M12 x 8	<input checked="" type="checkbox"/> Show Details	<input type="button" value="Close all Details"/>	<input checked="" type="checkbox"/>				
	Firmware Revision:	2.038							
	PNP Digital Inputs:	0 <input type="checkbox"/>	1 <input type="checkbox"/>	2 <input type="checkbox"/>	3 <input type="checkbox"/>	4 <input type="checkbox"/>	5 <input type="checkbox"/>	6 <input type="checkbox"/>	7 <input type="checkbox"/>
	Digital Outputs:	0 <input type="checkbox"/>	1 <input type="checkbox"/>	2 <input type="checkbox"/>	3 <input type="checkbox"/>	4 <input type="checkbox"/>	5 <input type="checkbox"/>	6 <input type="checkbox"/>	7 <input type="checkbox"/>
	Check/Uncheck box to force/un-force output								
	Connector Status:	A <input type="checkbox"/>	B <input type="checkbox"/>	C <input type="checkbox"/>	D <input type="checkbox"/>	E <input checked="" type="checkbox"/>	F <input type="checkbox"/>	G <input type="checkbox"/>	H <input type="checkbox"/>
Output Status:	0 <input checked="" type="checkbox"/>	1 <input checked="" type="checkbox"/>	2 <input checked="" type="checkbox"/>	3 <input checked="" type="checkbox"/>	4 <input checked="" type="checkbox"/>	5 <input checked="" type="checkbox"/>	6 <input checked="" type="checkbox"/>	7 <input checked="" type="checkbox"/>	
<ul style="list-style-type: none"> <input checked="" type="checkbox"/> = Short on Connector <input checked="" type="checkbox"/> = Shorted Output <input checked="" type="checkbox"/> = Open Load <input checked="" type="checkbox"/> = No Output Detected 									
<input type="checkbox"/> Show I/O Mappings and Sizes									

Shows Input & Output signal status

Shows diagnostic status of source power to sensor, "Connector E shorted"

No. 1	240-214	4 Inputs 4-20mA Analog M12 x 4	<input checked="" type="checkbox"/> Show Details	<input type="button" value="Close all Details"/>	<input checked="" type="checkbox"/>			
	Firmware Revision:	2.027						
	Analog Inputs:	AI0: 4.00 mA						
		AI1: 4.00 mA						
		AI2: 4.00 mA						
		AI3: 4.00 mA						
Input Status:	0 <input checked="" type="checkbox"/>	1 <input checked="" type="checkbox"/>	2 <input checked="" type="checkbox"/>	3 <input checked="" type="checkbox"/>				
<ul style="list-style-type: none"> <input checked="" type="checkbox"/> = Open Connection <input checked="" type="checkbox"/> = No Input Detected 								
Connector Status:	A <input type="checkbox"/>	B <input type="checkbox"/>	C <input type="checkbox"/>	D <input type="checkbox"/>				
<ul style="list-style-type: none"> <input checked="" type="checkbox"/> = Short on Connector Connection from 24VDC (Pin no. 1) to 0VDC (pin no. 3) 								
Alarms:	AI0 <input type="checkbox"/>	AI1 <input type="checkbox"/>	AI2 <input type="checkbox"/>	AI3 <input type="checkbox"/>				
<ul style="list-style-type: none"> <input type="checkbox"/> = Low Alarm <input type="checkbox"/> = High Alarm 	L: 0.00 H: 24.00	L: 0.00 H: 24.00	L: 0.00 H: 24.00	L: 0.00 H: 24.00				
<input type="checkbox"/> Show I/O Mappings and Sizes								

Shows input signal status

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Error / Event Log:

Keeps a running count of 50 events. First in First out (FIFO)

Event Number	Boot Count	Relative Time (HH:MM:SS.SS)	Description	User Comment	Clear Log
1	1	00:00:00.49	Reboot - build 43227		Add Comment
2	2	00:00:00.85	Reboot - build 43227		Add Comment
3	2	00:00:01.78	I/O Configuration Changed		Add Comment
4	3	00:00:00.49	Reboot - build 43227		Add Comment
5	4	00:00:00.49	Reboot - build 43227		Add Comment
6	5	00:00:00.07	Reboot - build 43227		Add Comment
7	6	00:00:00.07	Firmware reload initiated		Add Comment
8	7	00:00:00.07	Reboot - build 43476		Add Comment
9	7	00:00:00.98	I/O Configuration Changed		Add Comment
10	7	00:01:10.10	Ethernet link lost (Port 0)		Add Comment

Allow user to clear log

Allows user to add comments


Reboot events are shown in red

Show Error/Event Log

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Help:

The “Help” tab is a quick link to Aventics’ website. The computer must have internet access for this tab to be functional.



The screenshot shows the top navigation bar of the Emerson ASCO website. It includes the Emerson logo, a location selector (Set), a 'CONTACT US' button, a 'MY ASCO' button, and social media icons for Facebook, LinkedIn, Twitter, and YouTube. Below the navigation bar is a search bar and a main menu with links for ASCO HOME, PRODUCTS, INDUSTRY SOLUTIONS, TOOLS, LIBRARY, NEWS, and ABOUT. The main content area features the product title 'Numatics G3 Fieldbus Electronics' and a sub-header 'Fieldbus Communication Node, Analog/Digital I/O - DeviceNet, EtherNet, DeviceLogix, Profinet, Profibus - DP, Ethernet, CANopen'. The page is organized into four columns: a product image, a 'FEATURES' list, a 'RESOURCES' list, and an 'APPLICATIONS' list. The 'FEATURES' list includes items like 'Innovative Graphic Display', 'Highly Distributable', and 'IP65 / NEMA 4 Protection'. The 'RESOURCES' list includes 'Series G3/580 Fieldbus Electronics Catalog' and 'G3 Configuration Tutorial Videos'. The 'APPLICATIONS' list includes 'Bottling', 'Life Sciences', and 'Tire Manufacturing'. The 'INDUSTRIES' list includes 'Automotive & Tire' and 'Packaging'.


EMERSON

ASCO HOME | PRODUCTS | INDUSTRY SOLUTIONS | TOOLS | LIBRARY | NEWS | ABOUT

Search...

Numatics G3 Fieldbus Electronics

Fieldbus Communication Node, Analog/Digital I/O - DeviceNet, EtherNet, DeviceLogix, Profinet, Profibus - DP, Ethernet, CANopen



FEATURES

- Innovative Graphic Display is used for easy commissioning, visual status & diagnostics
- Graphic Display for Configuration & Diagnostics
- Highly Distributable
- Auto Recovery Module
- Easy, Robust Connections
- Power connector allows output power to be removed while inputs and communication are left active
- IP65 / NEMA 4 Protection
- Auto Recovery Module (ARM) protects configuration information during a critical failure
- Interfaces to 2002, 2005, 2012, 2035, ISO 15407-2 & ISO 5599/II Valve Series
- Learn more about [DeviceNet](#), [DeviceLogix](#), [Ethernet](#), [Profibus-DP](#), [Profinet](#) & [CANopen](#)

RESOURCES

- [Series G3/580 Fieldbus Electronics Catalog](#)
- [Series G3 Fieldbus Electronics Flyer](#)

TECHNICAL DOCUMENTATION

- [G3/580 Technical and Configuration Files](#)
- [G3 Configuration Tutorial Videos](#)

ACCESSORIES

APPLICATIONS

- [Bottling](#)
- [Life Sciences](#)
- [Press Room & Metal Stamping](#)
- [Tire Manufacturing](#)

INDUSTRIES

- [Automotive & Tire](#)
- [Other Industries](#)
- [Packaging](#)

AVENTICS™ G3 Series EtherCAT™ Technical Manual

13.5 IP Address Configuration

EtherCAT™ fieldbus devices do not communicate using a standard IP address. The Aventics G3 node's IP address is only used to access the nodes integrated web server for configuration and diagnostic information via a personal computer's web browser.

The IP address of the Aventics G3 EtherCAT™ node may only be set once EtherCAT communication is disabled (See page 5-36).

Integrated Web Page Configuration

The Aventics EtherCAT™ node has an integrated web server. This server can be accessed via any standard web browser program through a properly configured EtherCAT™ master device. With the IP Address, the "Node Configuration" page for the node can be accessed and the configuration parameters changed. Please note that the PC, where the web browser is installed, must be correctly configured for operation with the appropriate network IP ranges and subnet settings that match the EtherCAT™ master device configuration.



- Consult appropriate personnel before changing your computer's network settings and always record previous settings for later reversal before attempting changes.

Below is a representation of the "Node Configuration" page which is stored in the EtherCAT™ node. The IP address and Subnet Mask selections cannot be modified from this page. These parameters will be programmed in the node's non-volatile FLASH memory once "Update Configuration" is clicked, and power to the node is cycled.



Node Configuration	
(Green selections denote Factory Default settings)	
Station Alias:	3
Web Server:	Enabled
Max Coils on Manifold (32 = Standard):	32
Safety Zones (Only configurable when Max Coils = 32):	None
COMM Fault / Idle Mode:	Turn OFF All Outputs
Diagnostic Word:	Mapped
I/O (Diagnostics) Status:	Mapped
Node Configuration Parameters:	Unlocked
I/O Configuration:	Unlocked
Display Orientation (Global):	Normal
Display Brightness (Global):	Medium

Update Configuration

AVENTICS™ G3 Series EtherCAT™ Technical Manual

13.6 User Configurable Device Parameters

The Aventics' G3 EtherCAT™ node allows the user to set many user options which define how the manifold behaves in certain instances. The following is a description of these device parameters.

<i>Name</i>	<i>Description</i>	<i>Settable Via</i>	
		<i>Display</i>	<i>Web Server</i>
IP Address	Sets the IP address to access the node web page	X	X
Gateway IP	Set the Gateway IP address	X	X
Params Lock	Selects Parameters Locked/Unlocked	✓	✓
Config Lock	Selects I/O Configuration Locked/Unlocked	✓	✓
Diagnostic Word	Enables / Disables the diagnostic word	✓	X
I/O Diagnostic Status	Allocates I/O diagnostic status bits	✓	X
Output Fault Action	Determines whether to use idle value attribute or hold last state	✓	X

13.7 Parameters Lock

This parameter lock is used to lock out changes to all node configuration parameters (except parameter lock). Once the manifold is commissioned the Parameters lock should be set to "LOCKED" to ensure that parameters are not unintentionally modified.

13.8 I/O Configuration Lock

This I/O configuration lock parameter is used to lock the I/O configuration of the manifold. The manifold's I/O configuration map is determined on power-up of the node. Once the manifold is commissioned the I/O configuration lock should be set to "LOCKED" to ensure the I/O will not re-map in the event of an I/O module failure. If an I/O module fails with configuration locked the node will report an I/O module missing at the location of the failed module.

13.9 Communication Fault Mode Parameter

This parameter is used to describe characteristics or behaviors of output points (bits). The parameter shown below is used to determine what state the outputs will have, during a "Fault" event. The Communication Fault Mode parameter will allow control of all output points on the manifold.

The user, through PLC configuration settings, can determine how the outputs behave when a communication fault action occurs. These settings are non-volatile and thus will not change upon loss of power.

The two behavior options are:


1. Turn Off All Outputs
2. Maintain Last Output State

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Communication Fault Sequence

The Communication Fault parameter determines the output state if the device encounters a communication fault. A Communication Fault is defined as an inability for the master node to communicate with a slave node on a network. The process for determining the output state during a Communication Fault/Idle Mode is as follows:

1. The device receives a Communication Fault event.
2. The device determines what action to take based on the Communication Fault attribute setting configured in the G3 EtherCAT™ node advanced parameters.
3. If the attribute is set to turn off all outputs, all of the outputs will turn off (Factory Default Setting).
4. If the attribute is set to hold last state, all of the outputs will hold their last state.




AVENTICS™ G3 Series EtherCAT™ Technical Manual

14. G3 EtherCAT™ PLC Configuration

14.1 Create Aventics G3 EtherCAT™ configuration (Beckhoff PLC)


The following example illustrates the necessary steps to add a Aventics G3 EtherCAT™ Manifold to an existing Beckhoff PLC configuration. This includes how to install the Aventics EtherCAT™ XML file and how to select the various software components to configure a G3 Manifold (GSD and XML files are available at www.asco/g3.com). The following examples assume an existing configuration based on Beckhoff TwinCAT System Manager Ver. 2.11 programming software.

Copy the current "Aventics-G3.XML" file to the following directory; C:\TwinCAT\IO\EtherCAT




AVENTICS™ G3 Series EtherCAT™ Technical Manual

Add the G3 EtherCAT™ node
Launch TwinCAT “System Manager”
Select I/O Configuration
Expand I/O Devices




Right Click I/O Devices
Select Append Box




AVENTICS™ G3 Series EtherCAT™ Technical Manual

The “Insert EtherCAT™ Device” Dialogue Box Appears
Select the “Numatics Inc.” Device Folder




Double Click Numatics G3




AVENTICS™ G3 Series EtherCAT™ Technical Manual

Create the G3 I/O mapping
Expand the “Numatics G3” Box (device)




Press the “Linked to” button to select an input variable (byte) to map to the G3 manifold
*Note- the I/O variables must already exist within the associated PLC Control Project




AVENTICS™ G3 Series EtherCAT™ Technical Manual

Select the Variable tag(s) from the PLC program to associate with the G3 Input Byte(s)



Expand the Numatics G3 Outputs list

Press the "Linked to" button to select an output variable (byte) to map to the G3 manifold
Select the Variable tag(s) from the PLC program to associate with the G3 Output Byte(s)




AVENTICS™ G3 Series EtherCAT™ Technical Manual

14.3 Twincat configuration for IP communication over EtherCAT™ (Beckhoff PLC)


This configuration is required for a PC to communicate with the G3 node web page through the EtherCAT™ master device.

- Expand the “Numatics G3” Box (device)
- Select the EtherCAT™ tab
- Click advanced settings




AVENTICS™ G3 Series EtherCAT™ Technical Manual

Expand the mailbox item
Select EOE (Ethernet over EtherCAT™)



Check "Virtual Ethernet Port"
Select "IP Port"



AVENTICS™ G3 Series EtherCAT™ Technical Manual


Select the box for IP Address

Enter an IP address of the G3 EtherCAT™ node


Enter the Subnet mask

Enter the default Gateway (The gateway must be the same as the Beckhoff controller's virtual port address)

Enter the DNS name "netx"



"Activate" the configuration



AVENTICS™ G3 Series EtherCAT™ Technical Manual

14.4 Configure IP communication with G3 over EtherCAT™ (Beckhoff PLC)

The Beckhoff PLC must be specifically configured to allow ethernet communications with the G3 node to access the G3 web page. This is accomplished by connecting a PC to the EtherCAT™ master device's ethernet port and connecting to the G3 node via ethernet over Ethercat™ (EoE) using the PLC's virtual Ethernet port. The Beckhoff virtual Ethernet port address is configured within the Beckhoff PC/PLC configuration (refer to your specific Beckhoff PLC's documentation for more information).

To access the G3 web page over EtherCAT™ the following settings must be configured on the Beckhoff PLC (master device) and the PC.

Set the PLC Ethernet communication port and the PC used to access the web page to the same subnet.

Set the Beckhoff PLC's virtual Ethernet port address setting to a different subnet.

Open the Beckhoff PLC's configuration "TCIP settings" select "IP Routing".


- Your PC:
 - o IP Address: 192.168.1.10
 - o Subnet Mask: 255.255.255.0
- X2 Interface on PLC (as identified by Beckhoff)
 - o IP Address: 192.168.1.20 (same subnet as PC)
 - o Subnet Mask: 255.255.255.0
- MP1 Interface on PLC (Virtual Ethernet port to access the EtherCAT™ network):
 - o IP Address: 192.168.3.20 (different subnet than PC)
 - o Subnet Mask: 255.255.255.0
- Numatics "Box" configuration in TwinCAT
 - o IP Address: 192.168.3.120 (same subnet as X1/MP1 interface)
 - o Subnet Mask: 255.255.255.0
 - o Gateway IP: 192.168.3.1 (same address as virtual Ethernet port)
- From a DOS/CMD prompt (run as administrator on Win7) enter the following command:
 - o route add 192.168.3.0 mask 255.255.255.0 192.168.1.20 metric 1
 - The first address is the subnet address of the "MP1" and the Numatics "Box".
 - The second address is the IP Address of the "X2" interface.
 - This tells the PC: any packets bound for 192.168.3.XXX should be sent to 192.168.1.20, i.e. to the PLC. The PLC then routes them to the other interface (due to checking of the "IP Routing" check box in the CX Configuration).
 - The command should respond with "Ok"

AVENTICS™ G3 Series EtherCAT™ Technical Manual

14.5 Create Aventics G3 EtherCAT™ configuration (Lenze PLC)


The following example illustrates the necessary steps to add a Aventics G3 EtherCAT™ Manifold to an existing Lenze PLC configuration. This includes how to install the Aventics EtherCAT™ XML file and how to select the various software components to configure a G3 Manifold (GSD and XML files are available at www.asco.com/g3). The following examples assume an existing configuration based on Lenze PLC Designer V3.8 programming software.

- Install the Aventics G3 XML file
- Launch PLC Designer V3.8 and
- Select Tools from the main menu
- Select Device Repository




AVENTICS™ G3 Series EtherCAT™ Technical Manual

Configure the location of the Aventics G3 XML file
Select Install




Select the XML file




AVENTICS™ G3 Series EtherCAT™ Technical Manual

Add the G3 EtherCAT™ node
PLC Designer V3.8
Select the EtherCAT™ Master from the Project Tree
Right Click and Select Add Device




AVENTICS™ G3 Series EtherCAT™ Technical Manual

Select the Numatics G3
Select Add Device




Double Click Numatics G3




AVENTICS™ G3 Series EtherCAT™ Technical Manual

Select the PLC Program Tab



Create the G3 I/O Program (Byte) Variables that will connect to the G3 I/O map
Example Outputs – OutB0, OutB1, OutB2 etc.
Example Inputs – InB0, InB1, InB2 etc.




AVENTICS™ G3 Series EtherCAT™ Technical Manual


Map the G3 I/O data to program variables

Select the Mapping reference for %QB0 (byte 0 Output data)

Press the Radio button to launch the Input Assistant (PLC variables table)



Select the Variable that will reference Byte 0 of G3 Outputs



AVENTICS™ G3 Series EtherCAT™ Technical Manual

Complete Mapping all necessary G3 Output Data to PLC variables

The screenshot shows the 'EtherCAT I/O Mapping' configuration window. The 'Channels' table is as follows:

Variable	Mapping	Channel	Address	Type	Default Value	Unit	Description
Application.PLC_PRG.OutB0		Out000	%QB1	BYTE			Out000
Application.PLC_PRG.OutB1		Out001	%QB2	BYTE			Out001
Application.PLC_PRG.OutB2		Out002	%QB3	BYTE			Out002
Application.PLC_PRG.OutB3		Out003	%QB4	BYTE			Out003
Application.PLC_PRG.OutB4		Out004	%QB5	BYTE			Out004
		Out005	%QB6	BYTE			Out005
		Out006	%QB7	BYTE			Out006
		Out007	%QB8	BYTE			Out007
		Out008	%QB9	BYTE			Out008
		Out009	%QB10	BYTE			Out009
		Out010	%QB11	BYTE			Out010
		Out011	%QB12	BYTE			Out011

The 'IEC Objects' table shows:

Variable	Mapping	Type
Numatics_G3		ETCSlave

Legend: = Create new variable, = Map to existing variable

Complete Mapping all necessary G3 Input Data to PLC variables

The screenshot shows the 'EtherCAT I/O Mapping' configuration window. The 'Channels' table is as follows:

Variable	Mapping	Channel	Address	Type	Default Value	Unit	Description
		Out145	%QB146	BYTE			Out145
		Out146	%QB147	BYTE			Out146
		Out147	%QB148	BYTE			Out147
		Out148	%QB149	BYTE			Out148
		Out149	%QB150	BYTE			Out149
Application.PLC_PRG.InB0		In000	%IB0	BYTE	0		In000
Application.PLC_PRG.InB1		In001	%IB1	BYTE	0		In001
Application.PLC_PRG.InB2		In002	%IB2	BYTE	0		In002
		In003	%IB11	BYTE	0		In003
		In004	%IB12	BYTE	0		In004
		In005	%IB13	BYTE	0		In005
		In006	%IB14	BYTE	0		In006

The 'IEC Objects' table shows:

Variable	Mapping	Type
Numatics_G3		ETCSlave

Legend: = Create new variable, = Map to existing variable

AVENTICS™ G3 Series EtherCAT™ Technical Manual

14.7 Create Aventics G3 EtherCAT™ configuration (Omron PLC)


The following example illustrates the necessary steps to add an Aventics G3 EtherCAT™ Manifold to an existing Omron PLC configuration. This includes how to install the Aventics EtherCAT™ XML file and how to select the various software components to configure a G3 Manifold (XML files are available at www.asco.com/g3). The following examples assume an existing configuration based on Omron Sysmac Studio (V 1.13).

Install the Aventics G3 XML file

Copy the current Aventics XML file into the following Sysmac Studio directory.

Program Files\Omron\Sysmac Studio\IODeviceProfiles\EsiFiles\UserEsiFiles

Launch Sysmac Studio



AVENTICS™ G3 Series EtherCAT™ Technical Manual


Add the G3 EtherCAT™ node

Open the Sysmac Studio project

Double click EtherCAT™


Scroll through the devices under the toolbox list at the right to find the Numatics G3

Drag the Numatics G3 to the EtherCat™ master



AVENTICS™ G3 Series EtherCAT™ Technical Manual

Configure the G3 EtherCat™ Node Address
Set the G3 Station Alias to match the Omron Node Address setting
For more information on setting Station Alias; see page 5-32



AVENTICS™ G3 Series EtherCAT™ Technical Manual

Assign Variables to the G3 I/O map data for the PLC program
 Build the Controller project and Transfer to controller

Position	Port	Description	R/W	Data Type	Variable	Variable Comment	Variable Type
	EtherCAT Network Configuration						
EtherCAT	Master						
Node1	Numatics G3						
	Outputs0_Out000_2000_01		W	BYTE	G3_CoilByte_0	Coils 1-8 of Numatics Manifold	Global Variables
	Outputs0_Out001_2000_02		W	BYTE	G3_CoilByte_1	Coils 9-16 of Numatics Manifold	Global Variables
	Outputs0_Out002_2000_03		W	BYTE			
	Outputs0_Out003_2000_04		W	BYTE			
	Outputs0_Out004_2000_05		W	BYTE			
	Outputs0_Out005_2000_06		W	BYTE			

15. EtherCAT™ Mapping

15.1 I/O Sizes

Manifold

Outputs

Outputs are defined as any valve solenoid coil and/or any discrete output point from any output module. The output size depends upon the physical configuration of the manifold (i.e. module type and how many are used). Please reference the following pages for a detailed explanation for calculating the output size.

Inputs

Inputs are defined as physical input bits from input modules and status bits (i.e. diagnostic word generated by the node, status input bits produced by output drivers and SCP status bits). Thus, the input size will include physical input points, as well as status input bits. Please reference the following pages for a detailed explanation for calculating the input size.

Valve Side

The size for the “valve side” of the manifold consists of an output bit for each valve solenoid coil driver and an input bit for the corresponding diagnostic status input bit. This value for the valve side size is 4 bytes of inputs and 4 bytes of outputs.

Discrete Side

The discrete side of the manifold is defined as all I/O modules connected to the left of the communication node. This includes physically attached modules as well as any distributed sub-bus modules. I/O sizes for the discrete side are automatically configured based on the I/O module type installed. However, the user can affect these sizes manually via settable parameters on the node. The output value consists of physical outputs (i.e. output bit for each output point). The input value consists of physical inputs (i.e. input bit for each input point) and user settable status input bits for corresponding physical outputs and SCP status bits.

Total I/O Size

The overall size of the I/O data for the manifold will consist of the valve size plus the discrete I/O size and all enabled Diagnostic bits. The I/O size can vary greatly, due to the many physical configuration and user settable parameters combinations. The following worksheet will allow accurate sizing of the I/O data.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

15.3 Manifold and I/O Data Sizing Worksheet

- 1** : Choose appropriate value and place the corresponding Input and Output values in the boxes labeled, "Valve Byte Requirements" at the bottom of the page
- 2** : Choose up to sixteen modules to be included on the discrete I/O side of the manifold and place sum of the corresponding input bytes and output bytes in the boxes labeled, "Sub-Bus Byte Requirements" at the bottom of the page.
- 3** : Total the input bytes and output bytes values from the boxes labeled "Sub-Bus Byte Requirements" and "Valve Byte Requirements" in the boxes labeled "Total Input and Output Bytes for Manifold". This is the total input and output byte values required for the configured manifold.

Valve Side					
Step	Valve Side		Input Bytes		Output Bytes
			Status Enabled	Status Disabled	
1	Up to 32 Solenoid Coils		4	0	4

Digital Modules					
Step	Module No.	Description	Input Bytes		Output Bytes
			Status Enabled	Status Disabled	
2	240-203/204	16 Inputs	3	2	0
	240-205/209	16 Inputs	3	2	0
	240-206/210/379	8 Inputs	2	1	0
	240-207	16 Outputs	2	0	2
	240-208	8 Outputs	1	0	1
	240-211	8 Inputs / 8 Outputs	3	1	1
	240-241	Sub – Bus Valve Output	4	0	4
	240-300	High Current 8 Outputs	1	0	1

Analog Modules					
Step	Module No.	Description	Input Bytes		Output Bytes
			Status Enabled	Status Disabled	
2	240-212/214	4 Inputs	10	8	0
	240-213/215/307	2 Inputs/ 2 Outputs	6	4	4

Total Input/Output Size Calculation					
Step	Module Position	Model Number	Input Bytes	Output Bytes	
2	1 st				
	2 nd				
	3 rd				
	4 th				
	5 th				
	6 th				
	7 th				
	8 th				
	9 th				
	10 th				
	11 th				
	12 th				
	13 th				
	14 th				
	15 th				
			Sub-Bus Byte Requirements:		
		Optional Diagnostic Word:	2	0	
1		Valve Byte Requirements:			
3	Total Input and Output Bytes for Manifold				

AVENTICS™ G3 Series EtherCAT™ Technical Manual

15.4 Bit Mapping Rules

The bit mapping for a G3 manifold varies with the physical configuration of the manifold. The following is a breakdown of the bit mapping rules associated with the Aventics valve manifold.

Valve Side

- 1) Solenoid coil outputs are connected to the valve coils using the Z-Boards™.
- 2) The valve solenoid coil output portion of the total output size is fixed at 4 bytes.
- 3) Solenoid coil output addressing begins at the 1st manifold station nearest the node using “14” coil 1st and then, if applicable, the “12” coil, and continues in ascending order away from the communication node.
- 4) Each manifold station allocates 1 or 2 output bits. This is dependent on the Z-Board™ type installed. A single Z-Board™ allocates 1 output bit. A double Z-Board™ allocates 2 output bits.
- 5) Z-Boards™ can be used in any arrangement (all singles, all doubles, or any combination) as long as output group No.1 and output group No. 2 bits do not overlap (i.e. combinations of Z-Boards™ could exist where the physical configuration of the manifold could exceed the output capacity).



Single solenoid valves can be used with double Z-Boards™. However, one of the two available outputs will remain unused.

Discrete I/O Side

Outputs

- 1) The Sub-Bus output byte size portion is self-configuring in byte increments, after an output module is installed on the Sub-Bus and power is applied.
- 2) Outputs are mapped consecutively by module. The output bits from the 1st module will be mapped directly after the bits from the valve coils. The output bits from the second module will be mapped directly after the output bits from the 1st module and so on.

Inputs

- 1) The Sub-Bus input byte size portion is self-configuring in byte increments, after an input module is plugged into back plane and power is applied.
- 2) Inputs are mapped consecutively by module. The input bits from the 1st module will be mapped directly after the status bits from the valve side. The input bits from the second module will be mapped directly after the input bits from the 1st module and so on.
- 3) All of the modules have associated internal status bits, which will affect the total value of input bytes.
- 4) When a module has discrete and status inputs, the status bits are mapped after the discrete input bits.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

I/O Mapping Examples

Assumed Settings

Example No. 1

- Double Z-Boards™ used with all valves
- I/O Modules and mapping schemes are identified by their corresponding color.
- I/O Status bits are enabled
- Diagnostic Word is enabled


Manifold I/O Configuration

Pos No.	Module Type	Part No.	In	Out
			Bytes	
1	16I PNP	240-205	3	0
2	4AI Analog	240-212	10	0
Diagnostic Word			2	0
Local Valve Size			4	4

Total: 19 4

How to Order

Qty	Part Number
1	8502AV3F300VA00
2	R502A1B10MA00F1
1	K502AMM22MA0010
1	R502A1B10MA00F1
1	R502A1B40MA00F1
1	K502AMM22MA0010
2	R502A1B40MA00F1
1	K502AMM22MA0010
1	G3EC102R0E44
1	240-205
1	240-212
	ASSEMBLED




AVENTICS™ G3 Series EtherCAT™ Technical Manual

Example No. 1 Table

Output Table								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Valve Coil No. 7	Valve Coil No. 6	Valve Coil No. 5	Valve Coil No. 4	Valve Coil No. 3	Valve Coil No. 2	Valve Coil No. 1	Valve Coil No. 0
1	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Valve Coil No. 11	Valve Coil No. 10	Valve Coil No. 9	Valve Coil No. 8
2	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved
3	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved

Input Table								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0 (Optional)	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit
1 (Optional)	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit
2 (Optional)	Coil No. 7 Status	Coil No. 6 Status	Coil No. 5 Status	Coil No. 4 Status	Coil No. 3 Status	Coil No. 2 Status	Coil No. 1 Status	Coil No. 0 Status
3 (Optional)	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Coil No. 11 Status	Coil No. 10 Status	Coil No. 9 Status	Coil No. 8 Status
4 (Optional)	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved
5 (Optional)	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved
6	Discrete Input No. 7	Discrete Input No. 6	Discrete Input No. 5	Discrete Input No. 4	Discrete Input No. 3	Discrete Input No. 2	Discrete Input No. 1	Discrete Input No. 0
7	Discrete Input No. 15	Discrete Input No. 14	Discrete Input No. 13	Discrete Input No. 12	Discrete Input No. 11	Discrete Input No. 10	Discrete Input No. 9	Discrete Input No. 8
8 (Optional)	Power Status for Conn. H	Power Status for Conn. G	Power Status for Conn. F	Power Status for Conn. E	Power Status for Conn. D	Power Status for Conn. C	Power Status for Conn. B	Power Status for Conn. A
9	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1 (LSB)
10	Analog Input No. 1 (MSB)	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1
11	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2 (LSB)
12	Analog Input No. 2 (MSB)	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2
13	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3 (LSB)
14	Analog Input No. 3 (MSB)	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3
15	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4 (LSB)
16	Analog Input No.4 (MSB)	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4
17 (Optional)	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Power Status for Conn. D	Power Status for Conn. C	Power Status for Conn. B	Power Status for Conn. A
18 (Optional)	High Alarm for Conn. D	Low Alarm for Conn. D	High Alarm for Conn. C	Low Alarm for Conn. C	High Alarm for Conn. B	Low Alarm for Conn. B	High Alarm for Conn. A	Low Alarm for Conn. A



• The Comm. Module Diagnostic Bits, Sub-Bus Diagnostic Bits, Coil Status Bits and Power Status Bits are optional. The factory default condition is Diagnostic bits enabled. These bits may be disabled to optimize the logical size of the manifold.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Assumed Settings

Example No. 2


- a. Double Z-Boards™ used with all valves
- b. I/O Modules and mapping schemes are identified by their corresponding color.
- c. I/O Status bits are enabled
- d. Diagnostic Word is enabled

Manifold I/O Configuration

Pos. No.	Module Type	Part No.	In	Out
			Bytes	
		Diagnostic Word	2	0
		Local Valve Size:	4	4
		Total:	6	4

How to Order

Qty	Part Number
1	8502AV3F300VA00
2	R502A1B10MA00F1
1	K502AMM22MA0010
1	R502A1B10MA00F1
1	R502A1B40MA00F1
1	K502AMM22MA0010
2	R502A1B40MA00F1
1	K502AMM22MA0010
1	G3EC100R0E44
	ASSEMBLED



AVENTICS™ G3 Series EtherCAT™ Technical Manual

Example No. 2 Table

Output Table								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Valve Coil No. 7	Valve Coil No. 6	Valve Coil No. 5	Valve Coil No. 4	Valve Coil No. 3	Valve Coil No. 2	Valve Coil No. 1	Valve Coil No. 0
1	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Valve Coil No. 11	Valve Coil No. 10	Valve Coil No. 9	Valve Coil No. 8
2	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved
3	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved

Input Table								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0 (Optional)	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit
1 (Optional)	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit
2 (Optional)	Coil No. 7 Status	Coil No. 6 Status	Coil No. 5 Status	Coil No. 4 Status	Coil No. 3 Status	Coil No. 2 Status	Coil No. 1 Status	Coil No. 0 Status
3 (Optional)	Coil No. 15 Status	Coil No. 14 Status	Coil No. 13 Status	Coil No. 12 Status	Coil No. 11 Status	Coil No. 10 Status	Coil No. 9 Status	Coil No. 8 Status
4 (Optional)	Coil No. 23 Status	Coil No. 22 Status	Coil No. 21 Status	Coil No. 20 Status	Coil No. 19 Status	Coil No. 18 Status	Coil No. 17 Status	Coil No. 16 Status
5 (Optional)	Coil No. 31 Status	Coil No. 30 Status	Coil No. 29 Status	Coil No. 28 Status	Coil No. 27 Status	Coil No. 26 Status	Coil No. 25 Status	Coil No. 24 Status



- *The Comm. Module Diagnostic Bits, Sub-Bus Diagnostic Bits, Coil Status Bits and Power Status Bits are optional. The factory default condition is Diagnostic bits are enabled. These bits may be disabled to optimize the logical size of the manifold*

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Assumed Settings

Example No. 3

- Double Z-Boards™ used with all valves
- I/O Modules and mapping schemes are identified by their corresponding color.
- I/O Status bits are enabled
- Diagnostic Word is enabled


Manifold I/O Configuration

Pos No.	Module Type	Part No.	In	Out
			Bytes	
1	16I PNP	240-205	3	0
2	4AI Analog	240-212	10	0
3	16I PNP	240-203	3	0
Diagnostic Word			2	0
Local Valves:			4	4

Total: 22 4

How to Order

Qty	Part Number
1	8503AV3F300VA00
2	R502A1B10MA00F1
1	K502AMM22MA0010
1	R502A1B10MA00F1
1	R502A1B40MA00F1
1	K502AMM22MA0010
2	R502A1B40MA00F1
1	K502AMM22MA0010
1	G3EC103D0E44
1	240-205
1	240-212
1	240-203
	ASSEMBLED



AVENTICS™ G3 Series EtherCAT™ Technical Manual

Example No. 3 Table

Output Table								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Valve Coil No. 7	Valve Coil No. 6	Valve Coil No. 5	Valve Coil No. 4	Valve Coil No. 3	Valve Coil No. 2	Valve Coil No. 1	Valve Coil No. 0
1	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Valve Coil No. 11	Valve Coil No. 10	Valve Coil No. 9	Valve Coil No. 8
2	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved
3	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved

Input Table								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0 (Optional)	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit
1 (Optional)	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit
2 (Optional)	Coil No. 7 Status	Coil No. 6 Status	Coil No. 5 Status	Coil No. 4 Status	Coil No. 3 Status	Coil No. 2 Status	Coil No. 1 Status	Coil No. 0 Status
3 (Optional)	Coil No. 15 Status	Coil No. 14 Status	Coil No. 13 Status	Coil No. 12 Status	Coil No. 11 Status	Coil No. 10 Status	Coil No. 9 Status	Coil No. 8 Status
4 (Optional)	Coil No. 23 Status	Coil No. 22 Status	Coil No. 21 Status	Coil No. 20 Status	Coil No. 19 Status	Coil No. 18 Status	Coil No. 17 Status	Coil No. 16 Status
5 (Optional)	Coil No. 31 Status	Coil No. 30 Status	Coil No. 29 Status	Coil No. 28 Status	Coil No. 27 Status	Coil No. 26 Status	Coil No. 25 Status	Coil No. 24 Status
6	Discrete Input No. 7	Discrete Input No. 6	Discrete Input No. 5	Discrete Input No. 4	Discrete Input No. 3	Discrete Input No. 2	Discrete Input No. 1	Discrete Input No. 0
7	Discrete Input No. 15	Discrete Input No. 14	Discrete Input No. 13	Discrete Input No. 12	Discrete Input No. 11	Discrete Input No. 10	Discrete Input No. 9	Discrete Input No. 8
8 (Optional)	Power Status for Conn. H	Power Status for Conn. G	Power Status for Conn. F	Power Status for Conn. E	Power Status for Conn. D	Power Status for Conn. C	Power Status for Conn. B	Power Status for Conn. A
9	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1 (LSB)
10	Analog Input No. 1 (MSB)	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1
11	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2 (LSB)
12	Analog Input No. 2 (MSB)	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2
13	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3 (LSB)
14	Analog Input No. 3 (MSB)	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3
15	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4 (LSB)
16	Analog Input No. 4 (MSB)	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4
17 (Optional)	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Power Status for Conn. D	Power Status for Conn. C	Power Status for Conn. B	Power Status for Conn. A
18 (Optional)	High Alarm for Conn. D	Low Alarm for Conn. D	High Alarm for Conn. C	Low Alarm for Conn. C	High Alarm for Conn. B	Low Alarm for Conn. B	High Alarm for Conn. A	Low Alarm for Conn. A
19	Discrete Input No. 7	Discrete Input No. 6	Discrete Input No. 5	Discrete Input No. 4	Discrete Input No. 3	Discrete Input No. 2	Discrete Input No. 1	Discrete Input No. 0
20	Discrete Input No. 15	Discrete Input No. 14	Discrete Input No. 13	Discrete Input No. 12	Discrete Input No. 11	Discrete Input No. 10	Discrete Input No. 9	Discrete Input No. 8
21 (Optional)	Power Status for Conn. H	Power Status for Conn. G	Power Status for Conn. F	Power Status for Conn. E	Power Status for Conn. D	Power Status for Conn. C	Power Status for Conn. B	Power Status for Conn. A

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Assumed Settings

Example No. 4

- a. Double Z-Boards™ used with all valves
- b. I/O Modules and mapping schemes are identified by their corresponding color.
- c. I/O Status bits are enabled
- d. Diagnostic Word is enabled


Manifold I/O Configuration

Pos No.	Module Type	Part No.	In Out	
			Bytes	
1	16I PNP	240-205	3	0
2	4I Analog	240-212	10	0
3	16I PNP	240-205	3	0
4	16I PNP	240-205	3	0
Diagnostic Word			2	0
Local Valves:			4	4

Total: 18 4

How to Order

Qty	Part Number
1	8503AV3F300VA00
2	R501A1B10MA00F1
1	K502AMM22MA0010
1	R501A1B10MA00F1
1	R501A1B40MA00F1
1	K502AMM22MA0010
2	R501A1B40MA00F1
1	K502AMM22MA0010
1	G3EP102D0E44
1	240-205
1	240-212
	ASSEMBLED
1	G3DS302R0STD
1	240-205
1	240-205
	ASSEMBLED



Valve Coil Number

When the 12 End Solenoid is energized, the 2 port is pressurized

When the 14 End Solenoid is energized, the 4 port is pressurized

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Example No. 4 Table

Output Table								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Valve Coil No. 7	Valve Coil No. 6	Valve Coil No. 5	Valve Coil No. 4	Valve Coil No. 3	Valve Coil No. 2	Valve Coil No. 1	Valve Coil No. 0
1	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Valve Coil No. 11	Valve Coil No. 10	Valve Coil No. 9	Valve Coil No. 8
2	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved
3	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved

Input Table								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0 (Optional)	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit	Comm. Module Diagnostic Bit
1 (Optional)	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit	Sub-bus Diagnostic Bit
2 (Optional)	Coil No. 7 Status	Coil No. 6 Status	Coil No. 5 Status	Coil No. 4 Status	Coil No. 3 Status	Coil No. 2 Status	Coil No. 1 Status	Coil No. 0 Status
3 (Optional)	Coil No. 15 Status	Coil No. 14 Status	Coil No. 13 Status	Coil No. 12 Status	Coil No. 11 Status	Coil No. 10 Status	Coil No. 9 Status	Coil No. 8 Status
4 (Optional)	Coil No. 23 Status	Coil No. 22 Status	Coil No. 21 Status	Coil No. 20 Status	Coil No. 19 Status	Coil No. 18 Status	Coil No. 17 Status	Coil No. 16 Status
5 (Optional)	Coil No. 31 Status	Coil No. 30 Status	Coil No. 29 Status	Coil No. 28 Status	Coil No. 27 Status	Coil No. 26 Status	Coil No. 25 Status	Coil No. 24 Status
6	Discrete Input No. 7	Discrete Input No. 6	Discrete Input No. 5	Discrete Input No. 4	Discrete Input No. 3	Discrete Input No. 2	Discrete Input No. 1	Discrete Input No. 0
7	Discrete Input No. 15	Discrete Input No. 14	Discrete Input No. 13	Discrete Input No. 12	Discrete Input No. 11	Discrete Input No. 10	Discrete Input No. 9	Discrete Input No. 8
8 (Optional)	Power Status for Conn. H	Power Status for Conn. G	Power Status for Conn. F	Power Status for Conn. E	Power Status for Conn. D	Power Status for Conn. C	Power Status for Conn. B	Power Status for Conn. A
9	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1 (LSB)
10	Analog Input No. 1 (MSB)	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1	Analog Input No. 1
11	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2 (LSB)
12	Analog Input No. 2 (MSB)	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2	Analog Input No. 2
13	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3 (LSB)
14	Analog Input No. 3 (MSB)	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3	Analog Input No. 3
15	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4 (LSB)
16	Analog Input No. 4 (MSB)	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4	Analog Input No. 4
17 (Optional)	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Allocated and Reserved	Power Status for Conn. D	Power Status for Conn. C	Power Status for Conn. B	Power Status for Conn. A
18 (Optional)	High Alarm for Conn. D	Low Alarm for Conn. D	High Alarm for Conn. C	Low Alarm for Conn. C	High Alarm for Conn. B	Low Alarm for Conn. B	High Alarm for Conn. A	Low Alarm for Conn. A
19	Discrete Input No. 7	Discrete Input No. 6	Discrete Input No. 5	Discrete Input No. 4	Discrete Input No. 3	Discrete Input No. 2	Discrete Input No. 1	Discrete Input No. 0
20	Discrete Input No. 15	Discrete Input No. 14	Discrete Input No. 13	Discrete Input No. 12	Discrete Input No. 11	Discrete Input No. 10	Discrete Input No. 9	Discrete Input No. 8
21 (Optional)	Power Status for Conn. H	Power Status for Conn. G	Power Status for Conn. F	Power Status for Conn. E	Power Status for Conn. D	Power Status for Conn. C	Power Status for Conn. B	Power Status for Conn. A
22	Discrete Input No. 7	Discrete Input No. 6	Discrete Input No. 5	Discrete Input No. 4	Discrete Input No. 3	Discrete Input No. 2	Discrete Input No. 1	Discrete Input No. 0
23	Discrete Input No. 15	Discrete Input No. 14	Discrete Input No. 13	Discrete Input No. 12	Discrete Input No. 11	Discrete Input No. 10	Discrete Input No. 9	Discrete Input No. 8
24 (Optional)	Power Status for Conn. H	Power Status for Conn. G	Power Status for Conn. F	Power Status for Conn. E	Power Status for Conn. D	Power Status for Conn. C	Power Status for Conn. B	Power Status for Conn. A

AVENTICS™ G3 Series EtherCAT™ Technical Manual

15.5 I/O Mapped Diagnostic Word

<i>Diagnostic Word Format</i>								
BYTE	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0 (Comm. Status)	Reserved	Reserved	Reserved	Reserved	Sub-Bus Short Circuit (1 = Error)	Sub-Bus Error (1=Error)	Un-Switched Power Status (1=Error)	Switched Power Status (1=Error)
1 (Sub-Bus Status)	Error Code	Error Code	Error Code	Module Address	Module Address	Module Address	Module Address	Module Address

Byte 0 (Communication Status)

Byte 0, Bit 0 Switched Power Status = Bit is high when valve / output power is not present on the comm. module.

Byte 0, Bit 1 Un-switched Power Status = Bit is high when node / input power is below 19VDC

Byte 0, Bit 2 Sub-Bus Error = Bit is high when there is an error on the sub-bus; see "Byte 1" of the diagnostic word for description.

Byte 0, Bit 3 Sub-Bus Short Circuit = A short circuit has been detected across the Sub-Bus

AVENTICS™ G3 Series EtherCAT™ Technical Manual

I/O Mapped Diagnostic Word Continued

Byte 1 (Sub-Bus Status)

Module Address

Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Description
0	0	0	0	0	No error
0	0	0	0	1	Communication Module
0	0	0	1	0	I/O module No. 1
0	0	0	1	1	I/O module No. 2
0	0	1	0	0	I/O module No. 3
0	0	1	0	1	I/O module No. 4
0	0	1	1	0	I/O module No. 5
0	0	1	1	1	I/O module No. 6
0	1	0	0	0	I/O module No. 7
0	1	0	0	1	I/O module No. 8
0	1	0	1	0	I/O module No. 9
0	1	0	1	1	I/O module No. 10
0	1	1	0	0	I/O module No. 11
0	1	1	0	1	I/O module No. 12
0	1	1	1	0	I/O module No. 13
0	1	1	1	1	I/O module No. 14
1	0	0	0	0	I/O module No. 15
1	0	0	0	1	I/O module No. 16
1	0	0	1	1	Communication Valve driver
1	0	1	0	0	ARM
X	X	X	X	X	N/A

Sub-Bus Errors

Error Code	Bit 7	Bit 6	Bit 5
0	0	0	0
1	0	0	1
2	0	1	0
3	0	1	1
4	1	0	0
5	1	0	1
6	1	1	0
7	1	1	1

Error Code 0 = No Errors

Error Code 1 = Lost communications between I/O module and communications module

Error Code 2 = Valve / Output power is below 19VDC

Error Code 3...7 = not defined / reserved

AVENTICS™ G3 Series EtherCAT™ Technical Manual

16. Appendix

16.1 System Specifications

<i>Electrical</i>	
Supply Voltage	Valves (2005, 2012, 2035): 24 VDC + 10%, -15% Valves (501, 502, 503): 24 VDC +/- 10% Node and Discrete I/O: 24 VDC ± 10%
Current	Total current on the Auxiliary Power Connector ("Valves and Outputs" and "Node and Inputs" Pins) must not exceed 8 Amps.
Internal Electronic Resettable Fuses	The Auxiliary Power Connector pins are each internally fused with an electronically resettable fuse. These fuses are set to the maximum current allowable through the G3 electronics.
Recommended External Fuse	External fuses should be chosen depending upon manifold configuration. Please refer to power consumption chart on page 4-26 for additional fuse sizing information.
Spike Suppression	Output spike suppression is internally provided for both discrete and valve outputs.
Discrete Outputs	Maximum 0.5 Amps per output. All outputs are short circuit protected and have internal spike suppression. Contact factory for higher current requirements.
Valve Solenoid Coil Output Drivers	Maximum 0.5 Amps per output. All output points are short circuit protected and have internal spike suppression.
Operating Temperature for Electronic Components	23 to 114°F (-5 to 50°C)

AVENTICS™ G3 Series EtherCAT™ Technical Manual

16.2 Factory Default Settings

<i>FACTORY DEFAULT SETTINGS</i>	
<i>Description</i>	<i>Default</i>
IP Address	193.168.003.120
Subnet Mask	255.255.255.0
Gateway IP	0.0.0.0
I/O Status	Enabled
Diag. Word	Enabled
Fault Action	Off
Brightness	Medium
Parameters	Unlocked
I/O configuration	Unlocked

AVENTICS™ G3 Series EtherCAT™ Technical Manual

16.3 G3 EtherCAT™ Process Data Map

The following process data map is available from the G3 node over EtherCat™ communications to controllers capable of reading the manifold configuration and building an internal mapping and diagnostic table.

Object

<u>Index:SubIndex</u>	<u>Description</u>
0x4000:0	Number of detected modules
0x4000:1	Module #1 ID (See ID numbers below)
0x4000:2	Module #2 ID
...	
0x4000:31	Module #31 ID
0x4010:0	Detected I/O sizes (number of elements: 2)
0x4010:1	Detected Input size
0x4010:2	Detected Output size
0x4020:0	Current I/O sizes (number of elements: 2)
0x4020:1	Current Input size (writable, default 150)
0x4020:2	Current Output size (writable, default 150)

<u>Module ID's</u>	<u>Description</u>
0x1000: 219-828	Valve Driver Output Module
0x1020: 219-898	PWM Valve Driver Output Module
0x2000: 240-203	16DI PNP Terminal Strip
0x2010: 240-204	16DI NPN Terminal Strip
0x2020: 240-205	16DI PNP M12 x 8
0x2030: 240-206	8DI PNP M12 x 8
0x2040: 240-207	16DO PNP M12 x 8
0x2050: 240-208	8DO PNP M12 x 8
0x2060: 240-209	16DI NPN M12 x 8
0x2070: 240-210	8DI NPN M12 x 8
0x2080: 240-211	8DI/8DO PNP M12 x 8
0x3000: 240-212	4AI 0-10V M12 x 4
0x3010: 240-213	2AI/2AO 0-10V M12 x 4
0x3020: 240-214	4AI 4-20mA M12 x 4
0x3030: 240-215	2AI/2AO 4-20mA M12 x 4
0x2090: 240-294	16DI PNP M12 with PE
0x20a0: 240-295	8DI PNP M12 with PE
0x20b0: 240-300	8DO High Current PNP M12 x 4
0x3040: 240-307	2AI/2AO High Current 0-10V M12 x 4
0x3050: 240-311	4AI RTD M12 x 4
0x2100: 240-316	8DI PNP Terminal Strip
0x20c0: 240-320	8DI Intrinsically Safe M12 x 8
0x20d0: 240-322	8DI Intrinsically Safe Terminal Strip
0x20e0: 240-323	16DI PNP 19 Pin
0x20f0: 240-330	16DO PNP Terminal Strip
0x1030: 425186-001	Atlas Valve Driver Output Module
0x1013: 240-241	Sub-Bus Valve Driver

AVENTICS™ G3 Series EtherCAT™ Technical Manual

16.4 Troubleshooting

Communication Node

<i>Symptom</i>	<i>Possible Cause</i>	<i>Solution</i>
The wrong valve solenoid coils are being energized.	Z-Board™ type mismatch. Single Z-Board™ present where double Z-Board™ expected or vice versa.	Check that correct Z-Board™ types are installed. Check that ribbon cable (Output group No. 2) is connected to appropriate valve station. See page 15-169 for bit mapping rules
Valve outputs do not energize.	Output power not present or connected improperly on Auxiliary Power connector.	Check for 24VDC on the +24 VDC (Valves and Outputs) pin of the MINI Auxiliary Power connector of the Comm. module.
No Activity/Link LED	No network connection	Verify the type of cable (straight-thru or crossover) that is being used. Also, verify the wiring of the cable.

I/O Modules

<i>Symptom</i>	<i>Possible Cause</i>	<i>Solution</i>
Outputs remain on when communication is lost and/or PLC is in "Program" mode.	Communication Fault parameters in PLC configuration set incorrectly	Review G3 Slave Node Configuration Comm. Fault Parameter

AVENTICS™ G3 Series EtherCAT™ Technical Manual

16.5 Glossary of Terms

The following is a list and description of common terms and symbols used throughout this document:

<i>Term</i>	<i>Description</i>
Address Resolution Protocol (ARP)	A protocol used to set an IP address using a MAC Address hardware address. This can be done in the command prompt window.
Bit	Smallest unit of digital information either a "0" or "1"
Bit Mapping	Chart showing which bit is connected to which physical input or output point.
BOOTstrap Protocol (BOOTP)	A protocol used to set an IP Address, Subnet Mask, and Gateway using a server.
Broadcast	A transmission method that sends packets to multiple unspecified devices.
Byte	8 bits (1/2 word)
Comm. Fault	One or more of the I/O connections have timed out.
Discrete I / O	The inputs / outputs that are available via the "Discrete I/O" side of manifold.
Dynamic Host Configuration Protocol (DHCP)	A protocol used by a node to obtain an IP Address, Subnet Mask, and Gateway Address from a server.
XDD File	XDD files are GSD files written in XML format. They describe the features of the ETHERCAT™ device model.
Explicit Messaging	Messaging that sends data to perform request/response functions.
Ground	This term is used to indicate an earth or chassis ground.
I/O	Any combination of inputs and outputs
Idle	A zero (0) length poll message (i.e.: scanner in program mode)
IGMP Snooping	See Implicit Messaging
Implicit Messaging	A function that that can control I/O messaging to another I/O device.
Internet Group Management Protocol (IGMP)	A protocol used to keep local switches informed in a multicast group. Nodes that leave the group will no longer be sent packets of information from switches and routers.
Layer 2 (data link layer or level)	The data layer that physically refers to the frame format and addressing. A layer 2 address is an Ethernet address.
Layer 3 (network layer or level)	The data layer that refers to IP and the IP packet format. A layer 3 address is an IP address.
Link	A group of nodes with different MAC addresses. Segments connected by repeaters make a link. Links that are connected by routers make up a network.
MAC Address	Media Access Connection Address
Multicast	A transmission where a packet is sent to all possible nodes of a certain subset.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

Glossary of Terms Continued

<i>Term</i>	<i>Description</i>
NEMA	National Electrical Manufacturers Association
Network	A group of nodes connected by a communication medium through repeaters, router, and gateways.
Node	A device on the network that contains a single MAC Address, which can communicate over a subnet.
Octet	8 bits of information. An IP address is made up of four octets.
Ping	A group of messages sent between a master and a slave that coordinates time.
Ping Request	A request to see if a device has received a message.
Ping Response	Response to a ping request.
Requested Packet Interval (RPI)	The frequency measure of the required transmission of data from the originating device to the target device.
Segment	Nodes connected to a continuous section of communication media.
Simple Network Management Protocol (SNMP)	A protocol used to monitor Ethernet devices, switches, routers, and networks connected by communication media.
Sinking (NPN)	Method of connecting electrical circuits in which the zero (0) volt DC side is switched and the common is positive
Sourcing (PNP)	Method of connecting electrical circuits in which the positive side is switched and the common is zero (0) volts DC.
Status Input bit	A bit in the input table that reports the health of a corresponding output. Indicates short circuit or open coil (load) diagnostics
Subnet	Nodes using the same protocol and shared media access arbitration.
System	Contains one or more domains.
Time to Live (TTL)	A method used in best-effort delivery systems to negate endlessly looping packets.
Unicast	A transmission where a packet is sent to a single node.
Word	2 Bytes (16 bits)
Z-Board™	Circuit board installed in the valve manifold which electrically connects the valve solenoid to the electrical /electronics interface. Available in single or double solenoid versions.

AVENTICS™ G3 Series EtherCAT™ Technical Manual

16.6 Technical Support

For technical support, contact your local Aventics distributor. If further information is required, please call the Technical Support Department at (248) 596-3337.

Issues relating to network setup, PLC programming, sequencing, software related functions, etc. should be handled with the appropriate product vendor.

Information on device files, technical manuals, local distributors, and other Aventics or Numatics products and support issues can be found on the Aventics web site at www.asco.com