

Original operating instructions

Stationary concrete pump



SP 1800

SP 2800

CAT



Dear Customer,

These operating instructions describe all series and special equipment of your machine available at the time of publication.

Country-specific differences are possible.

Please note that your machine cannot be equipped with all described functions. This also applies to safety-relevant systems and functions.

The operating instructions are an integral part of the machine.

Always keep the operating instructions readily available on to machine so they can be viewed at all times.

Please ensure prompt replacement of the operating instructions if they should become lost.

Specify the machine type and the machine number stamped on the type plate of your machine when placing an order.

Pass on these operating instructions when leaving the machine to someone else.

Imprint:



Editor:	Schwing GmbH
Department:	TDS 1
Address:	Heerstr. 9-27 44653 Herne GERMANY
Article number of the operating instructions:	98373677
Caterpillar	129, 151, 168 kW
Printed on:	7. January 2019
Version / Language:	3.12 / English

All rights reserved.

Reprint - in whole or in part - only with the prior consent of the publisher.

1 Contents

1	Contents	1
2	Introduction	11
2.1	Preface	13
2.1.1	Supplier documentation	14
2.2	Structure of the operating instructions	15
2.2.1	Typographic conventions	15
2.2.2	Contents of the individual chapters in these operating instructions	16
2.2.3	Page layout of the operating instructions	17
2.2.4	Structure of safety instructions	18
2.2.5	Warning of personal injury	18
2.2.6	Warning of material damage	19
2.2.7	Additional information	19
2.3	CE labelling	21
2.3.1	Declaration of conformity	21
2.3.2	EC declaration of conformity for truck-mounted concrete pumps	22
2.3.3	EC declaration of conformity for stationary concrete pumps	23
2.3.4	Termination of the declaration of conformity	24
2.4	Theoretical service life of a machine	25
2.4.1	Final decommissioning and disposal of the machine	26
2.5	Labelling SCHWING machines	27
2.5.1	Stationary concrete pumps	27
2.5.2	Additional designations	27
2.5.3	Type plates	27
2.6	Technical data for SP 1800 / 2800 CAT	29
2.7	Assembly groups and designations for your machine SP 1800 / 2800	37
2.7.1	Machine description	37
2.7.2	Transport option	37
2.7.3	Drive motors	37
2.7.4	Hydraulic system	37
2.7.5	Concrete pump	38
2.7.6	Rock valve	38

2.7.7	On the left in the direction of travel	40
2.7.8	On the right in the direction of travel	41
2.7.9	Aerial view	42
2.8	Noise information	43
2.8.2	The highest sound pressure level (LpA)	44
2.9	Pictographs without text	47
2.9.1	Pictographs	48
2.10	Control, warning and steering elements SP 1800 / 2800	51
2.10.1	Concrete pump control	51
2.10.2	Cable remote control	53
2.10.3	CAT control (IOPU control panel)	54
2.10.4	TSC function	56
2.10.5	“Regeneration” instructions	57
2.10.6	Hydraulic oil filter	60
2.10.7	Water separator	60
2.10.8	Output regulation	61
2.10.9	Fuel filter	62
2.10.10	Main switch for starter batteries	63
2.10.11	Forced motor switch-off	64
3	Operation	65
3.1	Driving operation PLC	67
3.1.1	Environmental protection and accident prevention	67
3.1.2	Air pressure table	67
3.1.3	Transporting people and goods	68
3.2	Installation site of the stationary concrete pump	69
3.2.1	Earthing to prevent static charges	70
3.3	Electrical connection (optional)	73
3.3.1	Instructions for electricians	73
3.3.2	Checking the rotational direction of the electric motors (control without phase sequence monitoring) 74	
3.3.3	Checking the rotational direction of the electric motors (control with phase sequence monitoring) 75	
3.4	EMERGENCY-STOP system for SP 1800 / 2800	77
3.4.1	Restarting the machine after an EMERGENCY STOP	79



3.5	Readying the machine for operation SP 1800/2800	81
3.5.1	Diesel engine	84
3.5.2	Fuel prefilter	86
3.5.3	AdBlue reservoir	86
3.5.4	Theoretical operating time	89
3.5.5	Example of an operating time calculation	90
3.6	Drive circuit SP 1800 / 2800	91
3.6.1	Starting the diesel engine	91
3.6.2	Switching off the diesel engine	93
3.6.3	Forced switch-off of motor	94
3.7	Setting up the machine	97
3.7.1	Downtimes	98
3.7.2	Outrigger variants	98
3.7.3	Machine with chassis frame (SP 1800)	99
3.7.4	Machine with chassis frame (SP 3800)	101
3.7.5	Mechanical outrigger	103
3.7.6	Semi-hydraulic outrigger (optional)	104
3.7.7	Servicing the crank support	105
3.8	Operating the pumping line	107
3.8.1	Observation during operation	107
3.8.2	Marking pumping pipes and elbows	108
3.8.3	Marking the pumping line on the placing boom	110
3.8.4	Pumping line on the placing boom	111
3.8.5	Disclaimer	112
3.8.6	Reconnectable concrete pumps	113
3.8.7	Short outlet (foldable)	115
3.8.8	Short outlet (foldable and rotatable)	116
3.8.9	Large outlet DN 180/180/150 (foldable)	118
3.8.10	Servicing the foldable and rotatable outlet	119
3.8.11	Separate pumping line	119
3.8.12	Concrete pumping hoses	122
3.8.13	Connecting hoses	123
3.8.14	Hose pipes	124
3.9	Working operation - General information SP 1800 / SP 2800	127
3.9.1	Special equipment	127
3.9.2	CP remote control	128

3.9.3	CP local control	129
3.9.4	Close maintenance flaps	130
3.10	Working operation - Concrete pump SP 1800 / 2800	131
3.10.1	General	131
3.10.2	Operational readiness	132
3.10.3	Agitator	132
3.10.4	Vibrator (special equipment)	133
3.10.5	Concrete pump	134
3.10.6	Switching off the concrete pump, agitator and special equipment	135
3.10.7	Reconnecting the concrete pump	135
3.11	Working operation - Auxiliary power units	139
3.12	Working operation - Water system SP 1800 / 2800	141
3.12.1	Preparation	141
3.12.2	Operation	142
3.12.3	End of operation	143
3.12.4	Winter operation	143
3.13	Working operation - Air system SP 1800 / 2800	145
3.13.1	Preparation	145
3.13.2	Operation	146
3.13.3	End of operation	147
3.13.4	Winter operation	147
3.14	Working operation - Hydraulic shut-off assembly (special equipment)	149
3.14.1	Preparation	149
3.14.2	Operation	149
3.15	Clearing blockages	151
3.15.1	Blockage in the pumping line	152
3.15.2	Mechanical blockage	153
3.16	Control of operations SP 1800/2800	155
3.16.1	Control of operations for concrete pump	155
3.16.2	Switching damping	159
3.16.3	Control of operations for diesel engine	160
3.17	Troubleshooting - Emergency operation SP 1800 / 2800	163
3.17.1	Control failure	163
3.17.2	Electrical fuse protection for the machine control system	163



3.17.3 Bypass	165
3.17.4 Directional valve emergency actuation	166
3.17.5 EMERGENCY-STOP valve	167
3.18 Cleaning	169
3.18.1 Cleaning devices	169
3.18.2 Cleaning the pumping line	170
3.18.3 Reverse pumping concrete	171
3.18.4 Clearing the pumping line with water	176
3.18.5 Rinsing the pumping line	176
3.18.6 Blowing out the pumping line with compressed air	178
3.18.7 Cleaning the concrete pump	180
3.18.8 Securing the machine	180
3.18.9 Interior cleaning	180
3.18.10 Exterior cleaning	184
3.18.11 Using high-pressure cleaners (HP cleaners)	185
3.18.12 Using cleaning agents	186
3.18.13 After cleaning	186
3.18.14 Water box flushing (special equipment)	186
3.19 Hazard prevention on the concrete filling hopper	189
3.19.1 Hopper grate	189
3.19.2 Cleaning flap and pipeline outlet	190
3.20 Establishing transport readiness	191
3.20.1 Mechanical outrigger SP 1800	191
3.20.2 Mechanical outrigger SP 3800	193
3.20.3 Semi-hydraulic outrigger SP 1800	195
3.20.4 Semi-hydraulic outrigger SP 3800	196
3.20.5 Coupling SP 1800	197
3.20.6 Coupling SP 3800	197
3.20.7 Crane loading	198
3.21 Difficult operating conditions	199
3.21.1 Low ambient temperatures (up to -15 °C)	200
3.21.2 High ambient temperatures	207
3.22 Decommissioning	213
3.22.1 Tasks prior to decommissioning	213
3.22.2 Recommissioning	214

3.23	Technical preconditions for concreting	215
3.23.1	Properties of pumped concrete	215
3.23.2	Errors that inhibit pumping	215
4	Maintenance	217
4.1	General maintenance instructions	219
4.1.1	Maintenance work on special equipment	219
4.1.2	Cleanliness	219
4.1.3	Corrosion protection	220
4.1.4	Checking the oil level	220
4.1.5	Oil change	220
4.1.6	Draining condensation water	221
4.1.7	Seals and fuse elements	221
4.1.8	Lubrication	222
4.1.9	Leaks	222
4.1.10	Repairs, exchange	222
4.1.11	Welding	223
4.1.12	Mechanical processes	223
4.1.13	Painting and working with aggressive substances	223
4.1.14	High-pressure cleaning	223
4.1.15	Electrically powered machines	224
4.2	Consumable volumes (in litres)	225
4.3	Recommended lubricants and fuels	227
4.3.1	Behaviour in case of injuries	228
4.3.2	Explanation of the abbreviations used	228
4.3.3	Recommended hydraulic oil	230
4.3.4	Recommended gear oil (see gear type plate)	231
4.3.5	Recommended compressor oil	233
4.3.6	Recommended grease	234
4.3.7	Excerpt from the safety data sheet for hydraulic oil	236
4.4	Spare parts and accessories	239
4.4.1	Wear parts - Signs of wear	240
4.5	Explanation of the maintenance schedule - Stationary concrete pump	243
4.6	Maintenance plan for stationary concrete pump SP 1800/2800	245
4.6.1	General information	245



4.6.2	Concrete pump (pump kit)	246
4.6.3	Special equipment	247
4.6.4	Test intervals according to concrete delivery rate	248
4.7	Maintenance report	249
4.8	Hydraulic fluid and filters for stationary concrete pump	251
4.8.1	Checking the fill level of the reservoir	251
4.8.2	Filling the empty oil box	252
4.8.3	Purity of the hydraulic oil	252
4.8.4	What does the purity classification mean?	253
4.8.5	What advantages are there in observing the purity classification?	254
4.8.6	Extended changing intervals for hydraulic oil	254
4.8.7	Description of the oil sampling procedure	254
4.8.8	Draining condensation water	255
4.8.9	Changing the hydraulic fluid	256
4.8.10	Cleaning the reservoir	256
4.8.11	Changing the insert on the main filter (return flow filter)	257
4.9	Pressure checks - stationary concrete pumps	261
4.9.1	Concrete pump system	261
4.9.2	Performing a pressure check	262
4.10	Radiator	265
4.10.1	Hydraulic oil cooler	265
4.10.2	Motor cooler	266
4.11	Air-filter system	267
4.11.1	Dust discharge valve	267
4.11.2	Removing the filter element	267
4.11.3	Cleaning the filter element	268
4.11.4	Installing the filter element	270
4.11.5	Storage	270
4.11.6	Disposal	270
4.11.7	Function testing of maintenance indicator	270
4.12	Rock valve	271
4.12.1	Lubricating the bearing points	271
4.12.2	Checking the screw-type connections	274
4.12.3	Checking the axial play of the slewing shaft	274
4.12.4	Configuring the axial play of the slewing shaft	275

4.12.5	Checking the cutting ring	275
4.12.6	Rotating the cutting ring	277
4.12.7	Checking the seal of the slewing shaft	281
4.12.8	Prolonged downtime	281
4.12.9	Checking the wear of the rock	282
4.12.10	Preventive maintenance	282
4.13	Delivery and differential cylinders, pumping piston change	285
4.13.1	Pumping piston change	285
4.13.2	Preparing to change the pumping pistons	286
4.13.3	Checking the fastener	289
4.13.4	Changing the pumping piston	290
4.14	High-pressure version (HP) (pumping and differential cylinders) (optional)	295
4.14.1	Pumping pistons	296
4.14.2	The "Pumping piston change" operating mode	296
4.14.3	Removing the HP pumping pistons	296
4.14.4	Installing the HP pumping pistons	298
4.15	Multi-part pumping pistons (optional)	301
4.15.1	Replacing the main wear parts	301
4.16	Servicing the pumping line	305
4.16.1	Diagrams	307
4.16.2	Main wear zones	309
4.16.3	Impact bend	310
4.16.4	Measuring the wall thickness	312
4.16.5	Tube type - tubes	314
4.16.6	Measurement sheet - tubes	315
4.16.7	Tube type - elbows	316
4.16.8	Measurement sheet - elbows	317
4.16.9	Tube type - tapered tubes	318
4.16.10	Extending the service life	319
4.16.11	Replacing pumping pipes end elbows	320
4.16.12	Testing the pumping hoses	321
4.16.13	Visual inspection (exterior)	322
4.16.14	Visual inspection (internal)	322
4.16.15	Visual inspection of fixings	322
4.17	Rotary compressor	325
4.17.1	Maintenance packages	325



4.17.2	Checking the oil level.	326
4.17.3	Topping up the oil	327
4.17.4	Changing the oil	327
4.17.5	Cleaning / Replacing the air filter	328
4.17.6	Cleaning the oil cooler	328
4.17.7	Replacing compressed air hoses	329
4.17.8	Replacing the oil filter	330
4.17.9	Replacing oil return valves	330
4.17.10	Replacing the oil separator cartridge	331
4.18	Electrical / Electronic system, software	333
4.18.1	Electrical system: Description	333
4.18.2	Electrical safeguarding of SCHWING components	334
4.18.3	Changing the fuses in SCHWING components	335
4.18.4	Working on electrical / electronic components	338
4.18.5	Software	339
4.18.6	Electrically powered machines	339
4.18.7	Electric welding procedure	339
4.18.8	Jump starting	339
4.18.9	Jump starting stationary pumps with batteries connected in series	339
4.18.10	Mechanical processes	340
4.18.11	Painting and working with aggressive substances	340
4.18.12	Steam jet cleaning	340
4.18.13	Starter batteries (lead-acid batteries)	341
4.18.14	Checking the acid level	341
4.18.15	Checking the open-circuit voltage	341
4.18.16	Checking the acid density	342
4.18.17	Charging the battery	342
4.18.18	Maintaining the batteries during machine downtimes	343
4.18.19	Storage and installation	344
4.18.20	Disposal	344
4.19	Safety inspections	345
4.19.1	Machine operator	345
4.19.2	Competent person (specialist)	345
4.19.3	Expert	345
4.19.4	Additional inspections	345
4.19.5	Technical safety inspection	346
4.19.6	Safety components	346

4.19.7	Notification of damage for safety components	347
4.20	Repair welding	351
5	Remote control	353
5.1	Remote control	355
6	Special equipment	357
6.1	Hydraulic shut-off assembly (98383777)	359
6.1.1	Area of application	359
6.1.2	Safety	360
6.1.3	Structure of the system	362
6.1.4	Installation	363
6.1.5	Drive	363
6.1.6	Maintenance	363
6.1.7	Technical data	363
6.2	Central lubricating system	365
6.2.1	Safety	366
6.2.2	Instructions for filling with lubricant	366
6.2.3	Configuring the system	370
6.2.4	Checking the system	372
6.3	Remote pressure cut-off (“DAF”)	373
6.3.1	Intended use	373
6.3.2	Improper use. Foreseeable misuse	373
6.3.3	Delivery condition	373
6.3.4	Step-by-step instructions	374
7	Appendix	377
7.1	Information service	379
7.2	Always nearby	381
7.3	Always Ready	383
7.4	VDMA safety manual	401



2 Introduction

This chapter contains the most important information about your machine, including:

- Layout,
- Conventions and
- Handling

Of these operating instructions.



2.1 Preface

These operating instructions are intended to help you use your SCHWING machine safely and properly, and are an integral part of the machine.

Carefully read this manual before using your SCHWING machine for the first time and observe all corresponding provisions and instructions contained therein.

These operating instructions are intended for all persons who are entrusted with operating or servicing the SCHWING machine described below, as well as the owners and operators of the machine.

The machine is constructed according to state-of-the-art technology and recognised safety-related rules. Nevertheless, they can cause danger to persons and material goods in the event of incorrect use, operation, maintenance or repair.

Any use of the machine requires knowledge and careful observance of these operating instructions.

These operating instructions must always be available on the SCHWING machine.

Please be aware that the figures in these instructions may differ slightly from the actual design of your SCHWING machine.

In addition to the operating instructions, the general relevant legal and other rules on accident prevention of the country of operation should be observed.

SCHWING GmbH is not liable for damages caused by a failure to observe these provisions and/or these operating instructions or by improper use of the machine!

In the event of faults, any questions and to order spare parts, please contact your local representative or:

Address	SCHWING GmbH PO Box 20 03 62 D - 44647 Herne
Telephone	+ 49 (0) 2325 / 987-0
Fax	+ 49 (0) 2325 / 72922
Email	info@schwing.de

Our customer service department can be reached at:

Telephone	+ 49 (0) 2325 / 987-231 / 232
Fax	+ 49 (0) 2325 / 74674
Email	service@schwing.de

For all inquiries, always indicate the machine type and machine number. of your machine.

2.1.1 Supplier documentation

SCHWING builds truck-mounted concrete pumps on chassis frames from various manufacturers.

These manufactures provide their own operating instructions about their products.

The same also applies for the manufacturer of integrated motors used in our stationary concrete pumps.

Other special pieces of equipment on your SCHWING machine may also have their own operating instructions.

Please observe these documents, in addition to the SCHWING operating instructions, in order to service and maintain these components properly.

Should you encounter any problems with your vehicle or integrated motor, please contact the addresses listed in the manufacturer's operating instructions directly.

2.2 Structure of the operating instructions

The present operating instructions consist of several different chapters.

The operating instructions are structured logically in accordance with the applications and must be read and understood completely before the initial commissioning.

If you still have any questions or doubts after reading the operating instructions, please do not hesitate to contact the customer service department at Schwing GmbH. If necessary, you can also organise individual training seminars.

These operating instructions are also intended as reference work. The clear table of contents and the headers in the document were designed with that purpose in mind.

The safety chapter was prepared together with the VDMA and other concrete pump manufacturers and can also be ordered separately for training purposes, for example.

2.2.1 Typographic conventions

- This symbol marks a list or a hierarchical series, such as required materials, tools or a reminder list.
- This symbol indicates instructions.
Follow these instructions carefully.
Each point is a self-contained task.
- 1. Numeric enumerations represent sub-tasks.
Only after all of the sub-tasks have been performed, is the task considered completed.
- a) Alphabetical enumerations represent lists with an obligatory order.

CAPITALIZATION:

Words written completely in upper case are proper nouns. Proper nouns are not translated.

Examples:

SCHWING

EASy

VECTOR

2.2.2 Contents of the individual chapters in these operating instructions

Introduction

This chapter is intended to familiarise you with your machine.

It contains, for example, the technical specifications, a short description and an overview of the machine.

Operation

In this chapter, you will find descriptions of all machine operating procedures, from commissioning to working operation and cleaning to decommissioning.

Maintenance

This chapter contains essential information on when and how the machine should be serviced, as well as information on filling quantities and the lubricants and operating materials used.

Radio remote control

Your machine's radio control system is described in a separate chapter. If alternative remote controls are available for your machine, all up-to-date variants are shown here. This chapter is empty in the case of machines for which no radio remote control is offered.

Special equipment

This chapter provides information on all types of special equipment.

Each machine is tailored to the customer's requirements. Please note that your particular machine might not include all of the special equipment described here.

Appendix

In the appendix chapter, you will find all of the contact information, along with topics such as organisation and administration.

Safety

The safety manual is located in the appendix of these operating instructions and contains basic safety instructions regarding the operation of pumping, spraying and spreading machinery for concrete.

The safety manual is prepared jointly by leading manufacturers of concrete pumping and spreading machines under the auspices of the VDMA (Verband Deutscher Maschinen- und Anlagenbau/Mechanical Engineering Industry Association). It is applicable to our machines in full.

For this reason, the safety manual has a chapter of its own and separate page numbers.

Specific warnings can be found directly before descriptions of dangerous activities.

2.2.3 Page layout of the operating instructions

Header

A dynamic column title is contained in the header on the outer edge of the page.

The column title shows the corresponding sub-chapter currently being read, along with the chapter number and title.

The column title helps to maintain an overview and to find a desired topic quickly.

Footer

The outside edge of the footer contains the page number and an ID.

The ID is used to organise the documents internally; it is of no relevance for you.

If you have any questions regarding specific pages in your operating instructions, please provide us with:

- The title of your operating instructions (the exact designation of your machine and the print date)
- The page number
- The chapter in the column title

Margin column

The margin column provides a better orientation on the pages.


Using the margin column, you can find headers more quickly perceive any indications more easily.

2.2.4 Structure of safety instructions

In these operating instructions, safety instructions are placed in front of certain sections to warn readers of dangers that could cause potential personal injury or material danger.

The measures described to avert these dangers must be adhered to.

Safety instructions are structured as follows:

	Signal word
	Type of danger and its source
	Possible consequence(s) if disregarded
	Measure(s) for averting the danger

2.2.5 Warning of personal injury

The following safety instructions describe the grading and meaning of signal words for personal injuries.



Danger!

High risk!

Persons can be instantly killed or severely injured.

Describes how the danger can be avoided.



Warning!

Medium risk!

Persons can possibly be injured or killed.

Describes how the danger can be avoided.



Caution!

Risk!

Persons can be injured.

Describes how the danger can be avoided.

2.2.6 Warning of material damage

The following safety instructions describe the meaning of the signal word for material damage.



Attention!

Material damage!

Damage to your own machine or other objects.

Describes how the material damage can be avoided.

2.2.7 Additional information

The following symbol indicates useful tips and recommendations, as well as information for ensuring smooth and efficient operation.



Information

Text box for additional information.

2.3 CE labelling

Machines brought into circulation from 01 January 1995 in the member states of the European Economic Area (EEA) must comply with the basic health and safety requirements of the relevant EC regulations.

The machine manufacturers confirm this by affixing a mark (**Fig. 1**) to the machine and by issuing a "Declaration of Conformity".

The CE mark is located on the base frame. The positions of the signs and labels can be found on a drawing in the ET catalogue.



Fig. 1 Communauté Européenne (European Community)

2.3.1 Declaration of conformity

SCHWING declares that the machine placed on the market in the European Economic Area complies with the relevant EC directives.

We confirm this by issuing a declaration of conformity and affixing a CE mark to the machine.

The original of each declaration of conformity is archived at SCHWING.

The customer receives a copy of this declaration in the national language, together with the delivery note or invoice.

The following pages each contain a sample of the declaration of conformity for truck-mounted concrete pumps (S) and stationary concrete pumps (SP).



Information

Machines placed on the market in the European Economic Area must comply with the valid guidelines.

This does not apply when the machines are placed on the market outside of the European Economic Area. If a certain machine design deviates from the design required for the European Economic Area, SCHWING will not issue a declaration of conformity and the CE marking will not be affixed.

These machines may not be used in the European Economic Area!

2.3.2 EC declaration of conformity for truck-mounted concrete pumps

According to EC Machine Directive 2006/42/EC appendix II A

We hereby declare that the machine specified below

Designation of the machine:	TRUCK-MOUNTED CONCRETE PUMP
Machine type:	S
Machine no.	



complies with the following relevant provisions:

Machine Directive	2006 / 42 / EC
Low Voltage Directive	2014 / 35 / EU
EMC Directive	2014 / 30 / EU
Noise Emission Directive	2000 / 14 / EG

Applied harmonised standards ¹⁾ , especially:	DIN EN 12001, DIN EN ISO 12100, DIN EN 982, DIN EN 1088, DIN EN 13309, DIN EN 60204, DIN EN ISO 3744, DIN EN ISO 11688, DIN EN ISO 13849, DIN EN ISO 13850
--	--

Applied national standards and technical specifications ²⁾ , especially:	DIN 24117, DIN 24118
---	----------------------

- 1 Complete list of the applied harmonised standards, see »Normative references in DIN EN 12001 conveying, spraying- and placing machines for concrete and mortar — Safety requirements«
- 2 Complete list of the applied national standards and technical specifications, see »References in DIN EN 12001 conveying, spraying and placing machines for concrete and mortar — Safety requirements«, as well as the SCHWING factory standard.

Noise emission	
Installed effective output	P hydraulic = kW (diesel-hydraulic drive)
Measured sound power level	LWA measured = dB
Guaranteed sound power level	LWA guaranteed = dB

Person authorised, at the request of the market surveillance authorities, for the compilation of the relevant technical documents (declaration of conformity):
CE-person authorised by SCHWING GmbH

This declaration loses its validity in the event of any unauthorised changes to the machine.


Date/Signature by manufacturer

Information about signatory	Management
-----------------------------	------------

2.3.3 EC declaration of conformity for stationary concrete pumps

According to EC Machine Directive 2006/42/EC appendix II A

We hereby declare that the machine specified below

Designation of the machine:	STATIONARY CONCRETE PUMP	
Machine type:	SP	
Machine no.		

complies with the following relevant provisions:

Machine Directive	2006 / 42 / EC
Low Voltage Directive	2014 / 35 / EU
EMC Directive	2014 / 30 / EU
Noise Emission Directive	2000 / 14 / EG

Applied harmonised standards ¹⁾ , especially:	DIN EN 12001, DIN EN ISO 12100, DIN EN 982, DIN EN 1088, DIN EN 13309, DIN EN 60204, DIN EN ISO 3744, DIN EN ISO 11688, DIN EN ISO 13849, DIN EN ISO 13850, DIN EN ISO 13857
--	--

Applied national standards and technical specifications ²⁾ , especially:	DIN 24118
---	-----------

- 1 Complete list of the applied harmonised standards, see »Normative references in DIN EN 12001 conveying, spraying- and placing machines for concrete and mortar — Safety requirements«
- 2 Complete list of the applied national standards and technical specifications, see »References in DIN EN 12001 conveying, spraying and placing machines for concrete and mortar — Safety requirements«, as well as the SCHWING factory standard.

Noise emission	P hydraulic = kW (hydraulic drive)
Installed effective output	LWA measured = dB
Measured sound power level	LWA guaranteed = dB
Guaranteed sound power level	

Person authorised, at the request of the market surveillance authorities, for the compilation of the relevant technical documents (declaration of conformity):
CE-person authorised by SCHWING GmbH

This declaration loses its validity in the event of any unauthorised changes to the machine.

Date/Signature by manufacturer

Information about signatory Management

2.3.4 Termination of the declaration of conformity

CE marking and declaration of conformity only apply to design and scope of delivery of the machine delivered ex works.

Making changes to the machine without the approval of SCHWING, in addition to using accessories without the approval of SCHWING, shall cause both to lose their validity.

The competent supervisory authorities can decommission corresponding machines.

SCHWING is not liable for the consequences of the above manipulations. Operator and owner of the machine are responsible thereof.

2.4 Theoretical service life of a machine

Our concrete pumps and placing booms are designed, under normal use, for a theoretical life of up to 15 years.

The following reference and empirical values are used as a basis:

Truck-mounted concrete pump S 17 - S 43 SX	Reference value ¹
Delivery rate [m ³] / per year	30 000
Construction jobs per year ²	850
Truck-mounted concrete pump S 45 SX - S 65 SXF	Reference value ¹
Delivery rate [m ³] / per year	30 000
Construction jobs per year ²	500
Truck mixer pumps	Reference value ¹
Delivery rate [m ³] / per year	15 000
Construction jobs per year ²	250
Stationary concrete pump / Separate placing booms	Reference value ¹
Delivery rate [m ³] / per year	20 000
Construction jobs per year ²	280

Please note that, in addition to the number of construction jobs and the delivery rate (volume of pumped material), other operating factors can also significantly reduce the service life of a machine under certain conditions, such as:

- Not operating the machine in accordance with its intended purpose
- Misuse (e.g. using the boom as a lifting device)
- Improper extension of the end hoses
- Failure to follow the maintenance guidelines
- Operating a machine under extreme conditions, e.g. under excessive heat or excessive cold
- Improper operation by machine operators without adequate training or instruction
- Using concrete pipelines that are not approved by SCHWING
- Not performing the boom inspections and corresponding repairs on time

Any discrepancies can affect the service life accordingly. The information specified with regard to the theoretical life does not constitute any commitment or guarantee, nor does it represent any other assurance as to a machine's quality and durability.

¹ See "Maintenance" chapter for restrictions

² One construction job is generally defined as one extension and retraction cycle.

Furthermore, timely compliance with the prescribed maintenance work and technical safety inspections is also considered part of the intended use. See the "Maintenance" chapter and the safety manual in the appendix of these operating instructions.

In the event of damages of any kind, the entire machine must be inspected.

Contact SCHWING in the event of operations outside of the indicated reference values

The following applies to all SCHWING machines:

Fresh concrete temperature:	+15 °C
Operating site:	Outdoors / in rooms with sufficient ventilation
Operating temperature:	-15 °C / +45 °C
Maximum operating altitude:	2000 MASL (depending on the type of machine)

If exceedances of individual values or the simultaneous exceedance of several values can be expected, also see the "Difficult operating conditions" chapter.

2.4.1 Final decommissioning and disposal of the machine

The machines contain valuable raw materials that should be reused, but also materials and substances (for example: oils, greases, plastics, electronic components, rechargeable batteries, etc.) that should be disposed of properly due to their properties hazardous to life or -environmentally damaging.

Make sure that the decommissioned machine can no longer be put into operation.

Machines should be dismantled and disposed of in accordance with any regional accident prevention regulations, as well as any provisions regarding health and environmental protection.

Hand the machine over to a certified disposal company in order to ensure that it is disposed of properly.

In the event that certified disposal companies are not available in your region, for example, the authorities responsible for the environmental protection provide appropriate information.

2.5 Labelling SCHWING machines

The most common abbreviations and their meanings are listed and explained here.

2.5.1 Stationary concrete pumps

SP 1800 BR02		
SP		Stationary concrete Pump
	1800	technical parameters (minimum value)
	BR	Series

SP 3800 BR02		
SP		Stationary concrete Pump
	3800	technical parameters (minimum value)
	BR	Series

2.5.2 Additional designations

SP 2800 200 120 D 168 kW			
200	∅ the pumping cylinder in mm		
	120	∅ pistons of the hydraulic cylinders in mm	
		D	Diesel engine
			168 Drive power in kW

SP 3800 200 140 D 205 kW			
200	∅ the pumping cylinder in mm		
	140	∅ pistons of the hydraulic cylinders in mm	
		D	Diesel engine
			205 Drive power in kW

2.5.3 Type plates

The type plate for the concrete pump is located on the machine frame (**Fig. 2**).




Fig. 2



2.6 Technical data for SP 1800 / 2800 CAT





Information

Power ratings are theoretical max. values!






Warning!

The specified concrete pressures require suitable pumping line material!
(see “Operating the pumping line” on page 107)

TBS, Juni 2017		Technische Daten/Technical Data SP1800 Stage IIIA / Tier3			
					
DE	Pumpenbatterie			P1620 -120/80	
EN	Pump kit				
DE	Motorhersteller und Typ			Deutz TCD2013 L04	
EN	Engine				
DE	Abgasstufe			Diesel Stage IIIA/Tier3	
EN	Emission standard				
DE	Motorleistung			126kW/169hp	
EN	Engine power				
DE	max. Motordrehzahl			2300min ⁻¹	
EN	max. engine speed				
DE	Tankinhalt Diesel			250ltr	
EN	Fuel tank capacity				
DE	Tankinhalt Hydrauliköl			400ltr	
EN	Hydraulic tank capacity				
DE	max. Betondruck stangenseitig/kolbenseitig			60bar/108bar	
EN	max. concrete pressure rod side/piston side			870psi/1566psi	
DE	max. Fördervolumen stangenseitig/kolbenseitig			84m ³ /h / 48m ³ /h	
EN	max. concrete pressure rod side/piston side			110cu yd/h / 63cu yd/h	
DE	Abgang Rock			DN150	
EN	Outlet Diameter				
DE	Füllinhalt Trichter			570ltr	
EN	Hopper capacity				
DE	Verschleißschutz beidseitig			Hartmetall	
EN	Wear parts both sides			carbide metall	
DE	max. Einzelstützkraft statisch			xxxkN	
EN	max. single outrigger load				
DE	Gesamtgewicht			5.300kg/11.684lb	
EN	Gross weight				
DE	max. Schalleistung			123dB (A)	
EN	max. sound level				





TBS, März 2017		Technische Daten/Technical Data SP1800 Stage IIIB / Tier4i	
DE	Pumpenbatterie		P1620 -120/80
EN	Pump kit		
DE	Motorhersteller und Typ		Caterpillar C4.4
EN	Engine		
DE	Abgasstufe		Diesel Stage IIIB/Tier4i
EN	Emission standard		
DE	Motorleistung		129kW/173hp
EN	Engine power		
DE	max. Motordrehzahl		2200min ⁻¹
EN	max. engine speed		
DE	Tankinhalt Diesel		250ltr
EN	Fuel tank capacity		
DE	Tankinhalt Hydrauliköl		400ltr
EN	Hydraulic tank capacity		
DE	max. Betondruck stangenseitig/kolbenseitig		60bar/108bar
EN	max. concrete pressure rod side/piston side		870psi/1566psi
DE	max. Fördervolumen stangenseitig/kolbenseitig		80m ³ /h / 46m ³ /h
EN	max. concrete pressure rod side/piston side		105cu yd/h / 60cu yd/h
DE	Abgang Rock		DN150
EN	Outlet Diameter		
DE	Füllinhalt Trichter		570ltr
EN	Hopper capacity		
DE	Verschleißschutz beidseitig		Hartmetall
EN	Wear parts both sides		carbide metall
DE	max. Einzelstützkraft statisch		xxxkN
EN	max. single outrigger load		
DE	Gesamtgewicht		5.400kg/11.904lb
EN	Gross weight		
DE	max. Schalleistung		123dB (A)
EN	max. sound level		

TBS, Januar 2018		Technische Daten/Technical Data SP1800 Stage IV / Tier4f		 SCHWING Stetter	
					
DE	Pumpenbatterie			P1620 -120/80	
EN	Pump kit				
DE	Motorhersteller und Typ			Caterpillar C4.4	
EN	Engine				
DE	Abgasstufe			Diesel Stage IV/Tier4f	
EN	Emission standard				
DE	Motorleistung			129kW/173hp	
EN	Engine power				
DE	max. Motordrehzahl			2200min ⁻¹	
EN	max. engine speed				
DE	Tankinhalt Diesel			250ltr	
EN	Fuel tank capacity				
DE	Tankinhalt Hydrauliköl			400ltr	
EN	Hydraulic tank capacity				
DE	max. Betondruck stangenseitig/kolbenseitig			60bar/108bar	
EN	max. concrete pressure rod side/piston side			870psi/1566psi	
DE	max. Fördervolumen stangenseitig/kolbenseitig			80m ³ /h / 46m ³ /h	
EN	max. concrete pressure rod side/piston side			105cu yd/h / 60cu yd/h	
DE	Abgang Rock			DN150	
EN	Outlet Diameter				
DE	Füllinhalt Trichter			570ltr	
EN	Hopper capacity				
DE	Verschleißschutz beidseitig			Hartmetall	
EN	Wear parts both sides			carbide metall	
DE	max. Einzelstützkraft statisch			xxxkN	
EN	max. single outrigger load				
DE	Gesamtgewicht			5.400kg/11.904lb	
EN	Gross weight				
DE	max. Schalleistung			123dB (A)	
EN	max. sound level				



TBS, Juni 2017		Technische Daten/Technical Data SP2800 Stage IIIA / Tier3	
DE	Pumpenbatterie		P1620 -120/80
EN	Pump kit		
DE	Motorhersteller und Typ		Deutz TCD2012 L06
EN	Engine		
DE	Abgasstufe		Diesel Stage IIIA/Tier3
EN	Emission standard		
DE	Motorleistung		147kW/197hp
EN	Engine power		
DE	max. Motordrehzahl		2300min ⁻¹
EN	max. engine speed		
DE	Tankinhalt Diesel		250ltr
EN	Fuel tank capacity		
DE	Tankinhalt Hydrauliköl		400ltr
EN	Hydraulic tank capacity		
DE	max. Betondruck stangenseitig/kolbenseitig		60bar/108bar
EN	max. concrete pressure rod side/piston side		870psi/1566psi
DE	max. Fördervolumen stangenseitig/kolbenseitig		112m ³ /h / 64m ³ /h
EN	max. concrete pressure rod side/piston side		146cu yd/h / 84cu yd/h
DE	Abgang Rock		DN150
EN	Outlet Diameter		
DE	Füllinhalt Trichter		570ltr
EN	Hopper capacity		
DE	Verschleißschutz beidseitig		Hartmetall
EN	Wear parts both sides		carbide metall
DE	max. Einzelstützkraft statisch		xxxkN
EN	max. single outrigger load		
DE	Gesamtgewicht		5.400kg/11.904lb
EN	Gross weight		
DE	max. Schalleistung		123dB (A)
EN	max. sound level		

TBS, März 2017		Technische Daten/Technical Data SP2800 Stage IIIB / Tier4i			
					
DE	Pumpenbatterie				P1620 -120/80
EN	Pump kit				
DE	Motorhersteller und Typ				Caterpillar C7.1
EN	Engine				
DE	Abgasstufe				Diesel Stage3B/Tier4i
EN	Emission standard				
DE	Motorleistung				151kW/203hp
EN	Engine power				
DE	max. Motordrehzahl				2200min ⁻¹
EN	max. engine speed				
DE	Tankinhalt Diesel				250ltr
EN	Fuel tank capacity				
DE	Tankinhalt Hydrauliköl				400ltr
EN	Hydraulic tank capacity				
DE	max. Betondruck stangenseitig/kolbenseitig				60bar/108bar
EN	max. concrete pressure rod side/piston side				870psi/1566psi
DE	max. Fördervolumen stangenseitig/kolbenseitig				112m ³ /h / 64m ³ /h
EN	max. concrete pressure rod side/piston side				146cu yd/h / 84cu yd/h
DE	Abgang Rock				DN150
EN	Outlet Diameter				
DE	Füllinhalt Trichter				570ltr
EN	Hopper capacity				
DE	Verschleißschutz beidseitig				Hartmetall
EN	Wear parts both sides				carbide metall
DE	max. Einzelstützkraft statisch				xxxkN
EN	max. single outrigger load				
DE	Gesamtgewicht				5.700kg/12.566lb
EN	Gross weight				
DE	max. Schalleistung				123dB (A)
EN	max. sound level				



TBS, Juni 2017		Technische Daten/Technical Data SP2800 Stage IV / Tier4f	
DE	Pumpenbatterie		P1620 -120/80
EN	Pump kit		
DE	Motorhersteller und Typ		Caterpillar C7.1
EN	Engine		
DE	Abgasstufe		Diesel Stage IV /Tier4f
EN	Emission standard		
DE	Motorleistung		168kW/225hp
EN	Engine power		
DE	max. Motordrehzahl		2200min ⁻¹
EN	max. engine speed		
DE	Tankinhalt Diesel		250ltr
EN	Fuel tank capacity		
DE	Tankinhalt Hydrauliköl		400ltr
EN	Hydraulic tank capacity		
DE	max. Betondruck stangenseitig/kolbenseitig		60bar/108bar
EN	max. concrete pressure rod side/piston side		870psi/1566psi
DE	max. Fördervolumen stangenseitig/kolbenseitig		112m ³ /h / 64m ³ /h
EN	max. concrete pressure rod side/piston side		146cu yd/h / 84cu yd/h
DE	Abgang Rock		DN150
EN	Outlet Diameter		
DE	Füllinhalt Trichter		570ltr
EN	Hopper capacity		
DE	Verschleißschutz beidseitig		Hartmetall
EN	Wear parts both sides		carbide metall
DE	max. Einzelstützkraft statisch		xxxkN
EN	max. single outrigger load		
DE	Gesamtgewicht		6.100kg/13.448lb
EN	Gross weight		
DE	max. Schalleistung		123dB (A)
EN	max. sound level		



2.7 Assembly groups and designations for your machine SP 1800 / 2800

This chapter contains an overview of the main assembly groups for your machine and their respective positions.

2.7.1 Machine description

The concrete pumps from series SP 1800/2800/3800/7000/7500 are oil-hydraulically powered, two-cylinder piston pumps. They are designed for the pumping standard concrete through pipes.

Pumping other media, such as heavy concrete, lightweight concrete, screed and mortar, etc. is only permitted after consultation with SCHWING GmbH.

2.7.2 Transport option

The pump is mounted on a universally designed construction chassis frame with pneumatic tires. Other chassis frames are available on request.

2.7.3 Drive motors

The drive motor powers the pumps of the hydraulic system directly, without any intermediate gear.

There are alternative diesel or electric motors available.

The diesel engine used as standard is liquid-cooled. It is optimised for exhaust gas and noise emission, as well as fuel consumption.

2.7.4 Hydraulic system

The hydraulic system operates in an open circuit.

An adjustable hydraulic pump is available for the drive of the differential cylinder.

The hydraulic accumulator and slewing cylinder are supplied via an additional adjustable hydraulic pump.

Two fixed displacement pumps constantly pump hydraulic oil through the hydraulic oil cooler and filter.

Other fixed displacement pumps are available for the agitator and special equipment, such as the hydraulic outrigger, compressor, water pump and shut-off assembly.

The hydraulic accumulator facilitates the rapid switching of the rock valve.

2.7.5 Concrete pump

The concrete pump is a two-cylinder piston pump with a rock valve.

The most important assembly groups (Fig. 3 Concrete pump) include:

- 1 Rock valve
- 2 Pumping cylinder and piston
- 3 Water box
- 4 Hydraulic drive cylinder

2.7.6 Rock valve

Like in a reciprocating piston engine, the pumping pistons in the two-cylinder piston pump are constantly changing their direction of motion.

The two pistons run counter to one another.

As the receding piston draws concrete out of the filling hopper, the advancing piston pushes the previously drawn-in concrete into the pumping line.

At the same time, the rock valve (1) (Fig. 3 Concrete pump) swivels so that the "drawing" cylinder is connected to the filling hopper and the "pushing" cylinder to the pumping line.

By switching to "Suction" (reverse running), the concrete can be drawn from the pumping line and back into the filling hopper.

At the end positions, the hydraulic cylinders of the concrete pump and of the rock valve control hydraulic control valves, which coordinate the cylinder movements.

A hydraulic accumulator supports the rapid switching of the rock valve.




Fig. 3 Concrete pump

Caption (Fig. 3 Concrete pump)	
Pos.	Description
1	Rock valve
2	Pumping cylinder and piston
3	Water box
4	Hydraulic differential cylinders (drive cylinders)

2.7.7 On the left in the direction of travel




Fig. 4: Side view on the left in the direction of travel

Caption (Fig. 4: Side view on the left in the direction of travel)

Pos.	Description	Pos.	Description
1	Compressor	4	AdBlue reservoir
2	Water pump	5	hopper
3	Hydraulic oil box	6	Base frame



2.7.8 On the right in the direction of travel




Fig. 5 Side view on the right in the direction of travel

Caption (Fig. 5 Side view on the right in the direction of travel)			
Pos.	Description	Pos.	Description
1	Control	4	Diesel fuel tank
2	Drive motor	5	Rock valve
3	Drive with hydraulic pumps	6	Control lever for hydr. shut-off assembly 1

1.Special equipment

2.7.9 Aerial view




Fig. 6: Aerial view

Caption (Fig. 6: Aerial view)			
Pos.	Description	Pos.	Description
1	EMERGENCY-STOP button		

2.8 Noise information

Noise information regarding concrete pumping and spreading machines manufactured by SCHWING with the exception of truck-mounted concrete pumps in accordance with EC Machinery Directive 2006/42/EC and Noise Emissions Directive 2000/14/EC.

2.8.1 The guaranteed sound power level (L_{WA})

The sound power level is a measure of the total sound emitted by a machine in all directions. It is a measured value for technical comparison and is used in the calculation of the total noise level produced by a construction site.

The sound power level does not allow for any conclusions to be drawn with regard to the noise level at the workplace (of the pump operator).

In the EC, a sign must be affixed to the above machines, informing of the sound power level of the respective machine. See example figure "Fig. 7 Noise level".




Fig. 7 Noise level

The indicated value represents an average value for the respective series, plus a safety margin.

SCHWING guarantees that this value will not be exceeded by newly delivered, ex works machines.



Information

Regarding noise emissions, please observe the regionally applicable reductions in operating time!

2.8.2 The highest sound pressure level (L_{pA})

The sound pressure level is a measure of the sound emissions in the workplace. Machines equipped with a remote control unit as standard have no fixed workplace. In this case, the Machine Directive prescribes that the highest sound pressure level be measured at a distance of 1 m from the machine surface and 1.6 m across the ground, which must be indicated in the operating instructions. For machines without a remote control, the highest sound pressure level in the workplace is measured as above and given in the operating instructions.



Caution!

Hearing can be damaged!

Personal hearing protection must always be worn when a sound pressure level of 80 dB(A) is exceeded.

Failure to observe this may be harmful to your health.

Close all hoods, covers etc. that are provided to insulate the noise!

Machine type	Highest measured sound pressure level (L _{pAmax})	Measuring point L _{pAmax} *	L _{pA} in the workplace (control station)	Guaranteed sound power level (L _{WA})
SP 305, 500, 750	95 dB(A)	4 m from the front, on the right in the driving direction	95 dB(A)	123 dB(A)
SP 1400 D				123 dB(A)
SP 1800 D	92 dB(A)	4 m from the front, on the left in the driving direction	90 dB(A)	123 dB(A)
SP 1800 E				123 dB(A)
SP1800 D CAT 129 kW	101 dB(A)	4 m from the front, on the right in the driving direction	98 dB(A)	123 dB(A)
SP 2800 D	96 dB(A)	4 m from the front, on the left in the driving direction	95 dB(A)	123 dB(A)
SP 2800 E	97.1dB(A)	5 m from the front, on the left in the driving direction	98.5 dB(A)	107.8 dB(A)
SP2800 D CAT 151 kW	105 dB(A)	4 m from the front, on the right in the driving direction	101 dB(A)	123 dB(A)
SP 2800 D Tier4f 168 kW	115.7 dB (A)	at the front of the machine	98.4 dB(A)	123 dB(A)
SP 3800 D Tier3	119.1 dB(A)	at the front of the machine	98.4 dB(A)	123 dB(A)
SP 3800 D Tier4f	115.7 dB (A)	at the front of the machine	98.4 dB(A)	123 dB(A)
SP 3800 E				123 dB(A)
SP 9500 D Tier3	116.4 dB(A)	at the front of the machine	99.7 dB(A)	123 dB(A)
SP 9500 D Tier4f	119.3 dB(A)	at the front of the machine	105.4 dB(A)	123 dB(A)
SPB 25-32	85 dB(A)	at the drive	/	117 dB(A)
SPB 35	85 dB(A)	at the drive	/	117 dB(A)
TSR 30/10 E				123 dB(A)

Fig. 8 Sound values for stationary concrete pumps




Fig. 9 Measuring point (L_{pAmax}) measured from the front

Ground clearance:	1.6 m
Taking the measurement:	Operate the machine at maximum hydraulic power



Information

The measured sound pressure level (L_{pA}) is also influenced by the installed drive power and the drive motor used.

For this reason we have attributed the highest measured value to each type of our construction concrete pumps.

2.9 Pictographs without text

Different warning and information signs in the national language are located on your SCHWING concrete pump, in addition to textless pictographs.

An overview of all signs without text can be found below.

Pictographs without text are situated on various control elements on the machine.



Information

All signs and pictographs are important components of your machine!

Should the machine be used in a region with a different language than initially planned, the signs and labels must be exchanged for a version in the national language.

Always ensure that the signs are clearly legible and replace any damaged or illegible signs immediately. To do this, refer to the material number on the sign (Fig. 10 Material numbers for signs).
















Fig. 10 Material numbers for signs
















Information

Some of the signs indicated are not available on each machine. The scope of the signs and labels depends on the type and design of your machine.

2.9.1 Pictographs

<p>Concrete pump Pumping - 0 - Sucking</p>  <p>10144573</p>	<p>Start-up damping on / off</p>  <p>10187511</p>	<p>Start-up damping</p>  <p>10144566</p>	<p>Delivery rate adjustment</p>  <p>98362082</p>
<p>Agitator Pump operation (P) - 0 - Suction operation (R)</p>  <p>98362086</p>	<p>Concrete pump Suck - 0 - Pump</p>  <p>10115873</p>	<p>Isolation valve open</p>  <p>98362502</p>	<p>Isolation valve close</p>  <p>98362504</p>
<p>Chamber valve open Compressor Chamber valve closed</p>  <p>10177036</p>	<p>Chamber valve - 0 - Compressor</p>  <p>10189680</p>	<p>Chamber valve Open - 0 - Closed</p>  <p>10214311</p>	<p>Switching water box/ spray hose</p>  <p>10202103</p>

<p>Speed adjuster</p>  <p>10086507</p>	<p>Water pump</p>  <p>10158389</p>	<p>Compressor</p>  <p>10144568</p>	<p>CE signs</p>  <p>10148919</p>
<p>Main switch battery on - off</p>  <p>98394724</p>	<p>Delivery note box - No tread surface</p>  <p>98393988</p>		
<p>Stowing box Up - 0 - Down</p>  <p>10191719</p>	<p>EASy display</p>  <p>10200927</p>	<p>Underride protection device</p>  <p>98361549</p>	

 <p style="text-align: right; font-size: small;">98363577</p>	 <p style="text-align: right; font-size: small;">10163380</p>
<p>Attention! Example values for:</p> <ul style="list-style-type: none"> • Horizontal trailer load • Vertical trailer load  <p style="text-align: right; font-size: small;">98381870</p>	 <p style="text-align: right; font-size: small;">98381419</p>

Lifting eye; 98363577*

10163380

Attention!

Example values for:

- Horizontal trailer load
- Vertical trailer load

98381870*

98381419*

* = For stationary concrete pumps only



2.10 Control, warning and steering elements SP 1800 / 2800

This chapter clearly describes the positions of the control, warning and steering elements on your machine.

2.10.1 Concrete pump control

The concrete pump control lets the operator control all functions of the concrete pump electronically. The system includes the control panel and cable remote control, as well as the optional radio control.

Connect the cable remote control to the power outlet (11) (**Fig. 11**).

If the machine is operated with the radio remote control or operator keyboard, insert the bypass plug into the power outlet (11).

The control panel is equipped with the following elements.




Fig. 11 Concrete pump control

Caption (Fig. 11 Concrete pump control)	
Pos.	Description
1	Fuel level warning light
2	Illuminated ON / OFF button for agitator suction operation
3	Illuminated ON / OFF button for agitator pumping operation
4	Illuminated ON / OFF button for concrete vibrator
5	Concrete pump suction operation illuminated button
6	Illuminated OFF button for concrete pump



Caption (Fig. 11 Concrete pump control)	
Pos.	Description
7	Illuminated button for concrete pump pumping operation
8	EMERGENCY STOP
9	Water pump
10	Compressor
11	Power outlet for remote control cable / dummy plug
12	Hydraulic oil temperature indicator
13	CAT control

2.10.2 Cable remote control




Fig. 12 Cable remote control

Caption (Fig. 12 Cable remote control)	
Pos.	Description
1	Light: Remote control active
2	EMERGENCY-STOP button
3	Illuminated button: Concrete pump, suction
4	Button: Concrete pump off
5	Illuminated button: Concrete pump, pumping

2.10.3 CAT control (IOPU control panel)



Information

Note that regeneration occurs automatically with the SP 1800 CAT TIER 4i and 2800 TIER 4f.




Fig. 13 IOPU Tier 4i, Stage IIIB - CAT control panel

Caption (Fig. 13)

Pos.	Description
1	Yellow "fault/warning indicator" light indicates errors reported via the CAN bus.
2	Red "fault/warning indicator" light indicates a shutdown reported via the CAN bus.
3	"Regeneration request" button: The operator can use this button to send a regeneration request to the motor for the purpose of carrying out an active regeneration, see Chapter (2.10.5).
4	"Regeneration suppression" button: The operator can use this button to send a signal to the motor to instruct it to suppress an active regeneration, see Chapter (2.10.5).
5	"Enter" button: The operator can use this button to select settings in the settings screen for adjustments and saving.
6	"Right arrow" button: The operator can use this button to scroll through error lists in measurement display screens and through settings in the settings screen.



Caption (Fig. 13)	
Pos.	Description
7	IOPU control station connector: Connects the IOPU control station to the motor wiring harness.
8	"Left arrow" button: The operator can use this button to scroll through error lists in measurement display screens and through settings in the settings screen.
9	"Back" button: The operator can use this button to move between various screens and to quit the displayed settings without saving.
10	"Speed reduction" button: The operator can use this button to reduce the speed of the motor via the CAN bus by using TSC1. Pressing the button displays the desired motor speed screen to the operator. ("Reduction step" = 25 rpm, adjustable standard value; return time "Hold" = 200 rpm, adjustable standard value)
11	"Speed increase" button: The operator can use this button to increase the speed of the motor via the CAN bus by using TSC1. Pressing the button displays the desired motor speed screen to the operator. ("Increase step" = 25 rpm, adjustable standard value; ramp-up time "Hold" = 200 rpm, adjustable standard value)
12	Key-operated switch: The operator starts the motor by turning the key to the "Start" position.
13	"Motor shutdown via control panel" button. Switch actuation by the operator. To shut down the motor, the switch must be pushed in. Pulling out the switch causes the release for starting via the key-operated switch.

2.10.4 TSC function

The TSC function allows you to change and save the motor's rotational speed on the control panel.

The function is the equivalent of a cruise control in a passenger vehicle.

As long as the control is active, the configured value will remain saved on the clipboard and can be restored after any potential interruptions by using the "TSC" button (14).

As soon as the control is switched off using the key-operated switch (12), that saved value is deleted.

- To configure the rotational speed, enable the TSC function by pressing button (14) once.
- The current rotational speed is then shown on the display.
- Change the rotational speed with the help of buttons (10) and (11), see caption for (Fig. 13).



Fig. 14 IOPU Tier 4f, Stage IV - control panel

Caption (Fig. 14)	
Pos.	Description
14	TSC function ON
15	TSC function OFF

2.10.5 “Regeneration” instructions



Information

Engine power failure!

Observe the possible automatic regenerations of the diesel engine.

The motor speed can be lowered automatically or the diesel engine will be switched off in pumping operation.

Carry out the regeneration in due time according to the motor manufacturer’s specifications.






Attention!

Machine parts or the entire machine can be destroyed.

Follow the following description carefully for the manual “regeneration”.

Implementation of regeneration for Caterpillar motor CAT C7.1 Acert Tier 4i.

5.	The degree of clogging is displayed on the Caterpillar display, item 0 (Fig. 13) (bar graph or percentage).		
6.	Automatic regeneration of the diesel particle filter (DPF) can already be carried out from a degree of clogging of 30%.		
7.	Automatic regeneration of the diesel particle filter (DPF) is required starting at a degree of clogging of 80%; a control light appears on the display.		
8.	At a degree of clogging of 100%, the following lights up on the display.		
9.	Further use without regeneration will result in the motor performance being independently reduced.		
10.	If the degree of clogging increases further, then a warning buzzer sounds in addition to the indicators.		
11.	After the warning buzzer has been sounding for 5 minutes, the motor switches to idling speed.		
12.	Within the next 10 minutes of idling, regeneration must be carried out.		

<p>13. If generation is not carried out, then the motor is automatically locked and shuts down. When restarting, the motor shuts down again after 30 seconds and can only be unlocked again by authorised service technicians.</p>
<p>14. If, despite these locks, the motor continues to be run, then this can lead to the DPF being replaced.</p>
<p>15. Start of regeneration (from point 3 at the latest):</p> <ul style="list-style-type: none">a) Allow the machine to idle unencumbered.b) Switch on the upgraded key-operated switch (1) (Fig. 15).c) Press button (3) (Fig. 13) for at least 3 seconds.d) Regeneration starts within the next 10 minutes (the motor may still have to reach operating temperature, for example).
<p>5. Carrying out regeneration:</p> <ul style="list-style-type: none">a) The motor carries out regeneration independently.b) Do not attempt to carry out any machine functions during regeneration.c) Regeneration must not be interrupted.d) The process can last up to approx. 30 minutes.e) The motor independently adjusts its speed.
<p>6. End of regeneration:</p> <ul style="list-style-type: none">a) The indicator goes out. Attention, sometimes the indicator goes out on starting regeneration.b) The clogging indicator is set to "0", this means that the black bar is no longer visible on the display.c) Any increases in motor speed return to idling.d) Turn back the key-operated switch.e) Start working operation.



Fig. 15 The “Regeneration” key-operated switch




Fig. 16

Caption (Fig. 16)	
Pos.	Description
1	Locking bar for grid assembly filling-in hopper
2	Cleaning cover of the rock valve
3	Lubrication point
4	Locking bar for outrigger
6	Hydraulic oil pressure gauge for concrete pump

2.10.6 Hydraulic oil filter




Fig. 17

Caption (Fig. 17)	
Pos.	Description
1	Hydraulic oil filter

2.10.7 Water separator

A warning is issued when the water level in the fuel/water separator is too high.

Drain water from the fuel system:

- Connect a suitable hose to the draining device
- Open the drain valve
- Rotate the drain valve anti-clockwise
- Loosen the breather screw (2) (**Fig. 18**)
- Drain the fuel from the reservoir
- Remove the hose from the drain valve
- Tighten the breather screw
- The reservoir must be drained daily




Fig. 18

Caption (Fig. 18)	
Pos.	Description
2	Breather screw on the water separator

2.10.8 Output regulation




Fig. 19

Caption (Fig. 19)	
Pos.	Description
3	Output regulation of the concrete pump

2.10.9 Fuel filter




Fig. 20

Caption (Fig. 20)	
Pos.	Description
2	Fine fuel filter
3	Course fuel prefilter




Fig. 21

Caption (Fig. 21)	
Pos.	Description
4	Course fuel prefilter in detail

2.10.10 Main switch for starter batteries

The main switch for the starter batteries (1) and the button for the forced switch-off (2) are located on the left in the direction of travel for the machines described in these operating instructions.




Fig. 22 Position of button for forced switch-off / main switch for starter batteries

When working on the electrical system, performing maintenance and conducting repairs, your machine's power supply must always be switched off via the main switch (1) (**Fig. 23**) for the starter batteries. To do this, turn the main switch for the starter battery (1) to the right to the "0" position.




Fig. 23 Detailed view of main switch for starter batteries

2.10.11 Forced motor switch-off

Interruption of the run-on function!

The motor can be switched off immediately via a forced switch-off in case of an emergency.

To do so, actuate the button (2) (**Fig. 24**).

The button is located to the left in the direction of travel, next to the starter battery.

Only use the interruption of the run-on function (forced switch-off of motor) in case of emergency.



Attention!

Severe material damage to motor!

Repeatedly forcing the motor to switch off at short intervals can cause severe motor damage.

If it is not an emergency, do not shut down the diesel engine at full load but rather run it at idle for a few minutes to equalise the temperature.

Failure to observe these instructions may cause severe motor damage from overheating, especially with turbo-charged motors.

For certain motors, switching off the motor may be delayed at operating temperatures that are too high; motors will continue running for several minutes!

This automatic run-on function shown on the display. The run-on function must not be interrupted during normal operation (no emergency).

Observe operating instructions of the motor manufacturer!




Fig. 24



3 Operation

This chapter describes:

- All of your machine's operating modes
- Safe and proper handling
- Safe and economical operation



3.1 Driving operation PLC



Information

Stationary concrete pumps may only be driven in open road traffic with the appropriate approval.

The equipment for the concrete pump with a chassis frame approved for road traffic may require an amendment to the operating instructions.

This amendment is provided as a separate document, as needed.

The driver of the tractor must have the necessary driving licence. Observe the regulation in the country of use.

Make sure the machine is roadworthy before driving. This includes:

- The air pressure of the tyres according to the table
- The lighting is working properly (only for 80 km/h chassis frame)
- The braking system is working properly (only for 80 km/h chassis frame)
- Sound chassis frame maintenance
- Equipment and accessories are stored securely

3.1.1 Environmental protection and accident prevention

- Check for leaks in the reservoirs.
- Empty fuel tank and oil box, if necessary.
- Secure the outrigger against extending on its own.

3.1.2 Air pressure table

Tyre size	Air pressure (bar/psi)
6.50 R 16 C	5.0 / 70
7.00 R 16	6.0 / 85
7.50 R 16	6.5 / 90
8.25 R 16	7.0 / 95
8.50 R 17.5	6.0 / 85
9.00-20.14 PR	7.75 / 110
10 R 22.5	7.0 / 95

Tyre size	Air pressure (bar/psi)
275 / 70 R 22.5	7.0 / 102
445 / 45R 19.5	9.0 / 130

3.1.3 Transporting people and goods

Stationary concrete pumps are work machines.

They may not be used for the transport of people and goods.

This also applies for the transport of concrete in the filling-in hopper of the concrete pump.

Unfavourable weight distribution worsens vehicle handling and can lead to damage to the chassis frame and structure.

Accessories essential to the work application are excluded from the prohibition. Accessories must be stowed in a roadworthy manner. The permissible total weight and the maximum permissible axle load must not be exceeded.

3.2 Installation site of the stationary concrete pump

SCHWING recommends not driving onto the jobsite until you have been briefed by an “instructor” authorised by the site management.

If stationary concrete pumps (SP) are used for up-pumping or down-pumping, a certain amount of “run-up track” should be provided with horizontally laid tubes.

Observe the following points:

- Before driving onto the jobsite, determine the exact location on the site
- Together with the instructor, make sure that the allocated location can readily bear the supporting force of your machine (Fig. 25)
(Your machine’s stability must be guaranteed without fail)
- Refuse to commence operations if the stability cannot be 100 % guaranteed by the site management
- Clear the allocated location of any disturbing unevenness before driving onto the site
- Make sure that the truck mixer can reach the concrete filling hopper without any difficulties
- Avoid relocating the machine
- Ensure sufficient ventilation (exhaust fumes, overheating, fire hazards)
- Prevent collisions with other equipment on the jobsite (cranes, diggers, etc.)
- Maintain the prescribed safety distance between the machine and excavation pits (Fig. 26 Distances from excavation pits (example))
- Do not impair traffic on the jobsite or on the street
- Secure the installation site according to regulations if the machine protrudes into traffic.




Fig. 25




Fig. 26 Distances from excavation pits (example)

3.2.1 Earthing to prevent static charges



Danger!

Danger to life caused by electrical shock due to improper earthing!

The necessary work may only be carried out by a qualified electrician!

After connecting the earthing cable, the electrician must check the efficacy of the measures by measuring the resistance. If necessary, this test can be repeated during prolonged use.

The earthing of the machine does not offer any protection against a voltage transfer, such as would occur through direct contact with a live conductor or by arc transfer due to impermissible proximity to a transmission line!

Likewise, it does not protect against a lightning strike!

As described in our SAFETY MANUAL, the prescribed safety distance must absolutely be adhered to when working in proximity to transmission lines, or otherwise the line must be taken down.

During bad weather, the placing boom must be folded together into transport position.



Information

As of May 2012, SCHWING concrete pumps are equipped with a connection option for an earthing cable.

Before connecting the earthing cable, the supporting surfaces must be bare metal!



Information

Refer to the safety manual

Excerpt: "The radio control unit can suffer malfunctions in the proximity of transmitters (radio transmitters, etc.) and dangerous, electrical charges can occur on the machine. Persons bridging the gap between the charged components and the earth will be severely electrified upon contact.

Machines situated near the transmitters have to be earthed by means of the following minimum measures:

1. Earthing cable (min. 16 mm²)
2. Earthing point on the machine (bare metal point, incl. screw)
3. Conductive metal rod (min. insertion depth = 1.5 m)

Moisten the ground surrounding the metal rod generously in order to increase its conductivity.

The safety distances to high-voltage lines must be observed for earthed machines, too.

The earthing cable and conductive metal rod are not included in the scope of delivery of your SCHWING machine.

A stainless steel screw M12 with nut is pre-installed for the earthing connection on one of the two vertical spars (1) (**Fig. 27**) on the rock valve support (screw inside, nut outside).

For thick-walled plates, at this location a stainless steel screw M 12 is screwed in from the outside.

As the threads are located on both spars (1), the earthing connection can be relocated as needed.




Fig. 27 Rock valve support

3.2 Installation site of the stationary concrete pump

3.3 Electrical connection (optional)



Danger!

Only authorised personnel may connect, commission and disconnect electrically driven machines.

Only authorised personnel may open the switch cabinet.

The operator must initiate the correct connection of the machine.

In Germany, a special feed point is required in accordance with VDE 0100 § 55 (e.g. construction site power supply distributor with ground fault interrupt).

Observe the regulations in the country of use.

3.3.1 Instructions for electricians

3.3.1.1 Standard equipment

- Protection class: IP 54
- Operability during mains voltage fluctuations: ISO class B
- When connecting to the supply line, ensure that a right-hand rotating field is formed
- Protection against radio and television reception disturbances (no disturbances with asynchronous squirrel-cage motors)
- Switching diagrams: see sign in terminal box
- Other protection classes, voltage tolerances, etc. available on request.

3.3.1.2 Safeguarding and conductor cross-sections

Electric motor			Supply line max. 100m	
kW	V	A	mm ²	Fuse (A)
30	400	55	4 x 16	63
45	400	80	4 x 25	100
55	400	100	4 x 35	125
75	400	135	4 x 50	160
90	400	160	4 x 70	200
110	400	195	4 x 95	224
132	400	230	4 x 120	250
160	400	280	4 x 185	315
200	400	350	4 x 240	400
250				

3.3.2 Checking the rotational direction of the electric motors (control without phase sequence monitoring)

The rotational direction of the electric motors must be checked:

- Before every commissioning
- After the connection
- After repairs to the electrical system
- After changing the supply cable or parts of the cable
- After extending the supply line using additional cables




Danger!

Danger to life by electric shock!

Before replacing the phases, always move the main switch into the 0 position and pull the mains plug.

This is marked on new machines by arrows on the fan blowers of the motor.

The rotational direction is always towards the right when looking down at the ventilators (clockwise direction) (Fig. 28).



Drehrichtung-V01

Fig. 28

Proceed as follows to check the rotational direction:

- Switch on the motor briefly
- Check rotational direction by looking at the fan wheel
- Switch the phases if rotating in the wrong direction
- Recheck the rotational direction

3.3.3 Checking the rotational direction of the electric motors (control with phase sequence monitoring)

For machines with a control on which the phase sequence is monitored, checking the rotational direction is not necessary.

If the phase sequence is incorrect, the motor will not start.

Have authorised personnel replace the phase sequence.

Repeat the start-up procedure.

3.3 Electrical connection (optional)

3.4 EMERGENCY-STOP system for SP 1800 / 2800

Your machine's EMERGENCY-STOP system is intended to allow you to shut off dangerous machine functions as quickly as possible when other protective measures that have already been taken do not suffice.

Thus, you can prevent a dangerous situation from turning into an accident, minimise the severity of an accident or stop a machine malfunction before it causes any damage to the machine.



Danger!

Risk of accident due to inoperative EMERGENCY-STOP button!

Operating the machine with a defective EMERGENCY STOP system is prohibited and can lead to fatal accidents.

Prior to any working operation, check the function of all EMERGENCY STOP buttons.



Information

Inform any relevant persons of the positions of the EMERGENCY STOP buttons on your machine so that they can react in emergency situations.

The EMERGENCY STOP buttons built into your machine can be seen in (Fig. 29 EMERGENCY-STOP buttons; similar to illustration)




Fig. 29 EMERGENCY-STOP buttons; similar to illustration

The machine is equipped with EMERGENCY STOP buttons on the machine and remote control (**Fig. 30**).




Fig. 30 Remote control

**Warning!****The motor is not switched off!**

Such special equipment having locked control levers also continues to run.

- Switch off the motor or special equipment, if necessary, as described in the corresponding chapters.



3.4.1 Restarting the machine after an EMERGENCY STOP

- Switch all locked selector switches and control levers to the centre or 0 position.
- Remedy the fault.
- Unlock the EMERGENCY-STOP button by turning it towards the arrow.
- Start the motor, if necessary, and set the (diesel) operating speed.
- Start the desired functions using the corresponding control elements.

The tarnish protection prevents the concrete pump and agitator from starting by simply unlocking the actuated EMERGENCY-STOP button.



Caution!

Do not hesitate to press the nearest EMERGENCY-STOP switch immediately if this helps to prevent an accident.

If the machine carries out unwanted movements, directing the machine in the opposite direction can be ineffective if the corresponding hydraulic control valve jams, for example.

Therefore, press the nearest EMERGENCY-STOP switch immediately if the machine carries out unwanted movements, does not react or reacts incorrectly to control commands.

Please inform potential assistants (e.g. the mixer driver) of the function, task and position of the EMERGENCY-STOP switches on the machine if you leave with the remote control.

3.5 Readyng the machine for operation SP 1800/2800

Check the hydraulic oil level in the reservoir. The hydraulic oil box is located on the left in the direction of travel. The oil level must be visible between “min” and “max” on the level indicator (1) (**Fig. 31**). Top up the hydraulic oil, if possible.




Fig. 31

Caption of (Fig. 31)	
Pos.	Designation
1	Level indicator
2	Filling neck
3	Cleaning cover

The filling neck (2) is located at the top of the reservoir and can be accessed after loosening the top cover.



Attention!

Material damage caused by fuel in the hydraulic oil box!

The machine can be severely damaged if the tanks for hydraulic oil and fuel are mixed up.

Do not mix up the filling neck for hydraulic oil with the fuel filling neck on the opposite side!

- Ensure that all oil-filled aggregates are tight. Check oil levels and top up with oil, if necessary.

- Ensure that the screw joints of the hydraulic system are tight, and tighten them if necessary.
- Fill the water box (1) (**Fig. 32**) to the top edge of the pumping pistons. If there is a danger of frost, only add water immediately before concreting.



Warning!

Danger of crushing!

Only open water box with drive at a standstill and while pressure accumulator is discharged (if present).

Then close the water box and secure it with a wedge (2) and clip pin (3).




Fig. 32

- Check whether the ball valve (1) (**Fig. 33**) on the concrete pump control block is in the operating position. Observe the signs and labels.




Fig. 33 Pressure control for concrete pump

The ball valve is used to block the concrete pump during repair work.

- Check the grid assembly in the concrete filling hopper.

Two locking bars (3) (**Fig. 34**) are used to secure the grid assembly.

Insert both locking bars. Otherwise, the concrete would bend or push up the grid assembly. An end limit switch shuts down the agitator and concrete pump when the grid assembly is raised.




Fig. 34



Danger!

The machine may only be commissioned with closed covering caps and tightly closed grid assembly.

Shutdowns triggered by the end limit switch are not EMERGENCY-OFF shutdowns. The agitator and concrete pump restart after closing the grid assembly.

3.5.1 Diesel engine

- Carry out the necessary work in accordance with the motor operating instructions prior to commissioning the drive motor (check oil level, etc.).
- Check the fuel supply and AdBlue level on the concrete pump control unit.



Information

If the ignition is switched on, the warning light (1) (**Fig. 35**) turns on as soon as there are approx. 38 l remaining.

This amount is enough for an operating time of approx. 45 minutes.




Fig. 35



The filling neck (1) (**Fig. 36**) for the fuel tank is located on top of the fuel tank. The fuel tank features a level indicator (2) (**Fig. 36**).

- Top up diesel fuel, if necessary. Refer to the motor operating instructions for the fuel quality. The fuel tank has a capacity of approx. 250 litres.



Danger!

Risk of explosion!

- Only refuel when motor is not running!
- Do not spill fuel!
- Observe the safety regulations for handling fuel!

Ensure absolute cleanliness!



Attention!

Risk of confusion with the hydraulic oil filling neck!

The machine can be severely damaged if the tanks for fuel and hydraulic oil are mixed up.




Fig. 36 Diesel filling neck

3.5.2 Fuel prefilter

Any accumulated water must be drained daily from the settling vessel on the fuel prefilter (1) (**Fig. 37**) according to manufacturer's instructions.

Water collects in the lower part of the vessel.

- Position a suitable collection container below the drain cock.
- Open the drain cock and collect the escaping water.
- Collect fuel mixture and dispose of properly!
- Close the drain cock when pure fuel begins to pour out.




Fig. 37

3.5.3 AdBlue reservoir

The AdBlue tank is installed on the left in the direction of travel and can be swung out (1) (**Fig. 38**).

- In order to access the AdBlue tank, open the left-hand maintenance flap,
- Disengage the safety on the slewing arm (2) (**Fig. 39**) / detailed view (1) (**Fig. 40**),
- Swing the AdBlue tank out of the machine frame (**Fig. 41**),
- Secure the extended AdBlue tank with the split pin provided for that purpose (1) (**Fig. 42**), detailed view (**Fig. 43**).

Proceed in reverse order to swing the tank back in.




Fig. 38




Fig. 39






Fig. 40



Fig. 41





3.5.4 Theoretical operating time

Plan the operating times of the machine carefully before commencing work.

Find out about the average fuel consumption using the consumption values and thus calculate the theoretical operating times, see motor operating instructions!



Information

Engine power failure!

Depending on the engine, observe the required manual or automatic regenerations for the diesel engine.

In pumping operation, the engine speed can be reduced at any time during automatic regeneration or the diesel engine will be switched off.

Carry out the manual regeneration in due time according to the motor manufacturer's guidelines.



Attention!

Machine parts or the entire machine can be destroyed.

Perform the regeneration according to the guidelines.

3.5.5 Example of an operating time calculation

Theoretically, the following operating times apply for each full tank with an average fuel consumption of approx. 220 g per kW and hour:




Fig. 44

To A)	Max. diesel filling volume in (L) (tank contents)
To B)	Viscosity of diesel fuel at 15°C
To C)	Fuel consumption in kg / kW
To D)	kW of the motor

SP 1800:	$\frac{250 \times 0,82}{0,22 \times 126} \times \frac{l \times kg \times kW \times h}{kg \times kW \times l} = \underline{\underline{ca. 7,4h}}$
SP 2800:	$\frac{250 \times 0,82}{0,22 \times 147} \times \frac{l \times kg \times kW \times h}{kg \times kW \times l} = \underline{\underline{ca. 6,4h}}$

3.6 Drive circuit SP 1800 / 2800

3.6.1 Starting the diesel engine



Caution!

Unintentional start-up!

Hydraulic oil pressure is built up automatically!

After starting the drive motor, the hydraulic pumps immediately deliver oil.

- Insert the key into the key starter switch (12) (**Fig. 45**) or (**Fig. 46**).
- Press the key in slightly and turn it clockwise to the first locking position.

The warning lights (1 + 2) light up during a short automatic check (**Fig. 45**) or (**Fig. 46**). If no faults are detected, the lights go out after approx. 2 seconds.

- If light (1) (**Fig. 47**) does not go out, check the fuel supply.
- Actuate the starter by turning the key further clockwise.

If the motor fails to start up immediately, do not continue trying to start it for more than 10 seconds.

After each start-up procedure, take a one-minute break. Observe cold-start information in the motor operating instructions.

- Once the motor has started, let go of the starter key immediately.
- Increase the motor speed slightly using the button (11) (**Fig. 45**) or (**Fig. 46**) and let the diesel engine warm up at a moderate speed without a load. Pay attention to any irregularities.
- Once the diesel engine has warmed up, check the nominal output (operating speed). To do this, increase the rotational speed with the button (11) and make sure the adjustable maximum speed does not exceed the nominal speed.
- If the nominal speed (**chap. 2.6**) is exceeded, lower the rotational speed immediately with the button (10).
 - Have the engine timing checked.
- If the nominal speed is not reached:
 - Have the engine timing checked.
- Reduce the engine speed to idle until the concrete pump is placed into operation.




Fig. 45 Control panel with regeneration



Fig. 46 Control panel with TSC




Fig. 47

3.6.2 Switching off the diesel engine

Allow the engine to idle for a few minutes to equalise the temperature.
 Only switch off the engine at full load in an absolute emergency.



Attention!

Motor damage caused by overheating!

Switching off the engine at full load can cause severe motor damage from overheating, especially with turbo-charged motors.

For certain motors, switching off the motor may be delayed at operating temperatures that are too high; motors will continue running for several minutes!

This automatic run-on function is indicated by a symbol on the display. The run-on function must not be interrupted during normal operation (no emergency).

Observe MOTOR OPERATING INSTRUCTIONS!

Reduce the stroke rate of the concrete pump as far as possible using the pressure reducing valve (4) (Fig. 48).

Switch off the concrete pump and agitator.




Fig. 48 Maintenance flaps on left in direction of travel

3.6.3 Forced switch-off of motor

The motor can be switched off immediately via a forced switch-off in case of an emergency.




Fig. 49 Button for forced motor switch-off

- To do so, actuate the button (2) (**Fig. 49**). The button is located on the left in the direction of travel, next to the starter battery.

**Caution!****Motor damage caused by forced switch-off!**

- Only use the interruption of the run-on function (forced switch-off of motor) in case of emergency.

Repeatedly forcing the motor to switch off at short intervals can cause severe motor damage.

- In order to prevent a function from starting up unintentionally after switching the machine back on, switch all engaged steering elements to the "0 position".
- Reduce motor speed to idle.
- Turn the key of the starter switch (12) (**Fig. 45**) anti-clockwise.

The motor is shut down electronically.

- Turn the key further and remove it.

3.7 Setting up the machine

The installation site must be set up so that the transport vehicles can reach the concrete filling hopper without any problems and the machine is accessible for maintenance and cleaning purposes.

- Inquire about the permissible ground pressure at the jobsite. Refer to the technical specifications for the max. single outrigger static load. Deviations are possible due to different equipment versions.
- If necessary, use load-distributing underlay supports beneath the supporting dishes.



Danger!

Loss of stability!

The machine must not be installed if its maximum ground pressure exceeds the permissible value.

If necessary, the support surface must be extended using suitable means until the permissible ground pressure is reached.

Always insert socket pins and split pins to secure after supporting.

Unburden hydraulic!

Depending on the machine's length of stay, we recommend using our support pads (item no.: 1095646) or creating a suitable concrete surface.



Attention!

Extend hydraulic supports evenly, insert socket pins and split pins, and unburden hydraulics.

Do not drive a cylinder to the limit stop before the next one has been driven. The frame and outrigger were put under unnecessary strain.

If load-distributing underlay supports are used, they must be suitable and undamaged, as well as free of ice, oil, grease etc.

3.7.1 Downtimes

- Secure the machine against unintentional changes of position, even during short downtimes.



Information

Brake wedges are not included in your machine's scope of delivery!
Machines without a "chassis frame for road traffic" do not have brakes.

If the machine remains at an installation site for an extended period of time, we recommend removing the wheels (prior to lifting, loosen the wheel nuts).

Store the wheels and cover the wheel hubs.

3.7.2 Outrigger variants

The machine can be delivered with a mechanical or semi-hydraulic outrigger.

In this case, the machine must be installed using a crane.

- Use suitable slings and only attach them to the lifting eyes on the machine. Observe the warning signs (**Fig. 50**) and (**Fig. 51**).
- Create a suitable, even surface.
- Set the machine down in the prepared location and check its horizontal position.
- If necessary, lift the machine up again in order to reposition the supports.




Fig. 50




Fig. 51



Danger!

Falling loads!

Do NOT exceed load the capacity of the lifting eyes with additional weight from accessories and residual pumping material!

Determine weight of loads prior to raising.



Attention!


Chain lengths that are too short lead to serious strain on the straight frame.

When transporting the machine with chain slings, the individual chain lengths must be a minimum of 2.5 m!

3.7.3 Machine with chassis frame (SP 1800)

- Drive the machine to the prepared installation site.
- Lay a suitable support pad (e.g. item no.: 1095646) under the supporting dish of the crank support (**Fig. 52**).
- Before the concrete pump is uncoupled from the towing vehicle, remove the socket pin (1) and lower the interior tube (2) (**Fig. 52**).


- Reinsert the socket pin (1) and secure with split pins.
- Remove safety device (4) from crank.
- Lower the crank (3) by rotating the supporting dish until the trailer coupling is released.
- Lower the rear supports (2) (**Fig. 53**) and secure with socket pins and split pins.
- Secure the machine using the wheel wedge (1) (wheel wedges are not included in the scope of delivery) (**Fig. 54**).
- Uncouple the towing vehicle.




00109_SP-Stützwinde

Fig. 52 Support jack (SP 1800)

Caption of (Fig. 52)	
Pos.	Designation
1	Socket pin
2	Interior tube
3	Crank
4	Fuse
5	Exterior tube



00045_Abstützung_V01

Fig. 53 Example illustration

Fig. 54

3.7.4 Machine with chassis frame (SP 3800)


- Drive the machine to the prepared installation site.
- Lay a suitable support pad (e.g. item no.: 1095646) under the supporting dish of the crank support (**Fig. 55**).
- Before the concrete pump is uncoupled from the towing vehicle, remove the socket pin (1) and lower the interior tube (2) (**Fig. 55**).
- Reinsert the socket pin (1) and secure with split pins. Pull out the crank (3) and lower the supporting dish by rotating until the trailer coupling is released.

The crank (3) can be pulled out in 2 steps.

Step 1 = Overdrive

Step 2 = Low gear


- Lower the rear supports (2) (**Fig. 56**) and secure with socket pins and split pins.
- Secure the machine using the wheel wedge (1) (wheel wedges are not included in the scope of delivery) (**Fig. 57**).
- Uncouple the towing vehicle.



00045_Stützwinde_V01

Fig. 55 Support jack (SP 3800)

Caption of (Fig. 55)	
Pos.	Designation
1	Socket pin
2	Interior tube
3	Crank
6	Exterior tube



00045_Abstützung_V01

Fig. 56 Example illustration




Fig. 57

3.7.5 Mechanical outrigger

- Lower the front of the machine using the crank (3) (**Fig. 55**) / (**Fig. 52**).
- Lower the rear supports (2) (**Fig. 53**) / (**Fig. 56**) and secure with socket pins and split pins.
- Raise the machine at the front using the crank (3) and position it horizontally.
- Lower the front supports (1) and secure with socket pins and split pins.
- Retract the crank support with the crank (3).

The machine is properly supported when:

- The machine is level in all directions
- The axle is released and the wheels are free

3.7.6 Semi-hydraulic outrigger (optional)

For the semi-hydraulic outrigger, the oil flow from the agitator pump is directed into the control blocks of the outrigger.

- Lower the front of the machine using the crank (3) (**Fig. 52**) / (**Fig. 55**).
- Start the motor.
- Extend the front and rear hydraulic supports (1+2) on both sides of the machine using the control levers.
Extend the hydraulic supports evenly until the machine is horizontal in all directions.
The control levers are spring-centred and return to the central position once they have been released.
- Retract the crank support with the crank (3).

The machine is properly supported when:

- The machine is level in all directions
- The axle is released and the wheels are free



Danger!

Loss of stability

Always insert socket pins and split pins to secure after supporting.

Unburden hydraulic!



Danger!

Danger of crushing!

Do NOT remain in the danger area during actuation of the support legs!

3.7.7 Servicing the crank support

- Lubricate the grease nipples (7) (Fig. 58) / (Fig. 59) in accordance with the maintenance schedule.




Warning!

The operator has to carry out an expert inspection prior to each first commission, after any kind of changes to the support equipment and at least once a year according to manufacturer's instructions.


These inspections should be documented in a suitable form.

The operator should check the support equipment for damages and wear prior to each use. The connection and safety parts should be checked in particular for tightness and functionality.



00109_SP-Schmiernippel

Fig. 58 Grease nipples (SP 1800)



00045_Schmier_Stützwinde_V01

Fig. 59 Grease nipples (SP 3800)

3.8 Operating the pumping line

3.8.1 Observation during operation

Prior to operation, make sure that the pumping line is in sound operating condition. Check the safety devices of the pumping line, see (Fig. 60).




Fig. 60



Caution!

Injury caused by the cocking lever springing open!

Injuries such as bone fractures or concussions are possible

Immediately secure the cocking levers on the pumping pipe couplings after installing them.

When mounting split couplings, injuries can be caused by the cocking lever springing open unexpectedly.

Secure the cocking lever of the split couplings immediately after closing the cocking lever by using the "safety for split couplings".

Secure the cup expansion couplings evenly with the "Safety for cup expansion couplings" (clip pin).

The laying and operation of hose lines may only be carried out by appropriately trained personnel.

During operation, the pumping line must be observed for leaks.

A leaking pumping line induces clogging due to drying up "bleeding" of the concrete.

In the event of leaks, stop operation immediately and remedy the leak.



Danger!

Danger to life due to pipe breakage!

Severe injuries or even death due to pipes breaking.

Cease operation immediately if fluid is leaking from any lines. Release pumping line by means of reverse pumping!

If liquid is leaking from a pumping line component (e.g. a coupling, pipe wall or pipe elbow), there is a very high risk of accident.

A single inappropriate coupling can cause failure of the pumping line and accidents.

Check the pumping line frequently with a suitable wall thickness measurement device according to the operating conditions, see chapter (4.16).

SCHWING's customer service can recommend suitable measurement devices depending on the pumping line material being used.

We strongly recommend setting up the pumping line exclusively with appropriate SCHWING material.

This is an important contribution to high operational safety and efficiency.

SCHWING is not liable for any damages caused as a result of using inappropriate material!

3.8.2 Marking pumping pipes and elbows

All SCHWING pumping pipes and elbows are marked as follows, example (Fig. 61) - (Fig. 64).

The marking for pumping pipes is stamped / engraved on the top side of a flange (Fig. 61).




Fig. 61 Position of the tube marking until approx. 2017

Caption of (Fig. 61)	
Designation	Meaning
SH	Manufacturer SCHWING Herne



Caption of (Fig. 61)	
Designation	Meaning
DN	Nominal size in mm (inner)
PN	permissible operating pressure in bar
s	Wall thickness

SCHWING			
Charge	772792	1019280.00	Date 19/16
Material	10133770	960mm	DN 125 SUPER2000
WTmm	4,5 (2,5+2,0)		PN 85 bar / 1.233 psi
WeightNET/pc.	16,0 kg / 35,2 lbs		ODmm 132,0
WeightFWC/pc.	43,4 kg / 95,6 lbs		WeightFWC/l 42,2kg/m / 93.1lbs/ft

00065_Förderrohr_V01

Fig. 62 Pumping pipe marking as of approx. 2017

SCHWING			
Charge	77292	1019280.00	Date 19/16
Material	10115878	1550mm	DN 150/125 SUPER2000
WTmm	7,1		PN 85 bar / 1.233 psi
WeightNET/pc.	41,0 kg / 90.4 lbs		
WeightFWC/pc.	97,0kg / 213.9lbs		

00065_Reduzierrohr_V01

Fig. 63 Tapered tube marking as of approx. 2017

SCHWING			
Charge	77292	1019280.00	Date 19/16
Material	10189900	90,0°	DN 125 SUPER2000
WTmm	9,5 (7,0+2,5)		PN 85 bar / 1.233 psi
WeightNET/pc.	16,0 kg	35,3 lbs	
WeightFWC/pc.	27,8 kg/pc	45,6 lbs/pc	

00065_Rohrbogen_V01

Fig. 64 Elbow marking as of approx. 2017

Caption for (Fig. 62) - (Fig. 64)	
Designation	Meaning
Charge	Order no., customer no.
Date	Production week (MM/YY)
Material	SCHWING item no.

Caption for (Fig. 62) - (Fig. 64)	
Designation	Meaning
--	Dimensions mm/degree
DN	Nominal size in mm (inner diameter)
SUPER 1000	SCHWING quality label
WTmm	Total thickness (inside wall + outside wall)
PN	permissible operating pressure in bar
WeightNET/pc.	Net unit weight
OD	Outer diameter mm
Weight-FWC/pc.	Tube, elbow and tapered tube weight per unit, filled with concrete
WeightFWC/l	Tube weight per metre without flange, filled with concrete

3.8.3 Marking the pumping line on the placing boom

A distinctive type plate is located on the placing boom for the placing boom pumping line (**Fig. 65**). The nominal sizes (DN) specified on this type plate are the maximum allowable.

The nominal sizes and the wall thicknesses of the pumping line and the gross density of the pumped concrete must not exceed the specified limits.

The maximum operating pressures (PN) specified on the components and type plates are the maximum permissible operating pressures for components in new condition. If the minimum wall thickness is not met, then replace the tubes and elbows.

With truck-mounted concrete pumps, the concrete pressure for rod and piston-side pressure is also indicated on the type plate of the concrete pump (**Fig. 66**).

If no value is given for the rod side, it refers to a piston-sided pressurised concrete pump.

This concrete pump may not be interchanged!




Fig. 65 Example: Type plate on 5-part boom

Caption of (Fig. 65)	
Designation	Meaning
max. DN	max. nominal size for inlet side
T	Length of the pipe on the corresponding boom
max. DN	max. nominal size for outlet side



Fig. 66 Concrete pump type plate

3.8.4 Pumping line on the placing boom

Normally, a truck-mounted concrete pump delivers the concrete directly via the pumping line of the assembled placing boom.

A separate placing boom is supplied by a separate concrete pump.



Danger!

Loss of stability due to excessively heavy pumping lines on the placing boom!

The machine can topple over and cause severe or even fatal injuries as a result.

The concrete pumping line installed on the placing boom is an integral part of the machine and must not be changed.

In an extreme situation, the increased breakdown torque may cause the machine to topple over.

Pumping pipes with an excessive tare weight (thicker walls) and pumping pipes with larger diameters can overload the placing boom.

Unsuitable pumping lines cause damage (especially broken tube holders, cracks in boom profiles, etc.).

Due to changes to the pumping line, other safety-relevant adjustments of the machine may be mandatory.

After major changes that are not carried out by SCHWING, placing booms must be inspected by an expert before being recommissioned, see **(3.8.5)**.

3.8.5 Disclaimer

Independent modifications to the machine and using spare parts and accessories that have not been approved by SCHWING fall under the definition of “improper use”.

This also applies to the use of individual parts, such as: Tubes, couplings, elbows, etc.

We would like to draw attention once again to the fact that SCHWING is not liable for damages caused by improper or negligent operation, maintenance and repair or improper use.

This also applies to expansions and conversions, as well as other changes to the machine not approved by SCHWING.

For mounting and operation of separate pumping lines (tubes or hoses), the operator bears sole responsibility!

3.8.6 Reconnectable concrete pumps

In the interest of a high concrete delivery rate, reconnectable concrete pumps are usually supplied with rod-side pressure.



Danger!

Danger to life due to pipe breakage!

Severe to fatal injuries as a result of liquid being discharged explosively from defective pipelines.

The machine must only be modified by SCHWING's customer service.

With piston-side pressure, only use suitable pumping line material.

These concrete pumps must not pump through the end hose and boom pumping line with piston-side pressure.

Reconnectable concrete pumps can produce concrete pressures with piston-sided pressure exceeding the maximum permissible operating pressures of the boom pumping line and other components.

The concrete pressures for rod and piston-side pressure are indicated on the type plate of the concrete pump, see (Fig. 67).

Separately installed pumping lines are an exception.

The concrete pressure that can be reached by the hydraulic pressure must not exceed the maximum permissible concrete pressure of the pumping line components in use.

		SCHWING GmbH Postfach 20 03 62 44647 Herne GERMANY	
Typ	██████████	Masch.-Nr.	██████████
max. zulässig	██████████	bar Betondruck	
max. zulässig	██████████	bar Hydraulikdruck	
Baujahr	██████████		
Betondruck bei: stangenseitiger Beaufschlagung		PN	██████████
kolbenseitiger Beaufschlagung		PN	██████████
MADE IN GERMANY		98413842	

Fig. 67 Concrete pump type plate



Danger!

Danger to life due to moving parts!

Severe injuries or even death due to severed limbs.

Do not reach into the gate valve.

Before opening the pumping line / outlets, switch the drive motor off and secure it against unauthorised activation.

See (Fig. 68).



Fig. 68

3.8.7 Short outlet (foldable)

The foldable pipeline outlet can make the connection flange of the rock valve accessible and cleaned trough the foldable pipeline outlet.

In order to make the connection flange freely accessible:

- Pull the clip pin (1) (**Fig. 69**)
- Loosen the wedge (2)
- Remove the coupling (3)
- Pull the clip pin (4) out of the wedge (5)
- Remove the wedge (5) (**Fig. 69**) and keep it ready to use as a chock for the hinge (7)
- Fold open the outlet (6) to the right
- At an opening angle of approx. 100°, the wedge (5) (**Fig. 69**) can be wedged into the notch on the hinge, as illustrated in (**Fig. 70**).

The connection flange of the rock valve is now freely accessible and can be cleaned.

Once all the work on the flange of the rock valve has been completed, proceed in reverse order to fold back the pipeline outlet and mount to the pumping line of the truck-mounted concrete pump.




Fig. 69 Foldable outlet




Fig. 70 Wedge lock

3.8.8 Short outlet (foldable and rotatable)¹

In order to connect a separate pumping line more easily, certain SCHWING truck-mounted concrete pumps can be optionally equipped with a foldable and rotatable outlet (6; **Fig. 71**).

The short, foldable outlet (standard) can be fully replaced by the foldable and rotatable outlet.

In order to rotate the foldable and rotatable outlet:

- Pull the clip pin and remove the wedge (1) and coupling (5) first
- Pull the clip pin and remove the wedge (2)
- Open the foldable and rotatable outlet
- Loosen both the safety screw (4) and the second safety screw offset by 180° by approx. half a rotation
- Rotate the foldable and rotatable outlet into the required position (e.g. 6; **Fig. 71**) and fold it back
- Reinsert the wedge (2), but do not hammer it in place yet
- If necessary, correct the position of the foldable and rotatable outlet and then hammer the wedge (2) down. Secure the wedge using the clip pin.
- Reattach the upper and lower safety screws (4) Connect a separate pumping line.

In order to reconnect the foldable and rotatable outlet with the pumping line of the machine, proceed in reverse order.

¹.Optional, only for truck-mounted concrete pumps




Fig. 71 Outlet, foldable and rotatable

3.8.9 Large outlet DN 180/180/150 (foldable)

The folding function is the same as for the short outlet. The larger outlet 180/180/150 has the advantage of having less concrete resistance.

Use the “large outlet” when pumping concrete that is difficult to pump.

The larger outlet 180/180/150 also has a 14-degree elbow mounted on the rock valve, see (1) (Fig. 72).




Fig. 72 Large outlet, foldable

3.8.10 Servicing the foldable and rotatable outlet

Once a week, squeeze some lubricating grease into the grease nipple (3) (**Fig. 71**) and into the second nipple offset by 180°.

Actuate the grease gun until the grease visibly emerges.

Lubricate the seal of the split coupling with lubricating grease prior to mounting.

Clean used seals and check them for damage prior to mounting.

3.8.11 Separate pumping line

The use of a stationary concrete pump must always be planned carefully.

In addition to the selection of the right pump, the selection and installation of the pumping line is of great significance.

Both must be done with great care and expertise.

SCHWING offers an extensive range of pumping lines and accessories.

Should you have any questions regarding the pumping line, please contact SCHWING Customer Service.

When selecting the pumping lines, observe the maximum possible concrete pressure of the concrete pump, depending on the:

- Drive power of the concrete pump
- installed pump kit
- Application of the differential cylinder

Certain stationary concrete pumps can, for example, generate a concrete pressure of over 200 bar, see type plate.

These maximum values are rarely achieved during the normal operation.

However, given that, in the event of clogging, the complete pipeline between the concrete pump and the clog is under maximum pressure, the entire pumping line must be able to tolerate these values.

Separate pumping lines are available in different versions:

1. Pumping pipes for split couplings (Fig. 73)

These correspond to the system used for placing booms. They can be used with a pressure of up to 85 bar depending on the nominal sizes (DN). Separately installed pumping lines are suitable up to 110 bar.

Due to the external seal (3), which must be removed and cleaned with each modification, this solution as a separate pumping line is not as economical as the following ones:

2. Pumping pipes with a male and female flange for cup-tension couplings (Fig. 74).

The following versions are available:

- a) Standard tubes up to 4.5 mm thick walls (depending on the nominal size) are suitable for up to max. 110 bar.
- b) Thick-walled tubes with walls that are 7.1 mm thick are suitable for up to max. 160 bar.
- c) Extreme pressure tubes with wall thickness's of 7.1 to 10 mm (depending on the nominal size) are suitable up to 200 bar concrete pressure.

Ultra high pressure tubes are fitted with special high-pressure nozzles (Fig. 75).


They are indispensable for using our concrete pumps SP 3800 - 9500 HDR.



Cup expansion couplings are also used for our extreme pressure tubes.



Information

The figures show typical characteristics of the flange. The exact design is slightly different depending on the nominal size.





3.8.12 Concrete pumping hoses

3.8.12.1 End hoses

An end hose is connected at the end of the pumping line for the distribution of the concrete.



Danger!

Direct danger to life in the danger zone of the end hose!

Danger of death due to flapping end hose, spraying concrete and stones shooting out!

Always adhere to the required safety regulations!

Observe the following points in particular:

- The hose must hang freely when commencing pumping, when starting to pump again, and after blockages. No-one may remain in the danger zone of the end hose. The diameter of the danger zone is double the length of the end hose. It is prohibited to guide the end hose during pumping.
- Do **NOT** use fixed end pieces, reductions or extensions on the end hose! Connecting hoses with double-sided fixing are not permitted for use as end hoses!
- Do **NOT** use a longer end hose!
The maximum lengths and nominal sizes of the end hose are given for placing booms.

In exceptional cases, modifications and extensions are only permitted in strict accordance with the manufacturer's instructions, see the "End hose modification options" table in the ET catalogue. When using a longer end hose, the diameter of the danger zone also increases!

Observe the safety instructions on the machine, see (Fig. 76) - (Fig. 78).




Fig. 76



Fig. 77




Fig. 78

3.8.13 Connecting hoses

Connecting hoses with double-sided fixing can be used as flexible intermediate pieces in rigid pumping lines based on their permissible concrete pressure.

3.8.14 Hose pipes

Multiple connecting hoses are often connected to hose pipes in mobile restoration operations.

The hoses are usually carried on a specially equipped truck-mounted concrete pump, installed before use and removed again after use.

3.8.14.1 Installing and operating a hose pipe

The installation of the hose line, as well as its operation, requires special care and expertise.



Danger!

Danger to life due to flapping hoses!

Block off the danger zone and fix the hoses, cover hose in a suitable manner if required!

In order to avoid a premature failure and possible accidents, ensure the following:

- Only use functional, clean hoses, couplings, seals, etc. of the same system to set up a hose pipe.
- The maximum possible concrete pressure of the concrete pump must not exceed the permissible concrete pressure of all pumping line parts.
- The concreting personnel at the placement site must be aware of any potential dangers and be familiar with all necessary work.
- Install hoses in widest possible radius - do not bend (Radii that are too narrow cause abrasion on one side, thus allowing any bends to quickly destroy the hose. Narrow radii and bends encourage clogging and cause the hose to pulsate).
- Do not pull hoses, especially not over sharp edges.
- Do not twist hoses.
- Do not allow hoses to hang loose.
- Do not strike the hoses.
- Place hoses and fasten securely with belts. Do not use incising fixing parts.
- Do not drive over hoses. Place hose pipe in a protected manner.
- No unauthorised persons may remain near the hose pipe during pumping operations
- Moisten hose with water, then pump with flow mixture.
- Always observe the maximum grain size, depending on the diameter of the hose.
- Pump at a low delivery rate, hose must remain still.

3.8.14.2 Cleaning the hose pipe



Danger!

Direct danger to life due to flapping hoses!

Blowing out pumping hoses with compressed air is prohibited, see safety manual.

Hoses must be carefully cleaned after each use.

A thorough internal cleaning is especially important for this.

Dirty hoses wear out faster and cause clogging.

Suck back the cleaning ball, then knock off individual hoses and rinse thoroughly with water.

If it cannot be sucked back, knock off individual hoses, tip out and rinse thoroughly with water.

- Always make sure that the hose system is perfectly clean.

A clean hose helps prevent clogging.

Dried-up concrete can coalesce with rubber.

This means that not only the remaining concrete, but possibly a piece of rubber, will be pulled out during the next pumping.



3.9 Working operation - General information SP 1800 / SP 2800

3.9.1 Special equipment

Outrigger, compressor, water pump and shut-off assembly are supplied by the agitator pump and activated by engaging the control elements (see hydraulic switching diagram).



Caution!

Unintentional start-up!

After starting the drive motor, the hydraulic pumps immediately deliver oil.

In order to prevent a function from starting unintentionally, switch all engaged steering elements to the "0 position" prior to starting.

- Switch the upstream ball valve to the base position:




Fig. 79 Agitator

(If the machine is equipped with a hydraulic outrigger).

3.9.2 CP remote control

The cable remote control steers the concrete pump during operation.




Fig. 80 Control panel

- Insert the plug of the remote control cable into the power outlet (11) (**Fig. 80**) and secure it.

While the motor is running, the light “1” (**Fig. 81**) lights up on the cable remote control. Thus, the remote control is active.




Fig. 81 Cable remote control

3.9.3 CP local control

In the event that the machine has to be operated during an emergency or test operation, a bypass plug has to be inserted into the power outlet (11) (**Fig. 80**).

Without this plug, no electrical power is available for the machine control unit and the EMERGENCY STOP valve remains open. The concrete pump cannot be operated.

The plug is included in the tool set of the machine.



Information

Information regarding emergency operation see ("**Troubleshooting - Emergency operation SP 1800 / 2800**") on page 163).

3.9.4 Close maintenance flaps



Caution!

Hearing can be damaged!

Personal hearing protection must always be worn when a sound pressure level of 80 dB(A) is exceeded.

Failure to observe this may be harmful to your health.

Close all hoods, covers etc. that are provided to insulate the noise!

(see “**Noise information**” on page 43).

Furthermore, the flaps must be closed, in order to protect the machine from clogging and complicate unauthorised access to the machine.



3.10 Working operation - Concrete pump SP 1800 / 2800

3.10.1 General

- Lightly spray the concrete filling hopper with mould oil from the outside before pumping for the first time. This facilitates subsequent cleaning.

Make sure that no oil enters the hopper (risk of changes to concrete).

Use only rubber-compatible media.

- Switch on the agitator and vibrator.
- Fill a lubrication mixture into the concrete filling hopper.

The lubrication mixture consists of two parts cement, one part sand, and one part water.

The amount is determined by the length and diameter of the pumping line.

If you have a short pumping line or are pumping ready-mix concrete, the lubrication mixture may consist solely of cement and water.

- Never switch on the concrete pump with an empty filling hopper. Dry running wears out the pumping piston and kidney seal faster. Fill water into the filling hopper for maintenance and cleaning work.
- Fill concrete into the filling hopper before the lubrication mixture has been completely pumped out.
- Never pump at full speed; instead, set the required pumping power after concrete starts to exit the end of the pumping line.



Caution!

Risk of accidents due to parts or material being ejected!

Intake air is compressed in the pumping line and escapes abruptly at the end of the line or through the hopper.

Persons in the danger zone may be injured through pulsating of the end hose and flying parts.

To avoid this, the hopper must be filled up to the agitator shaft with concrete so that no air is drawn in.

- In case of wait times, especially in hot weather, keep the concrete moving (agitate it) by pumping it back and forth from time to time.
- Spray off the machine occasionally with water during operation to prevent concrete from setting.

3.10.2 Operational readiness

- Release the EMERGENCY STOP button on the remote control and on the machine by turning it in the direction of the arrow.
- Configure the operating speed of the diesel engine.

3.10.3 Agitator

The agitator can only be switched on if any interlocked controls of any special equipment in the agitator control block upstream are in "Agitator" position. (See switching diagram)






Fig. 82 Control panel

- Start the agitator by pressing button (2) or (3) on the control station (**Fig. 82**).


The corresponding button lights up.

The correct direction of rotation of the agitator depends on the intended pumping direction of the concrete pump:




	<p>If you want the concrete pump to pump, the agitator must feed the concrete to the suction intake: P = pump</p>
	<p>If you want the concrete pump to suck, the agitator must feed the concrete away from the suction intake: R = reverse</p>

3.10.4 Vibrator (special equipment)

	<p>Turn on the concrete vibrator by pressing button (4) (Fig. 82) on the control station. The button lights up.</p>
--	--



3.10.5 Concrete pump

- Switch on the concrete pump using the remote control (**Fig. 83**).



bp1801

Fig. 83 Remote control

	Button (5): Concrete pump, pumping
	Button (3): Concrete pump, suction

The corresponding button lights up. The concrete pump starts up.

- Set the desired concrete pump delivery volume (stroke count) using the handwheel (4) (**Fig. 84**).
- Close the maintenance flaps, and move away from the machine (noise reducing material!), taking the remote control with you.




Fig. 84 Maintenance flaps on right in direction of travel

3.10.6 Switching off the concrete pump, agitator and special equipment

- Switch off the concrete pump by pressing the button (4) (**Fig. 83**).
- Switch off the agitator and concrete vibrator by pressing the corresponding illuminated buttons on the control station.
- Switch off any special equipment by turning the corresponding controls to the "Agitator" position.

3.10.7 Reconnecting the concrete pump

The machine can be adjusted for high concrete delivery volumes or for high concrete pressures, according to operating conditions.

The adjustment is made by changing the existing hydraulic hose coupling assignments:

Piston-side pressure (Fig. 85) + (Fig. 86)	High concrete pressure
Rod-side pressure (Fig. 87) + (Fig. 88)	High concrete delivery volume





Fig. 85 Piston-side pressure



bp1808

Fig. 86 Piston-side pressure on the machine





Fig. 87 Rod-side pressure



bp1809

Fig. 88 Rod-side pressure on the machine

see (“**Technical data for SP 1800 / 2800 CAT**” on page 29).

The machine configured for rod-side pressure as a factory standard.



Warning!

The concrete pump must only be reconfigured by qualified personnel.

- Work only on the unpressurised hydraulic system.
 - Switch off the motor and secure it against being switched back on.
-



Attention!

Ensure that the pumping line material is suitable for the potential concrete pressure!

- Collect any escaping hydraulic oil.
 - Check all disconnected parts and immediately replace any damaged parts.
 - Check the oil level and perform a test run.
 - Check for leaks and check the oil level after the test run.
-



3.11 Working operation - Auxiliary power units

The hydraulic pump for the agitator supplies various types of special equipment, if necessary, for example:

- Hydraulic outrigger
- Water system (water pump)
- Air system (compressor)
- Hydraulic control unit (e.g.: hydraulic shut-off assembly*)

Switching the corresponding directional valve accordingly ensures that either the agitator or the special equipment can be operated. See switching diagram.

The simultaneous operation of agitator and special equipment, as well as various special equipment, is not possible.



Caution!

Unintentional start-up!

After switching on the drive motor, the auxiliary pump (agitator pump) pumps oil immediately.

However, the agitator only starts after being switched over electrically using the corresponding buttons on the control station of the agitator control block.

Any special equipment can start though because the respective control valve is located in the oil flow in front of the agitator control block.

For this reason:

- Always switch off the agitator electrically prior to starting any special equipment.
- Switch off each piece of special equipment immediately after use using the hydraulic control element (default position: agitator).

This will prevent the aggregates from running unintentionally when starting the motor or switching functions. Unnecessary oil heating is prevented.


The following description only applies to SP 1800 / 2800 types

For equipment with a hydraulic outrigger, a ball valve selects between the outrigger and additional functions.

In the position: Outrigger, only it can be driven.

In the position: "Agitator", the oil flow is conducted to other control valves of the special equipment and agitator. See switching diagram.

"Outrigger"



"Agitator"

3.12 Working operation - Water system SP 1800 / 2800

The machine can be equipped with various water systems, e.g. 80/8 (special equipment).

80/8 means that the water pump provides theoretically 80l of water per minute against an 8 bar pressure.

3.12.1 Preparation

The hydraulically powered water pump is self-priming (3) (**Fig. 89**). We recommend setting up a water case with clean water next to the pump.

The water must be free of solids, as they cause rapid wear on the water pump.

Connect suitable hoses to the suction socket (4) and delivery connection (7) (**Fig. 89**).




Fig. 89 Compressor - Water pump

Caption (Fig. 89 Compressor - Water pump)	
Pos.	Description
1	Stopcock
2	Compressor
3	Water pump
4	Water delivery connection
5	Pressure relief valve
6	Water suction socket
7	Air delivery connection

3.12.2 Operation

- Start the drive motor and adjust the speed of the diesel engine to idle. Regulation is not possible with the electric version.
- Switch the upstream ball valve to the base position:




Fig. 90 Agitator

- Open the spraying nozzle of the water hose and hold the hose tightly.
- Switch on the water pump using the button (9) (**Fig. 91**).



- Regulate the water flow rate by adjusting the engine speed (only for diesel engine).



Caution!

Do not switch on water pump with increased engine speed. Hose can pulsate.

The pressure relief valve (5) (**Fig. 89**) is set at the factory and may only be adjusted by SCHWING's customer service.

If the water pump is used to clean the pumping line, see ("**Cleaning**" on page 169).




Fig. 91 Control panel

3.12.3 End of operation

Switch off the water pump by pressing the button (9) (**Fig. 91**) again.

3.12.4 Winter operation

If there is danger of frost, the water pump must be drained after each operation.

- Remove the suction and pressure hose and drain them.
- Switch on the water pump briefly to remove residual water.



Attention!

Dry run!

Water pump may not run dry.



3.13 Working operation - Air system SP 1800 / 2800

The machine can be equipped with a rotary compressor (2) (**Fig. 92**) (special equipment). Theoretically, the compressor provides 900 l of air per minute against a pressure of 10 bar.




Fig. 92 Compressor - Water pump

3.13.1 Preparation



Caution!

If the compressor is used to clean the pumping line, see (“Cleaning” on page 169).

Switch off hydraulic downstream aggregates prior to commissioning the compressor.

Otherwise, these aggregates would stop after switching on the compressor and re-start after switching off the compressor!

- Attach a suitable pressure hose to the junction (7) (**Fig. 92**).
- Connect the pressure hose, e.g. to the junction (1) of the pumping line cleaning nozzle (**Fig. 93**).
- Open the air drain cock (3) (**Fig. 93**) in order to prevent pressure peaks when switching on the compressor.




Fig. 93

3.13.2 Operation

- Start the drive motor and adjust the speed of the diesel engine to idle. Regulation is not possible with the electric version.
- Switch the upstream ball valve to the base position:




Fig. 94 Agitator

If the machine is equipped with a hydraulic outrigger.

- Switch on the compressor using the button (10) (Fig. 95).



- Set the operating speed of the diesel engine and regulate the air flow rate by opening and closing the air drain cock (7) (Fig. 92) in the pressure line.




Fig. 95 Control panel

3.13.3 End of operation

- Open the air drain cock in the pressure line.
- Switch off the compressor using the button (10) (**Fig. 95**).

3.13.4 Winter operation

The rotary compressor can be used at temperatures of up to $-15\text{ }^{\circ}\text{C}$, with proper maintenance (**chap. 4.17**).

For lower temperatures, please contact us.



Attention!

Avoid corrosive damage!

The intake air of a compressor always contains, depending on the humidity, a certain amount of water.

This water is evaporated in the hot compressor depending on the system and discharged with the compressed air.

With the use (cleaning of the pumping line) typical for the concrete pump operation, the short duty cycle is often not sufficient to bring the compressor up to operating temperature.

Water can collect in the compressor (2) (**Fig. 92**) and cause damage.

For this reason, we recommend:

- Switching on the compressor once a week for at least 30 minutes continuously.
- Adhering to the maintenance intervals for the compressor.
- Only using original spare parts and the prescribed compressor oil when servicing your compressor.

Our maintenance packages:

10170389 (standard maintenance) and

10170388 (oil separator cartridge)

contain all of the spare parts needed to service your compressor, including the compressor oil.



3.14 Working operation - Hydraulic shut-off assembly (special equipment)

The machine can be provided with a control valve for a separate, hydraulically powered SCHWING shut-off assembly.

Hydraulically powered shut-off assemblies are required, for example, to prevent backflow from the concrete column to the concrete pump during up-pumping procedures.

3.14.1 Preparation

- Have a hydraulics technician connect the hydraulic junctions of the shut-off assembly to junctions A1 and B1 at machine position (6) (**Fig. 96**).

3.14.2 Operation

- Start the drive motor and adjust the rotational speed of the diesel engine to idle (adjusting is not possible for the electric version).
- Release the safety for the control lever and open or close the shut-off assembly using the control lever (5) (**Fig. 96**).
- Switch the control lever for the shut-off assembly to the centre position after use.




Fig. 96



Information

SCHWING provides the connection option for a shut-off assembly.

The operator is responsible for selecting and installing suitable material.


We recommend using the shut-off assembly (**Fig. 97**) and pumping line material from SCHWING.

When using unsuitable material, SCHWING is not liable for any damages!

We recommend DN 12 hydraulic hoses with up to a 15 m line length (for A and B lines) for the junction.

A separate aggregate and hoses with a larger diameter may be required for greater distances.

Please ask our customer service!



00048_Absperrschieber-V01

Fig. 97 Example of a shut-off assembly

3.15 Clearing blockages



Danger!

Danger to life due to suspended loads!

If interventions are required in the machine technology to release blockages, which go beyond the measures described below, these may only be carried out by qualified personnel.

The following must be observed in the process:

- Only work on unpressurised hydraulic systems. Although pressure relief valves help prevent the machine from overloading, the hydraulic system is under pressure when tripping the release of pressure.
 - Switch off the drive and secure it against being switched back on. Release the hydraulic system. This can be done, for example, by opening manual relief valves or also by repeated manual switching of the appropriate directional valve in both directions.
-

In contrast to a pressure test, an uncontrolled blockage of the machine occurring during operation is considered a serious incident.

If the energy stored during the blockage is suddenly released, it can cause serious accidents due to autonomous movements of the machine or the failure of components.

Even the use of inappropriate measures to clear such blockages can suddenly release the stored energy and cause serious accidents.



Danger!

Danger from uncontrolled movements!

Proceed as follows during an uncontrolled blockage:

- In case of danger, immediately press an EMERGENCY STOP button!
 - Remain calm!
 - Try to locate the blockage!
-

The following blockages are likely to occur:

3.15.1 Blockage in the pumping line

In the event of a clog (blockage) in the pumping line, the pressure in the concrete pump's hydraulic system will rise until the pressure relief valve (hereinafter: PRV) opens.

- The concrete pump stops,
- the drive motor works under high load,
- the hydraulic oil passing through the PRV produces a loud noise.



Information


A rapid pressure rise indicates a blockage directly behind the concrete pump.

The pressure rise is slower if a blockage is located at the end of the concrete pumping line.

The best way to prevent blockages is by keeping the pumping lines clean and free of leaks and by conveying standardised quality concrete, see ("**Technical preconditions for concreting**") on page 215).

- Remove the blockage by reverse pumping the concrete with the concrete pump.
- After that, cautiously start pumping again.
- If necessary, repeat the procedure until the blockage is removed.

If the blockage cannot be removed in this way, the pumping line must be relieved and the section affected must be dismantled.




Danger!
Danger to life due to pressurised pumping lines and blockages!


Concrete exiting at high pressure may seriously injure persons due to violent movements of the pumping line and also at a distance due to stones or fragments of the pumping line flying about.

Never try to loosen a blockage by using compressed air or pressure rise of the hydraulics. This presses in the blockage firmer and causes the pumping line to burst. Possible damage to the machine.

Never open a pumping line under pressure and do not tap it.

Relieve the pumping line by reverse pumping the concrete with the concrete pump.

Never work while directly bent over the line.



3.15.2 Mechanical blockage

Mechanical blockages may occur in all of the machine's systems, usually as a result of damage.

If there is no blockage as described above, try to locate the blockage as described below.

3.15.2.1 Blockages in the motor, gear, drive shaft

In most cases, blockages in the drive system cannot be cleared on site.

If necessary, the machine has to be placed into transport stand and towed.

To be able to put the placing boom into the transport position in the event of damage, we recommend keeping an emergency unit on hand.

3.15.2.2 Blockages in the control system

Blockages in the hydraulic pilot control system are often caused by dirt in the hydraulic oil.

This dirt causes the control piston to jam and in turn to not execute control commands or to execute them incorrectly.

A clogging of the oil is prevented through careful oil maintenance (filter change). Metallic abrasion in the oil points to damage.

Control blocks may also jam due to high temperature differences, for example, when feeding hot hydraulic oil to a cold control block in winter.

This can be avoided by heating the hydraulic system.

If control commands are not carried out properly.

- Immediately actuate an EMERGENCY STOP button.
- Use the emergency operation system to move the machine into the transport position, see (“**Clearing blockages**” on page 151).

3.16 Control of operations SP 1800/2800

Pressing an EMERGENCY-STOP button interrupts the main hydraulic functions, see (“**EMERGENCY-STOP system for SP 1800 / 2800**” on page 77).

- Pay attention to unusual noises, vibrations, etc. caused by the machine. There may be a damage that could be localised through timely repair.
- Check the stability and horizontal position of the machine and correct its position if necessary. All supporting dishes must be constantly, firmly on the ground.
- Ensure that there are no leaks in the pumping pipe connections. Fix leaks as quickly as possible. Bleeding the concrete results in clogging.

3.16.1 Control of operations for concrete pump



Caution!

Risk of accidents due to parts or material being ejected!

Intake air is compressed in the pumping line and escapes abruptly at the end of the line or through the hopper.

Persons in the danger zone may be injured through pulsating of the end hose and flying parts.

To avoid this, the hopper must be filled up to the agitator shaft with concrete so that no air is drawn in.

Otherwise, drawn-in air causes the concrete to spatter and dry running increases the wear on the pumping pistons and kidney seal.

- Check the hydraulic oil level. The oil level must be visible at the top of the level indicator (1) (**Fig. 98**) when the drive is not running.
- Check the hydraulic oil temperature (1) (**Fig. 99**) on the thermometer.
- If the temperature rises above 80 °C, the pumping speed must be reduced. Shut down the machine, top up oil or check cooling, if necessary.




Fig. 98




Fig. 99

- Monitor the water level and contamination in the water box (1) (Fig. 100). Drain any contaminated water using the drain valve (2) (Fig. 101) on the bottom and fill with clean water up to the top edge of the pumping pistons.




Fig. 100




Fig. 101



Warning!

Danger of crushing!

Before opening the water box, always switch off the drive motor and discharge the pressure accumulator (if available) in order to prevent the concrete pump from performing any unwanted working movements!

After filling up the box, mount the cover for the water box properly and secure it using a wedge and clip pin.

The water box must remain closed at all times during operation!


- Depending on the wear condition of the pumping pistons and cylinders, rinse the water box regularly. Check the water box weekly for deposits that could not be removed by the normal flushing process (see “**Cleaning**” on page 169).
- Check the operating pressure of the concrete pump while pumping concrete.



Information

The hydraulic pump of the concrete pump system is equipped with a pressure cut-off. This swivels the pump back before the maximum operating pressure set on the pressure relief valve (PRV) is reached, see (“**Pressure checks - stationary concrete pumps**” on page 261)..

- Open the shut-off valve (6) (**Fig. 102**) and release the operating pressure on the pressure gauge (1) (**Fig. 102**).

**Fig. 102**

If the operating pressure reaches the value configured for the pressure cut-off, pumping must be slowed down, a pumping line with a larger cross section must be laid, or the pumpability of the concrete must be improved.

For “ P_{max} ”, see the hydraulic switching diagram or data sheet.

The pressure relief valves set in the factory may not be altered.

Connect the concrete pump to piston-side pressure if more power is required (see “**Working operation - Concrete pump SP 1800 / 2800**” on page 131).

In order to protect the pressure gauge from spikes in pressure, close the shut-off valve (6) (**Fig. 102**) immediately after the test.

- Immediately prevent clogging at the base by pumping the concrete in reverse.
- Stop the agitator and concrete pump.
- Set the agitator to "reverse" and the concrete pump to "suction".

Do not forget to switch the agitator. The returning concrete could otherwise damage the agitator.

Should the clogging not be resolved with reverse pumping, switch off concrete pump and fix the problem.


- Monitor the agitator.

In the event of, for example, jamming caused by rocks (maximum pressure), switch agitator briefly to reverse running.

3.16.2 Switching damping

The machine is equipped with rock valve switching damping. It prevents a hard stop of the slewing cylinder in the end positions.

The switching damping is set at the factory and should only be changed for compelling reasons.



If hard, loud switching noises from the rock valve become apparent during operation, screwing in the adjustment spindle (4) (**Fig. 103**) can dampen the limit stop further.




Fig. 103

However, this results in a reduced stroke rate.

If the rock valve does not connect correctly, e.g. due to a rigid concrete consistency, reduce the damping by removing the spindle.

Set damping:

- Remove the protecting cap (3) (**Fig. 103**) above the adjustment spindle (4) (**Fig. 103**).
- Loosen the lock nut (2) (**Fig. 103**) on the adjustment spindle.
- Adjust the spindle. Remember and note rotations.
- Tighten lock nut and attach protecting cap.
- Reset the spindle to the starting position once the operating conditions have normalised.

3.16.3 Control of operations for diesel engine

- Check the fuel supply on the level indicator.

Open the right maintenance flap. The level indicator has been designed as a riser pipe and is located on the right next to the fuel prefilter (3) (**Fig. 104**).




Fig. 104

Top up fuel in due time.

Do not run on an empty fuel tank, as otherwise the fuel system will have to be vented.


See operating instructions for engine.



Warning!

Observe the safety regulations for handling fuel!

- Observe the warning lights on the control station (**Fig. 105**). They must not light up while the motor is running.


Fig. 105

In the event of certain failures (e.g. motor oil pressure too low), the motor must be shut down immediately in order to prevent serious motor damage.

In the event of other failures, it is possible to continue working at reduced power, if necessary (e.g. air filter dirty).



Information

Acquaint yourself early on with the operating instructions of the motor manufacturer so that you can respond appropriately in the event of an engine failure.



3.17 Troubleshooting - Emergency operation SP 1800 / 2800

3.17.1 Control failure

If a functional failure occurs, first check whether:

- An EMERGENCY-STOP button has been actuated.
- The grid assembly in the agitator hopper is raised.
- A fuse has been triggered.
- The magnets of the respective control valves are supplied with power.



Information

The plugs of the control valve magnets are equipped with light-emitting diodes for troubleshooting purposes, which should light up when connected to a power source.

3.17.2 Electrical fuse protection for the machine control system

Depending on the type of machine, the system can be secured in several places:

- A main safety fuse near the starter.
- Safety fuses in the switch cabinet or operator station of the concrete pump (**Fig. 106**).

Also see electrical circuit diagram.

Check fuses:

- Switch off the motor and remove the ignition key.
 - Open the top cover of the control station using the special key.
- Commercially available vehicle fuses are used.

Only insert newly equivalent fuses.



Attention!

Material damage caused by overrated fuses!

The electrical system is destroyed due to overrated and overridden fuses.




Fig. 106 Switch cabinet

- Close the cover of the control station and begin operating the machine.

If the error occurs again:

- Stop the machine and
- have an electrician inspect the system.

3.17.2.1 Main fuse

A 30A main fuse (1) (**Fig. 107**) / (**Fig. 108**) is located near the starter batteries on all machines with a diesel engine.

- Check this fuse when the entire electrical system has failed.

In addition to the main fuse (1) (**Fig. 107**) / (**Fig. 108**), a large 80A fuse (2) (**Fig. 108**) is located at the same position for the preheating system, provided the motor is equipped with such a system.




Fig. 107




Fig. 108

3.17.3 Bypass

In the event that the machine has to be operated during an emergency or test operation, a bypass plug has to be inserted into the power outlet (11) (**Fig. 106**).

Without this plug, no electrical power is available for the machine control unit and the EMERGENCY STOP valve remains open. The concrete pump cannot be operated.

The plug is included in the tool set of the machine.

3.17.4 Directional valve emergency actuation

A small control lever is available in the tool set for testing the concrete pump pilot control.

The control lever (1) (**Fig. 109**) may only be installed for testing purposes on the directional valve of the pilot control unit.




Fig. 109

In order to complicate an unintentional or unauthorised switching on of the concrete pump, the control lever must be disassembled immediately after completion of the test.

The control lever can switch the concrete pump into the "pump" or "suction" direction.

After releasing the control lever, it return to the centre position and the pump stops.

- Insert the bypass plug into the power outlet (11) (**Fig. 106**).
- Switch on the concrete pump with the control lever (1) (**Fig. 109**).



Warning!

Blocking the control lever is prohibited!

Wear your personal protective clothing, as well as hearing protection, during the control, and stay away from moving and hot machine parts.



3.17.5 EMERGENCY-STOP valve

The EMERGENCY STOP valve 1 (see hydraulic switching diagram or **(Fig. 110)**) is located at the front of the hydraulic oil reservoir and can be reached after removing the plastic cover.




Fig. 110

The valve is opened without current and, in open state, directs the pilot control oil of the pressure relief valve (PRV) of the concrete pump to the hydraulic oil box. The PRV opens and the concrete pump stops.

If the concrete pump stops unexpectedly, it is possible that the EMERGENCY STOP valve is open.

Check first if voltage is present at the valve. In this case, the light-emitting diode lights up in the plug of the magnet.

If this is not the case, perform troubleshooting on the electrical system.

If the diode lights up, the EMERGENCY STOP valve is defective and must be replaced.

In order to react quickly in the event of damage, we always recommend keeping an emergency unit ready.



3.18 Cleaning

After concreting, the pumping line and concrete pump must be cleaned thoroughly in order to prevent material damage.

- Finish the concrete feeding in good time so that the content of the hopper and pumping line can still be situated at the construction site.
- We recommend hosing down the equipment occasionally with a water hose during concrete breaks to prevent the concrete from setting.

3.18.1 Cleaning devices

Suitable devices can be ordered from SCHWING. For example:

- Compressor (**Fig. 111**).
- Water pump (1) and high-pressure cleaner (3) (**Fig. 112**).
- Cleaning head and trap basket (**Fig. 113**).



Attention!

Unsuitable material may cause damage!

Only use accessories in perfect condition approved by SCHWING for cleaning machine and pumping line.

SCHWING is not liable for damages caused by defective or unsuitable equipment and unsuitable cleaning methods and -means.




Fig. 111 Air compressor




Fig. 112 (Schematic diagram)




Fig. 113 Cleaning head and trap basket



Information

For information on the special equipment “High-pressure cleaning system”, please read the separate chapter.

3.18.2 Cleaning the pumping line

- After work, clean the pumping line first since this is where the concrete sets quicker.

The total quantity of concrete located in the pumping line is calculated as follows:

DN	50	=	2.0 l/m
DN	65	=	3.3 l/m
DN	75	=	4.4 l/m
DN	100	=	7.8 l/m
DN	112	=	9.8 l/m
DN	125	=	12.3 l/m

**Danger!****Danger caused by concrete under pressure!**

When opening pumping lines, sudden releases of pressure can cause severe injuries or even death.

Before opening the pumping line, the concrete column must be released by pumping backwards.

Various methods can be applied to clean a pumping line.

3.18.3 Reverse pumping concrete

Reverse pumping of concrete using a sponge rubber ball represents the normal cleaning of a placing boom pipeline:

- Produce a thin-consistency concrete and pump the pumping line full.
- Close the foldable covering for the hopper.

**Warning!****Risk of accident from badly secured cover!**

Secure the cover to prevent it from popping up due to overpressure in the filling hopper.

The safety device (**Fig. 114**) releases the overpressure through the lowered hopper rubber border in the back.

Ensure that the safety device is in sound operating condition and do not make any modifications!




Fig. 114 Cover for filling hopper

- Slowly pump hopper empty as far as possible.

- Position the placing boom as shown in **(Fig. 115)**.

A pumping pipe with a cleaning cover (2) **(Fig. 116)** is available as special equipment.

If the top cover is installed reversed, it retains the cleaning ball during reverse pumping.

- Switch agitator to reverse if the machine is not equipped with an automatic adjustment of the agitator rotational direction to pumping or suction operation.

Do not forget to switch. Machines with a VECTOR control switch automatically.

- First push the damp sponge rubber ball into the end hose **(Fig. 117)**, then switch the concrete pump to "Suction" (reverse running) with a lower stroke rate.



Attention!

Material damage to pumping lines and agitator

Failure to observe this information can cause deposits in the pumping line and subsequent clogging, as well as damage to the agitator.




Fig. 115 Cleaning position for placing boom (schematic diagram)




Fig. 116 Cleaning cover




Fig. 117 Sponge rubber ball

- Briefly tap on the pumping pipe with the handle of a hammer just in front of the cleaning aperture.

If there is still concrete in the line at this point, the tapping will produce a deep, dull sound (Fig. 118).

If the concrete and sponge rubber ball have passed the tapping point, the tapping will produce a high-pitched sound (Fig. 119).



Attention!

Damage to the pumping line!

Only use the handle of the hammer to tap the pumping line. Do not use metal objects:

- Dents cause rapid wear of the pumping pipe!
- The inner hardened layer of highly wear-resistant tubes can spall.

- Remove the top cover (2) (Fig. 120) and take out the cleaning ball.
- Reattach the top cover in "operating position".



Information

Bear in mind that the content of the pumping line can exceed the volume of the concrete filling hopper during back siphonage.

In such cases, it is necessary to interrupt the process and empty the filling hopper.




Fig. 118

Fig. 119




Fig. 120 Cleaning cover

It depends on several factors whether the concrete filling hopper can completely receive the flowing back concrete or how quick the hopper is full:

1. Volume of the filling hopper
2. Volume of the pumping line
3. Volume of the pumping cylinder
4. Degree of filling of the pumping cylinder



Example:

S 58 SX with pump kit 2525

at 1. = approx. 600 l

for 2. = approx. 850 l

for 3. = approx. 125 l (one cylinder)

for 4. = unknown

A theoretical degree of filling of the pumping cylinder of 100% would require approx. 7 strokes to empty the pumping line.

850 l/125 l = approx. 7 strokes

Which would cause the filling hopper to overflow.

In this case, we recommend interrupting the back-siphonage process after 4 strokes at the latest and emptying the hopper:

4x 125 l = 500 l

A certain degree of experience is helpful here.

The basic principles are:

The longer the pumping line, the sooner an overflow of the filling hopper during back siphonage can be anticipated.

The larger the volume of the pumping cylinder, the fewer strokes are required to empty the pumping line.

We recommend our chamber valve (**Fig. 121**) for cleaning the pumping line, especially for larger machines, see ("**Hydraulic shut-off assembly (98383777)**" on page 359).




Fig. 121 Chamber valve

3.18.4 Clearing the pumping line with water

This method is ideal for separately laid, long pipelines, vertical lines and lines with a downstream placing boom.

For stiff, rough, fine-grained or sand-poor concretes, this method can also be recommended for the boom pipeline of truck-mounted concrete pumps.

The following is required in addition to a powerful water pump (**Fig. 122**):

1. Cleaning head with water connection
2. Soft sponge rubber ball
3. Paper plug

The paper plug is made of soaked, double-folded, tightly rolled-up, empty cement bags.



Information

The plug must be completely sealed to prevent the concrete from leaching.

3.18.5 Rinsing the pumping line

Cement residues are removed from the tube walls by rinsing the emptied pumping line.

- To do this, press a soft sponge rubber ball about 1 m into the pumping pipe (**Fig. 123**).
- Mount the cleaning head, with a soft sponge rubber ball attached to it, onto the pipeline.
- Fill with water between both balls.
- Use the water cushion to press both balls through the line, like when blowing out with air, (see “**Blowing out the pumping line with compressed air**” on page 178). Raise the placing boom if necessary.



Attention!

Frost damage!

In case of danger of frost, remove water from the pumping line.




Fig. 122 Blowing out the pumping line




Fig. 123 Rinsing the pumping line

3.18.6 Blowing out the pumping line with compressed air



Warning!

Severe injuries due to compressed air

Severe injuries due to flying material.

Air can become compressed in pumping pipes and be discharged explosively, which can result in severe injuries.

Avoid excessive concentrations of compressed air in pumping pipes.

The following points must be observed when blowing out the pipeline with compressed air.

1. The blowing out must be carried out under expert guidance.
2. Elbows or hoses may not be mounted at the end of the pipeline.
3. No-one may remain in the area of the concrete output.
4. Empty and rinse tapered tubes manually. Only blow out pumping lines of the same nominal size.
5. A trap basket must be connected to the concrete outlet (**Fig. 124**).
6. Set the concrete output high so that the concrete can escape freely.
7. The cleaning head must be equipped with a functioning pressure gauge (2) and a large-dimensioned blow-out cock (3) (**Fig. 125**).
8. The length of the plug must be such that it seals the pipeline hermetically on the trap basket upon completion of the blowing out.
9. The plug must be sealed in order to prevent the compressed air from penetrating past it into the concrete.
10. Only work on unpressurised pipelines. Open blow-out cock (3) (**Fig. 125**). Concrete emerging under pressure can injure persons.
11. Individual tubes and short 10 m-long tube strings may not be blown out. High risk of accident caused by recoil due to low mass!

In addition to the prepared paper plug, as described above, a hard sponge rubber ball can be used to blow out tubes.




Fig. 124 Trap basket




Fig. 125 Cleaning head

3.18.7 Cleaning the concrete pump



Warning!

Make sure to observe the following points:

- Do not remove the cover grid from the concrete filling hopper or enter the grid.
- Do not reach into the machine while the drive motor is running or the pressure accumulator is charging, and do not hold objects in openings.

An end limit switch stops the concrete pump and the agitator if the grate in the concrete filling hopper is opened.

This is not an EMERGENCY STOP function!

The interrupted functions restart after closing the grid.



Danger!

Danger to life by electric shock!

- Do not direct water jets or the jet of a pressure cleaner towards the electrical components of the machine.

3.18.8 Securing the machine

- Remove the remote control cable.
- Connect the radio remote control transmitter.
- Use the local control.



Warning!

Severe injuries can be caused if the machine is left unattended!

If the machine has to be switched on for cleaning, the machinist is responsible that no unauthorised persons come near the open gate valve housing.

3.18.9 Interior cleaning

- Have a drip pan ready for residual concrete before beginning with the cleaning.
- Remove the tapered tube from the outlet on the stationary concrete pump or remove the outlet from the boom on the truck-mounted concrete pump by pivoting it to the side and securing it with the supplied wedge (2) (**Fig. 127**).
- Start up the concrete pump at the lowest stroke rate, in order to pump any residual concrete out of the hopper.

- Discard the residual concrete if you are no longer able to use it at the jobsite.
- Connect the water hose and hose out the filling hopper (**Fig. 126**). The concrete pump sucks in water and rinses out the pumping cylinders.
- Switch off the concrete pump and the vehicle engine.



Fig. 126 Cleaning the filling hopper




Fig. 127 Rotatable outlet

- Open the cleaning flap (**Fig. 128**) under the rock valve housing.
- Flush out the rock valve housing.
- Clean the agitator, gate valve housing, outlet, etc. using a strong water jet. Only hold the water jet and not the hose nozzle inside the opening of the gate valve housing (**Fig. 129**).

- Rinse the water box by switching on the concrete pump briefly with the lowest stroke rate with open drain valve.



Attention!

Material wear!

Switch off concrete pump immediately if water no longer comes out

- Hose out the water box with pressure water (**Fig. 130**). Do not remove the grid from the water box!
- Fill water box with fresh water.
- Check the water box weekly for deposits that could not be removed by normal flushing process. Increasing deposits may indicate wear on the pumping piston.



Warning!

Danger of crushing!

Always switch off the drive motor and relieve any existing pressure accumulators before opening the top covers on the water box.

Protective grids are only available in those water boxes whose top covers can be opened without tools!

After cleaning, mount protective grill and cover for water box properly.




Fig. 128 Open cleaning flap




Fig. 129 Clean concrete filling hopper



Fig. 130 Hose out water box

- Close and secure the cleaning flap on the rock valve (**Fig. 131**).
- Close the slewing lever on the cleaning flap by hitting it with a hammer in the axial direction.



Information

The hammer blows jam the flap in the wedge-shaped guides.
Vibrations can cause the flap to open.



Attention!

Material damage!

Never let rock valve machines run "dry".

The kidney seal faster can be damaged.





Fig. 131



A = close

B = open

C = secure

3.18.10 Exterior cleaning

- We recommend the occasional hosing down with a water hose during breaks to prevent the concrete setting.
- Lightly spray the outside of the concrete pump filling hopper with formwork oil.



Information

Only use environmentally-friendly oils.

Make sure that no oil enters the filling hopper.

3.18.11 Using high-pressure cleaners (HP cleaners)



Warning!

Poor preparation can cause accidents!

Observe the operating instructions of the high-pressure cleaner system, and wear the appropriate personal protective covering.



Information

New paints are only properly dry after approx. 3 months.

During this time, do not clean the machine with an HP cleaner.
This also applies to repainted sub-areas.

Newly painted surfaces may only be cleaned with a spray hose and cold water during the first 3 months. Use a soft brush, if necessary.

No HP cleaner should be used in areas with mechanical paint damage, because this can cause painted areas to separate even more.

Damaged painted surfaces should be repaired as soon as possible and in a professional manner.

During subsequent use of the HP cleaner, please observe:

- Maximum permissible water temperature 60 °C.
- Do not use additives.
- Maximum permissible water pressure 160 bar.
- Minimum permissible spraying distance 30 cm.



Attention!

Damages caused by strong water jet!

- If the HP cleaner used generates a higher water pressure, the spraying distance must be increased accordingly.

3.18.12 Using cleaning agents



Danger!

Fire hazard!

Do not use highly flammable agents.

- Do not use aggressive cleaning agents. They can corrode different materials (e.g. rubber) and painted surfaces.
- Commercially available paint cleaner and care products can be used, provided they do not exceed a pH value of 9 or fall below a pH value of 4.



Information

Ask the manufacturer of the cleaning agent to confirm its suitability.

Observe his directives on the application and health protection.

- Always rinse off the cleaning agents thoroughly with clean water. Do not leave puddles.

3.18.13 After cleaning

- Lubricate all lubrication points after cleaning.

We recommend spraying the dry machine with a wax-based preservative for protection against corrosion.

3.18.14 Water box flushing (special equipment)

Our truck-mounted concrete pumps can be equipped with a pressure flush valve for the water box as special equipment.

With this device, the usual manual cleaning of the water box is omitted to a large extent.

Four spraying nozzles in the top cover of the water box rinse the inside of the water box and piston rods of the differential cylinder.

Application:

- Open the drain cock (25) (**Fig. 132**) on the water box at the rear of the machine.
- Start the water pump and route pressurised water into the spraying nozzles (3) (**Fig. 133**) of the water box by switching the corresponding ball valves (11) (**Fig. 132**) at the rear of the machine and (2) (**Fig. 133**).
- Start the concrete pump at a lower stroke rate.



- End the cleaning process when clean water emerges from the drain cock.
- Close the drain cock and fill the water box with clean water.

This can also be done with the spraying nozzles or, as usual, through the drain hose.

Always rinse the water box immediately after each use of the concrete pump and visually inspect it once a week to make sure that it is clean.




Fig. 132 Rear of the machine




Fig. 133 Flushing the water box

3.19 Hazard prevention on the concrete filling hopper



Danger!

Danger of death due to exposed agitator!

Danger of death as a result of being crushed by or pulled into the agitator!

Disassembled or open hopper grates, as well as defective or manipulated end limit switches, can cause serious injuries and even death.

The following actions are prohibited on the agitator during operation:

- Reaching through the hopper grate.
 - Passing items (e.g. water hose, rod, etc.) through the hopper grate.
-

3.19.1 Hopper grate

The hopper grate in the concrete filling hopper is coupled to an end limit switch.

The end limit switch stops the rock valve and agitator when the hopper grate is opened.



Warning!

Risk of serious injury due to defective end limit switch!

If the agitator does not stop automatically when lifted, there is a risk of serious injury and even death.

The end limit switch has to be inspected daily and replaced in the event of a defect.

Arrangement and design of the hopper grate according to EN 12001.

Clean the concrete filling hopper with a strong water jet.

The water jet should be directed onto the area to be cleaned, do not pass the hose nozzle through the hopper grate.

Before removing any fixed concrete residues with the appropriate tools:

- Stop the machine.
- Switch off the drive motor and prevent it from starting up.
- Discharge the pressure accumulator, if applicable.

3.19.2 Cleaning flap and pipeline outlet



Fig. 134 Do not reach into the hopper



Fig. 135 Additional label for stationary concrete pumps

Secure the machine from being switched off before opening the cleaning flap under the rock valve housing or the elbow of the pipeline outlet of concrete pumps.

- Stop the machine.
- Switch off the drive motor and prevent it from starting up.
- Discharge the pressure accumulator - if present.

For older machines, the signs (**Fig. 134**) (**Fig. 135**) to the left and right of the agitator hopper and in its proximity may have to be updated.

Other signs can be ordered.

The adhesive areas must be clean and free of grease.

Make sure the signs are in good condition and replace damaged signs immediately.

3.20 Establishing transport readiness



Warning!

Checking safety components!

The operator has to carry out an expert inspection prior to each first commission, after any kind of changes to the support equipment and at least once a year according to manufacturer's instructions.

These inspections should be documented in a suitable form.

The operator should check the support equipment for damages and wear prior to each use. The connection and safety parts should be checked in particular for tightness and functionality.



Caution!

Danger of crushing!

When lowering the machine, ensure that no unauthorised persons are in the vicinity of the machine and no one will be crushed by the machine or machine parts.

Perform the following, general tasks:


- Clean the machine and switch off the concrete pump, auxiliary drive and drive motor.
- Disconnect the remote control cable from the machine.
- Mount the wheels, if necessary.
- Secure the machine using wheel wedges.
- Lay a suitable support pad (e.g. item no.: 1095646) under the supporting dish of the crank support (**Fig. 138**).

Proceed with the subsequent steps depending on the type of outrigger:

3.20.1 Mechanical outrigger SP 1800

- Lower the crank (3) (**Fig. 136**) by rotating the support dish.
- Lift the front of the machine slightly until the front supports (1) (**Fig. 137**) are unburdened.
- Insert the interior tubes of the front supports and secure them with socket pins and split pins.


- Unburden the rear supports (2) (**Fig. 137**) by lowering the front of the machine slightly with the crank.
- Insert the interior tubes of the rear supports and secure them with socket pins and split pins.
- Place the machine in a horizontal position with the crank support.



00109_SP-Stützwinde

Fig. 136 Support jack SP 1800

Caption of (Fig. 136)	
Pos.	Designation
1	Socket pin
2	Interior tube
3	Crank
4	Fuse
5	Exterior tube



00045_Abstützung_V01

Fig. 137 Example illustration

Caption of (Fig. 137)	
Pos.	Designation
1	Front outrigger
2	Rear outrigger
6	Crank support

3.20.2 Mechanical outrigger SP 3800

- Pull out the crank (3) (**Fig. 138**) and lower the supporting dish by rotating it.

 The crank can be pulled out in 2 steps.
 Step 1 = Overdrive
 Step 2 = Low gear
- Lift the front of the machine slightly until the front supports (1) (**Fig. 140**) are unburdened.
- Insert the interior tubes of the front supports and secure them with socket pins and split pins.
- Unburden the rear supports (2) (**Fig. 140**) by lowering the front of the machine slightly with the crank.
- Insert the interior tubes of the rear supports and secure them with socket pins and split pins.
- Place the machine in a horizontal position with the crank support.





Fig. 138 Crank support SP 3800

Caption of (Fig. 138)	
Pos.	Designation
1	Socket pin
2	Interior tube
3	Crank
6	Exterior tube



00045_Abstützung_V01


Fig. 139 Example illustration

Caption of (Fig. 139)	
Pos.	Designation
1	Front outrigger
2	Rear outrigger
6	Crank support

3.20.3 Semi-hydraulic outrigger SP 1800

(Special equipment)

- Lower the crank support (**Fig. 136**) until the supporting dish touches the ground.
- Switch the ball valve to the "Outrigger" position.



Information

The entire oil flow of the auxiliary pump is conducted to the outrigger, in the "Out-
rigger" position of the ball valve.

The auxiliary pump may not drive any other aggregates.

- Start the drive motor.
- Retract the front supports (1) (**Fig. 137**) using the control levers on the machine and secure them with socket pins and split pins.
- Shut off the drive motor.
- Unburden the rear supports (2) (**Fig. 137**) by lowering the front of the machine slightly with the crank.

- Retract the rear supports (2) using the control levers on the machine and secure them with socket pins and split pins.
- Place the machine in a horizontal position with the crank support.



Caution!

Danger of crushing!

When lowering the machine, ensure that no unauthorised persons are in the vicinity of the machine and no one will be crushed by the machine or machine parts.

- Have a qualified electrician disconnect the supply cable from the electric motor.
- Drain the operating materials, if necessary.
- Close and lock maintenance flaps.

3.20.4 Semi-hydraulic outrigger SP 3800

(Special equipment)

- Lower the crank support until the supporting dish touches the ground. For the semi-hydraulic outrigger, the oil flow from the agitator pump is directed into the control blocks of the outrigger.
- Start the drive motor.
- Switch on the agitator by means of the button (13) (**Fig. 140**).
- Retract the front supports (1) using the control levers on the machine and secure them with socket pins and split pins.
- Unburden the rear supports (2) by lowering the front of the machine slightly with the crank.
- Retract the rear supports (2) using the control levers on the machine and secure them with socket pins and split pins.
- Place the machine in a horizontal position with the crank support.
- Have a qualified electrician disconnect the supply cable from the electric motor.
- Drain the operating materials, if necessary.
- Close and lock maintenance flaps.



Fig. 140 SP 3800

3.20.5 Coupling SP 1800

**Caution!****Danger of crushing!**

No one may remain between concrete pump and towing vehicle during coupling.

- Set the height of the draw bar using the crank support and couple the machine to the towing vehicle.
- Slightly retract the interior tube of the crank support with the crank.
- Remove the socket pin and insert the interior tube of the crank support.
- Secure the interior tube with the socket pin and spit pins.

Remove the crank prior to driving operation.

3.20.6 Coupling SP 3800

**Caution!****Danger of crushing!**

No one may remain between concrete pump and towing vehicle during coupling.

- Set the height of the draw bar using the crank support and couple the machine to the towing vehicle.

The crank can be pulled out in 2 steps.

Step 1 = Overdrive

Step 2 = Low gear

- Slightly retract the interior tube of the crank support with the crank.
- Remove the socket pin and insert the interior tube of the crank support.
- Secure the interior tube with the socket pin and spit pins.
- Remove the crank prior to driving operation.

3.20.7 Crane loading

- Use suitable slings and only attach them to the lifting eyes on the machine!



Danger!

Falling loads!

Do NOT exceed the load capacity of the lifting eyes with additional weight from accessories and remnants of pumping medium!




Determine weight of loads prior to raising.




Danger!

Chain lengths that are too short lead to serious strain on the straight frame!

When transporting the machine with chain slings, the individual chain lengths must be a minimum of 2.5 m!

 GEFAHR / DANGER	
	<p> DE: NICHT unter schwebende Last treten!</p> <p>EN: Do NOT stand under suspended loads</p>
VDMA 24120	98380267

INFORMATION	
	<p>DE: Zum transportieren mit Hebezeug unbedingt nur die Verladeösen benutzen!</p> <p>EN: For handling with lifting gear use ONLY the lifting eyelets provided.</p>
	98363823

3.21 Difficult operating conditions

Heat, cold, dust, dirt, high humidity, sea water, continuous operation, etc. complicate the working conditions of your SCHWING machine.

Under certain circumstances, these working conditions exceed the "limits of the machine". Refer to chapter (2.4).

Our machines can be used by default at ambient temperatures of $-15\text{ }^{\circ}\text{C}$ to $+30\text{ }^{\circ}\text{C}$ when operating materials are used according to our recommendations.



Attention!

Placing booms may not be used at ambient temperatures below $-15\text{ }^{\circ}\text{C}$ (Fig. 141)!

There is a danger that it may cause brittle fractures to steel components. In addition, extreme cold can destroy rubber- and plastic parts.




Fig. 141

In case of frost, danger of frost, and in extreme heat, special measures are required, as summarised in the following chapters:

- (3.21.1 Low ambient temperatures (up to $-15\text{ }^{\circ}\text{C}$))
- (3.21.2 High ambient temperatures)

3.21.1 Low ambient temperatures (up to -15 °C)

3.21.1.1 General

- Move the machine into an enclosed building overnight, if possible.

3.21.1.2 Vehicle motor and integrated motor

Observe the manufacturer's operating instructions. Experience has shown that at least the following measures are required:

- Change oil and filter, unless a suitable multi-purpose oil is being used
- Check frost protection
- Adapt frost protector for air system
- Refuel with winter diesel fuel
- Ensure that the electrical system is in good condition, see **(3.21.1.9)**.

3.21.1.3 Water system



Attention!

Danger of ice and frost damage!!

Overflowing water freezes and can cause serious material damage.

Do not switch on frozen aggregates (e.g. water pump).

Do not heat with a flame or pour hot liquid over them.

Defrost machine fluids in an enclosed building.

- Fill the water into the water box and water case immediately before the first assignment.

A layer of ice must not form on the inside walls of the water box and pumping cylinders! Seals and pumping pistons will be destroyed.

Possibly fill with warmed (not hot!) water.

The water in the water box does not freeze as long as it is moving and all aggregates produce sufficient heat.

It is possible to add antifreeze to the water in the water case of the truck-mounted concrete pump.



Information

Water offset with antifreeze may not come into contact with concrete!

- After the assignment, drain the entire water system (water pipes and pump, water box, water case). Switch on the concrete pump briefly to remove the water from the pumping cylinders.

3.21.1.4 Hydraulic system

SCHWING recommends appropriate hydraulic fluids for different climates and applications, see (“**Recommended lubricants and fuels**” on page 227).

The multi-purpose hydraulic oil filled in at the Herne factory can remain in the system, as long as the starting temperature does not drop below -10 °C.

Should work be performed at temperatures ranging between -10 °C and -15 °C, switching over to winter oil (VG 32) is required.

Otherwise, the great oil viscosity can cause a risk of damage during a cold start. The hydraulic pumps suck in air (oil foams) and will be damaged.

When changing the oil, also replace the filters.

Make sure that the optimum operating viscosity (16 to 36 mm²/s) is also at an oil temperature between approx. 35 and 65 °C for hydraulic oil with viscosity class* VG 32.



Information

The system may only be fully loaded in the area of the optimum operating viscosity.

However, the highest permissible temperature for VG 32 is below that of VG 46 or VG 68.

See diagram in (Table 1 Comparison of viscosity classes).

- a) Cold-start limit in °C
- b) Oil temperature in °C
- c) Viscosity in mm²/s
- d) Operating temperature and viscosity

* Viscosity = Resistance to flow

Viscosity-temperature diagram:




Fig. 142 Viscosity-temperature diagram

Concessions must also be made for various winter oils regarding the pressure load and wear protection.

Please ask your supplier about the measures required when using its oil.

We recommend using a hydraulic oil from the same supplier and same series, as was the case for "summer operation". In these cases, lower quality losses are generally to be expected. However, residual oil in the system causes the viscosity range to shift.

Should series or manufacturer be changed, flushing with the new type of oil is required. Thereby switching all valves several times. Fully extend and retract all cylinders.

At temperatures below freezing point, there is the possibility to warm the hydraulic oil using the sturdier gear pump of the agitator circuit.

- To do this, close the ball valve (1) (**Fig. 143**) on the agitator motor.

The hydraulic oil is then routed to the tank via the pressure relief valve and thereby warms up faster.

The temperature of the hydraulic oil (optimal operating viscosity) can be found in the VECTOR control system.

If the optimum hydraulic oil temperature has been reached according to diagram (**Fig. 142**), reopen the ball valve.




Fig. 143

3.21.1.5 Air system

Due to their construction, piston compressors may not be started up at ambient temperatures below +1 °C (risk of damage caused by frozen condensate).

Rotation compressors can be used at up to -15 °C, with appropriate maintenance.

Since the vehicle air system supplies the electro-pneumatic pilot control for some truck-mounted concrete pumps, it is also important to set the vehicle air system to winter operation.

Vehicle air systems are equipped with air dryers or frost guards to prevent condensation water or to keep water from freezing.

3.21.1.6 Gear

A gear oil change is only required at continuous temperatures below -10 °C.

It is also possible to use a multi-purpose oil.

Should such oil not be available, use an oil with a viscosity level "thinner" than the recommended gear oil (see gear type plate).

VG 150 instead of VG 220 (industrial gear oil) or

SAE 80 instead of SAE 90 (vehicle gear oil)



3.21.1.7 Comparison of viscosity classes

Industry standard	Vehicle standard		
e.g. hydraulic oil	Motor oil	Gear oil	
ISO-VG	SAE	SAE	
22	5W		"thin"
32	10W	75	
46	15W		
68	20W / 20		
100	30	80	
150	40		
220	50	90	
320			
460		140	
680		140	
1000		250	

Table 1 Comparison of viscosity classes

3.21.1.8 Grease lubrication points

The KP2K lubricating greases listed in (chap. 4.3) are suitable for temperatures up to - 20 °C.

3.21.1.9 Electrical system

The initial capacity of the batteries depends on the charging status and ambient temperature.

- Always ensure the batteries are well charged. Remove batteries when machine is not used.
- Store batteries in a warm and dry place, recharge, if necessary.
- Ensure good contact of the terminal connections.
- Check the V-belt tension and charging status of the generator.

3.21.1.10 Radio remote control

The radio control can be used at up to -20 °C.

Please heat the driver's cab or use a separate charger, if possible, at a room temperature of +20 °C.



Information

Charging the battery becomes problematic at temperatures below +10 °C.

3.21.1.11 Setting up the machine

Frost, thaw, rain, etc. can significantly change the load-bearing capacity of the ground.

- Before starting to work, check the ground conditions and monitor them during operation.

3.21.1.12 Cold start

- Move the machine into an enclosed building overnight, if possible.
- After a cold start, operate the hydraulic system without a load at a low speed for several minutes.

This will heat up the aggregates and oil, building up a stable lubricating film.

- Extend the connection pieces at a low pump speed.
- Raise the placing boom at a low pump speed and run through all boom cylinders.
- Run the concrete pump with a reduced stroke count until the hydraulic system reaches the operating temperature.

3.21.1.13 Pump operation

In general, heated concrete is used at ambient temperatures below freezing. Expect short setting times.

In order to prevent "bleeding", the heated concrete must be mixed thoroughly.

- Keep pumping breaks as short as possible.
- Clean the pumping line and concrete pump immediately after pumping.
- Be sure to remove residual water immediately and completely after cleaning.

3.21.1.14 Decommissioning

- Clean the machine after the work assignment.
- Clean steps, platforms, etc. from ice and dirt.
- Position the machine on firm, dry ground.
- Secure the machine properly from rolling away.
- Only release the parking brake (can freeze) if the machine can be otherwise secured effectively from rolling away.

3.21.2 High ambient temperatures



Attention!

Material damage due to overflowing fluids!

Overflowing fluids can cause serious material damage and even fires.

Always make sure that containers are filled according to regulations and keep the containers closed.

3.21.2.1 General information

In principle, it is useful to keep an eye on the temperatures of the pumping line, individual aggregates and fluids at high ambient temperatures.

If possible, set up the machine so that it is protected from direct sunlight.

Machine and pumping line should be painted brightly.

Relocate separate pumping lines preferably in the shade, cover, if necessary.

Please note, the VECTOR control system in our truck-mounted concrete pumps monitors the hydraulic oil temperature and reduces the power of the concrete pump starting at approx. +85 °C. The concrete pump switches off at +95 °C.

Furthermore, the temperatures of the motor coolant and compressors can also be monitored.

This monitoring can also be combined with a switch off function.

It is, therefore, useful to ensure optimum cooling:

- Fill all the oils and the coolant up to the max. mark.
- Prevent fluids from overflowing. This can damage the machine.
- Keep the blades of the motor radiator and hydraulic cooler clean.
- Clean more often with high dust accumulation.
- Replace the insert of the motor air filter, if necessary.
- Do not open the maintenance flaps in order to augment the cooling effect. This could interfere with the air circulation and have the opposite effect.

- Ensure that the hydraulic system is configured correctly. For example, a pressure relief valve that is set too low will cause the oil temperature to increase because oil is continuously discharged under high pressure through a small cross section.
- Replace the water in the water box with fresh water if it becomes too warm.
- Sprinkle the differential cylinders of the concrete pump with a water hose.



Attention!

Do not use water to cool down hydraulic oil box!

Cooling down the box causes heavy water condensation inside the box.

Condensate water in the hydraulic oil can cause material damage to the hydraulic system.

- Do not pump with maximum stroke rate.
High stroke rates increase the temperature of the hydraulic system and are extremely pointless for stiff concrete, as they are then sucked in poorly.
- Prevent air from being sucked in. Air in the pumping pipes can cause the boom to move and the end hose to flail about! Always make sure that the agitator shaft is in the concrete so that no air can be sucked in.
- Run the system in idle during pumping breaks.
This will continue pumping the hydraulic oil through the radiator, and the motor oil transporting the heat away from the hot turbo charger.

3.21.2.2 Vehicle motor and integrated motor

Observe the manufacturer's operating instructions. Experience has shown that at least the following measures are required:

- Change oil and filter, unless a suitable multi-purpose oil is being used.
- Adapt frost protector for air system.

3.21.2.3 Water system

- Also make sure that the water case is well filled because water may be required to cool the concrete pump.



3.21.2.4 Hydraulic system

The multi-purpose hydraulic oil filled in at the Herne plant covers the viscosity class VG 46 and the viscosity class VG 68, intended for tropical applications, see (“**Recommended lubricants and fuels**” on page 227).

If a single-purpose oil VG 46 is used, the oil must be changed to VG 68. When changing the oil, also exchange the filters.

Should these oils be insufficient despite having configured the hydraulic system properly and despite optimum cooling, see (**chap. 3.21.2.1**), please contact us.

Please note that a "thicker" hydraulic oil with viscosity class VG 100 has a cold-start limit of +3 °C, and the optimum operating viscosity is significantly higher.

This can cause difficulties in areas with highly variable temperatures (night/day), see (Fig. 142 Viscosity-temperature diagram).

3.21.2.5 Air system

Use a compressor oil for the reciprocating compressor of viscosity class VG 150.

The synthetic oil prescribed for our rotation compressors is suitable for temperatures up to +40 °C.

This is sufficient for the normal concrete pump application (no continuous operation).

Should the VECTOR control cause the machine to shutdown nevertheless due to overheating, please contact us.

3.21.2.6 Gear

The gear oils recommended in (**chap. 4.3**) are suitable for continuous ambient temperatures of approx. -10 °C to approx. +40 °C.



Information

A gear oil change is only required at continuous temperatures below +40 °C.

It is also possible to use a multi-purpose oil.

If such an oil is not available, please use an oil with a higher viscosity level than the recommended gear oil (see gear type plate), i.e. VG 320 instead of VG 220 (industrial gear oil) or SAE 140 instead of SAE 90 (vehicle gear oil), see (Table 1 Comparison of viscosity classes).

3.21.2.7 Grease lubrication points

The KP2K lubricating greases listed in (**chap. 4.3**) are suitable for temperatures of -20° to +140 °C.

3.21.2.8 Electrical system

Check the acid level of the battery cells more frequently at high ambient temperatures.

Only refill with distilled water!

3.21.2.9 Radio remote control

The radio control can be used at up to +60 °C.

3.21.2.10 Setting up the machine

The load-bearing capacity of heat-sensitive subsoils, such as asphalt, decreases as the ambient temperature rises.

- Make sure the ground is firm.

3.21.2.11 Cold start

Make sure in particular to start the system gently when the machine is equipped with special lubrications for high temperatures.

Lubricants of high viscosity (viscous) only reach their maximum optimum operating viscosity later on.

The hydraulic pumps can be damaged, as described under in (**chap. 3.21.1.12**).



3.21.2.12 Pump operation

The concrete is frequently prepared in hot areas with cooled aggregates or cooled water.

The placement of the concrete should take place preferably during cooler periods of the time, such as in the morning or evening.

- Rinse a heated pumping line with water before pumping.
- Use a somewhat mushier start-up mixture for long lines.
- Make sure that the concrete can be pumped easily.
- Avoid extended breaks.

Cover the concrete in the filling hopper of the concrete pump with wet bags, for example.

- Start cleaning immediately after pumping.

3.21.2.13 Decommissioning

- Let the machine idle for some minutes with the pump drive active.

This way, the turbo charger transports the heat away from the diesel engine and cools the hydraulic oil by continuing to pump it through the radiator.

3.22 Decommissioning

If the machine is to be decommissioned for an extended period of time, please observe the following list.

3.22.1 Tasks prior to decommissioning

1. Clean and lubricate the machine thoroughly.
2. Check the concentration of antifreeze for liquid-cooled motors and top up if necessary.
3. Drain condensation water from fuel, hydraulic and air system reservoirs.
4. Fill fuel tank and oil box to the brim.
If the oil is in poor condition, change it.
5. Fill all gearboxes with the prescribed amount of oil.
If the oil is in poor condition, change it.
6. Apply acid-free grease to bare machine parts or spray them with preserving oil.
7. Preserve concrete pumping pipes by pushing a cotton waste plug soaked in preserving oil through the pumping line.
8. Retract all hydraulic cylinders.
9. Set all control elements to position 0.
10. Relieve pressure accumulators.
11. Preserve the motor as described in the motor's operating instructions.
12. Drain water from the reservoir, water box and water pump.
13. Spray water box with a rust-protective agent.
14. Close all openings and waterproof.
15. Jack up the vehicle in order to let down the tyres.
16. Check tyre air pressure.
17. Release parking brake.
18. Remove starter batteries (lead-acid batteries) and store in a cool (5-15 °C), clean and dry location.
19. Permanently connect batteries to a charger with trickle charging, or charge at monthly intervals (no quick charging). Then check the fluid level.



Attention!

Never allow batteries to remain discharged!

Deep discharge will destroy them!

Frost can cause the housing of discharged batteries to rupture due to freezing of the contents!

In order to prevent premature ageing, up to destruction, the above instructions must be observed!

Observe further instructions in chapter 4.60, in addition to the operating instructions from the motor or chassis manufacturer.

3.22.2 Recommissioning

1. Remove preservation.
2. Check all oil levels.
3. Empty hydraulic oil box to inspection glass level, when full to the brim.
4. Check and install batteries.
5. Check tyre air pressure.
6. Completely lubricate machine.
7. Carry out functional testing.



Information

For storage of the machine under difficult conditions, special regulations apply.

Difficult conditions include, for example:

- Storage periods of over 6 months.
- High air humidity.
- Sea air, etc.

Contact SCHWING customer service.



3.23 Technical preconditions for concreting



Information

Pumped concrete is not a special concrete, but a standardised quality concrete.

3.23.1 Properties of pumped concrete

- A minimum fine grain content of approx. 400 kg per m³ (with a maximum grain size of 32 mm).
- A minimum cement content of approx. 240 kg per m³ (with a maximum grain size of 32 mm).
- Water/Cement ratio of 0.42 w/c - 0.65 w/c.
- Grain composition according to grading curve.
- Consistency of K 2 to K 3.

3.23.2 Errors that inhibit pumping

- Incorrect concrete composition (see above).
- Poor upkeep of the machine and pumping line (cleaning!).
- Inadequate mixing quality.
- Separation caused by improper transport.
- Incorrect maximum grain size selected based on diameter of pumping line.
- "Bleeding" of fresh concrete.
- Incorrect use of admixtures.



4 Maintenance

This chapter contains maintenance instructions for concrete pumps.

Further measures should be carried out by SCHWING's customer service department or by trained and qualified personnel. Otherwise, the warranty and liability shall become void for this machine.



4.1 General maintenance instructions

Carry out the maintenance on time and with care.

We recommend copying the maintenance schedule (**chap. 4.6**).

The maintenance personnel can then acknowledge the work carried out on the copies.

Schwing expressly prohibits any maintenance work carried out by personnel who are not specially trained and authorised.



Danger!

Severe to fatal accidents and serious material damage can be caused by unqualified personnel!

Should you not have trained personnel and appropriate workshop equipment, commission the SCHWING customer service to service your machine.

4.1.1 Maintenance work on special equipment

Maintenance work on special equipment is described in chapter “**Special equipment**” on page 357.

4.1.2 Cleanliness

- Clean all units located within the work area before starting to work.



Attention!

Material damage caused by high-pressure cleaner!

The use of high-pressure cleaners can damaged sensitive parts!

Do not use a steam jet to clean rubber and electrical parts.

- As a rule, prevent dirt from entering - especially in the hydraulic system.
- Lubricate your entire machine after a high-pressure cleaning.

4.1.3 Corrosion protection

Heavy rust weakens the material and may cause fractures and cracks.

- Repair damaged painted surfaces within due time and grease bare machine parts.

4.1.4 Checking the oil level

In general, take the following points into account when checking the oil:

- Make sure that the machine is level
- Switch off the drive approx. 10 min. before performing an oil check
- Move mobile machines into the transport position and brace them (outrigger in transport position).

4.1.5 Oil change

- Drain the oil while it is still at operating temperature in order to flush out contaminants better.



Caution!

Risk of injury caused by hydraulic oil!

Hydraulic fluid can cause irritation to the skin and eyes!

Always wear suitable protective clothing.

-
- Always fill hydraulic fluid from clean vessels through the filling hole on the tank provided for the purpose.
 - If possible, use flushing or filtration units to add the new oil.



Caution!

Danger caused by pressure rise in the oil box!

Do not fill reservoir with pressure! Make sure that the displaced air can easily escape from the reservoir.

Hang the filling hose loosely in the oil box. Never screw in the filling hose so that it is airtight!

-
- Always prevent containers from overflowing.
 - Check the oil level after each test run.
 - Do not store hydraulic oil barrels outdoors.



- Do not store hydraulic oil barrels horizontally.
- Prior to removal, the barrel must remain stationary for an extended period of time.
Contaminants can deposit easily.
- Never roll hydraulic oil barrels to the filling site.
- Make sure not to insert the suction hose too deep into the hydraulic oil barrel in order to avoid sucking in contaminants from the barrel floor.



Information

Before each oil change, we recommend taking an oil sample and examining it for discolouration and solid materials (suspended particles).

This makes it possible to determine early on whether preventive maintenance measures need to be initiated.

4.1.6 Draining condensation water

Humidity and fluctuating temperatures form condensation in hydraulic oil boxes, which mixes with the oil.

As the ratio of water increases, the lubricating power of the mixture decreases rapidly.

Solution:

After several days of not using the machine, the water separates from the oil and collects at the bottom of the box.

By opening the drain screw on the hydraulic oil box, you can then drain the water from the bottom of the box.



Information

Best downtime!

The hydraulic oil used at SCHWING requires a downtime period of at least 2 days in order to achieve good results.

4.1.7 Seals and fuse elements

- Make sure that no seals, spring washers, etc. are lost when removing top covers, closing screw plugs, and the like.
- Before closing them again, clean the sealing surfaces of the screws and covers, etc. and make sure not to damage them.
- Replace the seals, split pins, spring washers, etc. immediately if they are worn or damaged.

4.1.8 Lubrication

- Clean grease nipples before and after lubrication.
- Remove any excess grease from the lubrication points.

4.1.9 Leaks

- Check all containers, hoses, screw connections, etc. regularly for leaks.



Attention!

Environmental damage caused by flowing out oil!

Check the system for oil leaks and eliminate their causes.



Warning!

Risk of serious injury due to leaks in lines and tubes!

Bursting lines or operating material emerging under pressure can cause serious injuries.

- Immediately replace any damaged tubes and damaged or moist hydraulic hoses.

4.1.10 Repairs, exchange



Information

It may be less expensive to exchange complete units instead of repairing them. Contact SCHWING's customer service for an individual consultation.

- Only use original SCHWING spare parts for repairs or replacements. SCHWING will not be held liable for damage caused by use of third-party products or improper equipment.
- Only use mineral oil-based greases for installation work on the hydraulic system.
- If a unit (pump motor, etc.) fails, flush out the entire hydraulic system and replace the filters in order to prevent consequential damages caused by metallic dust.



Contact SCHWING's customer service for non-binding informational material on available flushing / filtration units (**Fig. 144**).



Fig. 144 Available flushing / filtration units

- After such procedures, always perform a test run with the machine and then check the oil level afterwards.
During the test run, watch for unusual sounds, temperatures and leaks.
- Perform maintenance work on repaired or exchanged units as per usual.

4.1.11 Welding

Welding work may only be carried out by trained professionals according to manufacturer regulations (see ("**Repair welding**" on page 351).

4.1.12 Mechanical processes

Cover devices, cables etc. when drilling or grinding work etc. is to be carried out on the machine.

4.1.13 Painting and working with aggressive substances

Cover devices, cables etc. to protect them against paint mist and aggressive substances.

4.1.14 High-pressure cleaning

Cover any electrical and electronic components.

Never direct a water or steam jet to these components.

Any penetrating moisture leads to malfunctions and can destroy electronics and electrical components completely.

4.1.15 Electrically powered machines

- Have an electrician disconnect the power supply to such machines prior to carrying out repair work on the respective machine.



Danger!

Danger to life by electric shock!

Working on systems still connected to a power source poses an acute danger to life from electric shock!

Always turn off all main switches and secure them against being turned back on without authorisation.

Repairs on electrical systems may only be performed by electricians!

4.2 Consumable volumes (in litres)

4.3 Recommended lubricants and fuels

**Danger!****Oil under pressure is very dangerous!**

The following points must be observed:

- Only qualified personnel may work on hydraulic systems.
- Personal protective equipment must be worn during work (safety glasses, suitable gloves and clothing).
- Work only on unpressurised systems. The entrapped oil can also be under pressure when the drive is at standstill and pressure accumulator is unpressurised.
- If, for example, systems under pressure need to be opened when venting, mount a breather line first while the system is depressurised or use the existing mini-measurement connection.
- If this is not possible due to a lack of space, for example, make sure that nobody can be hit by escaping oil.
- Open the breather screw very carefully until oil emerges. By no means open further or remove the junction.

**Danger!****Danger caused by oil jet!**

Hydraulic oil escaping under pressure can penetrate the skin and cause severe tissue damage.

This represents an acute medical emergency.

Immediately consult a doctor!

Even with a minor injury caused by an oil jet, insist on immediate medical help!

4.3.1 Behaviour in case of injuries

Immediately seek a doctor familiar with such injuries.

Seek a doctor even if the wound seems harmless.

Hydraulic fluid sprayed under the skin must be removed immediately. This could result in serious circulatory disorders and tissue damage (gangrene).

These could require significant surgical procedures.

Penetration of bacteria could also accelerate tissue destruction.

The bacteria entering the bloodstream causes danger to life.

On the following pages you will find a limited number of suitable lubricants and equipment. If these products are not available, other materials can be used in accordance with the specified standard marks. Selection and sequence of the products listed do not include qualitative assessment.

4.3.2 Explanation of the abbreviations used

4.3.2.1 General

BI	= Central Federation of the German Construction Industry. As an alternative to the lubricants and fuel recommended, the normal lubricants specified in column "BI" can be used.
DIN	= German National Standard.
ISO	= International Organisation for Standardisation.
MIL-L	= American Military Standard for Lubricants.
API	= American Institute for Lubricants.
SAE	= Merger of American Automotive Engineers.
VL	= Viscosity grade in mm ² /s at 40 °C.

4.3.2.2 Hydraulic oil

API-CD	= Motor oil for heavy-duty diesel engines with and without supercharging.
EO	= BI normal lubricant, a quality motor oil.
HLP	= A hydraulic oil according to DIN 51524 with agents designed to improve anti-corrosion, durability and wear protection within the mixed friction range.
HVLP	= A hydraulic oil according to DIN 51524 with low viscosity temperature dependence, otherwise HLP.



4.3.2.3 Industrial gear oil

CLP	= A circulating lubricating oil according to DIN 51517 with agents designed to improve anti-corrosion, durability and wear protection in the mixed friction range, and to increase the gear capacity.
PG	= Synthetic lubricating oil for extreme load on polyglycol base suitable as long-term lubricant.
PAO	= Synthetic gear oil with excellent high-pressure properties and excellent temperature behaviour based on poly alpha olefin.

4.3.2.4 Vehicle gear oil

GO 90	= BI standard lubricant, a gear oil according to API-GL 5.
MIL-L 2105 B	= Hypoid gear oil for severe stress in gears and axles, roughly corresponds to API-GL 5.

4.3.2.5 Compressor oil

VDL	= Mineral oil for air compressor with agents designed to improve anti-corrosion and durability. Carbon residue after ageing max. 3 % according to DIN 51352.
Rotor oil 8000 F2	= Synthetic, all-season oil for rotary compressors.

4.3.2.6 Lubricating grease

KP 2 K	= A lubricating grease according to DIN 51502 for high pressure stress in the service temperature range of -20 °C to +140 °C, worked penetration 265 to 295, no changes or minor changes caused by water.
MPG-A	= BI standard lubricant, a lubricating grease according to KP2N, covering KP2K and K2K.
MLE2N-40	= Special lubricant for material pairing: Plastic / metal for prolonged lubrication of the slider in the telescopic arms.
Art. no.: 10197297	= SCHWING drive line grease. Only use this grease to lubricate the SCHWING drive lines.

4.3.3 Recommended hydraulic oil

Viscosity (ISO):	VG 32		VG 46		VG 68	
Type (DIN):	HLP	HVLP	HLP	HVLP	HLP	HVLP
BP Energol	HM 32		HM 46		HM 68	
Fuchs Renolin		B 32 HVI		B 46 HVI		B 68 HVI
Fuchs Renolin		Xtreme Temp 32		Xtreme Temp 46		
Klüber Lamora	HLP 32		HLP 46		HLP 68	
Liqui Moly				HVLP 46		
Mobil DTE	24		25		26	
Mobil Nuto	H 32		H 46		H 68	
Mobil Unavis		N 32		N 46		N 68
Q8 HVLP Hydraulic Oil				46		
Shell Tellus	S2 MX 32	S2 VX 32	S2 MX 46	S2 VX 46	S2 MX 68	S2 VX 68
SRS Wiolan	HS 32	HV 32	HS 46	HV 46 ¹	HS 68	HV 68

1. Standard filling SCHWING GmbH Herne

VG 32 = Winter operating conditions in Central Europe

VG 46 = Summer operating conditions in Central Europe

VG 68 = Rooms with high amounts of heat or tropics



Attention!

Material damage can be caused by the wrong oil quality!

Do not mix hydraulic oils from different manufacturers!

Using hydraulic oil from another manufacturer, or using an oil of a different quality, requires a complete oil and filter change.

Mixing the same oils with different viscosities is only permitted after consultation with SCHWING GmbH.

Only use oils that contain zinc.

4.3.4 Recommended gear oil (see gear type plate)

4.3.4.1 Industrial gear oil	
Viscosity according to ISO:	VG 220
Quality according to DIN:	CLP
ARAL	Degol BG 220/Degol BMB 220
BP	Energol GR-XP 220
KLÜBER	Klüberoil GEM 1-220
MOBIL	Mobilgear 600 XP 220
SHELL	Omala oil 220
SUNOCO	Sunep 1220
TEXACO	Meropa 220
WINTERSHALL	Wiolan IT 220
BI	/
4.3.4.2 Vehicle gear oil	
Viscosity according to SAE:	90 (85w-90)
Quality according to MIL-L:	2105 B
ARAL	Gear oil HYP
BP	Energear HYPO 90/Hypogear 90 EP
MOBIL	Mobilube HD-A 85w-90
SHELL	Spirax HD/Spirax MB 90
SUNOCO	GL-5
TEXACO	Geartex EP-C
WINTERSHALL	Wiolan Hypoid gear oil 90
BI	GO 90



Information

The gear oils described above are suited for continuous ambient temperatures of approx. -10 °C to approx. +40 °C.

For extreme operating conditions, please contact us. The viscosity class ISO VG 220 roughly corresponds to SAE 90.

4.3.4.3 Industrial gear oil (polyglycol base)	
Viscosity according to ISO:	VG 220
Quality according to DIN:	PG
ARAL	Degol GS 220
AVIA	Avilub VSG 220
BP	Energol SG - XP 220
ELF	Syntherma P 270
FUCHS	Renodiol PGP 220
MOBIL	Glygoyle 30
SHELL	Tivela WB
TEXACO	Synlube CLP 220
BI	/



Attention!

Material damage can be caused by the wrong oil quality!

The synthetic lubricating oils with a polyglycol base listed above must not be mixed with oils using another base.

4.3.4.4 Industrial gear oil (poly alpha olefin base)	
Viscosity according to ISO:	VG 220
Quality according to DIN:	PAO
ADDINOL	CKT 220
TOTAL	CARTER SH 220
BP	Enersyn HTX 220
AVIA	Syntogear PE 220
CASTROL	Alphasyn EP 220
MOBIL	Mobilgear SHC XMP 220
FUCHS	RENOLIN UNISYN CLP 220
FUNKE	Finkol PA 220

4.3.5 Recommended compressor oil

4.3.5.1 Reciprocating compressor		
Viscosity according to ISO:	VG 100	VG 150
Quality according to DIN:	VDL	VDL
ARAL	Motanol HE 100	Motanol HE 150
BP	Energol RC 100	Energol RC 150
SHELL	Corena oil H 100 D	Corena Öl H 150 D
SUNOCO	Sunvis 9100	Sunvis 9150
TEXACO	Compr. Oil EP 100	Compr. Oil EP 150
MOBIL	Rarus 427	Rarus 429
WINTERSHALL	Wiolan CD 100	Wiolan CD 150
BI	/	/
4.3.5.2 Rotary compressor		



Attention!

Material damage caused by the wrong oil!

Only synthetic ROTOR OIL 8000 F2 may be used for our rotary compressors, see (“Rotary compressor” on page 325).

4.3.6 Recommended grease

4.3.6.1 SCHWING drive line grease

Only use this grease to lubricate the SCHWING drive lines.

SCHWING item no.: 10197297

400 g cartridge for hand grease gun

4.3.6.2 Lithium-saponified high-pressure grease

KP 2 K according to DIN 51502 without solid lubricant

ARAL	Aralub HLP 2
BP	Energrease LS-EP 2
KLÜBER	Centoplex 2 EP
SHELL	Alvania EP Fett 2
SUNOCO	Multi Duty EP-2
TEXACO	Multifak EP 2
MOBIL	Mobilux EP 2
WINTERSHALL	Wiolub LFP 2
BI	MPG-A

4.3.6.3 Special lubricants for severe operating conditions

Under severe operating conditions, we recommend using a particularly adhesive and pressure-resistant grease for the SLIDING BEARING OF THE BOOM COLUMN and SLIDING PIECES OF THE ROTARY DRIVE, such as:

OPTIMOL-OPTIPIT

KLÜBER-COSTRAC GL 1501

Severe applications are, for example:

- high exposure to dust, dirt, heat, humidity, sea water
- strong impact load and vibrations
- multi-week abandonment.

It is imperative to use OPTIMOL-OPTIPIT in the mounting of the above components. It is available in 400g cartridges under art. no.: 10087948 from SCHWING's spare parts service.



4.3.6.4 Recommended spray-on grease

Sprayable EP lubricating grease for open gears with MOS2 and graphite additive

ARAL	Sinit FZ 2
BP	Energol WR P
KLÜBER	Grafloscon C-SG 0 ULTRA
	Grafloscon CA 901 ULTRA-SPRAY
SHELL	Cardium Fluid D
TEXACO	Crater XX Fluid
MOBIL	Mobilgear OGL 007
BI	LUB-A

4.3.6.5 Special lubricants for the plastic sliders in the telescopic arm

Designation according to DIN: MLE2N-40

SCHWING item no.: 10194658 10 kg tin

4.3.6.6 Special lubricants for couplings and seals in pumping lines

OPTIMOL OLIT CLS 10 kg tin

SCHWING item no.: 10149905

Optimol Olit CLS is a rubber-friendly, water-resistant, high-performance grease on lithium/calcium base.

As an alternative to Optimol Olit CLS, the high-pressure grease listed in table Lithium-saponified high-pressure grease

SHELL Alvania EP grease 2

can also be used. When switching between these two types, remove old grease residues carefully.

4.3.7 Excerpt from the safety data sheet for hydraulic oil

This is an excerpt from the manufacturer's safety data sheet according to the Directive 91/155/EC.

Please request the complete safety data sheet from your oil supplier in your country of operation.

TRADE NAME:

(Product name of oil)

USAGE:

Hydraulic oil

PREPARATION:

Mixture of highly-refined mineral oils and additives

POTENTIAL DANGERS:

Prolonged and repeated skin contact may cause drying of the skin, irritation and dermatitis.

Avoid formation of oil mist.

Avoid uncontrolled release into the environment.
Not fully biodegradable.

FIRST-AID MEASURES:

After inhalation:

Take the affected person into fresh air and place in a resting position. Seek medical advice.

After skin contact:

Remove contaminated clothing and wash skin with water and soap.

If the skin was penetrated by high pressure, consult a doctor immediately.

After eye contact:

Immediately rinse thoroughly for 15 minutes under running water with the eyelids open and consult a doctor.

After ingestion:

Do not induce vomiting. Seek medical advice.

Note to the doctor:

Symptomatic treatment.

FIRE PREVENTION AND -FIGHTING:

Do not smoke when handling the product, no open flame or other exposure to heat.

Fire class according to DIN EN2: B

Suitable extinguishing agent:

Foam, powder, carbon dioxide, sand or earth.

Do not use strong water jet!

ACCIDENTAL RELEASE MEASURES:**Person-related measures:**

Ventilate affected rooms thoroughly. Avoid skin contact.

Environmental protection:

Prevent further leakage and flow into drains.

Erect sand or earth barriers or other suitable blocking measures.

In case of leakage into water, canalisation or soil, contact competent authorities.

CLEANING AND ABSORPTION:

Absorb or contain with sand, earth or absorbent material.

Shovel into a marked reservoir and dispose of according to local regulations.

HANDLING AND STORAGE:

Do not eat, drink, smoke or sniff during work. Avoid spilling.

Avoid sun, direct exposure to heat and strong oxidants during storage. Store dry and do not expose to large temperature switches.

PERSONAL PROTECTIVE EQUIPMENT:**Respiratory protection:**

Use oil mist protective mask with filter for organic vapours and particles.

Hand protection:

Protective gloves made of PVC or nitrile rubber, provided they meet safety standards

Eye protection:

Wear protective glasses in case of risk of splashing

Body protection:

Avoid skin contact, wear overalls.

GENERAL PROTECTIVE- AND HYGIENIC MEASURES:

Do not carry oil-soaked cleaning rags within the clothing. Do not eat, drink, smoke, sniff during work.

SAFETY-RELEVANT DATA:

See safety data sheet from the manufacturer.

DISPOSAL:**Product:**

By approved waste disposal company. EU waste code no.: 130110

Packaging:

Completely emptied by approved waste disposal company.

MARKING:

Not subject to marking regulations according to EU directives. Observe national regulations!

4.4 Spare parts and accessories



Information

Please observe the special instructions on safety components in chapter “**Safety inspections**” on page 345.

Spare parts and accessories must comply with the requirements defined by SCHWING.

This is guaranteed by the use of original SCHWING spare parts and accessories.

Use the article numbers of the machine-specific spare part catalogue in order to clearly identify the spare parts.

Spare parts with the same name can differ from one another slightly with regard to their shape and appearance, or in some cases not at all. However, the material quality, weight, function, etc. can be extremely different. Therefore, only use spare parts that comply with the specifications in the spare part catalogue.

SCHWING can also provide - beyond the legal provisions - original spare parts for older machines.

A wide range of accessories is also available.

SCHWING is not liable for damages resulting from the use of spare- and additional parts in non-compliance with the above requirements.

It is possible that, by using unsuitable or unauthorised accessories, the definition of "improper use" is met.

We recommend using our customer service for installing our original spare parts and accessories, as well as for all maintenance and repair work on your SCHWING machine.

Please note that SCHWING must rule out all warranties in the event that you or a third party commissioned by you carry out improper work.

SCHWING is also not liable in such cases for any consequences thereof.

Also see our "Delivery, service and payment terms and conditions".

The machine's accessories should also be checked during safety-related inspections, regardless of whether they can be installed securely or carried along loosely.

It should also be observed that, in addition to the soundness, this accessory is suitable and approved by SCHWING.

4.4.1 Wear parts - Signs of wear

All components of a machine are subject to natural ageing. In addition, the wear of moving parts varies greatly depending on their load.

Careful maintenance and upkeep, as well as proper use of the machine can delay, but not entirely prevent, this so-called wear.

Since the wear and tear on various components of your SCHWING machine can vary greatly depending on their operating conditions, there are no universal rules to be applied for inspecting and replacing these parts.

However, there are signs indicating the need for an early review.

4.4.1.1 Case examples

Sand in the water box of the concrete pump

If, while conducting your regular cleaning of the water box, you notice that the water is becoming increasingly contaminated with concrete particulate matter, this means that the pumping pistons are worn.

If the same incident occurs again in the short term, the pumping cylinders also need to be replaced.

Hydraulic oil in the water box of the concrete pump

If you notice oil streaks on the water surface or a milky emulsion in the water box when the concrete pump is upright, the seal on the differential cylinders could be worn.

Water in the hydraulic oil

Small amounts of condensation in the hydraulic oil box are normal and should be drained regularly according to maintenance schedule.

A strong increase of the water content suggests water ingress from the outside.

It can also be assumed in this case that the seal in the differential cylinder is worn.

Dirt in the hydraulic oil

An oil analysis should be carried out first if clogging from an outside source can be excluded (e.g. refilling from an unclean reservoir), see (**chap. 4.8.3**).

The oil analysis determines the type of clogging.

In consequence thereof, e.g. the condition of the hydraulic pumps (metal particles) can be concluded.

If you determine that the clogging is caused by concrete particulate matter, the seals on the differential cylinders should be checked as well.



Information

Our machines are constantly optimised in the course of improving the specification. In doing so, a critical focus is on the improvement of the wear and tear.

Special components are also available for special applications.

If necessary, please ask our customer service for the optimal solution to your wear problem.



4.5 Explanation of the maintenance schedule - Stationary concrete pump



Fig. 145: Illustration of similar

Symbols used in the following maintenance schedule:

❶ = CHECK ❷ = LUBRICATE ❸ = CLEAN ❹ = REPLACE

① ② ③ ④ = ditto, after the initial commissioning

Time interval in the following maintenance schedule:

A = daily or 10 operating hours

B = weekly or 50 operating hours

C = monthly or 200 operating hours

D = quarter-annually or 500 operating hours

E = semi-annually or 1000 operating hours

F = annually or 2000 operating hours

G = every 2 years

whichever comes first!





4.6 Maintenance plan for stationary concrete pump SP 1800/2800

4.6.1 General information

Description	A	B	C	D	E	F	G	Chap.
A1 Technical safety inspection by experts. Intervals according to time or operating hours, whichever occurs first.								(chap. 7.4) (chap. 4.19)
A2 Visual and functional test by machine operators	①							(chap. 4.19)
A3 Check hydraulic oil level (before every commissioning)	①							(chap. 4.8)
A4 Hydraulic oil (after successfully passing an oil inspection, the hydraulic oil can be used for more than 2 years)						①	④	(chap. 4.8)
A5 Draining condensation from the hydraulic oil box		③						(chap. 4.8)
A6 Clean cooling vanes of the hydraulic oil cooler, as well as those of the radiator		③						(chap. 4.10)
A7 Pressure controls	①							(chap. 4.9)
A8 Grease joints of the operating levers			②					--
A9 Check the hydraulic and water systems, aggregates, reservoirs, pumping lines, etc. for leaks		①	②					(chap. 4.16)
A10 Check that the structure, outrigger, pumping line, reservoirs, aggregates, pump kit, drive lines, etc. are fastened correctly		①	①					(chap. 4.13)
A11 Check oil level of the distributor gearbox (special equipment)			①					
A12 Change oil in the distributor gearbox (special equipment)			④		④			
A13 Check oil level of the agitator gear (special equipment)		①						
A14 Change oil in the agitator gear (special equipment)		④		④				
A15 Crank support			②					

(** = lubricate every 100 operating hours)

Interval:	Explanation of the symbols						
After the first commissioning:	①	= inspect	②	= lubricate	③	= clean	④ = replace
After time interval:	①	= inspect	②	= lubricate	③	= clean	④ = replace

Time interval after operating hours:					
A =	daily or every 10 operating hours	B =	weekly or every 50 operating hours	C =	monthly or every 200 operating hours
D =	every three months or every 500 operating hours	E =	semi-annually or every 1000 operating hours	F =	annually or every 2000 operating hours
G =	every 2 years		whichever comes first!		

100** = lubricate every 100 operating hours!

Interval:	Explanation of the symbols						
After the first commissioning:	①	= inspect	②	= lubricate	③	= clean	④ = replace

4.6.2 Concrete pump (pump kit)

Description	A	B	C	D	E	F	G	CHAP:
B1 Flush water box	③							(chap. 3.16)
B2 Check water box for deposits, clean as required		③						(chap. 3.16)
B3 Replace main hydraulic oil filter after maintenance interval or in the event of an error message				④	④			(chap. 4.8)
B4 Check fixing of pumping pistons			①					(chap. 4.13)
B5 Lubricate grease nipple on rock valve, slewing cylinder, agitator and filling hopper	②							(chap. 4.12)
B6 Check clamping screws of the rock valve swivel head for tightness		①						(chap. 4.12)
B7 Check screws of the rock valve cover for tightness		①						(chap. 4.12)
B8 Check the axial play of the rock valve slewing shaft		①						(chap. 4.12)
B9 Check the seal on the rock valve slewing shaft						①		(chap. 4.12)
B10 Check cutting ring of the rock valve		①						(chap. 4.12)

Interval:	Explanation of the symbols							
After the first commissioning:	①	= inspect	②	= lubricate	③	= clean	④	= replace
After time interval:	①	= inspect	②	= lubricate	③	= clean	④	= replace

Time interval after operating hours:					
A =	daily or every 10 operating hours	B =	weekly or every 50 operating hours	C =	monthly or every 200 operating hours
D =	every three months or every 500 operating hours	E =	semi-annually or every 1000 operating hours	F =	annually or every 2000 operating hours
G =	every 2 years		whichever comes first!		

4.6.3 Special equipment

Description	A	B	C	D	E	F	G	CHAP.
Rotary compressor:								
Z3 Check oil level (before every commissioning)	①							(chap. 4.17)
Z4 Oil change with ROTORÖL 8000 F2			④			④		(chap. 4.17)
Z5 Replacing the oil filter			④			④		(chap. 4.17)
Z6 Replacing oil return valves			④			④		(chap. 4.17)
Z7 Clean / Replace air intake filter			③		④			(chap. 4.17)
Z8 Cleaning the oil cooler			③					(chap. 4.17)
Z9 Replacing the oil separator cartridge							④	(chap. 4.17)

Description	A	B	C	D	E	F	G	CHAP.
Diesel engine:								
D1 Check fuel supply and AdBlue every 4 hours	①							
D2 Check starter batteries			①					
D3 Check fuel pre-filter daily or clean after maintenance indicator turns on (special equipment)	①							
Air-filter system:								
D4 Check air filter contamination (maintenance indicator)	①							
D5 Check dust discharge valve on the air filter for damage and clean		① ③						
D6 Check clean air pipe for damage and tightness			①					
D7 Check filter element after maintenance indicator, renew at least after one year						④		
D8 Check filter housing and bracket for damage(cracks)	for each filter maintenance							
D9 Function testing of maintenance indicator						①		
D10 Empty fuel / water separator daily	①							
D11 Check soot level monitor (start manual regeneration) for C 7.1 Tier 4i motors		③						

Interval:	Explanation of the symbols							
After the first commissioning:	①	= inspect	②	= lubricate	③	= clean	④	= replace
After time interval:	①	= inspect	②	= lubricate	③	= clean	④	= replace
Time interval after operating hours:								
A =	daily or every 10 operating hours	B =	weekly or every 50 operating hours	C =	monthly or every 200 operating hours			
D =	every three months or every 500 operating hours	E =	semi-annually or every 1000 operating hours	F =	annually or every 2000 operating hours			
G =	every 2 years		whichever comes first!					

For more information on engine maintenance, see the manufacturer's operating instructions!

4.6.4 Test intervals according to concrete delivery rate

The amount of wear on your machine's parts depends on the operating conditions (e.g.: concrete type, concrete pump stroke rate, etc.).

We therefore recommend testing new components after having pumped a specified amount of concrete.

This allows you to determine the wear behaviour of the components and define the necessary test intervals:

		First test after m ³	Further tests after	Further information chapter
P1	Concrete pumping line	5000	Demand	(chap. 7.4)
P2	Rock swivel head	5000	Demand	(chap. 4.12)

4.8 Hydraulic fluid and filters for stationary concrete pump

4.8.1 Checking the fill level of the reservoir

The reservoir for the hydraulic oil is equipped with an oil level indicator (1) (**Fig. 146**) / (**Fig. 147**).




Fig. 146 SP 1800




Fig. 147 SP 3800

Caption (Fig. 146) / (Fig. 147)

1	Oil level display
4	Filler cap
5	Cleaning cover



Attention!

If the oil level is too high, the reservoir can overflow when the oil is heated!

If the oil level is too low, there is a risk of damage because the hydraulic pumps suck air in.

Before starting the machine, always check the oil level!

Check the oil level only when the oil is cold, before you start the hydraulic pump drive for the first time prior to daily use.

To do so, the machine must be level in all directions.

When the oil is cold, the oil level must be shown in the middle of the oil level indicator (**Fig. 146**) / (**Fig. 147**) SP 3800. If present, ensure that the adhesive label is in good condition and replace it as required.

When warm, the hydraulic oil is expanded and the indicated oil level is not correct.

If necessary, top up the hydraulic oil via the filler cap (4) (**Fig. 146**) / (**Fig. 147**).

Do not mix different types of oil.



Attention!

Ensure absolute cleanliness!

To do this, we recommend using SCHWING's flushing and filtration unit. For more information on this, contact SCHWING.

4.8.2 Filling the empty oil box

- Top up the hydraulic oil box as described above.
- Wait approx. 10 minutes until the oil is free of air bubbles and top up with more oil if necessary.
- Run all functions.
- Check the oil level again with cold oil while the machine is in a horizontal position.
- Top up hydraulic oil if necessary.

4.8.3 Purity of the hydraulic oil

The purer the hydraulic oil is, the smoother the hydraulic systems and greasing units function. 75 percent of all system failures are due to damage to the inserted components - caused by impure hydraulic oil.



In complex hydraulic systems, the most sensitive component determines the required purity in the entire system.

For components used in SCHWING GmbH hydraulic systems, a purity classification as set out in the manufacturer's specifications is required, which should at least be compliant with or better than classification 20/18/15 according to ISO 4406.

SCHWING GmbH supplies its machines with purity classification 18/16/13 according to ISO 4406.



Attention!

Always make sure to adhere to the recommended purity classifications of SCHWING GmbH, as a minimum those of the component manufacturer!

4.8.4 What does the purity classification mean?

Contaminations cannot be convincingly detected through a visual inspection.

The classification of solid contamination in lubricants and hydraulic fluids is determined according to ISO 4406.

To determine the oil purity classification, solid particles are counted in 100 ml of fluid, arranged according to size and quantity and divided into particle areas.

Depending on the procedure for the particle counting, there will be two or three areas.




Fig. 148 Purity classifications



Information

The smaller the values, the purer the hydraulic oil!

Further information on purity classifications and contaminations of operating materials can be obtained from the manufacturer information on filter systems as well as lubrication and operating materials.

4.8.5 What advantages are there in observing the purity classification?

Adherence to the purity classification contributes significantly to the reduction of costs due to the extension of the oil change interval and to the prevention of damage due to contamination.

As such, machine's availability and productivity increase.



Information

Failure to comply with the purity classification results in the loss of warranty!

4.8.6 Extended changing intervals for hydraulic oil

Through diligent oil care and regular changing of the oil filter, the oil changing interval can be extended.

The oil quality must be monitored through regular laboratory tests.

The laboratory report contains the analysis values of your sample, comments from expert technicians on the state of the oil and machine, as well as recommendations on how to proceed.

For an oil analysis, the oil must be removed from the system and sent to a laboratory for analysis.

To keep your personal costs as low as possible, we recommend analysis sets.

The samples can thus be taken cleanly, quickly and easily and sent.

4.8.7 Description of the oil sampling procedure

Take the oil sample:

- During operation or shortly after shut-down – because dirt and wear particles are floating, potentially present water has not been removed.
- At a normal operating temperature (max. 80 °C), warm oil can be removed more quickly.
- Always following the same method and at the same point.
- Wherever possible before the filter, never out of the filter.
- Not shortly after an oil change or after a large quantity of oil has been refilled.
- Only in a clean and dry sample cup – at best directly into the "original" from the analysis set.

You can obtain suitable measuring and flushing devices via SCHWING.

Please contact our Customer Services:

Telephone: + 49 (0) 2325 / 987 - 231/232

Email: service@schwing.de

4.8.8 Draining condensation water



Attention!

Danger of unintentional draining!

Do not leave the draining site while draining is in progress.

After an extended period of downtime, drain any water from the hydraulic oil box. To do this, use the drain valve (1) (**Fig. 149**) on the bottom of the box.

- Remove the lock nut from the drain valve (1) (**Fig. 149**).
- Screw the drain hose (2) onto the drain valve.
- The drain valve opens automatically. When pure hydraulic fluid flows out, remove the hose immediately and reattach the lock nut.
- After draining, check the level of the hydraulic oil.




Fig. 149

4.8.9 Changing the hydraulic fluid

- Warm the hydraulic system up.
- Provide a waste oil receptacle.
- Due to the large quantity to be changed, you should first pump out as much fluid as possible through the upper cleaning opening. We recommend using our flushing and filtration unit for this.
- Drain residual oil using the drain valve as described above.
- Clean the box and replace the filter inserts whenever you change the oil.
- Document the oil and filter changes using the appropriate SCHWING tags, see (Fig. 153) and (Fig. 154).

4.8.10 Cleaning the reservoir

In particular during long periods at standstill, the hydraulic oil excretes dirt particles which are deposited onto the bottom of the container.

Therefore, during each oil change, check the inner walls and the inner floor.



Danger!

Risk of explosion!

Do not use naked light!

-
- Clean the oil reservoir as needed. In addition:
 - Clean the area surrounding the cleaning cover and remove the cleaning cover (5) (Fig. 146) / (Fig. 147).
 - Remove the suction hoses of the hydraulic pumps from the box and close them to prevent dirt from getting into the pumps.



Attention!

Pumps can be destroyed!

- Clean the inside with flushing oil and a lint-free cloth.

Textile fibres and solvents can damage the hydraulic system. For this reason, do not use steel wool, diesel oil, petrol, etc. for cleaning purposes.

-
- Wipe the inner sides of the box using a dry cloth.
 - Check the seal and mount the cleaning cover.

4.8.11 Changing the insert on the main filter (return flow filter)



Caution!

Pressure equipment!

For all work on the pressure equipment, ensure that the affected pressure space (filter housing) is depressurised.

Disconnect the power supply to the optional motor.

Ensure that the ventilator is no longer rotating and that the device has cooled down.

The machine is equipped with a main filter (2) (**Fig. 151**). The filter is located inside the machine.

As a rule, replace the insert on the main filter rather than cleaning it.

Never operate the hydraulic system without a filter insert.

Old filter inserts belong in special waste.

Clean and check all individual parts. Look out for rubbed-off metallic particles in the filter, as this would be an indication of damage.

Document the oil and filter changes using the appropriate SCHWING tags, see (**Fig. 153**) and (**Fig. 154**).




Fig. 150 SP 1800




Fig. 151 SP 3800

4.8.11.1 Dismantling

- Unscrew the filter bowl (3) (**Fig. 152**) at the bottom hexagon (4) using a ring spanner.
- Collect the fluid in a suitable receptacle and clean it or dispose of it in an environmentally responsible way.
- Screw (pre-2011 models: "pull") the old filter insert (2) off of the filter head.
- Clean the filter bowl and the filter head, ensuring that the thread in particular is clean.
- Inspect the O-rings and back-up rings, replace if necessary.

4.8.11.2 Mounting

- Apply clean operating fluid to the thread and sealing surfaces of the filter bowl, filter head and O-ring.
- Screw (pre-2011 models: "insert") the new filter insert (2) into the filter head.
- Screw in the filter bowl (3) until it reaches the limit stop and then loosen it by one quarter turn.
- Bleed the hydraulic system.



Information

The sealing effect is not improved by tightening!

4.9 Pressure checks - stationary concrete pumps

All hydraulic consumers are secured by pressure relief valves (PRV).

These valves are set at the factory. Readjustment is as a rule only necessary after replacement or repair of the hydraulic systems.

Regular pressure checks serve to detect errors early on. Carry out the checks while the machine is running at operating temperature and speed.



Warning!

The factory-set pressures must not be altered. Settings may only be configured by technically qualified workshop personnel!

- Only loosen hydraulic system connections if the drive is not running and the pressure accumulator (if present) is relieved. This also applies to the assembly and disassembly of test pressure gauges.
 - After the pressure check, first switch off the concrete pump, then turn the ball valve. This is to prevent an uncontrolled start-up of the concrete pump.
-



Attention!

When checking the pressure of the concrete pump hydraulic system, be sure to set the direction to "Pump".

In the direction "Sucking", the seals of the concrete pump control block may be pushed out.

4.9.1 Concrete pump system

The hydraulic pump of the concrete pump system is equipped with a "pressure cut-off". This swivels the pump back before the maximum operating pressure set on the pressure relief valve (PRV) is reached.

The pressure cut-off prevents the loss of performance and heating of oil which occur when hydraulic oil is discharged from the pressure relief valve.

The value displayed on the pressure gauge during the pressure test must be lower than the setting on the pressure relief valve. See hydraulic switching diagram.

Appropriate settings are carried out on the hydraulic pump and pressure relief valve.

If, during the check, the prescribed values are clearly exceeded or fallen short of, leave the required setting adjustment work to SCHWING's customer service.

Take the machine out of service and transmit the measured values to customer service.

4.9.2 Performing a pressure check

- Close the ball valves (1) (**Fig. 155**) or (1 and 2) (**Fig. 156**) or (**Fig. 157**).
- Configure the max. delivery rate (stroke rate) of the concrete pump.
- Switch the concrete pump on.

The pumping pistons are moved into the end position and remain there.

The indicator on the concrete pump pressure gauge (2) (**Fig. 158**) on the rear of the machine must increase to the value set for the pressure cut-off.

- Note setting value.
- After the pressure check, first switch off the concrete pump, then switch the ball valves back to their operating position. In this way, you prevent uncontrolled running of the concrete pump after turning the ball valve.




Fig. 155 SP 1800




Fig. 156 SP 3800, 7000, 7500




Fig. 157 SP 9000, SP 9500




Fig. 158 Pressure gauge pressure check

4.10 Radiator



Caution!

Risk of injury due to rotating fan blades and hot machine parts!

Before working on radiators:

- Switch off all control units.
- Switch off the motor and ignition.
- Allow the cooler to cool down.

Wear work gloves, helmet and safety glasses.

Remount all safety devices after finishing the cleaning work.

Only then, recommission the machine.

4.10.1 Hydraulic oil cooler

The hydraulic oil system can be equipped with an oil cooler.

Dusty precipitation on the fins of the oil cooler (1) (**Fig. 159**) reduces the cooling efficacy.




Fig. 159

4.10.1.1 Cleaning the exterior of the hydraulic oil cooler

Carefully clean the radiator with compressed air. To do this, bring the air flow parallel to the cooler fins and against the normal flow direction.

Cleaning with water or steam jet is possible for heavy soiling.



Attention!

Steam jet cleaning can potentially cause damage!

Before steam jet cleaning:

- Disassemble fan motor.
- Only use cleaning agents that do not corrode aluminium.
- Use water and steam jets carefully.

4.10.1.2 Cleaning the inside of the hydraulic oil cooler

- Remove the cooler.
- Connect cooler to a flushing system with filters.
- Flush for at least 30 minutes.
- After cleaning, remove the flushing medium completely.
- Then, flush the cooler with an oil type intended for the hydraulic system.

4.10.2 Motor cooler

Liquid-cooled motors have an appropriate cooler.

Depending on the type, the drive motor can be additionally equipped with a motor oil cooler.

Please make sure, when working on dusty jobsites, that the cooling fins of the motor cooler are cleaned from time to time.

Otherwise, this can result in damage due to the motor overheating.

Instructions on how to clean the cooler can be found in the respective motor or vehicle operating instructions.

4.11 Air-filter system

Only service air filter when motor is not running. Do not start the motor while the filter element is removed.


Assess the condition and tightness of the suction line each time the filter is serviced. Repair leaky suction line immediately.

4.11.1 Dust discharge valve

Check the condition of the automatic dust discharge valve and make sure that it is functioning properly (arrow, **(Fig. 160)**).

The valve must not be restricted. Remove any dust incrustations. Renew damaged valve.

The valve must point down when in installed condition.




Luftf_1
Fig. 160

4.11.2 Removing the filter element

If the machine is equipped with an air filter monitoring system, then only service the air filter element when the warning light signals on the control station light up.


Intermediate cleaning is not necessary.

- Release snap-in hooks and remove top cover (**Fig. 161**).
- Remove filter element by means of slight rotations (**Fig. 162**).
- Clean filter housing, in particular on the sealing surfaces, with a damp cloth. Ensure that no dust enters the clean air pipe to the motor.



Lufff_2

Fig. 161



Lufff_3

Fig. 162

4.11.3 Cleaning the filter element

Replace the filter element after 3 cleanings or after one year at the latest.



Attention!

Improper cleaning!

Never wash or brush filter element or clean by slamming.

Clean and dry compressed air is used for the cleaning (max. 5 bar). Dust may not get to the inside of the element when blowing out dust.

- A tube whose end is bent by approx. 90° should be placed onto the compressed air gun. It must extend to the bottom of the element (**Fig. 163**).
- Blow out the element from the inside out by moving the pipe up and down until dust no longer emerges (**Fig. 164**). Do not damage the filter element!

**Caution!****Health hazard!**

Do not inhale dust! Wear respiratory protection (dust mask)!

- Inspect the cleaned element for damages (paper bellows, seals) before re-installing it. Cracks and holes in the paper bellows can be detected with a torch.

**Attention!****Potential motor damage!**

Never continue using a damaged filter element. If in doubt, replace the element with an original spare part.




Fig. 163




Fig. 164

4.11 Air-filter system

4.11.4 Installing the filter element

- Insert filter element carefully into the housing.
- Mount cover of housing. Ensure that the dust discharge valve faces downwards. When closing the top cover, the filter element is automatically pressed into the correct position.

4.11.5 Storage

Store the filter element upright in the original packaging and protected from dust, moisture and damage.

4.11.6 Disposal

The filter element consists of filter paper and polyurethane foam.

All filter elements are hazardous waste and must be disposed of according to the local provisions.

4.11.7 Function testing of maintenance indicator

- Reduce the suction intake of the air-filter system (e.g. with a stable plate or cardboard) while the motor idles until the maintenance indicator reacts.



Attention!

Motor damage!

Do not, by any means, close the suction intake completely!

4.12 Rock valve



Danger!

Danger of crushing and injury!

To prevent unwanted working movements prior to working on the rock valve, always follow the points below!

- Switch off the drive motor and prevent it from starting up.
- Switch off concrete pump and agitator.
- Do not reach into the gate valve while the drive motor is running.
- Discharge the pressure accumulator, if applicable.

4.12.1 Lubricating the bearing points

Concrete pumps without central greasing have a central greasing strip, see examples (Fig. 165 Greasing strip on stationary concrete pumps) and (Fig. 166 Greasing strip on truck-mounted concrete pumps).

The grease nipples on this strip are connected to the bearing points of the rock valve.

Bearing points include:

- Slewing shaft
- Slewing cylinder
- Agitator

Depending on the type of rock valve, the number of grease nipples can vary. Additional grease nipples are located on the greasing strip for the mixer bearing in truck mixer concrete pumps.

Lubricate all grease nipples daily on the greasing strip. Lubricate more frequently during continuous operation, at least every 8 hours:

Lubrication procedure:

- Clean the lubrication point.
- Remove the protection caps from the grease nipples.
- Press grease into each grease nipple until the old grease emerges from the bearing point.
- Wipe off old grease with cleaning rags. Dispose of grease and cleaning rags properly.
- Reattach the protection caps.



Fig. 165 Greasing strip on stationary concrete pumps




Fig. 166 Greasing strip on truck-mounted concrete pumps



Information

In various pumping units, the swivel head of the rock valve is powered by the mounted ball bearing of the hydraulic cylinder.

Cylinders with unilateral and bilateral ball bearings are allowed.

The appropriate lubrication points are connected to the lubrication point (or the central greasing) through the greasing lines.

The additional grease nipples, e.g. (1) (**Fig. 167**) do not have to be lubricated!

They are used to press out the ball socket during repair work.




Fig. 167

4.12.2 Checking the screw-type connections

Regularly make sure that the cover screws (14) and clamping screws on the swivel head (15) are tight, in accordance with the maintenance schedule (**Fig. 168**).

If necessary, tighten screws using a torque wrench in accordance with the torque table in the preface of the spare parts catalogue.




Fig. 168

Caption (Fig. 168)	
Pos.	Designation
A	See detailed view (Fig. 169)
B	See detailed view (Fig. 170)
14	Cover screws
15	Clamping screws

4.12.3 Checking the axial play of the slewing shaft



No air gap may be visible between the bearing bushing (4), the locking wheel (2) and the adjusting nut (1) (**Fig. 169**), even during operation.

There must be a measurable distance of distance of 1.5 to 3.0 mm between the swivel head (rock) (5) and housing lining (6) while the kidney seal (7) is in contact with the housing lining (6) (**Fig. 170**).

Metallic contact between the swivel head (rock) and housing lining is an indication of an error, for example:

- Kidney seal (7) defective.
- Adjusting nut (1) too tight.

- Cutting ring jammed.
- Too much grease was used during assembly or parts were not cleaned carefully.


Fig. 169

Fig. 170

Caption for (Fig. 169) and (Fig. 170)	
Pos.	Designation
1	Adjusting nut
2	Locking disc
3	Safety screw
4	Bearing bushing
5	Swivel head (rock)
6	Housing lining
7	Kidney seal

4.12.4 Configuring the axial play of the slewing shaft

- Remove safety screw (3) (**Fig. 169**) together with disc.
- Set distance "B" = 1.5 to 3.0 mm using the adjusting nut (1).
- Align the bore in the collar of the adjusting nut with the nearest threaded bore in the locking disc (2) (rotate the nut forward or backward).
- Attach safety screw (3) with disc.

4.12.5 Checking the cutting ring

The cutting ring and wearing insert on the housing lining are worn unevenly due to external influences (e.g. varying types of concrete) and different stresses in sub-areas (area "B", (**Fig. 168**)).

Grooves are caused primarily by friction and breaking of stones.



Information

Grooves are irrelevant as long as the wearing insert is not fully worn.

A one-piece wearing insert (9) (**Fig. 171**) made of white cast iron is used as standard.

A two-piece wearing insert (9) (**Fig. 172**) made of white cast iron with an appropriate support plate is available as special equipment.

In order to achieve an even wear pattern and thus considerably longer service lives of the parts, we recommend:

- After a thorough cleaning, bring the rock into the left and right end position and check the condition of the cutting ring and wearing insert along the entire perimeter of the cutting ring in accordance with the maintenance schedule.
- If a visible gap has formed between the cutting ring (10) and the wearing insert (9) (max. allowed 1.0 - 1.5 mm), rotate the cutting ring 90°.




Fig. 171




Fig. 172

4.12.6 Rotating the cutting ring

In order to be able to rotate the cutting ring, proceed as follows:

- Disconnect the pumping line from the outlet of the rock valve. To do this:
 - a) Remove the tapered tube for stationary concrete pumps.
 - b) Remove the wedges (1+2) and the coupling (3) for truck-mounted concrete pumps.
- Swivel the outlet for the boom (4) to the side and secure with a wedge (1), (**Fig. 173**).




Fig. 173

- Loosen the adjusting nut (1) (**Fig. 174**) by two to three turns.
- Loosen the cover screws (14) evenly by approx. two to three turns to release the pressure spring in the cutting ring.



Caution!

Danger of crushing and breakage!

If you were to remove the cover screws completely, the heavy steel cover would fall off.

This can cause personal injury and material damage!

Do not unscrew the cover screws completely!

- Press off the cover of the housing using two assembly levers until it hits the loosened screws; there are press-off points (arrow) (**Fig. 174**) located on the top cover for this purpose.
- Retract the swivel head (rock) until the cutting ring is released. If the cutting ring is not exposed yet, then loosen the cover screws some more and repeat the process.
- Loosen the cutting ring, if necessary, by tapping on it lightly.
- Rotate the cutting ring 90°.



Information

Always rotate the cutting ring into the same direction!



- Make sure that the cutting ring is guided securely by the rock and cannot fall out or tilt.
- Also make sure that no stones etc. are trapped between the individual components when tightening the cover screws.
- Tighten the cover screws (14) evenly and carefully. Make sure that the cutting ring slides into the rock without tilting.
- Gradually tighten all cover screws (14) crosswise using a torque wrench. Observe the proper tightening torque for these screws.
- Set the axial play of the slewing shaft approximately in order to be able to switch through the rock valve for "setting" the parts. To do this, set the adjusting nut (1) into position and loosen it by a ½ turn.
- Dampen the kidney seal with water and switch through the rock valve several times in order for all parts to "set".



Attention!

Risk of damage!

Do not switch through the rock valve when dry.

- Set the axial play of the slewing shaft as described in chapter (4.12.4).




Fig. 174

- Check the distance between the cutting ring (10) and the swivel head (rock) (5) (Fig. 175) and (Fig. 176) after each rotation. If it is more than 8 mm, the cutting ring is no longer guided securely in the rock and must be replaced.

- When replacing the cutting ring, check the condition of the wearing insert (9) and pressure spring (11) (**Fig. 176**).




Fig. 175




Fig. 176




Fig. 177

4.12.7 Checking the seal of the slewing shaft

The bearings of the slewing shaft are sealed against the medium being pumped with O-rings (Fig. 177).

In the event of leaks, replace the O-rings (super-fine concrete components penetrate outwards through the bearing) immediately before the bearing is destroyed.

To do this, the slewing shaft has to be removed, see separate rock valve repair manual.

4.12.8 Prolonged downtime

Should the rock valve not be used for an extended period of time, we recommend lubricating the kidney seal and the housing lining with a lubricating and anti-corrosive agent of specification MIL 907D (e.g. ANTI-SEIZE by LOCTITE).

This agent prevents the seal from "caking".



Attention!

Spray may affect rubber parts!

Do not use a spray.

4.12.9 Checking the wear of the rock

Most of our swivel heads (rocks) are armoured on the outside and inside by means of welding to reduce wear.

The means of armouring depends on empirical values from the main fields of application for the individual swivel heads (rocks), see example (Fig. 178).




Fig. 178 Swivel head (rock)

Caption (Fig. 178)	
Pos.	Designation
1	Inner armour
2	outer armour

4.12.10 Preventive maintenance

Since the wear largely depends on the operating conditions, we recommend checking a new rock for the first time after about 5000 m³ conveyed concrete:

- To do so, clean the concrete pump as per usual.
- Move the swivel head (rock) into an end position.



Danger!

Danger of crushing and injury caused by switching rock valve!

Switch off the drive motor and empty the pressure accumulator to prevent the rock from moving independently.

- Loosen the outlet and inspect the inside of the rock with a torch.
- Move the rock into the other end position and repeat the inspection.



Further inspection intervals can now be determined depending on the condition.

The swivel head (rock) must be replaced if the basic material "shows through" at certain points.

The inner armouring usually wears faster than the outer armouring.

The exterior should be checked as soon as significant wear is detected on the inside.



Information

A regeneration by means of renewed hard facing is no longer possible for the materials currently used!

We strongly advise against unqualified welding and the use of replicas.

SCHWING is not liable for damages caused by improper repair attempts or replicas.



4.13 Delivery and differential cylinders, pumping piston change

- Make sure the fastening screws on the differential and pumping cylinders are tight.
- Tighten any loose fastening screws crosswise in three steps using a torque wrench (**Fig. 179**).




Fig. 179

The necessary tightening torques can be found in the preface of the spare part catalogue.

4.13.1 Pumping piston change

Work on the pumping pistons is carried out in the water box.



Danger!

Danger of crushing!

Rock can switch!

Before working in the water box, always switch off drive motor and release pressure accumulator in order to prevent unwanted working movements of the concrete pump.

Proceed to a safe location when driving the concrete pump with open water box.

Do not reach into the water box!

No other work must be carried out on the concrete pump while working on the pumping piston.

Make sure that no-one comes near the sliding system.

In the event of danger, actuate the EMERGENCY-STOP button.



Warning!

Different water boxes can be available depending on the installed concrete pump kit!

The covers are designed correspondingly.

The basic principles are:

- If the top cover of the water box can be opened without tools, bolted protective grids are located under the top cover.
- If a tool is required for opening the cover, then no grids are available.

Always ensure that the grids are present and bolted down tightly. Attach the top cover correctly and secure, if necessary (e.g. with a wedge).

4.13.2 Preparing to change the pumping pistons

- Take off the top cover of the water box (2) (**Fig. 180**) and remove the protective grills.
- Drain the water with the lever (3).
- Switch the ball valves (1) (**Fig. 181**) or (1+2) (**Fig. 182**) or (**Fig. 183**) to the "Pressure control" position in order to prevent the piston rods from switching into the end positions.




Fig. 180 Example




Fig. 181 Example SP 1800




Fig. 182 Example of SP 3800 BR02





Fig. 183 Example of SP 9500 BR02

4.13.2.1 Driving the concrete pump in repair mode (SP1800)

- Remove the top cover on the water box (**Fig. 184**).




BP1547

Fig. 184 Water box

- Drain the water.
- Close the ball valve 1 (**Fig. 181**) on the concrete pump control block in order to prevent the piston rods from switching into the end positions.
- Start the motor and select a higher idling speed.
- Set the lowest concrete pump stroke rate.
- Operate the concrete pump using the remote control.

4.13.2.2 “Pumping piston change” operating mode (SP3800)


The machine is equipped with a special control for the pumping piston change.



- Activate "Pumping piston change" operating mode by actuating the button (1) (**Fig. 185**).

Activating the operating mode "Pumping piston change" automatically reduces the rotational speed of the diesel engine and delivery rate to "0". Only the buttons for the CP control on the cable remote control are activated. The operator keyboard is deactivated.

- Now move the concrete pump using the remote control and by simultaneously actuating the button (1) (**Fig. 185**). Simultaneous actuation must take place within 0.5 sec. If there is no further action within 0.5 seconds, e.g. in the case of a required change of direction of the pumping piston, you must repeat the process!
- Deactivate "Pumping piston change" operating mode by switching off the diesel engine and motor control.



00045_Förderkolbenwechsel_V01

Fig. 185 Example of pumping piston change control

4.13.3 Checking the fastener

- Lift the top cover off of the water box (2) (**Fig. 180**) and remove the protective grills.
- Move an intermediate piece into the water box.
- Drain the water.
- Make sure the fastening screws are tight (**Fig. 186**). While doing so, hold the distance piece on the continuous hexagon.
- Move the second intermediate piece into the water box and repeat the check.




Fig. 186

4.13.4 Changing the pumping piston



Attention!

Material damage caused by leaking pumping pistons.

If sand is in the water box, the pumping pistons are worn and need to be replaced.

Leaking pumping pistons cause premature wear on the pumping cylinders.

Always replace both pumping pistons together.

However, should sand get into the water box despite the new pumping pistons, then the cylinders must also be replaced.



Caution!

High weight!

Depending on the size, a pumping piston weighs over 25 kg.

Use tools for installing and removing (e.g. a belt), and have another person help you.

Instruct the assistant. Only switch on the motor again when the assistant has left the machine.



4.13.4.1 Removal

- Close the ball valves (1) (**Fig. 181**) or (1+2) (**Fig. 182**) / (**Fig. 183**) on the concrete pump control block. Closing the ball valve prevents switching of the piston rods in the final position.
- Remove the cover from the water box.
- Drain the water.
- Move the pumping piston to just before the rear end position. The distance piece (**Fig. 187**) must be fully visible in the water box.




Fig. 187

- Loosen the fastening screws on the distance piece and remove them. While doing so, hold the distance piece on the continuous hexagon (**Fig. 188**).
- Move the piston rod into the rear end position.
- Remove the distance piece (3) (**Fig. 189**).
- Slowly move the piston rod along the pumping piston.
- Connect the piston rod flange (1) to the pumping piston flange (2) using a screw and nut as shown in (**Fig. 190**).
- Tighten the screws by hand.
- Slowly retract the piston rod, which in turn pulls the pumping piston out of the cylinder (**Fig. 191**).
- Loosen the screw connection.
- Remove the pumping piston from the water box.
- Clean and check all parts.




Fig. 188




Fig. 189




Fig. 190




Fig. 191

4.13.4.2 Installation

- Apply a thick layer of grease to the new piston and cylinder wall.
- Attach the new pistons to the piston rod flange using a screw and nut.
- Move the pumping piston far enough into the cylinder that the screw connection can still be loosened (**Fig. 192**).
- Remove the screw connection.
- Retract the piston rod.
- Insert the distance piece and screw it onto the pumping piston (**Fig. 193**).
- Slowly move the piston rod onto the distance piece.
- If necessary, align the distance piece and screw it onto the piston rod.
- Add water.
- Attach the protective grill and the top cover of the water box.
- Switch the ball valves (1) (**Fig. 181**) or (1+2) (**Fig. 182**) / (**Fig. 183**) on the concrete pump control block into the operating position.




Fig. 192




Fig. 193



4.14 High-pressure version (HP) (pumping and differential cylinders) (optional)

Work on the pumping pistons is carried out in the water box.



Warning!

Danger of crushing!

Before working in the water box, always switch off drive motor and release pressure accumulator in order to prevent unwanted working movements of the concrete pump.

Proceed to a safe location when driving the concrete pump with open water box.

Do not reach into the water box!

No other work must be carried out on the concrete pump while working on the pumping piston.

Make sure that no-one comes near the sliding system. Rock can switch!

In the event of danger, actuate the EMERGENCY-STOP button

- Check the fastening screws of the differential and pumping cylinders for tight fit.
- Tighten loose fastening screws crosswise in three steps with a torque wrench (**Fig. 194**).

The necessary tightening torques can be found in the preface of the spare part catalogue.




Fig. 194

4.14.1 Pumping pistons

Work on the pumping pistons is carried out in the water box.



Warning!

Different water boxes can be available depending on the installed concrete pump kit!

The covers are designed correspondingly.

The basic principles are:

- If the top cover of the water box can be opened without tools, bolted protective grids are located under the top cover.
- If a tool is required for opening the cover, then no grids are available.

Always ensure that the grids are present and bolted down tightly. Attach the top cover correctly and secure, if necessary (e.g. with a wedge).

4.14.2 The “Pumping piston change” operating mode

(see “Delivery and differential cylinders, pumping piston change” on page 285)

4.14.3 Removing the HP pumping pistons

- Close the ball valves (1+2) (**Fig. 182**) or (**Fig. 183**) on the concrete pump control block. Closing the ball valve prevents switching of the piston rods in the final position.
- Remove the cover from the water box.
- Drain the water.
- Move the pumping piston to just before the rear end position. The distance piece (**Fig. 195**) must be fully visible in the water box.




Fig. 195



- Loosen, but do not unscrew, fastening screws on the distance piece.

The flanges of the piston rod and pumping piston may not be twisted against each other as this may complicate the removal of the pumping piston.

In order to loosen the fastening screws below, position an open-jawed spanner (SW 60) onto the hexagon of the distance piece and rotate the distance piece (along with pumping piston and piston rod).

- Remove all screws after they are loosened.
- Screw two assembly aids (**Fig. 196**) into the threads of the pumping piston. Use two countered nuts for this.
- Remove the lock nuts and check the alignment of the assembly aids (3) with the through holes in the piston rod flange (2) (**Fig. 197**).
- Drive piston rod flange carefully to the flange of the pumping piston (1) and place into position. The through holes must slide over the assembly aids in the process.
- Unscrew one nut with disc on each assembly aid.
- Retract the piston rod slowly and pull the pumping piston (1) (**Fig. 198**) out of the cylinder.
- Remove the assembly aids and take the pumping piston out of the water box.
- Repeat the process for the second pumping piston.
- Clean and check all parts.




Fig. 196




Fig. 197




Fig. 198

4.14.4 Installing the HP pumping pistons

- Screw two assembly aids (1) (**Fig. 199**) into the pumping piston.
- Mount new pumping piston onto the piston rod flange.
- Apply a thick coat of multi-purpose grease to the new piston and cylinder wall.
- Drive the pumping piston into the cylinder so that the assembly aids can still be removed and the distance piece can be incorporated into the water box.
- Remove assembly aids and retract the piston rod.
- Mount distance piece with the narrow flange onto the pumping piston (1) (**Fig. 200**).



- Only use new, original safety discs to fasten the pumping pistons. The smaller disc diameter has to face towards the screw head (**Fig. 201**).
- Tighten screws manually.
- Drive piston rod to the distance piece.
- Align distance piece (open-jawed spanner SW 60), if necessary, and screw onto the piston rod.
- Tighten the screws using a torque wrench in accordance with the tightening torques.

The necessary tightening torques can be found in the preface of the spare part catalogue.

- Repeat the process for the second pumping piston.




Fig. 199




Fig. 200




Fig. 201

- Fill in water, mount protective grill and top cover and secure using a wedge and clip pin.

Switch the ball valves (1+2) (**Fig. 182**) or (**Fig. 183**) on the concrete pump control block into the operating position.

4.15 Multi-part pumping pistons (optional)

The pumping cylinders DN 180 for concrete pumps SP 9000 and SP 9500 can be equipped with multi-part, renewable pumping pistons.

Multi-part pumping pistons consist of the following individual parts (**Fig. 202**), (**Fig. 203**), (**Fig. 204**):

Caption for	
Pos.	Designation
10	HP piston collar adapter
20	Pumping piston body DN 180
30	Guide ring DN 180
40*	Pumping piston collar DN 180-NBR
50	Pumping piston cover DN 180
60*	Screw M 20x180 - 8.8
70	Bushing C 30x22/50
80*	Nut M 20 - 8

* Main wearing parts

The pumping pistons are installed and removed as previously described for the one-piece pumping pistons.

In order to avoid damaging renewed pumping pistons during installation, ensure absolute cleanliness:


- Remove residual concrete.
- Use ample grease.
- Drive the pistons slowly and carefully into the cylinders.

4.15.1 Replacing the main wear parts

Remove the pumping pistons, as described in (**chap. 4.14**).


- Loosen the central screw connection.
- Disassemble the pumping piston.
- Clean and inspect all parts.
- Assemble the pumping piston with a new pumping piston collar (40). Use a new self-locking nut (80) Replace the screw (60) as necessary.
- Tighten the screw connection to a tightening torque of 300 Nm.

- Install the pumping pistons, as described in (chap. 4.14).




k2364

Fig. 202



K2363

Fig. 203



K2362

Fig. 204

4.15 Multi-part pumping pistons (optional)

4.16 Servicing the pumping line



Danger!

Risk of explosion due to ruptured tubes!

Pumping lines are wear parts.

If the minimum wall strength is not met, then there is a great risk of tube breakage.

Check the pumping line regularly using a suitable wall-thickness measuring device.

If the minimum wall thickness is not met, then replace the tubes and elbows.

Under extreme conditions, daily checks may be necessary.

SCHWING's customer service can recommend suitable measurement devices depending on the pumping line material being used.

The minimum permissible wall thickness depends on the maximum possible concrete pressure of the concrete pump.

During operation, the operator must monitor the pumping line for leaks (water escaping). Leakages lead to blockages due to the concrete "bleeding" out. Stop operation immediately and remedy leakage.



Warning!

If fluid leaks from the walls of a pipe or formed part, there is a great risk of accidents due to pipe breakage.

Stop operation immediately and release pumping line by means of back-siphonage!



Attention!

Tapping with a hammer is not recommended, because:

- Any resulting dents can lead to accelerated wear.
 - It can damage the hardened layer of highly wear-resistant tubes
-



Information

Depending on the installation situation, the wear and tear on the pumping lines can vary greatly.

Check the elbows and reductions under highest strain especially carefully.

Experience has shown that the concrete pump outlet as well as the “impact elbows” on the last section of the boom (see “**Impact bend**” on page 310) wear more quickly than the rest of the pumping line.



Caution!

Injury caused by the cocking lever springing open!

When mounting split couplings, injuries can be caused by the cocking lever springing open unexpectedly.

Injuries such as bone fractures to concussions are possible.

Secure the cocking lever of the split coupling immediately after closing the cocking lever by using the "safety for split couplings".





4.16.1 Diagrams

For determining the required minimum wall strengths of concrete pumping lines from P 355 (with prescribed, twofold safety):

(Y) = Concrete pressure PN in bar

(X) = Minimum wall strength in mm





4.16.2 Main wear zones

(pay particular attention during inspections)

Pumping pipes

The main wear zone is located in the direction of the flowing concrete approx. 100 mm behind the flange (**Fig. 205**).




Fig. 205

Elbows

The main wear zone is located in the direction of the flowing concrete in the "inlet bend" (**Fig. 206**).




Fig. 206

Two-layer materials

Two-layer materials must be replaced, at the latest, when the inner hardened layer has worn through to the outer layer in places (**Fig. 207**).




Fig. 207

4.16.3 Impact bend

The impact bend (1) (**Fig. 208**) is the penultimate bend in the boom pumping line. The concrete frequently falls into this elbow and the impacting material causes so-called impact wear.

Impact wear can be largely avoided if the last boom section is positioned horizontally during the pumping process (**Fig. 209**).

Position "1" + "2" = limited impact wear

Position "3" = high impact wear

Measurement points:

Wear measurement is only possible via a regular optical inspection, as the main wear points vary greatly between concrete pumps. Empirical values can be extended individually by the indicated measurement, if necessary (**Fig. 210**).




Fig. 208




Fig. 209




Fig. 210

4.16.4 Measuring the wall thickness

(Excerpts from Sales Booklet Esser ES4045)

The wall thickness of pumping pipes can be measured using a commercial calliper ((**Fig. 211**) company Kroeplin GmbH). Observe the operating instructions from the manufacturer of the measuring device.

Double-walled pumping pipes cannot be measured using ultrasound.

Procedure:

1. Type specification of the pipeline component

Determine which type is available in which quality.

The measurement sheet is selected based on the type. Should you have questions or be missing measurement sheets, please contact SCHWING's customer service.

2. Specification of the installation situation

The respective installation situation is specified on the measurement sheet, according to the installation present.

3. Taking the measurement

Depending on the prescribed measurement methods, the respective minimum wall strengths must be specified.

4. Comparison of indicator values

The measured minimum wall strengths must now be compared with the indicator values taken from the relevant measurement sheets.



5. Decision on further use

If one of the measured values has been reached, then at this critical point the pumping pipe has a remaining wall thickness of 0.5 mm and should be replaced as soon as possible.

Summary

1. Type specification
2. Installation situation
3. Measurement
4. Comparison
5. Decision



00024_messuhr

Fig. 211

Wall-thickness sensor C3R30 supplied by Kroeplin GmbH

4.16.5 Tube type - tubes


4.16.5.1 Installation situation 1 - tube after tube

Measurement points:

(P1) approx. 20-30 mm behind the welding seam of the inlet flange

(P2) measurement on the shoulder of the inlet flange around the entire circumference.

Set the measuring tip as far on the end of the shoulder as possible, in the direction of the groove.




4.16.5.2 Installation situation 2 - tube after elbow

Measurement points:

(P1) approx. 20-30 mm behind the welding seam of the inlet flange in extension of the elbow inner radius and elbow outer radius.


(P2) measurement on the shoulder of the inlet flange around the entire circumference.


Set the measuring tip as far on the end of the shoulder as possible, in the direction of the groove.



4.16.6 Measurement sheet - tubes

(As of 31/10/2012, excerpt from Esser Sales Booklet EM120029 _ EM130023 DE 141208):

		Removal of the pipe component must be done on reaching a measurement point (P1 or P2) at the latest!		
Type: SUPER 2000 TUBES (ESSER TWIN PIPE 700 TUBES)				
Nominal size DN [mm]	Quality type	Wall thickness [mm]	P1 [mm]	P2 [mm]
100	700	4.0 (2.0+2.0)	2.7	10.2
100	700	7.7 (4.5+3.2)	3.8	10.2
125	700	4.0 (2.0+2.0)	2.7	8.3
125	700	4.5 (2.5+2.0)	2.7	8.3
125	700	8.6 (5.6+3.0)	4.0	8.3

		Removal of the pipe component must be done on reaching a measurement point (P1 or P2) at the latest!		
Type: SUPER 3000 TUBES (ESSER TWIN CAST 900 TUBES)				
Nominal size DN [mm]	Quality type	Wall thickness [mm]	P1 [mm]	P2 [mm]
112	900	2.0+2.0	2.9	15.6
125	900	2.0+2.0	2.9	9.6
125	900	3.0+1.5	2.4	8.8
125	900	5.6+3.0	4.1	8.8

4.16.7 Tube type - elbows

4.16.7.1 Installation situations 1, 2, 3 - elbow after elbow / tube / tapered tube

For all elbows of 10° to 90° with standard connection, but without leg extension


Measurement points:

(P1) measurement on the shoulder of the installation flange around the entire circumference.

Set the measuring tip as far on the end of the shoulder as possible, in the direction of the groove.

(P2) measurement on the shoulder of the outlet flange in extension of the elbow outer radius.


Set the measuring tip as far on the end of the shoulder as possible, in the direction of the groove.





4.16.8 Measurement sheet - elbows

(As of 31.10.2012, excerpt from the Esser Sales Booklet ES4045):

	Removal of the pipe component must be done on reaching a measurement point (P1 or P2) at the latest!			
Type: SUPER 2000 ELBOWS (ESSER TWIN PIPE 700 ELBOWS)				
Nominal size DN [mm]	Quality type	Wall thickness [mm]	P1 [mm]	P2 [mm]
100	700	8.2 (5.0+3.2)	10.0	10.0
125	700	10.6 (7.0+3.6) 11.0 (7.0+4.0)	8.0	8.0


4.16.9 Tube type - tapered tubes

Measurement points:

(P1) measurement in the 50 mm area in front of the outlet flange welding seam.

(P2) measurement on the shoulder of the outlet flange around the entire circumference.


Set the measuring tip as far on the end of the shoulder as possible, in the direction of the groove.





4.16.9.1 Measurement sheet - tapered tubes

(As of 31.10.2012, excerpt from the Esser Sales Booklet ES4045):

		Removal of the pipe component must be done on reaching a measurement point (P1 or P2) at the latest!			
Type: SUPER 2000 TAPERED TUBES (ESSER TWIN PIPE 700 TAPERED TUBES)					
DN inlet [mm]	DN outlet [mm]	Quality type	Wall thickness [mm]	P1 [mm]	P2 [mm]
125	100	700	8.0 (4.0+4.0)	4.9	10.3
150	125	700	8.0 (4.0+4.0)	4.9	8.7

4.16.10 Extending the service life



Information

Does not apply to directional tubes and elbows!

Directional tubes and elbows may only be installed in the pumping direction. For this purpose, directional arrows are located on the material.

The service lives of conventional (non-directional) tubes and elbows can be extended if the parts are rotated regularly.

- Turn pumping pipes and elbows 180° from the inlet side to the outlet side after 50 % of their expected service life (Fig. 212).




Fig. 212

4.16.11 Replacing pumping pipes end elbows



Information

Directional tubes and elbows may only be installed in the pumping direction. For this purpose, directional arrows are located on the material.

- Pay attention to the quality and correct size of spare parts.

Only original SCHWING spare parts correspond exactly to the factory-installed parts.

- During the initial assembly at the factory, the boom pumping line is assembled without tension on a folded placing boom.

Incorrect assembly can lead to an increased load on the placing boom kinematics and damage such as broken line holders.

In order to avoid damage, likewise always exchange individual parts on a folded placing boom.

The length of the pipe installed in the pumping line outlet is specified on a sign on the machine (**Fig. 213**).

When pumping line parts are replaced later on, a different pipe length may be required in some cases. For this reason, always give the required length when ordering.



Warning!

Pumping pipes and elbows can be very heavy!

A 3 m long pumping pipe DN 125 of Super 2000 quality weighs, for example, approx. 45 kg.

Attach tubes and elbows to lifting gear before removing them.

- Use new seals and fuses for the couplings.
- Clean and check the couplings carefully.
- Lubricate the couplings and seals with a rubber-compatible lubricant, e.g. "Optimol Olit CLS".

"Optimol Olit CLS" is a water-resistant, high-performance grease with a lithium/calcium base.

**Information**

While being assembled at the factory, the pumping lines are fitted with special web seals. As such, the required precision is achieved when first assembling the pumping line. The centres of rotation for the pumping lines, however, are fitted with simple seals without web. When replacing worn pumping line parts later on, the seals with a web can be replaced with simple seals at all tube connection points.

If you would like to replace multiple parts of the pumping line, replace those parts individually and sequentially.

Do not disassemble the entire pumping line. In this case, on the assembly of the new line the centres of rotation would have to be redefined.

This work should only be carried out by specially trained persons using special equipment




Fig. 213

4.16.12 Testing the pumping hoses

Due to natural ageing, rubber hoses may be 6 years old at most (including a storage time of 2 years).

They must be replaced every 6 years from the date of manufacture, even if they superficially appear "okay".

For end hoses and connecting hoses, a daily, external visual inspection is prescribed.

Loose pumping hoses must be tested before every use.

As wear strongly depends on the operating conditions (concrete, pressure, delivery rate, etc.), then the inner side of all new hoses should be tested for the first time after pumping approx. 1000 m³ of concrete:

Plan further tests on the basis of the test results.

4.16.13 Visual inspection (exterior)

- Check the safety catch on one of the placing boom end hoses to make sure it is in proper working order.
- The outlet end of an end hose must not be "frayed".
- Check all pumping hoses for dents, kinks or other deformations that might indicate displaced or destroyed armour hose casing (steel cord insert).
- Check the outer skin for cuts, ruptures or abrasions that could imply damage to the armour hose casing.

Hoses with a damaged casing must be replaced!

4.16.14 Visual inspection (internal)

- Lay the cleaned hose out horizontally and use a pocket torch.
- Pay attention to points at which the armour casing is exposed or protrudes.
- Also pay attention to areas with loose rubber coating, dents, cuts and local wear zones.
- Check the main wear zones on the inlet side of the hose in particular. The heaviest wear is located on the first 30 cm of the rubber coating (behind the fixing).

Hoses with damaged armour casing or excessive wear must be replaced!

4.16.15 Visual inspection of fixings

- Make sure the fixings are tight.

The hose and fixing must be firmly connected together.

- Check the inner sides of the fixings for wear.
- Check the sealing surfaces for damage and clean any concrete residue off of them.

Hoses with damaged or loose fixings (hose creeps out of the fixing) must be replaced!



Information

Take extra care to check end hoses equipped with a non-return valve.

Due to the greater load, check end hoses with a non-return valve (**Fig. 214**) especially carefully in the pressure area of the non-return valve.




Fig. 214

4.17 Rotary compressor

4.17.1 Maintenance packages

SCHWING provides two different packages with material for servicing your compressor:

4.17.1.1 Maintenance package 1

(Standard maintenance) art. no.: 10197336

This package contains all filters, seals and a reservoir with compressor oil for the maintenance work described below.

The oil quantity is sufficient for an oil change and possible refill between changes.

4.17.1.2 Maintenance package 2

(Oil separator cartridge) art. no.: 10170388

This package contains an oil separator cartridge and all of the seals necessary for replacing it.




Information

In order to ensure safe and smooth operation, please only use the material mentioned above.

SCHWING is not liable for any damages caused by improperly performed maintenance and/or unsuitable material.

* = Special equipment



Information

Read these instructions before starting with the work.

Do not use flammable substances and naked flames during cleaning work and maintenance.

4.17.2 Checking the oil level

- Check oil level when drive is at a standstill and compressor is depressurised (pressure gauge at "0").
- Place vehicle on level ground.
- The sight glass (4) can be used to check the oil level (Fig. 215).

The oil level must exceed the upper edge of the sight glass.

The oil level should reach about the centre of the sight glass with a running compressor.




Fig. 215 Maintenance openings on compressor



Caution!

Attention, risk of burns!

The surface of the compressor can be very hot!

Contact with the skin can cause burns.

When working on and with the compressor, always wear appropriate protective clothing.

4.17.3 Topping up the oil

- Top up oil when drive is at a standstill and compressor is depressurised (pressure gauge at "0").
- Carefully open the filler plug **(1)** (**Fig. 215**) to equalise the pressure.
- Make sure that no oil foam emerges from the opening **(5)**.
- Wait a few minutes, if necessary, until the oil foam has reduced.
- Only use the same oil for refill as is in the compressor.



Attention!

Material damage caused by the wrong compressor oil.

Using the wrong oils or mixtures of various oil types can cause severe material damage to the compressor.

Always use the recommended oil and do not mix compressor oils of different brands and viscosities.

- Refill the oil until it overflows over the opening **(5)**.
- Replace the sealing ring **(3)** and attach the filler plug **(1)**.

4.17.4 Changing the oil

Drain the oil at operating temperature for it to drain properly.

- First loosen the filler plug **(1)** as described above.
- Open the drain cock **(2)**.
- Close the drain cock after emptying it completely.
- Fill in new oil, as described above.
- Let the compressor run for a few minutes, then check the oil level and check for leaks. Add more oil, if necessary.

**Information**

New compressors are filled with a run-in oil. That oil must be changed during the first oil change with a compressor oil recommended by the compressor manufacturer.

Using the correct oil is imperative for the safe function of the compressor.

Only use the Rotor Oil 8000 F2 included in maintenance package 1.

Rotor Oil 8000 F 2 is a synthetic all-season oil suitable for an ambient temperature of -25 to 40 °C.

It may not, under any circumstances, be mixed with other oils.

4.17.5 Cleaning / Replacing the air filter

- Loosen the knurled nuts **(1)** (**Fig. 216**).
- Remove the sealing ring **(2)** and filter cover **(3)**.
- Pull out the filter insert **(4)**.
- Clean all parts with compressed air (max. 5 bar).
- Blow out the filter insert from the inside out using upward and downward movements until dust no longer emerges.
- After multiple cleanings, replace the filter insert in accordance with the maintenance schedule (see “**Maintenance plan for stationary concrete pump**” on page 245).
- Install filter in reverse order.

4.17.6 Cleaning the oil cooler

- Clean the cooling fins of the oil cooler with a compressed air gun (**Fig. 217**).

A dirty cooler causes the oil to heat up more and can result in outages due to overheating. If oil is too hot, it ages faster and loses its lubrication properties. This increases the wear on the compressor.

- Blow the compressed air opposite the normal flow direction of the cooling air.

4.17.7 Replacing compressed air hoses

Compressed air hoses must be replaced after 3 years at the latest.

The production information is engraved on the hoses.




Fig. 216 Air filter



Fig. 217 Air compressor

4.17.8 Replacing the oil filter

- Drain the old oil as described above.
- Loosen the screws **(1)** on the filter cover **(2)** (**Fig. 219**).
- Rotate the top cover 90° and remove the cover together with the filter.
- Remove the filter **(3)** from the top cover.
- Clean the top cover and seating surfaces of the housing.



Warning!

Do not use flammable cleaning agents!

No traces of cleaning agent may get into the compressor.

-
- Attach a new filter to the top cover.
 - Attach the top cover with a new sealing ring **(4)**.
 - Top up the compressor oil as described above.

4.17.9 Replacing oil return valves

- Loosen the hollow screws **(1)** (**Fig. 218**).
- Pay attention to the sealing rings **(3)**.
- Unscrew the return valves **(4)** from the separator housing.
- Install new valves with new O-rings **(5)**.
- Attach the screw connections **(2)** with new sealing rings **(3)**.




Fig. 218 Oil return valves




Fig. 219 Oil filter

4.17.10 Replacing the oil separator cartridge

4.17.10.1 Removing the oil separator cartridge

- Disconnect the plug for the solenoid valve (1) on the separator housing (2) (Fig. 220) and loosen the air hose (3).
- Loosen the oil return valve (4) as described above.
- Remove the compressed air tube (5) from the separator housing.
- Remove the radial groove nut (6).



Information

Pay attention to the mounting mark on the connection tube (7).

Mark position, if necessary.

The connection tube must be remounted later in exactly the same position.

- Loosen the connection tube and lift the separator housing (2) out of the oil chamber.
- Remove the connection tube (7) from the separator housing.
- Lever the cover of the housing (8) with the oil separator cartridge (12) carefully out of the housing.
- Loosen the nuts (9) and remove the sealing disc (10) and top cover (11).
- Remove the old oil separator cartridge (12) together with O-rings (13).

4.17.10.2 Installing the oil separator cartridge

- Install the parts in reverse order.
- Always use a new oil separator cartridge and new seals (10, 13, 14, 15, 16).
- Press the O-rings (13) with some grease into the seat pan of the oil separator cartridge.
- Make sure that:
 1. The separator cover (8) is mounted in the indicated position (arrow)
 2. The connection tube (7) is mounted according to its marking




Fig. 220 Oil separator cartridge

4.18 Electrical / Electronic system, software

4.18.1 Electrical system: Description

The electric system of the SP 1800 D / SP 3800 D is powered by two 12V batteries connected in series with 24V.

The following should be observed in terms of jump-starting and welding due to the spatial separation of both batteries (one on the right-hand and one on the left-hand side).

4.18.1.1 Jump starting

A diesel engine uses considerably more power to start than a gasoline engine, which must be considered in the selection of the dispenser unit.

The jump lead should be made of high-quality copper cable in accordance with DIN 72553-25 and have a cross section of min. 35 mm².

The positive terminal of the machine engine battery (-G12 right-hand side) and positive terminal of the dispenser unit are connected with the red cable.

First, the black cable is attached to the negative terminal of the donor unit and then to the negative terminal of the machine battery (-G13 on the left-hand side).

Make sure to observe the correct order!

Under no circumstances may the terminals of the batteries be connected the other way round.

The two batteries of the SP must remain connected electrically; an interruption can lead to the destruction of the alternator.

If the diesel engine of the SP has started, the cables can be removed again in the reverse order.

4.18.1.2 Welding



Attention!

Welding work on the frame may only be carried out by qualified personnel!

Do not conduct welding work on the motor!

In order to protect the electronic components from surges during electric welding work, the following safety measures must be observed:

- Positive terminal (on the battery -G12 right-hand side) and minus terminals (on the battery -G13 left-hand side) should be removed from the batteries and covered.

- The earth terminal of the welding device should be connected directly to the part being welded.
- The housing of the electronic components (e.g. control parts) and electronic cables must not come into contact with the welding electrode or earth terminal on the welding device.
- The earth terminal on the welding device must not be connected to the motor.
- Do not conduct welding work on the motor!

4.18.2 Electrical safeguarding of SCHWING components

Depending on the type of machine, the system can be secured in several places, also see electrical circuit diagram:

- A main safety fuse near the starter
- Safety fuses in the switch cabinet or operator station of the concrete pump, see **(Fig. 221)** / **(Fig. 222)**.




Fig. 221 Example: Operator station on a stationary concrete pump SP 1800.




Fig. 222 Example: Operator station on a stationary concrete pump SP 3800.

4.18.3 Changing the fuses in SCHWING components

- Switch off the machine's control unit and the drive motor.
- Switch the main battery switch (1) to the "0" position (**Fig. 224**), (**Fig. 225**) or (**Fig. 226**).
- Open the top cover of the switch cabinet or control station.
- Refer to the diagram on the inside of the switch cabinet cover or to the electrical circuit diagram for the allocation of the fuses.

The fuses are marked with "F". Commercial vehicle fuses are used.

- Only replace defective fuses with equivalent new ones.



Attention!

The electrical/electronic system can be destroyed due to overrated or by-passed fuses.




Fig. 223 Panel with regeneration

➤ If triggered again, there is a short circuit.

Stop the machine and have an electrician inspect the system.

If a fuse is tripped once again, there is a short circuit. Stop the machine and have an electrician inspect the system.




Fig. 224 Example SP 1800



Fig. 225 Example: SP 3800 BR02



Fig. 226 Example: SP 9500 BR02

4.18.4 Working on electrical / electronic components



Warning!

Only suitably qualified personnel may work on the electrical control and electronics.

Unqualified interventions impair operational safety and result in the termination of the operating license and CE certification.

➤ Before working on electrical or electronic components, disconnect:

1. First the negative lead (-).
2. Then the positive lead (+).

from the drive motor's starter batteries. This is sufficient for preventing short circuits and protecting the SCHWING control unit.

➤ Connect in reverse order.



Attention!

Risk of short circuit!

Do not place tools on batteries.

Further protective measures may be required for the vehicle electronics (e.g. for the anti-lock braking system ABS).

- Read the operating instructions of the engine manufacturer or vehicle manufacturer to find out about how to protect its electronics.
- Do not touch live parts.
- Never check the voltage by touching the ground.
- Replace defective control lamps immediately.
- Never disconnect a cable from the starter batteries, alternator or regulator while the motor is running.
- Earth the machine to establish equipotential bonding between the machine and the ground.

4.18.5 Software

Only representatives of SCHWING are permitted to alter the machine's software. This also applies to updates.



Danger!

Unauthorised modifications to the software can result in serious damage and accidents.

SCHWING is not liable for the consequences of unauthorised software modifications.

4.18.6 Electrically powered machines

Have an electrician disconnect the power supply to such machines prior to carrying out repair work on the respective machine.



Danger!

Danger caused by electric shock!

Only qualified electricians may work on the electrical system.

4.18.7 Electric welding procedure

See (chap. 4.20).

4.18.8 Jump starting

Connect the jumper cable as described in the operating instructions for the vehicle or the motor.

4.18.9 Jump starting stationary pumps with batteries connected in series

Machines can be supplied with 24V by two 12V batteries connected in series.

Observe the information below when jump starting due to the spatial separation of both batteries (e.g. one on the right-hand and one on the left-hand side of the machine).

- Connect the positive terminal of the machine battery (the battery is located near the starter motor) to the positive terminal of the donor unit using the red jump lead.
- Next, attach the black jump lead to the negative terminal of the donor unit and then to the negative terminal of the machine battery (e.g. on the opposite side of the machine).

Make sure to observe the correct order!

Under no circumstances may the terminals of the batteries be connected the other way round.

If the engine starts, then the cables can be removed again in the reverse order.

A diesel engine uses considerably more power to start than a gasoline engine, which must be taken into account when selecting the donor unit. The jump lead should be made of high-quality copper cable in accordance with DIN 72553-25 and have a cross section of min. 35 mm².

4.18.10 Mechanical processes

Cover devices, cables etc. when drilling or grinding work etc. is to be carried out on the machine.

4.18.11 Painting and working with aggressive substances

Cover devices, cables etc. to protect them against paint mist and aggressive substances.

4.18.12 Steam jet cleaning

Cover any electrical and electronic components.

Never direct a water or steam jet onto these components.

Any penetrating moisture leads to malfunctions and can destroy electronics and electrical components completely.

4.18.13 Starter batteries (lead-acid batteries)



Danger!

Risk of explosion!

The gases discharged when charging the lead acid rechargeable batteries are highly explosive! Fire, sparks, smoking and naked lights are prohibited in the vicinity!

Danger of acid burns!

Wear protective glasses and protective gloves! Avoid any contact with skin and clothing!

Risk of short circuit!

Do not place tools on batteries!



Attention!

The following instructions do not apply to maintenance-free starter batteries.

Strictly observe the manufacturer instructions!

4.18.14 Checking the acid level

- Clean battery surface, open locking caps.
- The fluid should typically be 10 to 15 mm above the plates or at the level of the control device. Observe the manufacturer instructions.
- Refill with distilled water (not acid!), if necessary.
- Mount locking caps.

4.18.15 Checking the open-circuit voltage

In order to achieve a correct result, the battery may have been neither connected to a load nor charged at least two hours before the measurement.

If the open-circuit voltage is to be measured with a built-in battery, first disconnect the negative terminal and then the positive terminal from the battery. Otherwise, there is a danger of short circuiting!

- Measure the voltage between the terminals.

If the measuring device displays at least 12.5 volts, then the battery is in order. The battery must be charged immediately once below 12.5 volts.

4.18.16 Checking the acid density

Using a hydrometer (**Fig. 227**) measures the acid density of each individual cell. The acid temperature must be at least at 10 °C during this process.

The acid densities of the individual cells may not deviate by more than 0.03 kg/l. Otherwise, the battery is defective and must be replaced.

It should further be noted that the acid density is lower under tropical conditions. See (**Table 2**).




Fig. 227 Hydrometer

Acid density (kg/l)	Charging status	Action	
1.28	1.23	good	-
1.20	1.12	half	charged
1.12	1.08	empty	charge immediately!

Table 2

4.18.17 Charging the battery

Charge battery by running the motor for several hours or with a charger.

When charging with a charger, the battery must be at a temperature of at least 10 °C.

- Disconnect both terminal posts from the battery.



Information

Always disconnect the negative terminal first and then the positive.

Otherwise, there is a risk of short circuiting!

- Open locking cap.
- Charging current max. 10 % of the battery capacity:

Example:	120 Ah battery
Charging current max.:	12 ampere

- Stop charging after reaching an acid density of 1.28 kg/l or 1.23 kg/l (in the tropics) if the charger does not have an automatic regulator.
- Check acid level and refill with distilled water, if necessary.
- Clean battery terminals and terminal posts.
- First connect the positive terminal and then the negative terminal. Otherwise, there is a risk of short circuiting! Only tighten terminal posts by hand.
- Apply a thin layer of acid protective grease to the terminal posts.

4.18.18 Maintaining the batteries during machine downtimes

The following measures are necessary in order to prevent damage to the machine's batteries during long periods of downtime.

4.18.18.1 Downtime of 1 to 4 weeks

Disconnect the batteries (disconnect ground wires on the batteries and, if available, switch the battery main switch to pos. 0). This prevents the batteries from losing their charge due to quiescent current consumption.

4.18.18.2 Downtime of more than 4 weeks:

During downtimes of 4 weeks or more, the batteries must be removed and stored in a dry place at a temperature of 0 °C to 30 °C. The batteries must be stored standing up. During this time, the battery voltage must be consistently kept at over 12.55 V. If the voltage of the battery falls below 12.1 V, this can cause damage and it has to be replaced.



Information

Please refer to the manufacturer specifications for further information on the starter batteries!

4.18.19 Storage and installation

Keep battery clean and dry in order to prevent discharge through leakage.

Ensure proper installation in the machine. Vibrations shorten the service life. Damage to the battery case entails high follow-up costs due to escaping acid.

4.18.20 Disposal

Turn in old batteries at a collection point. Observe regional regulations for disposal of batteries and sulphuric acid.



Information

Please refer to the operating instructions from the vehicle or engine manufacturer for further information on the starter batteries

4.19 Safety inspections

Alongside regular maintenance work, continuous observation and technical safety inspections are essential tools in maintaining operational and work safety with the machine and accessories.

As such, the responsibilities are as follows:

4.19.1 Machine operator

The machine operator is responsible for the visual and functional inspections of "his" machine, including accessories, before and during operation.

He must discontinue use of the machine if he/she discovers defects endangering work safety.

He/she is responsible for the external condition of "his/her" machine. As such, he/she must ensure e.g. the timely repair of damage to paintwork.

Especially on placing booms, corrosion pitting can lead to tears and breaks!

As the vehicle driver, he/she is responsible for the roadworthy condition of his/her vehicle, in the sense of local regulations in the country of use.

4.19.2 Competent person (specialist)

A competent person has to carry out the necessary technical safety inspections at regular intervals and record the results in the inspection book.

The definition of a competent person is given in the SAFETY MANUAL.

We recommend only contracting SCHWING employees to carry out this inspection.

4.19.3 Expert

An expert must be consulted in case of significant changes and extensive repairs (for example, if welding is carried out on load-bearing parts).

The definition of an expert is given in the SAFETY MANUAL.

4.19.4 Additional inspections

For certain units relevant to safety, such as accumulators, the relevant inspection regulations in the country of use must be observed.

If no qualified personnel are available, we highly recommend contracting a SCHWING employee to carry out the inspection.

4.19.5 Technical safety inspection

As there is more risk of damage with older machines, the technical safety inspection interval for concrete pumps and placing booms is dependant on the age of the machine.

That means that older machines must be more frequently checked than newer ones. The respective inspection intervals are given in the SAFETY MANUAL.



Information

Test intervals

Adhering to these inspection intervals is imperative for increasing the service life and reducing repair costs!

Due to the dynamic loads that occur on all machines, over time fatigue can occur on steel parts, leading to cracks or fractures.

Of course other components also age, for example through environmental influences, and should be checked regularly.

The older the machine, the higher the probability of damage.

Therefore the graded, regular technical safety inspection is an effective means for detecting damage at an early stage, before it leads to machine failure and (or) an accident.



Information

Case of damage!

Please be aware that in the event of damage, the question of whether the machine was checked regularly and correctly can be critical for assessing liability!

4.19.6 Safety components

If a defect is detected on a safety component during a technical safety inspection or on any other occasion, the machine must not be used until it is repaired.

As a rule, special skills are required to carry out repairs, which is why we strongly recommend contracting SCHWING's customer service to perform this inspection.

If you carry out repairs on safety components yourself or hire a third party to do this, we encourage you to notify us of the damage and the work carried out.

You help us to improve our products and if necessary, initiate appropriate urgent measures.

For your notification you can use a copy of the form found on the next page.



4.19.6.1 What are safety components?

The SCHWING factory standard distinguishes between safety components of the first (S1) and second order (S2).

The failure of S1 parts can pose a danger to life and limb. All persons inside the danger zone are in extreme danger of being killed.

S1 parts include, for example:

- Placing boom arms
- Levers and bolts on the placing boom
- Hydraulic cylinders on the boom and outrigger
- Outriggers
- EMERGENCY STOP parts and controls

Upon failure of S2 parts, primarily the main functions of the machine, such as "pumping concrete" or "distributing concrete", fail.

S2 parts include, for example:

- Hydraulic pumps
- Drives
- Gear
- Chutes
- Concrete filling hoppers

In practice, S1 and S2 components are often installed together. This makes it difficult to clearly assess a component's individual relevance to technical safety in the event of a failure.

It also always depends on the specific situation. Ruptured concrete pumping lines or hydraulic hoses, for example, can result in machine failure and can also endanger the lives and health of people located nearby!

Please also do not hesitate to inform us of damage of which the technical relevance is not immediately apparent.

In any case, you still help us to improve our products - and you are on the safe side.

In advance, we thank you very much for your help.

Please copy!

4.19.7 Notification of damage for safety components

Please complete the copy of this questionnaire and send the completed copy to:

SCHWING GmbH
Service
PO Box 20 03 62
D-44647 Herne

Of course you can also fax us this page or reply by email:

Email: service@schwing.de

Customer no.:	
Address:	
Contact person:	
Tel.:	
Fax:	
Email:	
Machine type:	
Machine no.:	
Operating hours:	
Concrete delivery volume in m³:	



Short description of the damage:

The following parts were replaced (item number, if known):

Was welded?	<input type="checkbox"/> Yes	<input type="checkbox"/> No
If so, where?		
Were mechanical procedures carried out?		
<input type="checkbox"/> Drilling	<input type="checkbox"/> Sanding	<input type="checkbox"/> Other
If so, where?		
Was the work documented by photos or drawings?		
<input type="checkbox"/> Yes		<input type="checkbox"/> No
If so, is this document attached to this message?		
<input type="checkbox"/> Yes		<input type="checkbox"/> No

4.20 Repair welding

On the placing boom, on the support or on other components important to work safety, welding may only be carried out by authorised representatives of the manufacturer.

In general, welding should only be carried out by personnel specially trained and qualified for this activity.

Work must comply with the maintenance instructions and with all relevant safety rules and local regulations.

Welding work must be inspected by an expert.

Observe the sign on the machine (**Fig. 228**)

Before carrying out electric welding, disconnect all batteries and, where appropriate, take measures to protect the vehicle and engine electronics.

- Refer to the documentation from the vehicle or engine manufacturer.

Disconnect the multi-plug of the cable remote control or the radio receiver from the machine.

Attach the negative pole of the welding machine directly to the component to be welded.

The welding current should not pass through a hydraulic cylinder, for example, as doing so will result in damage to the chrome layer of the piston rods.

Protect equipment, cables and cable connectors from the heat, slag, etc.





Fig. 228

OPERATING INSTRUCTIONS



Planar-V4

R-18, R-CAN

R6, R10

Compact-M, Compact-V

Compact-M2

Receiver Type / Version

Factory No.

Frequency

Transmitter Type / Version

Factory No.

Frequency

1. STANDARD SPECIFICATION

- Portable transmitter.
- Receiver with integrated mounting holes.
- Multi-pin connecting cable for the receiver according to your specifications.

The actual delivery specification is as detailed on the confirmation of order or the delivery note accompanying the goods!

2. SAFETY PRECAUTIONS

Even if you are accustomed to working with radio control systems, read these operating instructions carefully before using this equipment. Only this document contains the latest information relating to your NBB radio control system.

For explanatory notes on obtaining an operating permit please refer to registration documents enclosed in the appendix of this operating instruction. Observe all applicable work-safety and accident prevention regulations carefully. Only fully trained, authorized personnel may use the NBB radio control equipment. Components, etc. built into the NBB equipment for safety purposes must be regularly inspected.

If the NBB radio control unit develops a fault, it must be shut down immediately. The transmitter should be switched off with the STOP key. The connecting cable must be disconnected at the receiver from the connecting socket (terminal) of the unit to be controlled. The repair of the equipment must not be carried out other than by NBB or an NBB authorized technician.



Failure to observe these recommendations will put both you yourself and others at risk. Under these circumstances, NBB rescinds the guarantee and any other form of liability. This radio control unit is designed exclusively for the control of construction machines and industrial plants. Only under these conditions are the safety systems (STOP and zero setting) fully effective. No other form of use is permitted. Any non-observance of this condition will relieve NBB of all liability.

3. TRANSMITTER

Switching on: To make the unit ready for use, unscrew the screw plug of the battery compartment on the back of the transmitter and remove the cover. Insert 2 charged AA Mignon batteries 1,2V NiMH (or batteries 1,5V - not rechargeable) into the battery compartment, close the cover and tighten the screw plug again.



**Rechargeable batteries (NiMH or NiCd) must be fully charged before first use!
Never attempt to charge standard non rechargeable 1,5V AA batteries!**



The functions of the receiver are released with the "ON/HORN" key.
The receiver has to be switched off with the "STOP" key when work is finished.
A red dot flashes on the Planar display during operation.

Energy saving function: The transmitter switches off automatically, if the keys are not pressed within a specified time. The red dot goes out.

Optional: Transmitter for continuous operation possible.

**The duration of this stand-by can be specified when ordering.*

88.

Operation:
The red dot flashes.

LO

Slowly flashing:
Batteries are to low, to
operate the transmitter.

Quickly flashing:
Batteries are nearly empty.
Transmitter can be operated
for appr. 30 minutes more.



Base Unit

When a transmitter is operated with AA Mignon 1,2 V NiMH rechargeable batteries, these batteries automatically charge inside the transmitter in the optional base unit. To start the charging process simply slide the transmitter into base unit (see image 1). An automatically controlled charging process keeps batteries from over-charging. Base unit has to be connected to a power supply (optional also with dc-charger) – (see image 2).



WARNING: Never try to charge regular AA batteries (non-rechargeable batteries) – danger of explosion!



WARNING: Charge 8 hours (2000 mA/h) after total discharge of batteries or before first use.




Image 1



Image 2



Connection power plug/
car power plug



Pre-drilled
mounting holes

5. RECEIVER

R-6, R-10, R-18, R-CAN,
Compact-M,
Compact-V



R-6, R-10 R-18



R-CAN




Compact-M




Compact-V



Mounting possibility of the receiver
R-18, R-CAN, Compact-M.



Mounting possibility of the receiver
Compact-V.




Mounting possibility of the receiver
R-6, R-10, R-18


The receiver is connected to the unit to be controlled with the multi-pin connecting cable supplied. Please observe the instructions issued by the manufacturer of the unit to be controlled! **We recommend urgently to realize this connection via a central, well accessible, multi-pin plug connector (for example HTS-plug connector series HE/HB/HN/HA or comparable ones of other manufacturers) to make possible a quick and clear fault diagnosis in the service case and to take off the receiver without an expenditure of assembly.**

The power supply of the receiver is generally effected by the connecting cable.

- In general, an earth lead is required in case the units to be controlled have not previously been operated by radio control. Failing this, the receiver electronic circuit will not receive any power supply. Ensure that the operating voltage of the receiver complies with the electrical specifications of the unit to be controlled. The applicable operating voltage is specified in the supplement.
- Never expose the receiver to a high pressure cleaning jet. This applies to the transmitter also.
- The receiver should always be fixed vertically at the outside panel of the switching cabinet. (The antenna should always reach over the top of the panel.)
- You have to make sure that the antenna is not shielded by metal parts totally or partly.
- Mounting the receiver in a cabine or in a switching cabinet the antenna should be layed with an extension cable to the outside and be attached with the fastening strapping as horizontally as possible with distance to the shielding metal parts.
- In general the antenna should always be mounted in such a way so that the antenna is still visible with each change of position of the transmitter.



Mounting on a tower slewing crane.



Top slewing crane: Mount the antenna with extension cable horizontally.

4. OPERATING THE UNIT

Safety equipment in the NBB-radio remote control:

In the transmitter, this comprises mainly:

- STOP (transmitter ON/OFF) with automatic disconnection of the power supply.
- Automatic zero positioning.

In the receiver:

- Automatic zero setting when switching back on after radio interruption.
- Locking of the radio commands at relay level in the event of a defective STOP circuit.


To ensure fault-free operation, please follow precisely the following rules for operation: The unit to be controlled can only be switched on - it is assumed that the transmitter is ready to operate - when no command unit is actuated. The command necessary to do so is triggered by the key "ON/HORN". This triggers a horn signal in the unit to be controlled. After switch-on of the facility to be controlled, this key is used for repeated emission of the horn signal in accordance with working regulations.

If the NBB radio remote control is not used for a long period, it is urgently recommended - if you use rechargeable batteries - that they should be charged now and again (about every 4 weeks). This prevents deep discharges of the batteries and prolongs their useful life. If you shut down the NBB radio remote control for a long period, we recommend you take the batteries out of the transmitter.

Frequency change Planar-V4:

A manual frequency change isn't necessary. By turning on the receiver locks into the new frequency, which will be shown shortly in the 7- segment functional display. If it's necessary to change the channel, the transmitter has to be turned off and on again.

The selection of the channel happens automatically.



Turn on / Turn off

Turn on: The toggle switch ON/OFF turn to ON, until the red dot flashes.

Turn off: The toggle switch ON/OFF turn shortly to OFF until the red dot doesn't flash anymore.

6. FUNCTION CHECK

To maintain operational safety, a regular function check of the NBB radio remote control is necessary. In single-shift day-to-day operation, we recommend performing this check at least once a week. Checking is possible using the display lights provided on the receiver. To do so, the transmitter must be set to the ready-to-operate state.

First connect just the receiver - the transmitter remains switched off.

- Activate the transmitter by pressing the "STOP" key, resp. the key "START/ ON/ HORN".
- Now check the commands (always start with the lowest stage) and check for correct function of the unit to be controlled.
- Ensure in particular that there is nobody in the danger area. **ACCIDENT RISK!**
- **STOP, check.** Press the STOP key at the transmitter until the switch engages. Then observe if the unit to be controlled is switched off (time to switch off according to the application).

7. RATING PLATES

The rating plates state the type of transmitter or receiver, the factory number, the frequency range and the approval number for non EU countries.

Always state the factory number in all your queries.

Example:

Transmitter Type / Version: Planar-B Factory No.: 999 899 4990 Frequency: 402-470 Mhz	Receiver Type / Version: Compact-V Factory No.: 999 899 4990 Frequency: 402-470 Mhz
--	--

8. MAINTENANCE

Your NBB radio remote control is largely maintenance-free. Nevertheless, please bear in mind the following points:

- The STOP key must be easy to move.
- Remove any leftover building materials!
- During electro-welding work on the unit to be controlled, disconnect the receiver from the current supply! Otherwise there is a risk of damage to the receiver's electronic system!
- Check wear and tear parts like dust shield tops regular!

9. WARRANTY

We grant a function warranty for 12 months after the sale date for all NBB radio remote controls (transmitter, receiver, charger). The warranty covers working time and material used. Shipping costs shall be charged to the customer. The warranty shall not cover: wear and tear parts, relays and batteries. The function warranty shall be invalidated in the case of damage, accident damage, negligence, incorrect use, non-compliance with operating conditions, non-compliance with operating, testing and maintenance instructions, and repairs or unit modifications not authorised by NBB. NBB shall not be liable for indirect damage and reserves the right to decide on repair or replacement.

10. IN CASE OF DEFECTS

Do not attempt to continue working with a defective NBB radio remote control. Even initially minor defects might be the start of a more extensive defect.

Do not try to repair the NBB radio remote control yourself. If there is any fault please contact your dealer or our company.

TECHNICAL DATA



Operating ambient temperature -20 to +70 °C
Insulation class - Protection IP 65

TRANSMITTER

Planar-V4

Transmission frequency range see rating plate

The use of synthesizer technology permits frequencies to be selected in accordance with the appropriate waveband for the country of use.

Low frequency modulation GFSK
Data repetition rate about 15 ms / 60 ms
Baud rate 1200 - 9600 Baud (Bit / sec.)
Range about 100 m
Power input about 60 mA
RF output < 10 mW
Weight (without battery) about 420g
Size (L x W x H) 12,2 x 15,6 x 8,1 cm

Power supply 2 x rechargeable batteries 1,2V AA NiMH
(or 2 x batteries 1,5V - not rechargeable)
Operating duration >30h (2000mA/h NiMH batteries)

RECEIVER

R-6, -10, -18, -CAN, Compact-M, Compact-V

Reception frequency range see rating plate

Data security:

Generates a CRC code with a Hamming distance = 4. Generates a neutral position.

Addressing of each transmitter with its own, unique combination (max. 2^{16} possible combinations).




Security EMERGENCY STOP with self test.

max. switching voltage 250V AC (12V / 24V DC - R-18, R-CAN, Compact-M, Compact-V)
max. switching current 4A AC (3A DC at 12V / 24V - R-18, R-CAN, Compact-M, Compact-V)
max. switching power 1000 VA

	Weight	Size (L x W x H)
R-6 (with cable)	640 g	13,5 x 8,6 x 5,7 cm
R-10 (with cable)	740 g	13,5 x 8,6 x 7,3 cm
R-18, R-CAN	640 g	18 x 9,7 x 4,4 cm
(potted)	800 g	
Compact-M	640 g	18 x 9 x 7 cm
(potted)	800 g	
Compact-V (potted)	1,5 kg	21,5 x 16 x 6,5 cm

CHARGING UNIT


Input 12V/24 V/DC, P=2W
Output 5 V DC $\overline{\overline{=}}$ 320 mA
Weight about 90g
Size (L x W x H) 4,9 x 7,0 x 9,8 cm




No.	Description:	Order-No.:	No.:	Description:	Order-No.:	No.:	Description:	Order-No.:
1	Key switch 0-ON	3.740.1001	13	Rotary switch Gray-Code 12 steps	3.740.1029	25	Toggle switch (Otto) lever lock. MOM-0-ON	3.740.1081
2	Key switch 0-MOM	3.740.1011	14	Rotary switch BCD-Code 16 steps	3.740.1025	26	Piezo Emergency Stop Switch	3.740.5006
3	Toggle switch 0-ON	3.740.1016	15	Potentiometer 5k + Contr. knob ϕ 16	3.980.1156	27	Toggle OTTO switch lever lock. ON-0	3.740.1082
4	Toggle switch MOM-0-MOM	3.740.1017	16	Control knob ϕ 17mm	3.930.1002	28	Potentiometer 4,7k	3.980.1518
5	Toggle switch ON-0-ON	3.740.1018	17	Control knob ϕ 20mm	3.930.1003	29		
6	Toggle switch ON-0-MOM	3.740.1019	18	Control knob ϕ 24mm	3.930.1004	30		
7	Toggle switch lever lock. ON-0-ON	3.740.1020	19	Emergency Stop Switch with key 0-On red	3.740.1000	31		
8	Pushbutton switch APR 0-MOM	3.740.1022	20	Emergency Stop Switch 0-On red	3.740.1014	32		
9	Rotary switch ON-0-ON	3.740.1022	21	Rotary switch Gray-Code 3 steps	3.740.1076	33		
10	Rotary switch Gray-Code 3 steps	3.740.1041	22	Toggle switch 0-MOM	3.740.1043	34		
11	Rotary switch BCD-Code 10 steps	3.740.1026	23	Miniature pushbutton switch 0-MOM	3.740.1030	35		
12	Rotary switch BCD-Code 12 steps	3.740.1027	24	Toggle switch APR lever lock. ON-0	3.740.1045	36		

Serial no.:	Ref.:	9999904790
Model:	Line- Pumps	
Customer:	Schwing Hydraulik	
Date:	04.02.2011	
Name:	P. Heit	
Änderung:	M. Tscholak	
Date:		
Signature stamp:		
Approval:		

TRANSMITTER
Planar V4






TRANSMITTER-CODE



NOTE	RECEIVER POTTED	YES	NO
		X	
Serial no.:	Ref.: 9999904790		
Model:	Line-Pumps		
Customer:	Schwing Hydraulik		
Date:	04.02.2011		
Name:	P. Heit		
Modification:	M. Tscholak		
		RECEIVER Compact M-B	

R-18 CONNECTING PLAN

Serial no.: Ref. : 9999904790	Cable length: ~2.5 m
Model: Line-Pumps	Cable loop-no.: 3.400.7011 (15 x 0,75mm²)
Wiring diagram no.: ---	System-plug-no.: Harting Han 10A (19200101540)*
Producer: Schwing Hydraulik	Indert-no.: Harting Han D 15pol. (09210153001)*
Date: 2011-03-16	*Connector installed by costumer.
Name: M. Tscholak	
Modification:	

RECEIVER	CONTROL CABLE		SYSTEM
Terminal strip no.:	Function:	Wire-No./Pin-No.:	Terminal strip: / or plug socket:
			
1	Power supply 24V DC	1 / B1	
2	Power supply 0V DC	2 / C5	
14	Common	14 / B3	
IN 1			
OUT 1/ SW07	ON/ HORN (momentary) **	13 / B4	
OUT 2/	** To activate the receiver OUT3 + OUT4 must be off.	/	
IN 2			
6	Common	6 / C1	
OUT 3/ SW05	pumping/ Forward (maintained)	5 / C3	
OUT 4/ SW06	suction/ Reverse (maintained)	7 / C4	
IN 3		/	
OUT 5/		/	
OUT 6/		/	
IN 4		/	
OUT 7/		/	
OUT 8/		/	
IN 5		/	
OUT 9/		/	
OUT 10/		/	
IN 6		/	
OUT 11/		/	
OUT 12/		/	
IN 7		/	
OUT 13/		/	
OUT 14		/	
IN 8		/	
OUT 15/		/	
OUT 16/		/	
IN 9		/	
OUT 17/		/	
IN 10		/	
OUT 18/		/	
	Common 1	3 / B1	
	Emergency- stop 1 (Floating contact)	4 / B2	
	Common 2	8 / A1	
	Emergency- stop 2 (Floating contact)	9 / A2	



DATASHEET TRANSMITTER

SERIAL No.: 9999904790

Formular-Nr.: 154_engl

Stand: 01-10/10

NAME: **M. Tscholak**

DATE:

16.03.2011

Transmitter *Planar V4*

	QUANTITY	PART No.:	BOARD TITLE:	NOTE:
FREQUENCY BAND			<i>F- Band</i>	
FM	yes			
Active / Passive	2s			
LBT-Mode	1			
Auto Off	no			
Charger	no			
PROGRAM 1	1 1 1		Firmware Config Interpreter	<i>Forst_V1_1_V_2_4.txt</i> <i>PLV4_4139.scd</i> <i>PLV4_4139.il2</i>
PROGRAM 2			Firmware Config Interpreter	
UPPER PART	1	3.300.1620		black
LOWER PART	1	2.250.1670		black, AA
PART	1	3.300.1110		black
FACE PLATE 1	1			silver, lasered
FACE PLATE 2				
FACE PLATE 3				
BOARD 1	1	2.100.1331	S-SW18A1 V1/1	mainboard
BOARD 2	1	2.100.1330	S-SW08A2 V1/1	adaptor board
BOARD 3	1	2.100.1329	S-AD04A4 V1/1	display board 7-Segment Forst
BOARD 4				
SPECIAL 1				
SPECIAL 2				
SPECIAL 3				
SPECIAL 4				

**DATASHEET RECEIVER**

SERIAL No.: 9999904790

Formular-Nr.: 154_engl

Stand: 01-10/10

NAME:	M. Tscholak	DATE:	16.03.2011
-------	--------------------	-------	-------------------

RECEIVER Compact M- B				
	QUANTITY	PART No.:	BOARD TITLE:	NOTE:
FREQUENCY BAND			F- Band	
FM	yes			
Active / Passive	2s			
RECEIVER POTTED	yes			
PROGRAM 1	1		H86	<i>E_5029.H86</i>
PROGRAM 2			Firmware Config Interpreter	
UPPER PART	1	3.300.1410		black
LOWER PART	1	2.250.1601		black
PART	1	3.300.2621		black
FACE PLATE	1	3.820.1215		silver
HOUSING				
INSERT				
BOARD 1	1	2.100.1198	E-DC02A7 V1/5	mainboard
BOARD 2	1	2.100.1310	A-AD07A1 V1/5	emergency board
BOARD 3	1	2.102.1171	S-EM01A0 V2/4	HF- part: Prog:s_em01a0_rw_v11.afm
BOARD 4				
SPECIAL 1				
SPECIAL 2				
SPECIAL 3	1	3.680.1019		emergency- stop relay with 2 contacts
CABLE	1	3.400.7011		15 x 0,75mm ²
CABLE LENGTH	~2,5m			
SYSTEM PLUG				
INSERT				

Approvals EU countries:

Enclosure:

EC Declaration of Conformity

Obtainable at demand:

M-Zert mbH

Certificate DIN EN ISO 9001:2008 No. 03022

© NBB Controls + Components GmbH
Otto-Hahn-Straße 3-5
DE-75248 Ölbronn-Dürrn
Tel.: 0 72 37 / 9 99 - 0
Fax: 0 72 37 / 9 99 - 1 99
eMail: sales@nbb.de
<http://www.nbb.de>

We reserve the right to alter specifications without notice.



Bedienungsanleitung Planar-V4, R-18, R-CAN, Compact-M, Compact-V
englisch, Teile-Nr. 3.150.1340, Stand 07.11



6 Special equipment

Please note that the possibility to use special equipment depends on the machine model.



6.1 Hydraulic shut-off assembly (98383777)

SCHWING's hydraulic shut-off assemblies (**Fig. 229**) are designed for installation in SCHWING concrete pumping lines.

The shut-off assemblies can be supplied for various:

- Pumping line diameters
- Concrete pressures
- Flanges

Should you have any queries or issues, please contact our customer service department or your SCHWING representative.




Fig. 229

6.1.1 Area of application

Hydraulic shut-off assemblies are required for up-pumping or down-pumping as of approx. 30 m high (deep).

While the pump is interrupted, the closed shut-off assembly prevents, for example:

- During up-pumping (install at the rear of the concrete pump), the concrete column from flowing back into the concrete pump.
- During down-pumping (install to the rear of the line), the concrete column from breaking off.

6.1.2 Safety

Read through these operating instructions carefully before the initial commissioning. Only begin with the work when you have understood everything.

Should you have any doubts or queries, never begin to work!

In case of danger, actuate an EMERGENCY-OFF button on the machine.



Warning!

Malfunctions while pressure cleaning the pumping lines are dangerous!

- Only authorised persons (experts) may operate the shut-off assembly.
- The pumping line must only be opened when pressure free.
- The machine operator is responsible for ensuring that no unauthorised persons access the immediate vicinity of the shut-off assembly or associated control elements.
- Persons not involved must leave the danger area of the shut-off assembly.
- During the cleaning process, no one must be at the end of the line in the area of the concrete output.
- Make sure to read (**chap. 3.18**).
- Do not use the shut-off assembly under any circumstances to push out clogs!

**Warning!****Danger of crushing and injury!**

Do NOT reach into the openings of the shut-off assembly and the pumping line and do not hold any objects inside.

Switch off the drive motor of the machine prior to opening the shut-off assembly and secure the machine from unintentional switching on.

During the spraying process with the water hose, only direct the water spray into the openings, do not put the hose nozzle in.





Fig. 230 Schematic drawing of shut-off assembly

6.1.3 Structure of the system

1	Junction tube
2	Housing
3	"Retract" junction = gate valve "open"
4	"Extend" junction = gate valve "closed"
5	Visual display of the switch position
6	Cone-type lubricating nipple
7	* optional proximity switch

* = required for operation from a control station



6.1.4 Installation

The shut-off assembly is installed in the pumping line using two couplings.



Warning!

The use and insertion of materials other than those supplied by Schwing result in the loss of operational safety and thus automatically in the loss of operational approval!

Only use original SCHWING couplings and spare parts.

6.1.5 Drive

Hydraulic shut-off assemblies can be connected to the concrete pump's hydraulic system and actuated via a separate aggregate or hand pump.



Warning!

Do NOT operate the shut-off assembly when it is not visible.

If required, a second person should be present.

6.1.6 Maintenance

Depending on the operating conditions, the shut-off assembly must be lubricated at least once a week with grease (grease nipple). As the lubrication requirement increases with progressive wear, the lubricating intervals must be shortened accordingly.

6.1.7 Technical data

Closing volume:	0.63 l
Opening volume:	0.38 l
Stroke:	125 mm
Piston diameter:	80 mm
Piston rod diameter:	50 mm
P max. hydr.:	200 bar

6.2 Central lubricating system

SCHWING machines can be equipped as special equipment with a central lubrication system.

The electrically powered piston pump, reservoir and electronic control part are combined into a single unit (**Fig. 231**). This unit supplies the lubrication points of the machine via distributors and lines (**Fig. 232**).

Any other use is deemed improper.

The amount of grease and lubricating intervals are set at the factory.

On truck-mounted concrete pumps, the settings can only be implemented on the control part of the piston pump. The lubrication only occurs during pumping operations (pump kit ON).

For stationary machines (SP 3800/4800), the settings can be configured on the machine control system and on the display of the piston pump.



Information

Please note that the settings in the machine control system and those on the electronic control unit of the piston pump interact.

Should an adjustment to special operating conditions appear necessary, please contact the SCHWING customer service for the purpose of reprogramming.



Fig. 231




Fig. 232 Example of a progressive system

6.2.1 Safety



Information

Supply documentation.

In addition to these operating instructions, the supplier documentation and any other legal provisions and related regulations on accident prevention and environmental protection must be observed and applied.

6.2.2 Instructions for filling with lubricant

Only use clean lubricant with a suitable filling device. Contaminated lubricants can lead to system faults.

- Use a lubricating grease as indicated in our lubricant recommendations (**chap. 4.3**):
(KP 2 K according to DIN 51502 without solid lubricant, NLGI class 2).

The central lubrication system can operate at up to approx. $-25\text{ }^{\circ}\text{C}$ when using the lubricating grease prescribed for our machines.

6.2.2.1 Filling with lubricant

The machine is filled with lubricant via the cone-type lubricating nipple DIN 71412-AM10x1 (1) (**Fig. 233**) using a conventional grease gun. The cone-type lubricating nipple can be repositioned to position (2) (**Fig. 233**), e.g. in order to provide improved access.

The filling of the reservoir must be carried out correctly (observe the filling level monitoring).



Danger!

Risk of explosion due to an explosive atmosphere!

Filling via the "reservoir lid" is not permitted.

6.2.2.2 Filling level check on the pump unit

The transparent lubricant reservoir enables a visual filling level check. This check must be carried out regularly for safety reasons. If the reservoir has been drained to below the "min" mark, the entire system must be vented.



Fig. 233

6.2.2.3 Vent system

- Fill reservoir with lubricant
- Remove the main lines (1) (**Fig. 235**) from the male connector (2) (**Fig. 235**) on the pump elements (3) (**Fig. 235**)
- Let the pump run until lubricant emerges from the male connector on the pump elements without any air bubbles
- Reattach the main lines
- Let the pump run until grease emerges from all lubrication points.

Furthermore, “emergency grease nipples” (4) (**Fig. 235**) are available on the male connectors of the pump elements.

Through these, the separate lubricant circuits of the lubrication system can be amply supplied with lubricant manually via hand-operated grease guns in the case of power failures or pump faults.

6.2.2.4 Pressure relief valve

A pressure relief valve (5) (**Fig. 236**) protects the entire lubrication system against excessive system pressures. It is mounted directly on the pump element.

The configured opening pressure is 300 or 200 bar, depending on the valve.

If a clogged distributor or lubrication point causes an operating pressure of over 300 or 200 bar, the valve opens and grease will visibly emerge from the escape point (6) (**Fig. 236**).

At the same time this also acts as an optical system monitoring.

As such, the pump unit is protected against damage.




Fig. 234 Arrangement of the pump elements




Fig. 235

Pump element (3) with male connector (2) and emergency grease nipple (4)




Fig. 236

Pressure relief valve with discharge opening









6.2.3 Configuring the system

The pump units of the KFGS series are equipped with integrated control part type IG502-2-I with an operating display (**Fig. 237**). Operating parameters such as pause times (Timer) and pump runtimes (Contact) can be parameterised via the control part.

The display and operating unit is protected from spray water and mechanical damage by a transparent plastic cover. For programming, the cover must be removed and then reinstalled.



Fig. 237 Operating display

Display elements and controls on the KFGS operating display (Fig. 237)		
Depiction	Designation	Function of
	Three-digit LED display	Values and operating status
	PAUSE LED	Pause time
	CONTACT LED	Contact time display (pumping operation)
	1 = CS LED 2 = PS LED	CS=Cycle Switch: monitors the function with an external cycle switch PS=Pressure Switch: monitors the function with an external pressure switch
	FAULT LED	Fault message
	UP or DOWN button	Switch on display Display values and parameters Set values and parameters
	SET button	Switch between programming and display mode Confirm values
	DK button	Trigger in-between lubrication Erase fault message

As lubrication of the lubrication points is only necessary at given intervals, the lubrication cycle or lubrication procedure is divided into a pump runtime and a pause time. A lubrication cycle always begins with a pump runtime.



After the pump runtime, the lubrication cycle is interrupted and then resumed after the configured pause time.

That is, a lubrication cycle always starts with the "residual lubrication time" or "residual pause time".

Even a power failure cannot erase the integrated data memory.

6.2.3.1 Pump runtime

The pump runtime corresponds to the time in which the pump conveys the lubricant.

In the case of a division into lubrication segments, one of the segment valves will be opened at the same time and closed again at the end of the pump runtime.

The duration of the pump runtime can be configured as a time value in hours, minutes and seconds.

6.2.3.2 Pause time

In the pause time, also referred to just as pause, the pump rests or in the case of a division into lubrication segments, the valve for the affected lubrication segment is closed.

The duration of the pause time can be configured.

In automatic operating mode, the pause time is determined by specifying a time value (Pause timer).

When configuring the lubrication scenario, the pause time thus corresponds to a delay time, by which the valves of the individual lubrication segments are opened successively once a lubrication cycle has been started. This therefore prevents all valves from opening at the same time.

6.2.3.3 Intermediate lubrication

If an additional lubrication appears to be necessary under certain operating conditions, you can trigger an intermediate lubrication by pressing the (1) (**Fig. 238**) button during a pause.

The piston pump runs for 4 minutes after being pressed once. You can actuate the button again after 4 minutes of runtime.

The pause time is set to "0" after the intermediate lubrication. The lubrication then continues to run as configured.



Fig. 238

6.2.4 Checking the system

- Check the system of lines (visual inspection) daily for leaks and external damages
- Check the supplied bearing points (visual inspection) daily

There must be clearly visible traces of lubricant.

- If any faults are detected during the check, have SCHWING's customer service repair the system immediately in order to prevent any consequential damages caused by a lack of lubrication.



Attention!

The drive line bearings of the concrete pump cannot be connected to the central greasing.

These lubrication points must be supplied "manually" according to the maintenance schedule.

If some lubrication points were not connected to the central greasing at customer request, they must also be lubricated using a grease gun.

6.3 Remote pressure cut-off ("DAF")




Fig. 239

6.3.1 Intended use.

The "DAF" accessory can be used to adjust the concrete pressure of the sludge pump at any time to the situation at hand, thus ensuring that no critical concrete pressure builds up in the pumping pipes connected to the sludge pump that could exceed the bursting pressure of your tubes and lines.

The "DAF" can also be used in other use cases to protect equipment connected to the sludge pump, such as concrete pumping hoses.

6.3.2 Improper use. Foreseeable misuse.

Any type of use other than or beyond that described in "**Intended use.**" is considered improper.

If the "DAF" is not operated as intended, SCHWING shall not be held liable for any resulting damage to the machine, other assets or private goods, or for consequential damages in the event of injury or death of persons or animals.

6.3.3 Delivery condition

When delivered, the ball valve (1) (**Fig. 239**) is situated in an upright position (=max. concrete pressure).

The hand-wheel (2) (**Fig. 242**) is locked and the key is located on the right-hand side inside the control cabinet.

Always store the key in a secure location in order to prevent unauthorised adjustments.

6.3.4 Step-by-step instructions

Proceed as follows in order to use the "DAF".

Situation:

You have acquainted yourself with the prevailing conditions on the jobsite beforehand and need to configure the "DAF" accordingly.

Adjust the pressure of your concrete pump in accordance with the requirements:

1. First proceed as described for the pressure control (in the "Pressure control" chapter of your operating instructions).
2. Move both ball valves (1+2) (**Fig. 240**) on the pump kit into the "pressure control" position (**Fig. 241**) so that the pistons come to a standstill.



Attention!

Material damage may be caused by switching during pumping operations!

Only change the position of the ball valve (1) (**Fig. 242**) if your concrete pump is set to the minimum delivery rate!

3. Move the ball valve (1) (**Fig. 242**) into the "I variable concrete pressure" position.
4. Start the concrete pump as per usual.
5. Now observe the pressure gauge on your "DAF" (4) (**Fig. 242**).
6. Unlock the hand-wheel using the key (3) (**Fig. 242**).
7. If the hydraulic pressure on the "DAF's" pressure gauge remains constant, the reduced hydraulic pressure that was last configured has been reached.
8. Now set the new maximum pressure using the hand-wheel (2) (**Fig. 239**).
 - a) To do this, please refer to the sign on the "DAF" block containing the required conversion factor for the respective pump (e.g., P2023-110/75 RB).
[$P_{\text{concrete}} = P_{\text{hydraulic}} \times 0.25$]
 - b) In the example, the value displayed on the "DAF's" pressure gauge has to be multiplied by 0.25 in order to obtain the desired concrete pressure.
3. After configuring the pressure, lock the hand-wheel again using the key / (secure it against being changed without authorisation) and remove the key.
4. Move the ball valves on the pump kit of your truck-mounted concrete pump back to the "operating position". To do this, carefully follow the descriptions in the "Pressure control" chapter of your operating instructions.



If you would like to switch your pump back to maximum pressure, move the ball valve (1) (Fig. 242) on the "DAF" back to the "II max. concrete pressure" position.




Fig. 240




Fig. 241




Fig. 242

7 Appendix





7.1 Information service

Are you already using our information service? - 5 minutes that pay off!

Dear Customer,

With the purchase of your SCHWING machine, you have acquired a high quality product.

Of course, we are constantly working to improve our products and would like to inform you when new findings become available. This service is completely free of charge, because we highly value customer support and product monitoring!

Our offer also expressly applies when the SCHWING machine was obtained second-hand!

In order to send you our information, we need your address.

Please complete the following questionnaire and send it to

SCHWING GmbH

Service

PO Box 20 03 62

D-44647 Herne

Of course you can also fax us this page or reply by email:

Fax: +49 (0)2325 74674

Email: service@schwing.de

We look forward to your response!

Please complete in block letters:

Customer no.:	
Address:	
Country:	
Contact person:	
Telephone:	
Fax:	
Email:	
Machine type:	
Machine no.:	



7.2 Always nearby



HERNE

SCHWING GmbH

Service Centre
Heerstraße 9-27
44653 Herne
Telephone: 02325/9870
ET Sales:
02325/987-352
Customer Service:
02325/987-231/232
Fax; 02325/987-470
Email: parts@schwing.de
Contact: Mr Beiersdorf

HAMBURG

SCHWING Stetter
Service Branch
Gewerbegebiet Ost
Theodor-Storm-Straße 9
25451 Quickborn/Holstein
Telephone: 04106/72321
Fax; 04106/71810

Email: Hamburg@schwing.de
Contact: Mr Hermann

KASSEL

SCHWING Stetter
Service Branch
Crumbacher Straße 56
34277 Fuldabrück
Telephone: 0561/581561
Fax; 0561/582963

Email: Kassel@schwing.de
Contact: Mr Döring

BERLIN

SCHWING Stetter
Service Support Centre
Gewerbegebiet Neu Boston
Kurzer Weg 7
15859 Storkow
Telephone: 033678/61308
033678/62015
Fax; 033678/62015
Email: Berlin@schwing.de
Contact: Mr Rahming

GOTHA

Eberhard Becker & Partner GmbH
Dr.-Troch-Straße 15
99867 Gotha
Telephone: 03621/404444
03621/404445
Fax; 03621/404446
Email: Gotha@schwing.de
Contact: Mr Becker

DRESDEN

Eberhard Becker & Partner GmbH

Hamburger Ring 13a

01665 Klipphausen

Telephone: 035204/47888

Fax; 035204/47887

Email: Dresden@schwing.de

Contact: Mr Rahming

NUREMBERG

SCHWING Stetter

Service Branch

Gießener Straße 22

90427 Nuremberg

Telephone: 0911/302875

Fax; 0911/306455

Email: Nuernberg@schwing.de

Contact: Mr Wolfram

MEMMINGEN

SCHWING Stetter

Service Centre

Dr.-Karl-Lenz-Straße 70

87700 Memmingen

Telephone: 08331/78-0

ET Sales: 08331/78-249

Customer Service: 08331/78-231

Fax; 08331/78-402

Email: info@stetter.de

LORSCH

SCHWING Stetter

Service Branch

In der Wolfshecke 5

64653 Lorsch

Telephone: 06251/9648-0

Fax; 06251/9648-20

Email: Lorsch@schwing.de

Contact: Mr Rothermel

STUTTGART

SCHWING Stetter

Service Support Centre

Telephone: 0173/8858288

Fax; 06251/964820

Email: Stuttgart@schwing.de

Contact: Mr Rothhermel

MUNICH

SCHWING Stetter

Service Support Centre

Oscar-von-Miller-Ring 5

85254 Sulzemoos

Telephone: 0911/302875

Fax; 0911/306455



Email: nuernberg@schwing.de

Contact: Mr Wolfram



7.3 Always Ready

	Schwing/Stetter GmbH Heerstr. 9 - 27 D - 44653 Herne	0049 - 2325 - 987 0 0049 - 2325 - 72922	info@schwing.de
Germany			
	Schwing Hydraulik-Elektronik GmbH Dorstener Str. 428 D - 44653 Herne	0049 - 2325 - 987 0 0049 - 2325 - 50568	info@schwing.de
Germany			
	Stetter GmbH Dr. Karl-Lenz-Str. 70 D - 87700 Memmingen	0049 - 8331 - 78 0 0049 - 8331 - 78 275	info@stetter.de
Germany			
	Memo Industrial Planning Ltd. El Nozha Street Nasr City P. O. Box 4525 11717 Cairo	0020 - 2 - 2419 2989 0020 - 2 - 2419 2986	memo@memoindustrial.com
Egypt			
	Schwing/Stetter Cité des PTT Rue C N° 55A Vallée de MAZA - Hydra	00213 - 21 - 60 82 63 00213 - 21 - 60 55 66	
People's Democratic Republic of Algeria			
	Cimertex S. A. Rua do Abade Mondego, 165 4455 - 489 Perafita Matosinhos	00351 - 220 - 912 600 00351 - 220 - 912 665	cimertex@cimertex.pt
Republic of Angola			
	Repas S/A Reconquista 336 piso 12 OF. "Y" 1335 Buenos Aires	0054 - 1 - 14393 9243 0054 - 1 - 14394 4965	secretaria@repas.co m.ar
Republic of Argentina			
	Repas S/A Ruta Panamericana Col. Oeste Km 28,900 1611 Don Torcuato Pcia. Buenos Aires	0054 - 1 - 14846- 1073 0054 - 1 - 14748- 4263	pschulzen@repas.co m.ar
Republic of Argentina			

	Schwing Australia Pty. Ltd. 77 Avoca Drive Green Point NSW 2251	0061 - 2 - 4369 6884 0061 - 2 - 4369 6774	contact@schwing.com.au
	Nass Commercial Commercial Division P.O. Box 669 Manama	00973 - 17 703 123 00973 - 17703090	info@nasscommercial.com www.nassgroup.com



	MRC Betontechnik Oost Jachtpark 14 9100 Sint Niklaas	0032 - 3766 7666 0032 - 3766 2958	reginald.judy@skynet.be
Kingdom of Belgium			
	n.v. auto- Construct Reutelhoekstraat 1 a 8980 Zonnebeke	0032 - 57466939 0032 - 57466231	
Kingdom of Belgium			
	Schwing Equipamentos Ind. Ltda. Rod. Fernão Dias, Km 56 Bairro terra Preta	0055 - 11 - 4486 8500 0055 - 11 - 4486 1344	info@schwing-stetter.com.br
Federal Republic of Brazil			
	Wassilev BM Eood Br. Bakston-Str. 134 4004 Plovdiv	00359 - 32 - 692727 00359 - 32 - 698 675	mwco@plov.omega.bg
Republic of Bulgaria			
	Emaresa Ingenieros y Representaciones S.A. Santa Adela 9901 Maipu Santiago do Chile	0056 - 2 - 4602020 0056 - 2 - 460 2025	evbischho@emaresa.cl
Republic of Chile			
	Imocom De Costa Rica, S.A. De Ucimed - Los Anonos 500 metros oeste Entrada Barrio Holanda 100 metros, mana derecha casa No. 14 San Jose 1000	00506 - 291-5212 o. 5213 00506 - 291-5214	imocomcostarica@ice.co.cr
Republic of Costa Rica			
	Bekoteknik Vaerkstedsvej 23 4600 Koge	0045 - 56 - 636 633 0045 - 56 - 636 368	
Kingdom of Denmark			
	ABS Pumper A/S Gydevang 30 DK 3450 Allerod	0045 - 48 - 17 11 10 0045 - 48 - 17 19 11	abspumper@abspumper.dk
Kingdom of Denmark			
	Imocom Ecuatoriana Cia. Ltd. Corea 318 y Nunez de Vela Edificio Karolina 2000 Planta baja Quito	00593 - 2 - 2435- 678 00593 - 2 - 2447 664	imocom@imocom.com
Republic of Ecuador			

	Imocom Ecuatoriana Cia. Ltda. Av. Francisco de Orellana 2001 Edf. AS-1, Cdla Iteel Detras dicentro Guayaquil Guayaquil	00593 - 4 - 423- 2470 00593 - 4 - 423- 1595	imocomg@gye.satnet.net
	CFCI Technique 6, Rue Thomas Edison Zone 4 B.P. 1844 Abidjan Elfenbeinküste	00225 - 354 034	
	Mytec Oy Rahkontie 21 85140 TYNKÄ Finland	00358 - 207528240 00358 - 207528249	mikko.ylitalo@mytec.fi
	Tamflow OY Kalevanpuistotie 7 33500 Tampere Finland	00358 - 3 - 31 38 44 00 00358 - 3 - 31 38 44 44	tamflow@yritys.tpo.fi
	Schwing / Stetter S.A. 12, Rue des Tuileries B.P.44 67460 Souffelweyersheim	0033 - 3 - 8881 5151 0033 - 3 - 8833 9955	DI@schwing-stetter.fr
	Impasse du Vexin 78250 Hardricourt France	0033-1 - 3492 9505 0033-1 - 3474 7260	
	Schwing/Stetter Hellas S. A. G. Margaritis - G. Karvounis Leoforos Athinon 204 GR-10442 Athens	0030 - 210 - 5155 505 0030 - 210 - 5150 034	
	Schwing/Stetter (UK) Ltd Unit 11, Perivale Ind. Estate Horsenden Lane South Greenford Middlesex UB6 7RL	0044 - 20 - 8997 1515 0044 - 20 - 8998 3517	hughbyrne@burlington-engineers.co.uk



Republic of Guatemala

Imocom Centroamericana S/

A de CA

8a, Calle 3-142, Zona 10

Apartado Postal 639 A

Guatemala City

00502 - 2 - 334







6148

00502 - 2 - 360

9677

imocom@infovia.co

m.gt

	Ekpac Equipment Limited 255 Gloucester Road 2803 Sino Plaza Causeway Bay Hong Kong	00852 - 2555 5555 00852 - 2873 6230	www.ekpac.com
	C. Crossfield & Co. Ltd. Room 1102 - 1112 Corporation Square 8 Lam Lok Street Kowloon Bay/Kowloon	00852 - 2753 8500 00852 - 2756 0700	scanlee@ccrossfield.com.hk
	Schwing/Stetter (India) PVT. Ltd. F-71 + 72, SIPCOT Industrial Park Irungattukottai Sriperumpudur Taluk Kancheepuram District Tamil Nadu 602 105	0091 - 44 - 371 78 100 0091 - 44 - 271 56 539	info@schwingstetterindia.com
	Schwing/Stetter (India) PVT. Ltd. 620 / 621, Nirmal Lifestyle Corporate Centre 6th Floor, LBS Marg Mulund - (WEST) Mumbai - 400 080	0091 - 22 - 256 24862 - /863 0091 - 22 - 256 24865 / 6	\$SSIPL-Mumbai\$@Schwing.dia.com
	Schwing/Stetter (India) PVT. Ltd. 19, Okhla Industrial Estate Phase III New Delhi 110 020	0091 - 11 - 4290 3000 0091 - 11 - 4290 3030	SSIPL-Newdelhi@schwingstetterindia.com
	PT. Cahaya Indotama Engineering JALAN JABABEKA 5 BLOK F NO. 4 CIKARANG, BEKASI 17550	0062 - 21 - 8983 3124 & 8983 3125 0062 - 21- 8981 1537	hardikang@yahoo.com



Republic of Iran

Schwing Stetter Pars
Hamgam
Hydraulic Robot Co.
No. 97 Karoon Ave next to
Tolid St Emam Khomeyni
Blvd
Robot Karim Saveh Road
Tehran

+49 172 - 150-4648

szaidi@schwingstetterpa
rs.de











Ireland

Harris Assemblers
Naas Road
P. O. Box 3960
Dublin 12

00353 - 1 - 4194
500

00353 - 1 - 4602
278

John.Davitt@hino.ie

	Thor Ltd. P.O. Box 1194 Reykjavik	00354 - 681 500	
Republic of Iceland			
	M. Bar Maintenance Ltd. P.O. Box 3055 20 Harduf Hanechalim Street 38900 Caesarea	00972 - 4 - 6378595 00972 - 4 - 6378667	info@mbar.co.il
Israel			
	Farradj & Co. P. O. Box 974 Jabal El Weibdeh Amman 11118 Jordan	00962 - 6 - 464 3800 o. 3801 o. 2900 00962 - 6 - 464 3901	k.abujaber@ abujaber-group.com
al-Mamlaka al-Urduniyya al-Ha-schimiyya			
	Gecolsa Avd. Amèricas No. 42A - 21 Bogotá	0057 - 1 - 405 5554 or 405 5544 0057 - 1 - 268 4902	cesar_palomino@geco lsa. com.co
Republic of Colombia			
	ENC., Ltd. 4 floor, yuhan (old) B/D # 49-6 Daebang-Dong, Dongjak-Gu Seoul	0082 - 2 - 8282 - 119 0082 - 2 - 8282 - 125	encltd@unitel.co.kr
Daehan Minguk			
	Zupanac/Stepinac GmbH Domoviceva 4 10255 Gornji Stupnik Zagreb	003851 - 6588 568 003851 - 6588 568	hrvoje.zupanac@zg.hi net.hr
Republic of Croatia			
	Equipment Company P.O. Box 192 99, Shuwaikh Industrial Area Block No. 2, Street No. 12 13002 Kuwait/Safat	00965 - 1802440	agm@equipcokuwait.c om www.equipcokuwait.c om
Daulat al-Kuwait			
	Al-Khonaini al-Katami Trading & Contracting Co. P.O. Box 593 Safat Kuwait	00965 - 483 1955 00965 - 484 2986	
Daulat al-Kuwait			
	Baladi Freres S.A.L. P.O. Box 90-1191 Jdeidet El Metn Metn 1202 2090	00961 - 1 - 873 992 o. 894 841 00961 - 1 - 884 010	mail@baladifreres.co m
Lebanon			



Libya

Mediterranean Engineering
& Maintenance Operation

00218 - 92501 3310

[memolibya@moussa.n](mailto:memolibya@moussa.net)

[et](mailto:memolibya@moussa.net)










00218 - 21 - 480

Erabi Compound, Office No.
60

6473









P.O. Box 83993

Tripoli

	Comat S.A. Zone Industrielle 10, Rue de bruyeres 1274 Howald	00352 - 496 121 00352 - 402 274	
Grand Duchy of Luxembourg			
	UMW Equipment Sdn Bhd Jalan Utas 15/7 P.O. Box 7052 40915 Shah Alam, Sengalor Darul Ehsan	0060 - 3 - 5519 1911 0060 - 3 - 5510 5517	
Malaysia			
	Game Maroc 148-150, Bd. Emile-Zola MA-21700 Casablanca	00212 - 2 - 248 660 00212 - 2 - 245 442	
Morocco			
	Imocom de Mexico S/A de CV Av. Presidente Juárez No. 2032 Col. La Loma Tlalnepantla, Edo. de Mexico 54000 México	0052 - 55 - 9114 - 3918 0052 - 55 - 9114 - 3930	imocom@imocom.com.mx
United Mexican States			
	Imocom de Mexico S/A de CA Av. Afonso Reyes 1760 Fracc. Bernado Reyes Monterrey, N.L.	0052 - 8 - 311 0411 0052 - 8 - 311 0911	
United Mexican States			
	Schwing/Stetter B.V. Bliet 15 (Dombusch 1) NL-4941 SG Raamsdonksveer	0031 - 162 - 518 882 0031 - 162 - 518 699	
The Netherlands			
	Axflow B.V. De Steiger 30 NL-1351 AB Almere	0031 - 365 - 381 211 0031 - 365 - 314 004	
The Netherlands			
	B M E Baumaschinen & Ersatzteilhandels GmbH Flischstraße 53 60388 Frankfurt	0 69 - 4 20 97 30 0 69 - 4 20 37 60	
Federal Republic of Nigeria			
	Alpha Maskin AS PO Box 56 N - 1901 Fetsund	0047 - 63 - 88 78 70 0047 - 63 - 88 78 71	bjorn@alphamaskin.no
Kingdom of Norway			



	ABS Pumper A/S	0047 - 6 - 754 4760	
	PO Box 473		
	Sandvika	0047 - 6 - 754 3848	
Kingdom of Norway			
	AL Fairuz Trading & Cont. Co.	00968 - 2456 1399	info@alfairuzoman.co
	Wadi Adal - Al Amerat Road		m
	P.O. Box 330, Muscat		
Sultanate of Oman	Postal Code - 100		www.alfairuzoman.co
			m

	Schwing/Stetter Baumachinen Ges.m.b.H Heizwerkstraße 6 1230 Vienna	0043 - 16 16 73 13 0043 - 16 16 70 66	
Federal Republic of Austria			
	Schwing GmbH Friedrich-Wilh. Schwing Str. 1 9431 St. Stefan Lavanttal	0043 - 43 52 28 12 0043 - 43 52 29 53	
Federal Republic of Austria			
	Gordon Ingenieros Maquinaria S.A. A. Franco 282 Urb. Chama Lima 33	0051 - 1- 448 6612 0051 - 1 - 448 3725	gordonsa@amauta.rcp.net.pe
Republic of Peru			
			
Republic of Poland			
	Edificio Vecofabril Divisao Equibetão Estrada da Paiã 1679-007 Pontinha	+351 (21) 478 8500	pedro.f.maia@equibetao.pt
Republic of Portugal			
	Hill Construcccion Montehiedra Cinema Bldg. Suite 201 (Altos Banco Bilbao Vicaya) Montehiedra Town Center 9410 Los Romeros, AV San Juan	001 - 787 -287 3200 001 - 787 - 287 3204	
Commonwealth of Puerto Rico			
	Quatar Tractor & Equipment Co. P.O. Box 5257 Doha	00974 - 44602946	talibgrp@qatar.net.qa
State of Qatar			
	Kreis Construct 7, I.C. Bratianu Str. Otopeni 075100 ILFOV	0040 - 21 - 350 20 56 o.57 o. 58 0040 - 21 - 350 20 53 o. 55	www.talebgroup.com guranco@rdslink.ro
Romania			
	Puschkiner Baumaschinenwerk Puschkiner Kreis Ul.Novoderevenskaya 17 196 608 St. Petersburg	007 - 812 - 476 2411 007 - 812 - 470 1951	pmz@mail.wplus.net
Federation of Russia			



	Federation of Russia	Schwing/Stetter Krasnopresnenskaja Naberezhnaja 12 Entry 6 - Apartment 1412 123610 Moscow	007 - 495 - 258 1412 007 - 495 - 258 2092	Stetter@datarecovery.ru
	Saudi Arabia	Zahid Tractor Co. P.O. Box 1588 Jeddah 12441	00966 - (0) 2 6209173	info@zahid.com
	Saudi Arabia	Bakheet Co. for Machinery P.O. Box 6101 Madina Road, Kilo 9 Jeddah 21442	00966 - (0) 2 691 0550	inquirejd@bakheet.com.sa
				www.bakheet.com.sa
	Kingdom of Sweden	Bekoteknik Sverige AB Möbelgatan 4 43133 Mölndal	0046 - 31 - 30 11 241	
	Kingdom of Sweden	MAF Sweden AB E.A. Rosengrem gata 27 S-42131 V. Frölunda	0046 - 31 - 30 11 248 0046 - 31 - 45 27 40 0046 - 31 - 49 76 81	
	Swiss Confederation	Avesco AG Hasenmatt Str. 2 CH-4901 Langenthal	0041 - 62 - 915 80 80	Lukas.Schreiber@avesco.ch
	Swiss Confederation	Ingtec AG PO Box 2 16 Unterfortstraße CH-4313 Möhlin	0041 - 62 - 915 81 35 0041 - 61 - 8 55 51 51 0041 - 61 - 8 55 30 31	
	Republic of Serbia	Magni-Baza d.o.o. Ustanicka 128 A, V sprat 11000 Belgrade Serbia	0038 - 11 - 13474183 0038 - 11 - 13474182	Robert.mecava@magnibaza.com
	Republic of Singapore	UMW Equipment & Engineering Pte Ltd. 108 International Road Singapore 629 173	0065 - 6265 3155 0065 - 6265 8494	richard.ho.kt@umweepl.com.sg



Kingdom of Spain

Schwing/Stetter Iberica S. L.	0034 - 91 - 6162	cgrohmann@schwing.
C.I.F.: B-84832997	700	es
C/Nardos, nº 15, Polígono		
Industrial El Molino	0034 - 91 - 6162	
28970 Humanes de Madrid	753	



	TFM Industries 411 Industry Road Clayville Ext 4 P.O. Box 1200 Olifantsfontein	0027 - 11 - 316 4161 0027 - 11 - 316 4786	allanpl@tfm.co.za
Republic of South Africa			
	Said Kourabi & Co. P.O. Box 2966 63, Jadet Hafez Ibrahim Al Shalan Str. Damascus	00963 - 11 - 333 65 62 00963 - 11 - 333 79 93	mail@kourabi.com
Syria			
	Shenger Corporation G 21 Fl. No. 98, Hsin-Tai-Wu Rd. Section 1, Hsi-Chih Taipei Hsien	00886 - 2 - 770 88168 00886 - 2 - 770 88198	shenger@shenger.com .tw
Taiwan			
	C & C Corporation Ltd. 495 Krungthep Kreetha Road Huamark. Bangapi Bangkok 10240	0066 - 2 - 7317364 - 73 0066 - 2 - 7316824	
Kingdom of Thailand			
	Schwing/Stetter Ostrava s.r.o. Moravska 1215/6 CZ-70030 Ostrava-Hrabuvka	00420 - 596 - 746 780 - 2 00420 - 596 - 746 783	servis@schwing.cz
Czech Republic			
	Alfatek Co. Ltd Ferhatpasa Mah., Akdeniz CAD. G-63 SK., No 4 34888 Samandira - Istanbul	0090 - 216 - 660 09 00 0090 - 216 - 660 09 09	c.simsek@alfatekturk.com
Republic of Turkey			
	Construction Machinery Ltd. 54 a, Petropavlovskaya Str. 04086 Kiev	00380 - 44 - 467 2601 o. 467 2602 00380 - 44 - 467 2607	kiev@construction.com.ua
Ukraine			
	Schwing America, Inc. 5900 Centerville Road White Bear Minnesota 55127	001 - 651 - 4 29 09 99 001 - 651 - 4 29 34 64	
United States of America			

	Inversiones Resansil, CA 4a. Tranv. De Montecristo, Edif.	0058 - 2 - 12237 7726	resansil@cantv.net
Bolivarian Republic of Venezuela	Bancaracas, Piso 2, Oficina 2, Caracas 1071	0058 - 2 - 12237 9515	
	Schwing GmbH-Dubai Branch Dubai Investment Park European Business Centre 3rd Floor, Office #326 P.O. Box 487432 Jebel Ali	00971 - 4 - 88 55 145 00971 - 50 - 298 3203 00971 - 4 - 88 55 146	OBisada@Stetter.de H. Shukoor
U.A.E.			



	Construction Machinery Center Co. P.O. Box 5261 Deira Dubai	00971 - 4 - 2858959	info@cmcgulf.com www.cmcgulf.com
U.A.E.			
	Inma - The Gulf Development & Construction Co. P.O. Box 4560 Dubai	0097 - 14 - 2857 272 0097 - 14 - 2857 512	
U.A.E.			
	GREEN INDOCHINA INVESTMENT & COMMERCIAL CORP. No. 14 lot 10B, Trung yen New Residential Area Trung Hoa, Cau giay Hanoi	0084 - 4 - 3783 4234 0084 - 4 - 3783 4256	ncamlinh@yahoo.com. vn
Vietnam			
	Schwing Shanghai Machinery Co.Ltd. 5 Xin Xiao Road Xin Qiao Industrial Zone Song Jiang Shanghai 201 602	0086 - 21 - 5764 5855 0086 - 21 - 5764 5577	
Republic of China			
	Mugahed Trading Company LTD. P. O. Box 837 Sana'a Republic of Yemen	00967 - 1447 961-2 00967 - 1447 963	malik@y.net.ye
Yemen			
	Uniplant Ltd. P.O. Box 12516 182, Limassol Avenue CY- 2250 Latsia	00357 - 2 - 488777 00357 - 2 - 488885	sales@uniplant.com
Cyprus			



7.4 VDMA safety manual

This chapter serves as the safety manual and contains basic safety instructions regarding the operation of pumping, spraying and spreading machinery for concrete.

The safety manual is prepared jointly by leading manufacturers of concrete pumping and spreading machines under the auspices of the VDMA (Verband Deutscher Maschinen- und Anlagenbau/Mechanical Engineering Industry Association). It is applicable to our machines in full.

For this reason, the safety manual has a chapter of its own and separate page numbers.

Specific warnings can always be found before each description of a dangerous activity.

Safety Manual

Concrete delivery and placing machines



Imprint

Edition 01/2018 Rev16 EN

Published by:

Verband Deutscher Maschinen- und
Anlagenbau e. V. (VDMA)
Bau- und Baustoffmaschinen
Lyoner Straße 18
60528 Frankfurt

Telefon +49 69 6603-1262

Fax +49 69 6603-2262

E-Mail bub@vdma.org

Internet bub.vdma.org

This safety manual was produced with
the co-operation of the following com-
panies:

Putzmeister Concrete Pumps GmbH
Max-Eyth-Straße 10
72631 Aichtal

Schwing GmbH
Heerstraße 9-27
44653 Herne

Liebherr-Betonpumpen GmbH
Lessingstraße 4
89231 Neu-Ulm

1.—
2.—
3.—
...

Table of contents

	Foreword	7
1	Terms, definitions, requirements	9
1.1	Definition of terms	11
1.1.1	Machine	11
1.1.2	Concrete pump	11
1.1.3	Arm assembly	11
1.1.4	Placing boom	11
1.1.5	Base structure	11
1.1.6	Truck mixer	12
1.1.7	Delivery line systems	12
1.1.8	End hose	12
1.1.9	Manufacturer	12
1.1.10	Operator	12
1.1.11	Machine operator	12
1.1.12	Hoseman	12
1.1.13	Signaller and other auxiliary personnel	13
1.1.14	Truck mixer driver	13
1.1.15	Subject expert	13
1.1.16	Qualified personnel	13
1.1.17	After Sales Service personnel	13
1.1.18	Maintenance	13
1.1.19	Place of work, working area, danger zone	14
1.2	Designated use	18
1.2.1	Retesting (safety inspection)	19
1.2.2	Inspection intervals for retesting	19
1.3	Improper use	20
1.3.1	Transporting goods	20
1.3.2	Lifting loads	21
1.3.3	Removing obstacles	21
1.3.4	Extending the reach	21
1.3.5	Extending the placing boom and end hose	21
1.3.6	Impermissible end hose	22
1.3.7	Impermissible working area	22
1.3.8	Climbing the placing boom	23
1.3.9	Highpressure delivery	23
1.3.10	Accessories and attachments	23
1.3.11	Changes to the machine	23
1.4	Exclusion of liability	24

1.—
2.—
3.—
...

Table of contents

Concrete delivery and placing machines

1.5	Personnel	24
1.5.1	Requirements	24
1.5.2	Qualifications	25
1.5.3	Responsibility of the machine operator	25
1.6	Operating Instructions, operating procedures and other regulations	25
1.6.1	Operating Instructions	25
1.6.2	Operating procedures	26
1.6.3	Other regulations	27
1.7	Personal protective equipment	27
2	Setting up and working with the machine	29
2.1	Before working with the machine	31
2.1.1	Checking that the machine is ready for operation	31
2.1.2	Rendering the machine ready for operation	31
2.2	Danger due to high voltage	31
2.2.1	High-voltage lines	31
2.2.2	Discharge voltage pattern	32
2.2.3	Clearances	32
2.2.4	Highvoltage warning devices	33
2.2.5	Procedure in the event of a flash over	33
2.2.6	Earthing in the event of electrostatic charging	34
2.2.7	Earthing on construction sites with special equipment	34
2.3	Stationary machines	35
2.3.1	Setup site	35
2.3.2	Stationary placing booms	35
2.3.3	Lifting machines and components	35
2.3.4	Loading and transporting	35
2.4	Mobile machines	36
2.4.1	Setup site	36
2.4.2	Supporting ground	37
2.4.3	Corner bearing loads	38
2.4.4	Supports	38
2.4.5	Driving	39
2.4.6	Towing	41
2.4.7	Loading	41
2.5	Placing booms	42
2.5.1	Unfold placing boom	42
2.5.2	End hose	43
2.5.3	Guiding the end hose ergonomically	44
2.5.4	Connecting drills	45
2.5.5	Procedure in storms	45

Table of contents

Concrete delivery and placing machines

1.—
2.—
3.—
...

2.5.6	Concreting in cold weather	46
2.6	Delivery line systems	46
2.6.1	Suitable delivery lines	46
2.6.2	Securing delivery lines	46
2.6.3	Leak tightness and blockages	47
2.6.4	Opening delivery lines	48
2.6.5	Clearance to delivery lines	48
2.6.6	Securing the delivery lines	48
2.6.7	Continuation delivery lines	48
2.6.8	Devices for shutting off, diverting and cleaning	49
2.7	Pumping operations	49
2.7.1	Place of work	49
2.7.2	Safety	49
2.7.3	Remote control	50
2.7.4	Moving machine components and hot surfaces	50
2.7.5	Constant observation of the machine	51
2.7.6	Truck mixer	51
2.8	Cleaning	51
2.8.1	General	51
2.8.2	Cleaning agents	52
2.8.3	Cleaning with compressed air	53
2.8.4	Protection against water	54
2.8.5	Post-cleaning procedure	55
3	Maintenance and special work	57
3.1	Requirements for special work	59
3.2	Welding	60
3.3	Working on the placing boom	61
3.4	Safetyrelevant components	62
3.5	Software	62
3.6	Protective and safety equipment	62
3.7	Electrical power	63
3.7.1	General	63
3.7.2	Electrical components	63
3.7.3	Power at the construction site	64
3.8	Hydraulic systems	64
3.8.1	General	64
3.8.2	Replacing hydraulic hoses	66

1.—
2.—
3.—
...

Table of contents

Concrete delivery and placing machines

3.9	Noise emissions	66
3.10	Exhaust fumes	66
3.11	Functional fluids	67
3.12	Disposal of the machine	68
	Index	69



Foreword

This Safety Manual contains important information on how to operate concrete delivery and placing machines safely, properly and economically. Observing these instructions helps to avoid danger, to reduce repair costs and downtimes and to increase the reliability and service life of the machine.

This Safety Manual must not be considered a substitute for knowledge of legal regulations, but should supplement and explain this knowledge in a practical way. The manufacturer's Operating Instructions that may be supplemented by this Safety Manual must also be observed. There has been no classification of the hazards according to the degree of injury or amount of damage to be expected.

Infringements of the rules laid down in this Safety Manual may lead to accidents and/or machine failures, even if not expressly described. Significant damage may be caused and persons in the vicinity of the machine could be injured or killed.

This Safety Manual must be read and applied by anyone who is tasked with working with/on the machine, and with the following in particular:

- Operation, including setting up, fault rectification in the course of work, maintenance, disposal of functional fluids and consumables
- maintenance (servicing, inspection, repair) and/or
- transport.

This Safety Manual is revised periodically. The current version can be obtained at any time from the publisher.



1 Terms, definitions, requirements



1.1 Definition of terms

The terms used in this Safety Manual are explained below, along with descriptions of the requirements placed on specific groups of people.

1.1.1 Machine

For the purposes of this Safety Manual, concrete delivery and placing machines are defined as:

- Truck-mounted concrete pumps (an ensemble of truck and concrete pump with and without placing boom). The safety regulations issued by the truck manufacturer also apply to the truck.
- Truck mixer concrete pump (an ensemble of truck mixer, concrete pump and placing boom). The safety regulations issued by the truck mixer manufacturer and by the truck manufacturer also apply to truck mixer concrete pumps.
- Stationary concrete pumps
- Stationary placing systems (an ensemble of placing boom and base structure)

1.1.2 Concrete pump

For the purposes of this Safety Manual, concrete pumps are defined as devices which are designed to deliver concrete to placement sites via pipes or hoses.

1.1.3 Arm assembly

Arm assembly is a synonym for placing boom and can be used interchangeably.

1.1.4 Placing boom

For the purposes of this Safety Manual, placing booms are defined as powered, slewable devices consisting of one or more swinging or folding sections for guiding the delivery line.

1.1.5 Base structure

For the purposes of this Safety Manual, base structures are defined as equipment which is designed to hold a stationary placing boom to give the latter the required stability.



Safety Manual

Concrete delivery and placing machines

1.1.6 Truck mixer

For the purposes of this Safety Manual, truck mixers are defined as vehicles with mixing equipment for transporting concrete.

1.1.7 Delivery line systems

For the purposes of this Safety Manual, delivery line systems are defined as self-contained pipes or hoses in which concrete is pumped from the concrete pump to the placement site. Devices for shutting off, diverting or cleaning delivery lines can be integrated into delivery line systems.

1.1.8 End hose

For the purposes of this Safety Manual, end hose is defined as the hose that is fitted on the placing boom at the end of the delivery line for distributing the concrete. There must be no couplings, spouts, discharge stops or other items fixed to the outlet end of the end hose unless they are approved by the manufacturer.

1.1.9 Manufacturer

Any natural or legal person that markets a machine or incomplete machine that is dealt with in this Safety Manual.

1.1.10 Operator

Authorised representative of the owner of the concrete pumps and/or placing booms. The operator is responsible for the use of these machines.

1.1.11 Machine operator

Persons trained in and charged with the operation of concrete pumps and placing booms.

1.1.12 Hoseman

Persons instructed by the site management in how an end hose is guided. Hosemen must be able to independently evaluate all dangerous situations which may occur in the area of the end hose and react according to the situation.



1.1.13 Signaller and other auxiliary personnel

Persons instructed by the site management to help the machine operator in his work if the latter is unable to observe all areas of operation and danger zones. Signallers must be able to independently evaluate all dangerous situations which may occur when working with a concrete pump and/or placing boom and react according to the situation. The signaller must have a suitable means of communication with the machine operator.

1.1.14 Truck mixer driver

Persons who supply the concrete pump with concrete from a truck mixer. Truck mixer drivers must be instructed by the machine operator to operate the operating elements on the concrete pump provided for their use. Truck mixer drivers must be able to independently evaluate all dangerous situations which may occur when working in the area of the hopper of a concrete pump and react according to the situation.

1.1.15 Subject expert

For the purposes of this Safety Manual, a subject expert is defined as a person who, through their professional training, their professional experience and their recent professional activity, has the required specialist knowledge to inspect the tools.

1.1.16 Qualified personnel

Persons who have completed specialist training for a particular activity which qualifies them to carry out their roles.

1.1.17 After Sales Service personnel

Qualified personnel employed by the manufacturer who are responsible in particular for maintenance of the machine.

1.1.18 Maintenance

Maintenance includes all measures required to inspect, maintain and repair a machine.



Safety Manual

Concrete delivery and placing machines

1.1.19 Place of work, working area, danger zone

1.1.19.1 Mobile machines




Figure 1: Example

1.1.19.2 Stationary machines




Figure 2: Example



Pos.	Designation		Explanation
1	Place of work (during pumping operations)	Machine operator	In normal operation, with the remote control
2		Hoseman	At the end hose in the danger zone
3		Signaller	In the machine operator's range of vision
4		Auxiliary personnel	As machine operators of the manual placing system
5		Truck mixer driver	At the hopper in the danger zone
6	Working area	Permitted	Area with a radius of the reach of the placing boom + end hose length
7	Working area	Impermissible	The end hose must not be moved backwards beyond the vertical of the placing boom.
8	Danger zone	At the end hose	Risk of injury when pumping is started, during pumping operations, when removing a blockage and during cleaning procedures. The diameter of the danger zone is twice the end hose length.
9	Danger zone	Beneath the placing boom	Risk of injury from falling items
10	Danger zone	Area of the support legs and feet or area of the base structure	Risk of crushing when setting up or dismantling the machine
11	Danger zone	On the machine	Any presence on or below the machine when the pump is in operation is prohibited
12	Danger zone	On the hopper	Risk of injury during cleaning procedures and when the hopper is being filled using a truck mixer
13	Danger zone	Area of the delivery line systems	Hazard posed if lines burst, risk of injury from crushing or shearing, particularly with gate valves
14	Structure or area being concreted		Example



Safety Manual

Concrete delivery and placing machines

1.1.19.3 Place of work

The place of work is the area in which people must remain in order to carry out the work.

Place of work – machine operator

The machine operator's place of work is with the remote control when the pump is in operation. The place of work must be selected so as to allow visual contact with the placement site and the truck mixer driver, and so that the working area can be observed at the same time. A signaller must otherwise be used.

The machine operator's place of work is with the machine when this is being set up or prepared for driving.

Place of work – hoseman

The hoseman's place of work is within the danger zone of the end hose, but not beneath the placing boom. This requires a greater level of caution. The hoseman and machine operator must have visual contact.

Place of work – truck mixer driver

The truck mixer driver's place of work is in the danger zone of the hopper and at operating elements for the agitator and truck mixer. This requires a greater level of caution. The truck mixer driver and machine operator must have visual contact.

1.1.19.4 Working area

The working area is the area in which work is carried out with or on the machine. Parts of the working area can become danger zones depending on the operation being carried out and the position of the placing boom.

The working area must be secured and clearly identified. Suitable personal protective equipment is required in the working area. The machine operator is responsible for safety in the working area of the machine whilst the machine is in use.



Impermissible working area

Because of their high manoeuvrability, some placing booms can also be shifted into positions for which they are not designed. This may overload or damage the placing boom. Placing booms must therefore only be moved within the permitted working area. (*Impermissible working area P. 22*)

1.1.19.5 Danger zone

The danger zone is the area surrounding the machine, in which people may be at risk of injury from movements required by the work.

The danger zone varies within the working area and depends on the activity being carried out and the position of the placing boom, if one is present. Danger zones must be secured and clearly identified. The machine operator must be capable of seeing the danger zone at all times and under all circumstances. If necessary, he must appoint a signaller to supervise the danger zone.

Depending on the working situation, places of work may occasionally fall within the danger zone, especially the place of work of the hose-man and the truck mixer driver. If a place of work falls within the danger zone, increased caution is required and suitable personal protective equipment is prescribed. Persons who are authorised to be present in such a place of work must use their own discretion to assess dangerous situations and be able to react according to the situation.

The machine operator is responsible for safety in the danger zone of the machine whilst the machine is in use.

The machine operator must stop work immediately and press the EMERGENCY STOP button if an unauthorised person enters the danger zone.

Support legs and support feet

There is a risk of crushing in the swingout and extension zone for the supports.

Placing boom

The danger zone when working with the placing boom is the zone over which the placing boom is slewed. In this area there is a risk of injury from falling concrete and delivery line components.



Safety Manual

Concrete delivery and placing machines

Machine

All the time the vehicle is in operation, there is a risk of injury on and below the machine from moving parts and bursting delivery lines or hydraulic hoses, as well as a risk of falling on slippery surfaces or steps.

End hose

The danger zone when pumping is started, during pumping operations, when removing a blockage and during cleaning procedures is the area around the end hose in which the end hose may swing out. The diameter of the danger zone is twice the end hose length.

Hopper

In the area of the hopper, there is a risk of becoming trapped between the truck mixer and the hopper and of being sprayed with concrete. There is a risk of being crushed and of injury by shearing from the transfer tube. There is a risk of becoming caught in the rotating agitator.

Delivery line systems

In the area around the delivery line systems there is a risk of injury from the delivery line bursting if there is an abrupt rise in pressure. There is a risk of crushing and injury by shearing with devices integrated in delivery line systems.

1.2 Designated use

The machine must only be operated as intended and in technically perfect condition. All protective and safety-oriented devices, particularly removable protective devices and EMERGENCY STOP devices, must be available and fully functional.

The machine is designed exclusively for the delivery and placing of concrete up to a bulk density of 2400 kg/m^3 . It must only be used for pumping operations on construction sites. The maximum delivery pressure must not exceed that specified on the rating plate or in the check book.



You must also observe the Operating Instructions and comply with the intervals and conditions for inspections (particularly retesting) and maintenance work in order to operate the machine within the limits of its proper use.

1.2.1 Retesting (safety inspection)

After initial commissioning of the machine, the operational safety of the machine must be checked regularly by a subject expert. The inspection intervals depend on the age of the machine. The older the machine, the greater the probability of damage. For this reason, regular retesting of the machine, appropriate to its age, must be carried out in order to detect damage in good time. Retesting should be carried out in accordance with the inspection intervals listed below.

Retesting must consist of the following:

- Retesting of the condition of the components and equipment with regard to the formation of cracks, damage, wear, corrosion and other changes;
- Retesting of the completeness and effectiveness of the safety equipment;
- Retesting to find out whether any defects which are found during the tests mentioned above and which could affect safety have been adequately rectified.

Furthermore, information provided by the manufacturer to the operator with reference to special instructions for maintenance and inspection must be observed.

1.2.2 Inspection intervals for retesting

The inspection intervals are fixed as follows:

- Machines up to and including 5 years old:
Inspect after every 1000 operating hours or 1 year, whichever is soonest. The interval is repeated after every retest.
- Machines more than 5 years old:
Inspect after every 500 operating hours or 1 year, whichever is soonest. The interval is repeated after every retest.
- Machines more than 10 years old:
Inspect after every 250 operating hours or 1 year, whichever is soonest. The interval is repeated after every retest.



Safety Manual

Concrete delivery and placing machines

The day of initial commissioning in accordance with the handover report and the machine's operating hours meter are definitive for the intervals. This operating hours meter records the hours of pumping operations. The operating hours meter must always be kept in good working order. It must not be tampered with. For machines without an operating hours meter, the operating hours must be recorded in a traceable form in writing.

Retesting must be arranged by the operator. The results of retesting must be entered in the check book and signed. The check book must always be kept with the machine and must be produced upon the request of the national supervisory bodies.

Notwithstanding national legislation, the operator can be liable in the event of damage, if it is proved that the damage has arisen as a consequence of regular retesting not being properly carried out.

If retesting is not carried out, the manufacturer will assume that the machine has been shut down. When the machine is restarted, retesting must be carried out.

1.3 Improper use

Improper use is defined as use which is not described in or goes beyond that described in the "Designated use", (*Designated use P. 18*) section. The manufacturer accepts no liability for damage resulting from such use. Some examples of conceivable improper uses are given below.

1.3.1 Transporting goods

The machine must not be used for the transport of goods, except for carrying the accessories used for the machine, such as pipes, hoses, etc. The maximum permissible gross weight may not be exceeded.



1.3.2 Lifting loads

The placing boom must never be used for lifting loads.



1.3.3 Removing obstacles

The placing boom must not be used under any circumstances to remove obstacles. This would overload the placing boom, causing damage and endangering people.

1.3.4 Extending the reach

It is forbidden to attach an extension to the end hose or boom tip of the placing boom (e.g. freely suspended transition liner) in order to extend the reach or in order to be able to pump “around corners”. Since the placing boom and the lifting equipment for the extension have differing pivot points and modes of control, it is not possible to co-ordinate their movements.

1.3.5 Extending the placing boom and end hose

Extension of the placing boom and end hose beyond the length specified on the rating plate is forbidden.

If the manufacturer defines the weight rather than the length of the end hose, you can use a reducer pipe with a longer end hose, for example. The quoted gross weight must not be exceeded. (*End hose P. 43*)


When using a longer end hose, the diameter of the danger zone also increases. (*End hose P. 43*)

End hoses with a length of more than 4 m must not be guided by hand.




Safety Manual

Concrete delivery and placing machines




1.3.6 Impermissible end hose

There must be no couplings, spouts, discharge stops or other items fixed to the outlet end of the end hose unless they are approved by the manufacturer.



1.3.7 Impermissible working area

During pumping operations, the end hose must not be moved backwards beyond the vertical axis of rotation of the placing boom.






In addition to this, additional impermissible working areas exist, depending on the machine model and manufacturer, which are described in the Operating Instructions.

1.3.8 Climbing the placing boom

It is prohibited to climb the placing boom, to stand on top of it or to misuse it as a working platform or climbing aid.



1.3.9 Highpressure delivery

It is prohibited to deliver concrete at high pressure (concrete pressure greater than 85 bar) through the delivery line of the placing boom. Delivery line elements are marked with the maximum permissible delivery pressure. The delivery line and end hose are only suitable for concrete pressures of up to 85 bar until the wear threshold is reached. For the wear threshold, refer to the Operating Instructions for the machine.

1.3.10 Accessories and attachments

It is prohibited to fit accessories and attachments to the machine if they have not been expressly approved for use on this machine by the manufacturer.

1.3.11 Changes to the machine

You are not allowed to carry out your own changes to the machine. Changes must always be approved by the manufacturer.



Safety Manual

Concrete delivery and placing machines

1.4 Exclusion of liability

Where the manufacturer's delivery conditions are agreed, liability will be as described in the provisions there. The manufacturer is not liable for damage in cases specified there.

Unless the responsibility of the manufacturer, the warranty will be invalidated in the following situations in particular:

- use contrary to designated use.
- incorrect operation, maintenance and repair.
- use of spare parts or accessories other than original manufacturer's spare parts and accessories or their equivalents.
- conversions, alterations or modifications to the machine.
- fitting of accessories and attachments not approved by the manufacturer.
- adjustment of safety pressures, speeds of movement, power outputs, speeds of rotation and other settings to values other than those set in the works.

1.5 Personnel

The operator must ensure that only persons who are qualified or have received the necessary instruction work on or with the machine. It is the responsibility of the operator to carry out regular (e.g. annual) safety briefings for their employees. Suitable training can be requested from the machine manufacturer. The operator must clearly define who is responsible for operation and maintenance of the machine.

The operating company must also ensure that only persons commissioned to work on the machine do so. In addition, the operator should provide the necessary personal protective equipment.

1.5.1 Requirements

Persons operating or carrying out maintenance work on the machine must meet the following requirements:

- They must be aged 18 years or over.
- They must be physically and mentally capable.
- They must be physiologically capable (rested and not under the influence of alcohol, drugs or medication).
- They must have been instructed in the operation and maintenance of the machine.



- They must have demonstrated their competence to the operator.
- They can be expected to reliably execute the tasks with which they are charged.

The operating personnel must not wear loose garments or jewellery, including rings. Long hair which is not tied back must be covered by a hair net. There is a risk of injury, in particular from being caught or trapped by moving parts.

All persons working on or with the machine must concentrate on the task at hand and not be distracted, particularly by smartphones and music played through headphones.

1.5.2 Qualifications

Persons who are being trained, introduced and instructed in the use of the machine are only permitted to operate the machine under the constant supervision of experienced personnel.

If you do not have qualified personnel, suitable workshop equipment, etc. available, you should commission the manufacturer's After Sales Department with the maintenance of your machine.

1.5.3 Responsibility of the machine operator

The operator must define the responsibility of the machine operator (including in respect to national road traffic regulations) and empower the machine operator to reject instructions from third parties prejudicial to safety. The machine operator must be able to reject the site of operations in the event of doubts regarding technical safety.

1.6 Operating Instructions, operating procedures and other regulations

1.6.1 Operating Instructions

Personnel that are authorised to work on the machine must have read the Operating Instructions, particularly the "Safety Regulations" section, and the Safety Manual before working with the machine. Reading the instructions after work has begun is too late. This applies especially to persons working only occasionally on the machine, e.g. during setting up or maintenance.



Safety Manual

Concrete delivery and placing machines

As the operator, you must always make sure that the Operating Instructions are available. The Operating Instructions and check book must always be kept to hand at the site of use of the machine (in the tool compartment or container provided for this purpose).

As the operator, you must have personnel working on the machine confirm in writing their knowledge, understanding and application of the Operating Instructions and Safety Regulations and Safety Manual. At regular intervals of at least once a year, check that personnel are conscious of safety and the hazards involved in their work and are taking account of the Operating Instructions.

Personnel entrusted with work on the machine must observe all safety instructions and hazard warnings, and must be familiar with the machine itself. You must practice all the operating procedures described in the Operating Instructions (extending the supports, operating the placing boom, shifting the placing boom into the driving position, preparing the vehicle for moving, etc.) under the supervision of a subject expert until you are certain you can execute them safely. Ask questions if there is something you have not understood. Begin operating the machine only once you are fully and explicitly familiar with the layout and significance of all the control and monitoring devices and the method of operation of the machine.

1.6.2 Operating procedures

The operator must produce operating procedures for their personnel in accordance with national regulations. These operating procedures must also contain instructions (including the obligation to provide supervision and reports) concerning the observance of special operational features, particularly in respect of work organization, working procedures or personnel deployment. Furthermore, reference must be made to other generally valid legal and otherwise mandatory regulations relating to accident prevention and environmental protection. Such regulations may also deal with handling hazardous substances, the issuing and wearing of personal protective equipment or with national road traffic regulations. You should familiarise yourself with the site of operations and with how to use fire extinguishers. Observe the firealarm and fire-fighting procedures.



1.6.3 Other regulations




The current regulations for concrete delivery and placing machines as issued by:

- The legal authorities in your country
- The national supervisory bodies
- The responsible commercial liability insurance company.

1.7 Personal protective equipment

In order to reduce risks to personnel, the operating personnel must use personal protective equipment insofar as this is necessary or deemed to be so by regulations. All personnel working on or with the machine must wear safety helmets, protective gloves and safety footwear.





Personal protective equipment must, as a minimum, comply with the requirements of the specified standards.

Symbol	Meaning
	<p>Safety helmet</p> <p>The safety helmet protects your head, e.g. from falling concrete or parts of delivery lines if lines burst.</p> <p>(DIN EN 397; Industrial safety helmets)</p>
	<p>Safety footwear</p> <p>Safety footwear protects your feet from falling objects and any protruding nails.</p> <p>(EN ISO 20345; Safety footwear for professional use; category S3)</p>
	<p>Hearing protectors</p> <p>Hearing protectors protect your ears when in the vicinity of the machine against any noise that arises there.</p> <p>(DIN EN 3521; Hearing protectors - General requirements - Part 1: Earmuffs or DIN EN 352-3; Hearing protectors - General requirements - Part 3: Earmuffs attached to industrial safety helmets)</p>



Safety Manual

Concrete delivery and placing machines

Symbol	Meaning
	<p>Protective gloves</p> <p>Protective gloves protect your hands from aggressive or chemical substances, mechanical effects (e.g. impact) and from cuts.</p> <p>(DIN EN 388; Protective gloves against mechanical risks; Class 1111)</p>
	<p>Protective goggles</p> <p>Protective goggles protect your eyes from injuries associated with concrete spatter and other small particles.</p> <p>(DIN EN 166; Personal eye protection - Specifications)</p>
	<p>Safety harness</p> <p>When working at height, use the climbing aids and working platforms provided for reasons of safety or wear a safety harness. The relevant national regulations must be complied with.</p> <p>(DIN EN 361; Personal protective equipment against falls from a height - Full body harnesses; Category III)</p>
	<p>Respiratory protection and face mask</p> <p>The respiratory protection and face mask protect you against particles of building materials that can enter the body via the respiratory passages (e.g. concrete admixture).</p> <p>(DIN EN 149; Respiratory protective devices - Filtering half masks to protect against particles - Requirements, testing, marking; Class FFP1)</p>



2 Setting up and working with the machine



2.1 Before working with the machine

2.1.1 Checking that the machine is ready for operation

As machine operator, it is your responsibility to check the machine for external damage and defects before any use of the machine. You must immediately report any changes (including changes in the working characteristics) to the organisation or person responsible. If necessary, shut the machine down immediately and secure it.

2.1.2 Rendering the machine ready for operation

As machine operator, you are responsible for rendering the machine ready for operation. This also includes topping up the functional fluids. Do not fill with fuel in enclosed spaces. Switch off the engine and the heating. Wipe up spilt fuel immediately. Do not smoke or use a naked flame when handling fuel.

Set all the control and monitoring devices to the zero position before you change the mode of control (control block, control console or remote control).

Never put the remote control down when the machine is ready for operation. If this is unavoidable in exceptional cases, you must switch off the remote control, disconnect it and lock it away.

Never leave the machine when the engine is running or when the engine could be started by an unauthorised person. If you need to leave the machine, proceed as follows:

- Switch off the remote control.
- Disconnect the remote control and lock it away.
- Switch off the ignition or the main switch.
- Lock the control cabinet.

2.2 Danger due to high voltage

2.2.1 High-voltage lines

Whenever you touch a high-voltage line, there is a risk of death for all persons either on the machine or in its vicinity or who are connected to it (via the remote control, end hose, etc.). A spark can jump across from a highvoltage line even if you just approach it and this will energise the machine and the surrounding area.



Safety Manual

Concrete delivery and placing machines

2.2.2 Discharge voltage pattern


In the event of a flash over, what is known as a “discharge voltage pattern” is formed in the vicinity of the machine. The voltage decreases from the inside to the outside in this discharge voltage pattern. If you step inside this discharge voltage pattern, you will bridge different potentials. This will cause a voltage corresponding to the potential difference to flow through your body.

2.2.3 Clearances

Maintain a minimum clearance from highvoltage lines in accordance with the following table. The minimum clearance is measured in the horizontal when the placing boom is fully extended.

Rated voltage [V]	Minimum clearance [m]
up to 1 kV	1,0
1 kV up to 110 kV	3,0
110 kV up to 220 kV	4,0
220 kV up to 380 kV	5,0
unknown rated voltage	5,0

The specified clearances are minimum requirements. You must observe any greater clearances that may be specified in the country of use.



When you set a minimum clearance, the possibility of the high-voltage lines and the placing boom swaying in the wind must also be taken into consideration. You should further note that where air humidity is high, clearances greater than the minimum clearances shown above are always necessary.



You must stand as close as possible to the unfolded placing boom if you wish to correctly estimate the movements of the boom and, above all, the clearance between the placing boom and obstacles or high-voltage lines.

The same minimum clearances are necessary when driving under overhead cables.

In the event that this minimum clearance cannot be maintained under all possible working positions, the power station responsible must be contacted and you must have the high-voltage line switched off.


Should you have any doubts, it is better to forgo the use of the placing boom and to lay a separate delivery line, for instance.

2.2.4 Highvoltage warning devices

According to the current rules of engineering, highvoltage warning devices do not meet a safety standard which enables minimum clearances to highvoltage lines that are smaller than the required minimum clearances to be used. Previous experience has shown that highvoltage warning devices cannot make all situations in working procedures safe. Flash overs and fatal accidents can occur despite the use of a highvoltage warning device. You must therefore always maintain the minimum clearances mentioned above.

2.2.5 Procedure in the event of a flash over

If, despite all precautions, a flash over occurs, stay calm and do not move (potential differential) or touch anything.





Safety Manual

Concrete delivery and placing machines

If your machine comes into contact with high-voltage lines:

- Warn people standing outside the area not to approach or touch the machine.
- Have the power switched off.
- Only leave the machine once you are sure that the line you have touched or damaged has been deenergised.

Electricity generator works are always equipped with automatic start-up systems. If a circuit breaker trips, the short-circuited line will be switched back on again after a brief interval. Brief intervals where the voltage is absent create a false sense of safety.

You must not move or rescue injured persons until a representative of the power station has notified you that the line has been switched off.

A radio remote control system only protects the machine operator if he is standing outside the discharge voltage pattern.

2.2.6 Earthing in the event of electrostatic charging

Working in the vicinity of transmitters (radio transmitter, etc.) can result in faults in the radio remote control system and dangerous electrical charges in the machine. Persons who bridge the charged parts to the earth are heavily charged on contact.

Machines in use in the vicinity of transmitters must be earthed. This earthing may be carried out by trained personnel.

Even with an earthed machine, the safe clearances to high-voltage lines (*Clearances P. 32*) and the instructions relating to storms and bad weather (*Procedure in storms P. 45*) must be complied with.

If you have any further questions about earthing the machine, please contact site management or the operator of the machine.

2.2.7 Earthing on construction sites with special equipment

When carrying out work in the area of special installations (particularly overhead lines for railways or substations), it may be the case that the machine needs to be earthed upon request and in consultation with the operator of the special installation. This earthing must only be carried out by qualified personnel.

Even with an earthed machine, the safe clearances to high-voltage lines (*Clearances P. 32*) and the instructions relating to storms and bad weather (*Procedure in storms P. 45*) must be complied with.



2.3 Stationary machines

2.3.1 Setup site

Stationary machines are generally used on a construction site for a lengthy period. For this reason, site management should prepare the setup site carefully. Site management must deliver the necessary documents in good time in order to be able to prepare the foundations, base plates or similar on time.

When selecting the setup site, remember that the machine must be dismantled and transported away again at the end of its use on site. The ambient conditions may change as construction work progresses.

Please also observe the (*Setup site P. 36*) section.

2.3.2 Stationary placing booms

Stationary placing booms can be erected on tubular columns, lattice booms or other base structures. The base/structural elements to which the base structure is fixed must be able to withstand the forces and moments transferred via the base structure, as specified in the manufacturer's information. The base frame of the base structure must be fastened in place so that it is level on the base/structural elements in every direction. Check the documentation provided by the manufacturer in this regard and the corresponding notes in the operating instructions.

2.3.3 Lifting machines and components

Machines which are transported to the setup site in individual parts or not under their own power must only be lifted with suitable lifting equipment in accordance with the specifications in the Operating Instructions. The lifting gear on the machine must be capable of accepting the lifting equipment and lifting the load. No one should stand under suspended loads. Before work is started, a subject expert must check that the assembled machine is working properly.

2.3.4 Loading and transporting

Only use suitable means to load and transport stationary machines. Ensure that no one can be injured by the machine tipping over or slipping.



Safety Manual

Concrete delivery and placing machines

If there are transport fixtures provided for the machine or its individual components, only these should be used. The machine/components must be properly secured during transport. The transport vehicle and machine must be marked to conform with the road traffic regulations in the country concerned if they are to use the public highway.

Please also observe the (*Driving P. 39*) section.

2.4 Mobile machines

2.4.1 Setup site

Site management must prepare and assign the set-up site. It is the machine operator who takes responsibility for setting up the machine safely. The machine operator must inspect the setup site proposed by site management and must refuse to set the machine up at the site of operations if there are any doubts regarding safety.

As machine operator, you must familiarise yourself with the working area and surroundings before work is begun. The working area and surroundings include, in particular, obstacles in the work and travelling areas, the load-bearing capacity of the supporting ground and any barriers separating the construction site from public roads.

The setup site must have sufficient lighting to ensure safe operation of the machine. Ensure that the setup site is adequately lit.

Do not set up the machine in areas where equipment may fall down.

Incidents of overlapping with the working areas of other machines (particularly cranes, other placing booms, etc.) should be avoided as far as possible. If this is not possible, special care and attention is required when setting up and operating machinery. If necessary, you must use a signaller.


You must also check the approach route to the site where the machine will be set up. If you are unsure whether the approach route is suitable, prepare the route before work is started. It is especially necessary to walk the approach route once in darkness and at dusk or dawn. You should repeat this exercise again before leaving the construction site.

Always ask for a signaller if you need to reverse. If necessary, have the approach route closed off or secured by signallers. Have any materials or equipment that hinder your approach removed.



2.4.2 Supporting ground

Find out the load-bearing capacity of the supporting ground. The site management will be able to state the permitted ground pressure. If the load-bearing capacity is unknown, assume the that worst case scenario applies.



The supporting ground must be level and even. If necessary, set up a level surface on top of the uneven ground. There must be no voids or other ground irregularities under the support feet. Asphalt, concrete slabs, etc. may have been washed out underneath. Never set the machine up on backfilled ground, obvious or known voids or uneven ground.

The support area must be enlarged as required. Support plates and timber blocks may be used to increase the support area. The supports must be undamaged and free from ice, oil, grease, etc. The support blocks and timber blocks must be laid under the support plates such that the load is distributed uniformly and the support leg cannot slip off the side of the support.

Check the stability of the machine regularly during operation. Interrupt the pumping operation if the machine becomes unstable.

Factors which reduce stability include, for instance:

- Modifications to the ground conditions, particularly caused by rain water or the thawing of frozen ground
- The support sinking on one side
- Fluid losses through leaks in the support hydraulics




Safety Manual

Concrete delivery and placing machines

2.4.3 Corner bearing loads

The corner bearing load is stated on each support leg. This value must always be legible.



The load supported by each support leg is conically diffused in the ground at an angle of 45° . Safe clearance to the pits and slopes must be maintained, and such clearance must be determined in accordance with the nature of the ground. The safe clearance is measured from the foot of the pit.

On undisturbed, compacted ground, the safe clearance corresponds to the pit depth, but must be at least 2 m.

On loose or backfilled ground, the safe clearance corresponds to double the pit depth, but must be at least 2 m.

2.4.4 Supports

The placing boom must not be raised until the machine has been supported in accordance with the Operating Instructions. There is otherwise a risk of the machine toppling over.


Swing out and telescope the support legs to their end positions in sequence. Intermediate positions are prohibited to guarantee stability. Exceptions are machines which have been equipped by the manufacturer with a device which allows secure erection with a reduction in support. Check the corresponding notes in this regard in the operating instructions.



Do not carry out more than one movement at a time. If a movement is stopped, the entire volume of fluid is available for the remaining movements, and can increase their speeds. Depending on the design, it may be the case that carrying out several movements at once (as opposed to carrying out a single movement at maximum speed at any one time) does not bring any advantage in terms of time. Carrying out several movements at once requires an increased level of attentiveness.

Lock all supports mechanically, if this is provided for in the design. Close all shut-off valves in the support hydraulics. Leaks can cause the supports to sink on one side.

The machine must be made level in all directions. Provided the manufacturer does not state otherwise, the maximum permissible deviation from the horizontal is 3°. Greater deviations from the horizontal overload the slewing gear for the placing boom as well as its overall support structure, jeopardising the stability of the machine.



Check stability regularly during operation. The elastic distortions to the machine frame occasionally occurring under extreme positions of the placing boom (one support foot lifts from the ground) must be compensated for by resetting the support cylinders until all support feet are firmly placed on the ground.

2.4.5 Driving

When preparing the machine for driving, you must perform the following tasks in particular:

- The placing boom must be folded in fully and positioned on the placing boom support provided.
- The support legs and support feet must be fully retracted and secured.
- Raised or locked axles must be lowered and released.




Safety Manual

Concrete delivery and placing machines

- Accessories and moving parts belonging to the machine must be safely stowed/secured.
- The maximum permissible gross weight must not be exceeded.

While the vehicle is being driven, the delivery line, pump and hopper must be empty. If there is concrete residue in the hopper, there is a risk of injury from the concrete residue, which may be thrown out while the vehicle is in motion. This also affects the centre of gravity of the machine. Observe the road traffic regulations and specifications of the machine manufacturer.

Maintain a distance of at least 1 m to the secured edges of the pit and a distance of at least 2 m to slopes.



Always make sure that there is sufficient clearance when driving under underpasses, over bridges and through tunnels or when passing under overhead cables. The same minimum clearances apply when driving under high-voltage lines as when working with the placing boom. Be aware of the height of the truck. Only drive over arches, bridges or other supporting structures if their load-bearing capacity is sufficient.

Do not drive across uphill or downhill gradients. Be aware of the elevated position of the truck's centre of gravity when travelling on a slope and on ascending or descending routes. Always adapt your travelling speed to the prevailing conditions on sloping terrain.

Observe national road traffic regulations. If necessary, clean the tyres, lights and number plate. Before travelling with the machine, check that the braking, steering, signalling and lighting systems are fully functional.

Persons accompanying the driver must be seated on the passenger seats provided for this purpose.



For truck mixer concrete pumps, only turn the mixer drum at the maximum specified speed of rotation whilst the truck is in motion. The truck is at risk of toppling over, particularly when travelling round corners.


2.4.6 Towing

The machine must only be towed, loaded and transported in accordance with the Operating Instructions. Only use existing towing hitches for towing and observe the truck manufacturer's regulations.

You must comply with the prescribed driving position, permitted speed and itinerary when towing.

2.4.7 Loading

Many lifting points fitted to the machine are provided for assembly purposes only. They are not suitable for lifting the complete machine. The lifting points for lifting the entire machine are specially marked.



Use only appropriate means of transport and lifting equipment of adequate load-bearing capacity. Lifting equipment, lifting tackle, support trestles and other auxiliary equipment must be reliable and safe in operation.

Use only stable loading ramps of adequate load-bearing capacity for loading. Ensure that no one is at risk from the machine tipping over or slipping.

Secure the machine on the transport vehicle to prevent it rolling away, slipping and toppling over.



Safety Manual

Concrete delivery and placing machines

2.5 Placing booms

2.5.1 Unfold placing boom

Only raise a mobile placing boom from the driving position once the machine has been supported in accordance with the Operating Instructions. Stationary placing booms may only be raised after the proper set-up has been checked by a subject expert.

Only raise the placing boom in the sequence described in the Operating Instructions. The correct sequence depends on the “Folding system” (roll-and-fold system, Z fold system, etc.).

Do not carry out more than one movement at a time. If a movement is stopped, the entire volume of fluid is available for the remaining movements, and can increase their speeds. Depending on the design, it may be the case that carrying out several movements at once (as opposed to carrying out a single movement at maximum speed at any one time) does not bring any advantage in terms of time. Carrying out several movements at once requires an increased level of attentiveness.


The range of a radio remote control is long enough for the machine to receive control commands (e.g. from a great distance, from inside enclosed spaces) even without visual contact. If there is no visual contact, for example, because you are changing workplace, you must switch off the remote control. If there is no visual contact, for example, because the construction site is unclear, signallers **MUST** be used, and must remain in contact with the machine operator using suitable means, and have visual contact with the site of concrete placement, work areas and danger zones, and the machine.

Always ask the site management to provide you with an assistant to act as a signaller. Agree clear hand signals or other signals with the signaller so that you can communicate with each other. You should position the signaller such that he can always observe the whole of the placing boom. Your primary duty as the machine operator is to observe the site of concrete placement.

Only slew the placing boom over persons when the delivery line and end hose are empty. There is a risk of concrete falling out of the end hose.



Press the EMERGENCY STOP BUTTON immediately if the placing boom moves unexpectedly. If this should occur, you must cease working and have the cause of the fault rectified by your qualified personnel or our After Sales Service personnel.



Placing booms with placing boom hinges which allow considerable flex angles have a very large potential working area. This high manoeuvrability means different placing booms can also be moved into dangerous positions. Prohibited areas can be found in the Operating Instructions.

There is a risk that you will damage the truck, truck superstructure or obstacles on the construction site with the placing boom. Under certain circumstances it is even possible to overload or cause damage to the placing boom. Uncontrolled movements may result from the sudden, violent release of the placing boom after collisions. This may also result in (possibly fatal) personal injury.

The manufacturer has indicated such impermissible working areas by the use of warning signs and information plates on the machine and appropriate notes in the Operating Instructions.

2.5.2 End hose


The end hose must hang freely each time you start pumping, when you start pumping again after blockages, and during cleaning procedures. No one should stand within the danger zone of the end hose.



Safety Manual

Concrete delivery and placing machines

The diameter of the danger zone is twice the end hose length. Do not guide the end hose when pumping is started. There is a risk of accident from the end hose swinging out or stones being ejected.



When using a longer end hose, the diameter of the danger zone (*Extending the placing boom and end hose P. 21*) also increases.

End hoses with a length of more than 4 m must not be guided by hand.

There is a risk of injury to the hoseman if the end hose becomes caught in the reinforcement and suddenly jumps out on further movement of the placing boom.

Never bend the end hose over. Never attempt to straighten a bent end hose by increasing the pressure. The end hose must not be submerged below the surface of the concrete being delivered, otherwise the concrete may spray upwards.

The concrete may also spray from the end hose due to the presence of air in the delivery line. To prevent this from occurring, the hopper must be filled with concrete at least as far as the agitator shaft so that no air can be sucked in.

The end hose must be secured against falling.

2.5.3 Guiding the end hose ergonomically

The hoseman must guide the end hose in such a way that prevents excess spraying of concrete, and so that concrete is directed precisely into the site of concrete placement.

Control the placing boom so that the hoseman can guide the end hose without power consumption. The hoseman must not carry the end hose by hand, because the weight of it may cause permanent personal injury.



2.5.4 Connecting drills

If a drill is connected to the delivery line for the placing boom, it must not place any further strain on the placing boom. The placing boom must be connected to the drill in such a way that the placing boom does not require adjustment. There should be 1-2 delivery hoses between the placing boom and the drill; these must be secured so that they cannot move in an uncontrolled manner. If the drill is moved on the construction site, the placing boom must not be connected.

2.5.5 Procedure in storms

Return the placing boom to the driving position or rest position in the event of storms or bad weather.

- Placing booms with a vertical reach of 42 m or more must only be operated in winds of up to wind force 7 (wind speed 51 km/h).
- Placing booms with a vertical reach of less than 42 m may only be operated in winds of up to wind force 8 (wind speed 74 km/h).

The definitive wind speed is measured at the height of the boom tip.

Wind speeds in accordance with the Beaufort scale are average wind speeds measured over a period of 10 minutes. Higher speed gusts of wind may occur briefly during the measuring period.

Higher wind speeds jeopardise the stability and safety of structural elements. There is a risk of lightning strike in a thunderstorm.

Lightning strikes pose a risk of death. The machine and the surrounding area will be charged with electricity. Earthing the machine does not reduce this risk. For this reason, you should fold in the placing boom if there is a risk of lightning strike.

Tower cranes on construction sites generally have wind speed measuring equipment, enabling you to find out the wind speed at any time. If no wind speed measuring equipment is available, you can ask the nearest meteorological office what the wind speed is, or estimate the wind speed using the following rule of thumb:

- In winds of force 7 and greater, green leaves break from the trees and there is perceptible resistance when walking against the wind.
- In winds of force 8 and greater, small branches break from trees and walking outside is significantly impeded.



Safety Manual

Concrete delivery and placing machines

2.5.6 Concreting in cold weather

Placing booms must not be used at temperatures of below minus 15 °C (+5 °F) except with the express approval of the manufacturer. There is a danger of damage to the steel (brittle fracture) and the seals throughout the system at such extreme minus temperatures.

In addition, such minus temperatures should be considered the realistic lower limit for concrete placement, as it is no longer possible to prepare concrete such that it can achieve its strength without the use of special additives.

2.6 Delivery line systems


2.6.1 Suitable delivery lines

Use only delivery lines, end hoses, couplings, etc. which are in perfect condition and suitable for the delivery job and have been approved by the machine manufacturer. Delivery lines are subject to wear which varies according to the pressure and composition of the concrete, the material from which the delivery line is made, etc.

If you are not responsible for the separate delivery lines, the permissible operating pressures of these should be confirmed by the operating company.

2.6.2 Securing delivery lines


Delivery lines, delivery hoses, end hoses and couplings must be securely fastened and secured to prevent spontaneous opening.





2.6.3 Leak tightness and blockages

Regularly force water through the delivery line under operating pressure to check that the system is watertight.



A properly cleaned delivery line is the best insurance against the formation of blockages. Blockages increase the risk of accidents. Never attempt to push through a blockage (e.g. by increasing the delivery pressure, using compressed air, etc.). There is a risk of death from the delivery line bursting or from concrete being ejected from the end of the delivery line.

Prevent blockages by adjusting the operating conditions. Remove blockages by reverse pumping and then restarting forward pumping. Repeat this process several times if necessary. If the blockage is not removed, relieve the pressure on the delivery line before removing the section of delivery line concerned.



Safety Manual

Concrete delivery and placing machines

2.6.4 Opening delivery lines

Delivery lines must not be opened or tapped off while they are pressurised. Concrete exiting under pressure can cause injury. The concrete column must be depressurised by reverse pumping before the delivery line is opened. Never bend over the coupling when you are working.



2.6.5 Clearance to delivery lines

No one should remain in the vicinity of separate delivery lines during pumping operations. Cordon off the danger zone. If it is not possible to place a large enough cordon around the danger zone, the delivery line must be covered by suitable means.

2.6.6 Securing the delivery lines

Delivery lines, in particular riser lines which are not laid along placing booms, must be securely fastened in order to transfer the forces generated in them into the structure or other structural members. The lines must be laid so as to avoid kinks, sharp bends, stresses and damage during pumping operations.

2.6.7 Continuation delivery lines

If a continuation delivery line is connected to the placing boom, it must not place any further strain on the placing boom.

While you connect, use and disconnect a continuation delivery line, you must switch off the placing boom control system to prevent unintended movements of the placing boom. There is a risk of accident posed by jerky movements of the boom tip.



2.6.8 Devices for shutting off, diverting and cleaning

During operation, there is a risk of being crushed and of injury by shearing. Hydraulically driven devices are generally supplied with power by the hydraulic system of a machine. For this reason, there must always be a line of sight between the devices and the machine fitted with the control unit. Observe the safety regulations for the machine and the device when connecting and operating a device. Before operating devices, ensure that no persons are present in the danger zone.

Use only devices that are suitable and in perfect working order to shut off, divert and clean the delivery line. Defective and unsuitable devices can lead to damage to the entire delivery system and injure people in the vicinity if they fail.

2.7 Pumping operations

2.7.1 Place of work

The machine operator's place of work is with the remote control when the pump is in operation. If you operate the machine using the remote control, all operating and control devices on the machine must be closed to prevent unauthorised access.

In the case of stationary placing booms, platforms or similar equipment are only provided for assembly and maintenance work. Use of these platforms as a place of work during operation is prohibited.

It is forbidden to climb onto the machine during operation. In the case of stationary placing booms, it is forbidden to climb ladders during operation.

2.7.2 Safety

Before switching on or restarting the machine or individual machine functions, you must ensure that doing so will not endanger anyone's safety.

Refrain from any procedures that may impair the stability of the machine or are prejudicial to safety in any other way.



Safety Manual

Concrete delivery and placing machines

2.7.3 Remote control

You must always carry the remote control on your person when the machine is ready for operation. Only in this way can it be guaranteed that you can press the EMERGENCY STOP BUTTON in the event of an emergency situation. The EMERGENCY STOP BUTTON may only be unlocked once the cause/emergency has been remedied.


As a general rule, you must carry the remote control so that no control elements are activated unintentionally. If your attention is drawn away from the machine (particularly when changing place of work), you must switch off the remote control.

During breaks in pumping, interruptions, maintenance work, or before you leave the machine, you must secure it to prevent unintended movements and unauthorised use. Switch off the remote control and lock it away.

2.7.4 Moving machine components and hot surfaces

Keep all access covers, maintenance flaps, guards, etc. closed and locked during operation. This also applies in particular to the grille, water box cover and covers over cylinders. There is otherwise a risk of injury from moving machine components and a risk of burning on hot surfaces. In particular, there is a risk of burning from the engine, attached parts and the exhaust.

Never start work unless the grille is closed and bolted down or otherwise secured.



Do not touch moving parts of the machine, whether the machine is running or switched off. Always switch off the engine first, and dump the accumulator pressure where an accumulator is fitted.



Do not insert any objects (shovel handle, trowel, etc.) into moving machine components. Such objects could become trapped and dragged into the machine. They might then hit you or be torn from your hands and cause you injury.

2.7.5 Constant observation of the machine

You should be constantly observing the machine for any damage or faults while it is in use. In the event of faults or malfunctions that impair safety at work, shut the machine down immediately and secure it. Have the faults rectified immediately. If it is not possible to rectify faults which jeopardise the safe operation of the machine, you must suspend operations until the defects are rectified.

2.7.6 Truck mixer

As the machine operator, it is your role to instruct the truck mixer drivers who deliver the concrete to you, so that they are able to operate the operating elements on the concrete pump provided for their use. Only allow the truck mixer drivers to work alone once you are certain that they have understood your instructions.

Make sure that no-one stands between the approaching truck mixer and the machine. There is a risk of crushing between the truck mixer and the machine.

2.8 Cleaning

2.8.1 General


You must drain the delivery line, pump and hopper completely. Concrete residue in the hopper, in particular, may be thrown out whilst the truck is moving.

The machine must not be driven with the placing boom unfolded or the support legs extended, even over short distances. This rule also applies when you have to drive the machine to a different site for cleaning. The placing boom and support legs must be fully retracted and secured.



Safety Manual

Concrete delivery and placing machines



The preferred methods for cleaning the delivery line are reverse pumping or forced cleaning with water. The agitator must be switched on during reverse pumping. Otherwise, the concrete flowing back into the hopper can bend the agitator shaft. Use a catch basket, pipe cleaning head and wash-out ball for forced cleaning to prevent any water from flowing into the formwork.

Never spray remote controls or control cabinets with barrier agents (mould oil or similar) to protect them against contamination. This causes significant corrosion damage to the electrical system.

There is a risk of injury at all points on the machine from slipping, tripping, bumping into things, etc. Use the handles and steps to climb into and out of the machine. It is forbidden to stand on the grille. Do not jump from the machine.

Do not reach into the hopper or any other moving machine components. This rule must also be followed when you are opening the outlet on the bottom of the hopper. Do not remove the grille.

Only point the water jet into the hopper or other moving machine components. Do not insert the hose. It could become entangled with moving machine components.

2.8.2 Cleaning agents

Take care when using aggressive cleaning agents. Aggressive cleaning agents may attack materials (e.g. rubber) and painted surfaces. You can use commercially available paint cleaning and care agents, as long as these have a pH value of between 4 and 9. Ask the manufacturer of the cleaning agent to confirm its suitability. Observe the



manufacturer's instructions regarding use and safe handling. Wear protective clothing. Always rinse off cleaning agent thoroughly with clean water; do not allow puddles to form.



Do not use sea water or other water containing salt for cleaning purposes.

Do not use any highly flammable agent for cleaning; there is a risk of fire.

2.8.3 Cleaning with compressed air

When the delivery line is being cleaned with compressed air, there is an increased risk of accidents caused by compressed air escaping explosively, spurting concrete, and delivery or end hoses moving uncontrollably if they have not been removed.

Compressed air should only be used for cleaning purposes under the supervision of a subject expert. All persons participating in the cleaning procedure must be instructed in the safety regulations.

The manufacturer accepts no liability for damage caused by incorrectly performed compressed air cleaning. You must observe the following rules without fail when you use compressed air to clean out the delivery line:

- Individual pipes and short pipe runs up to 10 m in length must not be blown through with compressed air. There is a risk of accident from rebound.
- Only blow out delivery lines that have the same nominal diameter throughout their length. Reducer pipes must be drained and flushed out by hand.
- No bends, delivery or end hoses may be fitted at the end of the delivery line.



Safety Manual

Concrete delivery and placing machines

- A catch basket must be fastened at the end of the delivery line and a wash-out adaptor must be fitted on the head of the delivery line. The catch basket and washout adaptor must fit the delivery line system.
- The concrete must be able to flow freely from the end of the delivery line.
- There must be no persons present within an area of 3 m around the delivery line, at the end of the delivery line and, in particular, in front of the opening in the catch basket.
- Care must be taken to ensure that any concrete that might be expelled from the catch basket cannot injure anybody or cause any damage.
- The wash-out adaptor must be fitted with a separate, large dump cock and a pressure gauge.
- The pressure gauge must be kept under constant observation during the cleaning process. The pressure in the delivery line must be rapidly dumped via the dump cock in the event of a sudden drop in pressure (concrete column exiting from the end of the line) or increase in pressure (risk of blockage).
- The sponge ball or the plug used to push the concrete out must be sufficiently dense that the air does not pass through it into the concrete. In addition, the delivery line must be sealed to the rear when the sponge ball or plug is caught in the catch basket.
- Only work on the delivery line (particularly when opening the delivery line) if it has been depressurised. Make sure that the compressed air has been dumped completely.
- The dump cock must be opened in such a way that no-one can be injured by concrete residue that might be expelled from the dump cock.
- Separate delivery lines that are cleaned with compressed air must be securely fastened so that they cannot move uncontrollably.
- If continuing distribution systems (e.g. rotary distributors), gate valves or other delivery line elements are connected to the delivery line, they must be secured in such a way that they cannot move uncontrollably.

2.8.4 Protection against water

Water spraying on the machine from random directions has no damaging effect. The electrical system is protected against spray water, but is not waterproof.



You must close/seal all openings into which water/steam/cleaning agent must not penetrate for safety or functional reasons before cleaning the machine with water or a steam jet (high-pressure cleaner) or other cleaning agents. Electric motors and control cabinets are particularly at risk.

2.8.5 Post-cleaning procedure

After the machine is cleaned, the covers/tapes must be completely removed and the machine must be checked to ensure that it is ready for operation (*Before working with the machine P. 31*).

Look out for leaks, loose connections, chafe marks and damage during the cleaning procedure. Any identified defects must be rectified immediately. The machine must be greased after it has been cleaned using a highpressure cleaner.



3 Maintenance and special work



3.1 Requirements for special work

As the operator, it is your responsibility to provide all the necessary information to the personnel involved before special work or maintenance work is carried out. Someone should be nominated as the person responsible for this.

Carry out the maintenance and inspection operations and comply with intervals specified in the Operating Instructions, including specifications for the replacement of parts and equipment. These tasks may only be carried out by qualified personnel.

Workshop equipment appropriate to the task in hand is absolutely necessary for the execution of maintenance work.

If changes have been made to the machine, it must be checked by a subject expert before recommissioning.

Secure a wide area around the maintenance area as far as is necessary.

A machine that has been completely shut down for maintenance and repair work must be secured to prevent it being restarted inadvertently:

- Lock the main control devices and remove the key.
- If a main switch is fitted, attach a warning plate to it.

Only carry out maintenance work if the machine is parked on level and sufficiently supporting ground and is secured to prevent it rolling away.

Use specially designed or otherwise suitable climbing aids and working platforms when carrying out assembly work above head height. Never use machine parts as climbing aids. Keep all handgrips, steps, railings, platforms and ladders free from dirt, snow and ice.

Carefully secure individual parts and large assemblies to lifting equipment when carrying out a replacement operation. Use only suitable and technically perfect lifting equipment and suspension systems with adequate lifting capacity. Never stand under suspended loads.

Attachment of loads and signalling to crane operators should only be entrusted to experienced personnel. The signaller must be within visual range of or in voice contact with the crane operator.

Observe national regulations when working with lifting equipment.



Safety Manual

Concrete delivery and placing machines

Work on chassis, braking and steering systems must only be carried out by qualified personnel trained for such work.

Clean any traces of oil, fuel or preservatives from the machine, especially connections and threaded unions, before carrying out maintenance or repair work. Do not use aggressive cleaning agents. Use lint-free cleaning rags.

Bolted connections that you have loosened for carrying out maintenance and repair work must always be replaced or retightened in accordance with manufacturer specifications.

Do not open gas-filled spring elements, as used on maintenance flaps, for instance. The spring elements are filled with gas under high pressure which can escape explosively if you attempt to open them. Relieve the tension on systems under mechanical stress.

Be aware of hot functional fluids and surfaces (hydraulic fluid, hydraulic fluid radiator, etc.).

Ensure that all functional fluids, consumables and replaced parts are disposed of safely and with minimum environmental impact.

3.2 Welding

Only carry out welding, flame cutting and grinding operations on the machine once this has been expressly approved by the manufacturer.

Only qualified personnel may carry out welding work in line with manufacturer specifications, especially on the placing boom, on the supports, on load-bearing parts, on fuel and oil tanks or other components which are important for industrial safety. This work must be inspected by qualified welding personnel. The operator must document the evidence of the formal qualifications of the welder and the qualified welding personnel.

Always attach the earth cable of the welding unit directly to the component which is being welded. The welding current must not flow through hinges, cylinders, etc. Significant damage may be caused in the event of a flash over.



Electronic components can be destroyed by stray voltage during arc welding processes. For this reason:

- Disconnect the remote control cable from the control console.
- Disconnect all cables leading to the receiver of the radio remote control system.
- Close connector sockets with caps.
- Disconnect the positive and negative leads from the battery.

Clean the machine and its surroundings of dust and flammable substances and make sure that the premises are adequately ventilated before carrying out welding, flamecutting and grinding operations, otherwise there is a risk of explosion.

3.3 Working on the placing boom

Only carry out maintenance and repair work on the placing boom if the placing boom is folded or properly supported, the engine is switched off and the support legs are secured.

Support the placing boom arms before starting work on the valves, cylinders or hydraulic lines on the boom.

The delivery line was installed without tension with the placing boom in the driving position and can only be replaced without difficulty in this condition. Stresses may be generated on folding if the delivery line is replaced when the placing boom is unfolded.

Do not remove the entire delivery line but rather replace the delivery line boom arm by boom arm, for example. Otherwise, the pivot points of the new delivery line will have to be redetermined using special equipment.



Safety Manual

Concrete delivery and placing machines

3.4 Safetyrelevant components

Work on safety-relevant components requires particular specialist knowledge.

The following activities in particular must only be carried out by qualified personnel that have been authorised by the manufacturer:

- Repairing, replacing or adjusting safety-relevant components and adjustable devices (pressure limiting valves, potentiometers, fluid flow limiters, hydraulic cylinders, sensors, etc.)
- Removing lead seals

Modifications to the machine data (in particular, increasing pressures, modifying speeds, etc.) are not permitted.

3.5 Software

If a machine is equipped with software, the software may only be used as is provided for in the manufacturer's Operating Instructions.

Only persons authorised by the manufacturer may intervene in the machine's software. This also applies to updates.

Unauthorised interventions in the machine's software may lead to severe damage and accidents.

3.6 Protective and safety equipment

Any safety equipment removed for maintenance purposes must be refitted and checked immediately upon completion of this work.

All equipment required for safety and accident prevention (warning signs and information plates, grilles, guards, etc.) must be in place. Such equipment must not be removed, modified or damaged.

Keep all warning signs and information plates on the machine complete and in a perfectly legible condition.

It is your responsibility as operator to ensure that any warning signs and information plates that have been damaged or rendered illegible are replaced without delay.



3.7 Electrical power

3.7.1 General

Work on electrical systems or operating equipment must only be carried out by qualified personnel. For further information on machines that are operated using the site power supply, see also the (*Power at the construction site P. 64*) section.



Machine components which are to undergo maintenance work must be deenergised. Ensure that disconnected machine components cannot be restarted. First of all, you must check that deenergised parts are indeed deenergised, then earth and shortcircuit them and isolate adjacent live parts.

Disconnect the negative lead from the battery before starting any work on the electrical system of machines with an internal combustion engine. When reconnecting, connect the positive terminal first, and then the negative terminal.

Before starting work on highvoltage assemblies and after cutting the power supply, you must connect the supply cable to earth and short-circuit the components, particularly the capacitors, with a rodtype earth electrode.

If work is to be carried out on live parts, the presence of a second person is required who can switch off the power supply to the machine in the event of an emergency. Secure the working area with a red-and-white safety chain and a warning plate. Use insulated tools only.

3.7.2 Electrical components

Control cabinet, motor and control elements are protected as standard in accordance with degree of protection IP 54.



Safety Manual

Concrete delivery and placing machines

IP 54 means:

- Complete protection against contact with live components or internal moving parts. Protection against damaging dust deposits.
- Water spraying on the equipment from random directions must not have a damaging effect.

Use only original fuses with the specified voltage rating. Bridging or the use of fuses with too high a rating can irreparably damage the electrical system. You must switch off the machine immediately if a fault occurs in the power supply.

3.7.3 Power at the construction site

The power on the construction site must be supplied from a special feed point (construction site power distribution point). Machines with an electric motor must not be connected to the mains power supply.

Only trained and qualified personnel are permitted to work on electrical systems with an operating voltage of more than 25 volts alternating voltage or 60 volts direct current. Only such qualified personnel may install, connect, disconnect and open electrical control cabinets.


An electric shock (possibly with fatal consequences) may be the result of touching machines with electric motors or contact with other electrical cables if the electrical connection has not been made properly or the supply cable is damaged.

3.8 Hydraulic systems

3.8.1 General

Work on hydraulic systems must only be carried out by qualified personnel.

Always wear your personal protective equipment when carrying out work on the hydraulic system. Escaping fluid is toxic and can penetrate the skin.



Injection through the skin is a major medical emergency. In the event of injuries caused by pressurised fluid, inform the company medical officer and call a medical specialist immediately. This also applies for injuries which may seem only slight. Hydraulic fluid which has penetrated underneath the skin must be removed immediately. Otherwise, there is a risk of death due to impaired blood circulation and infections.

Before starting repair work, depressurise the system sections and pressure lines (hydraulic system, pneumatic system, delivery line) that are going to be opened in accordance with the assembly descriptions.

Never work on systems that are still under pressure. Switch the hydraulic pump drive and the engine off. Otherwise there is a risk of injury caused by functional fluids escaping under pressure. If there is a hydraulic accumulator, open the accumulator dump valve to prevent any machine movements caused by residual pressure. Modifications to the hydraulic accumulator are prohibited.

Be aware that enclosed hydraulic fluid can remain pressurised for a certain length of time. Do not open any hydraulic systems if they are under load from an external force (particularly from a raised placing boom).

Lay and install hydraulic lines in accordance with the current rules of engineering. Connections must be fitted at the appropriate points. Fittings and the length and quality of the hoses must comply with requirements.

The hydraulic system must be properly vented after all maintenance work. Otherwise there is a risk of injury caused by swinging and telescopic support legs extending rapidly, the placing boom lowering, etc.



Safety Manual

Concrete delivery and placing machines

Open vent valves very carefully until hydraulic fluid starts to escape. You should on no account open vent valves further than necessary or go so far as to remove them.

Damaged hydraulic lines must be replaced rather than repaired. You must replace damaged or saturated hydraulic hoses immediately. Hydraulic fluid spray escaping under pressure can cause injuries and fires.

3.8.2 Replacing hydraulic hoses

During retesting, hydraulic hoses must be checked by a subject expert for external damage. The retest must be recorded in the check book. The operator must have hydraulic hoses replaced if they show signs of external damage.

3.9 Noise emissions

The place of work in normal operation is with the remote control. For this reason, it is not possible to specify a particular place of work for the machine operator. Take the values for the sound pressure level and sound power level from the machine Operating Instructions.

Wear suitable personal protective equipment in the vicinity of the machine.

As the operator, you must instruct your personnel to always wear their personal hearing protectors. You are responsible for ensuring that your personnel comply with this regulation.

All soundproofing equipment must be fitted and in perfect condition. All soundproofing equipment must be closed during operation. A high sound level can cause permanent hearing damage.

3.10 Exhaust fumes

Vehicle exhaust gases contain constituents that can be deadly or carcinogenic. Operate internal combustion engines and fuel-operated heating systems only in adequately ventilated premises. Before starting up the engine in enclosed spaces, make sure that there is adequate ventilation and direct the exhaust gases away from the place of work.



Wear personal protective clothing and equipment for all work in which exhaust gases or particles of building material can enter the body through the respiratory passages. Comply with the information issued by the manufacturer of the building material.

3.11 Functional fluids

When handling oils, greases and other functional fluids, observe the safety regulations applicable to the product concerned (see the safety data sheet).

Oils, fuel and other functional fluids may be hazardous to health upon contact with the skin, etc. You must therefore always wear personal protective clothing and equipment when you are handling toxic, caustic or other functional fluids that are hazardous to health and always take note of the manufacturer's information.



Take care when handling toxic and caustic functional fluids (brake fluid, battery acid, water glass, concrete set accelerating admixtures, cement, etc.). Building materials containing cement have a highly alkaline effect when they react with water (and also with perspiration). Admixtures are toxic and caustic.

Cleaning agents, concrete release agents, preserving agents etc. propelled by compressed air can cause very serious damage to the respiratory tract if a respiratory protection mask is not worn. Spray mist enters the lungs very easily.

Frequent injuries are eye injuries caused by concrete spatter, water glass or other chemical substances.


Take care when handling hot functional fluids and consumables (risk of burning or scalding).



Safety Manual

Concrete delivery and placing machines

Have used operating equipment and functional fluids such as filters, batteries, oil, brake fluid, etc. disposed of properly. Used cleaning rags should also be disposed of properly.



3.12 Disposal of the machine

To dispose of the machine, you must proceed in accordance with all points in the disposal regulations which apply in your country.

During the disposal operation, you must observe the following in particular:

- Remove the functional fluids, particularly hydraulic fluids, engine oils, fuel, brake fluid, concrete admixtures, any environmentally hazardous functional fluids or functional fluids which are hazardous in any other way, and dispose of these correctly.
- Remove the operating equipment, particularly the hydraulic fluid reservoir, hydraulic cylinder, hydraulic fluid radiator, hydraulic lines and hoses and other components which may contain residual functional fluids, and dispose of these correctly.
- Remove the steel structure and dispose of it correctly, e.g. by recycling.
- Dispose of the truck or the drive unit correctly.



Index

In this chapter, you will find the most important keywords and the number(s) of the page(s) on which they appear. This index of key words is in alphabetical order.

A

Accessories and attachments *P. 23*
After Sales Service personnel *P. 13*
Arm assembly *P. 11*

B

Base structure *P. 11*
Before working with the machine *P. 31*

C

Changes to the machine *P. 23*
Checking that the machine is ready for operation *P. 31*
Cleaning *P. 51*
Cleaning agents *P. 52*
Cleaning with compressed air *P. 53*
Clearances *P. 32*
Clearance to delivery lines *P. 48*
Climbing the placing boom *P. 23*
Concrete pump *P. 11*
Concreting in cold weather *P. 46*
Connecting drills *P. 45*
Constant observation of the machine *P. 51*
Continuation delivery lines *P. 48*
Corner bearing loads *P. 38*

D

Danger due to high voltage *P. 31*
Danger zone *P. 17*

Definition of terms *P. 11*

Delivery line systems *P. 12, 18, 46*

Designated use *P. 18*

Devices for shutting off, diverting and cleaning *P. 49*

Discharge voltage pattern *P. 32*

Disposal of the machine *P. 68*

Driving *P. 39*

E

Earthing in the event of electrostatic charging *P. 34*

Earthing on construction sites with special equipment
P. 34

Electrical components *P. 63*

Electrical power *P. 63*

End hose *P. 12, 18, 43*

Exclusion of liability *P. 24*

Exhaust fumes *P. 66*

Extending the placing boom and end hose *P. 21*

Extending the reach *P. 21*

F

Foreword *P. 7*

Functional fluids *P. 67*

G

General *P. 51, 63, 64*

Guiding the end hose ergonomically *P. 44*



Safety Manual

Concrete delivery and placing machines

H

Highpressure delivery *P. 23*
High-voltage lines *P. 31*
Highvoltage warning devices *P. 33*
Hopper *P. 18*
Hoseman *P. 12*
Hydraulic systems *P. 64*

I

Impermissible end hose *P. 22*
Impermissible working area *P. 17, 22*
Improper use *P. 20*
Inspection intervals for retesting *P. 19*

L

Leak tightness and blockages *P. 47*
Lifting loads *P. 21*
Lifting machines and components *P. 35*
Loading *P. 41*
Loading and transporting *P. 35*

M

Machine *P. 11, 18*
Machine operator *P. 12*
Maintenance *P. 13*
Maintenance and special work *P. 57*
Manufacturer *P. 12*
Mobile machines *P. 14, 36*
Moving machine components and hot surfaces *P. 50*

N

Noise emissions *P. 66*

O

Opening delivery lines *P. 48*
Operating Instructions *P. 25*
Operating Instructions, operating procedures and other regulations *P. 25*
Operating procedures *P. 26*
Operator *P. 12*
Other regulations *P. 27*

P

Personal protective equipment *P. 27*
Personnel *P. 24*
Place of work *P. 16, 49*
Place of work, working area, danger zone *P. 14*
Place of work – hoseman *P. 16*
Place of work – machine operator *P. 16*
Place of work – truck mixer driver *P. 16*
Placing boom *P. 11, 17*
Placing booms *P. 42*
Post-cleaning procedure *P. 55*
Power at the construction site *P. 64*
Procedure in storms *P. 45*
Procedure in the event of a flash over *P. 33*
Protection against water *P. 54*
Protective and safety equipment *P. 62*
Pumping operations *P. 49*

Q

Qualifications *P. 25*
Qualified personnel *P. 13*

R

Remote control *P. 50*



Removing obstacles *P. 21*
Rendering the machine ready for operation *P. 31*
Replacing hydraulic hoses *P. 66*
Requirements *P. 24*
Requirements for special work *P. 59*
Responsibility of the machine operator *P. 25*
Retesting (safety inspection) *P. 19*

S

Safety *P. 49*
Safetyrelevant components *P. 62*
Securing delivery lines *P. 46*
Securing the delivery lines *P. 48*
Setting up and working with the machine *P. 29*
Setup site *P. 35, 36*
Signaller and other auxiliary personnel *P. 13*
Software *P. 62*
Stationary machines *P. 14, 35*
Stationary placing booms *P. 35*
Subject expert *P. 13*
Suitable delivery lines *P. 46*
Supporting ground *P. 37*
Support legs and support feet *P. 17*
Supports *P. 38*

T

Terms, definitions, requirements *P. 9*
Towing *P. 41*
Transporting goods *P. 20*
Truck mixer *P. 12, 51*
Truck mixer driver *P. 13*

U

Unfold placing boom *P. 42*

W

Welding *P. 60*
Working area *P. 16*
Working on the placing boom *P. 61*

Verband Deutscher Maschinen- und
Anlagenbau e.V. (VDMA)
Bau- und Baustoffmaschinen
Lyoner Straße 18
60528 Frankfurt

Telefon +49 69 66 03 -1262

Fax +49 69 66 03 -2262

E-Mail bub@vdma.org

Internet bub.vdma.org

bub.vdma.org