# PACIFIC SUPPLYCO



Seattle (206) 322-1717 • Washington State (800) 541-9989 • Fax (206) 322-1744

## **Mop Bucket**

- Professional Rubbermaid 35 quart mop bucket
- WaveBrake® separates dirty water from the cleaning solution
- Rolling casters
- Powerful mop wringer
- Doubles as portable bucket





### Heavy Duty 42-Gallon Contractor Trash Bags



- Extra thick 3-mil bags for heavy-duty contractor use
- 2 ft. 9 in. x 4 ft.
- 20 bags and ties
- 42 gallon/ 6 bushel/171 liter capacity



A rease they

### Swiffer Wetjet

- All-in-one power mop starter kit
- Pulls and locks in the dirt and dirty water forever
- 1 pad easily cleans up to 2 large rooms or 30 sq. meters
- Safe on virtually all floors including wood and laminate, vinyl and linoleum, ceramic tiles, marble, stone and others.
- Kit contains power mop, 500mL bottle of multipurpose cleaning solution, dispos-

able cleaning pads, scrubbing strip (4 AA batteries not included)

Refills available



# **FIPS&TECHNIQUES**

### POST-IT NOTE FOR EASY DRILLING CLEANUP

When drilling into drywall, stick a Post-it underneath where you are drilling. Fold the Post-it in a V to catch all the drilling dust for little or no mess! (*from lifehacker.com*)

### NATURAL ROACH REPELLENT

Mix a handful of cloves with a handful of epson salts in a shallow dish. Place this in the cockroaches' favorite hiding spots: dishwashers, sinks, washing machines. A few drops of clove oil in corners and cupboards should help keep them away, too! (from homelife.com.au)

### SANDPAPER OPENS STUCK JAR

For stuck jars that are difficult to open, wrapping sandpaper around the lid may provide enough traction for you to open the jar! (Others have also recommended wrapping rubber bands around the lid for traction.)

#### **REMOVING CARPET STAINS**

Spray the stained area with a mixture of  $^{1/4}$  part white vinegar to  $^{3/4}$  parts water. Lay a damp towel over it, and iron with a hot iron set on the steam setting.

You can also remove candle wax on carpet. Lay a few paper towels over the waxy area. Iron over it with an iron set to a warm setting. The wax should melt enough to be absorbed by the paper towels.

