

NVR-series Install Camera Instruction

Compatible Model

NVR-0504	NVR-0508	NVR-1316	NVR-1332
NVR-0437	NVR-0732	NVR-0764	

Camera Protocol List

LevelOne 1

NVR include PoE port only working with Levelone1 protocol cameras.

FCS-3073	FCS-3084	FCS-3085	FCS-3086	FCS-3087
FCS-3088	FCS-3090	FCS-3096	FCS-3097	FCS-3098
FCS-4103	FCS-4203	FCS-5058	FCS-5059	FCS-5060
FCS-5067	FCS-5068	FCS-5092	FCS-5093	FCS-5094
FCS-5095	FCS-5096			


LevelOne 2

FCS-3101	FCS-3102	FCS-4101	FCS-4102	FCS-4201
FCS-4202	FCS-4301	FCS-4302	FCS-4041	FCS-4047
FCS-4059	FCS-1131	FCS-5051	FCS-5061	FCS-3081
FCS-3095				

LevelOne 3

FCS-1153	FCS-1154	FCS-1158	FCS-1160	FCS-5053
FCS-3053	FCS-3054	FCS-3055	FCS-3056	FCS-3063
FCS-3064	FCS-3065	FCS-3072	FCS-3082	FCS-3083
FCS-3092	FCS-3093	FCS-3094	FCS-3302	FCS-3303
FCS-3305	FCS-3306	FCS-3307	FCS-3304	FCS-4042
FCS-4044	FCS-4045	FCS-4046	FCS-4048	FCS-4043
FCS-5054	FCS-5055	FCS-5055	FCS-5056	FCS-5057
FCS-5063	FCS-5064	FCS-5065	FCS-5066	FCS-5101
FCS-5102	FCS-5103	FCS-5104		


1. Please login NVR Local GUI Menu into camera setting page



2. Click Edit



3. Edit camera information



Add Method :

Manual type: Support all camera include thirty part cameras.

Auto type: Support Protocol **LevelOne 1** cameras Plug and play with include PoE NVR-series.

IP Camera address :

Fill Camera IP address

Protocol:

LevelOne1, **LevelOne2**, **LevelOne3**, SONY, AXIS, BoSCH, SAMSUNG, PANASONIC....etc,
Please follow protocol of camera type; Levelone camera list refer P.1 camera type list.

4. Camera Management page Click Status pre-view video

