



# 深圳市深翔宇科技有限公司

广东省深圳市龙岗区布吉镇中心区诚信华庭2栋8B室

Tel: 86-755-33217600/33217601/33217602 Fax: 86-755-33217603

<http://www.sxyprinterparts.com> <http://sxy.en.alibaba.com>

## Accessories

printer model		parts	part no.
<b>HP LaserJet 1000/1200/1220</b>			
HP	Laser Jet 1000/1200	Fuser gear,29T	RAO-1088-000
HP	Laser Jet 1000/1200	Fuser gear,17T	RAO-1089-000
HP	Laser Jet 1000/1200/1300/1150/Canon383	Bushing Pressure roller	RAO-1094/1095
HP	LJ1000/1200/1150/1300/3300/3330/3380	Clutch separation	RAO-1154/ RM1-0551
HP	Laser Jet 1000/1200	Pickup gear 28T	RGO-1020-000
HP	LJ1000/1200/1300	fuser gear 19T	RA0-1118-000
HP	Laser Jet 1000/1200	Delivery roller	RAO-1198-000
HP	Laser Jet1000/1150/1200/1220/1300/3300/ Canon1210/3112/3200	Fuser pressure roller(Black)	RFO-1002-000
HP		Fuser pressure roller(Red)	RF5-2824-000
HP	Laser Jet 1000/1200	Delivery roller	RFO-1003-000
HP	Laser Jet 1000/1200/3300/3300/Canon383	Pick up roller	RFO-1008-000 (RL1-0303-000)
HP	Laser Jet 1000/1200	Separation pad	RFO-1014-000
HP	Laser Jet 1000/1200	Upper delivery roller	RFO-1114-000
HP	Laser Jet 1000/1200	Ashast paper pick up	RGO-1007-000
HP	Laser Jet 1000/1200	Transter Roller	RG9-1483-000
HP	Laser Jet 1000/1200	Fuser Gear	RG9-1483-Gear
HP	Laser Jet 1000/1200	Bushing transfer roller	RG9-1483-Bsh
HP	Laser Jet 1000/1200/1300/1150/Canon383	Arm swing gear	RA0-1005-000
HP		Arm swing gear with shelf	RA0-1005-000
HP	Laser Jet 1000/1200/1300	Cartridge Guide Fuser Handle Left Holding Lever	RA0-1022-000
<b>HP LaserJet M1005mfp</b>			
HP	Laser Jet M1005mfp	Transfer roller W/Gear	RM1-2093-000
HP	Laser Jet M1005mfp	Fuser pressure roller	RM1-0660-000
HP	Laser Jet M1005mfp	Separation pad	RC1-2038-000
HP	Laser Jet M1005mfp	Separation Assembly	RMI-0648-000
HP	Laser Jet M1005mfp	Pick up roller	RC1-0266-000
<b>HP LaserJet P1005</b>			
HP	LJP1005/1006/1102/1120/1505/1606 /M1522/1536MFP;Canon LBP3018/3010/3050	Transfer roller	RM1-4023-000
HP	Laser Jet P1006	Bushing pressure roller	/
HP	Laser Jet P1005	Separation pad	RM1-4006-000
HP	Laser Jet P1005/1008/1006/1007/1515/Canon LBP3018/3010/3050	Pick up roller	RL1-1442/ RC2-1048
HP	LJ P1005/1006/1007/1008/1515	Fuser pressure roller	/
<b>HP LaserJet P1008</b>			
HP	LJP1005/1006/1102/1120/1505/1606 /M1522/1536MFP;Canon LBP3018/3010/3050	Transfer roller	RM1-4023-000
HP	Laser Jet P1008/1006/1007/1515	Separation pad	RM1-4006-000

HP	Laser Jet P1005/1008/1006/1007/1515/Canon LBP3018/3010/3050	Pick up roller	RL1-1442-000
HP	LJ P1008/1006/1007	upper fuser cover	/
HP	LJ P1005/1006/1007/1008/1515	Fuser pressure roller	LPR-1008
<b>HP LaserJet 1010/1020</b>			
HP	Lasterjet 1010/M1005/1012/1015/1020/301 5/3020/3030/Canon LBP2900/LBP3000	Separation pad	RC1-2038-000
HP	Laster jet 1010/1020	Separation pad	RC1-2048-000
HP	Lasterjet 1010/1020/1012/1015/1018/1020/ 1022/3015/3020/3030/M1005/305 0/3052/3055/1600/2600/2605/Can on LBP2900/IC MF4350	Pick up roller	RC1-2050/RC1- 2030/RL1-0266
HP	Laster jet 1010/1020	Transfer roller W/Gear	RM1-0658-000
HP	Lasterjet 1010/1020/1012/1015/1018/3015/ 3020/3030/M1005/Canon LBP2900	Fuser pressure roller	LPR-1010
HP	Laster jet 1010/1020	Fuser Delivery roller Assy	RC1-2094-000
HP	Laster jet 1010/1020	Delivery roller	RC1-2051-000
HP	Laster jet 1010/1020/3600	Clutch separation roller	RU5-0184-000
HP	Laster jet 1010/1020/1015/1018/1022	Fuer Gear 29T	RU5-0185-000
HP	LJ1010/1018/1020/1022/3050/30 15/3020/3030	Fuer Gear 14T	GR-1010-14T
HP	Lasterjet 1010/1020/1012/1015/1018/1020/ 1022/3015/3020/3030/M1005/ Canon LBP2900	Bushing pressure roller(L&R)	RC1-2079-000
HP	Laster jet 1010/1020	Separation pad Assembly	RMI-0648-000
<b>HP LaserJet 1022/3050</b>			
HP	Laser Jet 1022	Lever Fuser Holding Right	RC1-5568-000
HP	Laser Jet 1022	Lever Fuser Holding Left	RC1-5567-000
HP	Laser Jet 3020/3050/3055	Lever Fuser Holding Right	RC1-2489-000
HP	Laser Jet 3020/3050/3055	Lever Fuser Holding Left	RC1-2488-000
HP	Laser Jet 1022/3050	Pick up roller	RC1-2050-000
HP	Laser Jet 1022/3050/3052/3055/Canon 1010	Fuser pressure roller	LPR-1022-000
HP	Laser Jet 1022/3050	Delivery roller	RC1-2094-000
HP	Laser Jet 1022/3050	Delivery roller	RC1-2051-000
HP	Laser Jet 1022/3050	Clutch separation roller	RU5-0184/0183
HP	Lasterjet 1010/1020/1012/1015/1018/1020/ 10222/3015/3020/3030/3050/M10 05/ Canon LBP2900	Bushing pressure roller ( 1 set )	RC1-2079-000
HP	Laser Jet 1022/3050	Separation pad Holder	RC1-5563-000
HP	Laser Jet 1022/3050	Separation pad	RC1-5564-000
HP	Laser Jet 1022/3050	Separation Assembly	RM1-2048-000
HP	LJ1022/3050/3052/3055/3030/30 20/3015	Fuser gear 37T	RU5-0523-000
HP	LJ1022/3050/3052/3055 74T	Fuser drive gear 原装全新黑色	RU5-0505
HP	Laser Jet 1022/3050	Transfer roller	RM1-0658-000
<b>HP Laser Jet 1100/3200</b>			
HP	Laser jet HP 1100/3200/Canon 940	Separation pad	RF5-2832-000
HP	Laser jet 1100/3200	Separation pad Kit	RY7-5050-000
HP	Laser jet HP 1100/3200/Canon 940	Separation pad ARM	RF5-2886-000
HP	Laser jet 1100/3200	Spring for Separation Arm	RS5-2502-000
HP	Laser jet HP 1100/3200/Canon 940	Pick up roller	RB2-4026-000

HP	Laser jet 1100/3200	Feed roller	RB2-3912-000
HP	Laser jet 1100/3200	CAM	RB2-3949-000
HP	Laser jet 1100/3200	Pick-Up Assembly(37T)	RG5-4585-000
HP	Laser jet 1100/3200	Roller Face-Down	RF5-2830-000
HP	Laser jet 1100/3200	Roller Face-up	RF5-2822-000
HP	Laser jet 1100/3200	Fuser pressure roller	RF5-2823-000
HP	Laser jet 1100/3200	Transfer roller	RG5-4657-000
HP	Laser jet 1100/3200	Bushing Left pressure roller	RB2-3956-000
HP	Laser jet 1100/3200	Bushing Right pressure roller	RB2-3957-000
HP	LJ1100/8100/8150/4600/4650/4700/5500/5550	Data cable	大口转小口, 并口18针

### HP LaserJet 1160/1320

HP	Laser Jet 1320/1160/2015	Delivery roller	RC1-3654-000
HP	LJ1320/1160/2400/2420/P2015/P3015/5/5200/M3027/M3035MFP	Separation pad	RM1-1298-000
HP	Laser Jet 1320/1160	Paper Pick- up roller	RL1-0540-000
HP	Laser 1320/1160/2420	Paper Pick- up roller Paper Pick- up roller-original	RB2-2891-000
HP	Laser Jet 1320/1160	Transfer roller M/Gear	RM1-1471-000
HP	Laser Jet 1320/1160	Fuser pressure roller	RC1-3612-000
HP	Laser Jet 1320/1160	Delivery roller	DP-1320-000
HP	Laser Jet 1320/1160	Delivery roller	RC1-3691-000
HP	Laser 1320/1160/2015	Lower Roller Gear 17T	RU5-0330-000
HP	Laser 1320/1160/2420/2400/2015	Lower Roller Gear 29T	RU5-0331-000
HP	Laser 1320/1160/2015	Lower Roller Gear 19T	RU5-0332-000
HP	Laser Jet 1320/1160	Clutch separation	RU5-0325-000 RM1-1301-000
HP	Laser Jet 1320/1160	Roller,Pick up Cam	RC1-3471-000
HP	Laser Jet 1320/1160	Roller holder	HR-1320-000
HP	Laser Jet 1320/1160	Fuser Gear 27T	RU5-0307-000
H.P	Laser Jet 1320/1160/P2015	Swing gear	RC1-3575-000
HP	Laser 1320/1160/2420/2400/P2015	Bushing pressure roller	RC1-3609/3610
HP	Laser 1320/1160/2100/IR1210	Fuser Gear 14T	RS6-0442-000
HP	Laser 1320/1160/2100/IR1210	Fuser Gear 15T	RS6-0443-000
H.P	Laser Jet 1320/1160/2015	Fuser Latch Clip, left	RC1-3616-CLN
H.P	Laser Jet 1320/1160/2015	Fuser Latch Clip, right	RC1-3617-CLN
H.P	Laser Jet 1320/1160/2015	Fuser guide	RC1-3621-000
H.P	Laser Jet 1320/1160	Bushing/shaft retainer	RC1-3665
H.P	Laser Jet 1320/1160	Roller Assy, Output Fuser	RC1-3645

### HP Laserjet P1505

HP	Laser Jet p1505	Separation pad	RM1-4207-000
HP	Laser Jet P1505/P1566/P1606/M1120/M1522NF	Paper Pick- up roller	RL1-1497-000
HP	Laser Jet p1505	Transfer roller	RM1-4234-000
HP	Laser Jet p1505	Clutch separation roller 31T/32T	RU5-0024-000
HP	Laser Jet p1505/1522	Swing Gear	RU6-0018-000
HP	LJ P1505/M1522/M1120/M1536/M1566/P1102W/1606	Fuser Preesure Roller	LPR-M1522-000

### HP Laserjet M1522mfp

HP	LJ M1522mfp	Transfer roller	TNR-HP1522
HP	HP 2820/2830/2840/3020/3030/3052/3300/3310/3320/3330/3380/3390/3392/M1522/M2727/CM1312/CM2320	ADF Pickup Roller Ass'y	C8187-67533/ CC334-60068/ C7309-60091/ C7309-60049/ C7309-60016
HP	HP3050 HPM1522 HPM2320 HPM2727	ADF Pickup Roller Kit	5851-3580-RK

HP	LJ P1505/M1522/M1120/M1536/M1566	Fuser Pressure Roller	LPR-M1522-000
<b>HP Laserjet P2015</b>			
HP	Laser jet 2015/1320	Gear 29T, Lower Roller	RU5-0331-000
HP	Laser jet 2015/1160	Roller, Pick up Cam	RC1-3471-000
HP	Laser jet 2015/1160	Clutch separation roller	RU5-0325-000
HP	Laser jet 2015/1160		RM1-1301-000
HP	Laser jet 2015/1320	Bushing Left, pressure roller	RC1-3610/3609
HP	Laser jet 2015	Lever Fuser Holding Right	RC1-3616-000
HP	Laser jet 2015	Lever Fuser Holding Left	RC1-3617-000
HP	LJ1320/1160/2400/2420/P2015/P3015/5200/M3027/M3035MFP	Separation pad	RM1-1298-000
HP	Laser jet 2015/5200	Separation pad Tray1	RB2-1524-000
HP	Laser jet 2015	Paper Pick- up roller Tray2	RB2-2891-000
HP	Laser jet P2014/P2015/M2727	Pick- up roller Tray1	RL1-1525-000
HP	Laser jet 2015	Paper Pick- up roller Tray2	RL1-0540-000
HP	Laser Jet 2015/1160	Delivery roller	RC1-3654-000
HP	Laser jet 2015	Arm swing	RC1-3575-000
HP	Laser jet 2015	Transfer roller	RM1-4279-000
HP	Laser Jet 2015/1160	Delivery roller	DP-1320-000
HP	Laser Jet P2015	Fuser pressure roller	LPR-2015
HP	LJ2015/2400/2420/M3027/M3035MFP	Pick up roller	RL1-0568/ RL1-0569
<b>HP Laserjet P2035</b>			
HP	Laser jet P2035/2055/pro 400/M401;Canon LBP6300/6650	Fuser pressure roller	LPR-P2035
HP	LJ P2035/P2055;canon LBP6300	Bushing pressure roller	/
HP	Laser jet P2035	Clutch separation roller	RU5-0325-000
HP	Laser jet P2035	Arm swing gear	/
HP	Laser jet P2035	Roller, Pick up Cam	RC1-3471-000
HP	Laser jet P2035	Transfer roller	N/A
HP	Laser jet P2035	Fuser gear	GR-P2035-27T
HP	Laser jet P2035	Bushing pressure roller	N/A
HP	Laser jet P2035/2055	Separation pad Tray 1	RL1-2115-000
HP	Laser jet P2035/2055	Separation pad Tray 2	RM1-6397-000
HP	Laser jet P2035/2055	Pickup roller, Tray 2	RM1-6414
HP	Laser jet PP2030/2035/2050/2055	Pickup roller, Tray 1	RL1-2120
<b>HP Laser jet 2100</b>			
HP	Laser jet 2100	Transfer roller w/gear	RG5-4164-000
HP	Laser jet 2100;Canon IR1510/1210/1230/1270/1310/1330/1370F/1510/1530/1570/1630/1670;Canon IC D660/D661/D680F/D760 /D761/D780/D860/D861, /D880;Canon PC1060/1061/1080F/PC1255/PC1275	Fuser Pressure Roller	RF5-2601-000
HP	Laser jet 2100	Delivery roller	RF5-2603-000
HP	Laser jet 2100	Delivery roller	RF5-2604-000
HP	Laser jet 2100/2200/1500/2500	Bushing(pressure roller)	RB2-2973-000
HP	Laser jet 2100/2200/2250/2820/2840/iR1210/1230/1310/1370F	Pick up roller mp tray	RB2-2900-000
HP	Laser jet 2100/2200	Separation pad Tray1	RB2-2835/6348
HP	Laser jet 2100	Separation pad Tray1	RB2-2838-000
HP	Laser jet 2100/2200	Separation pad Tray2	RB2-3008-000

HP	Laser jet 2100/2200	Separation pad Tray2	RB9-0695-000
HP	Laser jet 2100/2200/2300/1160/1320	Pick up roller	RB2-2891-000
HP	Laser jet 2100	Roller, Guide	RB2-2892-000
HP	Laser jet 2100	Upper Delivery roller	RB2-2851-000
HP	Laser jet 2100	Gear assembly,drive	RG5-4156-000
HP	Laser jet 2100	Clip pick up	RB1-2190-000
HP	Laser jet 2100	Fuser gear(15T)	RS6-0443-000
HP	Laser jet 2100	Fuser gear(14T)	RS6-0442-000
HP	Laser jet 2100/IR1210	Fuser gear(26T)	RS6-0458-000
HP	Laser jet 2100	Fuser Delivery roller Assy	RF5-2603-000

### HP Laser Jet 2200

H.P	Laser Jet 2200/2100/2300	Separation pad Tray2	RB2-6349-000
H.P	Laser Jet 2200/2100	Separation pad Tray1	RB2-6348-000
H.P	Laser Jet 2200/2100	Separation pad	RB9-0695-000
H.P	Laser Jet 2200	Separation pad Holder Tray 1	RF5-6254-000
H.P	Laser Jet 2200	Separation pad Assy Tray 1	RB2-3272-000
H.P	Laser Jet 2200/IR1210	Pick up roller mp Tray	RB2-2900-000
H.P	Laser Jet 2200	Transfer roller W/Gear	RG5-5581-000
H.P	Laser Jet 2100/2200	Bushing pressure roller	RB2-2973-000
H.P	Laser Jet 2200	Fuser pressure roller	RB2-6368/6369
H.P	Laser Jet 2200	Fuser Delivery roller Assy	RB2-6372-000
H.P	Laser Jet 2200/2100/1160/1320/2300	Pick up roller	RB2-6304-000 RB2-2891-000
HP	Laser jet 2200	Roller, Guide(1 set)	RB2-2892-000
H.P	Laser Jet 2200	Upper Delivery roller Assy	RF5-3275-000
HP	Laser Jet 2200	Gear,15T,UpperDelivery Roller	RS6-0441-000
H.P	Laser Jet 2200	Fuser Gear 27T	RS6-0923-000

### HP Laser jet 2300

HP	Laser jet 2300	Separation pad,Tray 2	RC1-0954-000
HP	CLJ3500/3700;LJP3005/2300/2400/2420	Separation pad Tray 1	RC1-0939-000
HP	Laser jet 2300	Pick up roller	RB2-6304-000
HP	Laser jet 2300	Roller, Guide(2pcs)	RB2-2892-000
HP	Laser jet 2300	Pick up roller, Tray 2	RC1-0945-000
HP	Laser jet 2300	Transfer roller W/Gear	RM1-0338-000
HP	Laser jet 2300	Bushing pressure roller(2pcs)	RC1-0988-000
HP	Laser jet 2300	Fuser pressure roller	RC1-0991-000
HP	Laser jet 2300	Delivery Roller Assemldy	RM1-0371-000
HP	Laser jet 2300	Upper Delivery roller	RB2-2851-000 RC1-0982-000
HP	Laser jet 2300	Fuser Gear 27T	RS6-0923-000
HP	Laser jet 2300	Separation pad	RF5-4258-000

### HP Laser Jet 2420/2400

H.P	LJ1320/1160/2400/2420/P2015/P3015/5200/M3027/M3035MFP	Separation pad-Tray2	RM1-1298-000
H.P	CLJ3500/3700;LJP3005/2300/2400/2420	Separation pad-Tray1	RC1-0939-000
H.P	Laser Jet 2420	Pick up roller	RL1-0542-000
H.P	LJ2015/2400/2420/2430/M3027/M3035MFP	Pick up roller	RL1-0568/ RL1-0569
H.P	Laser Jet 2400/2420	Fuser pressure roller	RC1-3969-000
H.P	Laser Jet 2420	Delivery roller lower	DR-2400-LO
H.P	Laser Jet 2420	Delivery roller	RC1-3991-000
H.P	Laser Jet 2420/1160	Bushing pressure roller Left	RC1-3610-000
H.P	Laser Jet 2420/1160	Bushing pressure roller Right	RC1-3609-000
H.P	LJ2400/2420/P3005/M3027/M3035	Transfer roller W/Gear	RM1-1508-000
H.P	Laser Jet 2420/2400	Pickup cam	RC1-3913-000
H.P	Laser Jet 2420/2400/P3005	Gear(26T)	RU5-0366-000

HP	Laser Jet 2420/2400(Cluster of Fuser Driver Gears)	GEAR(21T)	RU5-0377-000
HP		GEAR(20T)	RU5-0378-000
HP		GEAR(19T)	RU5-0379-000
HP	Laser Jet 2420/2400	Gear	RU5-0383-000
H.P	Laser Jet 2420/1160/1320	Lower Roller Gear 29T	RU5-0331-000
H.P	Laser Jet 2400/2420	Fuser Gear 15T	GR-2400-15T
H.P	Laser Jet 2400/2420/2430/P3005	Guide,Upper delivery	RC1-3976-000
H.P	Laser Jet 2400/2420/2430/P3005	Guide,Lower delivery	RC1-3977-000
H.P	Laser Jet 2400/2420	Fuser cover	RC1-3989-000
H.P	Laser Jet 2400/2420/P3005	Entrance Guide	RC1-3974-000

### HP Laserjet P3005

HP	CLJ3500/3700;LJP3005/2300/2400/2420	Separation pad-Tray1	RC1-0939-000
HP	LJ2015/2400/2420/M3027/M3035 MFP	Pick up roller, Tray 1	RL1-0568/ RL1-0569
HP	LJ1320/1160/2400/2420/P2015/P3015/5200/M3027/M3035MFP	Separation pad-Tray2	RM1-1298-000
HP	M3027/M3035/P3005	Separation Pad and Holder Assembly, Tray-2 or Tray-3 500-Sheet Tray	RM1-3738/ RM1-6303
HP	LJ P3005/P3015/M3027M3027/M3035	Pickup Roller Assembly Tray2	RM1-6313/3763
HP	Laser Jet P3005/M3027/M3035	Pick up roller, Tray 2/3	RL1-1370/3167
HP	LJ2400/2420/P3005/M3027/M3035	Transfer roller W/Gear	RM1-1508-000
HP	Laser Jet P3005	Delivery roller lower	DR-P3005-LO
HP	Laser Jet P3005	Guide blade	RC1-3974-000
HP	LJ M3027/3035/P3005	Gear 42T	RU5-0955-000
HP	Laser Jet	Gear 20/20T	RU5-0956-000
HP	P3005/M20/20/M3027/M3035(一整套就是四个齿轮加一个卡扣)(Cluster of Fuser Driver Gears)整套6元13071500500T	Gear 20T	RU5-0957-000
HP		Gear 17T	RU5-0958-000
HP		Gear 19T	RU5-0959-000
HP	LJ M3027/3035/P3005	Gear 31T	RU5-0960-000
HP	Laser Jet P3005	Gear 19T/31T	RU5-0961-000
HP	LJ M3027/3035/P3005	Gear 65T	RU5-0962-000
HP	Laser Jet P3005	Gear , Roller 29T	RU5-0964-000
HP	Laser Jet P3005	Fuser gear 20T	RU5-0966-000
HP	Laser Jet P3005/M3035/M3027	Fuser pressure roller	LPR-3005
HP	Laser Jet P3005	PAPER PICK UP ASS'Y	RM1-3762-000
HP	Laser Jet P3005	Gear 15T	GR-P3005-15T
HP	Laser Jet P3005/M3035/M3027	Bushing,pressure roller (2pcs)	/
HP	Laser Jet P3005/M3035/3027	Fuser Preesure Roller	/
HP	LJ2400/2420/P3005	Fuser Lower Delivery Guide	RC2-0670

### Laser Jet 3010/3020/3030

HP	Laser Jet 3010/3015/3030	Separation pad	RC1-2038-000
HP	Laser Jet 3010/3015/3030	Separation pad	RC1-2048-000
HP	Laser Jet 3010/3015/3030	Pick up roller	RC1-2050/2030
HP	Laser Jet 3010/3015/3030	Transfer roller, W/Gear	RM1-0658-000
HP	Laser Jet 3010/3015/3030	Fuser pressure roller	RM1-0660-000
HP	Laser Jet 3010/3015/3030	Clutch separation roller	RU5-0184-000
HP	Laser Jet 3010/3015/3030	Delivery roller	RC1-2094-000
HP	Laser Jet 3010/3015/3030	Delivery roller	RC1-2051-000
HP	Laser Jet P3003/3027/3035	PAPER PICK UP ASS'Y	RM1-3762-000
HP	LJ 3015/3050/M1319	Scanner Separation Pad	RM1-0891

### HP Laser Jet P3015



HP	Laser Jet P3015/P3020/P3030	Fuser Pressure roller	LPR-P3015
HP	Laser Jet P3015	Transfer roller,with gear	RM1-6321
HP	Laser Jet P3015	Gear 29T	RU7-0028
HP	LJ1320/1160/2400/2420/P2015/P3015/5200/M3027/M3035MFP	Separation Pad-Tray2	RM1-1298-000
HP	Laser Jet P3015	Pickup Roller, Tray 1	RL1-2412
HP	LJ P3005/P3015/M3027M3027/M3035	Pickup Roller Assembly Tray2	RM1-6313/3763
HP	Laser Jet	Bushing of pressure roller	/
HP	P4014N/4015N/P4515N/P3015	Bushing L & R	左+右
HP	Laser Jet	Gear 20/20T	RU5-0956-000
HP	P3005/M20/20/M3027/M3035(—整套就是四个齿轮加一个卡扣)(Cluster of Fuser Driver Gears)整套6元13071500500T	Gear 18T	RU5-0965-000
HP		Gear 17T	RU5-0958-000
HP		Gear 19T	RU5-0959-000

### Laser Jet M3027/M3035MFP

HP	LJ M3027/M3035MFP/P3005	Fuser pressure roller	LPR-3005
HP	LJ M3027/M3035MFP/P3005	Bushing,pressure roller	RC1-3610/3609
HP	LJ1320/1160/2400/2420/P2015/P3015/5200/M3027/M3035MFP	Separation pad-TRAY2	RM1-1298-000
HP	LJ P3005/P3015/M3027M3027/M3035	Pick up roller	RM1-6313/3763
HP	LJ2015/2400/2420/M3027/M3035MFP	Pick up roller TRAY1	RL1-0568/ RL1-0569
HP	Laser Jet M3027/M3035MFP	Gear , Roller 29T	RU5-0964-000
HP	Laser Jet M3027/M3035MFP	Transfer roller W/Gear	RM1-1508-000

### HP Laser jet 2/3/SX/2D/3D

HP	Laser jet SX	Upper fuser roller	RF1-1145-000
HP	Laser jet 2/3/SX	Upper fuser roller	RA1-3968-000
HP	Laser jet 2/3/SX	Fuser gear,heat roller 32T	RS5-0020-000
HP	Laser jet 2/3/2D/3D	Fuser gear 20T	Rs1-0116-000
HP	Laser jet 2/3/2D/3D/SX	Arm	RF1-0921-000
HP	Laser jet SX	Delievery coupler assembly	RG1-0967-000
HP	Laser jet 2/3/2D/3D/SX	Delievery roller	RA1-3976-000

### HP Laser jet IIP/IIIP/LX

HP	Laser jet IIP/IIIP/LX	Fuser pressure roller	RA1-7583-000
HP	Laser jet IIP/IIIP/LX	Delievery roller	RA1-7708-000
HP	Laser jet IIP/IIIP/LX	Upper fuser roller	RF1-2505-000
HP	Laser jet IIP/IIIP/LX	Bypass pick up roller	RA1-7674-000
HP	Laser jet IIP/IIIP/LX	Separation pad	RG1-1912-000

### HP Laser jet 3SI/4SI/NX

HP	Laser jet 3SI/4SI/NX	Duplex pick up roller	RF5-0081-000
HP	Laser jet 3SI/4SI/NX	Pick up roller	RF5-0041-000
HP	Laser jet 3SI/4SI/NX	Transfer roller	RG5-0141-000
HP	Laser jet 3SI/4SI/NX	Upper fuser roller	RB1-0323-000
HP	Laser jet 3SI/4SI/NX	Fuser gear	RS5-0062-000
HP	Laser jet 3SI/4SI/NX	Fuser gear(16T)	RF5-0060-000
HP	Laser jet 3SI/4SI/NX	Fuser gear(23T)	RS5-0057-000
HP	Laser jet 3SI/4SI/NX	Fuser gear(18T)	RS5-0059-000
HP	Laser jet 3SI/4SI/NX	Fuser gear(27T)	RF5-0068-000
HP	Laser jet 3SI/4SI/NX	Clip,transfer roller	RB1-0818-000
HP	Laser jet 3SI/4SI/NX	Delivery roller	RB1-0531-000

### HP Laser Jet 4000/4050

H.P	Laser Jet 4000/4050	Transter Roller	RG5-4283-000
H.P	Laser Jet 4000/4050	Transter Roller Gear	RS5-0948-000
H.P	Laser Jet 4000/4050	Fuser pressure roller	RBI-8794-000
H.P	Laser Jet 4000/4050	Bushing pressure roller	RS5-1297/1310
H.P	Laser Jet 4000/4050/4500/4550/8100	Pickup roller Tray 2 =RF5-2490	RF5-1885

H.P	Laser Jet 4000/4050/4500/4550/IR1600/2200	Pickup roller	RBI-8865/FB4-9817
H.P	CLJ5500/4600/4650;LJ4100/4000/4050	Pick up roller Tary1	RG9-1529/ RG5-3718
H.P	Laser Jet 4000/4050	Pad separation	RB1-8773-000
H.P	Laser Jet 4000/4050	Pad separation	RG5-5281-000
H.P	Laser Jet 4000/4050	Torpue limier	RB1-8974-000
H.P	Laser Jet 4000/4050/4100	Upper Delivery roller	RB1-8798-000
H.P	Laser Jet 4000/4050	Lower Delicery roller	RG5-2648-000
H.P	Laser Jet 4000/4050	Cam,Deflector	RB1-8811-000
H.P	Laser Jet 4000/4050	Coupler,pickup	RB1-8877-000
H.P	Laser Jet 4000/4050	Guide blade	RS5-8797-000
H.P	Laser Jet 4000/4050/4100	Fuser gear(34T)	RS5-0922-000
H.P	Laser Jet 4000/4050	Fuser gear(33T)	RS5-0921-000
H.P	Laser Jet 4000/4050	Fuser drive gear 18T/16T	RS5-0923-000
H.P	Laser Jet 4000/4050	Fuser gear(21T)	RS5-0924-000
H.P	Laser Jet 4000/4050	Fuser gear(26T)	RS5-0925-000
H.P	Laser Jet 4000/4050	Fuser screw	RS5-8819-000
H.P	Laser Jet 4000/4050	Pick-Up Roller Assemldy	RF5-2484-000
H.P	Laser Jet 4000/4050	Clip,pickup spring	RB1-2190-000
H.P	Laser Jet 4000/4050/4100/4101MFP	sensor cover	RB1-8788-000
H.P		sensor lever	RB1-8787-000
<b>HP Laser Jet P4014/4015/4515</b>			
H.P	Laser Jet P4014N/4015N/P4515N	Transfer Roller Assy	RM1-1110/RM1-5462
HP	Laser Jet P4014N/4015N/P4515N/P3015	Bushing Right, pressure roller	BSH-4014
HP	4200/4240/4250 4300/4350 4700/4730 CP4005 M4345 P4014/P4015/P4515	Pick up roller Tray 2/3	RM1-0036-000
HP	4200/4240/4250 4300/4345/4350 4700/4730/5200/P4014/P4015/P4515/CP3530/CP3525/CP4005/CM4730/M4345	Tray2 feed/sep roller	RM1-0037-000
HP	Laser Jet P4014N/4015N/P4515N <b>(CB506-67905)</b>	feed roller TRAY1	RL1-1663-000
HP		Separation roller TRAY1	RL1-1654-000
HP		Pick up roller TRAY1	RL1-1641-000
HP	Laser Jet P4014N/4015N/P4515N	Fuser gear(18T)	RU6-0164-000
HP	Laser Jet P4014N/4015N/P4515N	Fuser gear(17T)	RU6-0165-000
HP	Laser Jet P4014N/4015N/P4515N	Fuser gear(32T)	RC2-2399-000
HP	Laser Jet P4014N/4015N/P4515N	Fuser gear	RU6-0166-000
HP	Laser Jet P4014N/4015N/P4515N	Fuser gear	RU6-0167-000
HP	Laser Jet P4014N/4015N/P4515N	Fuser gear	RU6-0169-000
HP	Laser Jet P4014N/4015N/P4515N	Fuser gear	RU6-0170-000
HP	Laser Jet P4014N/4015N/P4515N	Fuser gear(33T)	RU6-0171-000
HP	Laser Jet P4014N/4015N/P4515N	Fuser gear	RU6-0172-000
HP	Laser Jet P4014N/4015N/P4515N	Cover asm left	CVR-P4015-L
HP	Laser Jet P4014N/4015N/P4515N	Cover asm right	CVR-P4015-R
HP	Laser Jet P4014N/4015N/P4515N	Fuser gear(17T)	N/A
HP	Laser Jet P4014N/4015N/P4515N	Fuser Guide Delivery	RC2-5208-000
HP	Laser Jet P4014N/4015N/P4515N	Fuser Latch Clip, right	LVR-P4014-RGT
HP		Fuser Latch Clip, left	LVR-4014-LFT
HP	Laser Jet P4014N/4015N/P4515N	Handle, right	RC2-2840-000
HP		Handle, left	RC2-2841-000
H.P	Laser Jet P4014/4015/4515	Fuser pressure roller	LPR-4014-LOW
H.P	Laser Jet P4014/4015/4515	Thermistor	TM-P4014
<b>HP Laser Jet 4100</b>			
HP	Laser jet 4100	Transfer roller assembly	RG5-5295-000
H.P	Laser Jet 4100	Transter Roller Gear	RS5-0948-000



HP	Laser jet 4100	Fuser pressure roller	RB2-4919-000
HP	Laser jet 4100	Bushing,pressure,roller,Right	BSH-4100-PR
HP	Laser jet 4100	Bushing,pressure,roller,Left	BSH-4100-PL
HP	Laser jet 4100	Bushing,pressure,roller,Right	BSH-4100-PR
HP	Laser jet 4100	Bushing,pressure,roller,Left	BSH-4100-PL
HP	Laser jet 4100	Fuser roller	RS5-0922-000
HP	Laser jet 4100	Fuser gear 33T	RS6-0688-000
HP	Laser jet 4100	Fuser gear 28T	RS5-0677-000
HP	Laser jet 4100	Fuser gear 14T/21T	RS5-0675-000
HP	Laser jet 4100	Fuser gear 21T	RS5-0676-000
HP	Laser jet 4100	Fuser gear 18T/16T	RS5-0923-000
HP	Laser jet 4100	Separatin pad	RF5-3086-000
HP	Laser jet 4100/4200/4300/4250/4000/ 4050/4350	Separatin pad ass'y Tray	RG5-5281-000
HP	Laser jet 4100	Delivey roller	DR-4100-L-000
HP	Laser jet 4100	Joint Pickup	RB1-8877-000
HP	Laser jet 4100	Lever Left holding	RB2-4931-000
HP	Laser jet 4100	Lever Right holding	RB2-4932-000
HP	Laser jet 4100	Feedr/Tray2 Pick-Up roller	RF5-3114-000
HP	CLJ5500/4600/4650;LJ4100/4000/ /4050	Pick up roller Tary1	RG9-1529/ RG5-3718
HP	4000/4100/4500/4550	Roller ,Feed	RB1-8957-000
HP	LJ4100	ADF Pickup Roller	RB2-8769-CLN
HP	Laser jet 4100	Clip Pickup spring	RB1-2190-000
HP	Laser jet 4100	Torque limiter	RB1-8974-000
HP	Laser jet 4100	Fuser Delivery Cover	RB2-4894

### HP Laser Jet 4200

H.P	4200/4240/4250 4300/4345/4350 4700/4730/5200/P4014/P4015/P4 515/CP3525/CP4005/CM4730/M4 345	Tray2 feed/sep roller	RMI-0037-000
H.P	4200/4240/4250 4300/4350 4700/4730 CP4005 M4345 P4014/P4015/P4515	Tray2 pickup roller	RMI-0036-000
H.P	4005/4200/4240/4250/4300/4345/43 50/4700/4730	Paper pick-up Roller-Tray1	RL1-0019-000
H.P	4200/4240/4250/4300/4345/4350/ 4700	MP/Tray1 Separation Pad	RL1-0007-000
H.P	Laser Jet 4200	Separation pad-Tray1	RG5-5281-000
H.P	Laser Jet 4200/4300/4345	Fuser pressure roller	RC1-0070-000
H.P	Laser Jet 4200/4300	Fuser Guide Delivery	RC1-0062-000
H.P	Laser Jet 4200/4300	Fuser gear 40T	RU5-0016-000
H.P	Laser Jet 4200/4250	Torpue Limiter	RB1-6588-000
H.P	Laser Jet 4200	Transter Roller	RM1-0699-000
H.P	Laser Jet 4200	Transter Roller Gear	RM1-0699-Gear
H.P	Laser Jet 4200/4250	Fuser Gear 18T	RU5-0018-000
H.P	Laser Jet 4200/4250	Delivery roller	DR-4200
H.P	Laser Jet 4200/4250/4300	Fuser Gear 27T	RU5-0017-000
H.P	Laser Jet 4200/4250/4300/4345	Fuser Gear 41/15T	RU5-0020-000
H.P	Laser Jet 4200/4250/4300	Fuser Gear 14T	RU5-0021-000
H.P	4200/4250/4300/4350	Drive Gear with board	RM1-0043-GRB
H.P	4200/4250/4300/4350 41T	Drive Gear without board	RU5-0277-000
H.P	4200/4250/4300/4350	Drive Gear Assembly	RM1-0043-060/ RM1-0043-020
H.P	Laser Jet 4200/4250/4300	Fuser Latch Clip, left	LVR-4200-LFT /RC1-0091
H.P	Laser Jet 4200/4250/4300	Fuser Latch Clip, right	LVR-4200-RGT/ RL1-0497
H.P	Laser Jet 4200/4250/4300	Bushing pressure rollerLeft	RC1-3361半圆形
H.P	Laser Jet 4200/4250/4300	Bushing pressure rollerRight	RC1-3362圆形

H.P	Laser Jet 4200	Fuser flange left	FLNG-4200-L
H.P	Laser Jet 4200	Fuser flange right	FLNG-4200-R
H.P	Laser Jet 4200/4250/4300/4345	Cover asm left	CVR-4200-L
H.P	Laser Jet 4200/4250/4300/4345	Cover asm right	CVR-4200-R
H.P	Laser Jet 4200/4250/4300	Lower fuser feed guide	RC1-0072-CLN
H.P	Laser Jet 4200/4250/4300	Upper fuser feed guide	GD-4200-UP
H.P	Laser Jet 4200/4300	Fuser guide delivery	RC-0062-000
H.P	Laser Jet 4200/4250/4350/4345	Thermistor	RH7-7150
H.P	Laser Jet 2400/2410/2420/P3005/3500/370 0/4000/4050/4200/4250/4300/435 0/4500/4550/4600/4650/5000/510 0/5500/5550/8500/8550/9000/950 0/EP83/EP82/LBP52X/LBP62X	Photo Interrupter	WG8-5362

### HP Laser jet 4300

HP	4200/4240/4250/4300/4350 4700/4730 CP4005 M4345 P4014/P4015/P4515	Tray2 pickup roller	RM1-0036-000
HP	4200/4240/4250 4300/4345/4350 4700/4730/5200/P4014/P4015/P4 515/CP3525/CP4005/CM4730/M4 345	Tray2 feed/sep roller	RM1-0037-000
HP	4005/4200/4240/4250/4300/4345/43 50/4700/4730	Paper pick-up Roller-Tray1	RL1-0019-000
HP	Laser jet 4300	Separation pad	RG5-5281-000
HP	4200/4300/4250/4350	Transfer roller	RC1-0044-000
HP	Laser Jet 4200/4300/4345	Fuser pressure roller	RC1-0070-000
HP	Laser jet 4300	Delivery roller W/Gear	DR-4200-000
HP	Laser jet 4300/4250/4200	Fuser gear	RU5-0018-000
HP	Laser jet 4300	Fuser gear	RU5-0275-000
HP	Laser jet 4300/4250	Fuser gear 41T	RU5-0276-000
HP	Laser jet 4200/4250/4300	Fuser gear	RU5-0020-000
HP	Laser jet 4300	Fuser gear	RC1-3324/3325
H.P	Laser Jet 4200	Black Swing plate Assy 41T	RU5-0277-000
HP	Laser jet 4300	Bushing pressure roller Right	RC1-3362圆形
HP	Laser jet 4300	Bushing pressure roller Left	RC1-3361半圆形
HP	Laser jet 4300	Fuser Latch Clip, right	LVR-4200-RGT
HP	Laser jet 4300	Fuser Latch Clip, left	LVR-4200-LFT

### HP Laser Jet 4250/4350

H.P	4200/4240/4250 4300/4345/4350 4700/4730/5200/P4014/P4015/P4 515/CP3525/CP4005/CM4730/M4 345	Tray2 feed/sep roller	RMI-0037-000
H.P	4200/4240/4250/4300/4350 4700/4730 CP4005 M4345 P4014/P4015/P4515	Tray2 pickup roller	RMI-0036-000
H.P	4005/4200/4240/4250/4300/4345/43 50/4700/4730	Paper pick-up Roller-Tray1	RL1-0019-000
H.P	4200/4240/4250/4300/4345/4350	MP/Tray1 Separation Pad	RL1-0007-000
H.P	Laser Jet 4250/4350	Fuser pressure roller	RC1-0070-000 RMI-1091-000
H.P	Laser Jet 4250/4350	Guide Only Delivery	RC1-3329-000
H.P	Laser Jet 4250/4350	Lower roller gear 40T	RC1-3324/3325
H.P	Laser Jet 4250/4350	Torpue Limiter	RB1-6588-000
H.P	Laser Jet 4250/4350	Separation pad-Tray1	RG5-5281-000
H.P	Laser Jet 4250/4350	Transter Roller	RM1-1110-000
H.P	Laser Jet 4250/4350	Transter Roller Gear	RM1-1118-Gear
H.P	Laser Jet 4250/4350	Fuser Gear 18T	RU5-0018-000
H.P	Laser Jet 4250/4350	Delivery roller	DR-4250
H.P	Laser Jet 4250/4350	Fuser Gear 27T	RU5-0275-000
H.P	Laser Jet 4250/4350	Fuser Gear 41/15T	RU5-0020-000
H.P	Laser Jet 4250/4350	Fuser Latch Clip, left	LVR-4200-LFT

H.P	Laser Jet 4250/4350	Fuser Latch Clip, right	LVR-4200-RGT
H.P	Laser Jet 4250/4350	Bushing pressure rollerLeft	RC1-3361半圆形
H.P	Laser Jet 4250/4350	Bushing pressure rollerRight	RC1-3362圆形
H.P	Laser Jet 4250/4350	Black Swing plate Assy 51T	RU5-0044-000
H.P	Laser Jet 4250/4350	Guide UPPER DELIVERY	GD-4200-UP
H.P	LJ4200/4240/50/4345/M4345/49/4350/P4xxx	THERMISTOR	RK2-0359-000CLN
H.P	LJ4250/4350	Heating Element Holder	RC1-0103

### HP Laser Jet 4345

H.P	Laser Jet 4345	Guide Only Delivery	RC1-3329-000
H.P	Laser Jet 4345	Fuser gear 40T	RC1-3324/3325
HP	Laser Jet 4200/4300/4345	Fuser pressure roller	RC1-0070-000
H.P	Laser Jet 4345	Separation pad-Tray1	RG5-5281-000
H.P	LJ4345/4730	ADF paper seperation pad assembly	PF2282K035NI
H.P	Laser Jet 4345	Transfer Roller Assy	RM1-1110-000
H.P	Laser Jet 4345	Delivery roller	DR-4250
H.P	Laser Jet 4345	Fuser Gear 18T	RU5-0018-000
H.P	Laser Jet 4345	Fuser Gear 27T	RU5-0275-000
H.P	Laser Jet 4345	Fuser Gear 41/15T	RU5-0020-000
H.P	Laser Jet 4345	Fuser Latch Clip, left	LVR-4345-LFT
H.P	Laser Jet 4345	Fuser Latch Clip, right	LVR-4345-RGT
H.P	Laser Jet 4345	Bushing Left, pressure roller	BSH-4345-LFT
H.P	Laser Jet 4345	Bushing Right, pressure roller	BSH-4345-RGT

### HP Laser jet 4/4M/Canon EX

HP	Laser jet 4/4M(EX)	Pick -up roller	RB1-2126-000
HP	Laser jet 4/4M(EX)/4+	Mp tray pick up roller	RB1-2127-000
HP	Laser jet 4/4M(EX)	Lower cassette pick up roller	RB1-2632-000
HP	Laser jet 4/4M(EX)	Fuser gear(34T)	RS5-0230-000
HP	Laser jet 4/4M(EX)	Fuser gear(23T)	RS6-0232/RS5-0393
HP	LJ4/4+/5, EX/EX+	Drive Gear(17T/32T)	RS5-0237-000
HP	Laser jet 4/4M(EX)	Upper pressure roller	RB1-2263-000
HP	Laser jet 4/4M(EX)	Fuser pressure roller	RB1-2264-000
HP	Laser jet 4/4M(EX)/4+/5	Upper delivey roller	RF5-1076-000
HP	Laser jet 4/4M(EX)/4+/5	Lower delivery roller	RF5-1077-000
HP	Laser jet 4/4M(EX)/4+/5	Transfer roller	RF5-0349-000
HP	Laser jet 4+/EX+/4/5	Arm swing	RB1-0350-000
HP	Laser jet 4/4M/Canon EX	Heating element 240V,500W	RH7-4049-000
HP	Laser jet 4/4M/Canon EX	Heating element 240V,750W	RH7-4055-000

### HP Laser jet 4+/Canon EX+

HP	Laser jet 4+/EX+	Pick -up roller	RB1-2650-000
HP	Laser jet 4+/EX+	Pick -up roller	RB1-3477-000
HP	Laser jet 4+/EX+	Roller,holder(4 REQ)	RF5-0425-000
HP	Laser jet 4+/EX+	Delivery roller (4 REQ'D)	RB1-2299-000
HP	Laser jet 4+/EX+/5	Fuser gear,heat roller 42T	RS5-0388-000
HP	Laser jet 4+/EX+	Fuser gear 23T	RS6-0232/RS5-0393
HP	Laser jet 4+/EX+/4/5	Fuser gear 19T	RG5-0231-000
HP	Laser jet 4+/EX+/4/5/5P	Separation pad	RF5-0343-000
HP	Laser jet 4+/EX+/5	Upper fuser roller	RB1-3516-000
HP	Laser jet 4+/EX+/5	Fuser pressure roller	RB1-3517-000
HP	Laser jet 4+/EX+/5	Upper Roller Bushing	RS5-1097-000
HP	Laser jet 4+/EX+/5	Upper Roller Bushing	RS5-1098-000
HP	Laser jet 4+/EX+	Transfer roller	RS5-0260-000
HP	Laser jet 4+/EX+/5	Wire cover	RF5-0738-000
HP	Laser jet 4+/EX+	HEAT LAMP115V500W	RH7-4046-000
HP	Laser jet 4+/EX+	HEAT LAMP240V500W	RH7-4049-000
HP	Laser jet 4+/EX+	HEAT LAMP120V750W	RH7-4054-000
HP	Laser jet 4+/EX+	HEAT LAMP240V750W	RH7-4055-000

**HP Laser jet 4L/4P/4ML/PX**

HP	4L/4P/4ML/PX	Pick up roller	RB1-3029-000
HP	4L/4P/4ML/PX	Pick up roller	RB1-3368-000
HP	4L/4P/4ML/PX	Delivery roller	RB1-3103-000
HP	4L/4P/4ML/PX	Transfer roller	RB1-0596-000
HP	4L/4P/4ML/PX	Fuser pressure roller	RB1-3100-000
HP	4L/4P/4ML/PX	Roller holder	RB1-3107-000
HP	4L/4P/4ML/PX	Motor gear(18T)	RG5-0765-GEAR

**HP Laser jet 4VC/BX**

HP	Laser jet 4VC/BX	Separation pad	RF5-0302-000
HP	Laser jet 4VC/BX	Pick up roller,mp tray	RB1-1411-000
HP	Laser jet 4VC/BX	Dual pick up roller	RB1-1386-000
HP	Laser jet 4VC/BX	Transfer roller	RG5-1410-000
HP	Laser jet 4VC/BX	Upper fuser roller	RB1-5495-000
HP	Laser jet 4VC/BX	Fuser gear(39T)	RS5-0603-000
HP	Laser jet 4VC/BX	Gear (14T)	RS5-0183-000
HP	Laser jet 4VC/BX	Gear (18T)	RS5-0184-000
HP	Laser jet 4VC/BX	Fuser gear (32T)	RS5-0180-000
HP	Laser jet 4VC/BX	Fuser gear (18T)	RS5-0194-000
HP	Laser jet 4VC/BX	Fuser pressure roller	RB1-1443-000
HP	Laser jet 4VC/BX	Face-down delivery roller	RG5-0198-000
HP	Laser jet 4VC/BX	Gear(14T)	RS5-0182-000

**HP Laser jet 5**

HP	Laser jet 5	Pick up roller	RB1-2205-000
HP	Laser jet 5	Pick up roller	RB1-7911-000

**HP Laser jet 5p/6p**

HP	Laser jet 5p/6p	Separation pad	RF5-0343-000
HP	Laser jet 5p/6p	Pick up roller	RB1-6332-000
HP	Laser jet 5p/6p/5	Pick up roller	RB1-2127-000 (RB1-2205-000)
HP	Laser jet 5p/6p	Delivery roller	RG5-0683-000
HP	Laser jet 5p/6p	Exit roller	RB1-9181-000
HP	Laser jet 5p/6p	Transfer roller	RG5-1290-000
HP	Laser jet 5p/6p/VX	Fuser gear,pressure roller	RS5-0637-000
HP	Laser jet 5p/6p	Fuser gear((17T/16T))	RS5-0979-000
HP	Laser jet 5p/6p	Fuser gear((17T/17T))	RS5-0978-000
HP	Laser jet 5p/6p	Fuser pressure roller(6P)	RB1-9210-000
HP	Laser jet 5p/6p/5MP	Fuser pressure roller(5P)	RB1-5910-000
HP	Laser jet 5p/6p	Roller holder	RB1-3107-000
HP	Laser jet 5p/6p/VX	Fuser gear	RS5-0636-000

**HP Laser jet 5L/6L**

HP	Laser jet 5L/6L	Separation pad	RB1-7181-000
HP	Laser jet 5L/6L	Separation pad kit (=RB1-7181+RY7-2502)	RY7-5077-000
HP	Laser jet 5L/6L	Spring separation arm	RS5-2502-000
HP	Laser jet 5L/6L	Pick up roller	RB2-1634-000
HP	Laser jet 5L/6L/4500	Feed up roller	RB2-1699-000
HP	Laser jet 5L/6L	Pick up roller ass'y	RG5-1951-000
HP	Laser jet 5L/6L	Delivery roller	RF5-2367-000
HP	Laser jet 5L/6L	Delivery roller	RF5-1521-000
HP	Laser jet 5L	Fuser pressure roller	RF5-1516-000
HP	Laser jet 6L	Fuser pressure roller	RF5-2364-000
HP	Laser jet 5L/6L	Transfer roller	RF5-1534-000
HP	Laser jet 5L/6L	Bushing pressure roller(2pcs)	RB1-7246-000
HP	Laser jet 5L/6L	Arm ass'y(exit roller) 2pcs	RB2-7180-GEAR
HP	Laser jet 5L/6L/4500	Arm pressure,Feed Roller	RB1-7203-000
HP	Laser jet 5L/6L	Motor gear	RH7-1320-000

**HP Laser jet 5000**

HP	Laser jet 5000	Separation pad,with spring	RF5-2435/1481
----	----------------	----------------------------	---------------

HP	Laser jet 5000/5100	Separation pad-Tray 1	RF5-2400-000
HP	Laser jet 5000	PAD assembly(2pcs)	RF5-2399-000
HP	Laser jet 5000	Pad Assembly Tray 1	RF5-4117
HP	Laser jet 5000/5100	Separation pad,with spring-Tray 2	RG9-1485/ RF5-4120
HP	Laser jet 5000	Separation pad-Tray 1	RF5-3439-000
HP	Laser jet 5000	Delivery roller	RB2-1984-000
HP	Laser jet 5000	Pick up roller-Tray 2	RB2-1821-000
HP	Laser jet 5000	Pick up roller-Tray 1	RB2-1820-000
HP	Laser jet 5000/IR2018/2022/2025/2030/2120/2116(FF6-1621)	Feed roller	RF5-2634-000
HP	Laser jet 5000	Pick-uprollerASS'Y 500 SHEET	RF5-2636-000
HP	Laser jet 5000	ARM,SWING/GR-5000-14T	RF5-2409-000
HP	Laser jet 5000	Fuser gear(29T/14T)	RS6-0348-000
HP	Laser jet 5000/5100	Fuser pressure roller(SLVD)	RB2-1919-000
HP	Laser jet 5000	Transfer roller	RG5-3579-000
HP	Laser jet 5000	Bushing pressure roller(2pcs)	RS6-1389-000
HP	Laser jet 5000/5100	Fuser gear(21T)	RS6-0356-000
HP	Laser jet 5000	Fuser gear(16T/23T)	RS5-0355-000
HP	Laser jet 5000	Fuser gear(15T)	RD6-0354-000
<b>HP Laser jet 5100</b>			
HP	Laser jet 5100	Pick up roller Tray2	RB2-1821-000
HP	Laser jet 5100	Pick up roller Tray1	RB2-1820-000
HP	Laser jet 5100	Feed roller-Tray 2	RF5-2636-000
HP	Laser jet 5100	Pick up roller	RF5-2634-000
HP	Laser jet 5000/5100	Fuser pressure roller	RB2-1919-000
HP	Laser jet 5100	Bushing, pressure roller	RS5-1389-000
HP	Laser jet 5100	Fuser gear( 29/14 T )	RS6-0348-000
HP	Laser jet 5100	Fuser gear( 15T )	RS6-0354-000
HP	Laser jet 5100	Fuser gear( 16/23 T )	RS6-0355-000
HP	Laser jet 5100	Fuser gear( 21 T )	RS6-0356-000
HP	Laser jet 5100	Separation pad	RF5-2435-000
HP	Laser jet 5100	Separation pad-Tray 1	RF5-4119-000
HP	Laser jet 5100	Separation pad-Tray 1	RF5-2400-000
HP	Laser jet 5100	Separation pad-Tray 2	RF5-4128-000
HP	Laser jet 5100	Separation pad(2pcs)	RF5-2399-000
HP	Laser jet 5100	ARM,SWING	RF5-2409-000
HP	Laser jet 5100	Transfer roller	RG9-1542-000
<b>HP Laser jet 5200</b>			
HP	Laser jet 5200/5035MFP	Fuser pressure roller	LPR-5200
HP	LJ5200	Transfer roller	RM1-2485
HP	Laser jet 5200	Separation pad Tray1	RC2-0418-000
HP	LJ1320/1160/2400/2420/P2015/P3015/5200/M3027/M3035MFP	Separation pad Tray2	RM1-1298-000
HP	LJ5200	MP/Tray 1 paper pickup roller	RL1-0915
HP	LJ5200/3500/3550/3700/5035MFP	Pick up roller Tray2	RM1-3537/0731/2530
HP	Laser jet 5200/5035MFP	Bushing, pressure roller(2pcs)	RS5-1389-000
HP	Laser jet 5200/CANON LBP3500	Fuser gear( 29T )	RU5-0556-000
HP	Laser jet 5200/CANON LBP3500	Fuser gear( 37T/16TT )	RU5-0574-000
HP	Laser jet 5200/CANON LBP3500	Fuser gear( 19T/33T )	RU5-0575-000
HP	Laser jet 5200/CANON LBP3500	Fuser gear( 17T/36T )	RU5-0576-000
HP	Laser jet 5200	GEAR FUSER DRIVE (31T)	RU5-0577-000
HP	Laser jet 5200	GEAR DRIVE (17/36T)	RU5-0756-CLN
HP	Laser jet 5200	GEAR DRIVE (19/33T)	RU5-0755-CLN
HP	Laser jet 5200	Clutch separation roller(27T/28T)	/
HP	Laser jet 5200	Fuser gear( 16T )	/



HP	Laser jet 5200	GEAR DRIVE (16/18T)	/
HP	Laser jet 5200	Roller,Pick up Cam	/
HP	Laser jet 5200	Gear	RU5-0546-020
HP	Laser jet 5200	Gear	RU5-0548
HP	Laser jet 5200/M5025/5035/5039	Coupling Lever	RC1-7285
<b>HP Laster jet 8000/5Si</b>			
HP	Laster jet 8000/5Si	Separation pad	RF5-1455-000
HP	Laster jet 8000/5Si	Pick up roller	RF5-1834-000
HP	Laster jet 8000/5Si	Pick up roller	RB1-6730-000
HP	Laster jet 8000/5Si	Pick up roller tray 2	RF5-1835-000
HP	Laster jet 8000/5Si	Upper delivery roller	RB1-6686-000
HP	Laster jet 8000/5Si	Lower delivery roller	RB2-6687-000
HP	Laster jet 8000/5Si	Cleaning roller	RB2-3546-000
HP	Laster jet 8000/5Si	Cleaning roller kit	RB2-3546-kit
HP	Laster jet 8000/5Si	Transfer roller, W/Gear	RF5-1412-000
HP	Laster jet 8000/5Si	Fuser pressure roller	RB1-6623-000
HP	Laster jet 8000/5Si	Upper fuser roller	RB1-6622-000
HP	Laster jet 8000/5Si	Roller delivery	RB1-6606-000
HP	Laster jet 8000/5Si	Roller second pass	RB1-6581-000
HP	Laster jet 8000/5Si	Fuser gear	RS5-0750-000
HP	Laster jet 8000/5Si	Fuser gear(20T)	RS5-0748-000
HP	Laster jet 8000/5Si	Fuser gear(29T)	RS5-0749-000
HP	Laster jet 8000/5Si	Fuser gear(18T)	RS5-0751-000
HP	Laster jet 8000/5Si	Fuser gear(14T)	RS5-0752-000
HP	Laster jet 8000/5Si	Paper feed roller	RB1-6561-000
HP	Laster jet 8000/5Si	Paper feed roller,upper	RB1-6598-000
HP	Laster jet 8000/5Si	Bushing,heating roller	RB1-6823-BSH
HP	Laster jet 8000/5Si	Torque Limiter	RB1-6588-000
HP	Laster jet 8000/5Si	Fuser flag	RB1-6614-000
HP	Laster jet 8000/5Si/NP6050/6030	Bearing, Fuser Roller	XG9-0266-000
HP	Laster jet 8000/5Si	Bearing, Lower Roller	XG9-0331-000
HP	Laster jet 8000/5Si	HEAT LAMP 115V/500W	RH7-4071-000
HP	Laster jet 8000/5Si	HEAT LAMP 115V/500W	RH7-4070-000
HP	Laster jet 8000/5Si	HEAT LAMP 240V/500W	RH74074-000
HP	Laster jet 8000/5Si	HEAT LAMP 240V/500W	RH7-4075-000
HP	Laster jet 8000/5Si/8100	Fixing coupler	RF5-1449-FC
<b>HP Laster jet 8100/8150</b>			
HP	Laster jet 8100	Separation pad	RF5-2703-000
HP	Laster jet 8100	Pick up roller	RF5-1834-000
HP	Laster jet 8100/8500	Pick up roller	RF5-2708-000
HP	Laster jet 8100	Pick up roller tray 2	RF5-1835-000
HP	Laster jet 8100	Pick up roller-mp tray	RB1-9526-000
HP	Laster jet 8100/8150	Transfer roller	RF9-1394-000
HP	Laster jet 8100	Upper fuser roller	RB2-3521-000
HP	Laster jet 8100	Fuser pressure roller	RB2-3522-000
HP	Laster jet 8100	Fuser guide gear(3T)	RB2-3518 -000
HP	Laster jet 8100	Fuser gear(26T)	RS6-0505-000
HP	Laster jet 8100	Fuser gear(54T)	RS6-0507-000
HP	Laster jet 8100	Fuser gear (20T)	RS5-0748-000
HP	Laster jet 8100	Fuser gear (14T)	RS5-0752-000
HP	Laster jet 8100/8150	Fuser gear (23T)	RS6-0506 -000
HP	Laster jet 8100	Upper Roller Bushing 2pcs	RB1-6610-000
HP	Laster jet 8100	Upper Roller Bearing 1pcs	XG9-0377-000
HP	Laster jet 8000/8100	Lower Roller Bearing 1pcs	XG9-0331/0379
HP	Laster jet 8100	Torque limiter	RB1-6588-000
HP	Laster jet 8100	Fuser flag	RB1-6614-000
HP	Laster jet 8100	Roller Delivery	RB1-6606-000
HP	Laster jet 8100	Roller second pass	RB1-6581-000
HP	Laster jet 8100	Paper seed roller	RB1-6561-000
HP	Laster jet 8100	Paper seed roller	RB1-6598-000
HP	Laster jet 8100	Upper Delivery roller	RB1-6686-000

HP	Laster jet 8100	Lower Delivery roller	RB1-6687-000
HP	Laster jet 8100	Cleaning roller bushing(2pcs/set)	RB2-3517-000
HP	Laster jet 8100	Cleaning roller	RB2-3516-000
HP	Laster jet 8100	Cleaning roller Assembly	Rb2-3516-KIT
HP	Laster jet 8100	Upper Separation Guide	RB2-3528
HP	Laster jet 8100/8150	Lamp	/

### HP Laser Jet 9000/9050

HP	Laser Jet 9000	Transfer roller W/Gear	RF5-3319-000
HP	Laser Jet 9000	Pick up roller	RF5-3340-000
HP	LJ9000/9050	Tray 1 Pickup Roller	RF5-3403
HP	LJ9000/9050	TRAY 1 SEPARATION ROLLER	RF5-3404
HP	Laser Jet 9000/5550	Feed/separation/pickup roller ,Tray 2	RF5-3338-000
HP	Laser Jet 9000	Torque Limiter, Spacer	RB2-5759-000
HP	Laser Jet 9000	Fuser Gear(18T)	RS6-0844-000
HP	Laser Jet 9000	Fuser Gear(21T)	RS6-0845-000
HP	Laser Jet 9000	Fuser Gear(49T)	RS6-0841-000
HP	Laser Jet 9000	Fuser Gear(36/24T)	RS6-0842-000
HP	Laser Jet 9000	Troque Limiter	RB2-5759-000
HP	Laser Jet 9000	Delivery roller	DR-9000-LOW
HP	Laser Jet 9000 一套有两个	BUSHING,UPPER ROLLER	BSH-9000-UP
HP	Laser Jet 9000 一套有两个	BUSHING,PESSURE ROLLER	BSH-9000-LOW
HP	Laser Jet 9000	Upper fuser roller	RB2-5948-000
HP	Laser Jet 9000	Fuser pressure roller	RB2-5921-000
HP	Laser Jet 9000	Fuser Feed Sensor	LVR-9000
HP	Laser Jet 9000	Fuser Paper Jam Sensor	SNR-9000-FUSER
HP	Laser Jet 9000	Lever, Fuser Left holding	LVR-9000-LFT
HP	Laser Jet 9000	Lever, Fuser Right holding	LVR-9000-RGT
HP	Laser Jet 9000	Guide,Lower Separation	RB2-5946
HP	Laser Jet 9000	Connector,Fuser,Small	CNT-9000-S
HP	Laser Jet 9000	Cover Plate,Fuser Cover Left	RB2-5956
HP	Laser Jet 9000	Cover Plate,Fuser Cover ,Right	RB2-5957
HP	Laser Jet 9000	Fuser Cover,Left	RB2-5958
HP	Laser Jet 9000	Fuser Cover,Right	RB2-5959
HP	Laser Jet 9000	Transfer roller	RG5-5662-000
HP	Aficio 2051/2060/2075/XEROX V228/230/258/288/330/388/HP8500/8550/9000	Upper Roller Bearing(1个价格)	XG9-0442
HP	Laser Jet 9000/9050	Lower Roller Bearing(1个价)	BRG-9000-Low
HP	LJ9000/9050(110V)	Heating lamp (90V) A	LMP-9000-110A
		Heating lamp (90V) B	LMP-9000-110B
		Heating lamp (90V) C	LMP-9000-110C
HP	LJ9000/9050(220V)	Heating lamp (160V) A	LMP-9000-220A
		Heating lamp (160V) B	LMP-9000-220B
		Heating lamp (160V) C	LMP-9000-220C

### HP Laserjet CM1312/2320

HP	HP CM1312/2320/CP2020/CP2025/Canon MF8330Cdn/MF8350Cdn(CC436-67904)	Tray 1 separation pad	RL1-1785-000
HP		MP tray pick-up roller	RL1-1802-000

### HP Color Laser jet CP1515

HP	CP1515/1215/1312/2320	Pick up roller Tray 2	RC2-1949
----	-----------------------	-----------------------	----------

### HP Color Laser jet CP2025

HP	CLJ CP1210/1215/1510/1515/1518/2020/2025;CM1312MFP/2320MFP	Tray-2 Separation Roller assy	RM1-4425/ RM1-4840
HP	CP2025	Fuser pressure roller	/
HP	CLJ	Pickup roller-original	RM1-4426

HP	CP2020/2025;CM1312/2320MFP	Pickup roller-Original	RM1-4420
<b>HP Color LaserJet 1600/2600</b>			
HP	Color 1600/1020/1022	Pick up roller	RC1-5440-000
HP	Color 1600/1160/2420	Separation pad	RC1-3515-000
HP	Color laser jet 1600/2600	Fuser pressure roller	LPR-2600
HP	Color laser jet 1600/2600	Toner Carriage Handel	RC1-5319/ RM1-1925
<b>HP Color LaserJet 2500</b>			
HP	Color laser jet 2500	Lower Sleeved Roller	RB3-1034-000
HP	Color laser jet 2500	Paper Pick-UP Tray1	RB3-0160-000
HP	Color laser jet 2500	Separation Pad Tray1	RF5-4012-000
HP	Color laser jet 2500	Separation pad Tray2	RC1-0954-000
HP	Color laser jet 2500	Pick up roller Tray2	RB3-0161-000
<b>HP Color LaserJet 2550</b>			
HP	Color 2550/3500/3700	Lower Sleeved Roller	RB3-1034-000
HP	Color laser jet 2550	Separation Pad Tray1	RF5-4012-000
HP	Color laser jet 2550	Paper Pick-UP Tray1	RB3-0160-000
HP	Color laser jet 2550/2820	THERMISTOR	TM-2550
<b>HP Color LaserJet 2840/2830/2820</b>			
HP	Color laser jet 2820/2840	Lower Sleeved Roller	RB3-1034-000
HP	Color 2820/2840	Separation Pad Tray1	RF5-4012-000
HP	Color laser jet 2820/2840	Paper Pick-UP Tray1	RB3-0160-000
HP	CLJ2820/2830/2840/3055/3390	ADF Pick Roller Assembly	Q3948-67904
HP	HP 28xx,305x/33xx/M1522/M2727/M37 5/475/CM2320	ADF paper seperation pad assembly	Q2665-60125
<b>HP Color Laser Jet 3500/3700</b>			
HP	3500/3700/2550	Fuser pressure roller	RB3-1034-000
HP	CLJ3500/3700;LJP3005/2300/2400/2420	Separation pad-Tray1	RC1-0939-000
HP	3500/3700/2300	Separation pad-Tray2	RC1-0954-000
HP	3500/3700/2300	Paper Pick up roller-Tray1	RC1-0945/1535
HP	LJ5200/3500/3550/3700/5035MFP	Pick-up Assy-Tray2	RM1- 3537/0731/2530
HP	COLOR 3500/3700	Delivery roller	DR-3500
<b>HP Color Laser Jet CP3525/3530MFP</b>			
HP	CP3525/CM3530/M5025/M5035( CC468-67924/CC468- 67911/CC468-67921) Tray2/3 Roller Kits	250-Sheet Tray-2 Pickup roller	RM1-4968
HP		500-Sheet Tray-3 Pickup roller	RL1-2099
HP		Separation roller	RM1-0377
HP		250-Sheet Tray-2 Separation Roller Assembly	RM1-4966
HP	CP3525/M575	MP pick up roller	RL1-1928
<b>HP COLOR LaserJet 3600</b>			
HP	CLJ2700/3000/3600/3800/cp3505	Pickup Roller Tray 1	RM1-2741
HP	COLOR laser jet 3600	Pick up roller Tray 2	RC1-6541
HP	CLJ2700/3000/3600/3800/CP3505 (Q5982-67926)	Pickup Roller Tray 2 (250 sheet)兼容全新	RM1-2702
		Cassette Pick-up Roller Kit原 装全新	RM1-2760
HP	CLJ2700/3000/3600/3800/cp3505	Separation Pad Tray 1	RM1-2699
HP	CLJ2700/3000/3600/3800/cp3505	Separation Pad Tray 2	RM1-2709
HP	COLOR laser jet 3600	Lower sleeve roller	LPR-3600
HP	CLJ3600/3800	Fuser Gear(22T/15T)	RC1-6281
HP		Fuser Gear	GR-3800-22T





HP	CLJ3600/3800	Fuser Gear	GR-3600-25T
HP	CLJ3600	Fuser Gear	GR-3600-15T
HP	COLOR laser jet 3600	Fuser Gear(23T/23T)	RC1-6270
HP	CLJ3600/3800	Fuser Gear(31T)	RC1-6275
HP	CLJ 3600/3800;Canon imageCLASS MFC 9150/9170	Fuser Gear(15T)	RC1-6285
HP	COLOR laser jet 3600	Clutch separation roller	RU5-0184/0183
HP	COLOR laser jet 3600	Thermistor	/
HP	CLJ2700/3000/3600/3800/CP3505	Left rod link/Left side door rod link	RC1-6639
HP	CLJ2700/3000/3600/3800/CP3505	Lever slide lock (Left)	RC1-6636
HP	CLJ2700/3000/3600/cp3505/3600/3800	Lever slide lock	RC1-6643
<b>HP LaserJet 3820</b>			
HP	Laser jet 3820	gear(big)	/
HP	Laser jet 3820	gear(small)	/
<b>HP Laser Jet CP4025</b>			
H.P	Color LaserJet CP4025/4525	Tray 2/3/4/5 Pickup Roller	RL1-2099
<b>HP COLOR LaserJet 4500/4550</b>			
HP	COLOR laser jet 4500/4550	Separation pad	RF5-2111-000
HP	COLOR laser jet 4500/4550	Separation pad	RB2-0734-000
HP	COLOR laser jet 4500/4550	Feed/Separation	RF5-2110-000
HP	COLOR laser jet 4500/4550	Feed/Separation	RF5-3750-000
HP	COLOR laser jet 4500/4550	Pick up roller	RF5-2490-000
HP	COLOR laser jet 4500/4550	Paper pick up roller	RB1-8865-000
HP	COLOR laser jet 4500/4550	Paper pick up roller	RB1-8957-000
HP	COLOR laser jet 4500/4550	Paper pick up roller	RB2-0717-000
HP	COLOR laser jet 4500/4550	Paper pick up roller	RF5-2092-000
HP	COLOR laser jet 4500/4550	Paper pick up roller	RF5-3739-000
HP	COLOR laser jet 4500/4550	Transfer roller, W/Gear	RF5-2112-000
HP	COLOR laser jet 4500/4550	Paper pick up roller	RG9-1529-000
HP	COLOR laser jet 4500/4550	Upper fuser roller	RB2-0501-000
HP	COLOR laser jet 4500/4550	Lower sleeve roller	RB2-0502-000
HP	COLOR laser jet 4500/4550	HEAT LAMP,lower 220V	RH7-4112-000
HP	COLOR laser jet 4500/4550	HEAT LAMP,Upper 220V	RH7-4114-000
HP	COLOR laser jet 4500/4550	HEAT LAMP 115V 400W	RH7-4116-000
HP	COLOR laser jet 4500/4550	HEAT LAMP 115V 490W	RH7-4118-000
<b>HP COLOR laserJet 4600/4650</b>			
HP	COLOR laser jet4600	Fuser pressure roller	LPR-4600
HP	COLOR laser jet4600	Paper pick up roller Tary1	RG9-1529-000
HP	COLOR laser jet4600	Paper pick up roller Tary2	RF5-3739-000
HP	COLOR laser jet4600	Separation pad Tary1	RF5-3750-000
HP	COLOR laser jet4600	Junction guide	RB2-8306-GD
HP	CLJ4600/Lexmark OPTRA W820/Xerox N40	Bearing for Pressure roller	BGR-4600-LPR/BRG-N40-LOW
<b>HP COLOR LaserJet 4700</b>			
HP	COLOR laser jet4700	Fuser pressure roller	LPR-4700
HP	COLOR laser jet4700	Separation pad Tary1	RF5-3750-000
HP	4005/4200/4240/4250/4300/4345/4350/4700/4730	Paper pick-up Roller-Tray1	RL1-0019-000
HP	4200/4240/4250 4300/4350 4700/4730 CP4005 M4345 P4014/P4015/P4515	Tray2 pickup roller	RM1-0036-000
HP	4200/4240/4250 4300/4345/4350 4700/4730/5200/P4014/P4015/P4515/CP3525/CP4005/CM4730/M4345	Tray2 feed/sep roller	RM1-0037-000
HP	CLJ4700/4730	Inner Entrance Guide	RC1-4742
<b>HP Color LaserJet 5500/5550</b>			
HP	Color laser jet 5500	Fuser pressure soller	LPR-5500-000

HP	Color 5500/HP9000	Pick up roller	RF5-3338-000
HP	Color 5500/HP9000	Pick up roller	RF5-3340-000
HP	Color Laser jet5500	Separation pad Tsry1	RF5-3865-000
HP	CLJ5500/4600/4650;LJ4100/4000/4050	Pick up roller Tary1	RG9-1529/ RG5-3718
HP	Color 5500/HP9000	Torque limiter	RB2-5759-000
HP	Color Laser jet5500	Entrance guide	RB2-9258

### HP Color Laser Jet CP5525MFP

HP	CP5525MFP	Tray 1 Pickup Roller	CE710-69006
----	-----------	----------------------	-------------

### HP Color LaserJet CP6015

HP	Color laser jet CP6015;CM6030/6040/6049	Q3931-67919/Q3931-67938 Paper Feed Kit for Tray 2, 3, 4 or 5,搓纸轮套件(1) Pickup Roller, (2) Separation Rolle	/	
			RL1-1289	
HP		Q3931-67920 MP/Tray1 Roller Kit	RC1-8567	
			RM1-4392	
HP	Color laser jet CM6030/6040	ADF pickup roller and separation pad	CE487B原装全新	
HP	Color laser jet CP6015/6030	Transfer roller	RM1-3319	
HP	CLJ CP6014/6015/6016;CM6030/6040	Upper fuser roller	/	
HP	/6050	Lower pressure roller	/	

### HP Color LaserJet 8500

HP	Laster jet 8100/8500	Feed pickup roller	RB1-9526-000
HP	Laster jet 8500	Paper pickup roller	RF5-1834-000
HP	Laster jet 8500	Paper pickup roller	RF5-1835-000
HP	Laster jet 8500	Paper pickup roller	RF5-2708-000
HP	Laster jet 8500	Separation pad	RF5-1989-000
HP	Laster jet 8500	Upper fuser roller	/
HP	Laster jet 8500	Lower pressure roller	RB1-9720-000

### HP Color LaserJet 9500

HP	Color laser jet 9500	Pick up roller	RF5-3340-000
HP	Color laser jet 9500	Pick up roller	RF5-3338-000
H P	Color laser jet 9500	Pick up roller Tray1	RB2-1820-000
HP	Color laser jet 9500	Upper fuser roller	/
HP	Color laser jet 9500	Fuser pressure roller	/

### SAMUNG ML1510

SAMUNG	ML1510	Pick up roller	JC72-0123A
SAMUNG	ML1510/1520/1710/1610/1740/1750/ 2010/SCX4026/4116/4200/XEROX31 17/DELL1100//4500/1220/808/SF550 /555P/530	Fuser pressure roller	JC66-00600A
SAMUNG	ML1510/1610/1710/1740/1750/20 10;SCX4100/4116/4200/XEROX3 115/3117/3130/565p/XEROX342 R	Upper fuser roller	JC66-00601A
SAMUNG	ML1510	Transfer roller	/
SAMUNG	ML1510	Coupling Gear Assemldy	CGA-SM1510



SAMUNG	ML1510/ML2250/2151N/2152	Separation pad	SP-SM1510/JC73-00140A
SAMUNG	ML1510	Bushing heat roller(2pcs)	BSH-SM1510-UPR
SAMUNG	ML1510/1610	Fuser gear heat roller37T	JC66-00564A
SAMUNG	ML1510	Electric Motor Gear 53 /26T	FG-SM1510
SAMUNG	ML1510	Lamp	/
<b>SAMUNG ML1610</b>			
SAMUNG	ML1610/1640/1641/2240/2241/2010/SCX4521F	Pick up roller	PUR-SM1610/JC73-00211A/JC97-02688A
SAMUNG	ML1510/1520/1710/1610/1740/1750/2010/SCX4026/4116/4200/XEROX317/DELL1100//4500/1220/808/SF550/555P/530	Fuser pressure roller	JC66-00600A
SAMUNG	ML1510/1610/1710/1740/1750/2010;SCX4100/4116/4200/XEROX3115/3117/3130/565p/XEROX342	Upper fuser roller	JC66-00601A
SAMUNG	ML1610	Separation pad	JC61-01169A
SAMUNG	ML1610	Transfer roller	TNR-SM1610
SAMUNG	ML1610	Coupling Gear Assembledly	CGA-SM1610/JC97-02179A
SAMUNG	ML1610	Delivery roller	DR-SM1610
SAMUNG	ML1510/1610/1710	Bushing heat roller(2pcs)	JC61-00589A/JC61-00590A
SAMUNG	ML1610/1510	Fuser gear	JC66—00564A
SAMUNG	ML1610	Lamp	/
<b>SAMUNG ML1640</b>			
SAMUNG	ML1640/1641/2240/2241	Fuser pressure roller	/
<b>SAMUNG ML1660</b>			
SAMUNG	ML-1660/1665;SCX-3200/3205/3205W	Pick up roller	JC73-00321A
<b>SAMUNG ML1710/1740</b>			
SAMUNG	ML1210/1710/ML4100/1510/1740/2250/4720/565P/4520/ 4016/4216/XEROX3116	Pick up roller	JC72-01231A
SAMUNG	ML1210/1710/ML4100/1510/1740/2250/4720/565P/4520/ 4016/4216/XEROX3116	Separation pad	SP-SM1510/JC73-00140A
SAMUNG	ML1510/1520/1710/1610/1740/1750/2010/SCX4026/4116/4200/XEROX317/DELL1100//4500/1220/808/SF550/555P/530	Fuser pressure roller	JC66-00600A
SAMUNG	ML1510/1610/1710/1740/1750/2010;SCX4100/4116/4200/XEROX3115/3117/3130/565p/XEROX342	Upper fuser roller	JC66-00601A
SAMUNG	ML1710	Transfer roller	/
SAMUNG	ML1510/1710/1740	Bushing, heat roller(2pcs)	JC61-00590A
SAMUNG	ML1710/1740	Fuser gear 37T	JC66-00564A
SAMUNG	ML1710/1740	Electric Motor Gear 53 /26T	FG-SM1510
	ML1510/1210/1710	Motor Gear 53T/26T	JC66-00388A
SAMUNG	ML1710/1510	Lamp 220V,600W	/
SAMUNG	ML-1520/1710/1740/1750; SCX-4016/4100/4116/4200/4216F/4321/4521F/4521FG; SF-560R/565P/565PR	Holder M Plate Claw	JC61-00584A
SAMUNG	ML1710/2250/2550/SCX4116/4216/4720/4016;Xerox PE16;Ricoh AC104/Gestetner DS516pf;Lexmark X215	Thermoswitch/Termostato	JC47-00005A

SAMUNG	Samsung SCX4016/4216F/4100/4116/4200;ML 1710/1740/1750;Xerox WC PE16/WC PE114E/Phaser3120/pahser3130/ph aser3121/wc3119;Ricoh C104;Lexmark x215	Atuador sensor fusor /PMO Actuator Exit	JC72-00987A/ 120N00428
<b>SAMUNG ML-1910</b>			
SAMUNG	ML1910	Pick up roller	/
SAMUNG	ML1910	Fuser pressure roller	/
<b>SAMUNG ML-2250</b>			
SAMUNG	ML-2250	Separation pad	SP-SM1510
SAMUNG	Samsung: ML2250, ML2251N, ML2252W, SCX4720F Dell: 1600n Gestetner: DSM520PF, DSM520PFL Lanier: AC122, AC122L Ricoh: AC205, AC205L, BP20, BP20N Savin: AC205, AC205L Xerox: Workcentre PE120i	Pick up roller	JC97-01926A
SAMUNG	ML- 2240/2250/2251/2252/4520/4720/ 4725/理光200/施乐3200	Upper fuser roller	JC66-00729A
SAMUNG	ML2250/2251/2252;XEROX 3150 PE120 - RICOH AC205 AFICIO BP20	Fuser pressure roller	JC66-00600B
SAMUNG	ML2250/2251/2252;SCX4720	Bushing, heat roller(2pcs/套)	/
	ML1710/1740/1750/2010/2250/2550/2571 /3050; SCX4016/4100/4200/4521F/4720/5312F/5 112/5315F/5115/6320F/6220/SF830/SF83 55530/6220/5320/6322/SCX4116/4216F;X erox WORKCENTRE 3119/PE114E/PE16PE220/PHASER 3120/3130/312/M20/M418/M4118; RICOH AC104 ;GESTETNER DSM516PF ;LEXMARK X215	Bushing, Pressure roller(2pcs/套)	JC66-10901A
SAMUNG	SCX 4016/SCX 4116/SCX 4216F/SCX 4720/ML 2250/ML 2550/Xerox PE16/Ricoh AC104/Gestetner DSm516pf/Lexmark X215	Thermostat	JC47-00005A 原装全新
<b>SAMUNG ML-2510</b>			
SAMUNG	ML-1910/1915/2510/2525/ml- 2570/2571/2580N/SCX- 4600/4623/4725FN	Upper fuser roller	JC66-01256A
SAMUNG	ML2510/2570/2571N;SCX4725/4725FN	Pickup Roller	JC73-00239A
SAMUNG	ML140/22501510/1710/1750/3560/35 61N/3050/3051/1520P/225x; SCX- 4200/4016/4100/4116/4216F/4100/S F-56x; xerox Phaser 3428/3130/3120/3119/3115/3121/31 50/WC PE16/114e/3119	lpr-Plate Pad	JC70-00314A/ JC70-00314B/ 019N00820
SAMUNG	ML-2510/2570/2571N/2570/2571N; SCX- 4725FN/4725FN	Actuator Feed Sensor	JC66-01250A
<b>SAMUNG ML-2550</b>			
SAMUNG	ML- 2150/2060/2550/2551/3560/3561/4050/45 51	Separation pad	JC61-00684A + JC73-00132A
SAMUNG	ML-2550/2551/Xerox 3420/3425/3450	Upper fuser roller	UFR-SM2550
SAMUNG	ML-2550/2551/2150/2115/2550/2552	Fuser pressure roller	LPR- SM2550/JC66- 00597A

**SAMUNG ML-2580**

SAMUNG	CLP610ND, CLP620ND, CLP660N, CLP660ND, CLP670N, CLP670ND, CLX6200FX, CLX6210FX, CLX6220FX, CLX6240FX, CLX6250FX, ML1915, ML2525, ML2525W, ML2540, ML2540R, ML2545, ML2580N, SCX4600, SCX4623F, SCX4623FN, SCX4623FW, SF650, SF650P	Holder-pad	JC61-03344A
SAMUNG	SCX4623	Pickup roller tire	JC73-00315A

**SAMUNG ML-2851**

SAMUNG	ML-2850/2851/2855/SCX4824/SCX4828	Pickup roller tire	JC73-00265A
SAMUNG	ML1910/1915/2525/2850/2851/2855 ;SCX4824/4826/4828;XEROX WC3210/WC3220/3250	Separation Pad	JC96-04743A/ JC90-00941A
SAMUNG	ML- 2850/2851/2855/SCX4824/SCX4828	Bushing heat roller(Left)	JC61-02334A
SAMUNG	; Xerox wc3210/3220	Bushing heat roller(Right)	JC61-02335A
SAMUNG		Fuser pressure roller 1st	JC66-01663A
SAMUNG	ML-2850/2851/2855/SCX4824/SCX4828	Fuser pressure roller 2nd	JC66-01664A
SAMUNG		Upper fuser roller	JC66-01256B
SAMUNG	ML-2850/2851/2855/SCX4824/SCX4828	Bushing pressure roller 1st	JC61-02336A
SAMUNG	SCX 4824/4828;ML2850/2851/3050	gear,heat roller	JC66-01254A
SAMUNG	SCX 4824/4828;ML2850/2851	Fuser gear	JC66-01637A

**SAMUNG SCX-4100**

SAMUNG	SCX-4100	Pick up roller	JC72-0123A
SAMUNG	SCX- 4100/ML1310/1770/1740/1730/2010	Fuser pressure roller	LPR-SM1210
SAMUNG	ML1310/1310/1770/1740/1730/2010; SCX4100/4116/4200/XEROX3115/3117/3130/565p/XEROX342	Upper fuser roller	JC66-00601A
SAMUNG	SCX-4100	Separation pad	SP-SM1510
SAMUNG	SCX-4100	Fuser gear,heat roller37T	JC66-00564A
SAMUNG	SCX-4100/XEROX PE114	Bushing heat roller, Left	JC61-00947A
SAMUNG		Bushing heat roller, Right	JC61-00948A

**SAMUNG SCX-4200**

SAMUNG	SCX-4200	Pick up roller	JC72-0123A
SAMUNG	ML1510/1520/1710/1610/1740/1750/ 2010/SCX4026/4116/4200/XEROX3117/ DELL1100//4500/1220/808/SF550/555P/530	Fuser pressure roller	JC66-00600A
SAMUNG	ML1510/1610/1710/1740/1750/2010; SCX4100/4116/4200/XEROX3115/3117/3130/565p/XEROX342	Upper fuser roller	JC66-00601A
SAMUNG	SCX-4200	Transfer roller	/
SAMUNG	SCX-4200	Separation pad	SP-SM1510
SAMUNG	ML-1910/2525/2540/2580N;SCX-4200/4220/4300/4600/4623	Fuser Drive Gear	JC66-01202A
SAMUNG	SCX-4200	Fuser gear,heat roller37T	JC66-00564A
SAMUNG	SCX-4200	Bushing heat roller(2pcs)	BSH-SM1510
SAMUNG	SCX-4200	Coupling Gear Assemldy	CGA-SM1510

**SAMUNG SCX-4725**

SAMUNG	ML2510/2570/2571/3124;SCX-4275	Separation Pad	JC97-02669A
SAMUNG	ML2571	Pick up roller	JCJ1-03514A
SAMUNG	ML2510/2571/2671;SCX4725	Guide Claw	JC61-01721A

**SAMUNG ML-3051**

SAMSUNG	ML3050/3051	Pick up roller	JC97-02034A
SAMUNG	ML305X/SCX5330	Pick up roller tire	JC66-00265A

SAMUNG	SCX5330/CLP-600N/CLP-610ND/CLP-620ND/CLP-650N/CLP-660ND/CLP-670ND/CLP-770ND/CLP-775ND/CLX-6200FX/CLX-6210FX/CLX-6220FX/CLX-6240FX/CLX-6250FX/ML-3560/ML-3561N/ML-4050ND/ML-4551N/ML-4551ND/ML-4551NDR/ML-4551NR/ML305X/ML3471	Pick up roller	JC66-01168A/JC73-00310A/JC97-02441A/JC97-02441B/JC97-02441C/JC97-03132A/JC97-03512A/JC90-00932A JC66-01168A
SAMUNG	ML2250/2251N/2252W/3050/3051N;SCX4520/4720F/4920N;WOR KCENTREPE120	Separation pad	JC97-01931A
SAMUNG	ML3050/3051/3470/3471/3475;SCX4725/5525/5530;Xerox Phaser 3428	Upper fuser roller	JC66-01194A
SAMUNG	ML3050/3051/3470/3471;SCX5530;Xerox 3428	Fuser pressure roller	JC66-01195A
SAMUNG	ML3050/3051/3470/3471/3475;SCX4725/5525/5530;Xerox Phaser 3428	Bushing heat roller(2pcs)	一对价格
SAMUNG	ML3050/3051/3470/3471/3475;SCX4725/5525/5530;Xerox Phaser 3428	Fuser gear,heat roller37T	JC66-01192A
SAMUNG	ML3050/3051/Xerox 3428	Upper roller bushing (一对价格)	JC61-01631A; JC61-01629A
SAMUNG	SCX3200 SCX3205 SCX3205W SCX5835 Samsung ML1665 Samsung ML1660 Samsung SCX4600 Samsung SCX4623 Samsung SCX4824 SCX4828 ML3050/ML3051N/SCX5330N/SCX5330FN/SCX5635FN/CLX3170/CLX3170FN/CLX3175/CLX3175FN/CLX3175FW/SCX4824FN/SCX4828FN/SCX4200/ML2850/ML2851 Xerox WorkCentre 3119/Gestetner Sp3200sf/Lanier Ac230n Muratec Mfx3050/Ricoh Aficio Sp3200sf /Samsung Scx5530fn/Savin Sp3200sf /Xerox Phaser 3300mfp	Thermostat	4712-001031
<b>SAMUNG ML3472</b>			
SAMUNG	ML3472	Upper fuser roller	JC66-01593A
<b>SAMUNG ML4500/ML1210</b>			
SAMUNG	ML1210/ML808/4500/1220/1430/SF530/550/555P	Separation pad	JC72—00124A/ JC75-00052A
SAMUNG	ML4500/ML1210	Pick up roller	JC73—00018A
SAMUNG	ML1210/ML808/4500/1220/1430/SF530/550/555P/4600	Upper fuser roller	JC71—00012B
SAMUNG	ML4500/ML1210/808/4600	Fuser pressure roller	LPR-SM4500
SAMUNG	ML4500/ML1210	Delivery roller	DP-SM4500
SAMUNG	ML4500/ML1210	Fuser gear	FG-SM4500
SAMUNG	ML4500/ML1210	Bushing Heat roller(2pcs)	BSH-SM4500-UPR
SAMUNG	ML4500/ML1210	Coupling Gear Assembledly	CGA-SM4500
SAMUNG	ML1210 ,220V 500W	Lamp	/
<b>SAMUNG ML4550</b>			
SAMUNG	ML4551	Upper fuser roller	拆机9成
SAMUNG	ML4550/4551	Fuser pressure roller	兼容全新

**SAMUNG SCX4521**

SAMUNG	SCX-4521(原装全新)	ADF Paper Pickup Roller Assembly	JC97-02203A
SAMUNG	ML-1610 / SCX4521	Separation Pad	JC97-02217A
SAMUNG	SCX4521F;ML2010;Xerox PE220	Fuser Drive Gear (63/35T)	JC66-00807A

**SAMSUNG 5100**

SAMUNG	SAMSUNG 5100	Upper fuser roller	JC71-00004A
SAMUNG	SAMSUNG 5100	Fuser pressure roller	JC75-00027A

**SAMSUNG SF-565P**

SAMUNG	SF-565P	Upper fuser roller	JC66-006601A
SAMUNG	SF-565P	Fuser pressure roller	LPR-1510
SAMUNG	SF-565P	Fuser gear	JC66-00564A
SAMUNG	SF-565P	Coupling Gear Assembledly	CGA-1510
SAMUNG	SF-565P	Bushing, Heat roller(2pcs)	BSH-1510
SAMUNG	SF-565P	Pick up roller	JC72-0123A
SAMUNG	SF-565P	Separation pad	SP-1510
SAMUNG	SF-565P	Electric Motor Gear 53/26T	TRG-1510

**SAMSUNG COLOR CLP300**

SAMUNG	COLOR laser CLP300	Pressure Roller	JC66-01079A
SAMUNG	CLP-300 310 315	Upper roller	JC66-01078A

**SAMSUNG COLOR CLP500/510/550/600**

SAMUNG	COLOR laser CLP510/510/550N	Fuser gear,35T	N/A
SAMUNG	COLOR laser CLP510/510/550N	Upper roller Bushing	N/A
SAMUNG	COLOR laser CLP510/510/550N	LOWER roller Bushing	N/A
SAMUNG	COLOR laser CLP510/510/550N	FUSER FLAG	N/A
SAMUNG	COLOR laser CLP510/510/550N	ROLLER,PICK up Cam TRAY1	N/A
SAMUNG	COLOR laser CLP510/510/550N	CLUTCH SEPARATION ROLLER	N/A
SAMUNG	COLOR laser CLP510/510/550N	FUSER GUIDE DELIVERY	JC72-01083A
SAMUNG	COLOR laser CLP510/510/550N	FUSER GUIDE DELIVERY	JC72-01208A
SAMUNG	COLOR laser CLP510/510/550N	FUSER ROLLER	N/A
SAMUNG	COLOR laser CLP510	Transfer roller, Assembledly	
SAMUNG	COLOR laser CLP550N	Fuser Assembly 110V	N/A
SAMUNG	COLOR laser CLP550N	Transfer roller, Assembledly	
SAMUNG	COLOR laser CLP500	Fuser Assembly 110V	N/A
SAMUNG	COLOR laser CLP500	Transfer roller, Assembledly	
SAMUNG	CLP500/510/550N	Waster Toner Cabel	J063-00272A
SAMUNG	CLP500/510/550N	moto, waster toner	
SAMUNG	CLP500/510/550N	Pick up roller Tray1	
SAMUNG	CLP500/510/550N	Separation pad Tray1	
SAMUNG	CLP500/510/550N	Pick up roller Assy Tray2	

**EPSON 1300W/1350W**

EPSON	1300W/1350W	Upper fuser roller	4136-5501-01
EPSON	1300W/1350W	Fuser pressure roller	4136-5502-01
EPSON	1300W/1350W	Transfer roller	4136-4103-01

**EPSON EPL 5700/5800**

EPSON	SON EPL 5700/5800	Upper fuser roller	1040806
EPSON	SON EPL 5700/5800/5900	Fuser pressure roller	1040805
EPSON	SON EPL 5700/5800	Transfer roller	1040763

**EPSON EPL 6200**

EPSON	EPSONEPL 6200	Upper fuser roller	4316-5501-01
EPSON	EPSONEPL6200	Fuser pressure roller	4136-5502-01
EPSON	EPSONEPL 6200	Transfer roller	4136-4103-01

**EPSON EPL-N2550**

EPSON	EPSON EPL-N2550/N3000	Roll Feed Kit(Made in China)	1246284
-------	-----------------------	------------------------------	---------



EPSON	EPSON EPL-N2550/N3000	Roll Feed Kit(Original)	1240204
<b>EPSON COLOR LASER C1100</b>			
EPSON	SON COLOR LASER C1100	Fuser pressure roller	LPR-1100
EPSON	SON COLOR LASER C1100	Transfer roller	N/A
<b>Lexmark OPTRA E120</b>			
Lexmark	Lexmark E120	Pick up roller	/
Lexmark	Lexmark E120	Separation pad	/
Lexmark	Lexmark E120	Upper Fuser roller	UFP-E120
Lexmark	Lexmark E120	Fuser pressure roller	LPR-120
Lexmark	Lexmark E120	Transfer roller	TR-E120
<b>Lexmark OPTRA E210/4510</b>			
Lexmark	E210/4510	Separation pad	12G6779
Lexmark	E210/4510	Clutch separation	12G6780
Lexmark	E210/4510	Pick up roller	56P2501
Lexmark	E210/4510	Upper Fuser roller	69G9977
Lexmark	E210/4510	Lower pressure roller	69G9978
Lexmark	E210/4510	Bushing Hear Roller (2pcs)	BSH—E210
Lexmark	E210/4510	Fuser gear	FG-4500
<b>Lexmark OPTRA E232/230/234/240/330/332/340/342</b>			
Lexmark	E232/230/234/240/330/332/ 340/342/DELL1700	Upper fuser roller	UFP-E232
Lexmark		Fuser pressure roller	LPR-E232
Lexmark		Transfer roller	56P1823
Lexmark		Htr Lamp 110V600W	N/A
Lexmark		Htr Lamp 110V600W	N/A
Lexmark	E232/230/234/240/250/330/332/ 340/342/350/352/450;DELL1700	Pick up roller	56P1820 个价格
Lexmark	Dell 1700 Lexmark 4505 E230 E232 E330 E332	Delivery Sensor Flag	40X1325
<b>Lexmark E250</b>			
Lexmark	E250D	Pick up roller	搓纸轮
Lexmark	E250D/E350/E352/E450/X364D	Fuser pressure roller	下辊
<b>Lexmark E260</b>			
Lexmark	E260/E360/E460/DN/X264/DN MEP	Tray 2 Paper Feed roller	下纸盒搓纸轮
Lexmark	E260/E360/E460/E462/X264/X36 3/X364/X463/X464/X466	Transfer roller	转印辊
Lexmark	E260	Fuser pressure roller	下辊
<b>Lexmark OPTRA E32X/E22X/4500</b>			
Lexmark	E322/320	Pick up roller	12G4483
Lexmark	E322/320/220	Transfer roller	12G4470
Lexmark	E322/320/220	Upper fuser roller	12G4491
Lexmark	E322/320/220	Fuser pressure roller	12G4494
Lexmark	E322/320/220	Separation pad Right	12G0119
Lexmark	E322/320/220	Separation pad Left	12G1932
Lexmark	E322/320/220	Pick up roller Ass'y	12G4483/ 56P0690
Lexmark	E322/320/220	Charge Roller	99A1017
Lexmark	E322/320/220	Separation pad	12G4493
Lexmark	E322/320/220	Htr Lamp 150V600W	12G4485
Lexmark	E322/320/220	Htr Lamp 220V600W	12G4487
<b>Lexmark OPTRA E312/310</b>			
Lexmark	E312/310	Upper fuser roller	12G0079
Lexmark	E312/310	Lower sleeved roller	12G0086
Lexmark	E312/310	Transfer roller	12G0048



Lexmark	E312/310	Separation pad	12G0062
Lexmark	E312/310	Separation pad Left	12G0119
Lexmark	E312/310	Separation pad Right	12G0120
Lexmark	E312/310	Pick up roller Ass'y	12G0067
Lexmark	E312/310	Input paper feed	12G0070
Lexmark	E312/310	Delivery roller	12G0084
Lexmark	E312/310	Delivery roller	12G0165
<b>Lexmark OPERA E4044</b>			
Lexmark	OPERA E4044	Separation pad Right	12G0119
Lexmark	OPERA E4044	Separation pad Left	12G1932
Lexmark	OPERA E4044	Separation pad	12G0062
Lexmark	OPERA E4044	Transfer roller	12G0048
Lexmark	OPERA E4044	Pick up roller Ass'y	12G4483
Lexmark	OPERA E4044	Pick up roller Ass'y	12G0067
Lexmark	OPERA E4044	Input paper feed	12G0070
Lexmark	OPERA E4044	Delivery roller	12G0084
Lexmark	OPERA E4044	Delivery roller	12G0165
Lexmark	OPERA E4044	Delivery roller	12G0307
Lexmark	OPERA E4044	Delivery roller	12G0308
Lexmark	OPERA E4044	Bushing heat roller	12G0077
<b>Lexmark 4039</b>			
Lexmark	Lexmark 4039	Transfer roller	1381008
Lexmark	Lexmark 4039	Fuser gear 38T	1328124
Lexmark	Lexmark 4039	Cover D-Roller IBM 4039	1381549Tire
Lexmark	Lexmark 4039	Bearing Heat Roller	BSH-4039
Lexmark	Lexmark 4039	Pick up roller	69G5480
Lexmark	Lexmark 4039	Fuser gear	56P1463
Lexmark	Lexmark 4039	Flag pack	40355101
<b>Lexmark 4059</b>			
Lexmark	Lexmark 4059/T614	Fuser pressure roller	99A0160
Lexmark	Lexmark 4059	Paper pick up roller	99A0070
Lexmark	Lexmark 4059	Feed pick up roller	99A0076
Lexmark	Lexmark 4059	Feed separation pad	99A0083
Lexmark	Lexmark 4059	Bushing Lower roller	99A0159
Lexmark	Lexmark 4059	Bushing Upper roller	99A0150
Lexmark	Lexmark 4059	Transfer roller	99A0179
Lexmark	Lexmark 4059	Delivery roller	99A0336
Lexmark	Lexmark 4059	Delivery roller	99A1631
Lexmark	Lexmark 4059	Upper fuser roller	99A0562
Lexmark	Lexmark 4059	Fuser gear	99A0563
<b>Lexmark OPTRA M41X/4045</b>			
Lexmark	OPERA M41X4045	Pick up roller	12G0323
Lexmark	OPERA M41X4045	Transfer roller	12G0354
Lexmark	OPERA M41X4045	Fuser Gear 51T	12G0332
Lexmark	OPERA M41X4045	Input paper feed	12G0070
Lexmark	OPERA M41X4045	Delivery roller	12G0307
Lexmark	OPERA M41X4045	Delivery roller	12G0308
<b>Lexmark OPTERA T420</b>			
Lexmark	OPTERA T420	Upper fuser roller	UFP-420
Lexmark	OPTERA T420	Fuser pressure roller	LPR-420
Lexmark	OPTERA T420	Transfer roller W/Gear	56P0643
Lexmark	OPTERA T420	Transfer roller	56P0643
Lexmark	OPTERA T420	Cover F-D-Roller	56P0613
<b>Lexmark OPTERA T430</b>			
Lexmark	OPTERA T430	Fuser pressure roller	LPR-430

	T420/X422/T420D/T430	Paper Feed Roller Tray	56P0656
Lexmark	OPTERA T430	Transfer roller W/Gear	56P2329
Lexmark	OPTERA T430	Bushing	/
Lexmark	OPTERA T430	Gear	GR-T430-24T
Lexmark	OPTERA T430	Lower pressure roller gear	GR-T430-24/28T

### Lexmark OPTERA T520/522

Lexmark	OPTERA T520/522/630/632/634/640/644/650/652/654	Upper fuser roller	99A2036
Lexmark	OPTERA T520/522	Fuser pressure roller	99A2038
Lexmark	OPTERA T520/522	Delivery roller	99A0147
Lexmark	OPTERA T520/522	Bushing, heat roller (2pcs)	99A0150
Lexmark	OPTERA T520/522	Pick up roller,mp tray	99A0076
Lexmark	OPTERA T520/522	Pick up roller	99A0070
Lexmark	OPTERA T520/522	Separation pad Right	99A0083
Lexmark	OPTERA T520/522	Guide Only Delivery	99A0833
Lexmark	OPTERA T520/522	Transfer roller, W/Gear	99A1015
Lexmark	OPTERA T520/522	Bearing, Heat roller	99A0143
Lexmark	OPTERA T520/522	Bearing, sleeved roller	99A1621
Lexmark	OPTERA T520/522	Fuser gear	99A0148
Lexmark	OPTERA T520/522	Fuser gear	99A0157
Lexmark	OPTERA T520/522	Charge Roller	99A1017
Lexmark	OPTERA T520/522	DOCTOR Bar	N/A
Lexmark	OPTERA T522/632	GEAR	GR-T522-50T
Lexmark	OPTERA T520/522	Htr lamp115V630V	99A2050
Lexmark	OPTERA T520/522	Htr lamp22V630V	99A2051
Lexmark	OPTERA T520/522	Picker Finger Assembly/ Detack Housing	99A2035

### Lexmark T614/616

Lexmark	T610/612/614/616/620/622/S1855	Upper fuser roller	99A1512/1549
Lexmark	Optra S2450/4059/T610/612/614/616/622/630/632/634/640/642/644/650/652/654	Fuser pressure roller	99A0158
Lexmark	T614	Separation pad ,mp tray	99A0083
Lexmark	T614/610/612/616	Pick up roller	99A0070
Lexmark	T610/612/614/616	Pick up roller,mp tray	99A0076
Lexmark	T614/610/612/616	Delivery roller	99A0147
Lexmark	T614610/612/616	Fuser gear	99A0157
Lexmark	T614610/612/616	Fuser gear	99A0148
Lexmark	T614	Bushing sleeve roller	99A0159
Lexmark	T614/610/612/616	Transfer roller	99A1015
Lexmark	T614610/612/616	Bearing Heat roller	99A0143
Lexmark	T610/612/616T614	Bearing sleeved roller	99A1621
Lexmark	T614/616/610/612	Guide Only Delivery	99A0833
Lexmark	T610/612/616T614	Doctor bar	N/A
Lexmark	T614/610/612/616	Delivery roller (4pcs)	DR-T614
Lexmark	T614/610/612/616	Lower Picker Finger	99A2472
Lexmark	T614/610/612/616	Upper Bushing roller	99A0150
Lexmark	T614/610/612/616	Charge Roller	99A1017
Lexmark	T614/616	HEAT LAMP 220V、875W	99A1548

### LEXMARK T630

Lexmark	OPTERA T520/522/630/632/634/640/644/650/652/654	Upper fuser roller	99A2036
Lexmark	Optra S2450/4059/T610/612/614/616/622/630/632/634/640/642/644/650/652/654	Fuser pressure roller	99A2470
Lexmark	LEXMARK T630	Pick up roller	99A0070

Lexmark	LEXMARK T630	Pick up roller,mp tray	99A0076
Lexmark	LEXMARK T630	Delivery roller	99A0147
Lexmark	LEXMARK T630	Delivery roller(1 set)	DR-T614
Lexmark	LEXMARK T630	Fuser gear	99A0157
Lexmark	LEXMARK T630	Fuser gear	99A0148
Lexmark	LEXMARK T630	Bushing heat roller(2pcs)	99A0150
Lexmark	LEXMARK T630	Transfer roller	56P1357
Lexmark	LEXMARK T630	Bearing Heat roller	99A0143
Lexmark	LEXMARK T630	Bearing sleeved roller	99A1621
Lexmark	LEXMARK T630	Guide Only Delivery	99A0833
Lexmark	LEXMARK T630	Doctor bar	N/A
Lexmark	LEXMARK T630	Lower Picker Finger	99A2472
Lexmark	EXMARK T630	Charge Roller	99A1017
Lexmark	LEXMARK T630	HEAT LAMP 220V、875W	99A1548
Lexmark	LEXMARK Optra T/4059/4060/4069/4520/T522/T610/ T612/T614/T616/T620/T622/T650/T 652/T654	Entrance Guide	AMS1109B (99A1591)

### LEXMARK OPTRA T640/642/644

Lexmark	OPTERA T520/522/630/632/634/640/644/6 50/652/654	Upper fuser roller	99A2036
Lexmark	Optra S/2450/4059/T610/612/614/616/622/630 /632/634/640/642/644/650/652/654	Fuser pressure roller	99A2470
Lexmark	EXMARK T640/642/644	Transfer roller	40X0130
Lexmark	EXMARK T640/642/644	Pick up roller,Mp tray	99A0076
Lexmark	EXMARK T640/642/644	Pick up roller	99A0070/40X0070
Lexmark	EXMARK T640/642/644	Bearing, Heat roller	99A0143
Lexmark	EXMARK T640/642/644	Bearing, sleeved roller	99A1621
Lexmark	EXMARK T640/642/644	Charge Roller	40X0127
Lexmark	EXMARK T640/642/644	Bushing, Upper roller	99A0150
Lexmark	EXMARK T640/642/644	Delivery roller	99A2469
Lexmark	EXMARK T640/642/644	Fuser gear	99A0148
Lexmark	EXMARK T640	Lamp holder,Right	CVR-T640-R
Lexmark	EXMARK T640	Lamp holder,Left	CVR-T640-L
Lexmark	EXMARK T520/522/630/632/640/644	GUIDE, ENTRANCE	AMS1109B

### LEXMARK T650

Lexmark	T650/T652/T654/T656/X65X/T644 DTN/T644N/X646EF MFP/T650DN/T650N	Pick up roller	40X4308
---------	---	----------------	---------

### LEXMARK C750

Lexmark	EXMARK C750	Upper fuser roller	/
Lexmark	EXMARK C750	Fuser pressure roller	/

### LEXMARK W820/4025

Lexmark	OPTRA w820	Separation pad,map tray	SP-W820
Lexmark	OPTRA w820	Pick up roller	600K61600
Lexmark	OPTRA w820	Pick up roller ,mp tray	N/A
Lexmark	OPTRA w820	Pick up roller ,mp tray	N/A
Lexmark	OPTRA w820	Feed Roller kit (6rollers)	12G4031
Lexmark	OPTRA w820	Transfer roller W/Gear	022k48230
Lexmark	OPTRA w820	Upper fuser roller	UFP-W820
Lexmark	OPTRA w820	Fuser pressure roller	LPR-W820
Lexmark	OPTRA W820/Xerox N40	Fuser Gear	GR-N40-13T

### LEXMARK C910

Lexmark	EXMARK C910/920	Upper fuser roller	/
Lexmark	EXMARK C910/920	Fuser pressure roller	/

**XEROX DOUPRINT N24/32/40**

Xerox	XEROX N24/32/40	Transfer roller, W/Gear	22K48230-GEN
Xerox	XEROX N24/32/40	Pick up roller	600K61600
Xerox	XEROX N24/32/40	Upper fuser roller	UFP-W820
Xerox	XEROX N24/32/40	Fuser pressure roller	LPR-W820
Xerox	XEROX N24/32/40	Separation pad	SP-N40

**Xerox P8E**

		Delivery roller	DR-P8E
Xerox	Xerox P8E	Upper fuser roller	12G0079
Xerox	Xerox P8E	Lower sleeved roller	12G0086
Xerox	Xerox P8E	Separation pad	SP-P8E
Xerox	Xerox P8E	Pick up roller	N/A

**XEROX 203A**

XEROX	XEROX 203A	Lower sleeve roller	LPR-203A
XEROX	XEROX 203A	UPPER ROLLER	UPR-203A

**Xerox PE220**

Xerox	Xerox PE220	Pick up roller	PUR-SM1610
Xerox	Xerox PE220	Separation pad	JC61-01169A
Xerox	Xerox PE220	Coupling Gear Assemldy	CGA-SM1610
Xerox	Xerox PE220	Bushing, heat roller(2pcs)	BSH-SM1510-UPR
Xerox	Xerox PE220	Fuser gear	JC66-00564A
Xerox	Xerox PE220	Transfer roller	TNR-SM1610

**XEROX 3000**

XEROX	XEROX3000/4000	Upper fuser roller	/
-------	----------------	--------------------	---

**XEROX 3115**

XEROX	XEROX3115	Separation pad	SP-1510
XEROX	XEROX3115	Upper fuser roller	JC66-06601A
XEROX	XEROX3115	Lower sleeved roller	LPR-1510
XEROX	XEROX3115	Pick up roller	JC72-0123A
XEROX	XEROX3115	Fuser gear	JC66-00564A
XEROX	XEROX3115	Bushing sleeve roller(2pcs)	BSH-1510
XEROX	XEROX3115	Coupling Gear Assemldy	CGA-1510
XEROX	XEROX3115	Electric Motor Gear 53 /26T	FG-1510

**XEROX 3116**

XEROX	XEROX 3116	Lower sleeve roller	/
XEROX	XEROX 3116	UPPER ROLLER	/

**XEROX 3117**

Xerox	XEROX3117	Pick up roller	PUR-SM1610
Xerox	XEROX3117	Fuser pressure roller	LPR-SM1510
Xerox	XEROX3117	Upper fuser roller	JC66-006601A
Xerox	XEROX3117	Separation pad	JC61-01169A
Xerox	XEROX3117	Transfer roller	TNR-SM1610
Xerox	XEROX3117	Coupling Gear Assemldy	CGA-SM1610
Xerox	XEROX3117	Delivery roller	DR-SM1610
Xerox	XEROX3117	Bushing, heat roller(2pcs)	BSH-SM1510-UPR
Xerox	XEROX3117	Fuser gear	JC66-00564A

**XEROX 3119**

XEROX	XEROX3119	Separation pad	SP-1510
XEROX	XEROX3119	Pick up roller	JC72-0123A
Xerox	XEROX3119	Fuser pressure roller	LPR-SM1510
Xerox	XEROX3119	Upper fuser roller	JC66-006601A
Xerox	XEROX3119	Bushing, heat roller(2pcs)	BSH-SM1510-UPR
Xerox	XEROX3119	Fuser gear	JC66-00564A

**XEROX 3210**

Xerox	Xerox 3210	Pick up roller	JC75-00054A
Xerox	Xerox 3210	Separation pad	JC72-00124A



Xerox	Xerox 3210	Delivery roller	DR-4500
Xerox	Xerox 3210	Upper fuser roller	JC71-00012B
Xerox	Xerox 3210	Fuser pressure roller	LPR-4500
Xerox	Xerox 3210	Fuser gear	FG-4500
Xerox	Xerox 3210	Bushing sleeve roller(2pcs)	BSH-4500
<b>XEROX 4500</b>			
XEROX	XEROX4500/4510	UPPER ROLLER	059K03380
XEROX	XEROX4500/4510	Lower sleeve roller	UR-X4500
XEROX	XEROX4500	Transfer roller, W/Gear	802K49746-GEN
XEROX	XEROX4500	Bearing, sleeve roller	013E22021
XEROX	XEROX4500	Heating lead	N/A
XEROX	XEROX4500	Fuser Gear 48T	FG-X4500
XEROX	XEROX4500	Bushing, Pressure roller	BSH-X4500
XEROX	XEROX4500	Bearing, Heat roller	BSH-U4500
XEROX	XEROX4500	Pick up poller	604k11192
<b>XEROX 4510</b>			
XEROX	XEROX4510	Lower sleeve roller	N/A
<b>XEROX 4517</b>			
XEROX	XEROX 4517	Transfer roller w/Gear	600K99290/63H2396
XEROX	XEROX 4517	Lower sleeve roller	LPR-4517-FX
<b>Konica minolta QMS2060</b>			
KM	QMS-2060	UPPER ROLLER	0993-5501-01-GEN
KM	QMS-2060	Lower sleeved poller	0993-5502-01-GEN
KM	QMS-2060	Heating lead	0993-6702-01
KM	QMS-2060	Lower Picker Finger	0993-5518-01
KM	QMS-2060	Bushing heat roller	0993-5535-01
KM	QMS-2060	Bushing sleeve roller	0993-5521-01
KM	QMS-2060	Fuser gear 15T	0993-5524-01
KM	QMS-2060	Fuser gear 15T	0993-5512-01
KM	QMS-2060	Bushing roller	0933-5533-01.
KM	QMS-2060	Bushing roller	0993-5537-01
KM	QMS-2060	Bushing roller	0993-5534-01
<b>BROTHER</b>			
BROTHER	HL2130	UPPER ROLLER	/
BROTHER	HL2140	UPPER ROLLER	/
BROTHER	HL 2045	Lower sleeve roller	LPR-203A
BROTHER	HL 2045	UPPER ROLLER	UPR-203A
BROTHER	HL1660/2060	Fuser pressure roller	/
BROTHER	HL2460	Fuser pressure roller	/
BROTHER	HL2820	UPPER ROLLER	/
BROTHER	HL5240/5250/8660/Lenovo LJ3500/7200	UPPER ROLLER	/
BROTHER	HL5240	Fuser pressure roller	/
BROTHER	HL5340/dcp8080	Upper Roller Bushing	一对价格
BROTHER	HL5340	Upper Roller Gear	/
<b>CANON FAX-L120/L100</b>			
CANON	Laser Jet FAX-L120	Separation pad	RC1-2038-000
CANON	Laser Jet FAX-L120	Separation pad	RC1-2048-000
CANON	Laser Jet FAX-L120	Pick up roller	RC1-2050
CANON	Laser Jet FAX-L120	Transfer roller, W/Gear	RM1-0658-000
CANON	Laser Jet FAX-L120	Fuser Delivery Assy	RC1-2094-000
CANON	Laser Jet FAX-L120	Delivery roller	RC1-2051-000
CANON	Laser Jet FAX-L120	Clutch separation roller	RU5-0184-000
CANON	Laser Jet FAX-L120	Separation Assembly	RMI-0648-000
CANON	Laser Jet FAX-L120	Fuer Gear 29T	RU5-0185-000
CANON	Laser Jet FAX-L120	Bushing pressure roller	RC1-2079-000

CANON	Laser Jet FAX-L120	Fuser pressure roller	RM1-0660-000
<b>CANON</b>			
CANON	LBP3018/3010/3050	Fuser pressure roller	LPR-1008
CANON	LJP1005/1006/1102/1120/1505/1606 /M1522/1536MFP;Canon LBP3018/3010/3050	Transfer roller	RM1-4023-000
CANON	LBP3018/3010/3050	Separation pad	RM1-4006-000
CANON	Laser Jet P1005/1008/1006/1007/1515/Can on LBP3018/3010/3050	Pick up roller	RL1-1442-000
CANON	MF-3220	Fuser pressure roller	LPR-3220
CANON	LBP 1710	Fuser pressure roller	/

**Note:**

- 1. Terms of payment: EX Factory price;**
- 2. Payment: T/T (by company bank or Western Union World Wide Money Transfer Company);**
- 3. Delievry time: 3-5 days with large quantity;**
- 4. Shipping way: by Express,by air and by sea.**