

LOS ANGELES
4751-B Littlejohn Street
Baldwin Park, California 91706

626 337-6646 or 800 322-2431
FAX: 626 337-8468 or 800 232-9927
parts@platen.com

SEATTLE
5506 First Avenue South
Seattle, Washington 98108

206 682-7780 or 800 221-2388
FAX: 206 682-7782 or 800 682-7782
dale@platen.com

e commerce

Internet: www.laserprinterparts.com

Laser Printer Parts & More

Brother • Canon • HP • Lexmark • Xerox

This is a partial listing of our inventory - for an expanded list, see our website. Quantity Pricing Available.



July 2005

We Know Office Machines Inside Out

Serving the Office Machine Industry Since 1924

Let Us Be Your Warehouse

*Laser Printer Parts • Laser Toner • Copy Toner • Paper Rolls • Fax Paper & Ribbons
• InkJet Cartridges • P-Touch Labeling Tape • Printwheels • Ribbons (Typewriter, Printer & POS) •
Security Devices and, of course, PLATENS*



Los Angeles

800 322-2431

Parts:

Brother	26	3100	15
Canon (Laser Fax)	29	3200	16
HP - Inkjet	24	3300	16
HP - Laser		3500 • 3550 • 3700	16
Convenience Kits	3	4000 • 4050	17
Fusing Assemblies	4	4100	18
Maintenance Kits	5	4200	18
Network Cards	3	4250	19
II(D) • III(D)	5	4300	19
IIP • IIIP	6	4350	20
IIISi • 4Si	7	4500 • 4550	20
4 • 4+ • 5	7	4600 • 4650	21
4L • 4P	9	5000	21
4V	9	5100	21
5L	10	5500	22
5P	10	8000 (5Si)	22
5Si • Lexmark Optra N	10	8100 • 8150	22
6L • Canon LBP-460	11	8500 • 8550	23
6P	12	9000 • 9500	24
1000	12	Lexmark	33
1010/1012/1015	12	Tektronix / Xerox	38
1100	12		
1150	13	Memory	
1160	13	Brother	38
1200	13	Canon	38
1300	13	HP	39
1500	13	Technical Manuals	
2100	13	Brother	39
2200	14	Canon	39
2300	15	HP - Ink Jet	39
2400	15	HP - Laser	39
2500	15	Lexmark	40
3015 • 3020 • 3030	15		

Terms and Conditions and other Great Things to Know

PRICING: This is listing of frequently used parts. prices can be checked on our web site at www.laserprinterparts.com
We update the site every few days.

WE WANT YOUR BUSINESS: Prices on laser printer parts do tend to change. Our prices are very competitive (good for you). Our low price commitment to you is that we will meet or beat any competitor's price on like items when humanly possible (also, good for you).

TERMS: Net 30 on approved credit. We accept Mastercard, Visa and American Express and can also ship COD. Orders for past due accounts will be held until the account is brought current. Past due accounts will be charged a late charge at the legal interest rate. We do charge \$35.00 for NSF checks. We do turn past due accounts (Not a good thing) over for collection if payment terms are not worked out in advance.

DAMAGED MERCHANDISE: If you receive a shipment from us with missing or damaged merchandise - save the shipping carton and notify the carrier. Then notify us with all the information and we will send out your replacement.

WARRANTY: Warranties expressed or implied are by the manufacturer. Return of defective merchandise is according to that manufacturers return policy.

RETURN AUTHORIZATIONS: You **MUST** have a RMA number, Merchandise will be refused if received without proper authorization. Non defective returned items must be returned in a new and sellable condition to receive credit and is subject to a restock charge. Special order items or sales over 30 days old may not be returned.

BACK ORDERS: Items not immediately available will be back ordered and shipped to you as soon as we receive them. Special order items are accepted on a noncancellable basis.

Seattle

800 221-2388

HP LASER PRINTERS

Convenience Kits

III Si / 4Si Paper Pickup Repair Kit - contains feed/separation rollers (6)	H3976-60001	4100 Roller Kit Includes "D" Pickup Roller, Tray 2 Feed/Sep Roll, Tray 1 Pickup Roll	H3970-60001
4/4+/5 Paper Exit Rebuild Kit - contains upper and lower delivery rollers, output rollers (4) and cogged belt	RG5-1425RBLT	4100 Repair Kit - includes pickup D rollers (4), clutch torque limiter, coupler, Tray1 pickup assy sep pad, Tray 2 feed sep roller, Tray 1 pickup roller	K4100
4V / 4MV Door Gear Set - contains 5 gears	LP-1552	4100 Tray 1 Repair Kit	K4000MP
5L Sep Pad Kit	RY7-5077	4200 & 4300 Tray 1 & 2 Roller Kit Includes Tray 1 Sep Pad, Tray 1 PU Roll, Tray 2&3 PU Roll, Tray 2&3 FR	LP-4200KIT
5L Pickup Assembly Repair Kit - Sep Pad Kit + PU Roller	RG5-1951-KIT	4200 & 4300 Tray 1 & 2 Roller Kit Includes Tray 1 PU Roll, Tray 2 Sep Pad, Tray 2 PU Rolls (2)	LP-4600RK
5Si PIU Rebuild Kit	RG5-1852-KIT	5000 Coupler Kit	C4119-67902
6L Sep Pad Kit	RY7-5077	5000 Repair Kit - includes pickup coupler, tray 1 pickup roller, Tray 2 pickup roller, sep pad(2), feed/sep roller (500 sheet), pickup roller assm (500 sht) tray 1 sep pad, Tray 2 sep pad & spring	K5000
6L Pickup Assembly Repair Kit - Sep Pad Kit + PU Roller	RG5-3486-KIT	5500/5550 Roller Kit - Tray 2, 3, & 4 Includes Pick up Roller (1) & Feed/Sep Roller (2)	RY7-5097
1100 Sep Pad + Pickup Roller Kit	RY7-5050-KIT	8100 / 8150 Paper Path Roller Kit - MP Tray feed roller, feed/sep roller (4), pickup roller (2)	H3977-60001
2100 Paper Feed Repair Kit - Includes Tray 1 pickup roller, Tray 1 sep pad, Tray 2 pickup roller, Tray 2 sep pad	LP-2100KIT	8100 PIU Repair Kit	RG5-4334-KIT
2200 Paper Feed Repair Kit - Includes Tray 1 pickup roller, Tray 1 sep pad, Tray 2 pickup roller, Tray 2 sep pad	LP-2200KIT		
3100 Sep Pad Kit	RY7-5077		
3100 Pickup Assembly Repair Kit - Sep Pad Kit + PU Roller	RG5-3486-KIT		
4000 / 4050 Tray 2/3 Tune Up Kit - includes half moon rollers (4), pickup coupler, clutch torque limiter and feed/sep rollers (2)	LP-4000KIT		
4000 / 4050 Tray 1 Repair Kit	K4000MP		
4000 / 4050 Tray Repair Kit - 500 Sheet - includes spring (4), sensor block (4), Lifter left & right (2) and stop	K4125A		
4000 / 4050 Tray Repair Kit - 250 Sheet - includes spring (4), sensor block (4), Lifter left & right (2) and sep roll mount assembly	K4126A		
4000 / 4050 Coupler Kit - includes pickup roller coupler and paper tray, load limit clips (4)	C4119-67902		
4000 / 4050 Paper Path Roller Kit - includes D roller (8), feed/sep roller (4), Tray 1 pickup roller	H3969-60001		

HP NETWORK CARDS

J3258 JETDIRECT 170X EXT - No Power Supply	J3258-61011
J3258 JETDIRECT EXT 170X 10BASET	J3258B
J3263 JETDIRECT EXTERNAL EXCHG	J3263-69001E
J6035 175x EXTERNAL JETDIRECT	J6035A
J6035A 175X PRINT SERVER	J6035-61051
J7934A JETDIRECT 620N 10BASE T	J7934-61001
J7934A JETDIRECT 620N EXCHANGE	J7934-69001E

HP FUSERS

II/III Fuser with Exchange	RG1-0939R	2200 Fuser with Exchange	RG5-5559E
		2200 Fixing Film Sleeve	LP-5560F
IIP/IIIP Fuser	RG1-1788	2300 Fuser	RM1-0354
IIP/IIIP Fuser with Exchange	RG1-1788E	2300 Fixing Film Sleeve	LP-0354F
IIISi/4Si Fuser with Exchange	RG5-0046E	2420 / 2430 Fuser	RM1-1491
4 Fuser	RG5-0454	2500 Fuser	RG5-6903
4 Fuser with Exchange	RG5-0454E	2550 Fuser	RG5-7572
4+/5 Fuser	RG5-0879	3015 / 3020 / 3030mfp Fuser	RM1-0865
4+/5 Fuser with Exchange	RG5-0879E	3100/3150 Fuser, Heating Element	RG5-4678
4L Fuser	RG5-0676	3100/3150 Fixing Film Sleeve	LP-2802F
4L Fixing Film Sleeve	LP-0678F	3200 Fixing Film Assembly	RG5-4589
4P Fuser	RG5-0676	3200 Fixing Film Sleeve	LP-4589F
4P Fixing Film Sleeve	LP-0678F	3300 Series Fuser	RG9-1493
4V Fuser with Exchange	RG5-1557E	3300 Series Fixing Film Sleeve	LP-1493F
5L Fixing Film Sleeve	LP-1964F	3380mfp Fuser	RM1-0999
5L Heating Element Assembly	RG5-1964	3500 / 3550 / 3700 CLJ Fuser Kit	Q3655A
5P Fuser	RG5-1700	4000/4050 Fuser with Exchange	RG5-2661E
5P Fuser with Exchange	RG5-1700E	4000/4050 Fixing Film Sleeve	LP-2661F
5P Fixing Film Sleeve	LP-2802F	4100 Fuser	RG5-5063
5SI Fuser (RG5-3686)	RG5-4447	4100 Fuser with Exchange	RG5-5063E
5SI Fuser with Exchange	RG5-4447E	4100 Fixing Film Sleeve	LP-5063F
6L Fixing Film Sleeve	LP-1964F	4200 Fuser	RM1-0013
6L Heating Element Assembly	RG5-3459	4200 Fuser Remfg with Exchange	RM1-0013E
6P Fuser with Exchange	RG5-4110E	4200 Fixing Film Sleeve	LP-0013F
6P Fixing Film Sleeve	LP-2802F	4250 Fuser	RM1-1082
1000 Fuser	RG9-1493	4300 Fuser	RM1-0101
1000 Fixing Film Sleeve	LP-1493F	4350 Fuser	RM1-1082
1100 Fixing Film Assembly	RG5-4589	4500 / 4550 Fuser Kit	C4197A
1100 Fixing Film Sleeve	LP-4589F	4500 / 4550 Fuser Kit with Exchange	C4197ACE
1150 Fuser	RM1-0715	4500 / 4550 Fuser ONLY with Exchange	RG5-5154E
1200 Fuser	RG9-1493	4500 / 4550 Transfer Kit	C4196A
1200 Fixing Film Sleeve	LP-1493F	4500 / 4550 Transfer Kit - Refurb by GRC	C4196AC
1300 Fuser	RM1-0715	4500 / 4550 Drum Kit	C4195A
1320 Fuser	RM1-1289	4600 Fuser Kit	C9725A
1500 Fuser	RG5-6903	4600 Transfer Kit	C9724A
2100 Fuser with Exchange	RG5-4132E	4650 Fuser	Q3676A
2100 Fixing Film Sleeve	LP-2661F	5000 Fuser with Exchange	RG5-5455E
		5000 Fixing Film Sleeve	LP-5455F
		5000-D640 Fuser High Production	C5627A

5100 Fuser	RG5-7060	3200 Maintenance Kit	H3965-60001
5100E Fuser with Exchange	RG5-7060E	4000/4050 Maintenance Kit	C4118-67909
5500 Fuser Kit	C9735A	4000/4050 Maintenance Kit with Exch Fuser	C4118-67902E
5550 Fuser Kit	Q3984-67901	4100 / 4101 Maintenance Kit	C8057-67901
8000 Fuser (RG5-3686)	RG5-4447	4100 / 4101 Maint Kit with Exch Fuser	C8057-67901E
8000 Fuser with Exchange	RG5-4447E	4200 Maintenance Kit	Q2429-67902
8100/8150 Fuser with Exchange	RG5-4318E	4200 Maintenance Kit with Exchange Fuser	Q2429-67902E
8100/8150 Fuser	RG5-4318	4300 Maintenance Kit	Q2436-67901
8500/8550 Drum Kit	C4153A	5000 Maintenance Kit with Exchange Fuser	C4110-69006E
8500/8550 Fuser Kit	C4155A	5100 Maintenance Kit	Q1860-67910
8500/8550 Transfer Kit	C4154A	5100 Maintenance Kit with Exchange Fuser	Q1860-69027E
9000 / 9050 Fuser with Exchange	RG5-5750E	8000 Maintenance Kit with Exchange Fuser	C3971-69002E
CLJ 9000 Fuser	C8556A	8100/8150 Maint Kit with Exch Fuser	C3914-69001E
Grease for Installing Fuser Sleeves	8172-25G	9000 Maintenance Kit	C9152-67901
HP MAINTENANCE KITS		9000 Maintenance Kit with Exchange Fuser	C9152-67901E
II/III Maintenance Kit with Rebuilt Fuser	33449-69007R	HP LASER PRINTER PARTS - By Description	
IIP/IIIP Maintenance Kit with Exch Fuser	33481-69007E	II / IID / III / IIID (SX)	
IIISi/4Si Maintenance Kit with Exch Fuser	C2062-67901E	II CABLE, LASER/SCANNER	RG1-0908
4 Maintenance Kit with Exchange Fuser	C2001-67912E	II CASSETTE STOP RIGHT	RA1-3913
4+ Maintenance Kit with Exchange Fuser	C2037-69010E	II CLUTCH SPRING	LP82-2847
4L/4P Maintenance Kit	C2003-69010	II COVER, REAR	RA1-4024
4V Maintenance Kit with Exchange Fuser	C3141-69010E	II DC CONTROLLER EXCHANGE	RG1-0710E
5 Maintenance Kit with Exchange Fuser	C3916-69001E	II DC POWER SUPPLY PCB - EXCH	RG1-1394E
5L Maintenance Kit	H3971-60001	II DEFLECTOR	RA1-4021
5P Maintenance Kit with Exchange Fuser	H3973-69001E	II FAN, UPPER - GENERIC	RH7-1122GN
5Si Maintenance Kit with Exchange Fuser	C3971-69002E	II FIXING ROLLER CLEANER	RG1-0966
6L Maintenance Kit	H3972-60001	II FORMATTER PCA EXCH	SG4-6212E
6P Maintenance Kit with Exchange Fuser	H3966-69010E	II GEAR, 14T	RS1-0132
1100 Maintenance Kit	H3965-60001	II GEAR, 20T	RS1-0116
2100 Maintenance Kit with Exchange Fuser	H3974-60001E	II GEAR, 53T	RS1-0119
2200 Maintenance Kit with Exchange Fuser	H3978-60001E	II GEAR, HEAT ROLLER 32T	RS5-0020
2300 Maintenance Kit	U6180-60001	II HEATER LAMP 115V 620W HALOG	RH7-4024
3100/3150 Maintenance Kit	H3975-69001	II OZONE FILTER	RF1-2130
		II OZONE FILTER EARLY STYLE	RA1-4081
		II PAPER DELIVERY ASSY	RG1-0945
		II PAPER PRESS ASSY LEFT ST	RA1-3917
		II PICK UP ROLLER DRIVE ASSY	RG1-0934
		II POWER SUPPLY HIGH VOLT-EXCH	RG1-0936E
		II PRESSURE ASSEMBLY	RG1-0935
		II SEP PAD CORK (4/PK)	LP-1145
		II SEPARATION PAD GENERIC	RF1-1145G
		II SIZE SENSOR PCB ASSY	RG9-0605

4 LASER SCANNER REBUILT	RG5-0449R	4/4+/5 PAPER EXIT REBUILD KIT WITH GEARS	
4 LATCH HOLDER	RB1-2125	RG5-0456-KIT	
4 LATCH, REAR DOOR	RB1-2335	4/4+/5 PAPER FEEDER PCB ASS'Y	RG5-1086
4 MAINTENANCE KIT-EXCH	C2001-67912E	4/4+/5 PLATE, GROUNDING	RB1-2106
4 MOTOR, MAIN DC 5.8W	RH7-1152	4/4+/5 ROLLER, DELIVERY LOWER	RF5-1077
4 PAPER FEED ASSY	RG5-0451	4/4+/5 ROLLER, DELIVERY UPPER	RF5-1076
4 PAPER INPUT ASM EXCHG	RG5-0451E	4/4+/5 ROLLER, ENV FEED	RA2-1567
4 PICKUP MOTOR DRIVER PCB ASSY	RG5-0512	4/4+/5 ROLLER, LOWER CASS PICK UP	RB1-2632
4 PIU REBUILT (C2001-60161)	RG5-0451R	4/4+/5 ROLLER, TRANSFER	RF5-0349
4 POWER ASSY	RG5-0531	4/4+/5 SENSOR HOLDER ASSEMBLY	RG5-0466
4 RETROFIT KIT	LP1-050	4/4+/5 SENSOR PCB ASS'Y	RG5-0514
4 ROLLER, ENV FEEDER PICKUP 2	RF1-3547	4/4+/5 SHUTTER, LASER	RB1-2080
4 ROLLER, FUSER UPPER	RB1-2263	4/4+/5 SOLENOID PICKUP	RH7-5071
4 ROLLER, LOWER FUSER	RB1-2264G	4/4+/5 SPRING, COMPRESSION	RS5-2175
4 ROLLER, PICK UP TRAY 2	RB1-2126	4/4+/5 SPRING, LEAF	RB1-2139
4 ROLLER, PICK UP TRAY 2 GENERIC	RB1-2126G	4/4+/5 SUPPORT, CARTRIDGE	RB1-2105
4 ROLLER, PRESSURE, LOWER	RB1-2264	4/4+/5 TRANSFER GUIDE ASSEMBLY	RG5-0469
4 ROLLER, UPPER, FUSER	RB1-2263G	4+ BUSHING, ROLLER, LEFT	RS5-1098
4 SENSOR LEVER	RB1-2273	4+ BUSHING, ROLLER, RIGHT	RS5-1097
4 SEP PAD	RF5-0343	4+ COVER, LEFT	RF5-0737
4 SEP PAD CORK (4/PK)	LP-0343	4+ COVER, RIGHT	RF5-0736
4 SHAFT, GEAR	RB1-2319	4+ DC CONTR EXCH	RG5-0966E
4 SPRING, COMPRESSION	RS5-2218	4+ DISPLAY ASSY	RG5-1077
4 SPRING, REAR DOOR	RS5-2219	4+ DOOR ASSY, REAR	RF5-0733
4 SUPPORT STRAP FOR REAR DOOR	RB1-2354	4+ DOOR, MP (FRONT PANEL)	RB1-3559
4 THERMISTOR	RH7-7045	4+ DRIVE ASSM, LWR CASSETTE	RG5-1099
4 THERMOSWITCH ASS'Y	RG5-0474	4+ FAN	RH7-1177
4 TRAY ASSM MP	RG5-0472	4+ FORMATTER PCB REBUILT	C2038-67901R
4 TRAY EXTENDER MP	RB1-2143	4+ GUIDE, SEPARATION	RF5-0744
4 UNIVERSAL 500 SHEET TRAY	C2084A	4+ HEAT LAMP 220V	RH7-4055
4/4+ BASE, GUIDE	RB1-2116	4+ HINGE, TOP COVER LARGE	RB1-3473
4/4+ CLEANING BRUSH	RB1-2260	4+ LEVER, FUSER SENSOR	RB1-3522
4/4+ COVER, INNER	RB1-2141	4+ MAINT KIT-EXCH	C2037-69010E
4/4+ DELIVERY UNIT EXCHANGE	RG5-1425E	4+ PAPER FEED ASSY REBUILT	RG5-0877R
4/4+ HINGE, TOP COVER, RT SMALL	RB1-2364	4+ PAPER OUTPUT ASSM	RG5-0886
4/4+ HOLDER, PAPER, FRONT	RF5-0369	4+ PHOTOSENSOR	WG8-0291
4/4+ PLATE, END (LENGTH ADJ)	RF5-0446	4+ ROLLER, TRAY 2 PICKUP, GENR	RB1-3477G
4/4+ ROLLER, MP TRAY P/U	RB1-2127	4+ ROLLER, LOWER, FUSER	RB1-3517G
4/4+ ROLLER, PICK-UP TRAY 3	RB1-2650	4+ ROLLER, UPPER, FUSER	RB1-3516G
4/4+ TRANSFER GUIDE ASSY	RG5-0468	4+ THERMISTOR	RH7-7054
4/4+ TRAY BASE, MP ASSEMBLY	RG5-0467	4+ TRAY ASSM, MP	RG5-0888
4/4+ UPPER GUIDE, DELIVERY	RF5-0532	4+ TRAY, MP EXTENDER	RB1-3558
4/4+/5 ARM, SENSOR	RB1-2168	4+/5 CABLE, DC CONT/LASER	RG5-0976
4/4+/5 ARM, SENSOR 1	RB1-2132	4+/5 CABLE, DC CONT/SCANNER	RG5-0975
4/4+/5 ARM, SENSOR 2	RB1-2133	4+/5 COVER, WIRE	RF5-0738
4/4+/5 BELT, COGGED	XF9-0410	4+/5 DC POWER SUPPLY REBUILT	RG5-2499R
4/4+/5 COVER, HIGH VOLTAGE	RB1-2226	4+/5 DRIVE GEAR ASM	RG5-0876
4/4+/5 COVER, SENSOR	RB1-2186	4+/5 FAN -TAKE OFF PART	RH7-1177-TO
4/4+/5 ENV FEEDER P/U ROLL #1	RA2-1839	4+/5 FUSER ASSEMBLY	RG5-0879
4/4+/5 ENV FEEDER P/U ROLL #2	RA2-1840	4+/5 FUSER ASSEMBLY EXCH	RG5-0879E
4/4+/5 ENV FEEDER SEP ROLL LWR	RF1-3545	4+/5 FUSER OUTPUT GEAR	RS5-0393
4/4+/5 FOOT	RB1-2114	4+/5 GEAR, UFR 42T	RS5-0388
4/4+/5 GUIDE	RB1-2131	4+/5 GUIDE, PAPER ENTRANCE	RB1-3518
4/4+/5 GUIDE, MP TRAY, UPPER	RB1-2129	4+/5 GUIDE, SEPARATION, LOWER	RB1-3526
4/4+/5 HOLDER, SENSOR	RB1-2134	4+/5 HEATER LAMP HALOGEN	RH7-4054
4/4+/5 HOLDER, SEPARATION PAD	RB1-2173	4+/5 LEVER, SWITCH	RB1-2138
4/4+/5 LEVER, SENSOR	RB1-2177	4+/5 MOTOR, MAIN DRIVE	RH7-1301
4/4+/5 MOTOR, STEPPING	RH7-1197	4+/5 ROLLER, FUSER, UPPER	RB1-3516
4/4+/5 PAPER EXIT REBUILD KIT	RG5-	4+/5 ROLLER, PRESSURE, LOWER	RB1-3517
1425RBLT		4+/5 SCANNER ASM REBUILT (RG5-0911)	RG5-0903R

4+/5 SPRING, COMPRESSION RS5-2267
 4+/5 THERMOSWITCH ASSEMBLY RG5-0881
 5 COVER, TOP ASSY RG5-2186
 5 DELIVERY UNIT EXCHANGE RG5-2189E
 5 DOOR, TRAY 1 RB1-7886
 5 EXTENSION, TRAY 1 RB1-7885
 5 FAN ASSY RH7-1178
 5 FORMATTER PCA EXCHANGE C3919-69001E
 5 GUIDE, UPPER DELIVERY RF5-0647
 5 LATCH, DOOR RB1-7890
 5 MAINTENANCE KIT EXCH C3916-69001E
 5 OPTIONAL 500 SHEET ASM C3921A
 5 PAPER FEED ASSY EXCHG. RG5-2195E
 5 PAPER OUTPUT ASSEMBLY RG5-2189
 5 PLATE, SIDE RF5-0430
 5 POWER SUPPLY RG5-2499
 5 ROLLER, PICK UP, 2ND CASSETT RB1-7983
 5 ROLLER, PICK UP, TRAY 1 RB1-2205
 5 ROLLER, PICK UP, UPPER CASSETTE RB1-7911
 5 SPRING, REAR DOOR LATCH RS5-2571
 5 TRANSFER GUIDE ASSY (No Roller) RG5-2192
 5 TRAY ASSM RG5-2199
 5 TRAY, 250 SHEET UNIV C3924A
 5 TRAY, 500 SHEET UNIVERSAL C3923A

4L / 4P (PX)

4L ROLLER, PU "D-Shaped" RB1-3029G
 4L DELIVERY ASS'Y RG5-0681
 4L DOOR, RIGHT (POWER) RB1-2978
 4L DOOR, TOP RB1-3129
 4L DOOR, LEFT, I/O RB1-2977
 4L FAN RG5-0703
 4L FIXING FILM ONLY LP-0678F
 4L FUSER ASM RG5-0676
 4L FUSER EXCHANGE RG5-0676E
 4L GEAR 17T/17T RS5-0316
 4L GEAR 22T RS5-0315
 4L GEAR TRAIN PLATE RG5-0791
 4L GEAR, MOTOR RG5-0765X
 4L MAINTENANCE KIT C2003-69010
 4L MIRROR ASS'Y RG5-0667
 4L MOTOR, MAIN RG5-0765
 4L PAPER PICKUP ASSEMBLY RG5-0668
 4L REAR DOOR ASSY RG5-0691
 4L ROLL, PRESSURE RB1-3100
 4L ROLLER (USED IN FUSER) RB1-3107
 4L ROLLER ASSEMBLY, TOP OBL RG5-0711
 4L ROLLER ASSY, FRONT OBLIQUE RG5-0669
 4L ROLLER, DELIVERY ASSY RG5-0683
 4L ROLLER, FUSER DELIVERY RB1-3103
 4L ROLLER, PICK UP - "D" SHAPPED RB1-3029
 4L ROLLER, PICK-UP - ROUND RB1-3028
 4L ROLLER, TRANSFER RF5-0596
 4L RUBBER, CONTINUITY RB1-3109
 4L SCANNER RG5-0662
 4L SENSOR, PAPER RF5-0601
 4L SEP PAD RF5-0343
 4L SOLENOID, PICK UP (SC2) RH7-5092
 4P DELIVERY ASS'Y RG5-0681
 4P FAN RG5-0703

4P FIXING FILM ONLY LP-0678F
 4P FUSER ASM RG5-0676
 4P FUSER ASM EXCHANGE RG5-0676E
 4P GEAR TRAIN PLATE RG5-0791
 4P GEAR, MOTOR RG5-0765X
 4P GUIDE, FUSER ENTRANCE RG5-0690
 4P MAINTENANCE KIT C2003-69010
 4P MOTOR, MAIN RG5-0765
 4P PANEL, LIMIT RF5-1366
 4P PAPER PICKUP ASSEMBLY RG5-0668
 4P POWER SWITCH ASSY RG5-0805
 4P ROLLER (USED IN FUSER) RB1-3107
 4P ROLLER ASSEMBLY, TOP OBLIQUE RG5-0711
 4P ROLLER ASSM, FRONT OBLIQUE RG5-0669
 4P ROLLER, FUSER DELIVERY RB1-3103
 4P ROLLER, PICK UP - ROUND RB1-3028
 4P ROLLER, PICK UP -"D" SHAPED RB1-3029
 4P ROLLER, PRESSURE RB1-3100
 4P ROLLER, PU "D-Shaped" RB1-3029G
 4P ROLLER, TRANSFER RF5-0596
 4P RUBBER, CONTINUITY RB1-3109
 4P SCANNER ASSY. EXCH. RG5-0800E
 4P SENSOR, PAPER RF5-0601
 4P SEP PAD RF5-0343
 4P SOLENOID, PICK UP (SC2) RH7-5092

4V (BX)

4V ASSEMBLY, GEAR MOUNTING RG5-1396
 4V CLIP, PAPER ADJ TRAY 3 C3760-60509
 4V CLUTCH RH7-5095
 4V CLUTCH, ELECTROMAGNETIC RH7-5094
 4V CLUTCH, ELECTROMECH RH7-5152
 4V DC CONTROLLER REBUILT RG5-1559R
 4V DC POWER SUPPLY - EXCHG RH3-2150E
 4V DELIVERY DRIVE ASSY RG5-0505
 4V DOOR ASSEMBLY, FRONT RG5-1552
 4V DOOR GEAR SET LP-1552
 4V DRIVE ASSEMBLY, MAIN RG5-1398
 4V DRUM DRIVE ASSM RG5-1566
 4V FACE DOWN DELIVERY ASSEMBLY RG5-0198
 4V FAN RH7-1126
 4V FAN, RIGHT REAR RH7-1214
 4V FAN, UPPER RH7-1317
 4V FORMATTER PCA EXCHANGE C3143-69001E
 4V FUSER ASM - EXCH RG5-1557E
 4V FUSER/PAPER GUIDE BX RF5-0327
 4V GEAR, 14T RS5-0182
 4V GEAR, 14T RS5-0194
 4V GEAR, 18T RS5-0581
 4V GEAR, 40T RS5-0058
 4V GEAR, HEAT ROLLER RS5-0180
 4V GUIDE, DELIVERY UNIT RG5-1545
 4V LAMP, FUSER RH7-4014
 4V LEVER RB1-1324
 4V LEVER, RELEASE RB1-1360
 4V LEVER, SHUTTER, DRUM RB1-1374
 4V MAINTENANCE KIT EXCH C3141-69010E
 4V MOTOR, MAIN (DC 17.5W) RH7-1199
 4V PICK UP ROLLER, TRAY 2 (2 per mach) RB1-1386G
 4V POWER SUPPLY, HIGH VOLTAGE RG5-2044E

4V ROD, LEFT	RB1-1294
4V ROLLER, FIXING, UPPER	RG5-1468
4V ROLLER, FUSER, UPPER	RB1-1442
4V ROLLER, LOWER CASSETTE P/U	C3760-60506
4V ROLLER, PICKUP	RB1-1386
4V ROLLER, PICKUP ASSEMBLY	RG5-1391
4V ROLLER, PICKUP, GENERIC	RB1-1411G
4V ROLLER, PICK-UP, TRAY 1	RB1-1411
4V ROLLER, PRESSURE	RB1-1443
4V ROLLER, PRESSURE, SLEEVED	RB1-5472
4V ROLLER, REGISTRATION	RG5-0195
4V ROLLER, TRANSFER ASSY	RG5-1410
4V SEP PAD, MP TRAY	RF5-0302
4V SEP. CLAWS (PICKER FINGERS)	RB1-1449
4V THUMBSCREW	RB1-5788

5L (AX) Canon LBP460

5L ARM, PRESSURE	RB1-7203
5L ARM, SEPARATION	RB2-6221
5L BUSHING	RB1-7184
5L BUSHING	RB1-7224
5L BUSHING	RB1-7288
5L CLUTCH	RB1-7197
5L COVER INTERLOCK ASSY.	RG5-1984
5L DOOR, MEMORY	RB1-7321
5L DOOR, TONER	RF5-1501
5L FEEDER ASSEMBLY	RG5-1942
5L FEEDER DRIVE ASSEMBLY	RG5-1947
5L FIXING FILM ASSM	RG5-1964
5L FIXING FILM ONLY	LP-1964F
5L FUSER RELEASE KIT	RY7-5007
5L GEAR KIT	RY7-5005
5L GEAR, 27T	RS5-0796
5L HOLDER, ARM	RB1-7206
5L LEVER, FACE UP/FACE DOWN	RB1-7276
5L LEVER, SENS	RB1-7293
5L MAINTENANCE KIT	H3971-60001
5L MOTOR, MAIN	RH7-1282
5L OUTPUT EXTENDER 1	RB1-7326
5L PICKUP ASSEMBLY REPAIR KIT	RG5-1951-KIT
5L PROTECTOR JP	RB1-7334
5L ROLLER ASSM, PICK-UP	RG5-1951
5L ROLLER, 2 SECTION IDLER	RB1-7226
5L ROLLER, DELIVERY (FACE DOWN)	RB1-7284
5L ROLLER, EXIT	RF5-1521
5L ROLLER, FACE UP	RB1-7285
5L ROLLER, FUSER EXIT	RF5-1522
5L ROLLER, PICK-UP	RB2-1634
5L ROLLER, PRESSURE, LOWER	RF5-1516
5L ROLLER, TRANSFER	RF5-1534
5L SCANNER ASSEMBLY	RG5-2004
5L SEP PAD KIT	RY7-5077
5L SOLENOID, PAPER P/U	RH7-5139
5L SPRING WIRE #1, DELIVERY	RB1-7286
5L SPRING WIRE #2, DELIVERY	RB1-7287
5L SPRING, COMPRESSION	RS5-2502
5L SPRING, TORSION	RB1-7294
5L SWITCH, FACEUP/FACEDOWN	RB2-1644

5P (PX)

5P ARM, INPUT SENSOR	RB1-6006
5P ARM, MULTI PURPOSE SENSOR	RB1-5939
5P BRUSH, CLEANING	RF5-0593
5P CAM	RB1-6317
5P COVER, SIDE ASSEMBLY	RG5-1710
5P COVER, TOP	RG5-1709
5P DELIVERY ASSY	RG5-0681
5P DELIVERY COVER	RB1-5918
5P FACE UP TRAY ASSY	RG5-1707
5P FAN ASSY	RG5-1801
5P FIXING FILM ONLY	LP-2802F
5P FUSER ASM	RG5-1700
5P FUSER ASM EXCH	RG5-1700E
5P FUSING ROLLER ASM	RG5-1702
5P GEAR TRAIN ASSEMBLY	RG5-1713
5P GEAR, 24T FUSER	RS5-0637
5P NAME PLATE	C3150-00004
5P PANEL, LIMIT	RF5-1366
5P PICKUP ASSEMBLY, MP	RG9-1083
5P PICKUP ASSEMBLY, TRAY 2	RG5-1692
5P PLATE, END	RB1-6382
5P ROLLER (USED IN FUSER)	RB1-3107
5P ROLLER ASM, SMALL MEDIA	RG5-1814
5P ROLLER ASSY, TOP OBLIQUE	RG5-1698
5P ROLLER P/U MP TRAY	RB1-2205
5P ROLLER, FUSER DELIVERY	RB1-5917
5P ROLLER, LOWER DELIVERY ASM	RG5-0682
5P ROLLER, PRESSURE, LOW	RB1-5910G
5P ROLLER, TRANSFER	RF5-0596
5P ROLLER, TRAY 2 PICK-UP	RB1-6332
5P RUBBER, CONTINUITY	RB1-3109
5P SCANNER, LASER ASSY	RG5-1780
5P SEP PAD	RF5-0343
5P TRANSFER GUIDE ASSY	RG5-1706
5P TRAY-(TRAY 1 ASSY) MP	RG5-1697

5Si (WX) Also HP8000 / Lexmark Optra N / QMS 550

5SI MOTOR, PICK-UP (SMT31)	RH7-1172
5SI ARM, SENSOR	RB1-6417
5SI BELT, TIMING	XF9-0564
5SI BUSHING	FB1-6823
5SI BUSHING, TRAN GUI	RB1-6441
5SI CLAW, LIFTER ARM	RB1-6538
5SI CLAW, SEPARATION	RB1-6613
5SI CLAW, SEPARATION, TEFLON	RB1-6643
5SI CLUTCH, ELECTROMAGNETIC	RH7-5204
5SI CLUTCH, ELECTROMAGNETIC	RH7-5205
5Si COVER, RIGHT (FUSER)	RB1-6618
5SI COVER, RT	RG5-1915
5Si DISPLAY PANEL	RG5-2433
5SI DIVERTER ASSEMBLY	RG9-1150
5SI DOOR ASM, TRAY 1	RG5-1883
5SI DUPLEX UNIT EXCH	C4782-69501E
5SI DUPLEXER EXCHANGE	C3762-60501E
5SI FACEDOWN DEL ASY	RG5-1874
5SI FACEDOWN DEL EXCH	RG5-1874E
5SI FAN (FAM 1, FAN 2)	RH7-1266
5SI FAN (FAN 3)	RH7-1271

6P (PX)

6P AC TERMINAL PCB ASS'Y	RG5-1417
6P ARM, INPUT SENSOR	RB1-6006
6P BRUSH, CLEANING	RF5-0593
6P CLAW, SEPARATION	RB1-3426
6P COVER ASSY, POWER CORD	RG5-2779
6P DC CONT/POW SUPPLY EXCH	RG5-2826E
6P DELIVERY ASS'Y	RG5-0681
6P DELIVERY COVER	RB1-5918
6P DOOR ASSY, TOP	RG5-2782
6P DOOR, I/O ACCESS	RB1-9151
6P FACE-UP ASSY	RG5-2784
6P FAN ASM	RG5-2776
6P FIXING FILM ASSY	RG5-2802
6P FIXING FILM ONLY	LP-2802F
6P FUSER ASSY	RG5-4110
6P FUSER ASSY EXCHG	RG5-4110E
6P GEAR, 16T	RS5-0636
6P GUIDE ASSY, TRANSFER	RG5-1706
6P GUIDE, LOWER DELIVERY	RB1-5915
6P MAINTENANCE KIT EXCHANGE	H3966-69010E
6P MOTOR, MAIN	RG5-2786
6P NAME PLATE	C3980-00001
6P OPERATOR INSTRUCTIONS ON CD	C3980-91037
6P PANEL, LIMIT	RF5-1366
6P PAPER PICKUP ASM TRAY 1	RG5-2790
6P PAPER PICKUP ASM TRAY 2	RG5-2796
6P PLATE, END	RB1-6382
6P ROLLER, FUSER DELIVERY	RB1-9181
6P ROLLER, LOWER PRESSURE	RB1-9210G
6P ROLLER, P/U ASM, MP TRAY 1	RG5-2791
6P ROLLER, P/U MP TRAY	RB1-2205
6P ROLLER, PRESSURE, LOWER	RB1-9210
6P ROLLER, TOP OBLIQUE ASSY	RG5-1698
6P ROLLER, TRANSFER	RF5-0596
6P ROLLER, TRAY 2 PICK-UP	RB1-6332
6P RUBBER, CONTINUITY	RB1-3109
6P SCANNER	RG5-2848
6P SCANNER EXCHANGE	RG5-2848E
6P SEP PAD	RF5-0343
6P TRAY, FACEUP	RB1-9171
6P USER GUIDE EURO ENGLISH	C3980-91013

1000 Series

1000 BOARD, ENGINE CONTROL	RG0-1093
1000 COVER, INPUT TRAY	RA0-1405
1000 DELIVERY SENSOR PCB	RG0-1082
1000 DOOR, TONER CART	RG0-1091
1000 FIXING FILM ONLY	LP-1493F
1000 FUSER	RG9-1493
1000 GEAR CLUTCH ASY	RG0-1020
1000 LINK, CONNECTING	RA0-1023
1000 LINK, CONNECTING	RA0-1023
1000 PAPER FEED ASSM	RG0-1005
1000 PAPER LIFT PLATE ASSY	RG0-1006
1000 PAPER PICKUP ASSM, TRAY 2	RG0-1085
1000 PAPER PICKUP SHAFT ASSM	RG0-1007
1000 PLATE ASSY, LEFT	RG0-1084
1000 PLATE ASSY, RIGHT SIDE	RG0-1083

1000 ROLLER, PAPER PICKUP	RL1-0303
1000 ROLLER, PRESSURE	RF0-1002G
1000 ROLLER, TRANSFER	RG9-1483
1000 SEP PAD	RF0-1014

1010/1012/1015

1010/1012/1015 FUSER 110V	RM1-0660
1010/1012/1015 PAPER PU ASSY	RM1-0641
1010/1012/1015 ROLL, PU "D"	RL1-0266
1010/1012/1015 SEP PAD	RM1-0648

1100

1100 BUSHING, PRESS ROLL, LEFT	RB2-3956
1100 BUSHING, PRESS ROLL, RIGHT	RB2-3957
1100 BUSHING, RIGHT TRANSF ROL	RB2-3939
1100 CLUTCH KIT	RY7-5051
1100 DELIVERY ASSEMBLY, KIT	RY7-5060
1100 DELIVERY ASSY	RG5-4593
1100 DUCT	RB2-4005
1100 FIXING FILM ASSEMBLY	RG5-4589
1100 FIXING FILM ONLY	LP-4589F
1100 FIXING PRESSURE ASSY LEFT	RG5-4591
1100 FIXING PRESSURE ASSY RIGHT	RG5-4592
1100 FLAG, PAP OUTPUTSENS	RB2-3960
1100 GEAR DRIVE ASSY	RG5-4586
1100 GEAR FOR PICK-UP	RG5-4585
1100 GEAR KIT	RY7-5049
1100 GUIDE, FIXING	RB2-3958
1100 GUIDE, LEFT CARTRIDGE GUI	RF5-2818
1100 GUIDE, RIGHT CARTRIDGE GU	RF5-2819
1100 HOLDER, OUTPUT	RG9-1329
1100 INPUT HOLDER	RG9-1332
1100 INPUT PAPER BIN	RG5-4602
1100 MAINTENANCE KIT	H3965-60001
1100 MOUNT, ARM	RB2-4034
1100 PAPER GUIDE PLATE ASSY	RG5-4582
1100 PICKUP ASSEMBLY	RG5-4581
1100 PLATE, RIGHT SIDE	RB2-3942
1100 POD, LEFT SIDE CHASSIS	RB2-4018
1100 POD, RIGHT (SUPPORT)	RB2-4019
1100 RIGHT DOOR RAIL ASSY	RG5-4588
1100 ROLLER HOLDER	RG5-4584
1100 ROLLER, FACE DOWN DELIVERY	RF5-2830
1100 ROLLER, FACE UP DELIVERY	RF5-2822
1100 ROLLER, FEEDER	RB2-3912
1100 ROLLER, IDLER	RB2-3931
1100 ROLLER, PAPER PICKUP	RB2-4026
1100 ROLLER, PRESSURE	RF5-2823
1100 ROLLER, TRANSFER	RG5-4657
1100 SEP PAD & PICKUP ROLLER KIT	RY7-5050-KIT
1100 SHAFT, PICKUP ROLLER DRIVE	RB2-3943
1100 SHAFT, ROLLER	RB2-3930
1100 SPRING, KICK PLATE	RS6-2122
1100 SUB PAD	RF5-2820
1100 SUB PAD	RF5-2821

1150

1150 FACE DOWN DEL ASY	RM1-0556
1150 FUSER ASM	RM1-0715
1150 GEAR/CLUTCH ASSY KIT	RM1-0551
1150 INPUT TRAY ASSY	RM1-0553
1150 LINK, CONNECTING	RA0-1023
1150 LINK, CONNECTING	RA0-1023
1150 PAPER PICKUP ASSM	RM1-0531
1150 ROLL, TRANSFER	RM1-0550
1150 ROLLER & HOLDER ASM	RG0-1019
1150 ROLLER, PICKUP	RL1-0303
1150 SEP PAD	RF0-1014

1160

1160 FUSER 110V	RM1-1289
1160 PAPER PU ROLL ASSY	RL1-0540
1160 ROLLER, TRANSFER	RM1-1471
1160 SEP PAD TRAY 2	RM1-1298

1200 Series

1200 CABLE, LASER SCANNER FLEX	RH2-5440
1200 ENGINE CONTROL BOARD	RG0-1012
1200 FACE DOWN DELIVERY ASSY	RG0-1010
1200 FIXING FILM ONLY	LP-1493F
1200 FORMATTER	C7857-60001
1200 FUSER ASSY	RG9-1493
1200 GEAR CLUTCH ASY	RG0-1020
1200 GEAR KIT	RY7-5081
1200 GEAR KIT	RY7-5081
1200 LASER SCANNER ASSM	RG9-1486
1200 LINK, CONNECTING	RA0-1023
1200 LINK, CONNECTING	RA0-1023
1200 PAPER FEED ASSM	RG0-1005
1200 PAPER LIFT PLATE ASSY	RG0-1006
1200 PAPER PICKUP SHAFT ASSM	RG0-1007
1200 PLATE ASSY, LEFT	RG0-1002
1200 PLATE ASSY, RIGHT	RG0-1001
1200 PRINTER INPUT, PAPER TRAY	RG0-1013
1200 PRINTER INPUT, TRAY COVER	RG0-1014
1200 ROLLER, PICK UP	RL1-0303
1200 ROLLER, PRESSUR	RF0-1002G
1200 ROLLER, TRANSFER	RG9-1483
1200 SEP PAD	RF0-1014
1200 SEP PAD KIT, SCANNER	RY7-5055
1200 TRAY ASSY, PICKUP	RG0-1069
1220 DELIVERY SENSOR PCB	RG0-1082
1220 COPIER/SCANNER ASSY	R37-5020
1220 COPIER/SCANNER ASSY EXCHA	R37-5020E
1220 TRAY ASSY, PICKUP	RG0-1069

1300 Series

1300 1284I/O EEE MODUAL	C6436-67004
1300 250 SHEET PI CASS (No Front Cover)	RM1-0613
1300 FACE DOWN DEL ASY	RM1-0556
1300 FORMATTER (Q1334A)	Q1890-60001
1300 FUSER ASM	RM1-0715
1300 GEAR, 41T	RC1-1755
1300 GEAR, REDUCTION, 87/23T	RC1-1752

1300 GEAR/CLUTCH ASSY KIT	RM1-0551
1300 JETDIRECT 200M PRINTSERVER	J6039-61041
1300 LINK, CONNECTING	RA0-1023
1300 LINK, CONNECTING	RA0-1023
1300 PAPER PICKUP ASSM	RM1-0531
1300 PLATE ASSY, RIGHT SIDE	RM1-0527
1300 ROLL, TRANSFER	RM1-0550
1300 ROLLER & HOLDER ASM	RG0-1019
1300 ROLLER, PICKUP	RL1-0303
1300 SEP PAD	RF0-1014
1300xi INPUT TRAY ASSY	RM1-0553
1320 FUSER 110V	RM1-1289
1320 PAPER PU ROLL ASSY	RL1-0540
1320 ROLLER, TRANSFER	RM1-1471
1320 SEP PAD TRAY 2	RM1-1298
1320nw/tn TRAY 3 ASSY	Q5931A

1500

1500 COLLAR, SPRING	RB1-2190
1500 DAMPER ASSEMBLY	RB2-6248
1500 FUSER	RG5-6903
1500 HINGE, LEFT	RB2-3041
1500 PICKUP ASSM, TRAY 1	RG5-6952
1500 PICKUP ASSM, TRAY 2	RB3-0161
1500 ROLLER ASSY, OUTPUT	RG5-6897
1500 ROLLER, PICKUP, TRAY 1	RB3-0160
1500 ROLLER, PICKUP, TRAY 2	RB3-0129
1500 ROLLER, REGISTRATION	RG5-6939
1500 ROLLER, TRANSFER	RF5-4040
1500 SEP PAD TRAY 2	RF5-4258
1500 SEP PAD, TRAY 1	RF5-4012
1500 SEP PAD, TRAY 2	RF5-4258
1500 SPRING, TENSION	RS6-2030

2100 Series

2100 ARM, PAPER SENSOR	RB2-3010
2100 ARM, RELEASE, LEFT	RB2-3004
2100 ARM, RELEASE, RIGHT	RB2-3005
2100 BUSHING	RB2-3475
2100 BUSHING, LEFT SIDE PU ROLL	RB2-2896
2100 BUSHING, RIGHT ROLLER	RB2-3044
2100 BUSHING, SUPPORT	RB2-2973
2100 BUSHING, TRANS ROLL RT.	RB2-2926
2100 BUSHING, UPPER DELIV ROLL	RB2-2850
2100 CAM, PICKUP ROLLER, RIGHT	RB2-2903
2100 CASSETTE, BASE	RB2-3001
2100 COLLAR, SPRING	RB1-2190
2100 COVER ASSY TRAY 1	RG5-4121
2100 COVER, RT REAR SIDE	RB2-2862
2100 DELIVERY GUIDE, UPPER	RG5-4141
2100 ECB WITH EXCHANGE	RG5-4125E
2100 ENGINE CONTROL BOARD	RG5-4125
2100 FAN, COOLING	RH7-1383
2100 FIXING FILM ASSY 110V	RG5-4134
2100 FIXING FILM ONLY	LP-2661F
2100 FUSER	RG5-4132
2100 FUSER EXCHANGE	RG5-4132E
2100 GEAR	RS6-0499
2100 GEAR ASM, CASSETTE PICK UP	RG5-4156

2200 ROLLER, PRESSURE, LOWER RB2-6369
 2200 ROLLER, TRANSFER RG5-5581
 2200 SENSOR, PAPER, PS1305 WG8-5364
 2200 SEP PAD, TRAY 1 RF5-3272
 2200 SEP PAD, TRAY 2 RB9-0695
 2200 SEP PAD, TRAY 3 RB2-6474
 2200 SPRING, TENSION RS6-2030
 2200 TRAY ASSY, MP (TRAY 1) RG5-5576
 2200 TRAY, 250 SHEET RG5-5580

2300 Series

2300 BELT,PAPER FEED(3per MACH RC1-0918
 2300 COVER ASSEMBLY, RT SIDE RM1-0329
 2300 COVER, REAR RM1-0367
 2300 DRIVE ASSY, PRINTER RM1-0334
 2300 ENGINE CONTROLLER BOARD RG1-4307
 2300 FIXING FILM ONLY LP-0354F
 2300 FORMATTER Q1395-60002
 2300 FUSER ASSY RM1-0354
 2300 FUSER FILM ASSY RM1-0356
 2300 LASER SCANNER ASSY RM1-0313
 2300 LEVER, PAPER SENSOR RB2-6402
 2300 MAINTENANCE KIT U6180-60001
 2300 MOTOR, DC RH7-1588
 2300 PICKUP ASSY, TRAY 2 RM1-0332
 2300 POWER SUPPLY ASSY RM1-0340
 2300 POWER SUPPLY BOARD RG1-4306
 2300 PULLY,BELT (3per MACH) RC1-0933
 2300 REGISTRATION ASSY RM1-0347
 2300 ROLLER ASSY, TRANSFER RM1-0343
 2300 ROLLER ASSY, TRAY 2 FEED RG5-5555
 2300 ROLLER, DELIVERY (4 per Printer) RC1-0978
 2300 ROLLER, FACEDOWN OUTPUT RM1-0371
 2300 ROLLER, FEED RG5-4394
 2300 ROLLER, PICKUP, TRAY 1 RC1-0945
 2300 ROLLER, PICKUP, TRAY 2 RB2-6304
 2300 ROLLER, PRESSURE RC1-0991
 2300 ROLLER, TRANSFER RM1-0338
 2300 SEP PAD ASSY (Sep pad & holder) RM1-0345
 2300 SEP PAD KIT RY7-5100
 2300 SEP PAD, 250 SHEET TRAY RC1-0954
 2300 SEP PAD, TRAY 1 RC1-0939
 2300 SEPARATION PAD RB2-3007

2400 Series

2400 ENGINE CONTROL BOARD 110V RM1-1441
 2400 FAN, MAIN COOLING FAN FM1 RK2-0571
 2400 FUSER 110V RM1-1491
 2400 HOLDER, DEL ROLL (USES 4) RC1-3998
 2400 LASER/SCANNER ASSY RM1-1521
 2400 MOTOR, MAIN 26.2W DC M1 RL1-0587
 2400 PAPER PU ASSY - TRAY 1 RM1-1484
 2400 PAPER PU ASSY - TRAY 2 RM1-1481
 2400 POWER SUPPLY, HI VOLTAGE RM1-1505
 2400 ROLLER, DELIVERY (USES 4) RC1-3996
 2400 ROLLER, PAPER PICK-UP RL1-0542
 2400 ROLLER, PU TRAY 1 "D" RL1-0568
 2400 ROLLER, TRANSFER RM1-1508

2500 Series

2500 BELT,FEED 8/MCH RB3-0063
 2500 COLLAR, SPRING RB1-2190
 2500 DAMPER ASSEMBLY RB2-6248
 2500 DRUM, IMAGING C9704-67901
 2500 FUSER RG5-6903
 2500 HINGE, LEFT RB2-3041
 2500 PICKUP ASSM, TRAY 1 RG5-6952
 2500 PICKUP ASSM, TRAY 2 RB3-0161
 2500 PULLEY,ROLLER 2/MCH RB3-0061
 2500 PULLEY,ROLLER 2/MCH RB3-0067
 2500 READER, E-LABEL RG5-6957
 2500 ROLLER ASSY, OUTPUT RG5-6897
 2500 ROLLER, PICKUP, TRAY 1 RB3-0160
 2500 ROLLER, PICKUP, TRAY 2 RB3-0129
 2500 ROLLER, REGISTRATION RG5-6939
 2500 ROLLER, TRANSFER RF5-4040
 2500 SEP PAD TRAY 2 RF5-4258
 2500 SEP PAD, TRAY 1 RF5-4012
 2500 SEP PAD, TRAY 2 RF5-4258
 2500 SHAFT, FEED DRIVE RB3-0011
 2500 SPRING, TENSION RS6-2030
 2500 TRAY ASSY, MP RG5-6937
 2500 TRAY, 250 SHEET RG5-6914

2550 500 SHEET PAPER TRAY Q3710A
 2550 FUSER RG5-7572

3015 / 3020 / 3030

3015 BOARD, LIU Q2663-60001
 3015 ROLLER, SCANNER PICKUP RM1-0885
 3015 SEP PAD (SET) RM1-0891
 3015 SEP PAD ASSY, SCANNER RM1-0890
 3015 TRAY, SCANNER OUTPUT WIRE RC1-2560
 3015/3020/3030 FUSER ASSY RM1-0865
 3015/3020/3030 LASER SCANNER RM1-0171
 3015/3020/3030 MOTOR, STEPPING RK2-0107
 3015/3020/3030 PICKUP ASSY, PA RM1-0864
 3015/3020/3030 ROLL, PU "D" RL1-0266
 3015/3020/3030 ROLLER, TRANSFE RM1-0658
 3015/3020/3030 SEP PAD RM1-0648
 3015/3020/3030 TRAY, FACE DOWN RM1-0859
 3015/3020/3030 TRAY, PAPER INP RM1-0858
 3020 WINDOW, ADF C7296-00014
 3020/3030 PAD, ADF SEPARATION C7309-60076
 3030 ADF ASM C7309-60091

3100

3100 BUSHING RB1-7184
 3100 DELIVERY ASSY RG5-3474
 3100 DOC SCANNER (No Image Sensor) RG5-4771
 3100 DUCT 1 RB2-3401
 3100 DUCT 2 RB2-3402
 3100 ECB POWER SUPPLY RG5-4690
 3100 EP COVER INTERLOCK RG5-3453
 3100 FEED ASSY RG5-3485
 3100 FIXING FILM ONLY LP-2802F
 3100 FUSER, HEATING ELEMENT RG5-4678

3100 GEAR KIT	RY7-5005	3200 SPRING	RB2-3953
3100 GEAR, 21T/28T	HS5-0253	3200 SPRING, KICK PLATE	RS6-2122
3100 GUARD, HOLDER	RB2-3366	3200 SUB PAD	RF5-2820
3100 GUIDE, UPPER PAPER	RG5-4221	3200 SUB PAD	RF5-2821
3100 LEVER, SENS	RB1-7293	3200 SUPPORT EXT, DOC OUT	RB2-5407
3100 LINE INPUT UNIT BOARD	C3948-60001	3200 SUPPORT, DOCUMENT OUTPUT	RB2-5412
3100 MAINTENANCE KIT	H3975-60001	3200 SUPPORT, OUTPUT	RB2-5423
3100 PAD, SHEET SEPARATION	RB2-4114	3200 TRAY, PAPER PU, INPUT SUPPP	RB2-5493
3100 PAPER INPUT SUPPORT	RB2-3362	3200 TRAY, PAPER PICKUP	RB2-5437
3100 PICKUP ASSY REPAIR KIT	RG5-3486-KIT		
3100 ROLLER, EXIT ASSY	RF5-2367		
3100 ROLLER, FACE UP	RB2-1685		
3100 ROLLER, FEED	RB2-1699		
3100 ROLLER, P/U DOC SCANNER	RG5-4772		
3100 ROLLER, PICKUP	RG5-3486		
3100 ROLLER, PRESSURE	RF5-2364		
3100 ROLLER, TRANSFER	RF5-1534		
3100 SCANNER GROUND CLIP	RB2-1714		
3100 SCANNER, LASER	RG5-3497		
3100 SEP PAD KIT	RY7-5077		
3100 SEP PAD KIT, SCANNER	RY7-5055		
3100 SEPARATION GUIDE AS	HG5-1308		
3100 SOLENOID, PAPER P/U	RH7-5139		
3100 STOPPER, OPERATION PANEL	RB2-3354		
3100 SUPPORT, ADF DOCUMENT OUT	RB2-3470		
3100 SUPPORT, ADF DOCUMENT OUT	RB2-3470		
3100 SUPPORT, ADF INPUT T	RB2-3455		
3100 SUPPORT, PAPER OUTPUT	RB2-3410		
3100 TRAY, MANUAL FEED	RG5-4763		
3100 UPPER GUIDE ASSEMBLY	RG5-4768		
3200			
3200 BOARD, LINE INPUT UNIT	C7052-60004		
3200 CABLE, RIBBON	RG5-5405		
3200 COVER, DIMM ACCESS	RB2-5485		
3200 DELY ASSY, KIT	RY7-5060		
3200 ENGINE CONTROLLER BOARD	RG5-5395		
3200 EPROM 12MB SFLASH EXCH -(FIRMWARE UPGRADE)	C7867-69007E		
3200 FIXING FILM ASSY	RG5-4589		
3200 FLAG, PAP OUTPUTSENS	RB2-3960		
3200 FORMATTER BOARD EXCHANGE	C4261-69001E		
3200 GEAR DRIVE ASSY	RG5-4586		
3200 GUIDE, UPPER	RG5-5402		
3200 HINGE SUPPORT ASSY	RG5-5392		
3200 MAINTENANCE KIT	H3965-60001		
3200 PICKUP ASSEMBLY, FEED	RG5-4581		
3200 ROLLER, DELIVERY	RB2-4223		
3200 ROLLER, FACE UP	RB2-4222		
3200 ROLLER, PICKUP (ADF)	RG5-5401		
3200 ROLLER, PICKUP, TRAY 1	RB2-4026		
3200 ROLLER, PRESSURE	RF5-2823		
3200 ROLLER, TRANSFER	RG5-4657		
3200 SCANNER ASSY, DOCUMENT	RG5-5410		
3200 SCANNER, DOC FEEDER ASSY	RG5-5399		
3200 SEP PAD	RF5-2886		
3200 SEP PAD KIT, SCANNER	RY7-5055		
3200 SEPARATION ASSY ADF	RG5-5404		
3200 SPRING	RB2-3952		
		3300 Series	
		3300 ADF ASM	C7309-60091
		3300 ADF ASSY	C9143-60109
		3300 COVER ASSY, PAPER TRAY	RG0-1122
		3300 DOOR, TONER CART	RG0-1115
		3300 FIXING FILM ONLY	LP-1493F
		3300 FUSER ASSY	RG9-1493
		3300 GEAR CLUTCH ASY	RG0-1020
		3300 GEAR, 29T	RA0-1088
		3300 LEVER, PRESSURE RELEASE	RA0-1100
		3300 LEVER, TENSION RELEASE	RA0-1101
		3300 OJD ADF CLEANOUT	C7309-40128
		3300 PAPER FEED ASSM	RG0-1005
		3300 PICK UP ASSEMBLY	RG0-1120
		3300 PICK UP SHAFT ASSEMBLY	RG0-1007
		3300 PLATE ASSY, LEFT	RG0-1002
		3300 ROLLER, ADF PICK	C7309-60049
		3300 ROLLER, PICK UP	RL1-0303
		3300 ROLLER, PRESSUR	RF0-1002G
		3300 ROLLER, TRANSFER	RG9-1483
		3300 SCANNER, FLATBED ASSM	C9124-60103
		3300 SEP PAD	RF0-1014
		3300 SERIES BOARD, ECB	RG0-1117
		3300 SERIES SEP PAD, ADF	C7309-60009
		3300 WINDOW, ADF	C7296-00014
		3300/3330/3380 TRAY, INPUT	RG0-1121
		3300mfp DELIVERY SENSOR PCB	RG0-1082
		3320 LINK, CONNECTING	RA0-1457
		3330 ADF ASSY	C9143-60109
		3330 FAN, COOLING	RG0-1119
		3330 LIU UNIT	C9138-60001
		3330 MFP KEYPAD ASSY	C9126-60102
		3330 TRAY, PAPER INPUT, ADF	C9143-60102
		3380 FACE DOWN DEL ASY	RM1-0556
		3380 FUSER ASSY	RM1-0999
		3380 LIU UNIT	C9138-60001
		3380 PICKUP ASSY, PAPER	RM1-0838
		3380 ROLLER ASSY, PAPER FEED	RM1-0839
		3500 / 3550 / 3700	
		3500/3550/3700 Fuser Kit	Q3655A
		3500/3550/3700 ROLL PU TRAY 1	RC1-1535
		3500/3550/3700 ROLLER ASSY, PU	RM1-0731
		3500/3550/3700 TRANSFER KIT	Q3658A
		3500/3550/3700 TRAY, 250 SHEET	RM1-0470

4000 / 4050

4000 FORMATTER PCA - EXCHANGE	C4118-67908E	4000/4050 GEAR, RUBBER PRESS ROLL	RB1-8796
4000/4050 500 SHEET TRAY	C3122A	4000/4050 GEAR, SEP ROLL DRIVE	RB1-8948
4000/4050 ARM, LIFTER LEFT	RB1-8961	4000/4050 GUIDE ASSY PAPER ENTR	RG5-2721
4000/4050 ARM, LIFTER RIGHT	RB1-8962	4000/4050 GUIDE, LIMIT LOAD	RB1-9022
4000/4050 ARM, LIFTER, LEFT	RB1-9012	4000/4050 GUIDE, PAPER	RB1-8873
4000/4050 ARM, LIFTER, RIGHT	RB1-9013	4000/4050 GUIDE,PAPER	RB1-8890
4000/4050 ARM, MP TRAY RETAINING	RB2-2387	4000/4050 HOLDER, TRANSFER SHAFT	RB1-8685
4000/4050 ARM, OUTPUT KICKER LEFT	RB2-2409	4000/4050 KIT, PAPER GUIDE	C4251-67906
4000/4050 ARM, PAPER TRAY SENSING	RB1-8910	4000/4050 LABEL, CAUTION	RS5-8380
4000/4050 BELT, DUPLEX ROLLER	LP-BLT4000DP	4000/4050 LASER SHUTTER ARM	RB1-8700
4000/4050 BELT, FEED GUIDE DRIVE	RB1-8668	4000/4050 LATCH, REAR TRAY	RB1-8846
4000/4050 BLOCK, SENSOR	RB1-9009	4000/4050 LEVER	RB1-8880
4000/4050 BOARD, FEEDER CONTROL	RG5-2673	4000/4050 LEVER, DELIVERY SENSR Flag	RB1-8812
4000/4050 BUSHING	RS5-1310	4000/4050 LOW CASSETTE LOG PC	RG5-3821
4000/4050 BUSHING	RS5-1297	4000/4050 LWR PAPER DEL GUIDE	RB1-8801
4000/4050 BUSHING	RS5-1298	4000/4050 MAIN PAD ASSM TRAY 1	RG5-5281
4000/4050 BUSHING, SEP ROLL	RB1-8946	4000/4050 MAINT KIT ECONO EXCHANGE	C4118-6790EE
4000/4050 BUTTON, POWER SWITCH	RB1-8849	4000/4050 MAINTENANCE KIT NEW	C4118-67909
4000/4050 CABLE, FIXING	RG5-3409	4000/4050 MAINTENANCE KIT-EXCH	C4118-67902E
4000/4050 CABLE, MAIN MOTOR	RG5-3709	4000/4050 MOUNT ASSY, SEP ROLL	RF5-2489
4000/4050 CAM, FLAPPER	RB1-8811	4000/4050 OVERLAY ENGLISH	C4118-40002
4000/4050 CLUTCH TORQUE LIMITER	RB1-8974	4000/4050 PANEL, LEFT DUPL ACCESS	RB2-2400
4000/4050 CLUTCH, MP PICKUP	RB1-8765	4000/4050 PANEL, RIGHT DUPL ACCESS	RB2-2401
4000/4050 CLUTCH,PAPER FEED	RH7-5171	4000/4050 PANEL, ROLLER ACCESS	RB1-8947
4000/4050 COLLAR, SPRING	RB1-2190	4000/4050 PANEL, TONER CARTR ACCESS	RB1-8841
4000/4050 CONTROL PANEL	RG5-5372	4000/4050 PAPER DELIVERY ASSEMBLY	RB2-2408
4000/4050 COUPLER KIT	C4119-67902	4000/4050 PAPER FEED ASSEMBLY	RG5-2651
4000/4050 COUPLER, PICK UP	RB1-8877	4000/4050 PAPER FEED GUIDE ASSY	RG5-2643
4000/4050 COUPLER, SEP ROLLER	RB1-8945	4000/4050 PAPER INPUT, TRAY 1	RG5-2656
4000/4050 COVER ASSEMBLY,LEFT SIDE	RG5-2665	4000/4050 PAPER PICKUP DRIVE ASSY	RG5-2672
4000/4050 COVER, DELIVERY, FIXING	RB2-2747	4000/4050 PAPER PU DRIVE ASSY,LOW	RG5-2684
4000/4050 COVER, DUPLEXOR LEFT SIDE	RF5-1876	4000/4050 PICK-UP ASSEMBLY,TRAY 1	RG5-2655
4000/4050 COVER, DUPLEXOR TOP	RB1-9044	4000/4050 PLATE, PAPER LENGTH STOP	RB1-9371
4000/4050 COVER, DUST	C4232-60101	4000/4050 REGISTRATION ASSEMBLY	RG5-2652
4000/4050 COVER, FEEDER, RIGHT	RG5-2668	4000/4050 RING, E	XD9-0134
4000/4050 DAMPER	RB2-2399	4000/4050 ROD, REL TONR DRIVE ARM	RB1-8756
4000/4050 DEFLECTOR (FUSER)	RB1-8797	4000/4050 ROLLER	RB1-8728
4000/4050 DEFLECTOR, FRONT	RB2-4901	4000/4050 ROLLER DELIVERY	RB1-8720
4000/4050 DEFLECTOR, REAR	RB2-4902	4000/4050 ROLLER KIT	LP-4000RK
4000/4050 DELIVERY ASSEMBLY	RG5-2648	4000/4050 ROLLER, DELIVERY	RB1-8798
4000/4050 DELIVERY DRIVE ASSEMBLY	RG5-3721	4000/4050 ROLLER, DELIVERY	RB1-8798G
4000/4050 DRIVE ASSY, PU (Opt 500 Sht Tray)	RG5-2690	4000/4050 ROLLER, DELIVERY (FUSER)	RB1-8806
4000/4050 DRIVE, EIO 3.2GB HARD	C2985-61011	4000/4050 ROLLER, DUPLEXER, LONG	LP-DR4000-L
4000/4050 ENGINE BOARD, MAIN	RG5-3693	4000/4050 ROLLER, DUPLEXER, SHORT	LP-DR4000-S
4000/4050 ENGINE BOARD, MAIN - EXCH	RG5-3693E	4000/4050 ROLL, FEED (2/1 Roll in RG5-2651)	RB1-8732
4000/4050 ENVELOPE FEEDER	C8053B	4000/4050 ROLLER, FEED/SEP	RF5-1885
4000/4050 FAN, MAIN COOLING	RH7-1335	4000/4050 ROLLER, LOWER FUSER	RB9-0684
4000/4050 FEED ASSEMBLY, 500 SHEET	C8055A	4000/4050 ROLLER, PU "D" - 500 SHEET	RB1-8865
4000/4050 FIXING FILM ASM	RG5-4290	4000/4050 ROLLER, PICKUP ASSEMBLY	RF5-2484
4000/4050 FIXING FILM ONLY	LP-2661F	4000/4050 ROLLER, TRANSFER	RG5-4283
4000/4050 FRONT DOOR SPRING KIT	C4118-67907	4000/4050 ROLLER, TRANSPORT	RB1-8923
4000/4050 FUSER	RG5-2661	4000/4050 ROLLER,TRAY 1 PICK-UP	RG5-3718
4000/4050 FUSER - EXCHG	RG5-2661E	4000/4050 SCANNER, LASER	RG5-2641
4000/4050 FUSER RBLT ECONO EXCH	RG5-2661EE	4000/4050 SCANNER, LASER - EXCH	RG5-2641E
4000/4050 GEAR, 14T/19T	RS5-0959	4000/4050 SCREW (IN FUSER ASSY)	RB1-8819
4000/4050 GEAR, 16T/18T FUSER	RS5-0923	4000/4050 SENSOR ASSY, REG & FEED	RG5-2642
4000/4050 GEAR, 29T	RS5-0941	4000/4050 SENSOR LEVER ASSY,TRAY 1	RF5-3116
4000/4050 GEAR, PRESSURE ROLL, 34T	RS5-0922	4000/4050 SENSOR, OPTICAL	WG8-5362
		4000/4050 SEP ROLL TENSION SPR	RS5-2809
		4000/4050 SOLENOID, TRAY 1 (SL102)	RH7-5172

4200 CLIP, FUSER LEFT	LP-4200L	4200 TORQUE LIMITER	RC1-0335
4200 CLIP, FUSER RIGHT	LP-4200CLIPR	4200 TRAY 1 (DROP DOWN)	RM1-0005
4200 CLIP, FUSER RIGHT	LP-4200R	4200 TRAY 1 ASSY	RM1-0004
4200 CONTROL PANEL ASSY	RG1-4276	4200 TRAY 1/2 ROLLER KIT	LP-4200KIT
4200 COVER ASSY, RIGHT SIDE	RM1-0046	4200 TRAY ASY REAR W/STOP	RM1-0030
4200 COVER ASSY, TOP	RM1-0049	4200 TRAY, 500 SHEET Replacement Tray Only	RM1-0028
4200 COVER, CARTRIDGE ACCESS D	RM1-0047	4200 TRAY, 500 SHT REPLAC	RM1-1088
4200 COVER, DUPLEXER SLOT	RC1-0291		
4200 COVER, LEFT (FUSER)	CVR-4200-L	4250	
4200 COVER, LEFT (FUSER)	LP-4200CVR-L	4250 DC CONTROLLER PCB	RM1-1108
4200 COVER, REAR OUTPUT BIN	RM1-0027	4250 DUPLEXER ASSY	Q2439-67902
4200 COVER, RIGHT (FUSER)	CVR-4200-R	4250 FUSER 110V	RM1-1082
4200 COVER, RIGHT (FUSER)	LP-4200CVR-R	4250 MOTOR, MAIN	RK2-0272
4200 COVER, TOP REAR	RC1-0289	4250 PAPER PU DRIVER ASSY	RM1-1133
4200 DC CONTROLLER	RG1-4236	4250 ROLL, PAPER FEED ASY	RM1-0012
4200 DRIVE ASSY, TRAY LIF	RM1-0208	4250 ROLLER, TRANSFER	RM1-1110
4200 DUPLEXER ASSY	Q2439-67902	4250 SCANNER ASSY	RM1-1067
4200 DUPLEXER ASSY	Q2439A		
4200 FAN, COOLING LEFT SD	RH7-1573	4300	
4200 FIRMWARE DIMM	Q2453-67907	4300 TRAY, 500 SHT REPLAC	RM1-1088
4200 FIXING FILM ASSEMBLY	RM1-0015	4300 BUSHING, FEED ROLL SHAFT	RC1-0264
4200 FIXING FILM ONLY	LP-0013F	4300 CLIP, FUSER LEFT	LP-4200CLIPL
4200 FLAG, PAPER SIZE SENS-3/ASSM	RC1-0161	4300 CLIP, FUSER LEFT	LP-4200L
4200 FORMATTER BRD COVER	RC1-0288	4300 CLIP, FUSER RIGHT	LP-4200CLIPR
4200 FORMATTER EXCHANGE	C9652-69001E	4300 CLIP, FUSER RIGHT	LP-4200R
4200 FRONT COVER, TRAY 1	RM1-0050	4300 CONTROL PANEL ASSY	RG1-4276
4200 FRONT COVER, TRAY 1	RM1-0050	4300 COVER ASSY, RIGHT SIDE	RM1-0046
4200 FUSER	RM1-0013	4300 COVER ASSY, TOP	RM1-0049
4200 FUSER RBLT WITH EXCHANGE	RM1-0013E	4300 COVER, DUPLEXER SLOT	RC1-0291
4200 FUSER RBLT ECONO EXCH	RM1-0013EE	4300 COVER, LEFT (FUSER)	CVR-4200-L
4200 GEAR, 18T	RU5-0045	4300 COVER, LEFT (FUSER)	LP-4200CVR-L
4200 GEAR, 18T (500 SHEET PU ASSM)	RU5-0088	4300 COVER, RIGHT (FUSER)	CVR-4200-R
4200 GEAR, FUSER, 40T	RU5-0016	4300 COVER, RIGHT (FUSER)	LP-4200CVR-R
4200 GUIDE ASSY, DELIVERY	RC1-0062G	4300 DC CONTROLLER	RG1-4237
4200 INNER RT FRT COVER	RC1-0019	4300 DRIVE ASSY, TRAY LIF	RM1-0208
4200 LEFT SIDE COVER	RC1-0287	4300 DUPLEXER ASSY	Q2439-67902
4200 LIFTER DRIVE ASSY - 1500 SHEET TRAY		4300 DUPLEXER ASSY	Q2439A
RM1-0287		4300 FAN, COOLING LEFT SD	RH7-1573
4200 LIFTER DRIVE, TRAY 2	RM1-0033	4300 FLAG, PAPER SIZE SENS-3/ASSM	RC1-0161
4200 MAIN DRIVE ASSY	RM1-0001	4300 FORMATTER BRD COVER	RC1-0288
4200 MAINTENANCE KIT	Q2429-67902	4300 FORMATTER EXCHANGE	C9651-69001E
4200 MAINT KIT REMFG W/EXCH	Q2429-67902E	4300 FRONT COVER, TRAY 1	RM1-0050
4200 MAINT KIT ECONO EXCH	Q2429-6790EE	4300 FRONT COVER, TRAY 1	RM1-0050
4200 MEMORY, 8MB SDRAM DIMM	C7842-67901	4300 FUSER	RM1-0101
4200 MOTOR, MAIN	RH7-1570	4300 GEAR, 18T	RU5-0045
4200 PAPER DELIVERY ASSEMBLY	RM1-0026	4300 GEAR, 18T (500 SHEET PU ASSM)	RU5-0088
4200 PAPER FEED BELT ASSY	RM1-0025	4300 GEAR, FUSER, 40T	RU5-0016
4200 PAPER PICKUP ARM, TRAY 2	RC1-0211	4300 GUIDE ASSY, DELIVERY	RC1-0062G
4200 PICKUP ASSM TRAY 1	RM1-0034	4300 INNER RT FRT COVER	RC1-0019
4200 POWER SUPPLY 110V EXCHG	Q2425-69015E	4300 LEFT SIDE COVER	RC1-0287
4200 POWER SUPPLY ASSY 110V	RM1-0019	4300 LIFTER DRIVE ASSY-1500 SHT TRAY	RM1-0287
4200 ROLLER, FEED TRAY 2 & 3	RM1-0037	4300 LIFTER DRIVE, TRAY 2	RM1-0033
4200 ROLLER, PICKUP TRAY 1	RL1-0019	4300 MAIN DRIVE ASSY	RM1-0001
4200 ROLLER, PICKUP TRAY 2 & 3	RM1-0036	4300 MAINTENANCE KIT	Q2436-67901
4200 ROLLER, PRESSURE GEN	RC1-0070G	4300 MOTOR, MAIN	RH7-1570
4200 ROLLER, TRANSFER	RM1-0699	4300 MOTOR, TONER CARTRIDGE	RH7-1576
4200 SEP PAD TRAY 1	RL1-0007	4300 PAPER DELIVERY ASSEMBLY	RM1-0026
4200 SHEET FEED & TRAY - 500 SHEET	Q2440-67903	4300 PAPER PICKUP ARM, TRAY 2	RC1-0211
4200 SRS PU DRIVE ASSY	RM1-0056	4300 PICKUP ASSM TRAY 1	RM1-0034
4200 T2 CASSETTE GUIDE RT	RC1-0153		

4300 POWER SUPPLY ASSY	RM1-0107	4500/4550 BUSHING, LIFT PLATE	RB2-0830
4300 POWER SUPPLY ASSY EXCH (RM1-0107)		4500/4550 CABLE ASSY, ITB	RG5-4651
Q2431-69002E		4500/4550 CABLE, LASER, FLAT	RH2-5400
4300 ROLLER, FEED TRAY 2 & 3	RM1-0037	4500/4550 CABLE, VIDEO INTERFACE	RH2-5335
4300 ROLLER, PICKUP TRAY 1	RL1-0019	4500/4550 CAROUSEL DRIVE ASSY	RG5-5502
4300 ROLLER, PICKUP TRAY 2 & 3	RM1-0036	4500/4550 CLUTCH TORQUE LIMITER	RB1-8974
4300 ROLLER, PRESSURE GEN	RC1-0070G	4500/4550 CLUTCH, ELECTROMAGNE	RH7-5176
4300 ROLLER, TRANSFER	RM1-0699	4500/4550 CLUTCH, ONE WAY	RB2-0561
4300 SEP PAD TRAY 1	RL1-0007	4500/4550 COUPLER ASM-UP GEAR MT	RG5-3228
4300 SRS PU DRIVE ASSY	RM1-0056	4500/4550 COVER, DRUM DRAWER	RG5-5152
4300 T2 CASSETTE GUIDE RT	RC1-0153	4500/4550 COVER, ITB DRAWER	RG5-3320
4300 TORQUE LIMITER	RC1-0335	4500/4550 DOOR SWITCH ASSY, REAR	RG5-5170
4300 TRAY 1 (DROP DOWN)	RM1-0005	4500/4550 DRAWER SWITCH ASSY	RG5-3296
4300 TRAY 1 ASSY	RM1-0004	4500/4550 DRUM DRIVE ASSEMBLY	RG5-5206
4300 TRAY 1/2 ROLLER KIT	LP-4200KIT	4500/4550 Drum Kit	C4195A
4300 TRAY ASY REAR W/STOP	RM1-0030	4500/4550 FACE-DOWN DEL ASSEMBLY	RG5-5135
4300 TRAY, 500 SHEET Replacement Tray Only	RM1-0028	4500/4550 FAN (IN ITB DRAWER)	RH7-1401
		4500/4550 FAN, LG (Ser# between JPH & JPZ)	RHY-1435
		4500/4550 FAN, SMALL	RH7-1407
		4500/4550 FEEDER ASSY	RG5-5117
		4500/4550 FILTER, AIR, LARGE	RB2-1282
		4500/4550 FILTER, AIR, SMALL	RB2-1283
		4500/4550 FOOT, BLACK PLASTIC	XH9-0103
		4500/4550 FUSER Kit	C4197A
		4500/4550 FUSER Kit with Exchange	C4197ACE
		4500/4550 FUSER ONLY with Exchange	RG5-5154E
		4500/4550 GEAR, 31T	RS6-0136
		4500/4550 GEAR, 39T/31T	RS6-0154
		4500/4550 GEAR, 49T	RS6-0153
		4500/4550 HANDLE, ITB DRAWER	RB2-1361
		4500/4550 HOLDER, PLATE	RB2-0831
		4500/4550 KIT, FUSER DEFLECTOR	C4084-67911
		4500/4550 MOTOR (M1)	RG5-3227
		4500/4550 PANEL, SEPARATION ACCESS	RB1-9001
		4500/4550 PAPER SIZE SENSOR PCA	RG5-3816
		4500/4550 PCB-DEV SERIAL #JPH & UP	RG5-5180
		4500/4550 POWER SUPPLY EXCHANG	RH3-2219E
		4500/4550 POWER SUPPLY, 110V	RH3-2219
		4500/4550 ROLLER, FEED/SEP	RF5-1885
		4500/4550 ROLLER, LARGE PU TRAY1	RB2-0744
		4500/4550 ROLLER, SMALL PU TRAY1	RB2-0717
		4500/4550 ROLLER, TRANSFER	RF5-2112
		4500/4550 ROLLER, TRAY 2 FEEDROLL	RF5-2092
		4500/4550 ROWEL SWING	RG5-4696
		4500/4550 SENSOR LEVER,T2 PAPR	RB2-0576
		4500/4550 SENSOR, PAPER SIZE	RG5-3234
		4500/4550 SEP PAD,TRAY 1	RB2-0734
		4500/4550 SHAFT, PAPER PICKUP	RB2-0545
		4500/4550 SOLENOID, TRAY 2 FD	RG5-3245
		4500/4550 SOLENOID,TRAY 2 FEED	RG5-5119
		4500/4550 SPRING, TONER FLAP	RS6-2255
		4500/4550 Transfer Kit	C4196A
		4500/4550 Transfer Kit - Refurb by GRC	C4196AC
		4500/4550 TRAY 2, 250 SHEET	RG5-3400
		4550 ASSY, D ROLLER	RG5-3225
		4550 FIRMWARE MEM DIMM UPGRADE	C9130-67906
		4550 FORMATTER PCA EXCHANGE	C4227-69002E
		4550 LEVER, FLAPPER	RB2-0445
		4550/4550 ROLL, PICKUP "D"-500 SHEET	RB1-8865
4350			
4350 DC CONTROLLER PCB	RM1-1108		
4350 DUPLEXER ASSY	Q2439-67902		
4350 DUPLEXER ASSY	Q2439-67902		
4350 FUSER 110V	RM1-1082		
4350 MOTOR, MAIN	RK2-0272		
4350 PAPER PU DRIVER ASSY	RM1-1133		
4350 ROLL, PAPER FEED ASY	RM1-0012		
4350 ROLLER, TRANSFER	RM1-1110		
4350 SCANNER ASSY	RM1-1067		
4500 / 4550			
4500 CASE, PAD LEFT	RF5-2110		
4500 CASE, PAD RIGHT	RF5-2111		
4500 COVER, BOTTOM (FUSER)	RB2-0442		
4500 COVER, RIGHT FUSER	RF5-3167		
4500 COVER, TONER ACCESS	RF5-3137		
4500 DOOR, TONER ACCESS	RF5-2076		
4500 FAN, LARGE SN<JPGxxx	RH7-1346		
4500 FAN, SMALL	RH7-1407		
4500 GEAR, 16T (IN FUSER)	RS6-0196		
4500 GEAR, 21T	RS6-0223		
4500 GEAR, 41T (FUSER)	RS6-0763		
4500 GRIP	RB2-1502		
4500 HEATER, HALOGEN #1	RH7-4116		
4500 HEATER, HALOGEN #2	RH7-4114		
4500 KIT, OPC DRAWER NEED SER#	RG5-5230		
4500 MOTOR STEPPING M2	RH7-1343		
4500 REAR DOOR, ACCESS	RG5-3325		
4500 ROLLER, DELIVERY	RB2-0421		
4500 SPRING, PLATE LIFT	RS5-2733		
4500 THERMOSWITCH	RH7-7092		
4500 THERMOSWITCH ASSY	RH7-7090		
4500/4550 500 SHEET TRAY (TRAY 3)	RG5-3900		
4500/4550 ARM, LIFTER, LEFT	RB1-9012		
4500/4550 ARM, LIFTER, RIGHT	RB1-9013		
4500/4550 BLOCK, SENSOR	RB1-9009		
4500/4550 BRAKE ASSY	RG5-3309		
4500/4550 BUSHING	RS5-1293		
4500/4550 BUSHING	RB2-0453		

4600 / 4650

4600 CAM,66T CAM/GEAR	RS7-0135
4600 CONTACT ASSY, HV TONER	RG5-6449
4600 COVER ASSY, TOP FRONT	RG5-6465
4600 DC CONTROLLER	RG5-6391
4600 DRUM DRIVE ASSY - MAG & CYAN	RG5-6504
4600 DRUM DRIVE ASSEY - YEL	RG5-6506
4600 ETB ASSY TRANSFER BELT	RG5-6484
4600 FEEDER ASSY, 500 SH&TRAY3	C9664A
4600 FIRMWARE DIMM 03.014.1	C9712-67916
4650 FIRMWARE DIMM	Q2635-67916
4600 FORMATTER -DUPLEX ONLY	C9661-67902
4600 FORM PCB EXCH (DUPL PRINTERS)	C9661-69002E
4600 FORMATTER-SIMPLEX ONLY	C9660-67911
4600 FORMATTER-SIMPLEX-EXCHANG	C9660-69011E
4650 FORMATTER BOARD EXCHANGE	Q3999-69002E
4600 Fuser Kit	C9725A
4650 FUSER KIT	Q3676A
4600 GEAR, TONER SHUTTER	RB2-8122
4600 IC C2500 COVER, FUSER, LEFT	RF5-3774
4600 IC C2500 COVER, FUSER, RIGHT	RF5-3775
4600 IC C2500 GUIDE	RB2-8306
4600 LASER SCANNER	RG5-6390
4650 LASER SCANNER	RG5-7475
4600 PAPER PICKUP ASSM	RG5-6468
4600 POWER SUPPLY, FUSER	RG5-6399
4600 POWER SUPPLY, HIGH VOLTAG	RG5-6395
4600 ROLLER KIT	LP-4600RK
4600 TRANSFER KIT	C9724A
4650 TRANSFER KIT	Q3675A
4600 TRAY 2, 500 SHEET	RG5-6476
4600 TRAY, OPT 500 SHEET FEED	RG1-4140
4600/4650 FLAG, PAPER SENSOR	RB2-8498
4600/4650 ROLLER, TRAY 2 PICKUP	RF5-3739
4600/4650 SEP PAD, TRAY 2	RF5-3750
4600/4650 DROP-DOWN, FRONT, TRAY1	RG5-6467
4600/4650 FEEDER ASSY 500 SHEE	Q3673A
4600/4650 EIO HD - 20GB	J6054-69031
4650 MOTOR, 24V DC, BRUSHLESS	RH7-1605

5000

5000 500 SHT TRAY AND FEED ASM (Add On)	C4115A
5000 BELT, LG PAPER FEED	RB2-1887
5000 BELT, SM PAPER FEED	RB2-1888
5000 BUSHING, TRAY 1&2 PICKUP - 2/MACHINE	RS5-1392
5000 CABLE ASSY W/ FERRITE	RG5-4213
5000 CAM, RIGHT ROLLER	RB2-1805
5000 COLLAR, RIGHT	RB2-1803
5000 COLLAR, SPRING	RB1-2190
5000 CONTROL PANEL PCB	RG5-5438
5000 COUPLER KIT	C4119-67902
5000 COVER, EIO SLOT	5021-0349
5000 COVER, FUSER, RIGHT	RB2-1927
5000 COVER, UPPER	RB2-1748
5000 COVER, TONER DOOR	RG5-3556
5000 DRIVE, EIO 3.2GB HARD	C2985-61011
5000 FAN	RH7-1430
5000 FIXING FILM ASSY	RG9-1431

5000 FIXING FILM ONLY	LP-5455F
5000 FORMATTER EXCHANGE	C3974-69001E
5000 FUSER ASM	RG5-5455
5000 FUSER EXCHANGE	RG5-5455E
5000 FUSER FLAG	RF5-2694
5000 GEAR ASSY, MAIN	RG5-3543
5000 GEAR ASSY, PICKUP	RG5-3544
5000 GEAR, TRAY 2 SHAFT	RS5-0695
5000 LEVER, PAPER SIZE SENSOR	RB2-1782
5000 LEVER,SENSOR(FUSER)	RB2-1807
5000 LOCK, PAPER	RB2-2042
5000 MAINTENANCE KIT	C4110-67914
5000 MAINTENENCE KIT EXCHANGE	C4110-69006E
5000 OVERLAY, ENGLISH	C4110-40004
5000 PAPER CONTROL PCB	RG5-3560
5000 PAPER SENSOR PCB,500 SHT	RG5-4211
5000 PICKUP ASSM, TRAY 2	RG5-3521
5000 PLATE ASSM, MP PAPER GUIDE	RG5-3520
5000 PLATE, LENGTH ADJ	RB2-2023
5000 REVERSING ASM, DUPLEXER	RG5-3624
5000 ROLLER ASM, REGISTRATION	RG5-3524
5000 ROLLER, FEED	RB2-3232
5000 ROLLER, FEED/SEP 500 SHT	RF5-2634
5000 ROLLER, LOWER PRESSUR GEN	RB2-1919G
5000 ROLLER, PICKUP	RB2-1795
5000 ROLLER, PICKUP KIT	C4110-67912
5000 ROLLER, PICKUP "D" - 500 SHEET	RB1-8865
5000 ROLLER, PICKUP 500 SHEET	RB1-8865
5000 ROLLER, PICKUP ASSY 500 SHEET TRAY	RF5-2636
5000 ROLLER, PICK-UP, TRAY 1	RB2-1820
5000 ROLLER, PICK-UP, TRAY 2	RB2-1821
5000 ROLLER, PRESSURE, LOWER	RB2-1919
5000 ROLLER, TRANSFER	RG5-3579
5000 SENSOR LEVER,TRAY 2	RB2-1791
5000 SENSOR PCA, TRAY SIZE	RG5-4212
5000 SEP PAD	RF5-4117
5000 SEP PAD TRAY 1	RF5-3439
5000 SEP PAD W/SPRING, TRAY 2	RG9-1485
5000 SHAFT, ROLLER	RB2-1794
5000 SOLENOID, PAPER PU	RH7-5195
5000 SPRING, PAPER SENSOR LEVR	RB2-1784
5000 SPRING,LEAF	RB2-3286
5000 TEST TOOL	5184-0872
5000 TRAY 1 REPAIR KIT	RF5-3439-KIT
5000 TRAY, FACE UP	RG5-3552
5000/5100 TRAY, 250 SHEET	RG5-7188

5100

5100 COLLAR, SPRING	RB1-2190
5100 CONTROL PANEL PCB	RG5-5438
5100 COVER, TONER DOOR	RG5-3556
5100 FORMATTER BOARD	Q1860-67901
5100 FUSER ASM	RG5-7060
5100 FUSER ASM EXCHANGE	RG5-7060E
5100 GEAR ASSY, MAIN DRIVE	RG5-7079
5100 GEAR DRIVE ASSY,TRAY 3	RG5-7194
5100 GEAR, TRAY 2 SHAFT	RS5-0695
5100 LEVER, SENSOR, TRAY 2	RB2-1791

5100 LEVER,SENSOR(FUSER)	RB2-1807	8000 FACEDOWN DEL ASY	RG5-1874
5100 MAINTENANCE KIT EXCHANGE	Q1860-69027E	8000 FACEDWN DEL EXCH	RG5-1874E
5100 ROLLER ASSY, PAPER FEED	RG5-7084	8000 FEEDER ASM	RG5-1834
5100 ROLLER ASSY, REGISTRATION	RG5-4916	8000 FIRMWARE DIMM (VERS 4.62)	C4085-60009
5100 ROLLER, 250 SHEET FEED	RB1-7499	8000 FOOT	RB1-6421
5100 ROLLER, 250 SHEET PICKUP	RG5-3644	8000 FORMATTER PCB WITH EXCH	C4186-67902E
5100 ROLLER, FACE DOWN GUIDE	RG9-1337	8000 FUSER ASSY EXCH	RG5-4447E
5100 ROLLER, FEED	RB2-3232	8000 FUSER ASSY (RG5-3686)	RG5-4447
5100 ROLLER, PAPER PU ASSM TRAY 1	RG5-3519	8000 FUSER FLAG	RF5-2694
5100 ROLLER, PAPER PU ASSM TRAY 2	RG5-3521	8000 GEAR, 16T	RS5-0736
5100 ROLLER, PAPER PU TRAY 1	RB2-1820	8000 GEAR, 31T (IN PIU)	RS5-0745
5100 ROLLER, PICKUP "D" - 500 SHEET	RB1-8865	8000 HEAT LAMP 2 220V	RH7-4075
5100 ROLLER, TRANSFER	RG9-1542	8000 HEAT LAMP 220V	RH7-4074
5100 ROLLER, UPPER FD ROLL GDE	RB2-1998	8000 HOLDER, ROLLER	RB1-6678
5100 ROLLER, UPPER PAPER FD ROLL GDE	RB2-1998	8000 HOLDER, ROLLER	RB1-9644
5100 SEP PAD, TRAY 1	RF5-4119	8000 HOLDER, TRANSFER	RF5-1394
5100 SEP PAD, TRAY 2	RF5-4120	8000 LEVER, FUSER LOCK RT	RB1-6615
5100 SPRING, TRAY 1 COMPRESSIO	RS5-2441	8000 LOW VOLT DC POWER SUP RBLT	RG5-3676R
5100 SUB PAD	RF5-4117	8000 MAINT KIT EXCHG	C3971-69002E
5500 / 5550			
5500 DRIVE ASSY, PAPER PICKUP	RG5-6661	8000 MOTOR, MAIN	RH7-1260
5500 FLAG, PAPER SENSOR	RG5-6842	8000 PANEL, CONTROL W/DISPLY	RG5-5268
5500 FORMATTER PCB EXCH (DUPL PRINTERS)		8000 PAPER PICKUP EXCHANG	C4780-69504E
C9661-69002E		8000 PAPER SENSING LVR	RB1-6692
5500 FUSE	VD7-0648	8000 PHOTOSENSOR	WG8-0291
5500 FUSE	VD7-1732	8000 ROLL, MP TRAY PU	RB1-6730
5500 FUSER	RG5-6848	8000 ROLLER	RB1-6679
5500 FUSER EXCHANGE	C9656-69012E	8000 ROLLER, 2nd PASS	RB1-6581
5500 FUSER KIT	C9735A	8000 ROLLER, CLEANING	RB2-3546
5550 FUSER 110V	Q3984-67901	8000 ROLLER, PICKUP	RF5-2708
5500 PICKUP ASSY, TRAY 2	RG5-6670	8000 ROLLER, PICK-UP	RF5-1835
5550 PAPER PU ASSY TRAY 2	RG5-7709	8000 ROLLER, PICKUP GENERIC	RF5-1835G
5500 PICKUP ASSY, TRAY 3 & 4	RG5-6748	8000 SEPARATION GUIDE UPPER	RB1-6611
5500 POWER SUPPLY ASSY	RG5-6808	8000 SOLENOID FACE UP	RG5-1875
5500 ROLLER KIT	RY7-5097	8000 STOPPER, CARTRIDGE	RB1-6427
5500 ROLLER, FEED/SEP	RF5-3338	8000 TOP COVER ASSY	RG5-1870
5500 ROLLER, FEED/SEP (4 per Machine)	RF5-3338	8000 TRAY (2K) PAPER LIMIT	RG5-3849
5500 ROLLER, PICKUP MP/TRAY 1	RG9-1529	8000 TRAY 2 CASS UPP	R98-1005
5500 SEP PAD	RF5-3865	8000 TRAY 3	R98-1004
5500 TRAY ASSY, MP	RG5-6780	8000 VERT TRANS UNIT with EXCH	RG5-3854E
5500/5550 EIO HD - 20GB	J6054-69031E	8000 VTU,(C4780A) 2x500	RG5-4403E
5500/5550 PU ASSY, TRAY 3 & 4	RG5-6748		
5500/5550 TRANSFER KIT	C9734B		
8000			
8000 MOTOR, PICK-UP (SMT31)	RH7-1172	8100 / 8150	
8000 BUSHING,TRAN GUI	RB1-6441	8100 MOTOR, PICK-UP (SMT31)	RH7-1172
8000 CLAW, LIFTER ARM	RB1-6538	8100 BUSHING, PAP DECK DR	RS5-1399
8000 CLIP, RETAINER LEFT	RB1-6708	8100 BUSHING,TRAN GUI	RB1-6441
8000 CLIP, RETAINER RIGHT	RB1-6709	8100 CLAW, SEPARATION	RB2-3531
8000 CLIP, TRAY LOCK	RB2-3636	8100 CLIP, TRAY LOCK	RB2-3636
8000 COVER, EIO SLOT	5021-0349	8100 CLUTCH, SEP	RB1-0109
8000 COVER, RT	RG5-1915	8100 CONTROL PNL W/DISPLY	RG5-5268
8000 DIVERTER ASSEMBLY	RG9-1150	8100 CONTROLLER PCA 2X500 SHT	RG5-4442
8000 DOOR, LEFT ACCESS	RB1-6667	8100 DC CONTROLLER EXCHANGE	RG5-4375E
8000 DRIVE ASSY, PAP DECK	RG5-4416	8100 DRIVE ASSY, PAP DECK	RG5-4416
8000 DUPLEX UNIT EXCH	C4782-69501E	8100 DRIVE ASSY, PAP DECK	RG5-3851
8000 EIO 3.2GB HARD DRIVE	C2985-61011	8100 DUPLEX UNIT EXCH	C4782-69501E
		8100 FACEDOWN DEL ASY	RG5-1874
		8100 FACEDWN DEL EXCH	RG5-1874E
		8100 FAN, MOTOR FM1	RH7-1396
		8100 FEED ROLLER, MP TRAY	RB1-9526
		8100 FEEDER ASM	RG5-4305

8100 FOOT	RB1-6421	8100/8150 POWER SUPPLY HI VOLT	RG5-4306
8100 FORMATTER EXCHANGE	C4107-69001E	8100/8150 ROLLER, PICKUP	RF5-2708
8100 GEAR, 14T	RS5-0752	8100/8150 TRANSFER ROLLER ASSY	RG9-1361
8100 GEAR, 16T	RS5-0736	8100/8150 TRAY 3	R98-1004
8100 GEAR, 18T	RS6-0508	8100/8150 TRAY 4, 2000 SHT	RG5-3845
8100 GEAR, 23T	RS6-0506	8100/8150 TRAY, MP INPUT (TR1)	RG5-4329
8100 GEAR, FUSER 26T	RS6-0505		
8100 GUIDE, ON PAPER INPUT UNI	RB2-3580	8150 8MB FLASH FIRMWARE ROM	C8530-67909
8100 GUIDE, SEPARATION	RB2-3532	8150 8MB FLASH FIRMWARE ROM MM	C8530-67908
8100 HOLDER, ROLLER	RB1-6678	8150 CABLE, IEEE1394 FIREWIRE	8120-8749
8100 HOLDER, ROLLER	RB1-9644	8150 COVER ASSY, FIXING CABLE	RG5-4302
8100 LEVER, PAPER HEIGHT	RB1-6693	8150 FORMATTER MAIN LOGIC	C4265-67901
8100 LOWER FUSER ROLL, SLVD	RB2-3522	8150 FORMATTER MAIN LOGIC EXCH	C4265-69001E
8100 PAPER PICKUP EXCHANG	C4780-69504E	8150 PA03002-C115FJ LAMP, UPPER	PA03002-C115
8100 PAPER PU ASM 2K SHT EXCH	RG5-3843E		
8100 PAPER SENSING LVR	RB1-6692		
8100 PHOTOSENSOR	WG8-0291	8500 / 8550	
8100 PICKUP ASM 2K TR NEW	RG5-3843	8500 BUSHING, PAP DECK DR	RS5-1399
8100 PIU EXCHANGE	RG5-4334E	8500 COVER, SUB ASSY, RIGHT	RF5-1995
8100 PIU REPAIR KIT	RG5-4334-KIT	8500 DRIVE ASSY, PAP DECK	RG5-3851
8100 POWER SUPPLY, LOW VOLTAGE	RG5-4357	8500 FLAG, FUSER	RB1-9743
8100 REGISTRATION ASM	RG5-4303	8500 GEAR, FUSER, 29T	RS6-0042
8100 RETAINING RING	RB2-3543	8500 HOLDER, TRANSFR DRUM CLNR	RG5-3111
8100 RING, GROUNDING	RB2-3542	8500 KIT, ICL	RG9-1527
8100 ROLLER	RB1-6679	8500 LARGE FAN (EXHAUST)	RH7-1330
8100 ROLLER, 2nd PASS	RB1-6581	8500 LASER SCANNER, EXCHANGE	C3983-69007E
8100 ROLLER, TRANSFER	RF9-1394	8500 LEVER ASSM, TRANSFER DRUM	RG5-3046
8100 ROLLER, TRANSFER	RF9-1394	8500 PAPER PICK UP ASSM-EXCH	C7096-69009E
8100 SCANNER, LASER EXCHANGE	RG5-4344E	8500 PICKUP ASM 2K TR NEW	RG5-3843
8100 SENSOR UNIT	RH7-7105	8500 SENSOR, PAPER SIZE	RG5-2168
8100 SENSOR, PAPER SIZE	RG5-2168	8500 SPRING, SENSOR ARM	RB1-6409
8100 SOLENOID FACE UP	RG5-1875	8500 SPRING, TORSION	RB1-9798
8100 SPRING, COMPRESSION	RS6-2072	8500 TRAY 2 CASS UPP	R98-1005
8100 SPRING, SENSOR ARM	RB1-6409	8500 TRAY 3	R98-1004
8100 STOPPER, CARTRIDGE	RB1-6427	8500 VERT TRANS UNIT	RG5-3854E
8100 TORQUE LIMITER	RB2-3581	8500 VTU W/EXCHG	C4781-69510E
8100 TRAY (2K) PAPER LIMIT	RG5-3849		
8100 TRAY 2 CASS UPP	R98-1005	8500/8550 MOTOR, PICK-UP (SMT31)	RH7-1172
8100 UPPER FUSER COVER	RB2-3524	8500/8550 AC POWER SUPPLY EXGH	RH3-2185E
8100 UPPER HEAT ROLLER	RB2-3521	8500/8550 ATTACHMENT ASY	C4785-60516
8100 UPPER HEAT ROLLER	RB2-3521	8500/8550 BUSHING	RS5-1119
8100 VERT TRANS UNIT W/ EXCH	RG5-3854E	8500/8550 CLEANING ROLLER	RG5-3975
8100 VTU,(C4780A) 2x500	RG5-4403E	8500/8550 COLOR FUSER KIT	C4155A
		8500/8550 DC CONTROLLER	RG5-3037
8100/8150 ATTACHMENT ASY	C4785-60516	8500/8550 DELIVERY DRIVE ASSY	RG5-3067
8100/8150 CLUTCH, PAPER FEED	RH7-5188	8500/8550 FEED ASSY	RG5-3059
8100/8150 COVER, RT	RG5-1915	8500/8550 FILTER, AIR LARGE	RB1-9807
8100/8150 DIVERTER ASSY,DUPLXR	RG5-4325	8500/8550 FILTER, AIR SMALL	RB1-9808
8100/8150 DRIVE ASSY	RG5-4365	8500/8550 FUSER REBUILT EXCHAN	RG5-3060E
8100/8150 EIO 3.2GB HARD DRIVE	C2985-61011	8500/8550 IMAGING DRUM KIT	C4153A
8100/8150 FAN, TRAY 1	RH7-1397	8500/8550 LEVER, SHUTTER	RA0-0008
8100/8150 FUSER NEW OEM	RG5-4318	8500/8550 MAIN GEAR ASM	RG5-3066
8100/8150 FUSER EXCHANGE	RG5-4318E	8500/8550 MOTOR, MAIN	RH7-1499
8100/8150 INPUT ASM, TRAY1 EXCH	RG5-4330E	8500/8550 PAD, TRAY 1 SEPARATI	RF5-1989
8100/8150 LOW VOLT PWR SUP EXCH	RG5-4357E	8500/8550 PAPER PU ASM 2K SHT EXCH	RG5-3843E
8100/8150 MAINT.KIT REMAN EXCHG	C3914-69001E	8500/8550 PICKUP ASSY	RG5-3054
8100/8150 MAINTENANCE KIT 110V	C3914-69001	8500/8550 POWER SUPPLY, MAILBOX	C4785-60501
8100/8150 PAD, TRAY 1 SEPARATI	RF5-2703		
8100/8150 PAPER INPUT UNIT	RG5-4334	8500/8550 ROLLER ASSY, REGISTR	RG5-3009
8100/8150 PICKUP ASSY, TRAY 1	RG5-4330	8500/8550 SENSOR ASSY, DENSITY	RG5-3057

8500/8550 SENSOR, FUSING DELIV	RG5-3992
8500/8550 TRANSFER DRUM ASS'Y	RG5-3039
8500/8550 TRAY 1 INPUT ASSY	RG5-3134
8500/8550 TRAY 4, 2000 SHT	RG5-3845
8550/N/DN FORMATTER PCA EXCHG	C7096-69005E
8550MFP DC POWER SUPPLY	FG5-9845

9000 / 9500

9000 ACCUMULATOR ASSY	C8085-60531
9000 COVER ASSY, SERVICE	RG5-5811
9000 DELIVERY ASSY, FACE-UP	RG5-5647
9000 DOOR ASSY, LEFT	RG5-5646
9000 DRIVE ASSY, FUSER DELIVER	RG5-5659
9000 DRIVE ASSY, PAPER DECK	RG5-6228
9000 DUPLEXER UNIT NEW	C8532A
9000 FILTER, ADF OPTICAL UNIT	RF5-3850
9000 FORMATTER EXCHANGE	C8519-67901E
9000 FUSER	RG5-5750
9000 FUSER EXCHANGE	RG5-5750E
9000 LASER SCANNER UNIT	RG5-5826
9000 MAINT KIT(350K) EXCHANGE	C9152-67901E
9000 MAINTENANCE KIT 350K	C9152-67901
9000 PAPER INPUT UNIT	RG5-6208
9000 PIU WITH EXCHANGE	RG5-6208E
9000 PICKUP ASSY, PAPER	RG5-5681
9000 ROLLER OPT TRAY 1 PICKUP	RF5-3403
9000 ROLLER, FEED/SEP	RF5-3338
9000 ROLLER, FEED/SEP (4 per Machine)	RF5-3338
9000 ROLLER, SEPARATION	RF5-3404
9000 ROLLER, TRANSFER	RF5-3319
9000 ROLLER, TRANSFER	RF5-3319
9500 MP PAPER PU ASSY TRAY 1	RG5-6090
9500 SEP PAD, TRAY1	RF5-3490
9500 SUB PAD, TRAY 1 - 2/MACHINE	RF5-3489

HP InkJet

BI2600 PANEL ASSY, FRONT	C8109-67031
BI2600 PERSONALITY CARD EXCHA	C8109-69018E
BI2600 SERVICE STATION ASSY	C8109-67029
BIJ2230/2280 BOARD, MAIN LOGIC	C8119-67013
BIJ2600 ENCODER STRIP	C7790-60099
BJ 2230 / 2280 CARRIAGE ASM	C2688-67061
BJ 2230 / 2280 SEP PAD	C2688-67057
BJ 2600 INK SUPPLY STATION	C8109-67014
BJ 2600 ROLLER, FFED ASSM	C7790-60129
BJ 2600 SERVICE STATION	C8109-67014
BJ 3000 ROLLER, PICK UP	C8116-67019
BJ 3000 ROLLER, SEPARATION	C8116-67020
CP1700 CARRIAGE ASSY	C8108-67009
CP1700 INK SUPPLY STATION	C8108-67056
CP1700 PAPER MOTOR	C8108-67038
CP1700 STRIP, ENCODER	C8108-67010
DJ & PLOTTER SERVICE KIT	HP/TOOLKIT
DJ / DW / OJ PINCH ROLL	C2124-60116

DJ 500 LEVER MODIFIED FRAM	C2124-40111
DJ 500/600 CLUSTER GEAR	C2162-40002
DJ 500/600 SRS CARRIAGE MOTOR	C2162-60006
DJ 500/600 SRS ENCODER STRIP	C2124-80008
DJ 500/600 SRS SLIDER, REAR	C4549-40025
DJ 500/600 SRS SRVC STATION MTR	C2124-60190
DJ 500/DW SLED WIPER ASSY	HP02776
DJ 500/DW500 SRS ABSORBER	C2124-80004
DJ 520 LEVER ROTATOR FRM	C2124-40110
DJ 540 SLED ASM	C2162-67804
DJ 600 BEARING CARRIAGE	1410-1365
DJ 600 SERVICE STATION ASM	C2164-67811
DJ 600 SRS CLUTCH ACTUATOR	C2128-40023
DJ 600 SRS SLED	C2164-67810
DJ 600 SRS SLED ASM	C6450-60102
DJ 600 SRS SPITTOON SPONGE	C6450-80052
DJ 600 SRS SPRING, SLED	C2164-00016
DJ 600 SRS/800 SRS SEPARATOR	C4549-40029
DJ 600/700 SRS SEPARATION PAD	C2128-60018
DJ 600C NAMEPLATE HP OWG	C4547-40001
DJ 610/612/OJ/300 SPRING, BELT	C2124-20004
DJ 680c/672c/694c KEYPAD AS	C4549-60020
DJ 690/692/693/694/695/697 SLED	C4562-60044
DJ 700/800/900SRS SEP PAD	C4557-60011
DJ 700/800/900SRS GEAR, CLUSTER	C5870-40017
DJ 710/12/810 GEAR TRANSFER SS	C4557-40079
DJ 710/720 SPITTOON BASE	C5870-40014
DJ 710-895 SPITTOON SPONGE	C5870-80007
DJ 720 ROLLER, PINCH	C4557-20002
DJ 720,722,810, ENCODER STRIP	C4557-80001
DJ 720,895 SLED CAP ASSY	C4557-60013
DJ 720,895 SVC STATION MOTOR	C5870-60004
DJ 720,895 WIPER ASSY	C4557-60014
DJ 720/812 LIFTER, SEPARATOR	C4557-40063
DJ 720/OJ GUIDE, REAR PAPER	C4557-40013
DJ 720/OJT45 GUIDE, LOWER PAPER	C4557-40020
DJ 720C PAPER PUSHER	C5870-40022
DJ 72X/8XX PAPER ADVANCE MOTOR	C6409-60004
DJ 7XX/8XX LEVER, BANNER	C6411-40006
DJ 7xx/8xx OJR40/60 OOPS FLAG	C5870-40024
DJ 800 SERIES ENCODER STRIP	C2145-80016
DJ 820CSE Z-STOP, RIGHT	C2145-40101
DJ 842C P/U ROLLER SHAFT W/LG	C6426-60049
DJ 870 BLOTTER PAD	C2145-80011
DJ 882C PCA-PAPER ENCODER	C6409-60200
DJ 882C UPPER PAPER GUIDE	C6409-40022
DJ 890 PLATE BEARING	C4602-00014
DJ 890/OJ1170 BIAS SPRING	C4602-00012
DJ 930/950/970 LIFTER, SEP PEG	C6426-40100
DJ 930/970 GUIDE, INNER PAPER	C6429-60141
DJ 930/970 SPONGE (ABSORBER)	C6426-80019
DJ 930/970 TOWER, BELT ATTACHME	C6426-40017
DJ 930C/32C/35C BEAM-BELT ATTAC	C6426-40018
DJ 930C/970C RAIL, PUSHER	C6426-40026
DJ 950C FEED ROLL IDLER GEAR	C4557-40021
DJ 950C KICKER BAR CAM GEAR	C6426-40103
DJ 950C KICKER BAR CAM LINK	C6429-60025
DJ 950C LIFTER SPRING	C6426-00017
DJ 952C BLADE	C2145-00037
DJ 952C SPRING	C2145-00033

DJ 970 PAPER MOTOR WITH PULLEY	C6429-60004	DJ5650 DUPLEXER	C8955A
DJ 970/OJ G85 TRAYA, PAPER INP	C6429-60156	DJ5655 250 SHT PAPER TRAY	Q3447A
DJ 970Cse RIBBON CABLE,CARRIAGE	C6429-80084	DJ690-697 CARRIAGE ASSY	C4562-60043
DJ 970CXI SPITTOON	C6426-40085	DJ7XX/8XX/OJR40 WEAR STRIP	C5870-00004
DJ 9xx KICKER	C6426-40118	DJ820CSE PRE-GUIDE	C2145-40118
DJ 9XX/OJG55/85/95 P/U ROLL ASM	C6429-60144	DJ970/OJG95 BELT, CARRIAGE	C6426-40115
DJ POWER MODULE C2175A	9100-5124		
DJ1000/1100/1120/1125 SVC STAT	C2670-60124	DSJ 100 INK SUPPLY STATION	C8109-67014
DJ1000/1100/1200 ROLLER, PINCH	C2670-60115	DSJ 100 SERVICE STATION	C8109-67014
DJ1000/1100/1200 STRIP, ENCODR	C2670-60118	DSJ 200/20/650C ETC CARR BELT	1500-0856
DJ1000/1120/1125 BELT, CAR DRIVE	C2670-60119	DSJ 200/20/650C ETC CARR BELT	1500-0856
DJ1000C ROLLER ASSY, DRIVE	C2670-60113	DSJ 200/650 DRIVE-TENSR BRAKET	07575-40125
DJ1000C/1100C/1120C P/U ROLL	C2670-60138	DSJ 200/650 IDLE DRIVE PULLEY	07570-60112
DJ1000C/1100C/1120C SEP PAD	C2670-60134	DSJ 220/650/750 ENCODER STRIP	C4714-60098
DJ1100/1120 MOTOR, CARR DRIVE	C2670-60131	DSJ 230/250/430/450/488 PULLEY, IDLER E SIZE	
DJ1160C ROLL ASSY, PICKUP	C6436-67029	C3190-60132	
DJ1200/1200CPS PICK-UP MOTOR	C1676-60209	DSJ 250C BELT, D-SIZE	C4705-60082
DJ1200C CAP PACKAGE OF 4	C1676-40245	DSJ 330/350 TRAILING CBL	C4713-60181
DJ1200C SLED FILTER	C1676-40175	DSJ 500 SERVICE STATION	C7769-60149
DJ1220 CABLE, FLEX	C2693-67075	DSJ 500 SPITTOON, LEFT	C7769-60165
DJ1220 DOOR ASSY, REAR CLEANOU	C2693-67003	DSJ 500/800 BELT, CARRIAGE 42"	C7770-60014
DJ1220C CARRIAGE MOTOR	C2693-67017	DSJ 5000BELT, CARRIAGE (60")	Q1253-60021
DJ1220C KEYPAD ASSM	C2693-67006	DSJ 600/650 BRACKET, BAIL, LT	C1633-40038
DJ1220C PAPER OUTPUT TRAY	C2693-67002	DSJ 650 STARWHEEL MOUNT	C4713-60035
DJ1220C POWER SUPPLY	C2693-67012	DSJ 650/700/750 PRIMER ASSY	C4705-60109
DJ1220C ROLLER, PICK	C2693-67018	DSJ 650/700/750 PRIMER ASSY	C3195-60059
DJ1220C SENSOR ASSY, SPOT	C2693-67037	DSJ 650/750 OPT PRIM SNSR - E Size	C2858-60007
DJ1220C SEPARATION ASM	C2693-67032	DSJ 700/750 HARWARE KIT	C4704-60095
DJ1220C SERVICE STAT ABSORBER	C2693-67042	DSJ 700/750C/755C SVC STATION	C3195-60165
DJ1220C SERVICE STATION, COMPL	C2693-67039	DSJ 700/755CM BUSHING, REAR	C2858-40017
DJ1220C TRAY, PAPER INPUT WITH	C2693-67019	DSJ 750/755 MOTOR ASSY(X)EXCHG	C4724-69053E
DJ1220C/Cxi/Cse ENCODER STRIP	C2693-67015	DSJ 750/755 MOTOR ASSY, X AXIS	C4724-60053
DJ2000 BOARD, POWER SUPPLY	C4530-60038	DSJ 750C CARR BELT	C4706-60082
DJ2000/2250 STRIP, ENCODER	C4530-80004	DSJ 750C MOTOR(Y-AXIS) ASSY	C3195-60112
DJ2000/CXi INK SUP STA ROGUE	C4530-67817	DSJ 750C STRIP SVC D ASSY	C4713-60098
DJ2000C ABSORBER	C4530-80070	DSJ 7xxC PIN CARR EXCHANGE	C4708-69113E
DJ2000C WICK, ISS	C4530-80078	DSJ 7XXC PIN CARRIAGE	C4708-60113
DJ2200 / 2250 CARRIAGE ASM	C2688-67061	DSJ1050 CARRIAGE MOTOR/PULLEY	C6072-60394
DJ2200/2250 SENSOR, DRIVE ROLL	C2688-67055	DSJ1050 CARRIER KIT EXCHANGE	C6072-69147E
DJ2250 CARRIAGE BELT RETAINER	C4530-40288	DSJ1050 TENSIONER ASSY	C6072-60149
DJ2250 CARR BELT SPRING (2/Machine)	C4530-00105	DSJ1050C CARRAIGE ASSY KIT	C6072-60147
DJ2250 DR ROLLER & PIVOT ASSY	C2688-67044	DSJ1050C CARRAIGE ASSY KIT	C6072-67147E
DJ2500 ADJUST, PAP LGTH TRAY 2	C2684-60232	DSJ1050C DRIVE ROLLER ASSY	C6072-60191
DJ2500 ADJUST, PAP LGTH TRAY 3	C2684-60226	DSJ1050C DRIVE ROLLER GUIDE	C6072-60163
DJ2500 ADJUST, PAP WIDTH TRAY2	C2684-60233	DSJ1050C DROP DETECTOR	C6072-60179
DJ2500 ADJUST, PAP WIDTH TRAY3	C2684-60225	DSJ1050C MEDIA SENSOR	C6072-60190
DJ2500 COVER, CABLE HARNESS	C2684-60247	DSJ120N POWER SUPPLY,W/FAN	C7790-60091
DJ2500 PICK SHAFT ASSM	C2684-60311	DSJ120nr/130 CARRIAGE ASSY	C7791-60142
DJ2500 SERVICE STATION	C2684-60273	DSJ120nr/130 INK SUPPLY STAT	C7790-60089
DJ2500 TRAY 3, DUAL BIN INPUT	C2684-60310	DSJ2000 BELT, Y AXIS	C4704-60207
DJ2500C COVER, LCD DISPLAY PAN	C2684-60266	DSJ2000/2500 STARWHEEL MT ASSY	C4704-60143
DJ2500C FEED ROLL ASSY PK	C2684-60302	DSJ2000/2500/2800/3000/3500/3800 SSC	4723-60276
DJ2500C GUIDE, PAPER	C2684-60303	DSJ2500 FIRMWARE DIMM EXCHG	C4723-69294E
DJ2500C INK SUPPLY STATION	C2684-60306	DSJ2500 SVC STATION INTER CBL	C4704-60024
DJ2500C LATCH, CARTRIDGE	C4530-67807	DSJ2xxx/3xxx CARRIAGE ASSY EXG	C4723-69096E
DJ2500C PLATE, MEDIA	C2684-60227	DSJ2xxxCP CARRIER TRAIL CABLE	C4704-60015
DJ2500C SENSOR, SWIVEL	C2684-60268	DSJ3000/3500 BELT, CARRIAGE	C4723-60235
DJ2500C/CM PRINT MECH EXCHANGE	C2684-60319E	DSJ430 PEN CARRIAGE EXCHG.	C4713-69039E
DJ340 I/O PORT	C2655-60206	DSJ450C SERVICE STATION ASSY	C3190-60142
DJ3810 / 3820 DOOR, REAR PAPER JAM	C8952-60020	DSJ500/800 CARRIAGE BELT 24"	C7769-60182

DSJ500/800 INK SUPPLY STATION	C7769-60148
DSJ500/800 INK TUBES ASSY	C7769-60256
DSJ500/800 PREV MAINT KIT 24"	C7769-60251
DSJ500/800 PREV MAINT KIT 42"	C7770-60276
DSJ500/800 PWR SUPPLY,W/SWITCH	C7769-60145
DSJ5500 BELT, 42"	Q1251-60144
FAX 200 ADF FEED ROLLER	DZACC1014MGC
FAX 200 HP-ADF SEPARATOR PAD	AR1210-MGC
FAX 300 CARRIAGE ROD	C2162-20005
FAX 700 DOC FEEDER	C3530-63051
FAX 700/750 PAPER EXIT TRAY	C3530-62351
FAX1020 FEEDER ASSY, PAPER/DOC	C8580-40001
FAX1020 SEPARATOR PAD,ADF	C8580-80004
OJ 590/600 CARRIAGE ASSY	C6659-60045
OJ 300 OOPS FLAG-MEDIASENSOR	C2890-40108
OJ 300/DJ500/600 SRS BELT	C2164-40060
OJ 500/600 ADF PAPER SEP PAD	C3801-60167
OJ 500/600, FAX 910 LEVER,TORQU	C3801-40147
OJ 500/600/700 ADF FRICTION PAD	C3801-80051
OJ 6110 STRIP, ENCODER	C6487-80011
OJ 6110/6150 SERVICE STATION	C6487-60065
OJ 7130 TRAY, INPUT	C6436-60040
OJ D125/135/145 ADF EXCHANGE	C7309-69001E
OJ D135 250 SHEET TRAY	C7310A
OJ D135 DUPLEXER	C6437A
OJ G55 COVER, TOP-DOCUMENT LID	C6736-60018
OJ G55 LOGIC/DVR PCB	C6734-68001
OJ G85 ROLLER ASSY, FEED	C6455-60056
OJ G85 SCANNER MOTOR ASSY	C6734-60022
OJ G85/95/COPY280/290 ADF ASS EXCH	C6757-69001E
OJ K60/80/FAX1220 CONTR PAN ASSY	C6747-60297
OJ K60/K80 SCANNER	C6747-60007
OJ LATCH	C2890-00091
OJ OUTPUT TRAY COVER OWG 12/02	C2890-40054
OJ R40 / R60 / R80 INTER PCB	C6680-60202
OJ R80 CAM, PICK	C6409-40040
OJ R80 LINE INTERFACE UNIT LIU	C6680-60074
OJ R80 LINKAGE	C4557-40084
OJ T45 / T65 ADF FEED ROLLER	C5374-60015
OJ T45 POW SUP MODULE, ADP-40RB	0950-3807
OJ V30 / V40 / V45 REFERENCE WHITE	C8413-40005
OJ V30 / V40 / V45 SEPARATOR, ADF	C8413-60249
OJ V30/40/45 ADF WIRE OUTPUT TR	C8413-00009
OJ300 BRIDGE OWG	C4661-40006
OJ6110 RAIL, PAPER PUSHER	C6487-60054
OJ6110 TRAY, ADF PAPER INPUT	Q1636-60012
OJ7100 DUPLEXER MODULE	C6436-67006
OJ7100 POWER MODULE	C7296-60043
OJ7100 TRAY, ADF INPUT	C7309-60022
OJ7100 USER GUIDE	C8388-90141
PSC 500 / OJ-G85 SCANNER GLASS	C6680-60020
PSC 7150/7350/7550/7155W PWR MOD	0950-4081
SCANJET 7400 POWER MODULE	C7717-84200
SJ 5300 POWER SUPPLY	C7690-84200
SJ 7400 ADF ASSY	C7716-60140

BROTHER

DCP1000 SCANNER 2 ASSY	LE7197001
DCP8020 NETWORK LAN BOARD	NC9100H
DCP8025 NETWORK LAN BOARD	NC9100H
FAX 190 PRESSURE ROLLER	UF6706001
FAX 600 ARM B ASSY	UF3055001
FAX 600 GEAR 65/23	UF3018000
FAX 750 / 770 / 870 / 970MC SEP PAD	UU0145001
FAX 750 ROLLER, PAPER FD	UF9728001
FAX 750 SEPARATION PAD	UF9737001
FAX 770 CIS UNIT	LE5481001
FAX 770 ROLLER, EJECT ADF	UF9783001
FAX 775 CIS UNIT T5VA	LG3108001
FAX 870 ROLLER, EJECT ADF	UF9783001
FAX 870MC CIS UNIT	LE5481001
FAX 885MC CIS UNIT T5VA	LG3108001
FAX 900 DAMPER	UF3569001
FAX 970MC CIS UNIT	LE5481001
FAX 980 ROLL, EJECT	UF0024001
FAX 1150 FAX SEP ROLLER	UF6046001
FAX 1150 SCANNER GLASS	UF4447001
FAX 1150 SEP PAD	UF6276000
FAX 1170 CIS UNIT (SCANNER)	UG5064001
FAX 1170 EJECT ROLL SUPP	LE0218001
FAX 1170 LOCK LEVER LEFT	UF8504001
FAX 1170 LOCK LEVER RIGHT	UF8506001
FAX 1170 PAPER FEED ROLL ASSY	UF8116001
FAX 1170 PLATEN	UF8095001
FAX 1170 RECORDING HEAD ASSY	UF8070001
FAX 1170 SEPARATION ROLLER	UF5511001
FAX 1250 FAX SEP PAD	UF5584000
FAX 1250 FAX SEP PAD	UF5584000
FAX 1250 ROLLER, LOWER FEED	UF6265001
FAX 1250 SCANNER GLASS	UF4447001
FAX 1270 CIS UNIT (SCANNER)	UG5064001
FAX 1270 EJECT ROLL SUPP	LE0218001
FAX 1270 EJECTION ROLLER B	UF8144001
FAX 1270 FAX EJECTION ROLLER	UF0761001
FAX 1270 FRT COV SENSING ACTUATOR	UF8118001
FAX 1270 LOCK LEVER LEFT	UF8504001
FAX 1270 LOCK LEVER RIGHT	UF8506001
FAX 1270 PAPER FEED ROLL ASSY	UF8116001
FAX 1270 PAPER FEED SUB CHUTE	UF8104001
FAX 1270 PLATEN	UF8095001
FAX 1270 RECORDING HEAD ASSY	UF8070001
FAX 1270 SEP PAD	LF3667001
FAX 1270 SEPARATION PAD	LE0544001
FAX 1270 SEPARATION ROLLER	UF5511001
FAX 1270 SUB CHUTE FILM	UF8249001
FAX 1270e CIS UNIT	LG2629001
FAX 1270e SEP PAD	LF3667001
FAX 1350 SEP PAD	UF6276000
FAX 1450 SEP PAD	UF6276000
FAX 1500 CIS UNIT	LE7949001
FAX 1550 SEP PAD	UF6276000
FAX 1570 SEPARATION ROLLER	UF5511001
FAX 1750 SCANNER GLASS	UF4447001
FAX 1770 EJECT ROLL SUPP	LE0218001

FAX 1770 PAPER FEED SUB CHUTE	UF8104001	FAX 4550 SEP ROLLER	UF7015001
FAX 1770 SEPARATION ROLLER	UF5511001	FAX 4650 FIXING UNIT	UU7135001
FAX 1770 SUB CHUTE FILM	UF8249001	FAX 4650 FIXING UNIT EXCH	UU7135001E
FAX 1800 MAIN PCB ASSY	LG3652001	FAX 4650 SEP PAD	UU7521001
FAX 1800 PRINTHEAD	LK0935001	FAX 4650 TRAY ASSEMBLY, MP	UL6300004
FAX 1850 SCANNER GLASS	UF4447001	FAX 4750 ADF SEP PAD	UU2055001
FAX 1870 SEPARATION ROLLER	UF5511001	FAX 4750 BROTHERS BATTERY	LG3623001
FAX 1950 FAX SEP ROLLER	UF6046001	FAX 4750 DOC FEED ROLL	UU2029001
FAX 1970 SEPARATION ROLLER	UF5511001	FAX 4750 DOC SEP ROLL ZLM	LE1072001
FAX 2300 FAX FUSER	UL7170001	FAX 4750E FAX NCU PCB ASSY	LG2405022
FAX 2300 SCANNER	UL5800001	FAX 560 SEP PAD ADF	LE4082001
FAX 2400 FAX FUSER	UL7170001	FAX 5750 ADF SEP PAD	UU2055001
FAX 2400 SCANNER	UL5800001	FAX 5750 BROTHERS BATTERY	LG3623001
FAX 2500 CIS UNIT	LE7949001	FAX 5750 DOC FEED ROLL	UU2029001
FAX 2500 SCANNER	UL5800001	FAX 5750 DOC SEP ROLL ZLM	LE1072001
FAX 2600 CIS UNIT	LH7116001	FAX 5780 DOCUMENT TRAY & EXTEN	UU2069008
FAX 2600 MP SHEET FEEDER ASSM	LH0478005	FAX 6550 SEP ROLLER	UF7015001
FAX 2600 TRAY, PAPER EJECT	UU7114005	FAX 6650 SEP PAD	UU7521001
FAX 2750 CIS UNIT	UG4601001	FAX 6650 TRAY ASSEMBLY, MP	UL6300004
FAX 2750 FIXING UNIT	UU7135001	FAX 7050 SEP PAD	UU7521001
FAX 2750 FIXING UNIT EXCH	UU7135001E	FAX 7550 SEP ROLLER	UF7015001
FAX 2750 ROLLER, PRESSURE	UF9009001		
FAX 2750 SEP PAD	UU7521001	HD001 PRINTHEAD	ZA0336002
FAX 2800 ACTUATOR LEFT	LE6176001	HD002 PRINTHEAD (LK0045001)	ZA0504002
FAX 2800 ACTUATOR RIGHT	LE6177001		
FAX 2800 BEARING 6	UL6642000	HL 6 FUSER WITH EXCHANGE	UK1736001E
FAX 2800 CIS UNIT	LG3157001	HL 10V FUSER	UH0783001
FAX 2800 DOC SET TRAY	UU2080008	HL 630 PAPER SOLENOID	UL5090001
FAX 2800 FAX ROLLER, PAPER FEED	LE1945001	HL 630 TRAY EXTENSION	UL5214000
FAX 2800 KEY FPC YL4	LG3248001	HL 720 / 730 / 760 FIXING ASM	UL6877001
FAX 2800 LF ROLLER GEAR	LE1196001	HL 720 / 730 / 760 FIXING ASM EXCHG	UL6877001E
FAX 2800 PANEL SHEET	LE7164001	HL 960 FUSER	UH2791001
FAX 2800 PANEL, CONTROL	LE1920001	HL 960 PAPER P/U ROLL	UH2362001
FAX 2800 PANEL, REAR COVER	LE1925001	HL 960 SEPARATION PAD	UH2487001
FAX 2800 PAWLED BUSHING	LF4230001	HL1000 SRS SCANNER	UL8748001
FAX 2800 ROLLER, FEED 4PC	UL6654001	HL1030 PICKUP ROLLER ASSY	UL9066001
FAX 2800 ROLLER, PRESSURE	UF9009001	HL1040 FUSER WITH EXCHANGE	UL8750001E
FAX 2800 RUBBER, SEPARATIO	LE1926001	HL1060 FIXING UNIT WITH EXCHANGE	UH3164001E
FAX 2800 SCANNING DRIVE ASSY	LE1808001	HL1060 PICK UP ROLLER SHAFT	UH3074001
FAX 2800 SEP PAD	LE1943001	HL1060 SCANNER	UH3301001
FAX 2800 TOP COVER ASSY	LE1950001	HL1140 LASER/SCANNER	LJ5828001
FAX 2800N POWER SUPPLY PCB ASSY	LG5118001	HL1230 FUSER ASM	LJ7161001
FAX 2820 ROLLER, EJECT	LF6452001	HL1230 LASER/SCANNER	LJ5828001
FAX 2820 ROLLER, LF	LF6449001	HL1230 MOTOR, MAIN	LE1744001
FAX 2820 SEP RUBBER ADF	LF9097001	HL1230 SOLENOID	LJ5701001
FAX 2900 BEARING 6	UL6642000	HL1240 FUSER	LJ7759001
FAX 2900 PANEL, CONTROL	LE1920001	HL1240 FUSER EXCH	LJ7759001E
FAX 2900 PAWLED BUSHING	LF4230001	HL1240 HALOGEN LAMP	LJ4160001
FAX 2900 ROLLER, PRESSURE	UF9009001	HL1240 MAIN PCB	LJ8044001
FAX 2900 SEP PAD	LE1943001	HL1240 PAPER FEED ROLL ASSM	UL9060001
FAX 3550 GEAR COVER SHEET	UF7187001	HL1240 POWER SUPPLY HI VOLT	UK4431001
FAX 3550 SEP ROLLER	UF7015001	HL1240 SEP PAD HOLDER ASSM	UL9084001
FAX 3550 TRAY ASSY, MP	UF7309002	HL1240 SEP PAD SPRING	UL9090001
FAX 3800 LF ROLLER GEAR	LE1196001	HL1240 SOLENOID RELEASE SPRING	UL8970001
FAX 3800 SEP PAD	LE1943001	HL1250 FUSER	LJ7759001
FAX 4000ML FAX FUSER	UL7170001	HL1250 FUSER EXCH	LJ7759001E
FAX 4350 FIXING UNIT	UU7135001	HL1250 HALOGEN LAMP	LJ4160001
FAX 4350 FIXING UNIT EXCH	UU7135001E	HL1250 LOCK LEVER	UL9092001
FAX 4350 SEP PAD	UU7521001	HL1250 PAPER FEED ROLL ASSM	UL9060001
FAX 4350 TRAY ASSEMBLY, MP	UL6300004	HL1250 SEP PAD SPRING	UL9090001

HL1260 COVER, JAM REMOVE	UH2103001	HL3400CN/3450 OPTICAL SCAN	LJ2213001
HL1260 FUSER	UH2791001	HL4000 FEED ROLL ASSY	LM0009001
HL1260 PAPER P/U ROLL	UH2362001	HL4000 FUSER	LM0039001
HL1260 SCANNER	UH2790001	HL4000 PICKUP ASSY	LM008001
HL1260 SEPARATION PAD	UH2393001	HL4000 ROLLER, RETARD ASSY	LJ3998001
HL1260 SEPARATION PAD	UH2487001	HL4200CN SCANNER	LM0439001
HL1270 PICKUP ROLLER ASSY	UL9066001	HL5030 SEPARATION PAD HOLDER	LJ7307001
HL1440 CLNR, PINCH ROLLER (5 per mach)	LJ5268001	HL5030/40 PAPER FEED ROLL	LJ7703001
HL1440 FUSER ASM	LJ7161001	HL5030/5040 GEAR, IDLE 22	LJ7502001
HL1440 GEAR, HEAT ROLLER	UL8910001	HL5030/5040 GEAR, MIDDLE ROLLER	LJ7501001
HL1440 LASER/SCANNER	LJ5828001	HL5030/5040/5050/5070 PF KIT	LJ7920001K
HL1440 SOLENOID	LJ5701001	HL5030/5040/5050/5070N FUSER	LM2215001
HL1440/1450/1470 LAMP, HALOGEN	LJ5685001	HL5040 PICKUP ROLLER	LM2050001
HL1450 LASER/SCANNER	LJ5828001	HL5040 SEPARATION PAD HOLDER	LJ7307001
HL1650 CLNR, PINCH ROLLER (5 per mach)	LJ5268001	HL5050/5070 SEP PLATE ASSY	LJ7555001
HL1650 COVER, GLASS	UL9023001	HL5140/5070 FIXING UNIT	LM2579001
HL1650 FIXING ASSY	LJ7747001	HL5140/5150 LASER UNIT	LM2835001
HL1650 GEAR	LJ5112001	HL6050 FIXING UNIT	LJ1938001
HL1650 GEAR, FUSER	UL8923001	HL6050 SEP PAD ASSY	LM3543001
HL1650 KIT, PAPER FEED	LJ5615001	HL6050 SEP ROLLER ASSY	LM3454001
HL1650/1670 HOLDER, PAD	LJ5256001	HL6050D/DN LASER UNIT	LM3783001
HL1650/1670 ROLLER, PICKUP	LJ5016001	HL7050 FIXING UNIT	LJ1470001
HL1650/1670N SCANNER	LJ5604001	HL7050 SEP PLATE ASSY	LJ0295001
HL1650/1670N SEP PLATE ASSY	LJ5184001	HL8050 ROLLER ASSY - 3 ROLLS	LM0731001
HL1660 SCANNER	UH2185001	HL8050N FUSER UNIT	FP8000
HL1670 FIXING ASSY	LJ7747001	HL960 PAPER FEED ROLL (2 per mach)	UH2367001
HL1670 GEAR, FUSER	UL8923001	HL960 SEPARATION PAD	UH2393001
HL1670 KIT, PAPER FEED	LJ5615001		
HL1850 COVER, GLASS	UL9023001	MFC1150 LOCK SPRING, RIGHT	UF6086001
HL1850 FIXING UNIT	LJ7005001	MFC1270 GEAR 55	UF8122001
HL1850 GEAR	LJ5112001	MFC1350 BLUE LOCK LEVR Left	UF6085001
HL1850/1870 FEED ROLL KIT	LJ5927001	MFC1350 BLUE LOCK LEVR Right	UF6087001
HL1850/1870N SCANNER ASSY	LJ7004001	MFC1750 / 1760 LWR INK ABSORBER	UU1380001
HL1870 FIXING UNIT	LJ7005001	MFC1950 BLUE LOCK LEVR Left	UF6085001
HL1870 PAD HOLDER ASSY	LJ5919001	MFC1950 BLUE LOCK LEVR Right	UF6087001
HL2030/2040 FUSER UNIT	LM4573001	MFC2000 ROLLER ASSY, LF	UH3893001
HL2030/2040/2070N SCANNER	LM4578001	MFC2300 SEP PAD	UL5719000
HL2030/40/70 PU ROLL HOLD ASSY	LM4300001	MFC2400ML SEP PAD	UL5719000
HL2030/40/70 SEP PAD HOLD ASSY	LM4143001	MFC2500 SEP PAD	UL5719000
HL2060 FIXING UNIT	UH3607001	MFC31/32/5100/1 SEP PAD	LE6903001
HL2060 PAPER FEED ROLL ASSY	UH1488001	MFC3100 / MFC3200 PRINTHEAD	LK0935001
HL2060 ROLLER, HEAT	UH3609001	MFC3100 CR MOTOR	LE6434001
HL2400 FUSER	UH3470001	MFC3100 PAPER FEED MOTOR	LE6489001
HL2400C PAPER FEED ROLLER	UH3485001	MFC3100C EJECT ROLL	LE6096001
HL2400C SEP PAD	UH3486001	MFC3100C ROLL, EJECT ADF	LE6301001
HL2460 FUSER	LJ0959001	MFC3100C ROLLER LF ADF	LE6302001
HL2460 OPEN COVER	LJ0071001	MFC3100C ROLLER, PAPER FEED	LE6091001
HL2460 PAPER FEED ROLL ASSY	LJ0270001	MFC3550 SEP ROLLER	UF4366001
HL2460 PAPER ROLLER KIT	LJ0977001K	MFC3900 SEP PAD	UL5719000
HL2460 PAPER ROLLER KIT	LJ0977001	MFC3900 SEP ROLLER	UF4366001
HL2460 SCANNER	UH1374001	MFC420/620 SEP PAD	LF4975001
HL2460 SEP PAD	LJ0374001	MFC420CN ROLLER, FEED ADF	LF4955001
HL2460 SEP PLATE ASSY	LJ0295001	MFC420CN SEP ROLLER ADF	LF7006001
HL2460 SEPARATION PAD HOLDER	LJ7307001	MFC4300 CIS UNIT	LH7116001
HL2460/2460N SCANNER	LJ0935001	MFC4300 MP SHEET FEEDER ASSM	LH0478005
HL2460/2660/3400CN SEP PAD 2	LJ2317001	MFC4300 TRAY, PAPER EJECT	UU7114005
HL2460CN/2660CN OPTICAL SCAN	LJ3928001	MFC4300ML TRAY EXTENSION	UL5214000
HL2600 FUSING UNIT	LJ3875001	MFC4350 EJECT ROLL	UU7040001
HL2600 TRANSFER UNIT	LJ3881001	MFC4350 MP TRAY ASY WHI	UL6300004
HL3400CN FUSER	LJ2205001	MFC4350 ROLLER, SEPARATION	LF5446001

MFC4350 ROLLER, SEPARATION
MFC4350/4650 SCANNER
MFC4350/4650 SCANNER ASSY
MFC4420/4820C PRINTHEAD UNIT
MFC4450 BROS ADF SPRING PLATE
MFC4450 SPR PLATE, ADF FRONT
MFC4500 SEP PAD
MFC4500 SEP ROLLER
MFC4550 NCU PCB (MODEM BOARD)
MFC4550 SEPARATION PAD
MFC4600 CIS UNIT
MFC4600 MP SHEET FEEDER ASSM
MFC4600 TRAY, PAPER EJECT
MFC4650 EJECT ROLL
MFC4650 MP TRAY ASY WHI
MFC4750 BRUSH, ANTI-STATIC
MFC4750 CLAW, SEPARATION
MFC4750E MOTOR, MAIN
MFC4800 ACTUATOR LEFT
MFC4800 ACTUATOR RIGHT
MFC4800 BEARING 6
MFC4800 CIS UNIT
MFC4800 FIXING UNIT
MFC4800 KEY FPC YL4
MFC4800 PANEL, REAR COVER
MFC4800 ROLLER, FEED 4PC
MFC4800 RUBBER, SEPARATION
MFC4800 SEP PAD
MFC4800 TOP COVER ASSY
MFC5100 CR MOTOR
MFC5100 PAPER FEED MOTOR
MFC5100C NCU PCB(LIU)
MFC5200C PRINTHEAD ASSY
MFC5440/5840 SCANNER UNIT
MFC6650 CIS UNIT
MFC6650 EJECT ROLL
MFC6650 MP TRAY ASY WHI
MFC6800 ADF SEP PAD ASM
MFC6800 FIXING UNIT
MFC6800 SCANNER 2 ASSY
MFC7150 / 7160 UPPER INK ABSORBR
MFC7300 / 7400 PRINTHEAD BY4
MFC7300 PAD, SEPARATION
MFC7300 RUBBER, SEPARATION ADF
MFC7300C ROLL, EJECT
MFC7300C ROLL, EJECT ADF
MFC7300C ROLLER, ADF FEED
MFC7300C ROLLER, PAPER FEED
MFC8220 SEP ROLLER ADF
MFC8300 / 8600 / 8700 ADF SEP PAD
MFC8300 / 8600 HALOGEN LAMP
MFC8300 / 8600 HALOGEN LAMP
MFC8300 CLAW, SEPARATION
MFC8300 FEED ROLLER PLANETARY
MFC8300 FUSER
MFC8300 FUSER EXCH
MFC8300 GUIDE LEFT
MFC8300 GUIDE RIGHT
MFC8300 POWER SUPPLY HI VOLT
MFC8300 SEP PAD HOLDER ASSM

UU7031001
UL7134001
UU7134001
LK0877001
UF7159001
UF7160001
UL5719000
UF4366001
UF7311001
UF7158000
LH7116001
LH0478005
UU7114005
UU7040001
UL6300004
LE7305001
LJ4845001
LE1744001
LE6176001
LE6177001
UL6642000
LG3157001
LE7196001
LG3248001
LE1925001
UL6654001
LE1926001
LE1943001
LE1950001
LE6434001
LE6489001
LG3149001
LK0799001
LF7585001
UG4601001
UU7040001
UL6300004
LE6345001
LE7196001
LE7197001
UU1198001
LK0610001
LE3254001
LE3299001
LE3188001
LE3477001
LE3476001
LE3183001
LF2361001
UU2055001
UL8911001
UL8911001
LJ4845001
LJ5838001
LJ7759001
LJ7759001E
UF6114008
UF6115008
UK4431001
UL9084001

MFC8300/8500/8600/8700 DOC FEED ROLL
UU2029001
MFC8300/8600/8700 DOC SEP ROLL ZLM LE1072001
MFC8420 NETWORK LAN BOARD NC9100H
MFC8420/8820 PANEL,PCB ASSY LG4384001
MFC8500 CIS UNIT LE7949001
MFC8500 FUSER ASM LJ7161001
MFC8500 GUIDE LEFT UF6114008
MFC8500 GUIDE RIGHT UF6115008
MFC8500 MAIN PCB LG3288001
MFC8500 OUTER CHUTE, GREY LJ5763001
MFC8600 GUIDE LEFT UF6114008
MFC8600 GUIDE RIGHT UF6115008
MFC8600 PAPER EJECT ACTU UL8920001
MFC8820 NETWORK LAN BOARD NC9100H
MFC8840D FB SUPPLY ASSM LF2923001
MFC9100/9200 ROLLER, FEED ADF LE2037001
MFC9100C ROLL, EJECT UU1047001
MFC9100C ROLLER, PICKUP ASSY LE2213001
MFC9100C SEP PAD LE2208001
MFC9200 PRINTHEAD BY4 LK0610001
MFC9200C FPC KEY LG2667001
MFC9600 SEP PAD HOLDER ASSM UL9084001
MFC970 ROLLER, PAPER FD UF9728001
MFC970 SEPARATION PAD UF9737001
MFC9700 FRONT COVER UU2102003
MFC9700 HOLDER, DOC FEED ROLL LE2919001
MFC9700 LASER/SCANNER LJ5828001
MFC9700 SEP PAD SPRING UL9090001
MFC9700 SIWTCH, DOCUMENT COVER LG2737001
MFC9700 SOLENOID LJ5701001
MFC9700/9800 CCD UNIT ASSY LE7777001
MFC9700/9800 KEY TEN LE3431001
MFC9700 VIBRATION RUBBER UU7285001

CANON

B 70 FAX MOTOR, PAPER FEED HG1-3715
B380 / 540 / 640 SEP GUIDE (PAD) ASM HG5-0771
B380 SEP ROLLER ASM HG5-0596
B540 CANON PAPER TRAY COVER HG5-0416
B640 ARM, TRANSMISSION QB1-0420
B640 LEVER, LOCKING HB1-1263
B640 PAPER EJECT ROLLER HG5-0433
B640 ROLLER, PAPER FEED HF5-0106
B640 SEPARATION GUIDE UNIT HF5-0140
B640 SHEET, SEP GUIDE HB1-1255
BJC 210 HOOK, CARRIAGE QB1-2027
BJC 230 RING QB1-0429
BJC 600 COLOR PRINT HEAD QY6-0030
BJC5000 ABSORBER PAD QA8-0079
BJC5000 PURGE UNIT QG8-0011

D320/340 COVER, PAPER PICKUP HM1-0246
D320/340 FIXING ASSY HM1-0237
D320/340 LASER SCANNER ASSM RG9-1486
D320/340 TRAY, PAPER PICKUP HM1-0228
D680 CONTROLLER BOARD FM5-5323
F60/80, S750 PRINTHEAD QY6-0041

I250/MP390/S300/S330 PRthead	QY6-0037	LC2060 ARM, DETECTION	HB1-1867
i450/i470D/iP1500 PRINTHEAD	QY6-0054	LC2060 ARM, DETECTION (RPS)	HB1-4299
i560/i850 PRINT HEAD	QY6-0042	LC2060 ARM, LIFTING	HB1-1886
i70 PRINTHEAD	QY6-0046	LC2060 CAM UNIT	HG5-2186
i80 PRINTHEAD	QY6-0052	LC2060 CLUTCH	HB1-4286
I850 CORD, POWER	QH2-2725	LC2060 DELIVERY ASSY	RG5-3474
i900D/iP6000D PRINTHEAD	QY6-0050	LC2060 EXIT ROLLER ASSY	RF5-2367
IC 3305 DOC FEED BELT	FE6-3059	LC2060 FIXING FILM ONLY	LP-2802F
IC C2500 COVER, SHAFT	RB2-8417	LC2060 HEATING ELEMENT ASSM	RG5-3459
IC D780 FIXING ASSY	FM5-0992	LC2060 HIGH VOLTAGE PWR SUPPLY	HH3-5334
		LC2060 PAD, ADF SEPARATION	HB1-4265
IR2200 FIXING ASSY	FG6-1258	LC2060 ROLLER, ADF LO DOC FEED	HB1-4307
IR2200 PAPER PICKUP ASSY	FG6-5989	LC2060 ROLLER, ADF LOW DOC EJECT	HF5-0543
IR300/400 TRANSFER ROLL ASSY	FG6-0456	LC2060 ROLLER, FUSER EXIT	RF5-2368
IR330 SEP PAD	FF5-9160	LC2060 ROLLER, FUSER PRESSURE	RF5-2364
IR330/400 FUSER ASSY	FG6-0461	LC2060 ROLLER, PAP DRIVE PICKUP	HB1-4277
IR5000 FLAPPER, DUPLEXING	FB5-3304	LC2060 ROLLER, PAP FD PICKUP 2PC	HB1-4283
IR5000 ROLLER, PAPER FEED	FC3-0702	LC2060 ROLLER, PAP FEED PICKUP	HB1-4282
IR5000 SHAFT, SEPARATION ROLLER	FF5-9784	LC2060 ROLLER, PICK-UP	HF5-0547
IR5000 SPRING, TENSION	FS7-2334	LC2060 ROLLER, TRANSFER	RF5-1534
		LC2060 SEP PAD	HB1-4673
LBP 860 DOOR, MAIN TRAY 1 FRONT	RB1-2924	LC3170 ARM, HOOK	HB1-3863
LBP 860 PAPER DELIVERY ASSY	RG5-0636	LC3170 BUSHING	HB1-3808
LBP 860 TRAY 1 ASSM	RB1-2931	LC3170 FRAME, READER, UPPER	HB1-3902
LBP 860/1260 MP TRAY ASM	RG5-0635	LC3170 GEAR, 17T/38T	RS5-0930
LBP1760 BUSHING	RS5-1310	LC3170 GEAR, 18T	RS5-0929
LBP1760 BUSHING	RS5-1297	LC3170 RIB, TRAY	RB1-8990
LBP1760 DAMPER	RB2-2399	LC3170 TRAY, EXTENSION, FACEUP	HB1-3798
LBP1760 RING, E	XD9-0134	LC3170 TRAY, FACE-UP	HB1-3797
LBP1760 ROLLER DELIVERY	RB1-8720	LC3170/3175 ROLLER, LOWER SEPA	HB1-3899
LBP1760 STOPPER, REAR	RB1-8956	LC3170/3175 STAMP UNIT	HH7-2212
		LC3170/3175 TOP CVR SUPP ASM, RT	RG5-2645
L 75 FEED ROLLER	RB2-1699	LC3170/3175 TRAY, DOCUMENT	HG5-1932
L 75 FEEDER DRIVE ASSEMBLY	RG5-1947	LC3170/3175/MS BELT, LOW READ	XF2-1616
L 75 POWER SUPPLY UNIT	HH3-5391	LC3170/3175/MS FIXING FILM ASSM	RG5-4290
L 75 ROLLER, SUB, PAPER PICK-UP	RB2-1633	LC3170/3175/MS FIXING FILM ONLY	LP-5063F
L 75 SHEET, SEPARATION	RB2-1706	LC3170/3175/MS FUSER - WITH EXCH	RG5-2661E
		LC3170/3175/MS PAD, TRAY 1 MAIN ASSM	RG5-5281
L770/775 FAX ROLLER, SUB SEP	HA1-7352	LC3170/3175/MS ROLLER, DELIVERY	HB1-3807
L770/775 SEP PAD, ADF	HG1-2383	LC3170/3175/MS ROLLER, FEED/SEP	RF5-1885
L770/775 SEP ROLL, ADF	HA1-7351	LC3170/3175/MS ROLLER, LOW EJECT	HB1-3860
L775 DRIVE UNIT, ADF	HG1-3483	LC3170/3175/MS ROLL, LOW DOC FEED	HB1-3859
		LC3170/3175/MS ROLL, LOWER FUSER	RB9-0684
LC 710 / 720 / 730 ROLLER, PICKUP	HB1-3911	LC3170/3175/MS ROLLER, MID DOC FEED	HB1-3884
LC 710 DAMPER ASSEMBLY	RB2-6248	LC3170/3175/MS ROLLER, MID SEP	HG5-1935
LC710/720/730 GEAR ASSY	RG5-5577	LC3170/3175/MS ROLL, PRESS, LOW	RB9-0684G
LC710/720/730 ROLLER, FD DELIV	HG5-2832	LC3170/3175/MS ROLLER, REGISTER	RB1-8731
LC710/720/730 SEP ROLLER, UPPER	HB1-5284	LC3170/3175/MS ROLLER, TRANSFER	RG5-4283
LC710/720/730 SHAFT, ADF CONNE	HG5-2861	LC3170/3175/MS ROLL, TRAY 1 PICK UP	RG5-3718
LC710/720/730 SPRING, COMPRESSION	RS6-2021	LC3170/3175/MS ROLLER, UPPER SEP	HB1-3912
LC710i/720i/730i FEED ROLL UNIT, LOWER	HG5-2847		
		L3500 ARM, SEPARATION	RB2-6221
LC1060P FIXING ASSY	HG5-2337	L3500 FEED ASSY	RG5-3485
LC1060P ROLLER ASSY, PICKUP	HG5-2546	L3500 FIXING FILM ONLY	LP-2802F
LC1060P ROLLER, PRESSURE	RF5-5479	L3500 HEATING ELEMENT ASM	RG5-3459
LC1060P ROLLER, SEPARATION	HB1-4856	L3500 HOLDER, ARM	RB1-7206
LC1060P SEPARATION GUIDE ASSY	HG5-2556	L3500 LEVER, SENS	RB1-7293
		L3500 P/U SENSOR CABLE	RG9-1946
		L3500 PAD, LEFT	RF5-1492

L3500 PAD, RIGHT	RF5-1493	LC5000/5500 BELT, COGGED	XF9-0484
L3500 PICK-UP SEP REPAIR KIT	KFAX	LC5000/5500 BELT, LOW ADF DRIVE	XF9-0518
L3500 ROLLER UP ADF BACKU	HS5-6023	LC5000/5500 DELIVERY ASM	RG5-0681
L3500 ROLLER, ASSM EXIT	RF5-2367	LC5000/5500 FIXING FILM ONLY	LP-2802F
L3500 ROLLER, DELIVERY	HB1-2864	LC5000/5500 FUSER ASM	RG5-0676
L3500 ROLLER, DELIVERY 1	HS5-6042	LC5000/5500 GUIDE, ADF SEPARATI	HG5-0143
L3500 ROLLER, FEED	RB2-1699	LC5000/5500 HOLDER,SEP ROLLER	HB1-0616
L3500 ROLLER, FUSER EXIT	RF5-2368	LC5000/5500 LEVER, SEPARATION	HB1-0546
L3500 ROLLER, LOW ADF DOC EJEC	HF5-0328	LC5000/5500 PLATE, LIMIT	HB1-0558
L3500 ROLLER, LOW ADF DOC FEED	HB1-3033	LC5000/5500 POWER SUPPLY UNIT	HH3-5268
L3500 ROLLER, PICK-UP ASSM	HG5-1288	LC5000/5500 ROLLER ASSY, FEED	HG5-0120
L3500 ROLLER, PRESSURE	RF5-2364	LC5000/5500 ROLLER ASSY, PICKUP	HG5-0124
L3500 ROLLER, SEPARATION LOW ADF	HB1-4561	LC5000/5500 ROLLER, FEED	HB1-0527
L3500 SEP PAD	HB1-3035	LC5000/5500 ROLLER, FEED UNIT P/U	HG5-0109
L3500 SEPARATION GUIDE ASSM	HG5-1308	LC5000/5500 ROLLER, FUSER DELIVERY	RB1-3103
L3500 SPRING, COMPRESSION	RS5-2502	LC5000/5500 ROLLER, LO ADF DOC FD	HB1-0603
L4000 CUSHION, RUBBER	HB1-2578	LC5000/5500 ROLLER, LO ADF EJECT	HB1-0604
L4000 KEYTOP, DIAL	HB1-1802	LC5000/5500 ROLLER, LO PAPR EJECT	HB1-0582
L4000 SPRING	HS5-2103	LC5000/5500 ROLLER, LOADING	HF5-0045
LC4000 BUSHING	HS5-1041	LC5000/5500 ROLLER, P/U-FEEDER UN	HB1-0419
LC4000 CARRIAGE UNIT	QG5-0289	LC5000/5500 ROLLER, PICKUP	HB1-0540
LC4000 COVER, DOC GUIDE UPPER	HB1-1781	LC5000/5500 ROLLER, PRESSURE	RB1-3100
LC4000 FUSER	RG9-1136	LC5000/5500 ROLLER, SEPARATION	HF5-0044
LC4000 GUIDE, SEP PAD	HB1-1882	LC5000/5500 ROLLER, TRANSFER	RF5-0596
LC4000 GUIDE, SEPARATION	HG5-0704	LC5000/5500 ROLLER, UP ADF BACKUP	HA1-5327
LC4000 HEATING ELEMENT ASSY	RG5-1964	LC5000/5500 ROLLER, UP ADF EJECT	HA1-6852
LC4000 HOLDER, DOC FEED SEP	HB1-1794	LC5000/5500 SCANNER WITH EXCHANGE	RG5-0662E
LC4000 PLATE, TONER SENSOR	HB1-1855	LC5000/5500 SEP PAD	HB1-0542
LC4000 ROLLER, DOC FEED/SEPARAT	HB1-3697	LC5000/5500 SEP RUBBER	HB1-0650
LC4000 ROLLER, DOCUMENT EJECT	HB1-1773	LC5000/5500 SHAFT, PICKUP ROLLR	HB1-0442
LC4000 ROLLER, DOCUMENT FEED	HB1-1772	LC5000/5500 SPRING, CLUTCH	HS5-2028
LC4000 ROLLER, FACE DOWN	HF5-0215	LC5000/5500 TRANSFER GUIDE ASSM	RG5-0702
LC4000 ROLLER, FEED	HB1-1828	LC5500 TRAY, DOCUMENT	HB1-0486
LC4000 ROLLER, LOWER PRESSUR	RF5-1516	LC5500 TRAY, EXIT	HB1-0485
LC4000 ROLLER, MP PICKUP	HG5-1405	L7000 BOARD, OPERATION PANEL	HG1-4127
LC4000 ROLLER, PICK UP MP	HB1-1861	L7000 POWER SUPPLY ASSY	HH3-5278
LC4000 ROLLER, TRANSFER	RF5-1534	LC7000 PCNT ASSY	HG5-0117
LC4000 ROLLER, UP ADF BACKU	HS5-6023	LC7000 SHEET, FRICTION PET FIL	HB1-0637
LC4000 ROLLER, UP ADF BACKUP	HB1-1790	LC7000/7500 DELIVERY ASM	RG5-0681
LC4000 ROLLER, UPPER ADF BACKUP	HS5-6025	LC7000/7500 FAN	HH7-2023
LC4000 RUBBER, SEPARATION	HB1-1792	LC7000/7500 FIXING FILM ONLY	LP-2802F
LC4000 SEP PAD	HB1-1880	LC7000/7500 GEAR, MOTOR	RG5-0765X
LC4000 SHEET, STABILIZING	HB1-2553	LC7000/7500 MAIN MOTOR	RG5-0765
LC4000 SPRING, CLUTCH	HS5-2077	LC7000/7500 ROLLER, ASSM FEED	HG5-0120
LC4000 TRAY, FAX SUB	HB1-1817	LC7000/7500 ROLLER, ASSM PICK-UP	HG5-0124
L4500 ARM, DETECTION	HB1-1867	LC7000/7500 ROLLER, DOC EJECT LOW	HB1-0742
L4500 FRAME, LOWER ADF	HB1-1771	LC7000/7500 ROLLER, FEED (2)	HB1-0527
L4500 FUSER	RG9-1136	LC7000/7500 ROLLER, FEED UPPER	HB1-0713
L4500 GUIDE, SUB CART, RIGHT	RB1-7341	LC7000/7500 ROLLER, FEEDER UNIT PU	HG5-0109
L4500 POWER SUPPLY UNIT	HH3-5297	LC7000/7500 ROLLER, FUSER	RG5-0678
L4500 ROLLER, DOC FEED/SEPARAT	HB1-3697	LC7000/7500 ROLLER, FUSER DELIVERY	RB1-3103
L4500 ROLLER, MP PICKUP	HG5-1405	LC7000/7500 ROLLER, LO ADF DOC FD	HB1-0741
L4500 ROLLER, PICK UP MP	HB1-1861	LC7000/7500 ROLLER, LO ADF SEP	HG5-0167
L4500 ROLLER, TRANSFER	RF5-1534	LC7000/7500 ROLLER, LOADING	HF5-0058
L4500 SCNT BOARD ASSY	HG5-1066	LC7000/7500 ROLLER, LOWER SEP	HF5-0057
L4500 SEP PAD	HB1-1880	LC7000/7500 ROLL, PAPER EJECT LOW	HB1-0582
L4500 SEP RUBBER	HB1-1792	LC7000/7500 ROLLER, PICKUP (4)	HB1-0441
L4500 SPRING, CLUTCH	HS5-2077	LC7000/7500 ROLLER, PICKUP FEEDER	HB1-0419
		LC7000/7500 ROLLER, PRESSURE	RB1-3100

LC7000/7500 ROLLER, TRANSFER	RF5-0596	LC9000 SPRING,CLUTCH(LWR ADF)	HB1-2284
LC7000/7500 ROLLER, TRAY 1 PICKUP	HB1-0540	LC9000 TORQUE LIMITER	HB1-2313
LC7000/7500 ROLLER, UP ADF EJECT	HA1-6852		
LC7000/7500 ROLLER, UP ADF SEP	HG5-0172	MFC3500 SEPARATION PAD	HB1-2872
LC7000/7500 ROLLER, UPPER SEP	HB1-0718	MFC3500 SHEET, SEPARATION	HB1-2898
LC7000/7500 SCANNER WITH EXCHANGE	RG5-0662E	MP1000 ROLLER, PICKUP	HB1-0256
LC7000/7500 SEP PAD	HB1-0542	MP2500 CARTRIDGE HOLDER BJ	HB1-1549
LC7000/7500 TORQUE LIMITER	HB1-0716	MP3000 COVER,LEVER	QB1-0993
		MP6060,RDFA1 ELECTROMAG CLUTCH	FH7-5306
L8500/9000 CAM	HB1-2283	MP700/730 ABSORBER, INK	QA4-1012
L8500/9000 CAM STOP (LWR ADF)	HB1-2286	MP700/730 ABSORBER, INK	QA4-1013
LC8000 SEPARATION ROLLER ASSY	HG5-1652	MP700/730 ABSORBER, INK	QA4-1014
LC8500 COVER, BOTTOM CONT PANEL A	HB1-2334	MP700/730 ABSORBER, INK	QA4-1015
LC8500 SPRING, TONER SENSOR	HS5-2106	MP700/730 ABSORBER, INK	QA4-1055
LC8500 SUPPORT PEN	HB1-2461	MP-C2500 CAPPING ASSEMBLY	HG5-0514
LC8500/9000 CONNECTOR	VS1-5057	MPC5000 RIBBON CABLE,CARRIER	HG5-1138
LC8500/9000 CONTACT SENSOR UNIT	HG5-0914	MP-C5000 TRAY, SUPPORT, DOC	HB1-3286
LC8500/9000 GEAR, 18T	HS5-0070	MP-F50/S600 PRINT HEAD	QY6-0034
LC8500/9000 GEAR, 66T/31T	RS5-0979		
LC8500/9000 MIRROR ASSY	RG5-2861	PC 2/5 ROLLER, PICKUP	FB1-0131
LC8500/9000 PIECE, CTG PRESSUR	RB1-3130	PC 3/11 HEATER LAMP	FH7-4230
LC8500/9000 SPRING CLUTCH	HB1-2288	PC 5 SEPARATION PAD	FB1-0153
LC8500/9000 SPRING, SUPPORT	HB1-2388	PC 6 (A) BELT ROLLER (PC)	FB1-1444
LC8500/9000 TONER SENSOR	HH7-2221	PC 6/12/65/NP1020 GEAR,32T,UP FUS	FS4-0171
LC8500/9000 TRAY, EXIT	HB1-0485	PC 6/7/8/C100/NP1010/NP1020 UFR	FB1-9212
LC8500/9000/9500 CLUTCH, FEEDER	HB1-2456	PC 6 / 7 / RE SPRING, COMPRESSION	FS5-2031
LC8500/9000/9500 DELIVERY ASSY	RG5-1704	PC 6 CLNR FELT ASM	FG5-0018
LC8500/9000/9500 FIXING FILM ASSM	RG5-2802	PC 6 LOWER FUSER ROLL	FB1-1512
LC8500/9000/9500 FIXING FILM ONLY	LP-2802F	PC 6RE SWITCH, KEY	WC2-5057
LC8500/9000/9500 FUSER	RG5-2800	PC 6RE CANON EXPOSURE LAMP	FH7-3104
LC8500/9000/9500 FUSER	RG5-4110E	PC 6RE CLUTCH UNIT	FB1-1474
LC8500/9000/9500 GEAR, 16T	RS5-0636	PC 6RE GEAR, 25T	FS5-0061
LC8500/9000/9500 GEAR, 22T	HS5-0181	PC 6RE INNER EXIT TRAY	FB1-1721
LC8500/9000/9500 GEAR, 24T FUSER	RS5-0637	PC 6RE OUTER EXTNSION EXIT TRAY	FB1-1722
LC8500/9000/9500 GEAR,22T	HS5-0180	PC 6RE ROLLER, PAPER PICK-UP	FA4-5581
LC8500/9000/9500 HOLDER, TNR SENS	HB1-2376	PC 6RE SEPARATION CLAWS	FB1-0301
LC8500/9000/9500 MAIN MOTOR	RG5-2786	PC 6RE SLIDER, CASSETTE, FRONT	FB1-1833
LC8500/9000/9500 OPCNT BOARD ASSY	HG5-0923	PC 6RE SLIDER, CASSETTE, REAR	FB1-1834
LC8500/9000/9500 ROLLER, FEED	HB1-2451	PC 6RE SPRING	FS5-2002
LC8500/9000/9500 ROLLER, FUSER DEL	RB1-9181	PC 6RE STEPPER MOTOR	FH7-1517
LC8500/9000/9500 ROLL, LO ADF LOADN	HB1-2274	PC 6RE TRANSFER CORONA	FG5-0250
LC8500/9000/9500 ROLL, LO DOC EJECT	HB1-2272	PC 7 CLUTCH SPRING	87-2847-000
LC8500/9000/9500 ROLL, LOW DOC FEED	HB1-2271	PC10/14/25 FUSER ROLL, UPPER	FA2-5936
LC8500/9000/9500 ROLL, P/U FEEDER (2)	HB1-2450	PC10/20 EXPOSURE LAMP	FH7-3029
LC8500/9000/9500 ROLLER, PICKUP	HB1-2472	PC10/20 HEATER LAMP	FH7-4087
LC8500/9000/9500 ROLLER, PICK-UP MPF	HB1-1861	PC10/20/25 FEEDROLL TIRE	A9403584
LC8500/9000/9500 ROLLER, SEP	HB1-2470	PC10/25 CX FUSER ROLL, LOWER	FA2-5937
LC8500/9000/9500 ROLLER, SEP FEED	HB1-2470	PC25 EXPOSURE LAMP	FH7-3049
LC8500/9000/9500 ROLLER, SEP UPPER	HB1-2312	PC25 HEATER LAMP	FH7-4121
LC8500/9000/9500 ROLLER, TRANSFER	RF5-0596	PC3 FEED TABLE	FF5-0081
LC8500/9000/9500 ROLL, UP DOC EJECT	HA1-6852	PC6/12/65 STOPPER, HINGE FRONT	FF5-0189
LC8500/9000/9500 ROLL. LOW ADF SEP	HB1-2273	PC6/12/65 STOPPER, HINGE REAR	FF5-0190
LC8500/9000/9500 SEP PAD	HB1-0542	PC330/770/790 P/U ROLLER	FB1-7303
LC8500/9000/9500 TORQUE LIMITER	HB1-2462	PC420 SUPPORT, REG ROLL, REAR	FB2-9596
LC8500/9000/9500 XFER GUIDE ASSM	RG5-1706	PC430 GEAR, 20T	FB1-7317
LC8500/9000/9500 TRAY, DOCUMENT	HA1-6578	PC430 PLATEN GLASS	FG5-4787
LC9000 BOARD, POWER SUPPLY	HH3-5327	PC430 TRAY, MANUAL PAPER FEED	FB2-9672
LC9000 GEAR, 19T	HB1-2282	PC430 TRAY, PAPER DELIVERY	FB2-9663
LC9000 PCNT BOARD (POWER SUP)	HG5-0952	PC700 SERIES PULLEY	FF5-2867
LC9000 SHAFT, SEPARATION ROLL	HB1-2276	PC700 SPRING, TENSION (For Front Door)	FS5-2783

PC700/900 PRESSURE ROLLER	FB2-5043	2380/81 PRINTHEAD ASM	79F4792
PC700/900 PRINT SWITCH	WC2-5102	2380/81 PRINTHEAD EXCHANGE	79F4792E
PC710/720/795 EXPOSURE LAMP	FH7-3272	2380/81/90/91 PLATEN KNOB	79F4784
PC720 CONTROL PANEL	FF5-2880	2380/81 GEARS AND BUSHING KIT	79F4810
PC720 GEAR, 17/80T	FF5-3714	2380/90 FRT GUIDE CVR	79F4779
PC720 GEAR, 30/80T	FF5-3715	2380/90 LOW PNCH ROLL	79F4799
PC720 MOUNT SOLENOID	FB2-5276	2380/90 TRACTOR FEED ARM	1333153
PC720 SEPARATION PAD	FB2-5380	2380/90(-003) FEED ROLLER UPPER	1333226
PC720/730/740 ROLLER, HOOK	FB2-4863	2380/90/2480 RIB RACK DR GEAR	79F4802
PC720/730/740 SHAFT, ROLLER	FB2-4864	2381 ROLLER, PINCH (LOWER)	79F4832
PC720/740 SPRING	FS5-2780	2381/2391 TRACTOR	1333157
PC720/740/745 TRAY, COPY 1	FB4-9898	2390/2391 CARRIER MOTOR ASSY	1333222
PC720/740/745 TRAY,COPY,2	FB2-5426	2390/2391 SUB LOGIC CARD ASSY	1333224
PC720/740/770/790 VARISTOR	FF2-9779	2390/91 PRINTHEAD	79F4818
PC770 DELIVERY DRIVE ASSY	FG5-3501	2390/91 PRINTHEAD EXCH	1333220E
PC770 FLAG, SENSING 1	FB2-5383	2390/91 PRINTHEAD EXCHANGE	79F4818E
PC770 MOUNT SOLENOID	FF5-2873	2391 ROLLER, PINCH (LOWER)	79F4832
PC770/790 SEPARATION PAD	FB2-5210	23xx TRACTOR ASM(LT & RT)(SET)	1333160
PC770/NP6012 PICKUP DRIVE ASSY	FG5-3511	2481 ROLLER, LOWER PINCH	12G3943
PC785 FEDDING ASSY	FG5-6414	4019 FUSER - EXCHANGE	1381889E
PC785/795 ADF DRIVE ASSY	FG5-6416	4019 FUSER PARTS PACKET	1381075
PC795 PAD	FB3-3349	4019 UPPER SHAFT ASM	1368646
PC795/850 PICKUP ROLLER	FB1-8581	4019 (NEW STYLE)/4029 FUSER	1381889
PC795/980 ROLLER, ADF PICKUP	FB3-3373	4019 ANCHOR KIT	1383908
PC795/980 SEP PAD ASSY, ADF	FF5-4679	4019 ANCHOR KIT METERING	1383580
PC800/900/950 SCANNER DRIVE AS	FG6-3733	4019 BUCKLER	1381577
PC800/900/950 SHAFT,P/U ROLLER	FB4-9818	4019 CLUTCH MAGNET ASM.	1383433
PC800/900/950 SUPPORT,CLAW	FB5-0172	4019 D ROLLER	1368647
PC850 DEVELOPMENT BIAS PCB	FG5-2989	4019 DRIVE ROLLER ASSEM	1039603
PC850 LIGHT SENSING PCB ASSY	FG5-2884	4019 D-ROLLER TIRE	1039540
PC850/NP6016 ROLLER, PICK-UP	FB2-2251	4019 FRONT/REAR LOGO	1367806
PC900 DRIVE ASSY, PICKUP	FG6-4075	4019 FUSER INPUT GUIDE	1383419
PC921 KEYTOP, ON/OFF	FB5-1877	4019 GEAR PACK	1383317
PC921 PANEL, CONTROL	FG6-3772	4019 HOT ROLLER	1383322
PC1000 CAM, PICKUP ROLLER, RIGHT	RB2-2903	4019 HRDW PARTS PACK	1383314
PC1000 PIN, DOWEL	XD9-0159	4019 HV POWER SUPPLY	1383435
PC1000/1060 PAD, ADF,SPONGE	FC5-6088	4019 INPUT SENSOR BOARD	1383430
PC1000/1060 PAD,ADF MOUNT	FC5-6087	4019 JUMPER PARTS PACK	1383313
PC1000/1200 ROLLER, PAPER FEED	FC5-0005	4019 LASER PRINTER FAN	1383998
PC1000/1200 ROLLER, PAPER DELIV	FC5-0006	4019 LASER THERMAL FUSE	1381546
PC1000/1200 ROLLER, REGISTRATI	FC5-0070	4019 LH BELLCRANK	1039692
PC1000S PANEL, OPEN/CLOSE	FL2-0008	4019 LOWER SHAFT ASM	1381906
PC1000S ROLLER, WHITE	FC5-0007	4019 ON/OFF SW LVR	1195318
PC1060 FEEDER FRAME	FM2-0002	4019 OZONE CARTRIDGE ASM	1383429
PC1060 ROLLER, ADF PICKUP	FC5-0009	4019 PAPER TRAY 11"	1381583
PC1060 ROLLER, ADF SEPARATION	FM2-0015	4019 PAPER TRAY 14"	1381584
PC1060 SEP PAD ASSY	FL2-0006	4019 PAPERFEED GEAR PACK	1381884
PC1080 FILM	FG6-7948	4019 PAPERFEED ROLLER PA	1383320
R3250 ROLLER, REVERSE	RB1-6828	4019 PLENUM ASM	1368648
		4019 PRINTHEAD	1383321
		4019 PRINTHEAD - EXCH	1383321E
		4019 REDRIVE DEFLECTOR	1368645
		4019 RETAINER PARTS PACK	1383315
		4019 RH BELLCRANK	1039693
		4019 ROLLER, CBM	1368637
		4019 SHAFT	1039271
		4019 SPRING PACK	1383316
		4019 THERMAL FUSE	1381784
		4019 THERMISTOR	1383428
		4019 TRANSFER CORONA	1383387
LEXMARK			
1275 MAINT KIT EXCHANGE	11C0152E		
2380 CABLE, SHORT FLEXIBLE	1333225		
2380 PRINTER CABLE	79F4793		
2380/2390 DUAL TRACTOR MOTOR	11A3337		
2380/2390 GEAR & BUSHING KIT	95F6892		
2380/2390 PAPER GUIDE, ASF	95F6884		
2380/2390 PARTS PACK DUAL TR	11A3341		
2380/2390 POWER SUPPLY	1333242		

4025 OPTRA W820 SCREW BRACKET	12G4231	4029/4039 PAPER STOP	1183163
4026 D ROLLER	69G8375	4029-010 SYSTEM BOARD - EXCH	1381481E
4026 D ROLLER	69G9956	4035 FUSER PARTS PACKET	1381075
4026 DOOR LEVER	69G9697	4035 UPPER SHAFT ASM	1368646
4026 EXIT PAPER TRAY	69G8340	4035 ANCHOR KIT METERING	1383580
4026 HOT ROLL	69G9977	4035 BUCKLER	1381577
4026 OPTRA E BRACKET, BACKUP	11A7422	4035 D ROLLER	1368647
4026 OPTRA E BRACKET, REAR PAP	11A7385	4035 FRONT/REAR LOGO	1367806
4026 OPTRA E ROLLER, REAR PAP	11A7389	4035 FUSER INPUT GUIDE	1383419
4026 OPTRA E SEPARATOR, PAPER	11A7459	4035 HV POWER SUPPLY	1383968
4026 OPTRA E SEPARATOR, PAPER	69G8373	4035 LOWER SHAFT ASM	1381906
4026 PAPER FEED INPUT TRAY	69G8365	4035 OZONE CARTRIDGE ASM	1383429
4026 PAPER SEPARATOR	69G8330	4035 PAPER FEED MAGNET	1383925
4026 SPRING, INSIDE	69G8323	4035 PAPER TRAY 11"	1381583
4029 FUSER - EXCHANGE	1381889E	4035 PAPER TRAY 14"	1381584
4029 FUSER PARTS PACKET	1381075	4035 PAPERFEED ROLLER PA	1383320
4029 UPPER SHAFT ASM	1368646	4035 PLENUM ASM	1368648
4029 02X SYSTEM BOARD	1381482	4035 POWER SUPPLY EXCHANGE	1383974E
4029 030/40 FUSER 110V PURCHAS	1383522	4035 PRINthead	1383321
4029 030/40 FUSER EXCHANGE	1383522E	4035 PRINthead - EXCH	1383321E
4029 030/40 SYS BOARD	1381483	4035 REDRIVE DEFLECTOR	1368645
4029 ANCHOR KIT	1383908	4035 RETAINER	1383517
4029 ANCHOR KIT METERING	1383580	4035 ROLLER PACK AUX	1383934
4029 BUCKLER	1381577	4035 ROLLER PACK ENV	1383935
4029 D ROLLER	1368647	4035 THERMAL FUSE	1381784
4029 DRIVE ROLLER ASSEM	1039603	4035 TRANSFER CORONA	1383387
4029 D-ROLLER TIRE	1039540	4035/4039 FRONT COVER ASM	1328186
4029 FRONT/REAR LOGO	1367806	4035/4039 FRONT EXIT SLIDE	1328189
4029 FUSER INPUT GUIDE	1383419	4035/4039 FUSER ASSY EXCHANGE	1381626E
4029 HV POWER SUPPLY	1383435	4035/4039/4049 THERMISTOR	1381637
4029 HV POWER SUPPLY	1383968	4037 CHARGE ROLL ASSY	1381288
4029 LEX SYS CBL#1 OWG	1195551	4037 FUSER ASM	1381621
4029 LOWER SHAFT ASM	1381906	4037 LASER THERMAL FUSE	1381546
4029 MID SHAFT ASSEMBLY	1381910	4037 THERMISTOR	1381297
4029 ON/OFF SW LVR	1195318	4039 REDRIVE ASSEMBLY	1381897
4029 OZONE CARTRIDGE ASM	1383429	4039 (16L) POWER SUPPLY - EXCH	1381014E
4029 PAPER FEED MAGNET	1383925	4039 10P PRINthead	1381624
4029 PAPER TRAY 11"	1381583	4039 10P SYSTEM BOARD - EXCH	1381578E
4029 PAPER TRAY 14"	1381584	4039 10P/R SIMM ROM CODE 21.23	1381696
4029 PAPERFEED ROLLER PA	1383320	4039 10R SYS BOARD -EXCH	1381515E
4029 PLENUM ASM	1368648	4039 10R SYSTEM BOARD	1381515
4029 POWER SUPPLY EXCHANGE	1383974E	4039 10X MAINTENANCE KIT WITH EXCH	MK4039-10XE
4029 PRINthead	1383321	4039 12C METERING BELLCRANK BM	1409238
4029 PRINthead - EXCH	1383321E	4039 12R/C REDRIVE ASM	1381898
4029 REDRIVE	1368650	4039 16L CABLE	1381134
4029 REDRIVE ASSEMBLY	1381897	4039 16L MAINTENANCE KIT WITH EXCH	1329140E
4029 REDRIVE DEFLECTOR	1368645	4039 ANCHOR KIT	1383908
4029 RETAINER	1383517	4039 ANCHOR KIT METERING	1383580
4029 ROLLER PACK AUX	1383934	4039 BELLCRANK METER ASM	1427307
4029 ROLLER PACK ENV	1383935	4039 BELT, LOWER	1367804
4029 ROLLER, CBM	1368637	4039 BELT, UPPER	1367803
4029 SHAFT	1039271	4039 BUCKLER	1381577
4029 SLIP GEAR #9	1381881	4039 CABLE	1381095
4029 SPRING PACK	1383316	4039 CABLE	1325018
4029 SWITCH ASM OPT OWG	1383922	4039 CABLE, FAN/MIRROR MOTOR	1325017
4029 SWITCH ASM OPT PAP SOU	1381991	4039 COVER, CLIP BEARING	1328356
4029 SYSTEMS CABLE #1	99A1119	4039 D-ROLLER TIRE	1039540
4029 THERMAL FUSE	1381784	4039 FUSER BAIL KIT	1381888
4029 THERMISTER HI TEMP	1381674	4039 FUSER CABLE	1381537
4029 THERMISTOR	1383428	4039 FUSER EXCHANGE	1381639E

4039 FUSER EXCHANGE	1381640E	4045 FUSER ASSY	12G3982
4039 FUSER LAMP 110V	1381011	4045 FUSER EXCHANGE	12G3982E
4039 FUSER WIPER	1380785	4045 HV PWR SUPPLY	12G0376
4039 GEAR 11	1381726	4045 LVPS-110V	12G0369
4039 GEAR PACK	1383317	4045 M410 DRIVE ASSY, MAIN	12G0321
4039 GEAR PACK	1381886	4045 M410/412 COVER, EXIT	12G0258
4039 GEAR PLATE ASM	1409146	4045 M410/412 PAPER GUIDE	12G0296
4039 HOT ROLL ASM	1381076	4045 M410/412 ROLLER, HOT	12G0326
4039 HOT ROLLER	1383322	4045 M410/412 SOLENOID MPF PIC	12G0251
4039 HOT ROLLER	1381146	4045 M410/412 TRAY, MP INPUT	12G0266
4039 HRDW PARTS PACK	1383314	4045 ROLLER LWR DRV	12G0308
4039 HV POWER SUPPLY EXCHG	1381645E	4045 ROLLER, TRANSFER	12G0354
4039 INPUT SENSOR BOARD	1383430	4045 ROLLER,MP TRAY	12G0299
4039 JUMPER PARTS PACK	1383313	4045 ROLLER,P/U MAIN	12G0323
4039 LASER PRINTER FAN	1383998	4045 ROLLER,UPR DRV	12G0307
4039 LASER THERMAL FUSE	1381546	4045/M410,412 FUSE, THERMAL	12G3980
4039 LOWER REDRIVE SHAFT	1381912	4045/M410,412 ROLLER 500SH PIC	12G0399
4039 LOWER SHAFT ASM	1381906	4045/M410,412 SHAFT ASMMPPICK	12G0300
4039 MANUAL FEED TRAY	1328508	4045/M410,412 SHAFT ASSY	12G0400
4039 MID SHAFT ASSEMBLY	1381910	4045/M410,412 SHAFT ASSY PICK	12G0322
4039 ON/OFF SW LVR	1195318	4045/M410/M412 BELT,REDRIVE RL	12G0310
4039 PAPER FEED MAGNET	1383925	4046 OPTRA K GUIDE, PAPER END	12A4007
4039 PAPER SIZE SENSOR ASM	1381015	4046 POWER SUPPLY	11A4234
4039 PAPER TRAY 11"	1381583	4047 CHARGE ROLL ASSY	1381288
4039 PAPER TRAY 14"	1381584	4047 FUSER ASM	1381621
4039 PLENUM ASSY	1325022	4047 LASER THERMAL FUSE	1381546
4039 POWER SUPPLY EXCHANGE	13A0451E	4047 THERMISTOR	1381297
4039 PRINthead SHROUD ASSY	1368651	4049 12X ENGINE BOARD EXCHANGE	1381792E
4039 REDRIVE	1368650	4049 12X ENGINE BOARD NEW	1381792
4039 REDRIVE ARM ASM	1376367	4049 16X/RXO/LMX ENG BRD EXCHA	1381796E
4039 REDRIVE ASSY	1381895	4049 16X/RXO/LMX ENGINE BOARD	1381796
4039 RETAINER PARTS PACK	1383315	4049 500 SHEET LEGAL TRAY	1381814
4039 RIGHT HAND FRAME ASSY	1381950	4049 ANCHOR KIT	1383908
4039 RIGHT HAND FRAME EXCHANGE	1381950E	4049 ANCHOR KIT METERING	1383580
4039 ROLL ASM, HOT	1381086	4049 ANCHOR KIT METERING	1383580
4039 ROLLER PACK AUX	1383934	4049 BELLCRANK METER ASM	1427307
4039 ROLLER PACK ENV	1383935	4049 BELT, LOWER	1367804
4039 ROLLER, CBM	1368637	4049 BELT, UPPER	1367803
4039 ROLLER, PACK	1381145	4049 CLUTCH MAGNET ASM.	1383433
4039 SHAFT	1039271	4049 COVER TRAY	1381875
4039 SLIP GEAR #9	1381881	4049 COVER, CLIP BEARING	1328356
4039 SPRING FRONT COVER DEFL	1183599	4049 D ROLLER TIRE	1381842
4039 SPRING PACK	1383316	4049 DRIVE ASSY	1381638
4039 THERMAL FUSE (16X)	1381788	4049 DRIVE ROLLER ASM	1381843
4039 THERMISTOR (12X)	1381786	4049 D-ROLLER	69G5480
4039 TOP COVER PAPER TRAY	1381034	4049 FLAG PACK	1381669
4039 TRANS HOUSE	1381652	4049 FRONT COVER	69G9481
4039 TRANSFER CORONA	1383387	4049 FUSER BAIL KIT	1381888
4039 TRANSFER ROLL	1381008	4049 FUSER EXCHANGE	1381639E
4039 TRANSFER ROLL ASSEMBLY	1381922	4049 FUSER EXCHANGE	1381640E
4039 TRANSFER ROLL ASSEMBLY	1381922	4049 FUSER LAMP 110V	1381011
4039/4049 THRUST WASHER	1328279	4049 FUSER WIPER	1380785
4039/49 BACKUP ROLL	1329928	4049 FUSER WIPER ASSY 10P	1382204
4039/49 BELLCRANK PRE-ALIGNER	1328384	4049 GEAR 11	1381726
4039/49 OTR REDRIVE SHEILD	1328381	4049 GEAR PACK	1381886
4039/49/5040 FUSE SB 110V	1328463	4049 GEAR PACK 500 SHEET TRAY	1381920
4039-12C MAINT KIT EXCHANGE	1325949E	4049 GEAR PLATE ASM	1409146
4040 MOUNTS PLATE B/M	11A8182	4049 HOT ROLLER	1381146
4040 PAPER DECK DRIVE ASSY	11A8550	4049 HSYNC PRINthead CABL	1408034
4045 CARD INA 10/100 BASE TX	12G1695	4049 HV POWER SUPPLY EXCHG	1381645E

4049 LASER PRINTER FAN	1383998	4059 RESTRAINT SIDE, 250 SH TR	99A1894
4049 LASER THERMAL FUSE	1381546	4059 RIGHT COVER	99A0011
4049 LEGAL TRAY BUY OUTRIGHT	1364893	4059 ROLL ASM BACKUP	99A0160
4049 LOWER REDRIVE SHAFT	1381912	4059 ROLL ASM BACKUP	99A0158
4049 MANUAL TRAY	1408394	4059 ROLL ASM PICK 2/PACK	99A0070
4049 MTR ASM	1381633	4059 ROLL ASM, TRANSFER	99A0179
4049 PAPER GUIDE	1408708	4059 S1250/1255 CARD, EXCHANGE	99A1012E
4049 PAPER SIZE SENSOR ASM	1381015	4059 S1250/1255 FUSER	99A1185
4049 PAPER TRAY	1381813	4059 S1250/1255 FUSER 500W LMP	99A1185E
4049 PAPERFEED GEAR PACK	1381884	4059 S1250/1620 CARD ASM EXCHA	99A0187E
4049 POWER SUPPLY EXCHANGE	13A0451E	4059 S1650 FUSER 100V/500W LAMP	99A1187
4049 REDRIVE	1368650	4059 S1650/2420 CARD ASM EXCHA	99A0183E
4049 REDRIVE ASSEMBLY	1381899	4059 S16XX CARD ASSY, ENGINE	99A1016
4049 REDRIVE ASSY	1381895	4059 S1855 CARD ASSY, EXCHANGE	99A1018E
4049 ROLLER PACK AUX	1383934	4059 S2450 LV POW SUP PURCHASE	99A0214
4049 ROLLER PACK ENV	1383935	4059 SENSOR, TONER CART LE	99A0466
4049 ROLLER, PACK	1381145	4059 SEP PAD KIT	99A0083
4049 RT RAIL W/GEARS/MAGNE	1381801	4059 SHAFT, DUPLEX DRIVE	99A0316
4049 SLIP GEAR #9	1381881	4059 SPRING, DUPLEX SHAFT	99A0315
4049 SPRING PACK	1383316	4059 SPRING, UPPER DIVERTER	99A0104
4049 SPRING PACK	1381666	4059 STRIP, WEAR	56P1279
4049 SWITCH ASM OPT OWG	1383922	4059 TRAY, SPECIAL MEDIA	99A0911
4049 SWITCH ASM OPT PAP SOU	1381991	4059 WIPER FUSER ASM	99A0146
4049 THERMAL FUSE (16X)	1381788	4059/4069 CABLE, MAIN MOTOR	99A0255
4049 THERMISTOR (12X)	1381786	4059/4069 GEAR, FEEDROLL	99A0274
4049 TRANS HOUS	1381652	4059/4069 GEARBOX WITH MOTOR	99A0129
4049 TRANSFER ROLL	1381008	4059/4069 PACKET, RETAINERS	99A0267
4049 TRANSFER ROLL ASSEMBLY	1381922	4059/4069 PLATE, SNAP-IN	99A0124
4049-12L/R MAINTENANCE KIT EXC	69G5257E	4059/4069 ROLL, SKEWED BACKUP	99A0451
4049-16L/R MAINT KIT LV - EXCH	69G5249E	4059/4069 SHAFT, DEVELOPER DRV	99A0136
4049-16L/R MAINT KIT LV PURCHA	69G5249	4059/4069 SLIDER, AUTOSIZE 250	99A0127
4056 S16XX CARD, ENGINE-EXCHAN	99A1016E	4059/4069 SPRING LATCH	99A0004
4059 ARM, PAPER OUT, 500	99A0443	4059/4069 SPRING, SEPARATOR	99A0081
4059 BASE ASSY BOTTOM 500SH	99A0298	4059/4069/SE3455 CONTACT, SMART CART	99A0815
4059 BUSH, HOT ROLL	99A0150	4059/4069/SE3455 CONTACT, SMART CART	99A0816
4059 CARD ASM 250/500/2M TRAY0	56P0557	4059/4069/SE3455 PLUNG, OVRSTRESS	99A0834
4059 CARD ASM ENGINE	99A0946	4059-1250 LV PWR SUPPLY 110V	99A0218
4059 CHARGE ROLLER	99A1017	4060 T63x COVER, UPER FRONT	56P1303
4059 CLIP, 250 TRAY WEAR	99A0121	4060 T63x HINGE, UPPER FRT COV	56P1305
4059 COUPLER GEAR #55	99A0564	4069 ARM ASSY, PICK 500 INTEGR	99A1530
4059 COVER ASM LOWER FRONT	99A0023	4069 ARM, PAPER OUT 250 INT	99A1609
4059 COVER ASSY, REDRIVE CAP	99A0552	4069 ARM, PAPER OUT, 500 SHEET	99A1616
4059 COVER, FUSER WICK ASSY	99A0016	4069 BELLCRANK ROLLER RELEASE	99A1664
4059 DEFLECTOR ASSY	99A0091	4069 CABLE ASM, SMART CARTRIDG	99A1593
4059 DEFLECTOR ASSY, OUTER 250	99A0110	4069 COVER ASSY, REDRIVE CAP	99A1512
4059 FUSER LAMP 500W	99A0141	4069 COVER ASSY, RIGHT SIDE	99A1504
4059 FUSER LAMP 750W	99A0140	4069 COVER ASSY, RIGHT, TALL	99A1505
4059 GEAR IDLER	99A0148	4069 COVER ASSY, LOWER FRONT	99A1511
4059 HIGH VOLT POW SUP EXCH	99A0220E	4069 COVER, ASM LASER, 250	99A1506
4059 HIGH VOLTAGE POWER SUP	99A0220	4069 COVER, FUSER WICK ASSY	99A1508
4059 HINGE, UPPER FRONT COVER	99A1048	4069 COVER, LEFT SIDE, DOOR 1	99A1509
4059 HOT ROLL ASSM	99A0562	4069 COVER, SMART CARTRIDGE	99A1595
4059 HOT ROLL S2450/2420/2455	99A0149	4069 DEFLECTOR, UPPER REDRIVE	99A1857
4059 HOUSING ASSY, DETACK	99A0833	4069 DRIVE ASM, GEARBOX, W/MOTR	99A1543
4059 MAINT KIT EXCHANGE	99A1195E	4069 DRIVE ASSY, DEVELOPER	99A1544
4059 OPTRA S FLAG, EXIT SENSOR	99A0172	4069 FAN T630/632	56P1408
4059 OPTRA S(1250) 500 SHT TRAY	99A0289	4069 FAN, MAIN T630/632	56P1360
4059 PAD, RESTRAINT	99A0120	4069 HINGE, UP FRONT COVER	99A1503
4059 PARTS PACKET	99A0413	4069 HOTROLL ASSY	99A1521
4059 PICK-UP ROLLER	99A0076	4069 KNOB, PAPER SIZE	99A1537

4069 LATCH, BACK RESTRAINT	99A1601	5050 MAINTENANCE KIT	11G0601
4069 LATCH, UPPER COVER	99A1502	5050 MAINT KIT WITH EXCH	11G0601E
4069 OPTRA T SPRING, BELLCRANK	99A1930	5050 SENSOR, DRUM BLACK 614DSS	11G0550
4069 PANEL, OPERATOR	99A1501	5050 SENSOR, DRUM COLOR 614DSS	11G0548
4069 PICK-UP ROLLER	99A0076	5050 SENSOR, TONER (A) 611-TN	11G0207
4069 POWER SUPPLY HVPS	99A1823	5055 C910 MAINT KIT	56P9900E
4069 POWER SUPPLY LVPS 110V	99A1822	5055 FUSER OPTRA C910 WITH EXCH	56P9751E
4069 REDRIVE ASSY	99A1586	5060 C750 ITU BELT ASSY	56P1295
4069 ROLL ASM PICK 2/PACK	99A0070	5060 C750 PICK ASM PRIMARY 500	12G6427
4069 SPRING 250 INT TRAY BELLC	99A1927	5060/C750 MAINTENANCE KIT	12G6496
4069 SUPPORT, PAPER	99A1587	5060/C752 MODULE ASM ITU CRU	56P1544
4069 SWITCH, OP PANEL/COVER OP	99A1577	6782-89 UNIV PWR SUPPL	1400290
4069 T4/6/7XX TRANS ROLL ASM	99A1015	C710 CARD ASSY INA 10 BASE2/T	12G1696
4069 T41B/E/L LV POWER SUPPLY	99A1875	C710 FUSER	12G1698
4069 T610/612 BASE ASSY 500 SH	99A1636	C710 MOTOR ASSY, COUPLING DRIV	12G1620
4069 T610/612 FUSER EXCHANGE	99A1969E	C720 FUSER KIT	15W0908
4069 T610/717 CARD ASSY	99A1954	E310 001 CA CONTROL	12G3786
4069 T610/717 CARD ASSY EXCHAN	99A1954E	E320/322 PAWL DETACK	12G4495
4069 T610/717 PRINthead	99A1526	M410/412 ALIGN ASSY,PAPER FEED	12G0303
4069 T612 CARD ASSY EXCHANGE	99A1959E	M410/412 CARD ASM, CONTROLLER	12G3567
4069 T614/616/41B,E FUSER EXCH	99A1977E	M410/412 ROLLER, TRANSFER	12G0354
4069 T620 CONTACT SMART CARTRI	99A2471	M410/M412 FUSER ASSY	12G3982
4069 T620/622 ARM ASM PICK 500	99A2444	M410/M412 FUSER EXCHANGE	12G3982E
4069 TRAY ASSY, 250 SHHET INT	99A1536	M410/M412 HV PWR SUPPLY	12G0376
4077/4090 ACC PARTS PACK	69G4188	M410/M412 LVPS-110V	12G0369
4077/4090 PAPER GUIDE	70G3039	M410/M412 ROLLER LWR DRV	12G0308
4091 POWER SUPPLY	11B5592	M410/M412 ROLLER,MP TRAY	12G0299
4226 SENSOR ARM	79F4434	M410/M412 ROLLER,P/U MAIN	12G0323
4500 ASSY, D ROLL	12G4483	M410/M412 ROLLER,UPR DRV	12G0307
4500 E320 AD ASSY PAPER SEPARA	56P0691	OPTRA 1200 COLOR TRANSFER BELT	11G0202
4500 E320/322 ROLLER, PAPER FD	12G4490	OPTRA E210 FUSER ASSY 110V	12G6773
4500 E32x ROLLER, FUSER HOT	12G4491	OPTRA E210 PAD, LEFT SEPARATOR	12G6785
4500 FUSER	12G4484	OPTRA E210 PAD, MAIN SEPARATOR	12G6779
4520 T520/522 CARD ASM, ENGINE	56P1004	OPTRA E210 PAD, RIGHT SEPARATO	12G6786
4520 T520/522 CARD, ENGN EXCHA	56P1004E	OPTRA E210 ROLL ASSY, PICK	56P2501
4520 T522 FUSER EXCHANGE	99A2423E	OPTRA E210 ROLLER, TRANSFER	12G6770
5024 C720 ROLLER, PAPER FEED	12G7098	OPTRA E310 / 312 GEAR, FUSER HOT	12G0081
5040 CART DRIVE GEAR	12C0186	OPTRA E310 CLUTCH, PICK ROLL	12G0065
5040 EPROM SIMM 90.92 CODE LVL	12C0161	OPTRA E310 FRICTION, LEFT	12G0119
5040 FUSER	12C0575	OPTRA E310 FRICTION, RIGHT	12G0120
5040 FUSER WITH EXCHANGE	12C0575E	OPTRA E310 FUSER	12G0074
5040 GUIDE	12C0628	OPTRA E310 INPUT PAPER FEED	12G0070
5040 GUIDE	12C0629	OPTRA E310 PAD, FRICTION, LEFT	12G1931
5040 KIT ASM, CLEANING	12C0850	OPTRA E310 PAD, FRICTION,RIGHT	12G1932
5040 LEVER	12C0153	OPTRA E310 PICK-UP ROLLER ASSY	12G0067
5040 ROLLER	12C0247	OPTRA E310 POWER SUPPLY EXCHAN	12G0089E
5040 ROLLER, COLOR LASER	12C0291	OPTRA E310 SEPARATION PAD	12G0062
5040 ROLLER, PICKUP	12C0025	OPTRA E310 SPRING	12G0068
5040 SEPARATOR	12C0016	OPTRA E310,312 TRANSFER ROLLER	12G0048
5040 SHAFT	12C0626	OPTRA E310/312 CONTACT, MAIN	12G0053
5040 SPRING	12C0627	OPTRA E310/312 CONTACT, TRANSF	12G0052
5040 TRANSPORT BELT	12C0430	OPTRA E310/312 COVER, TOP	12G0041
5045 FUSER, OPTRA C	11A2470	OPTRA E310/312 FAN, COOLING	12G0128
5045 FUSER, OPTRA C WITH EXCHANGE	11A2470E	OPTRA E310/312 GUIDE, PAPER ST	12G0126
5045 OPTRA C (L) MAINTENANCE KIT	11A2374	OPTRA E310/312 HOLDER ASSY, SP	12G0063
5045 OPTRA C (L) MAINT KIT WITH EXCHE	11A2374E	OPTRA E310/312 ROLLER, BACK-UP	12G0086
5045 OPTRA C PRINthead ASSY	11A2072	OPTRA E312 COVER, FRONT W/OVER	12G3668
5050 DRUM/DRIVE GEAR SENSOR	11G0581	OPTRA E312 FUSER	12G1935
5050 FUSER, COLOR LASER NEW	11G0375	OPTRA E312 ROLLER ASSY, PICK	12G1933
5050 GEAR, 30 N/S	11G0366	OPTRA E312 SPRING PAD ASM, LOW	12G0121

OPTRA N 5SI STOPPER CARTRIDG	11A8062
OPTRA N FUSER	11A8233
OPTRA N FUSER WITH EXCHANGE	11A8233E
OPTRA N MAIN MOTOR	11A8033
OPTRA N MAINTENANCE KIT	11A8122
OPTRA N MAINTENANCE KIT WITH EXCH	11A8122E
OPTRA N PRINTER DRIVER	11A8265
OPTRA S (1250) 500 SHT TRAY	99A0289
OPTRA T620 FUSER EXCHANGE	99A2402E
OPTRA T620 MAINTENANCE KIT EXCH	99A2408E
OPTRA T630 FUSER EXCHANGE	56P1333E
OPTRA T630 MAINT KIT EXCHANGE	56P1409E
OPTRA T630 MAINT KIT PURCHASE	56P1409
OPTRA T630/632 FUSER EXCHANGE	56P2542E
S1250,1650,2450 SHAFT POWER	99A0134
S1250,1650,2450 SPRING, POWE	99A0275
S2450 MAINT KIT EXCHANGE	99A1195E
S2450 PRINthead EXCHANGE	99A0066E
W810 FUSER	12G2221
W810 MAINT KIT WITH FUSER	12G3421
Z51 BELT CARRIER	14R0182
Z53 LEXMARK POWER ADAPTER	12G3641
Z73/83 ENCODER STRIP	12G6151
Z73/83/X83 GEAR ASM GEAR TRAIN	12G6125

XEROX - TEKTRONIX

PHASER 550 COLOR IMAGING KIT	016-1457-00
PHASER 560 COLOR IMAGING UNIT	016-1523-00
PHASER 560 FUSER	016-1534-00
PHASER 560 ROLL,	016-1556-00
PHASER 740 COLOR IMAGING KIT	016-1662-00
PHASER 740 TRANSFER KIT	016-1664-00
PHASER 740(L) FUSER	016-1660-01
PHASER 750 COLOR IMAGING KIT	016-1841-00
PHASER 750 FUSER	016-1839-00
PHASER 750 MAIN CHARGE GRID	016-1665-00
PHASER 780 COLOR IMAGING KIT	016-1864-00
PHASER 780 FUSER ROLL	016-1866-01
PHASER 840 MAINT KIT 30K YIELD	016-1727-00
PHASER 850 EXT D MAINT KIT 45K	016-1834-00
PHASER 850 STD MAINT KIT 10K	016-1822-00
PHASER 860 EXT D MAINT KIT 40K	016-1932-00
PHASER 860 STD MAINT KIT	016-1933-00
PHASER 340/350/360 MAINT TRAY	436-0294-03
PHASER 540/550 FUSER	016-1323-00
PHASER 540/550 PAPER FEED ASSY	118-9185-04
PHASER 740 CLEANING PAD KIT	116-0329-00
PHASER 840/850/860 FLAG KIT	650-4156-00
PHASER 840/850/860/8200 BELT KIT	650-3615-00
PHASER 850 DRAWER, MAINTENANCE	436-0359-01
PHASER 850 EXIT COVER	200-4604-01
PHASER 850 GUIDE PICK ASSY	351-1032-00
PHASER 850 KEY SENSOR PKG OF 2	214-4595-02
PHASER 850 LFT MAINT DRAW GUID	351-1051-02
PHASER 850 LOWER EXIT PIVOTING	351-1016-00
PHASER 850 PAPER BACKSTOP	118-9588-01
PHASER 850 ROLLER ASSY, PICK	401-0813-01
PHASER 850 ROLLER, LOWER TRANS	401-0858-00
PHASER 850 RT MAINT DRAWR GUID	351-1053-01

PHASER 850 SHAFT CRS SAFETY CO	401-0781-01
PHASER 850 UP PREHEAT ENT GUID	351-1106-00
PHASER 860 CLUTCH, UNIVERSAL	650-4289-00
PHASER 860 EXIT LWR PIVOT GUID	351-1095-00
PHASER 860 PICK GUIDE ASSY	351-1088-00
PHASER 860 RAPID RELEASE GUIDE	650-4214-00
PHASER 860 Y AXIS PULLEY	650-4227-00
PHASER 1235 IMAGING DRUM BLACK	013R90132
PHASER 1235 IMAGING DRUM CYAN	013R90133
PHASER 1235 IMAGING DRUM MAG	013R90134
PHASER 1235 IMAGING DRUM YELL	013R90135
PHASER 1235 TRANSFER BELT UNIT	101R00419
PHASER 3450 FUSER	126E02480
PHASER 6200 CHUTE OUT ASSY	116-1410-00
PHASER 6200 FUSER	016-2014-00
PHASER 6200 IMAGING UNIT	016-2012-00
PHASER 6200 MPT BASE ASSY	116-1325-00
PHASER 6200 PAPER ROLLER KIT	116-1331-00
PHASER 6200 ROLLER, TRANSFER	016-2013-00
PHASER 6200/6250 ROLLER, TRANS	108R00592
PHASER 6250 FUSER	115R00029
PHASER 6250 IMAGING UNIT	108R00591
PHASER 6250 IP BOARD-NO MEMORY	650-4271-06
PHASER 7300 FUSER 110V	016-1998-00
PHASER 7300 IMAGE UNIT MAGENTA	016-1994-00
PHASER 7300 IMAGE UNIT YELLOW	016-1995-00
PHASER 7300 IMAGING UNIT BLACK	016-1996-00
PHASER 7300 IMAGING UNIT CYAN	016-1993-00
PHASER 7300 IMAGING UNIT KIT	016-1997-00
PHASER 7300 TRANSFER UNIT	016-2000-00
PHASER 7700 PRINT CARTRIDGE	016-1886-00
PHASER 8200 BOARD, MAIN	650-4250-00
PHASER 8200 BOARD, POWER CONTR	650-4251-00
PHASER 8200 DRUM MAINT CLUTCH	650-4288-00
PHASER 8200 EXT D MAINT KIT 40K	016-1932-00
PHASER 8200 HI-CAP PAPER TRAY	437-0495-00
PHASER 8200 I/O BOARD	671-5258-50
PHASER 8200 MAINT DRWR GUIDE LT	351-1097-01
PHASER 8200 MAINT DRWR GUIDE RT	351-1099-01
PHASER 8200 PREHEATER ASSY	650-4228-01
PHASER 8400 MAINTENANCE KIT - 30K	108R00603

MEMORY UPGRADES

BROTHER

HL 8E 2MB	BRORAM01E-2
HL10V/10DV/HL10PS 4MB	BRORAM2-4
HL1250/1440 16MB MEMORY UPGRAD	BRORAM10-16
HL1250/1440 32MB MEMORY UPGRAD	BRORAM10-32
HL1650,MFC9660 128MB UPGRADE	BRORAM09-128
HL1650,MFC9660 16MB UPGRADE	BRORAM09-016
HL1650,MFC9660 64MB UPGRADE	BRORAM09-064

CANON

LBP430/430W 4MB	CANRAM5-04
LC5000 512MB UPGRADE	CANFAX3-0.5

HP

DESIGNJET 650/750C/1600 16MB	HPMAX4-16
DESIGNJET 650/750C/1600/C 32MB	HPMAX4-32
DESIGNJET 330-16MB UPGR (C3416A)	HPMAX6-16
II/IIID 2MB (H33444B)	HP2DV2-2
II/IIID 4MB (H33445B)	HP2DV2-4
4/4M 4MB (C2065A)	HPMAX4-04
IIISi/4Si 4MB (C2065A)	HPMAX4-04
4/4M 8MB (C2066A)	HPMAX4-08
IIISi/4Si 8MB (C2066A)	HPMAX4-08
IIP/IIIP,III(D) 2MB UPGRADE (H33475B)	HP3PV2-2
IIP/IIIP,III(D) 4MB (H33477B)	HP3PV3-4
4+ / 5 - 16MB UPGRADE (C3416A)	HPMAX6-16
4P - 16MB UPGRADE (C3416A)	HPMAX6-16
4+/4P/5/5si/6P 32MB	HPMAX6-32
4+/5 4MB (C3132A)	HPMAX6-04
4+/5 8MB (C3133A)	HPMAX6-08
4P 4MB (C3132A)	HPMAX6-04
4P 8MB (C3133A)	HPMAX6-08
5L/6L 4MB UPGRADE (C3148A)	HPMAX8-04
5L/6L 8MB (C3149A)	HPMAX8-08
1100 16MB (C4137A)	HPRAM02-16
1200 16MB (C7843A)	HPRAM05-016
1200 32MB	HPRAM05-032
1200 64MB (C7846A)	HPRAM05-064
2100 16MB	HPRAM02-16
2200 16MB (C7843A)	HPRAM05-016
2200 32MB	HPRAM05-032
2200 64MB (C7846A)	HPRAM05-064
2250 MEM 64MB (F1457B)	HPRAM06-064
3200 16MB (C7843A)	HPRAM05-016
3200 32MB	HPRAM05-032
3200 64MB (C7846A)	HPRAM05-064
4000 / 4050 8MB UPGRADE (C4141A)	HPRAM01-08
4000 16MB (C7843A)	HPRAM05-016
4100 32MB MEMORY UPGRADE	HPRAM5-32
4100 128MB	HPRAM05-128
4100 128MB MEMORY UPGRADE	HPRAM5-128
4100 16MB (C7843A)	HPRAM05-016
4100 16MB MEMORY UPGRADE	HPRAM5-16
4100 32MB	HPRAM05-032
4100 64MB (C7846A)	HPRAM05-064
4200 FIRMWARE DIMM	Q2453-67905
4500 8MB UPGRADE (C4141A)	HPRAM01-08
4550 64MB	HPRAM7-64
4550 128MB (C7850A)	HPRAM7-128
5000 16MB (C7843A)	HPRAM05-016
8000 16MB (C7843A)	HPRAM05-016
8150 128MB	HPRAM05-128
8150 128MB MEMORY UPGRADE	HPRAM5-128
8150 16MB (C7843A)	HPRAM05-016
8150 32MB	HPRAM05-032
8150 64MB (C7846A)	HPRAM05-064
9000 128MB	HPRAM05-128
9000 16MB (C7843A)	HPRAM05-016
9000 32MB	HPRAM05-032
9000 64MB (C7846A)	HPRAM05-064

TECHNICAL MANUALS**BROTHER**

FAX 1170/1270/1770 PARTS MANUAL	5X4301BEO
FAX 2600 USER GUIDE	LH0409001
MFC4300 USER GUIDE	LH0409001
MFC4600 USER GUIDE	LH0409001

CANON

D340 IMAGECLASS PARTS MANUAL	HY8-39AY
D660/680/PC1080 PARTS CATALOG	HY8-31A4-030
IC 2300 (N) PARTS MANUAL	FY8-31G3
IC C2500 PARTS CATALOG	DU7-3111-000
IR3250 PARTS CATALOG	FY8-31EQ-000
L3500 FAX PARTS MANUAL	HY8-39AJ
L4500 FAX PARTS MANUAL	HY8-39AC
LC 710/720I/730I FAX PARTS MANL	HY8-39AW
LC1060P FAX PARTS MANUAL	HY8-39AR
LC2060 FAX PARTS MANUAL	HY8-39AN
LC3170/3175 FAX PARTS MANUAL	HY8-39AM
LC4000 FAX PARTS MANUAL	HY8-39A9
LC5000/5500 FAX PARTS MANUAL	HY8-39A0-010
LC7000/7500 FAX PARTS MANUAL	HY8-39A3-010
LC8500/9000/9500 PARTS MANUAL	HY8-39AB-020
LC9000/9500 INSTRUCTION BOOK	HT1-2088
PC 310/330/330L SERVICE MANUAL	FY8-13CB-000
PC 400/420/430 PARTS CATALOG	FY8-31DD-000
PC 700 SRS PARTS MANUAL	FY8-31C6-010
PC 745 PARTS MANUAL	FY8-31DB
PC 850 PARTS MANUAL	FY8-31BN
PC 920 SERVICE MANUAL	FY8-13GA-000
PC 920/940/950 PARTS CATALOG	FY8-31EB
PC1060/1080 PARTS MANUAL	HY8-39AT
PC1080F CANON SVC/PARTS CD	HY8-19AW

HP InkJet

DJ 500 TECH. REF MAN.	C2170-90099
DJ Service/Parts VER 4.1 - CD	LP-HPIJ
DJ CP1700 Service/Parts CD	C8108-67903
DJ1000C/1100C/1120C Service/PartsCD	LP-DJ1000CD
DJ2000 FAMILY Service/Parts CD	LP-DJ2000CD
DJ2500C TRAINKIT INC SVC MANUAL	C2684-60290
DSJ 700/755CM SERVICE MANUAL	C4705-90000
DSJ Service/Parts CD	LP-DESIGNCD
DSJ DRIVER,AUTOCAD DRIVER	C6072-60301
OJ & OJLX FAMILY Service/Parts	LP-MOJ
OJ 300/350 Service/Parts	LP-MOJ300

HP LASER

LJ QUICK REF GUIDE VOL V - MONO	5851-1891
II/III SERVICE/PARTS MANUAL	LP-MSX
IID/IIID SERVICE/PARTS MANUAL	33459-90906
IIISi/4Si SERVICE/PARTS MANUAL	LP-MNXIIP/IIIP
SERVICE/PARTS MANUAL	LP-MLX
4 USER MAN & QUICK REF	C2001-90912
4/4M/4+/4M+ SERVICE/PARTS MAN	LP-MEX

4L/4P/5P/6P SERVICE/PARTS MANUAL LP-MPX
 4V SERVICE/PARTS MANUAL LP-MBX
 5 USER MANUAL KIT C3916-99024
 5L SERVICE/PARTS MANUAL LP-MAX
 5SI SERVICE/PARTS MANUAL LP-MWX
 6L SERVICE/PARTS MANUAL LP-MAX
 6L USER INSTRUCTIONS C3990-90901
 1000 SERVICE/PARTS MANUAL LP-M1000
 1100 CD SERVICE MAN C4224-60161) LP-M1100CD
 1100 QUICK REF MANUAL C4218-90901
 1100 SERVICE/PARTS MANUAL LP-M1100
 1100 SERVICE/PARTS CD LP-M1000CD
 1150 SERVICE/PARTS MANUAL LP-M1300
 1160 PARTS AND SERVICE LP-M1320
 1200 SERVICE/PARTS MANUAL LP-M1200
 1200 SERVICE/PARTS CD LP-M1200CD
 1300 SERVICE/PARTS MANUAL LP-M1300
 1320 PARTS AND SERVICE LP-M1320
 1500 SERVICE MANUAL LP-M1500
 1500 SERVICE/PARTS CD LP-M1500CD
 2100 SERVICE/PARTS MANUAL LP-M2100
 2100 SERVICE/PARTS CD LP-M2100CD
 2200 SERVICE/PARTS MANUAL LP-M2200
 2200 SERVICE/PARTS CD LP-M2200CD
 2300 SERVICE/PARTS MANUAL LP-M2300
 2400 SERIES SERVICE & PARTS LP-M2400
 2400 SERVICE MANUAL Q5956-90932
 2500 SERVICE MANUAL LP-M1500
 2500 SERVICE/PARTS CD LP-M1500CD
 3015/3020/3030 SVC/PARTS MANL LP-M3015
 3100 USER MANUAL C3948-90968
 3100/3150 SERVICE/PARTS MANUAL LP-M3100
 3100/3150 SERVICE/PARTS CD LP-M3100CD
 3150 OPERATORS MANUAL C4256-90952
 3200 SERVICE/PARTS MANUAL LP-M3200
 3200 SERVICE/PARTS CD LP-M3200CD
 3200 USER MANUAL C7052-90951
 3300 SERVICE/PARTS MANUAL LP-M3300
 3380 SERVICE MANUAL LP-M3380
 4000 SERVICE/PARTS MANUAL LP-M4000
 4000/4050 SERVICE/PARTS CD LP-M4050CD
 4050 SERVICE/PARTS MANUAL LP-M4050
 4100 SERVICE/PARTS MANUAL LP-M4100
 4100 SERVICE/PARTS CD LP-M4100CD
 4200/4300 SERVICE/PARTS MANUAL LP-M4200
 4500/4550 MANUAL QUICK/REF SVC 5851-1493
 4500/4550 SERVICE/PARTS MANUAL LP-M4550
 4500/4550 SERVICE/PARTS CD LP-M4550CD
 4600 SERVICE/PARTS MANUAL LP-M4600
 4650 SERVICE/PARTS MANUAL LP-M4650
 5000 SERVICE/PARTS MANUAL LP-M5000
 5100 SERVICE/PARTS MANUAL LP-M5100
 5500 SERVICE/PARTS MANUAL LP-M5500
 8000 SERVICE/PARTS MANUAL LP-M8000
 8100/8150 SERVICE/PARTS MANUAL LP-M8150
 8550 SERVICE/PARTS MANUAL LP-M8550
 9000 SERVICE/PARTS MANUAL LP-M9000
 9500 SERVICE/PARTS CD LP-M9500CD

Don Thompson FIELD SVC GUIDE VOL 1 TR465
 Don Thompson FIELD SVC GUIDE VOL 2 TR475
 JETDIRECT NETWORK CONFIG GUIDE J2552-90001
 LASER PRINTER MODULE REPAIR TR420
 LASER PRINTER PROBLEM SOLVER TR430
 MANUAL KIT, TECHNICAL REF 5021-0377
 REF GUIDE VOL 3 5961-0953
 REF MANUAL VOL #1 5021-8943
 REF MANUAL VOL #2 5090-3390

LEXMARK

4012 SVC MANUAL MEDLEY FAX 69G6604
 4019 PARTS/SVC MANUAL 4019 1039671
 4019 USER GUIDE 1058223
 4019/4029 QUICK REF GUIDE 1058225
 4029 PARTS/SVC MANUAL 1183432
 4029USER GUIDE 1183417
 4039 USER GUIDE 1325316
 4039-10P PARTS/SERVICE MANUAL 1419488
 4045 SERVICE MANUAL 12G3517
 4049 PLUS LOOK WHAT'S NEW 69G8943
 4049 PLUS PARTS/SVC SOFT GUIDE 69G9150
 4049 SERVICE MANUAL 13A0329
 4049 TECHNICAL REFERENCE 69G9148
 4049 USER GUIDE 1408818
 4059 PARTS/SERVICE MANUAL 12G0139
 4208 USER GUIDE 94X5832
 4226 USER GUIDE 79F4468
 4520 T522 SERVICE/PARTS MANUAL 12G3967
 5016 OPTRA C710 SERVICE MANUAL 12G6111
 5040 OPTRA SC1275 SVC MANUAL 12C0985
 5045 SERVICE MANUAL 69G3225
 5045 USER GUIDE 69G3241
 IJ HANDBOOK IJ SVC REFERENCE 12G1795
 LEXMARK PARTS CD ROM 18A1525
 OPTRA E SVC MANUAL 11A7626
 OPTRA N PARTS/SVC MAN 11A9985
 OPTRA N USER GUIDE 11A9051
 OPTRA SC1275 USER GUIDE 18A0006
 P 238X,239X SERVICE MANUAL 11A3100
 PARTS CD ROM 18A1491
 SRVC REF HANDBOOK (LASER) 12G1798
 X4500 E32x PARTS/SVC MANUAL 12G9084