



## SPECIFICATIONS GUIDE Rack Bracket For PM PDUs

For technical support, visit:  
[www.avocent.com/support](http://www.avocent.com/support)

For document downloads, visit:  
[www.avocent.com/manuals](http://www.avocent.com/manuals)

The illustrations in this specifications guide are supplemental to the documentation included with your Avocent Power Management Power Distribution Unit (PM PDU). The illustrations display the dimensions for each model of PM PDU with rack mounting brackets attached.



### Horizontal PM PDUs

The illustrations for the horizontal PM PDUs are on the following pages of this guide:

- 3-outlet models ..... page 2
- 6-outlet models ..... page 3
- 10-outlet models ..... page 4

For specific rack mounting instructions, refer to either the PM PDU Horizontal Power Strip Quick Installation Guide or the Avocent PM PDU Installer/User Guide.

### Vertical PM PDUs

The illustrations for the vertical PM PDUs are on the following pages of this guide:

- 20-outlet models ..... pages 5-6
- 24-outlet models ..... page 7
- Rack mounting bracket ..... page 8

For specific rack mounting instructions, refer to either the PM PDU Vertical Power Strip Quick Installation Guide or the Avocent PM PDU Installer/User Guide.







**SPECIFICATIONS GUIDE Rack Bracket For PM PDUs**
**PM 2000 PDU Models**

- PM2001H-401
- PM2003H-401

**PM 3000 PDU Models**

- PM3001H-401
- PM3003H-401





**SPECIFICATIONS GUIDE Rack Bracket For PM PDUs**
**PM 2000 PDU Models**

- PM2002H-401
- PM2004H-401
- PM2005H-403
- PM2005H-404
- PM2005H-406
- PM2006H-401

**PM 3000 PDU Models**

- PM3002H-401
- PM3004H-401
- PM3005H-403
- PM3005H-404
- PM3005H-406
- PM3006H-401




**SPECIFICATIONS GUIDE Rack Bracket For PM PDUs**
**PM 1000 PDU Models**

- PM1009H-401
- PM1010H-401
- PM1011H-xxx\*



**PM 2000 PDU Models**

- PM2007H-401
- PM2008H-401
- PM2009H-xxx\*

**PM 3000 PDU Models**

- PM3007H-401
- PM3008H-401
- PM3009H-xxx\*

\* The actual part number for these models ends with the country-specific code and power cord type (for example, -001 is used for North America and includes an L6-20 cord).





**SPECIFICATIONS GUIDE Rack Bracket For PM PDUs**
**PM 1000 PDU Models**

PM1012V-401

PM1013V-401

PM1014V-xxx\*

\* The actual part number for these models ends with the country-specific code and power cord type (for example, -001 is used for North America and includes an L6-20 cord).




**SPECIFICATIONS GUIDE Rack Bracket For PM PDUs**
**PM 1000 PDU Models**


- PM1001V-401
- PM1002V-401
- PM1003V-401
- PM1004V-401
- PM1005V-401
- PM1006V-401
- PM1007V-401
- PM1008V-401

**PM 2000 PDU Models**

- PM2001V-401
- PM2002V-401
- PM2003V-401
- PM2004V-401
- PM2005V-403
- PM2005V-404
- PM2005V-406
- PM2006V-401

**PM 3000 PDU Models**

- PM3001V-401
- PM3002V-401
- PM3003V-401
- PM3004V-401
- PM3005V-403
- PM3005V-404
- PM3005V-406
- PM3006V-401





**SPECIFICATIONS GUIDE Rack Bracket For PM PDUs**
**PM 2000 PDU Models**

- PM2010V-401
- PM2011V-401
- PM2012V-xxx\*

**PM 3000 PDU Models**

- PM3010V-401
- PM3011V-401
- PM3012V-xxx\*

\* The actual part number for these models ends with the country-specific code and power cord type (for example, -001 is used for North America and includes an L6-20 cord).




**SPECIFICATIONS GUIDE Rack Bracket For PM PDUs**
**RMK-57**

Rack mount bracket included with vertical rack PDUs

