Dell Vostro 3350/3450/3550/3555/3750 **Setup And Features Information**

About Warnings

MARNING: A WARNING indicates a potential for property damage, personal injury, or death.

Front and Back View — Vostro 3350




Figure 1. Vostro 3350 — Front View

- 1. microphones (2)
- 2. camera
- 3. camera LED

- 4. display
- 5. Windows Mobility Center
- 6. Dell Support Center





Regulatory Model: : P13E, P13S, P16F, P19G Regulatory Type: : P13E001, P13S001, P16F001, P16F002, P19G001

- 7. Dell Instant Launch Manager
- 8. security slot
- 9. cooling vents
- 10. VGA connector
- 11. HDMI connector
- 12. eSATA/USB combo connector with **USB PowerShare**
- 13. audio connectors
- 14. fingerprint reader

- 15. 8-in-1 memory card reader
- 16. touchpad
- 17. touchpad buttons (2)
- 18. device status lights
- 19. touchpad disable LED
- 20. keyboard
- 21. power button




Figure 2. Vostro 3350 - Back View

- 1. cooling vents
- 2. battery
- 3. AC adapter connector
- 4. USB 3.0 connectors (2)

- 5. network connector
- 6. optical drive/bay
- 7. optical drive eject button



MARNING: Do not block, push objects into, or allow dust to accumulate in the air vents. Do not store your Dell computer in a low-airflow environment, such as a closed briefcase, while it is running. Restricting the airflow can damage the computer or cause a fire. The computer turns on the fan when the computer gets hot. Fan noise is normal and does not indicate a problem with the fan or the computer.

Front and Back View — Vostro 3450




Figure 3. Vostro 3450 — Front View

- 1. microphones (2)
- 2. camera
- 3. camera LED
- 4. display
- 5. Windows Mobility Center
- 6. Dell Support Center
- 7. Dell Instant Launch Manager
- 8. USB 3.0 connector
- 9. audio connectors
- 10. optical drive/bay

- 11. optical drive eject button
- 12. fingerprint reader
- 13. touchpad
- 14. touchpad buttons (2)
- 15. device status lights
- 16. touchpad disable LED
- 17. keyboard
- 18. power button




Figure 4. Vostro 3450 — Back View

- 1. network connector
- 2. USB 3.0 connector
- 3. battery
- 4. security cable slot
- 5. AC adapter connector
- 6. VGA connector
- 7. cooling vents

- 8. HDMI connector
- 9. e-SATA connector
- 10. USB 2.0 connector
- 11. 8-in-1 memory card reader
- 12. ExpressCard slot



WARNING: Do not block, push objects into, or allow dust to accumulate in the air vents. Do not store your Dell computer in a low-airflow environment, such as a closed briefcase, while it is running. Restricting the airflow can damage the computer or cause a fire. The computer turns on the fan when the computer gets hot. Fan noise is normal and does not indicate a problem with the fan or the computer.

Front and Back View — Vostro 3550/3555




Figure 5. Vostro 3550/3555 — Front View

- 1. microphones (2)
- 2. camera
- 3. camera LED
- 4. display
- 5. Windows Mobility Center
- 6. Dell Support Center
- 7. Dell Instant Launch Manager
- 8. USB 3.0 connector
- 9. audio connectors
- 10. optical drive/bay

- 11. optical-drive eject button
- 12. fingerprint reader
- 13. ExpressCard slot
- 14. touchpad
- 15. touchpad buttons (2)
- 16. device status lights
- 17. touchpad disable LED
- 18. keyboard
- 19. power button



Figure 6. Vostro 3550/3555 — Back View

- 1. security cable slot
- 2. network connector
- 3. USB 3.0 connector
- 4. battery
- 5. VGA connector
- 6. AC adapter connector
- 7. USB 2.0 connector (Vostro 3550) / USB 3.0 connector (Vostro 3555)

- 8. cooling vents
- 9. HDMI connector
- 10. e-SATA connector
- 11. 8-in-1 memory card reader



MARNING: Do not block, push objects into, or allow dust to accumulate in the air vents. Do not store your Dell computer in a low-airflow environment, such as a closed briefcase, while it is running. Restricting the airflow can damage the computer or cause a fire. The computer turns on the fan when the computer gets hot. Fan noise is normal and does not indicate a problem with the fan or the computer.

Front and Back View — Vostro 3750




Figure 7. Vostro 3750 — Front View

- 1. microphones (2)
- 2. camera
- 3. camera LED
- 4. display
- 5. Windows Mobility Center
- 6. Dell Support Center
- 7. Dell Instant Launch Manager
- 8. USB 2.0 connector
- 9. USB 3.0 connectors (2)
- 10. optical drive/bay

- 11. optical-drive eject button
- 12. fingerprint reader
- 13. ExpressCard slot
- 14. touchpad
- 15. touchpad buttons (2)
- 16. device status lights
- 17. touchpad disable LED
- 18. keyboard
- 19. power button




Figure 8. Vostro 3750 — Back View

- 1. network connector
- 2. VGA connector
- 3. battery
- 4. security cable slot
- 5. AC adapter connector
- 6. cooling vents

- 7. e-SATA connector
- 8. HDMI connector
- 9. audio connectors
- 10. 8-in-1 memory card reader

Δ

WARNING: Do not block, push objects into, or allow dust to accumulate in the air vents. Do not store your Dell computer in a low-airflow environment, such as a closed briefcase, while it is running. Restricting the airflow can damage the computer or cause a fire. The computer turns on the fan when the computer gets hot. Fan noise is normal and does not indicate a problem with the fan or the computer.

Quick Setup



WARNING: Before you begin any of the procedures in this section, read the safety information that shipped with your computer. For additional best practices information, see www.dell.com/regulatory_compliance.

WARNING: The AC adapter works with electrical outlets worldwide. However, power connectors and power strips vary among countries. Using an incompatible cable or improperly connecting the cable to the power strip or electrical outlet may

cause fire or equipment damage.

CAUTION: When you disconnect the AC adapter cable from the computer, grasp the connector, not the cable itself, and pull firmly but gently to avoid damaging the cable. When you wrap the AC adapter cable, ensure that you follow the angle of the connector on the AC adapter to avoid damaging the cable.

NOTE: Some devices may not be included if you did not order them.

NOTE: Fingerprint Reader drivers/applications are available for Windows 7 only.

 Connect the AC adapter to the AC adapter connector on the computer and to the electrical outlet.




Figure 9. AC Adapter

2. Connect the network cable.





Figure 10. Network Connector

3. Connect USB devices, such as a mouse or keyboard.






Figure 11. USB Connector

4. Open the computer display and press the power button to turn on the computer.



Figure 12. Power Button



NOTE: It is recommended that you turn on and shut down your computer at least once before you install any cards or connect the computer to a docking device or other external device, such as a printer.

Specifications



NOTE: Offerings may vary by region. The following specifications are only those required by law to ship with your computer. For more information regarding the configuration of your computer, click $\mathbf{Start} \to \mathbf{Help}$ and $\mathbf{Support}$ and select the option to view information about your computer.

System Information

Chipset:

Vostro 3350 / 3450 / 3550 / 3750 Intel HM67

Vostro 3555 AMD A70M

Processor:

Vostro 3350 / 3450 / 3550 / 3750

- Intel Core i3 / i5 series
- Intel Core i7 (Quad-Core for Vostro 3750 only)

Vostro 3555

· AMD Dual Core

System Information

AMD Quad Core

Video

Video type

integrated on system board

discrete video card

Video controller and memory

UMA:

Vostro 3350 / 3450 / 3550 / 3750

Intel Graphics Media Accelerator HD

Vostro 3555

AMD Radeon HD series — up to 256 MB / 512

MB of shared memory

Discrete

- AMD Radeon HD7470 GDDR5 1 GB or AMD Radeon HD7650 - 1 GB VRAM (Vostro 3350 and Vostro 3450)
- AMD Radeon HD7650 1 GB VRAM (Vostro 3550)
- NVIDIA GeForce GT 525M 1 GB (Vostro 3750 only)

Memory

Memory connector

two SODIMM slots

Memory capacity

1 GB, 2 GB, and 4 GB

Memory type

DDR3 SDRAM with 1333 MHz

Minimum memory

2 GB

Maximum memory

8 GB



NOTE: Only 64-bit operating systems can detect memory capacities greater than 4 GB.

Battery

Vostro 3350

Type

4-cell "smart" lithium ion (2.8 Ah)

Battery

8-cell "smart" lithium ion (2.8 Ah)

Dimensions:

Depth

4-cell / 8-cell — 43.45 mm (1.71 inches)

Height

4-cell — 19.10 mm (0.75 inch)

8-cell — 42.36 mm (1.67 inches)

Width

4-cell — 199.10 mm (7.84 inches)

8-cell — 270.00 mm (10.63 inches)

Weight

4-cell — 230.00 g (0.51 lb)

8-cell — 446.00 g (0.98 lb)

Voltage

14.8 VDC

Vostro 3450 / 3550 / 3555

Type

6-cell "smart" lithium ion (2.2 Ah)

9-cell "smart" lithium ion (2.8 Ah)

Dimensions:

Depth

6-cell / 9-cell — 57.80 mm (2.27 inches)

Height

6-cell — 20.80 mm (0.81 inch)

9-cell — 40.15 mm (1.58 inches)

Width

6-cell / 9-cell — 255.60 mm (10.06 inches)

Weight

6-cell — 340.00 g (0.75 lb)

9-cell — 504.50 g (1.11 lb)

Voltage

11.1 VDC

Vostro 3750

Type

6-cell "smart" lithium ion (2.6 Ah)

9-cell "smart" lithium ion (2.8 Ah)

Dimensions:

Battery

Depth

6-cell / 9-cell — 57.80 mm (2.27 inches)

Height

6-cell — 20.80 mm (0.82 inch)

9-cell — 40.15 mm (1.58 inches)

Width

6-cell/9-cell — 255.60 mm (10.06 inches)

Weight

6-cell — 340.00 g (0.75 lb)

9-cell — 504.50 g (1.11 lb)

Voltage

11.1 VDC

Temperature range:

Operating

0 °C to 35 °C (32 °F to 95 °F)

Non-operating

-40 °C to ~65 °C (-40 °F to ~149 °F)

Coin-cell battery

3 V CR2032 lithium ion

AC Adapter

Input voltage

100 VAC to 240 VAC

Input current (maximum)

1.5 A / 1.6 A / 1.7 A / 2.3 A / 2.5 A

Input frequency

50 Hz to 60 Hz

Output power

65 W, 90 W, or 130 W

NOTE: 130 W AC adapter is available for

Vostro 3750 only.

Output current

65 W

• 4.34 A (maximum at 4-second pulse)

3.34 A (continuous)

90 W

5.62 A (maximum at 4-second pulse)

4.62 A (continuous)

130 W

6.70 A (continuous)

Rated output voltage

19.5 +/- 1.0 VDC

AC Adapter

Dimensions:

Height

65 W - 28.30 mm (1.11 inches)

90 W - 22.60 mm (0.88 inch)

130 W — 25.40 mm (1.00 inch)

Width

65 W — 137.20 mm (5.40 inches)

90 W — 147.00 mm (5.78 inches)

130 W — 154.70 mm (6.09 inches)

Depth

65 W — 57.80 mm (2.27 inches)

90 W — 70.00 mm (2.75 inches)

130 W — 76.20 mm (3.00 inches)

Temperature:

Operating

0 °C to 35 °C (32 °F to 95 °F)

Non Operating

-40 °C to 65 °C (-40 °F to 149 °F)

Physical

Vostro 3350

Height 27.30 mm to 29.80 mm (1.07 inches to 1.17

inches)

Width 329.20 mm (12.96 inches)

Depth 228.50 mm (9.00 inches)

Weight (minimum) 2.04 kg (4.50 lb)

Vostro 3450

Height 30.60 mm to 33.20 mm (1.20 inches to 1.31

inches)

Width 343.00 mm (13.50 inches)

Depth 245.80 mm (9.68 inches)

Weight (minimum) 2.28 kg (5.02 lb)

Physical

Vostro 3550/3555

Height 30.40 mm to 34.80 mm (1.20 inches to 1.37

inches)

Width 375.40 mm (14.78 inches)

Depth 260.20 mm (10.24 inches)

Weight (minimum) 2.47 kg (5.45 lb)

Vostro 3750

Height 30.80 mm to 34.80 mm (1.21 inches to 1.37

inches)

Width 418.40 mm (16.47 inches)

Depth 286.70 mm (11.29 inches)

Weight (minimum) 3.00 kg (6.62 lb)

Environmental

Temperature:

Operating 10 °C to 35 °C (50 °F to 95 °F)

-40 °C to 65 °C (-40 °F to 149 °F)

Relative humidity (maximum):

Operating 10 % to 90 % (noncondensing)
Storage 5 % to 95 % (noncondensing)

Airborne contaminant level G1 or lower as defined by ISA-S71.04–1985

Finding More Information and Resources

See the safety and regulatory documents that shipped with your computer and the regulatory compliance website at **www.dell.com/regulatory_compliance** for more information on:

- · Safety best practices
- Regulatory certification
- · Ergonomics

See www.dell.com for additional information on:

- Warranty
- Terms and Conditions (U.S. only)
- End User License Agreement

Additional information on your product is available at support.dell.com/manuals.

Information in this publication is subject to change without notice.

© 2012 Dell Inc. All rights reserved.

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: Dell™, the DELL logo, Dell Precision™, Precision ON™, ExpressCharge™, Latitude™, Latitude ON™, OptiPlex™, Vostro™, and Wi-Fi Catcher™ are trademarks of Dell Inc. Intel®, Pentium®, Xeon®, Core™, Atom™, Centrino®, and Celeron® are registered trademarks or trademarks of Intel Corporation in the U.S. and other countries. AMD® is a registered trademark and AMD Opteron™, AMD Phenom™, AMD Sempron™, AMD Athlon™, ATI Radeon™, and ATI FirePro™ are trademarks of Advanced Micro Devices, Inc. Microsoft®, Windows®, MS-DOS®, Windows Vista®, the Windows Vista start button, and Office Outlook® are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. Blu-ray Disc™ is a trademark owned by the Blu-ray Disc Association (BDA) and licensed for use on discs and players. The Bluetooth® word mark is a registered trademark and owned by the Bluetooth® SIG, Inc. and any use of such mark by Dell Inc. is under license. Wi-Fi® is a registered trademark of Wireless Ethernet Compatibility Alliance, Inc.

Other trademarks and trade names may be used in this publication to refer to either the entities claiming the marks and names or their products, Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.