

Bluetooth™ Splitter



- Bluetooth 2.1+EDR transmitter for any audio source
- Can pair with two sets of Bluetooth headphones
- Sends the audio output simultaneously to two paired headphones




FEATURES:

- Bluetooth 2.1+EDR transmitter for any audio source
- Can pair with two sets of Bluetooth headphones
- Sends the audio output simultaneously to two paired headphones

CHARGING THE SPLITTER:

This Bluetooth device uses a rechargeable battery. You must charge the battery fully before using the device for the first time.

1. Plug the USB cable into the computer or USB power source
2. Connect the USB cable to the Bluetooth Splitter as shown below. The LED will glow Red, indicating that the battery is being charged.
3. When the battery is fully charged, the Red LED will turn off.



*** IMPORTANT:** The dongle cannot be used while charging.

BASIC OPERATIONS

Plug the 3.5mm plug on Bluetooth Splitter into 3.5mm headphone jack of an audio device.

Turning the Splitter on/off

1.To Turn the Splitter On

Press and hold the Power Button for about 2 seconds. The blue LED on the splitter will flash for 1 second. The splitter is now turned on.

2. To Turn the Splitter Off

Press and hold the Power Button for about 5 seconds. The red LED on the splitter will flash for 1 second. The splitter is now turned off.

3. When the blue LED indicator flashes red, it means that the battery is low and needs to be charged.

Pairing

Before using your splitter for the first time, you must pair it with your Bluetooth stereo headset(s).

1. Ensure that the splitter is on, as described above. Put your Bluetooth Stereo Headset into pairing mode.
2. Press and hold the Power Button on the splitter for about 2 seconds until the indicator light alternately flashes blue and red. The splitter is now in pairing mode.
3. After a few seconds, the splitter and headset will connect.

To pair a second Bluetooth stereo headset, simply repeat the above steps for the second headset.

After the second headset is connected, press the Power Button on the splitter twice to reconnect the first Bluetooth headset.

Note: You can connect both headsets at the same time. To do so, ensure both headsets are on in the first step above. The two headsets will simultaneously connect and pair with the splitter.

Storing the Splitter

- Always store the splitter with the power off.
- Avoid storage at temperatures in excess of +140°F, such as in a hot vehicle. Do not leave in direct sunlight.
- Do not expose the splitter or any of its supplied parts to rain or other liquids.

Specifications

- Bluetooth Version 2.1+EDR Specifications, Class II
- Supports Bluetooth A2DP & AVRCP Profiles and Bluetooth Stereo Headsets
- Connect with two Bluetooth devices simultaneously
- Built-in lithium-ion battery
- Operating Range: Up to 30 feet (10 meters)
- Frequency: 2.40~2.48GHz
- Charging Time: approximate to 2 hours*
- Play Time: Up to 9 hours*
- Standby Time: Up to 180 hours*
- Dimensions (LxWxD): 1.9" x 0.8" x 0.4" (49.5 x 20.5 x 11 mm)
- Weight: 0.7 oz. (19.2g)

*Depending on the phone type and usage, the actual time may vary.

Correct disposal of this product



(Waste Electrical & Electronic Equipment)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Bluetooth[®] is a trademark owned by Bluetooth SIG, Inc.