


Gigaset

QV830

Quick Start Guide

1 Overview



- 1 Volume Button
- 2 Micro USB Port
- 3 Microphone
- 4 Headphone Jack
- 5 Micro SD Slot

- 6 Power Button
- 7 Front Camera
- 8 Rear Camera
- 9 Reset Button
- 10 Speaker

2 Turning your Tablet on




- ◆ Press the **Power** button and hold for a few seconds.




- ◆ Slide the **Unlock** icon to the right.


3 Connecting to a WiFi Network




- ◆ Available WiFi network found.




- ◆ Touch the **All Apps** icon.




- ◆ Touch the **Settings** icon.



- ◆ Touch to select Wi-Fi.



- ◆ Select your desired WiFi connection.
- ◆ You may be asked to enter the WiFi password.




- ◆ Touch to enter the password.




- ◆ WiFi connection has been successfully established.

4 Opening an Application




- ◆ Touch the **All Apps** icon. 
- ◆ Touch the application you want to open.

5 Transferring Files between Tablet and Computer



- ◆ Use the included Micro USB cable to connect tablet and computer.
Tip: Install "Windows Media Player 11" if Windows XP or an earlier version is installed on your computer.




- ◆ Select drive "Gigaset QV830" to see the files stored on the tablet and to transfer files between tablet and computer.
- ◆ Disconnect cable when finished.
- ◆ For more information, visit: www.gigaset.com/service

6 Turning your Tablet off



- ◆ Press and hold the **Power** button until the dialogue box below appears.



- ◆ Touch to select **Power off**.





Selecting the Language

To change the language:

- ▶  Application screen ▶  **Settings** ▶  **Language & input** ▶ **Language** ▶ Select language.

Online Help

- ▶  Application screen ▶  **Help**.

Battery charging

- ▶ Battery charging in power-off mode is more efficient.

Issued by

Gigaset Communications GmbH
Frankenstr. 2a, D-46395 Bocholt


© Gigaset Communications GmbH 2013

Subject to availability.

All rights reserved. Rights of modification reserved.

www.gigaset.com

Google, Google Play, Android and other marks are trademarks of Google Inc.



A31008-N1166-R101-4-X143