



00083099 Hama adapter for Samsung TV scart clutch - Samsung plug

Compatible TVs with the required connector input

There are a few models that do not have a Samsung specific connector for this Scart adapter. This list contains the most common TV models that are compatible so you can determine if the adapter is suitable for your TV or not. Please note that new ones may have been added in the meantime that are not yet included in this list.

As of: 22.05.2013

- 1. Flat screen TV Samsung UE46C6000**
- 2. Flat screen TV Samsung UE46C6700**
- 3. Flat screen TV Samsung UE46C6740**
- 4. Flat screen TV Samsung UE46C6710**
- 5. Flat screen TV Samsung UE46C6730**
- 6. Flat screen TV Samsung UE46C5100**
- 7. Flat screen TV Samsung UE55C7700**
- 8. Flat screen TV Samsung UE55C8780**
- 9. Flat screen TV Samsung UE37C6000**
- 10. Flat screen TV Samsung UE37C6700**
- 11. Flat screen TV Samsung UE40C5100**
- 12. Flat screen TV Samsung UE37C6740**
- 13. Flat Screen TV LG Electronics 47SL9500**
- 14. Flat screen TV Samsung UE46C6200**
- 15. Flat screen TV Samsung UE37C6800**
- 16. Flat screen TV Samsung UE40C6200**

17. Flat screen TV Samsung UE37C6820
18. Flat screen TV Samsung UE46C6820
19. Flat screen TV Samsung UE46C6800
20. Flat screen TV Samsung UE46C8790
21. Flat screen TV Samsung UE46C8780
22. Flat screen TV Samsung UE46B7000WWXXC
23. Flat screen TV Samsung UE46C8700
24. Flat screen TV Samsung UE46C7700
25. Flat screen TV LG Electronics 42LH9000
26. Flat screen TV Samsung UE55C9090
27. Flat screen TV Samsung UE46C9090
28. Flat screen TV Samsung UE40C9090
29. Flat Screen TV LG Electronics 47LH9000
30. Flat screen TV Samsung UE37B6000
31. Flat Screen TV Samsung UE55B7020
32. Flat Screen TV Samsung UE55B7000
33. Flat screen TV Samsung UE32B7020
34. Flat Screen TV Samsung UE46B7020
35. Flat Screen TV Samsung UE32B7000
36. Flat screen TV Samsung UE40B7020
37. Flat screen TV Samsung UE32C6200
38. Flat screen TV Samsung UE46B8000
39. Flat screen TV Samsung UE46B8090
40. Flat Screen TV Samsung UE32B6000
41. Flat Screen TV Samsung UE40B8000
42. Flat screen TV Samsung UE46B6000

43. Flat screen TV Samsung UE26C4000
44. Flat screen TV Samsung UE40B6000
45. Flat Screen TV Samsung UE46C5700
46. Flat screen TV Samsung UE37C6200
47. Flat Screen TV LG Electronics 42SL9000
48. Samsung UE22C4000 flat screen TV
49. Flat screen TV Samsung UE40C6710
50. Flat Screen TV Samsung UE37C5100
51. Flat Screen TV Samsung UE55C6200
52. Samsung UE22C4010 flat screen TV
53. Flat screen TV Samsung UE40C6000
54. Flat screen TV Samsung UE40C6740
55. Flat Screen TV Samsung UE40C6730
56. Flat Screen TV LG Electronics 42SL9500
57. Flat Screen TV Samsung UE32C5700
58. Flat Screen TV Samsung UE32C6700
59. Flat Screen TV Samsung UE19C4000
60. Flat screen TV Samsung UE32C6000
61. Flat Screen TV Samsung UE32C4000
62. Flat screen TV Samsung UE32C5100
63. Flat screen TV Samsung UE32B7090
64. Flat Screen TV Samsung UE40B7090
65. Flat Screen TV Samsung UE46B7090

- 66. Flat Screen TV Samsung UE55B7090**
- 67. Flat Screen TV Samsung UE40B8090**
- 68. Flat Screen TV Samsung UE55C6000**
- 69. Flat screen TV Samsung UE55C6700**
- 70. Flat screen TV Toshiba 46 SL 733 G**
- 71. Flat screen TV Samsung UE32C6800**
- 72. Flat screen TV Samsung UE32C6740**
- 73. Flat Screen TV Samsung UE32C6820**
- 74. Flat screen TV Samsung UE32C6730**
- 75. Flat Screen TV Samsung UE32C6710**
- 76. Flat screen TV Panasonic TX-L32D25E**
- 77. Flat Screen TV LG Electronics 47SL9000**
- 78. Flat screen TV Samsung UE32C8790**
- 79. Flat screen TV Samsung UE40C8700**
- 80th flat screen TV Samsung UE65C8790**
- 81. Flat screen TV Samsung UE40C6800**
- 82. Flat screen TV Samsung UE40C6820**
- 83. Flat screen TV Samsung UE40C8790**
- 84. Samsung UE55C8790 flat screen TV**
- 85. Flat Screen TV Samsung UE40C7700**