

Hitachi Projector Accessories

Reference Guide



Lenses

For CPX10000/CPWX11000/CPSX12000

USL-801



Ultra short lens

SL-802



Short 1 lens

SL-803



Short 2 lens

SD-804



Standard lens

LL-805



Long lens

UL-806



Ultra long lens

For CPX505/X605/X608/X615/WX625/SX635/X705/X807/X809

FL601



Wide-fixed lens

SL602



Short zoom lens

LL603



Long throw zoom lens

UL604



Ultra long zoom lens

Lamps: Business Projectors

Ultra Portable Multi Purpose Installation

| | | | |
|---|---|--|---|
| DT00821 <ul style="list-style-type: none">• CPX3 • CPX5 • CPX264 | DT00781 <ul style="list-style-type: none">• CPX1 • CPX2• CX4 • CPRX70 | DT00701 <ul style="list-style-type: none">• CPRS55 • CPRS56 • CPRX60• CPRX61 • CPRS57 | DT01081 <ul style="list-style-type: none">• CPRX78 |
| DT01051 <ul style="list-style-type: none">• CPX4020 | DT01022 <ul style="list-style-type: none">• CPRX80 | DT01021 <ul style="list-style-type: none">• CPX2510E • CPX2510EN• CPX3010E • CPX3010EN• EDX40 • EDX42 | DT00911 <ul style="list-style-type: none">• CPX301 • CPX306 • CPX401• CPX450 • EDX31 • EDX33• CPWX410 • CPX467 |
| DT00893 <ul style="list-style-type: none">• EDA101 • EDA111 | DT00891 <ul style="list-style-type: none">• CPA100 • EDA100 • EDA110 | DT00841 <ul style="list-style-type: none">• CPX205 • CPX400 • CPX300• CPX305 • CPX308 • CPX417• EDX30 • EDX32 | DT00781 <ul style="list-style-type: none">• EDX20 • EDX22• MPJ1 • CPX253 |
| DT00757 <ul style="list-style-type: none">• EDX10 • EDX12 • EDX15 | DT00751 <ul style="list-style-type: none">• CPX260 • CPX265 • CPX268 | DT00731 <ul style="list-style-type: none">• CPS240 • CPX250 • CPX255• EDX8250 • EDX8255 | DT00691 <ul style="list-style-type: none">• CPX445 • CPX440 • CPX444 |
| DT00671 <ul style="list-style-type: none">• CPS335 • CPX340 • CPX345• CPX3350 • CPX3400 • CPX3450 | DT00621 <ul style="list-style-type: none">• CPS235 | DT00581 <ul style="list-style-type: none">• CPS210 | DT00471 <ul style="list-style-type: none">• CPX430 |
| DT00461 <ul style="list-style-type: none">• CPX275 • CPX327• EDX3250 • EDX3270 | DT00431 <ul style="list-style-type: none">• CPX380 • CPX385 • CPS370 | DT00401 <ul style="list-style-type: none">• CPS225(A) • CPS317 • CPS318• CPX328 • EDS3170 • EDX3280 | DT00331 <ul style="list-style-type: none">• CPX325 • CPS310 • CPX320 |
| DT00301 <ul style="list-style-type: none">• CPS220 • CPS220(A) • CPX270 | DT00236 <ul style="list-style-type: none">• CPX940B • CPX938B• CPS840B • CPS845 | DT00205 <ul style="list-style-type: none">• CPX940 • CPX938• CPS840 • CPS40A | DT01001 <ul style="list-style-type: none">• CPX10000 • CPWX11000• CPSX12000 |
| DT00873 <ul style="list-style-type: none">• CPWX625 • CPSX635 | DT00871 <ul style="list-style-type: none">• CPX807 • CPX705• CPX809 • CPX615 | DT00771 <ul style="list-style-type: none">• CPX505 • CPX605 • CPX608 | DT00601 <ul style="list-style-type: none">• CPX1250 • CPSX1350 |
| DT00591 <ul style="list-style-type: none">• CPX1200A | DT00571 <ul style="list-style-type: none">• CPX870 | DT00531 <ul style="list-style-type: none">• CPX880 • CPX885 | DT00491 <ul style="list-style-type: none">• CPX990 • CPX995 |

Lamps: Home Projectors

■ Installation ■ Home

| | | | |
|---|--|--|--|
| <p>DT00421</p> <ul style="list-style-type: none"> • CPSX5500 • CPSX5600 | <p>DT00341</p> <ul style="list-style-type: none"> • CPX930 • CPX985 | <p>DT00231</p> <ul style="list-style-type: none"> • CPS860 • CPX958 • CPX960 • CPX970 | <p>DT00707</p> <ul style="list-style-type: none"> • PJLC9 • EDPJ32 |
| <p>DT00701</p> <ul style="list-style-type: none"> • PJLC7 | <p>DT00665</p> <ul style="list-style-type: none"> • PJTX200 • PJTX300 | <p>DT00661</p> <ul style="list-style-type: none"> • PJTX100 | <p>DT00611</p> <ul style="list-style-type: none"> • PJTX10 |
| <p>DT00581</p> <ul style="list-style-type: none"> • PJLC5 | <p>DT00301</p> <ul style="list-style-type: none"> • PJLC2001 <i>(replaced DT00381)</i> | | |

Remote Controls

■ Ultra Portable ■ Multi Purpose ■ Professional ■ Installation ■ Home

| | | | |
|--|--|---|--|
|  <p>HL02483</p> <ul style="list-style-type: none"> • CPX3 |  <p>HL02228</p> <ul style="list-style-type: none"> • CPRX70 |  <p>HL02224</p> <ul style="list-style-type: none"> • CPX1 • CPX2 • CPX4 • CPX5 |  <p>HL02151</p> <ul style="list-style-type: none"> • CPRS55 • CPRS56 • CPRX60 • CPRX61 • CPRS57 |
|  <p>HL02488</p> <ul style="list-style-type: none"> • EDA101 • EDA111 |  <p>HL02483</p> <ul style="list-style-type: none"> • CPX301 • CPX306 • CPX401 • CPX450 • CPX467 • CPWX410 • CPRX78 • CPRX80 • CPX2510E • CPX2510EN • CPX3010E • CPX3010EN • CPX4020 • EDX31 • EDX33 • EDX40 • EDX42 |  <p>HL02482</p> <ul style="list-style-type: none"> • CPA100 • EDA100 • EDA110 |  <p>HL02227</p> <ul style="list-style-type: none"> • CPX205 • CPX300 • CPX305 • CPX308 • CPX400 • CPX417 • EDX30 • EDX32 |
|  <p>HL02224</p> <ul style="list-style-type: none"> • CPX253 • EDX20 • EDX22 • MPJ1 |  <p>HL02221</p> <ul style="list-style-type: none"> • CPX260 • CPX265 • CPX268 • EDX10 • EDX12 • EDX15 |  <p>HL02208</p> <ul style="list-style-type: none"> • CPS240 • CPX250 • CPX255 • EDX8250 |  <p>HL02204</p> <ul style="list-style-type: none"> • CPX440 • CPX444 |

Remote Controls

Ultra Portable
Multi Purpose
Professional
Installation
Home

| | | | |
|---|---|--|--|
|  <p>HL01898</p> <ul style="list-style-type: none"> • CPS235 • CPS335 • CPX340 • CPX345 • EDS3350 • EDX3400 • EDX3450 |  <p>HL01894</p> <ul style="list-style-type: none"> • CPS210 |  <p>HL01891</p> <ul style="list-style-type: none"> • CPS317 • CPS318 • CPX327 • CPX328 • EDS3170 • EDX3250 • EDX3270 • EDX3280 |  <p>HL01883</p> <ul style="list-style-type: none"> • CPX445 <p>LASER</p> |
|  <p>HL01841</p> <ul style="list-style-type: none"> • CPX430W • CPSX5500 • CPSX5600 <p>LASER</p> |  <p>HL01791</p> <ul style="list-style-type: none"> • CPX380 • CPX385 <p>LASER</p> |  <p>HL01451</p> <ul style="list-style-type: none"> • CPX320 • CPX325 <p>LASER</p> |  <p>HL01441</p> <ul style="list-style-type: none"> • CPS220 • CPS225 • CPX270 • CPX275 • CPS310 • CPS370 |
|  <p>HR01</p> <p>Transmitter plus USB receiver & laser pointer</p> <p>LASER</p> |  <p>TR01</p> <p>Teachers Remote</p> |  <p>HL02198</p> <ul style="list-style-type: none"> • CX10000 • CPWX11000 • CPSX12000 <p>LASER</p> |  <p>HL02197</p> <ul style="list-style-type: none"> • CPSX635 • CPX809 <p>LASER</p> |
|  <p>HL02196</p> <ul style="list-style-type: none"> • CPWX625 <p>LASER</p> |  <p>HL02194</p> <ul style="list-style-type: none"> • CPX505 • CPX605 • CPX608 • CPX807 • CPX705 • CPX615 <p>LASER</p> |  <p>HL02003</p> <ul style="list-style-type: none"> • CPSX1350 • CPX1200 • CPX1250 <p><i>(replaced HL02001)</i></p> <p>LASER</p> |  <p>HL01881</p> <ul style="list-style-type: none"> • CPX880 • CPX885 • CPX870 <p>LASER</p> |
|  <p>HL01811</p> <ul style="list-style-type: none"> • CPX990 • CPX995 <p>LASER</p> |  <p>HL01453</p> <ul style="list-style-type: none"> • CPX980 • CPX985 <p>LASER</p> |  <p>HL02151</p> <ul style="list-style-type: none"> • PJLC7 • PJLC9 |  <p>HL02104</p> <ul style="list-style-type: none"> • PJTX200 • PJTX300 |
|  <p>HL02101</p> <ul style="list-style-type: none"> • PJTX100 |  <p>HL01981</p> <ul style="list-style-type: none"> • PJTX10 |  <p>HL01894</p> <ul style="list-style-type: none"> • PJLC5 |  <p>HL01441</p> <ul style="list-style-type: none"> • PJLC2001 |

Carrying Cases

■ Hard Cases ■ Soft Cases

FLC800



Int. Dimensions:
440 x 320 x 125 (bottom)
440 x 320 x 55mm (top)

Ext. Dimensions:
505 x 340 x 235mm
Includes outer pockets

FLC300A



Int. Dimensions:
470 x 310 x 70mm

Ext. Dimensions:
470 x 310 x 90mm

FLC200



Int. Dimensions:
390 x 285 x 55mm

Ext. Dimensions:
420 x 320 x 115mm

SC400



Int. Dimensions:
390 x 280 x 130mm

Ext. Dimensions:
410 x 305 x 160mm
Includes outer pockets

SC300



Int. Dimensions:
330 x 255 x 75mm

Ext. Dimensions:
330 x 270 x 140mm
Includes outer pockets

SC120



Ext. Dimensions:
450 x 305 x 150mm
Includes outer pockets

SC100



Ext. Dimensions:
380 x 260 x 90mm

Projector Cable Cover

CC10000



- CPX10000 • CPWX11000 • CPSX12000

Lens Adapter

KU00041



- CPX10000 • CPWX11000
- CPSX12000

Smoke Filters

SF200

Spare filters for the SFUS200 (12 pieces)
For CPS225/CPX275

SF101

Spare filter for the SRC101 (1 piece)
For CPX880/CPX885

SFC10S

Spare filter for the SFUC10 (1 piece)
For CPS210

Wall Brackets

S001 Short Arm - for screen sizes up to 80"
L001 Long Arm - for screen sizes up to 100"



(S001 Short Arm)

- Mounts for: • CPA100 • EDA100 • EDA110 • EDA101 • EDA111

Table Top Kit

TT100



- CPA100 • EDA100 • EDA110

Projector Control Box

CTRL001



Wall mounted control unit with manual and automatic on/off and source selection functions.
Compatible with all current and the majority of legacy projectors.

Wireless SDIO Card

VA08331



- CPX417 • CPX807

M1-D Cable

EZ01661



Connects M1 socket on Projector to
DVI and USB on PC for Video signal
and Mouse control

HITACHI DIGITAL MEDIA
Hitachi Europe Ltd
Whitebrook Park, Lower Cookham Road,
Maidenhead, Berkshire SL6 8YA
United Kingdom
Tel: +44 (0)1628 585 000 Fax: +44 (0)1628 585 500
www.hitachidigitalmedia.com

Design and specifications are subject to change without notice.

HITACHI
Inspire the Next