## Important info.:


- Do not unplug or move phones to other jacks or wall plates.
   \*Open a helpdesk ticket at <a href="https://www.fau.edu/helpdesk">www.fau.edu/helpdesk</a> for all phone, fax, and analog line moves.
- View and download complete Openstage 40 and 20 User Guides and Quick Reference Guides at http://www.fau.edu/irm/phone/phone features.php
- Your programmed line appearances may not appear until everyone has moved into the new bldg.
- Support Services at 7.6235 is avail. Monday Friday from 8 am to 5 pm for assistance

## SIEMENS

Telephone Reference Guide OpenScape Voice – OpenStage 40


**FAU** 





NOTE: **SELECT = OK** on Touch Wheel

## Function Keys and Audio Keys



Key	Function during text input	Function when held down
<b>*</b> 🕁	Write special characters	Deactivate the ring tone.
#==	Switch between upper/lower case and digit entry.	Activate telephone lock.

(Below icons appear on Display Screen when feature is activated)

Display					
Components					
1:15pm 2222	Sat 07/27/07 HiPath 8000	Time and Date Own telephone number and menu icon			
1:15pm	07/27/07 (≠ 1	Time and Date A new entry in the call lists			

Icon	EXPLANATION
$oxed{\square}$	You have received one or more NEW MESSAGES
(≄	One or more new entries have been added to the CALL LIST
ţ.	CALL FORWARDING is active
•	The DO NOT DISTURB Function is active
+0	The PHONE LOCK is active

FEATURE	TOUCHWHEEL MENU/Button Options
ANSWERING AND PLACING A CALL via Handset Speaker Button or Headset	While telephone is ringing – Lift Handset OR Press the Speaker button. (Speaker LED will illuminate) OR Press the Headset button (Headset LED will illuminate) (icon appears in display)
Placing a call:  NOTE: All telephones have a "hot" keypad that allows immediate dialing without lifting receiver. This will automatically activate the SPEAKER option on each telephone. To move a call from speaker to handset, simply lift handset.  REDIAL  Enables user to select from their Redial list an internal/external number dialed  HOLD	EXTERNAL CALLS:  • Dial the 10-digit telephone number INTERNAL CALLS:  • Dial Internal Extension number only  • Press the REDIAL button  • Scroll ♦ to and select the number to redial  **NOTE: To return to the telephony MAIN MENU, press your MAILBOX BUTTON*  • LIGHTLY press the HOLD button (hold light will NOT illuminate)  • The Hold Icon will appear on the display next to call
Place a caller on hold .at your extension The HOLD ICON will appear in the display as the call is holding. (if applicable	NOTE: Do NOT replace handset in cradle. This will cancel the HOLD feature and call will "ring back."  To take the call OFF of HOLD: PRESS line button
TRANSFER Transfer a call to another party	<ul> <li>During a call, scroll (&gt;) to and select CONS/XFER         OR</li> <li>Scroll → to and select BLIND TRANSFER</li> <li>Dial the extension number, select OK         (If conducting a Blind Transfer, call is now transferred)</li> </ul>
* NOTE – If BLIND TRANSFER is selected, the call will immediately transfer to desired extension  CONSULT  Consult privately with a 2 <sup>nd</sup> party	<ul> <li>If CONSULTING or CONFERENCING</li> <li>Announce the call</li> <li>Hang up or Scroll → to and select:         <ul> <li>Alternate (toggles between the two calls)</li> <li>Complete Xfer (sends the call)</li> <li>Conference (joins all parties)</li> <li>Blind Transfer</li> </ul> </li> </ul>
CONFERENCE Create a Quick Conference Call (maximum of 16 parties)	<ul> <li>Blind Transfer</li> <li>Hold (places current connection on Hold)</li> <li>Disconnect &amp; Return (disconnects current connection and returns to call being transferred)</li> <li>If the party does not answer or does not want to join:</li> <li>Scroll \$\display\$ to and select Disconnect &amp; Return</li> </ul>

MUTE To temporarily deactivate the microphone on the handset or speakerphone.	<ul> <li>Press the Mute button</li> <li>The light on Mute button will illuminate to ensure feature is activated.</li> <li>To Deactivate mute, press the lit Mute button</li> <li>The light on the Mute button will deactivate</li> </ul>
FORWARDING	Right arrow to "more features" to program destinations

AUDIO SETTINGS ↓
Press the Program / MENU Button Access **USER** menu Scroll **♦** to and select **Audio** Scroll to and select **Volumes** or **Settings** Scroll ♦ to and select Ringer Melody
Scroll ♦ to and select tone 1 thru 8
Select Save & Exit and press OK