

# Video Repair Parts

This catalogue was updated 2023.

As items sell out, they become no longer available.

Please check our website for current price and availability.



■ VCR Parts .....	2	■ VCR Cassette Housings .....	64
■ VCR Heads .....	2	■ Akai .....	64
■ VCR Head Drums.....	3	■ Daewoo / Tempest .....	64
■ VCR Upper Drum Assembly.....	4	■ Funai / Teac / Palsonic .....	64
■ VCR Lower Drum Assembly.....	5	■ LG / Goldstar .....	64
■ Akai .....	5	■ JVC / Philips .....	64
■ Funai .....	5	■ Mitsubishi .....	65
■ JVC.....	5	■ Panasonic.....	65
■ Samsung .....	5	■ Samsung .....	65
■ Sharp.....	5	■ Sharp.....	66
■ AC Heads.....	6	■ Sanyo .....	66
■ Sony .....	6	■ Sony .....	66
■ Motors.....	7	■ VCR Tension Bands.....	67
■ Akai .....	7	■ Akai .....	67
■ Daewoo .....	8	■ Funai / Teac / Palsonic .....	67
■ Funai / Teac / Palsonic .....	8	■ JVC.....	67
■ Hitachi .....	8	■ Panasonic.....	68
■ JVC.....	8	■ NEC.....	68
■ LG / Goldstar .....	10	■ Samsung .....	68
■ Mitsubishi .....	11	■ Sanyo .....	68
■ NEC.....	11	■ Sharp.....	68
■ National .....	11		
■ Panasonic.....	12		
■ Samsung .....	13		
■ Sanyo .....	13		
■ Sharp.....	14		
■ Sony .....	17		
■ Video Belts .....	18	■ Mode Switches .....	69
■ Cross Reference .....	18	■ Akai .....	69
■ Belt Kits .....	20	■ Deitron / Tempest / Tracton .....	70
■ Video Belts & Idler Tyres .....	21	■ Funai / Teac .....	70
■ VCR Idler Tires .....	22	■ Goldstar .....	70
■ VCR Pinch Rollers .....	22	■ Hitachi .....	70
■ Akai .....	22	■ JVC.....	71
■ Daewoo .....	22	■ Mitsubishi .....	71
■ Funai / Teac.....	22	■ NEC.....	72
■ Goldstar / LG / NEC .....	23	■ National .....	72
■ Hitachi .....	23	■ Samsung .....	72
■ JVC / Philips .....	23	■ Sanyo .....	72
■ Mitsubishi .....	23	■ Sharp .....	73
■ NEC.....	23	■ Sony .....	74
■ Overhaul Replacement Kits .....	24	■ Push Button .....	74
■ Panasonic.....	24		
■ Philips / Teac .....	24		
■ Sharp.....	24		
■ Samsung .....	24		
■ Sanyo .....	24		
■ Sony .....	24		
■ Video Pinch Roller Listing .....	25		
■ VCR Overhaul Kits .....	26	■ Mode Sensors .....	75
■ JVC OEM .....	26	■ Universal Lamps.....	75
■ National Panasonic OEM .....	27	■ JVC.....	75
■ Overhaul Replacement Kits .....	28	■ Akai .....	75
■ VCR Idlers & Gears .....	29	■ Sharp .....	75
■ Akai .....	29	■ LG / Goldstar .....	75
■ Daewoo / NEC / AWA / Tempest .....	32	■ National .....	75
■ Funai / Teac / Palsonic .....	33	■ NEC .....	75
■ LG / Goldstar / NEC / Teac .....	34	■ OptoCouplers .....	75
■ Hitachi .....	36	■ JVC .....	75
■ JVC .....	37	■ Reel Sensor .....	75
■ Mitsubishi / AWA.....	42	■ Sharp .....	75
■ NEC.....	42	■ Infrared .....	75
■ NEC.....	43		
■ Panasonic.....	43		
■ Samsung .....	51		
■ Sanyo / Fisher / Sony .....	53		
■ Sharp.....	54		
■ Sony .....	60		
■ Toshiba.....	63		
■ Teac / Philips .....	63		

## Note!

This catalogue was updated 2023.  
As items sell out, they become no longer available. Please check our website for current price and availability.



# Video Repair Parts

VCR Parts  VCR Heads

## VIDEO HEADS - Full Listing

All VCR Heads are of OEM quality. Please be careful when replacing the heads, as physically damaged items are not covered under warranty. For a head not listed here, please enquire as there may be substitutes available. VH=Upper Drum Only VHD=Upper & Lower Drum with Motor.

Replaces	Equiv.	Models	Code
AKAI BV-V1004A280A	BV-V1022A170A	AKAIVS2, AKAIVS3, VP7100, VT55, VT77	VH50
AKAI BV-V1015A120A		AKAIVS6, VS8	VH57
AKAI BV-V1017A170A		AKAIVS4	VH53
AKAI BV-V1030A220D		VS105, VS112, VS115, VS116, VS125, VS126, VS201, VS202, VS220, VS240, VS301, VS303, VS304	VH55
AKAI BV-V1039A120A		VS12EA, VS15	VH270
AKAI BV-V1047A220A		VS155, VS165	VH56
AKAI BV-V1058A220B	BVV1058A220		VH280
AKAI BV-V1075A420B	BV-V1102A420E, V1123A420B	VS35, VS53, VS55, VS66, VS765, VSF30, VSF33, VSF400, VSF410, VSF430, VSF440, VSF441, VSG40, VSG43, VSG44, VSG45, VSG50, VSG51, VSG54, VSG55	VH59
AKAI BV-V1102A420D		VS965, VS967	VH286
AKAI BV-V1102A420G	BV-V1102A420C, V1102A420D	VS465, VSF12, VSF300, VSF301, VSG285A, VSG30, VSG305, VSG305EA, VSG315, VSG315EA, VSG33, VSG34, VSG35	VH285
AKAI BV-V1123A420C	CIRCUIT BOARD TYPE	VS75, VS75EA, VSA1100, VSA1110, VSA650, VSA77, VSA77A, VSF500, VSF510, VSF550, VSF560, VSF580, VSF590, VSF600, VSF650, VSG60, VSG64, VSG65	VH290
AKAI BV-V1182A420B		VSG405, VSG411, VSG415, VSG417, VSG418, VSG425, VSG445, VSG511	VH288
AKAI BV-V1234D430E	PIN TYPE	VSG260, VSG260EA, VSG262, VSG262EA, VSG265, VSG265EA, VSG280, VSG281	VH293
AMSTRAD 255015	FUNAI, TEAC 8059-08-05	DD9904, VCR3000, VCR9512	VH146
DAE-WOO, TEMPEST 97SA21790		TE970, TE970R, VCR32, VCR52, VCR8025	VH190
DAE-WOO, TEMPEST 97SA428700		DVR6158, DVR6158R, TE99R, VRD300	VH191
DAE-WOO, TEMPEST 97SA428700		DVR4773, DVR4773P, DVR6158, DVR6158D, KVR-10D, KVR10D, TE99R, VCR32, VCR52, VCR8025, VN20, VN22, VN25, VRD300	VH193
FUNAI,TANDY 8059-01-95		VR2700	VH144
FUNAI,TEAC 620806501610		MV6010	VH442
FUNAI,TEAC 62DD806501601		62DD806501601, MV3010, MV3050, VCR9600	VH440
FUNAI,TEAC 8000-01-13		MV1400, MV1400TV, MV1414, MV1430, MV1440, MV1440TV, MV2020, MV400, MV430, MV435, V-1, V-2, VCR4000, VCR4500, VCR4800, VCR5200, VCR6000, VGX510, VGX715, VGX720, VIP1000, VIP1400, VP100, VRD032, VX1000, VX2000	VH140
FUNAI,TEAC 8059-01-20		DD8904, GB115, HVG50GPS, HVG50GPS=AiWA, VCR6000=AMSTRAD, VCR6100, VCR6100=AMSTRAD	VH143
FUNAI,TEAC 8059-08-05 [SP]		UF22, VR2100, VR2100-GENEXXA	VH145
FUNAI,TEAC NFN513		MV606	VH147
GOLDSTAR 413-014/50/51/75/98		AV61, AV62, AV63, GHV1221, GHV1232, GHV1240, GHV1241, GHV1246, GHV1246H, GHV1247, GHV4300, GHV4301, GHV4305, GHV4306, GHV4310, GHV4311, GHV4315, GHV4316, GHV4320, GHV4321, GHV4325, GHV4326, GHV51, GHV51FP, GHV51P, KBV9012, M22, VCP4000, VCP4100, VCP4130, VCR7000, VR1500	VH180
GOLDSTAR 413-159A		AV64, AV65, AV66, GHV1290, GHV1291, GHV1295, GHV1296, GHV1296HQ, GHV1910, GHV1910H, KVP120, RA20, RA20H, RA21, RA21H, RG20, RG20H, VCP100, VCP100P, VCP101, VCP105, VCP106, VCP110, VCP110H, VCP111, VCP115, VCP116, VCP120, VCP121, VCP125, VCP126, VCP4300, VCR8000, VCR8400, VGX916	VH182
GOLDSTAR/NEC 413165D		MV4020, VGX930, VN63	VH185
HITACHI 5436103		VT540, VT545, VT546, VT548, VTD660, VTD665, VTM245, VTM548, VTM548E, VTM598, VTM640, VTM645, VTM646, VTM730, VTM731, VTM735, VTM736, VTM740, VTM745, VTM746, VTM748, VTM748E, VTM757, VTM757E, VTM838, VTM838E	VH245
HITACHI 5457471		VT100, VT110, VT111, VT113, VT115, VT118, VT120, VT125, VT128, VT418, VT518, VT518E, VT528, VT720, VT722, VT726, VT728, VTM328, VTM328E, VTM720, VTM722, VTM726, VTM728, VTM728E, VTM818	VH248
HITACHI 5457472		VT130, VT138, VT145, VT258, VT428, VT538, VTL30	VH249
HITACHI 5457474		VT168, VT498	VH240
HITACHI 5458104	5458282	VT4000, VT4200, VT5000, VT5500, VT5600	VH98
HITACHI 5458161	5458165	VT6500, VT680, VT6800, VT7000, VT8000, VT8040, VT8500, VT8700, VT9000, VT9300, VT9500, VT9700, VT9900	VH94
HITACHI 5458413,5458415,5458282	5.45899E+14	V4100, VT11, VT11E, VT14, VT14E, VT30, VT33, VT330, VT33E, VT34, VT340, VT503, VT61, VT62, VT63, VTP10, VTP30	VH96
HITACHI 5458434	5459002	VT17, VT19, VT20, VT20E, VT7	VH99
HITACHI 5459001		VT35E, VT38, VT39	VH100
JVC NKP0003LP	428869110625	VR288, VR299, VR299/75, VR29975, VR357, VR388, VR399, VR399/75, VR39975	VH425
JVC PDM2002C		BR9060, BR9060E, HRD330, HRD337, HRD337MS, HRD637, HRD641, HRD660, HRD667, HRD720, HRFC100, HRFC100MS, SRL900, SRL900E, VR3442	VH215
JVC PDM2004B		HRD180, HRD230, VR2941	VH204
JVC PDM2007A		HRD370, HRD430, HRD430EA, HRD470, HRD470E, VR2971, VR7979	VH205
JVC PDM2008B-5		HR-D540EA, HRD-X20, HRD160, HRD170, HRD171, HRD200, HRD210, HRD211, HRD217, HRD310, HRD320, HRD321, HRD520, HRD520EA, HRD521, HRD522, HRD525, HRD540, HRD540EA, HRD700, HRDX20, HRDX20EA, HRDX22, HRDX22EA, HRPS10, VR2931, VR4935, VR5935, VR6935.	VH216
JVC PDM2104B-9		BR7000, BR7030, BR7040	VH217
JVC PDM2112B		HRD750, HRD830, V3505, VR4965, VR5965	VH206
JVC PDM2119		HRS5000, HRS5500, HRS5800, VR6000, VR6985	VH202





## □ VCR Head Drums

### VIDEO HEADS - Continued...

Replaces	Equiv.	Models	Code
JVC PDM3353J14		HRJ400, HRJ400EA, HRJ415, HRJ415EA, VHR415, VR453, VR453/75, VR45375, VR454, VR454/75	VH420
JVC PDM3353L		HRJ200, HRJ200EA, VR254, VR254/75	VH219
JVC PDM3403C		HRJ220, HRJ220EA, HRJ221, VR155, VR256, VR256/75	VH210
JVC PQ20014C/C4		HRD455, VR1970	VH207
JVC PQ20016B-2		HRD140, HRD141, HRD142, HRD143, HRD150, HRD152, HRD156, HRD157, HRD158, HRD510, RTV324, RTV325, V1005, V1015, V1025, V1065, V304, VR2925, VR2930	VH16
JVC PQ20020B		HRD250, HRD257	VH15
JVC PRD2002D		BR7000ES, BR7000ES=JVC	VH214
JVC PRD30050B		CR6060, CR6060E, PR900, PR900E	VH218
JVC PU20850G		HR7655, V380, VR3994, VR3994=ITT	VH18
JVC PU31332D	PU31332-GIO	3V00, AT1, ATV1, AV1, HR3300, HR3320, HR3330, HR3360, HR4100, HS200, HV1000, HV2000, N830, N830EA, RV300, RV310, V100, V102, V250, V350, VR520, VR7000, VS9300, VS9500, VS9700, VS9800, VT3000	VH10
MITSUBISHI 927B499021		HSMX2, HSMX2A	VH123
MITSUBISHI 927B723014		HS541, HS541V, HSM541	VH134
MITSUBISHI 927B72302		HSMX5, HSMX5A, HSMX7, HSMX7A, HSMX7V	VH119
MITSUBISHI 927B730021		HSE17, HSMX1, HSMX10, HSMX3, HSMX3A, HSMX1	VH139
MITSUBISHI 928B00804	928B00803	ATV2, ATV4, ATV5, HS300, HS301, HS302, HS310, HSE300, HSE301, HSE302, HSE310	VH120
MITSUBISHI 928B09004		ATV10, ATV11, ATV20, ATV30, AV11, AV31, HS303, HS304, HS700, HS700E, TR101	VH126
MITSUBISHI 928B17302		AV12, AV14, HS306, HS318, HS410, TR102	VH125
MITSUBISHI 928B20702		AV51, HS307, HS319	VH135
MITSUBISHI 928B22102		AV400, HS400	VH121
MITSUBISHI 928B29602		AV52	VH130
MITSUBISHI 928B32207		AV338, HS338	VH132
MITSUBISHI 928B334020		AV337, AV347, AV47, HS337, HS347, HS521	VH122
MITSUBISHI 928B37107		AV49, CTR-3024, CTR3024, HS349, HSE31, HSM35	VH138
MITSUBISHI 928B40409		AV411, HS411	VH136
MITSUBISHI 928B64109		AV59, HSE11, HSE27, HSE30, HSE30A, HSE632, HSM33, HSMX20, HVF80, HVF80SH, MV505	VH127
MITSUBISHI 928B65409		AV58, HSE12, HSE20, HSE20A, HSE21	VH128
MITSUBISHI 928B79909		HSE51	VH124
MITSUBISHI 928B984021		HSE52, HSM54	VH133
MITSUBISHI 948B07002		AV21, HS330, TR201	VH137
NATIONAL VEH0103		NV2000, NV2010, NV300, NV330, NV332, NV333, NV340, NV390, NV8400	VH30
NATIONAL VEH0121		NV3000, NV7000, NV7200, NV7500, NV7800, NV8610, NV8620, RTV100, RTV200, RTV202, RTV211, RTV214, RTV222, RTV224, RTX100, RTX200, VR440	VH40
NATIONAL VEH0171		NV100, NV200, VR10	VH41
NATIONAL VEH0201		NV788, RTV348	VH43
NATIONAL VEH0209		NV600, RTV321	VH44
NATIONAL VEH0252		NV180, RTV260, RTX260, VR30, VR6711	VH45
NATIONAL VEH0269		NV480, NV630, NV780, RTV338, RTV338EA	VH299
NATIONAL VEH0286		NV230, NV260, NV433, NVG7, NVG9, RTV226, RTV315, RTV316, VGX540, VGX540A, VGX625, VGX625A	VH49
NATIONAL VEH0292			VH29
NATIONAL VEH0300			VH300
NATIONAL VEH0322		NVH70, RTV478	VH31
NATIONAL VEH0323		NVG400	VH303
NATIONAL VEH0339		NVH65, RTV454, RTV740	VH33
NATIONAL VEH0343		NVD38, NVD48, NVG20, NVG200, NVG21, NVG22, NVG25, NVG25A, NVG28, NVG38, VR6491	VH39
NATIONAL VEH0366		NVM7	VH32
NATIONAL VEH0400		NVG300, NVG50, NVG500	VH304
NATIONAL VEH0415		NV-FS1, NVFS1	VH305
NATIONAL VEH0416		NV-J1, NVG130, NVG30, NVG40, NVJ1, NVJ101, NVJ1A, NVJ3, NVJ30, NVJ33, NVJ36, NVJ4, NVJ40, NVL10, NVL15, NVL150, NVL20, NVP1, NVP10, RTV520, RTV560	VH34
NATIONAL VEH0531		NV-J45, NVJ22, NVJ45	VH319
NATIONAL VEH0532		NV-J11, NVJ11, NVJ11A, NVP10	VH320
NATIONAL VEH0598		AG1070, AG6124, AG6214E, NVSD20, NVSD20A, NVSD25	VH335
NEC 79V15036		SLVX700, SLVX90, SLVX95, SVT5000, SVT5000P, SVTS3050, TLS924, TLS924P, VHR150, VHR250, VHR260, VHR340, VHR350, VHR4770, VHR550, VHR650, VHR7500, VHR7770, VHSF54, VN70, VN72	VH172
NEC 79V15041		NECVH90, NECVH91, NECVH92, VHR190, VHR194, VHR219, VHR290, VHR390, VHR590, VHR774, VHR7900	VH174
NEC 824 23AH1		DX1600, DX1600A, N901, N9011, N9013, N901A, N9033, N9033A, N9034, N904, N9040, N9040A, N9052, N9052A, N9053, N9053A, N9063, N9063A, N9065, N9065A, N9066, N9066A, N9073, N9073A, N9077, N9083, N9083A, N9401, N9402	VH160
NEC 824 34AH1		N911, N911A, N912, N912A	VH161
NEC 826 11AH1		DX3000, N9610, N9680, N9680A, VH780, VH780D	VH163
NEC 826 91AH1		N9530, N9570, N9570A, N9580, N9580A	VH164
NEC 827 63AH1		N9280, N9280A	VH166
NEC 82B 26AH1		DS6000, DS6000A	VH165



# Video Repair Parts

## □ VCR Upper Drum Assembly

### VIDEO HEADS - Continued...

Replaces	Equiv.	Models	Code
NEC NNC601		2H20D, MV3080, VN23, VN24, VN26	VH168
ORION VH1, VH2		VH1, VH2, VH2B	VH150
ORION VH3		MIRR, MIRR=SHERWOOD, PV300, VH2B, VH3	VH155
SAMSUNG 69000-342-400		520T, DS757, PB980, PB980R, PB981, PB981R, PB982, PB982R, SC520T, TE77R, TE900, TE900A, TE90H, VB2215, VB2215P, VB520, VB617, VB617C, VB627, VB629, VB705, VB710, VB711, VB711A, VB712, VB713, VB713C, VB720, VB721, VB729, VB750, VB8220, VB900, VB900A, VB910, VB911, VB920, VB930, VB950, VB970, VB971, VB972, VB978, BD711, BD714, VRD100, VRD100L, VS11, VS12, VS200, VS200EA, VSP3, VSP3EA, VX510, VX520, VX616, VX970, VX971, VX972	VH75
SAMSUNG 69000-390-012		PB30, PB30R, PB31, PB31R, PB36, PB36R, VB1230, VB1260, VB1260A, VB1260N, VB1261, VB30, VB301, VB301A, VB306, VB30R, VB31, VB31R, VB320, VB320A, VB3260, VB3260A, VRD200L, VX1260E, VX3230, VX3231, VX3260, VX3261	VH76
SAMSUNG 69000-390-013		VB1530, VB1560, VB1561, VB300, VB3260, VB336, VB350	VH77
SAMSUNG 69000-390-026		VB1850, VB370	VH375
SAMSUNG 69000-390-271		PB990, PB990R, PB991, PB991R, PB992, PB992R, VB990, VB990R, VB991, VB991R	VH78
SAMSUNG 69020-124-042		AV30BV, SB30, SV30, SV30B, SV30BV, SVA25, SVA25B, SVA40	VH376
SANYO 143-0-771T-06500		VHR1500, VHR2500	VH81
SANYO 143-0-771T-13400		VHR3100, VHR3200	VH82
SANYO 143-0-771T-25221		VHR1300, VHR2370	VH88
SANYO 613-022-0264		VHR120, VHR130, VHR220, VHR230, VHR310, VHR4100, VHR510, VHR5100, VHR7100, VHR7200, VHRD4100, VHRD4400, VT9900EM	VH79
SANYO 613-096-8039		FVSP490, VHR5300, VHR7400, VHR7440, VR3000	VH171
SANYO 613-164-0719		VHR610, VHR630, VHR740	VH179
SANYO 613-166-2926		TLS2000, TLS2000P, TLS900, TLS900P	VH371
SHARP DDRMU0001HE10		VC2300, VC6000, VC6200, VC6300, VC6500, VC7300, VC7500, VC7700, VC7750, VC8000, VC8300	VH23
SHARP DDRMU0002HE04		VC300, VC3300, VC3300X, VC381, VC383, VC383X, VC385, VC386, VC387, VC400, VC8482, VC901, VC9100, VC9300, VC9700, VC9800, VR401, VR501, VR502, VR701, VR901, VR9700, VRD012, VRD022, VRS012, VRS022	VH24
SHARP DDRMU0002HE05		VC390, VC390X, VC496, VR601, VR6840	VH21
SHARP DDRMU0002HE09		VCA45, VCA45X, VCA48, VCA48X, VCA49, VCA49X	VH225
SHARP DDRMU0002HE36		VCA33, VCA33X, VCA34, VCA34X, VCA38, VCA39, VCA40, VCA43, VCA43X, VCA44, VCA44X, VCA46, VCA46X, VCB20	VH226
SHARP DDRMU0002HE39		VC483, VC486, VR6740, VR6745	VH27
SHARP DDRMU0004HE04		VC585, VC685, VC785, VR6543, VR6741, VR6742	VH22
SHARP DDRMU0004HE09		VC502, VC779, VC787, VC787X, VCA502, VCA505, VCA505X, VCA60, VCA60X, VCA61, VCA615, VCA63, VCA63X, VCA64, VCA64X, VCA65, VCA65X, VCB361, VCB361N, VCB60, VCB60X, VCD805, VCD805X, VCD815, VCD815X, VCD851, VCT510, VCT510X, VR6548, VR6549, VR6648, VR6843, VR6856	VH26
SHARP DDRMU0004HE14		VC780, VC79, VC79ETN, VC890, VC890ET, VT1418, VT1418M, VT2118M, VT3418, VT3418X, VT5118	VH228
SHARP DDRMU0004HE22		VC6F3, VC6F3X, VC793, VC793X, VCH851, VCH851X	VH224
SHARP DDRMU0005HE10		MV740, MV740A, VC488, VR6743, VR6940	VH220
SHARP DDRMW0005HE02		VCH80, VCH80X, VCH83, VCH83X, VCH84, VCH84X, VCH88, VCH88X	VH222
SHARP NSH516		VCA220, VCA220X, VCA36, VCA36X, VCA37, VCA37X, VCA41, VCA41X, VCMA33	VH229
SHARP NSH551		VCA420, VCA420X, VCA470, VCA470X, VCA62, VCA62X, VCA72, VCA72X	VH321
SHARP NSH852		VCH93, VCH93X	VH323
SHARP NSH853		VCA200, VCA200X, VCA270, VCA270X, VCA50, VCA50X, VT3428, VT3448, VT5128, VT5148	VH339
SHARP NSH855		SLV353	VH176
SONY 1-550-534-11		SLVX810, SLVX825, SLVX835, SLX810	VH177
SONY 1-550-694-11		SLV-X800, SLV-X800M, SLV-X800MN, SLVX800, SLVX800M, SLVX800MN	VH360
SONY 3-955-048-01		SLVX50, SLVX55, SLVX55AS, SLVX57, SLVX710, SLVX711	VH71
SONY 884-854-001		SLVK867, SLVKH3, SLVKH3PS, SLVKH7, SLVX811, SLVX811AS, SLVX812, SLVX817, SLVX822, SLVX823, SLVX827, SLVX837	VH178
SONY DSR-43R		B5, SL8000, SL8080, V5250	VH70
SONY DZR-27R 8848-54501		SLV215, SLVX30, SLVX30A, SLVX30PS, SLVX35	VH72
TOSHIBA 70321488		V8600	VH92
TOSHIBA 70321968		DV80, DV90, V71, V73, V74, V75, V81, V83, V83A, V84, V85, V85A, V86, V86A, V8700, V93, V93A	VH89
TOSHIBA 70321994		V63, V63A	VH93
TOSHIBA 70325174		V300, V300A	VH389
TOSHIBA 70325185		V500	VH390




## VCR Lower Drum Assembly

### Akai

#### AKAI DRUM ASSEMBLY

Includes Upper-Drum  
(Video Head) with  
Lower-Drum & Motor

OEM	BV-V9009A020, BV-V9009A020A, BVV9009A020
Suits	VS12EA, VS15
Code	DRM12




### Funai

#### FUNAI LOWER DRUM ASSEMBLY

##### NON-SOLDER TYPE

Original Part No	6004-09-01, Chassis V-3S
Models	MV307,316,445,450, VCR417, 9000, VGX815, 820, VR1900, VX4000
Suit	VH142 / 143 (not inc.)
Code	FU901



### Samsung

#### SAMSUNG LOWER DRUM ASSEMBLIES

##### 69000-370-034 (2HEAD)

Suit	Code
PB970,971,TE90H	DRM970




Image may differ from stock

##### 69000-291-083 (2HEAD)

Suit	Code
VB306	LDR83

##### 69000-291-084 (4HEAD)

Suit	Code
VB336	LDR84

HEAD SOLD SEPARATELY

#### SAMSUNG UPPER/LOWER DRUM ASSEMBLY

##### INCLUDES VIDEO HEAD

OEM	G8PB1A
Suits	PB981R, PD980, TE77R
Code	69018123714



Image may differ from stock

### JVC

#### JVC COMPLETE DRUM ASSEMBLY

Upper and lower  
drum assembly  
with motor, etc.  
Suit HR-D170,171, etc.

Code	DRM170
------	--------




Image may differ from stock

#### JVC LOWER DRUM ASSEMBLY

Lower drum & motor, etc.  
REQUIRES VIDEO HEAD

Suit	Code
HRD580	PDM2138H
HRDX20	PDM2138Y

##### VIDEO HEAD Optional Upper Drum

Suit	Code
HRDX20	VH216




Image may differ from stock

### Sharp

#### SHARP DRUM ASSEMBLY

Includes video head and motor

Suits	Code
VCH855X	DDRMW0008HE03
VCH83X	DDRMW0011HE02
	DDRMW0014TEX2
VCA220X	DDRMW0028TEX2
VCA270X	DDRMW0028TEX3
	DDRMW0029TEX2




## Servicing Tools and Accessories

### UNIVERSAL HEAD EXTRACTOR TOOL

Hand tool designed for extracting video  
heads without damage to the drum assembly.  
Adjustable for various heads.

Code	HT800
------	-------



### COTTON GLOVES

Eliminate the need to clean  
heads after fitting by using  
gloves. Recommended  
by leading manufacturers.  
Sold in pairs.

Code	GLV2
------	------





# Video Repair Parts

## □ AC Heads

### AUDIO CONTROL HEADS

#### DAEWOO / DEITRON / TEMPEST / TRACTON / ESC / VIDEO-PRO

Original Part No	Suit	Code
97PA450300	TE970/VCR32/VCR8025	VBR4503
97S8005520	DVR6158D/TE99R/VRD300L	VBR5520

#### FUNAI / PALSONIC / TEAC

Original Part No	Suit	Code
6204-15-06	Funai	FU1506
62D62041520	MV3010,30,50, VCR9688	AC1520

#### LG GOLDSTAR

Original Part No	Suit	Code
3041R-0005A	Akai VSJ200, 215, 411, 416, 700, 711, 716 LG AF293, 493, 993, AC250, 450, 950	AC0005
225-402C W903H	LG	AC5402

#### HITACHI

Suit	Code
VTM598, 838	AC4061

#### JVC

Suit	Code
HRJ200,400	PEHE0247
HRD520, etc	PU60617-3
HRD170,171 etc	PU59253

#### JVC ERASE HEAD

Original Part No	Suit	Code
TDK6B50, L491	HRDX20, 22	PU60616
QAH0010-002	HRJ255,455,655,755., Philips VR288,388. 4822-249-1057	AC0002

#### NATIONAL / PANASONIC AC HEADS

Suit	Code
NV300.	VBR0050
NVH70A	VBR0100
NV-G7,10,12,30 etc. & NV250,280,370 etc. & RTV301, VR6520.	VBR0103A
NVL15	VBR0129
NVF55, NVJ11	VED0160
	VEH0237
NV-G7,10,12,30 etc. & NV250,280,370 etc. & RTV301, VR6520.	VEH0247
NVSD220, 270, 420, 620, 670	VED0363
NV600,777,788,RTV322	VBR0061
NV-G20, NV-H75	VBR0125
NVSD10,20,30,NVHD70,100	VED0182
NVH70A	VEH0248
NV730, NV770	VEH0259

#### NEC

Original Part No	Suit	Code
79501140, 79501094		AC1140
79501145	N9033,N9034	AC1145
79501153	DX3000,N9052,9053,9530	AC1153
82417PAI	N901, N911	82417PA1
16190362	N9072/73/83, 9401/2, 9570	AC3620


#### SAMSUNG

Original Part No	Suit	Code
6526 4606 510	VB627	AC5033
6900 0291 032	VB300, 370, etc.	AC1032
66603-0006-00	SV10,11,12,30,80,140	AC600






#### SHARP

Original Part No	Suit	Code
RH-EDU0031GEZZ	VC381 etc.	DU0031
RH-EDU0040GEZZ		DU0040
RH-EDU0054GEZZ	VC100 etc.	DU0054
RH-EDU0056GEZZ	VC651X etc.	DU0056
RH-EDU0057GEZZ	VC782 etc.	DU0057
RH-EDU0058GEZZ	VCH851 etc.	DU0058
RH-EDU0070GEZZ	VCF18,VCA111,etc..	DU0070
RH-EDU0083GEZZ	VCA36, VCA37, VCA50	DU0083
RH-EDU0085CEZZ	VCA200, VCA460, VCH600, etc.	DU0085
RH-EDU0088GEZZ	VCA220,270,420,470.	DU0088

**MORE MODELS  
AVAILABLE SEE:**  
<http://www.wes.com.au/>



**NOTE. In some cases the PCB may differ.  
However, the head is interchangeable.**



<http://www.wes.com.au/>



## □ Motors

### □ Akai


#### SAMSUNG / AKAI VIDEO HEAD MOTOR

OEM	64769052057
Suits	VB520, VB711, VP2, VS11, VS12, VS200, VSP3
Code	VM2057




#### AKAI PC DRUM MOTOR BLOCK

Original	BM-M3223A020A
Part No	
Suit	VS105, 112, VS115, 116, VS165, etc.
Code	VM3223



#### AKAI DRUM MOTOR BLOCK

Original	BM-M3225A501A,
Part No	BM-M3225A020A
Suit	VS35 VS965
Code	VM3225



#### AKAI CAPSTAN MOTOR VS4

OEM	BM347730
Suits	VS4
Code	VM3477




#### AKAI MOTOR BM352233

OEM	BM352233
Suits	VB711, VS6, VS8, VS9, VS12, VS15.
Code	VM3522




#### AKAI LOADING MOTOR

Original	BM-348088,
Part No	MMN-5C2RP
Suit	VS1, 3, 4 VS6, 8, etc.
Code	VM2115




#### AKAI LOADING MOTOR

Original	BM433593N1
Part No	
Suit	VSG280, VSG2DPL VSG765, 790, 875.
Code	VM3593




#### AKAI DRUM MOTOR

Original	74680RB0004A, 743K000205-65
Part No	
Suit	VSG280, 480, 485, VSJ200, 416, VSJ700, 716.




#### AKAI DRUM MOTOR

Original	BM419324N2, BM419324N4, SDV-0302A
Part No	
Suit	VSG705 VSG735




#### AKAI MOTOR

Original	BM733648JI
Part No	
Suit	VS66, VS53




#### AKAI CAPSTAN MOTOR

BM419269N3	
Suit	VSG205, 317,




#### AKAI CAPSTAN MOTOR

Original	BM-386236J1, DFX-67B3VWA1
Part No	
Suit	VS422, 425, VS465, 756, VSF10, 12




#### AKAI CAPSTAN MOTOR

Original	BM-373098
Part No	
Suit	VS35



#### AKAI CAPSTAN MOTOR

Original	4680RA0002A, B, 4680RA0003A
Part No	
Suit	VSJ200, 215, 411, VSJ416, 700, 711, 716. GVC003A, VHRVK210, VN204, AC250, 450, 950, AF293, 493, 993






# Video Repair Parts

## Daewoo

### DAEWOO CAPSTAN MOTOR


FITS TEMPEST,TRACTON ESC,  
VIDEO-PRO

Original	97S8102300,
Part No	Sony BHF-310C
Suit	DVR6158D, TE99R...
Code	VM8025




### DAEWOO DRUM MOTOR

Original	97SA398910,
Part No	Sony U-14C
Suit	DVR6158D, TE99R...
Code	VM8910




### DAEWOO CAPSTAN MOTOR

Original	97S8102400, Sony
Part No	BHF-310B
Suit	DVR6158D, TE99R,etc.
Code	VM2400



### DAEWOO TEMPEST LOADING MOTOR


Original	97S8102000
Part No	
Suit	DVR6158, VCR32, 52, VCR8025, TE970R, 99R...
Code	VM0244



### DAEWOO DRUM MOTOR

FITS TEMPEST,TRACTON, ESC,  
VIDEO-PRO


Original	97SA393010, Sony
Part No	U-10A
Suit	TE970R, VCR32, VCR8025
Code	VM3010



## Funai / Teac / Palsonic

### FUNAI TEAC PALSONIC LOADING MOTOR

Original	62D806511301
Part No	
Suit	MV3010, 3030, 3050, MV4010, 6010, Palsonic VCR9688
Code	VM6158



## Hitachi

### HITACHI CAPSTAN MOTOR

Original	GP10123, GP10112
Part No	
Suit	VTM428, VTM448
Code	VM10112



### HITACHI CAPSTAN MOTOR

Original	5571743
Part No	
Suit	VTM728, etc.
Code	VM1743




### HITACHI CAPSTAN MOTOR

Original	5571475
Part No	
Suit	VTM598E, VTM838E
Code	VM1475



### HITACHI MOTOR & MODE SW


Original	7794932
Part No	
Suit	VTM757E
Code	MEC4932



## JVC

### JVC CAPSTAN MOTOR

Original	PU48854M
Part No	
Suit	HR7200,7650,D120,D 121,HRD125,140,150, 157,160,220,225,250, 725,N830,831,832,833 ,RV340,350,360,370,V CR1500,& AKAI,etc.
Code	VM2115






## JVC DRUM MOTOR


Original PU46414P, PU44619  
Part No HR3300,3330,36  
Suit 60,HV1000,2000,  
RV300,Also AKAI,  
HITACHI,NORMENDE  
& TELEFUNKEN and  
some early SHARPs.

Code VM2120




## JVC MOTOR

Original	PU55371V
Part No	
Suit	HRD110,111,HRD120 ,121,225,GE8100,930 0,N830,831,833,RV36 0,310,etc.
Code	VM5371




## JVC CAPSTAN MOTOR

Original	PU58635V
Part No	
Suit	HR-D160, 170, 171, 180, 210, 211, 217, 227, 230, 310, 320, 321, 370, 430, 470, 500,etc.
Code	VM5863




## JVC CAPSTAN MOTOR

Original	PU57647V
Part No	
Suit	HRD152, 157, 158, HRD565, 546, etc. MV800, VR2925, 2930, 2970
Code	VM5764




## JVC MOTOR

Original	PQ40244A-2
Part No	
Suit	HRD140 etc.
Code	VM0244



## JVC REEL MOTOR


Original	PU58636W
Part No	
Suit	HRD170, HRD180, HRD200, HRD530 And more
Code	VM5864



## JVC / PHILIPS CAPSTAN MOTOR


Original PU61285  
Part No HRD-X20,22,  
VR3241,3245.

Code VM6128




## JVC CAPSTAN

Original	HRD540,910
Part No	
Suit	
Code	PU61003




## JVC LOADING MOTOR

Original	PQ43676B-5
Part No	
Suit	HRJ200, HRJ400
Code	VM6282




## JVC CAPSTAN MOTOR

Suit	HRJ220, 221,HRJ625, etc.
Code	PU61435-1-6




## JVC / PHILIPS DRUM MOTOR STATOR

Original	JVC PDZ0141-1-2, Philips 482236210274
Part No	
Suit	HRJ220, 221, 425, HRJ435, 625, 635, Philips VR255-75, 357-75 VR555-75, 656-75
Code	PDZ0141



## JVC LOADING MOTOR

Original	PQ41996A, PQ41996B, PU60437
Part No	
Suit	HRD230, 320, HRD370, 430.
Code	VM4199





# Video Repair Parts


## JVC/PHILIPS CAPSTAN MOTORS

Original Part No	Suit	Code
QAR0032-003/5	HRJ255, 455, 655, 755.	VM2003
QAR0018-006	VR288, 399, 588, 988.	VM1094




## JVC LOADING MOTOR

Original Part No	PQ43676B-5
Suit	HRJ200, HRJ400
Code	VM6282



## JVC LOADING MOTOR

Original Part No	PU60628-3-2, QAR0023-001
Suit	HRJ255, 455, HRJ655, 755.
Code	VM6158




## JVC CAPSTAN MOTOR

Original Part No	PU61487-2-5
Suit	HRJ435, 635, HRS9400,...
Code	PU61487




## JVC DRIVE GEAR ASSEMBLY

Suit	HR7600, HR7650
Code	PU51859A-2



## JVC DRIVE GEAR ASSEMBLY

Suit	HRD110, HRD111, HRD120, HRD121.
Code	PU51859C-11




## □ LG / Goldstar

### LG GOLDSTAR LOADING MOTOR

Original Part No	414-051A
Code	VM4140

Also some Mitsubishi



### LG GOLDSTAR LOADING MOTOR / BRACKET

Original Part No	4811R0011A
Suit	AF293, 493, 993, AC250, 450, 950.
Code	VM0011




### LG GOLDSTAR CAPSTAN MOTOR

Original Part No	414-108A
Suit	VCP100, 101, VCP105, 106,
Code	VM4141




### LG GOLDSTAR MITSUBISHI CAPSTAN MOTOR

Original Part No	414-029A
Suit	AV61 GHV1232 GHV1240, etc.
Code	VM4144



### LG GOLDSTAR CAPSTAN MOTOR (A)

Original Part No	CXA8005
Suit	RA211X
Code	VM4121



### LG GOLDSTAR CAPSTAN MOTOR (B)

Original Part No	414-120B
Suit	RG20, RA20, RA21.
Code	VM4120



Version "B" Differs from "A"




## □ Mitsubishi

### MITSUBISHI/AWA REEL MOTOR


Original 288PO46010  
Part No  
Suit AV11,21,HS30,330,  
Code VM6010

OEM 288P034010  
Suits ATV10, ATV30,  
HS303  
Code VM8061




### MITSUBISHI/AWA LOADING

Original 288P06701  
Part No  
Suit AV49,58,63,  
AV337,411,  
HS337,411, HSE10-70,  
and more....  
Code VM0244



### MITSUBISHI LOADING MOTOR


Suit Many brands  
and models.  
Code VM6158



### MITSUBISHI PULLEY


The plastic one is  
broken, replace it  
with this brass one.  
Requires glue, (14-36)

Original 631D581010  
Part No  
Suit HSMX Series.  
Code PLY101




### MITSUBISHI CAPSTAN MOTOR

Original 288P08904  
Part No  
Suit HSE17,27,HSE52,82.  
Code VM8904



### MITSUBISHI CAPSTAN MOTOR

Original 288P11701  
Part No  
Suit HSM34,HSM380V,HSMX2,  
18,HSMX38  
Code VM1701



## □ NEC


### NEC CAPSTAN MOTOR

Original VM2700  
Part No  
Suit VN20, DVR2700,  
DVR4773  
Code VM2700



### NEC CAPSTAN MOTOR

Original 61308788-54, 079-  
Part No V1-5015, 192-9197-  
006  
Suit DVR4773, VHR120,  
1309,VN30, 32.  
Code VM5015



### NEC REEL MOTOR


OEM 4527V01100B,  
6130170712, V01100B.  
Suits M10, M20, VHR190,  
VTCM10, VTCM20,  
VTCM30, VTCM40.  
Code VM2220



## □ National

### NATIONAL LOADING MOTOR

Original VEM0218  
Part No  
Suit NV250 NV280  
NV450 NV470  
NV870  
Code VM0218



### NATIONAL REEL MOTOR


OEM MYN13V5L  
Suits NV300, NV340  
Code VM1350



### NATIONAL REEL MOTOR

Includes sleeve.  
Original KFN56FB8A  
Part No  
Suit NV777,788  
Code VM568

Rubber Sleeve only  
Code VIT400





# Video Repair Parts

## Panasonic

### NATIONAL LOADING MOTOR

#### GENERAL PURPOSE LOADING MOTOR


Original 288P04401

Part No

Suit

Many brands and models.

Code VM6158




### NATIONAL LOADING MOTOR

Original VEM0242

Part No

Suit NV-G7 &amp; others.

Code VM0242



### NATIONAL LOADING MOTOR


Original VEM0211

Part No

Suit NV250, 280, 450, 730, 770, 870, etc.

Code VM0211

Suit also GOLDSTAR



### NATIONAL REEL MOTOR

Original VEM0212

Part No


Suit NV730,770

Code VM0212

Rubber Sleeve only

Code

VIT400




### NATIONAL CAPSTAN MOTOR

Original MAX13V9LP

Part No

Suit NV600 etc.

Code VM1390



### NATIONAL CAPSTAN MOTOR

Suits Unknown

Code VEM0116



### NATIONAL PANASONIC MOTOR

OEM VEK7236

Suit NVFJ, NVHD, NVSJ...

Code VEM0715



### PANASONIC STATOR

Suit NVG20, NVG25,


NVG25A,

NVL15, VR6490,

VR6490/75,

VR712, VR715

Code VEK2944



### PANASONIC ROTOR G-MECH

OEM VXP0777

Suits G-Mech

Code VXP1113



### PANASONIC STATOR

Suit NV-L20,L25,NV-J1,

J35,&amp; More...

Code VEK4105




### PANASONIC CAPSTAN STATOR

Suit NVSD10, NVSD20,

NVSD30

Code VEK5927



### PANASONIC CAPSTAN MOTOR

Original VEK8024,


Part No VEK8239

Suit NVSD220, 270,

NVSD420,

NVHD620, 670.

Code VM8024




### PANASONIC LOADING MOTOR

Suit NVSD10,ETC.

Equiv. VEM0427

Code VM0427



### BUSH PULLEY / WORM

Code VDP1434

VDG0866






## Samsung

### SAMSUNG CAPSTAN MOTOR

Original 64769-053-330,  
Part No 64769-052-020  
Suit PB970, 971,  
PB972, TE90H.  
Code VM3330



### SAMSUNG TEMPEST CAPSTAN MOTOR


Original 64769052094,  
Part No 64769052095  
Suit PB980, 981,  
PB982, TE77R.  
Code VM2094



### SAMSUNG TEMPEST DRUM MOTOR


The motor only from  
above assembly

Original 64769052066  
Part No  
Suit PB980, 981,  
PB982, TE77R.  
Code VM1215



### SAMSUNG CAPSTAN MOTOR

Original 66823-0059-00  
Part No  
Suit SV10, 11, 12,  
SV30, 80, 140  
Code VM5900



### SAMSUNG MOTOR ASSEMBLY

Entire loading motor mechanism supplied


OEM 65292600310,  
D8-NR2A,  
N8NR2A  
Suits PB981R, TE77R  
Code VM0310



## Sanyo


### SANYO MOTOR

Original 613-017-0699  
Part No  
Suit VTC6500  
Code VM2215




### SANYO REEL MOTOR

Original 4-527V-10800  
Part No RM11  
Suit VTC5000,  
VTC5005,  
VTC5300,  
VTC5400  
Code VM2210




### SANYO CAPSTAN MOTOR

Original 613-089-9156  
Part No  
Suit TLS1000  
Code VM9156




### SANYO CAPSTAN MOTOR

Original 613-130-9425  
Part No  
Suit SRT500P,  
TLS900P,  
TLS924P,  
TLS2000,  
TLSS2500P  
Code VM9425



### SANYO CAPSTAN MOTOR

Original 645-008-1897  
Part No  
Suit VHR510, 530,  
VHR610, 630  
Code VM5008






# Video Repair Parts

## □ Sharp


### SHARP LOADING MOTOR

Original RMOTM1049GEZZ  
Part No  
Suit VCA10X,30,103,  
105,505,etc...  
Code VM1049




### SHARP CAPSTAN MOTOR

Original RMOTN2051GEZZ  
Part No  
Suit VCA62X, VCA63X  
Code VM2051




### SHARP CAPSTAN MOTOR

Original RMOTP 1029 GEZZ  
Part No  
Suit VC381, VC383,  
VC9100, VC9300  
Code VM2127




### SHARP MOTOR

Original RMOTM1017GEZZ  
Part No  
Suit VC300 series. and  
more....  
Code VM0244




### SHARP CAPSTAN MOTOR

Includes pulley.  
Original RMOTP1026GEZZ  
Part No  
Suit VC3300 and others.  
Code VM1026




### SHARP CAPSTAN MOTOR

Original RMOTP1059GEZZ  
Part No  
Suit MV740, VC100,488,  
VC581,582,583,  
VC584,585,5F3.  
VR6441,6541,6940  
Code VM1059



### SHARP REEL MOTOR

Original RMOTV 1010 GEZZ  
Part No  
Suit VC481,581,  
6441,6641,etc.  
Code VM1010




### BRASS PULLEY

Original NPLYV0121GEZZ  
Part No  
Code MP121

### SHARP CAPSTAN MOTOR


### SHARP CAPSTAN MOTOR

Original RMOTP1079GEZZ  
Part No  
Suit VC600, VC700 series  
Code VM1079




### SHARP CAPSTAN MOTOR

Original RMOTP1066GEZZ  
Part No  
Suit VC400 series  
Code VM1066




### SHARP CAPSTAN MOTOR

Original RMOTN2001GEZZ,  
RMOTN2003GEZZ  
Part No  
Suit VC772,781,782,785,78  
6,787,793,VCA101,etc.  
Code VM2001




### SHARP CAPSTAN MOTOR

Original RMOTN2012GEZZ  
Part No ,RMOTN2022GEZZ  
Suit VCA101x  
Code VM2012



### SHARP CAPSTAN MOTOR


Original RMOTN2020GEZZ  
Part No  
Suit VCA101X etc.  
Code VM2020






## SHARP CAPSTAN MOTOR

Original RMOTN2055GEZZ  
Part No  
Suit VCA220, 270, VCA420,  
470.  
Code VM2055




## SHARP DRUM MOTOR

Original RMOTP1139GEZZ,  
Part No RMOTP1141GEZZ  
Suit VCA220, 270, VCA420,  
470.  
Code VM1139



## SHARP CAPSTAN MOTOR

Original RMOTN2067GEZZ  
Part No  
Suit VCA240, 290,VCA490.  
Code VM2067



## SHARP LOADING MOTOR

Original RMOTM1078GEZZ  
Part No  
Suit VCA220, 270,VCA420,  
470.  
Code VM1078



## SHARP VIDEO HEAD MOTOR


Suits; VC381, VC383X,  
VC384, VC385, VC386,  
VC388, VC481, VC9300,  
VC9700, VR501, VR502,  
VR701, VR901

OEM RMOTP1047GEZZ  
Code VM1047




## SHARP VIDEO MOTOR

OEM RMOTP1055GEZZ  
Suits VC8300X, VCA270,  
VCH680, VCH900  
Code VM1055




## SHARP DRUM MOTOR

Original RMOTP1077GEZZ  
Part No  
Suit VC581,2,3, VC6826V3  
and others.  
Code VM1077



## SHARP LOADING MOTOR


Original RMOTM 1029 GEZZ,  
Part No RMOTM 1034 GEZZ  
Suit Many models eg.  
VCA500 series  
Code VM6158



USED IN MANY BRANDS, DAEWOO,  
DEITRON,TEMPEST,...


## SHARP DRUM MOTOR

Original RMOTP1092GEZZ,  
Part No RMOTP1084GEZZ  
Suit VCA101, 103, VCA502,  
VCD801, VR6443, etc.  
Code VM1092



## SHARP REEL MOTOR

Original RMOTV1007GEZZ  
Part No  
Suit ORION  
Code VM2122




## BRASS PULLEY

Original NPLYV0121GEZZ  
Part No  
Code MP121

## SHARP DRUM MOTOR


To suit MANY VCA,  
VCD & VCH series.  
Philips VR6349.

Original RMOTP1096GEZZ  
Part No  
Code VM1096



## SHARP DRUM MOTOR

Original RMOTP1102GEZZ,  
Part No RMOTP1107GEZZ  
Suit VCA10X etc.  
Code VM1107






# Video Repair Parts

## SHARP CAPSTAN MOTOR

Original Part No	RMOTN2010GEZZ
Suit	VCA103X etc.
Code	VM2010




## SHARP CAPSTAN MOTOR

Original Part No	RMOTN2052GEZZ
Suit	VCA36X, VCA50X and others.
Code	VM2051




## SHARP CAPSTAN MOTOR

Original Part No	RMOTN2019GEZZ
Suit	VCA105X, VC103X, VC505X etc.
Code	VM2019



## SHARP DRUM MOTOR

Original Part No	RMOTP1116GEZZ
Suit	VCA36,37,41,50, VCA53,62,67,72, VCA93,94,97,98, and more...
Code	VM1116




## SHARP CAPSTAN MOTOR

Original Part No	RMOTN-2028-GEZZ
Suit	VCA10,30,35,45, VCA60,615,H80, VR3260,3360, VR6349,6449, VR6549, etc..
Code	VM2028



## SHARP LOADING MOTOR

Original Part No	RMOTM 1062 GEZZ
Suit	VCA36,37,41,50,53, VCA53,62,63,67,72, VCH93,94,97,98, VCMH83, 93,VT3428, 5128
Code	VM1062




## SHARP CAPSTAN MOTOR

Original Part No	RMOTN-2038, 2047, 2048-GEZZ
Suit	14VT10X1, VCA33,34,38,39, VCA48,49,63,64, VCH83,84,85,87, VR3261, VF22,etc.
Code	VM2038




## SHARP VIDEO MOTOR

Original Part No	RMOTN2053GEZZ
Suit	Many Models
Code	VM2053




## SHARP REEL MOTOR

Original Part No	RMOTV 1008 GEZZ, RMOTV 1004 GEZZ
Suit	ORION
Code	VM1211




## BRASS PULLEY

Original Part No	NPLYV0121GEZZ
Code	MP121



## SHARP DRUM MOTOR

Original Part No	RMOTP-1151-GEZZ
Suit	VCH680, VCH900
Code	VM1151






## □ Sony


### SONY CAPSTAN MOTOR

Original	8-835-382-01/03
Part No	
Suit	SLVX50,etc..
Code	VM8203




### SONY CAPSTAN MOTOR

Original	1-698-409-14, 1-698-409-11
Part No	
Suit	SLVX812, SLVX822
Code	VM9140




### SONY CAPSTAN MOTOR

Original	3-740-369-02
Part No	
Suit	SLVX20
Code	VM6902




### SONY LOADING MOTOR

Original	X-3943-883-1
Part No	
Suit	SLVX812, SLVX822
Code	VM8831



### SONY CAPSTAN MOTOR

Original	F2QKB38 394702801,
Part No	62D60030354,
Suit	KV21VM3MT
Code	VM9500




### SONY LOADING MOTOR

Original	X-3727-784-1 RF-
Part No	270RH
Suit	SLVBS511, SLVF10,
Code	11, SLVP33, SLVX810 VM7841




### SONY CAPSTAN MOTOR

Original	8-835-489-01/11
Part No	
Suit	SLVX810
Code	VM8911




### SONY CAPSTAN MOTOR

Original	169897111,
Part No	169897114
Suit	SL-VEZ1, 10, 11,
Code	SL-VEZ22, 44, 66, SL-VEZ7, 70, 77. VM7111



### SONY CAPSTAN MOTOR

Original	8-835-394-11, 8-835-
Part No	394-01
Suit	SLVX55, SLV777
Code	VM9411



### SONY CAM MOTOR

Original	X37333021
Part No	
Suit	SL-VX810 SL-VX811
Code	VM3021










# Video Repair Parts

## □ Video Belts

## □ Cross Reference



### VIDEO BELT KIT SUBSTITUTION LIST

The following list has been compiled from information received from our customers and is offered as possible suggestions for usage. Please advise us if you find any errors or additions.

*Thank you.*

**PLEASE NOTE THE PRICES  
OF THE KITS ARE ON THE  
PREVIOUS PAGE**

#### Suit      Code

##### AKAI

VP77	VBK74
VS1,2,5	VBK3
VS3,4,6,8	VBK55
VS10	VBK4
VS11,12	VBK97
VS15	VBK55
VS22,26,35	VBK91
VS53,55,75	VBK91
VS112,115	VBK71
VS155,165	VBK71
VS200	VBK93
VS240,515	VBK71
VS7100	VBK40
VS7300	VBK1
VS9300,9500	VBK34
VS9700	VBK2
VS9800	VBK34
VSP3	VBK81

##### AIWA

HV-G900BPG	VBK87
------------	-------

##### AMSTRAD

DD9904	VBK129
UF22	VBK120
VCR6000	VBK87

##### AWA/THORN

2H20D, 4H40D	VBK123
AV1,ATV1	VBK37
AV12,14	VBK76
AV47,49	VBK111
AV51,52	VBK76
AV58,59	VBK111
AV61	VBK79
AV62	VBK100
AV337	VBK111
AV400,410,	VBK76
AV411,412,421	VBK111
TR102	VBK76

##### BLAUPUNKT

RTC250,256,350	VBK131
RTV222	VBK. 8
RTV301	VBK49
RTV311,434	VBK50
RTV322	VBK43
RTV328	VBK52
RTV350,356,456	VBK131
RTV424,444	VBK46
RTV716,725,785	VBK131
RTX200	VBK11

##### CASIO

VX2000	VBK88
--------	-------

##### COMPUTAR

CTR3024	VBK118
---------	--------

#### Suit      Code

##### DEITRON

DVR6158D	VBK103
----------	--------

##### DISTAR

DS757	VBK97
-------	-------

##### E.S.C.

VCR8025	VBK85
---------	-------

##### FUNAI

VCR4600,4800	VBK110
VCR5200,5400	VBK110
VCR5600,6600	VBK110
VIP5000	VBK110

##### FISHER

FVH-P520	VBK82
FVH-P530	VBK96
FVH-P620	VBK94
FVH-P710,720	VBK94
VBS9000	VBK27

##### HITACHI

VT7E,8E	VBK67
VT11E,17E,19E,20E	VBK68
VT33E,35	VBK72
VT63E,88	VBK68
VT138	VBK108
VT168	VBK108
VT178E	VBK73
VT258	VBK68
VT330	VBK73
VT518	VBK51
VT640,660	VBK73
VT860	VBK73
VT3000	VBK42
VT5000	VBK. 5
VT6500,6800	VBK115
VT8000,8050	VBK44
VT8500	VBK65
VT9300	VBK66
VT9500	VBK114
VT-P30	VBK72

##### HMV

HV1000	VBK41
HV2000	VBK53
HV3000	VBK54
HV4000	VBK45
HV7000	VBK4
HV8000	VBK36
PP24	VBK74

##### GAC

VB910	VBK81
-------	-------

##### G.E.

6900	VBK45
64007300	VBK64
8100	VBK64
8900	VBK36
9300	VBK64

##### GENERAL

VGX930A	VBK102
---------	--------

##### CASIO

VX2000	VBK88
--------	-------

##### COMPUTAR

CTR3024	VBK118
---------	--------

#### Suit

#### Code

##### GOLDSTAR

GHV1232,1240,1246	VBK79
GHV1296	VBK102
VCP100,105,110,	VBK119
VCP120,126,	VBK119
VCP4100	VBK79

##### GENERAL

VG220A	VBK32
VGX510	VBK99
VGX540	VBK109
VGX625,645	VBK109
VGX715,720	VBK110
VGX815,820A	VBK87

##### JVC

CP5000E	VBK75
CR6000E,6060E	VBK75
HR2200	VBK74
HR2650	VBK45
HR3300,3600	VBK53
HR3330	VBK. 7
HR3360,3660	VBK54
HR4100	VBK20
HR7200	VBK45
HR7650,7655	VBK36
HR7600	VBK36
HR7700	VBK. 4
HR-D110,111	VBK64
HR-D120,125	VBK64
HR-D140,141,143	VBK78
HR-D150,152,156	VBK78
HR-D157,158,160	VBK78
HR-D170,171,180	VBK77
HR-D190	VBK78
HR-D220,225	VBK64
HR-D250,275	VBK78
HR-D320,370,430	VBK86
HR-D455	VBK78
HR-D520,521,522	VBK116
HR-D540,580	VBK124
HR-D565,566	VBK78
HR-D600,610,620	VBK116
HR-D725,755	VBK78
HR-D790	VBK125
HR-D830	VBK116
HR-DX20,22	VBK116
HR-J200,400	VBK116
HR-J220,221	VBK128
HR-J255,455	VBK133
HR-J600	VBK127
HR-J625,635	VBK128
HR-J655,755	VBK133

##### KAMBROOK

KVP120	VBK119
--------	--------

##### MARANTZ

MV740A	VBK61
--------	-------

See Sharp/Philips

##### MITSUBISHI

(SEE ALSO AWA)

HS337,338	VBK111
HS347,349	VBK111
HSE11,21,41	VBK118
HSM54,59	VBK118
HSMX1,X2	VBK118
HSMX7	VBK126

##### NORMENDE

VR200	VBK41
-------	-------





Suit	Code	Suit	Code	Suit	Code	Suit	Code
<b>NATIONAL/PANASONIC</b>							
NV-MI,M3	VBK51	PIONEER	VBK83	SANYO	VBK105	TEAC	VBK87
NV250,280	VBK50	VBH-780D	VBK83	VHR120	VBK105	MV306,307,308,330P	VBK120
NV300,333,340	VBK12			VHR1100,1300	VBK89	MV314,315	VBK120
NV370	VBK49			VHR1500	VBK89	MV3410,4810	VBK120
NV450,470	VBK50			VHR2500	VBK104	MV400,430	VBK88
NV730,770	VBK52			VHR2700	VBK92	MV435,440	VBK88
NV750	VBK47			VHR3100,3500	VBK90	MV445,450,616	VBK87
NV777,788	VBK43			VHR3700	VBK90	MV7,77,777	VBK131
NV850	VBK46			VHR4100,5100	VBK105	MV1400,1414TV	VBK88
NV870	VBK50			VHR5300,5700	VBK105	MV1480	VBK87
NV2000,3000	VBK11			VHR7100,7200	VBK105	MV2020TV	VBK88
NV7000	VBK10			VHR7500,7900	VBK105		
NVT200,7500	VBK8			VHR-D500,D700	VBK90		
NV8170	VBK95			VHR-D4400,4600	VBK105		
NV8400	VBK35			VHR-D4800,4890	VBK105		
NV8600,8610,8620	VBK9			VHR-D5810	VBK105		
NV-G7,9,10,11,12	VBK79			VHR-S-700	VBK106		
NV-G16,30	VBK79			M10,M20N,M50,NX10	VBK59		
NV-H70A	VBK79			VTC5300,5400	VBK57		
				VTC5500	VBK27		
				VTC6500	VBK60		
				VTC9300,9500	VBK. 6		
<b>THE LATER MODELS USE ONE BELT ONLY eg.</b>							
NVD48,80,							
NV-G20,21,28,							
NV-G33,38,45,48,							
NV-H65,75,NV-L25,							
FS1,90,100, RTV740,..							
Code	VDV0169						
Cost	3.05						
<b>NEC</b>							
DS6000	VBK83						
DX1600,3000	VBK83						
N830EA,831A,833EA	VBK64						
N901,904,911,912	VBK70						
N9033,9034,9040	VBK83						
N9052,9053	VBK83						
N9063,9065,9066	VBK83						
N9073,9083,9280	VBK83						
N9401,9402	VBK83						
N9530,9570,9580	VBK83						
N9610,9680	VBK83						
PVC754E	VBK63						
VCP1	VBK83						
VCR5000	VBK64						
VH81,91	VBK105						
VN23,26,64	VBK123						
VN30,32,32	VBK105						
VN35,70,71	VBK105						
<b>ORION</b>							
Some units may have different mech's for the same model No.							
The following is a general guide							
for the most likely "VBK" to suit.							
<b>NATIONAL MECH. TYPES eg.</b>							
VH2A MK11	VBK11						
<b>SHARP MECH. TYPES eg.</b>							
VH3C, VN2B	VBK39						
<b>ORION MECH. TYPES eg.</b>							
2B	VBK84						
RVP-114	VBK121						
VC10P	VBK117						
VCP	VBK117						
VCRLS, VDLJ, VLBK	VBK130						
<b>PALSONIC</b>							
VCR5000	VBK99						
VCR6000	VBK88						
VCR7000	VBK100						
VCR8000	VBK102						
VCR9000	VBK87						
VCR9500	VBK122						
<b>PIONEER</b>							
VBH-780D	VBK83						
<b>PANASONIC</b>							
SEE NATIONAL							
<b>PHILIPS</b>							
VR107,110	VBK132						
VR155,255,455	VBK128						
VR210,275,299	VBK132						
VR256	VBK128						
VR257,357,357,399	VBK132						
VR401,501,502	VBK39						
VR456,656	VBK128						
VR457,499,610,620	VBK132						
VR555,655,755	VBK128						
VR601,701,901	VBK39						
VR656	VBK128						
VR757,799,810	VBK132						
VR820,857,899	VBK132						
VR856	VBK128						
VR3360	VBK102						
VR3442	VBK116						
VR6440,6540	VBK61						
VR6441	VBK62						
VR6442,6443	VBK69						
VR6448,6475	VBK102						
VR6520	VBK69						
VR6540	VBK61						
VR6542,6543	VBK69						
VR6548,6549	VBK102						
VR6743	VBK69						
VR6541,6575,6937	VBK62						
VR6640,6740,6940,6840	VBK61						
VR9489	VBK131						
<b>PRESIDENT</b>							
PV300,500	VBK117						
<b>PYE</b>							
VRS012,022	VBK39						
VRD100	VBK107						
VRD300	VBK103						
<b>RANK</b>							
RV300	VBK41						
RV310	VBK7						
RV320	VBK54						
RV330	VBK4						
RV340	VBK45						
RV350	VBK36						
RV360,370,380	VBK64						
VP100	VBK74						
<b>SAMSUNG</b>							
VB617,617C	VBK98						
VB627,629	VBK98						
VB711	VBK97						
VB711A	VBK107						
VB750	VBK107						
VB900A,910	VBK81						
VB970,971,972	VBK97						
VB2215P	VBK81						
VB8220	VBK107						
PB981R	VBK107						
<b>SANYO</b>							
MHCU800	VBK134						
SLC5E	VBK14						
SLC6E	VBK28						
SLC7E, SLT7E	VBK14						
SLT9ME	VBK22						
SL5400,5600,5800	VBK31						
SLVX10PS,20PS	VBK105						
SLVX25PS	VBK105						
SLVX37,X57	VBK122						
<b>SONY</b>							
SOME MODELS	VBK45						
See JVC							
<b>VIDEO-PRO</b>							
VCR8025	VBK85						
<b>TANDY</b>							
2B	VBK84						
<b>TEAC</b>							
VHR120	VBK105						
VHR1100,1300	VBK89						
VHR1500	VBK89						
VHR2500	VBK104						
VHR2700	VBK92						
VHR3100,3500	VBK90						
VHR4100,5100	VBK105						
VHR5300,5700	VBK105						
VHR7100,7200	VBK105						
VHR7500,7900	VBK105						
VHR-D500,D700	VBK90						
VHR-D4400,4600	VBK105						
VHR-D4800,4890	VBK105						
VHR-D5810	VBK105						
VHR-S-700	VBK106						
M10,M20N,M50,NX10	VBK59						
VTC5300,5400	VBK57						
VTC5500	VBK27						
VTC6500	VBK60						
VTC9300,9500	VBK. 6						
<b>TELEFUNKEN</b>							
VR200	VBK41						
VR400	VBK54						
VR440	VBK41						
VR449	VBK54						
VR500	VBK54						
VR540	VBK4						
<b>TEMPEST</b>							
TE77R	VBK107						
TE90H	VBK97						
TE99R	VBK103						
TE900A	VBK81						
TE970	VBK85						
<b>TITAN</b>							
VCR1500	VBK45						
VCR1600	VBK64						
<b>TRACKTON</b>							
VCR-32	VBK85						
VCR-417TR	VBK87						
<b>TOSHIBA</b>							
V31,33	VBK21						
V55,57	VBK64						
V63	VBK78						
V71,73,74,75	VBK101						
V81,83,84,85	VB						



# Video Repair Parts

## Belt Kits

### VIDEO BELT KITS

Code number and cost listing. Primary models listed only, due to space. For other models, see Cross-Reference Pages.

Suit	Code	Suit	Code
AKAI VS7300	VBK1	HITACHI VT33E	VBK72
AKAI VS9700	VBK2	HITACHI VT640, 660, 860	VBK73
AKAI VS2E/V5E	VBK3	JVC 2200, AKAI VP77	VBK74
AKAI VS10, JVC HR7700	VBK4	JVC CR 5000E, 6000E, 6060E	VBK75
HITACHI VT5000E	VBK5	AWA AV12, AV14	VBK76
SANYO 9300/9500	VBK6	JVC HRD170, 370	VBK77
JVC HR3330	VBK7	JVC HRD140 etc	VBK78
NATIONAL NV7200EN	VBK8	NATIONAL NVG7, 9, 16	VBK79
NATIONAL NV8600/NV8620	VBK9	GOLDSTAR VARIOUS	VBK79
NATIONAL NV7000	VBK10	AKAI/SAMSUNG/TEMPEST 900	VBK81
NATIONAL NV2000	VBK11	FISHER FVH-520	VBK82
NATIONAL NV300/NV340	VBK12	NEC N9530A	VBK83
SONY SL8000/SL8080	VBK13	ORION VH2B	VBK84
SONY C5E/C7E/T7E/T9E	VBK14	SAMSUNG and equivalents	VBK85
TOSHIBA V5250/V5280	VBK15	JVC HR-D430EA	VBK86
SHARP VC7300	VBK17	TEAC MV330P, 450, 445	VBK87
SHARP VC6300	VBK18	TEAC MV400, 430, 435 etc	VBK88
SHARP VC6000	VBK19	SANYO VHR-1300	VBK89
JVC HR4100	VBK20	SANYO VHR-3100	VBK90
TOSHIBA V31/V33	VBK21	AKAI VS22	VBK91
SONY SLT9ME	VBK22	SANYO VHR-2700	VBK92
SHARP VC2300K	VBK23	AKAI VS200	VBK93
SHARP VC387	VBK24	FISHER FVHP620, 710, 720	VBK94
SHARP VC3300	VBK25	NATIONAL NV8170	VBK95
SHARP VC220N	VBK26	FISHER FVH-P530	VBK96
SANYO VTC5500	VBK27	TEMPEST TE90H	VBK97
SONY SLC6E	VBK28	SAMSUNG VB617, etc	VBK98
TOSHIBA V5470/V7540	VBK29	PALSONIC VCR5000	VBK99
SHARP 7650	VBK30	PALSONIC VCR7000	VBK100
SONY SL5400/SL5600	VBK31	TOSHIBA V71, 73 etc	VBK101
TOSHIBA V5310C/V5310T	VBK33	SHARP VC-A105	VBK102
AKAI 9300/9500/9800	VBK34	TEMPEST TE99R	VBK103
NATIONAL NV8400	VBK35	SANYO VHR-2500	VBK104
RANK RV350, HMV8000	VBK36	SANYO VHR-4100	VBK105
AWA ATVI ATI	VBK37	SANYO VHR-S700	VBK106
SHARP 300 & 9000 SERIES	VBK39	TEMPEST TE77R, PB980R	VBK107
AKAI VS7100	VBK40	HITACHI VT138	VBK108
HMV1000-RANK RV300	VBK41	GENERAL VGX540/625/645	VBK109
HITACHI 3000	VBK42	GENERAL, FUNAI	VBK110
NATIONAL NV777	VBK43	AWA, MITSUBISHI	VBK111
HITACHI 8000/8050	VBK44	TOSHIBA V93	VBK112
JVC HR2650/HR7200	VBK45	TOSHIBA V500	VBK113
NATIONAL NV850	VBK46	HITACHI VT9500	VBK114
NATIONAL NV750	VBK47	HITACHI VT6500, 6800	VBK115
NATIONAL NV370	VBK49	JVC HRD520, 522, 600	VBK116
NATIONAL NV470	VBK50	PRESIDENT PV300, PV500	VBK117
NATIONAL NV-M1	VBK51	MITSUBISHI HSE11, MX1, 2	VBK118
NATIONAL NV730/770	VBK52	GOLDSTAR KAMBROOK	VBK119
JVC HR3300	VBK53	TEAC MV314, 315	VBK120
JVC HR3660	VBK54	ORION RVP-114	VBK121
AKAI VS3/VS4	VBK55	SONY SLVX37	VBK122
SHARP VC8300	VBK56	NEC VN23, 26, 64 & AWA	VBK123
SANYO VTC5300	VBK57	JVC HRD540 / 580	VBK124
SANYO M10/M20/NX10	VBK59	JVC HRD790	VBK125
SANYO VTC6500	VBK60	MITSUBISHI HSMX7	VBK126
SHARP VC400 SERIES	VBK61	JVC HRJ600	VBK127
SHARP VC581, 582, 583 etc	VBK62	JVC HRJ220, 221, 625	VBK128
NEC PVC754E	VBK63	AMSTRAD DD9904	VBK129
JVC HR-D110/D120/D225	VBK64	ORION VCRLS, VDLJ, VLBK	VBK130
HITACHI VT8500	VBK65	PHILIPS VR9489-39	VBK131
HITACHI VT 9300	VBK66	PHILIPS VR155 TO VR755	VBK132
HITACHI VT7E, VT8E	VBK67	JVC LP30005-003, -005	VBK133
HITACHI VT19E/20E/63E/88	VBK68	SONY MHCU-800	VBK134
SHARP 600 & 700 SERIES	VBK69		
NEC 901A, 911A	VBK70		
AKAI VS112, 115	VBK71		

10 KITS ASSORTED LESS 10%  
50 KITS ASSORTED LESS 20%  
100 KITS ASSORTED LESS 25%

MOST VCR USE ONLY ONE BELT?...  
If only one belt! See following pages.



MORE MODELS AVAILABLE SEE:


<http://www.wes.com.au/>



## □ Video Belts & Idler Tyres

### AKAI

Original Part No	Suit	Size	Code
MB387289J	VS12,F10	1.8 <sup>2</sup> x 33mmØ	33X1.85
MB364011	VS112,115, VS165,etc.	1.8 <sup>2</sup> x 77mmØ	77X1.8
MB420053N	VSG mech.		BLT4011
BM433627N	VSG Mech	72x2x2mm	97X2
			72X2



### JVC

Original Part No	Suit	Equiv.	Code
HRD170,180,370,400, HRD530, HRS5000, 5500.		PQM30003-19	
HRD160,200,230, HRD400,530, S5000, etc.		PQM30003-20	
PU48941-2	HR7200,etc.	PU50350	29X1.6
	HR-D540, 580.		PU61006

### NEC/DAEWOO

#### CAPSTAN BELT

Original	79TD 3675
Part No	
Suit	NEC VN23, VN26, AWA 2H20D,4H40D, and others.
Code	66X2

#### LOADING BELT

Original	97S5500100, 79TD4460
Part No	
Suit	VN23,26, AWA 2H20D,4H40D,
Code	39X2

#### LOADING BELT

Original	16629251
Part No	
Suit	N901,904,911,etc
Code	30X1.45



#### REEL BELT

Original	97S5501800
Part No	
Suit	VN20
Code	62.5X2



#### REEL BELT

Original	97S 550 2300, 79TD
Part No	3940
Suit	VN22, VN25, NEC, AWA, and others.
Code	72X2




#### REEL BELT

Original	97S 550 0400
Part No	
Suit	D284G, D884G, DVK10W, 224D, DVK424D, 824D4, MV3080, 6080.
Code	69X2



### PANASONIC/NATIONAL

Code	VDV0149
	VDV0169
	VDV0235



### SAMSUNG

Original Part No	Suit	Code
65274-603-	VB1230, etc. PB991, 210 etc. VX & VR,...	VDV0149
65274-603-	VB300, 306, 320, 336 910	82X2
61794-0009-00	SV10, 11, 12, 30, 80, 140	BLT6009

### SHARP

#### MAIN BELT

Original Part No	NBLTK0067AJ00
Suit	VCA220, 270, 420, 470
Code	77.5X1.9




#### CAMCORDER BELT

Original Part No	NBLTK0054GEOO
Code	17X1

#### REEL BELT

Suit	VCA36,37,41,50,53,62, VCA67,93,94,97,98,...
Code	110X2



### SONY

#### SYNCHRO BELT


Original Part No	Suit	Code
3-977-510-01	SLVKH7,9	105X2
3-679-119-11	SLC30,32,33, SLC34,35,40.	BLT1911

#### TOOTHED BELT

Original Part No	Suit	Code
3-736-013-01	SLV215,353,757, SLVX30,35,50, SLVX810,etc.	BLT1301

### TEAC PALSONIC

Original Part No	62D80650920
Suit	MV3010, 3030, 3050, MV4010, 6010, Palsonic VCR9688
Code	69X2



### PANASONIC GEAR KIT

Kit combines VXP0767 VDV0159 and washers.

Code	VXP0917K
------	----------



# Video Repair Parts

## VCR Idler Tires

### VIDEO TYRES & BELTS

Part numbers quoted are original manufacturers' part numbers for the complete assembly. Tyres only are supplied. When ordering please quote our VIT number only or you may receive the whole assembly! Many units are identical internally so you may find these tyres will substitute with other part numbers, other brands, etc.



### AWA-THORN

Original Part No 522P002101 IDLER	Code VIT70
--------------------------------------	---------------

### AKAI TYRES

Original Part No BV321979 TYRE	Code VIT20
-----------------------------------	---------------

### JVC TYRES

Original Part No PU58645-1-4 TYRE	Code VIT240
--------------------------------------	----------------

### PANASONIC TYRES

Original Part No MOTOR SLV NV730,777,788	Code VIT400
VXP0521 IDLER 24X30X3	VIT352
VXP0521 IDLER 23X30X3	VIT353

### SANYO TYRES

Original Part No 143-0-551T-01400 REW IDLER	Code VIT500
143-0-547T-00200 FF IDLR	VIT502
143-0-662T 01201 REEL DR, 143-0-741T-20001	VIT512
143-0-741T-11101 FWD RLR	VIT516

### SHARP TYRES

Original Part No NIDL0005GEZZ IDLER	Code VIT608
NIDL0006GEZZ IDLER.	VIT612
MLEVF0027GEZZ F/F IDLER	VIT614
NBLTK0054GEOO Camcorder	17X1
NPLYV0107GEZZ PULLEY and	VIT632
NPLYV0111GEZZ PULLEY	

### SONY

Original Part No X-3659-324-0	Code VIT708
A-6706-348B	VIT720

## VCR Pinch Rollers

### Akai

#### AKAI PINCH ROLLERS FROM VS SERIES

The original pinch roller used in some VS series Akai VCR's was a one piece type. The roller only for this assembly is VPR67. The one piece assembly has been upgraded and if a complete assembly is ordered then a new TWO piece type (VPR150) will be supplied. The roller only for VPR150 is a VPR69. We recommend using VPR150 for reliable service.



OLD TYPE

Original BL-387501J1

Part No

Equiv. BL-V1075A180D

Suit

VS22,26,35,55,66,75,77,  
VS422,425,465,725, VSA650  
,VSF10,11,220,221,400,410,  
VSF422,425,430,600

Code VPR150




#### AKAI PINCH ROLLER

Original BL433609N3, N4

Part No

Suit VSG280, VSG2DPL,  
VSG765, VSG790,  
VSG875.

Code VPR156



## Daewoo


### DAEWOO

Original 97SB381800, 79TD3701

Part No

Suit VN22,25, NEC, AWA, etc

Code VPR185




### DAEWOO

Original 97SA310700

Part No

Suit D284G, etc.,

Code VPR187



## Funai / Teac



### FUNAI/TEAC

Original 8059-06-301

Part No

Suit VCR417 & More...

Code VPR180






## □ Goldstar / LG / NEC


### GOLDSTAR

Original 333-209  
Part No  
Code VPR170



### GOLDSTAR / NEC PINCH ROLLER

Original 340-070A, 340-073A, 340-  
Part No 195A, 386-401A, 4930-  
Suit 0138A, NEC 79VG1020  
Code VPR171



### GOLDSTAR LG PINCH ROLLER


Original 4261R0011A  
Part No  
Suit AC250, 450, 950, AF293,  
493, 993, Akai VSJ200,  
215, 411, VSJ416, 700, 711,  
VSJ716, etc...  
Code VPR230



## □ Hitachi

### HITACHI PINCH ROLLER

Original 6975768, 6384352  
Part No  
Suit VTM598E, VTM838E  
Code VPR220




## □ JVC / Philips

### JVC PINCH ROLLER


Original PQ43558  
Part No  
Suit HRD520, 640, 830,  
HRDS5000, HRDX20EA,  
Philips VR3241, VR3275  
Code VPR143

Lifter to suit  
PQ32415




### JVC PINCH ROLLER

Original PQ42006B  
Part No  
Suit HRD170, etc. HRD200, 210,  
HRS5000, HRS5500,  
HRS9000  
Code VPR141




### JVC PINCH ROLLER

Original PQ45921E, PQ45921A6  
Part No  
Suit HRJ600  
Code VPR139




## JVC PINCH ROLLER

Original PQ40134B  
Part No  
Suit HRD110, 120, HRD121, 225,  
NEC N531, 830, 833 GR8100,  
9300, and others.  
Code VPR140




## JVC PINCH ROLLER ARM

Original JVC PQ46327A-2 Philips  
Part No 482252811051  
Suit HRJ425, 435, HRJ625, etc.  
Philips VR656-75, VR555-75  
Code VPR142



## JVC / PHILIPS PINCH ROLLER

Original LP40105-001A/B 4822-402-  
11057  
Part No  
Suit HRJ255, 455, HRJ655, 755.  
VR288, 388.  
Code VPR165



## JVC PINCH ROLLER ASSEMBLY

OEM PQ43558C, 482240370447  
Model. HRDX20, VR3241/75  
Code VPR144




## □ Mitsubishi

### MITSUBISHI PINCH ROLLER


Orig. 948D20010 or 789C007020  
Suit HSE11, 12, 21,

Description	Code
Original	VPR160
Replacement	VPR161



### MITSUBISHI PINCH ROLLER


Original 948D044001  
Part No  
Suit HSM50,X3, HSMX5,X7,  
HSMX10,20.  
Code VPR175



## □ NEC

### NEC PINCH ROLLER

Suit VN26, 26 NEC 79TD3683  
97SA300600  
Code VPR186






# Video Repair Parts

## Overhaul Replacement Kits

### NATIONAL PINCH ROLLER


Original Part No	VXL1674	VXL1772
Suit	NV-MC10	NV-MC30, MS50
Code	VPR118	VPR136



### PANASONIC ROLLER ASSEMBLY


VXL1858 or VXL1743 NV-G20, 21, 22, 25, NV-G28, 40, 45,...  
NV-D38, D48, NV-H65, H75, RTV740, etc...

Code  
VPR120



### NATIONAL PINCH ROLLER


Original Part No	VXP0330
Suit	NV2000, 3000, Series
Code	VPR130



## Panasonic

### PANASONIC ROLLER ASSEMBLY

Original Part No	VXL2676, VXL2785
Suit	NVSD220, 270, 420, NVHD620, 670.
Code	VXL2676



## Philips / Teac

### PHILIPS TEAC PINCH ROLLER - UPDATE

Original Part No	4822 528 70774, 8619 119 175
Suit	MV7, 77, 777, RTV785, VR9489,
Code	VPR274



(Differs to original by roller shaft diameter)

### ROLLER ONLY - 2 TYPES 2.5mm & 3mm

#### 3.0mm BEARING SHAFT


ROLLERS ONLY  
Fits the new VPR274

Code  
VPR125

#### 2.5mm BEARING SHAFT

Roller only. Suit original.

Code  
VPR124




VPR274 (Above) will replace assemblies in ALL units!

## Sharp


### SHARP PINCH ROLLER

Original Part No	MLEVF0281GEZZ
Suit	VCA10,30,35,60,105, 111,115,125,505,etc...
Code	VPR134




### SHARP PINCH ROLLER

Original Part No	MLEVF0416GEZZ
Suit	VCA36X,37X,50X
Code	VPR416



### SHARP PINCH ROLLER


Original Part No	MLEVF0500GEZZ
Suit	VCA220, 270,VCA420, 470.
Code	VPR500



## Samsung

### SAMSUNG PINCH ROLLER


Original Part No	61523002101
Suit	VB300, VB370, etc.
Code	VPR190



## Sanyo

### SANYO PINCH ROLLER

Original Part No	613-151-8803
Suit	VHR510,530, VHR590,610, VHR630,650.
Code	VPR205




## Sony

### SONY PINCH ROLLER

X3749-173-4, X3749-770-1

Suit	SLV215,353 SLV757,777, SLVX30,X50, SLVX810,etc.
Code	VPR200






## Video Pinch Roller Listing

### VIDEO PINCH ROLLERS AND ASSEMBLIES

Please note that the substitution listing is to be used as a guide only.  
Please measure the roller required and choose from the dimensions listed.



Suit	Amm x Bmm x Cmm	Code
AKAI VS1, 2, 3, 4, 5, 6, 8, 15 and others.	13 X 18 X 3	VPR64
AKAI VS10, 9300, 9500, 9800, AKAI VP77, * HMV VP77 JVC-HR2200, 3300, 3330, 3660, RANK VP100 PALSONIC VCR5000, 6000	15 X 21 X 4	VPR56
AKAI VS11, 12, SHARP NROLR0005GEZZ SUITS EARLY MODEL SHARP VC6000, 6300, 7000, 8000, 9000, ALL 300 SERIES plus VC2300, 3300 ORION VH3 TEMPEST TE77R, TE90H, DISTAR DS757, PHILIPS VR401, 501, 502, 701, 901 AKAI VS11, PYE VRD100L SAMSUNG VB750, VB970, 971, VB8220 PLUS OTHERS. THIS IS A VERY POPULAR TYPE USED IN TOO MANY MODELS TO LIST.	18 X 20 X 4	VPR59
AKAI VS112, 155, 165, 240, 515	18 X 20 X 3	VPR66
AKAI VS202, 303, 606, 607 VSP8	16 X 20 X 3	VPR68
AKAI VS22, 35, 53, 66, 422, 425, 725 VSA77, VSF10, 11, 400, 410, 422, 425, 430, 600 * NOTE. THIS SUITS THE 2 PIECE TYPE ASSEMBLY.	18 X 18 X 3	VPR69
AKAI VS33, 35, 53, 55, 66, 422, 425, 426, 427, 725, VSF10, 11, 220, 400, 410, 422, 425, 430, 600 * NOTE. THIS SUITS THE ONE PIECE TYPE ASSEMBLY. * SEE DETAILS ON THE NEXT PAGES FOR "AKAI PINCH ROLLERS"	18 X 18 X 3	VPR67
AKAI VS9700	16.5 X 20 X 4	VPR61
AKAI VSG204... VSG2100... VSG305... VSG405...		VPR155
AKAI VSJ200, 215, 411, 416, 700, 711, 716. SANYO VHR-VK210, ROLLER FROM VXL2785 (NOT VXL2676 - Check "C"!) Panasonic NVHD620A, 670A, NVSD220A, 270A, 420A. GOLDSTAR AF293, 493, 993, AC250, 450, 950. NEC VN204 *	14 X 18.5 X 2.5	VPR123
Please Note! Similar outer dimensions to VPR50 and VPR121		
FISHER FVH-P620, 710, 720, 725	15.5 X 21 X 4	VPR80
GOLDSTAR 434-037D GHV SERIES.	18 X 17 X 4	VPR40
HITACHI VT100, 128, 135, 138, 168, FISHER FVH-P905, 908, 910, 911, etc.	15.5 X 19 X 4	VPR78
HITACHI-VT7, 11, 14, 17, 33, 35, 88E, 4000, 4200, 5000, 6500, 6800, 7000, 8500, 9300, 9500, 9700, and FISHER FVH-P520, 530 and others.	15.5 X 22 X 4	VPR60
HRD170, 180, 200, 210, 230, 300, 320, 330, 337, HRD370, 377, 400, 430, 470, 530, 700, 750, 950, HRS5000, 5500, 9000, etc..	17 X 17 X 4	VPR104
JVC HR2650, 7200, 7600, 7610, 7655, 7650, 7700 GE-V9600 * HMV4000, 7000 RANK RV330, 340, 350 * T/FUNKEN VR530	17 X 21 X 4	VPR90
JVC HR-D110, 111, 120, 121, 125, 140, 150, 160, 225, 250, 455, 565, 566, 755, NEC ALL 800 SERIES N830, 833, 895 ETC	17 X 18 X 4	VPR105
TOSHIBA V55, 57, 71, 73, 75, 81, 83, 84, 85, 86 GENERAL GE8100, 9300 THIS IS A VERY POPULAR TYPE USED IN TOO MANY MODELS TO LIST		
JVC HR-D230, D520, D521, D530, D540, D580, D600, D610, D620, HR-D830, HR-DX20EA, HR-S5800, & PHILIPS VR3241/75	16 X 17 X 4	VPR106
MITSUBISHI AV SERIES AV12, 14, 47, 51, 58, 59, 400, 410, HS SERIES HS30, 304, 306, 307, 310, 318, 319, 337, HS338, 347, 349, 400, 410, 411, 412, SOME HSE SERIES HS-E10, 20, 70, 347 THORN TR102	15 X 18 X 4	VPR75
MITSUBISHI HSE11, 12, 21, 27, 31, 41... Also HSM and HSMX Series. SAMSUNG SV10, 11, 12, 30, 80, 81, 140	14 X 17 X 3	VPR76
NATIONAL- NV100, 600, 300, 333, 777, 788, and BLAUPUNKT equivalents.	16 X 23 X 3	VPR87
NATIONAL NV250, 280, 370, 430, 450, 460, 470, 730, 770, 830, 850, 870, 2000, 3000, 7000, 7200, 8400, 8600, 8610, 8620	18 X 23 X 3	VPR57
NV-G7, 9, 10, 11, 16, 30, ORION VH-1, 2, 2B PHILIPS VR6920, GENERAL VGX540A, 625A		
NEC ALL 900 & MANY 9000 SERIES, DX1600, DX3000, Original P/No. 016-17-8363, PALSONIC VCR9688, TEAC MV3010, 30, 50, MV4010, 6010.	16 X 19 X 4	VPR70
NEC DS6000A, N9073, N9570	15 X 17 X 4	VPR71
NEC VN22, 23, 25, 26 97SB361200 DAEWOO DVR4773 70322134 2H20D 4H40D TOSHIBA V31, 33, 51, 53, 8600, 8650, 9600, VP88	15 X 17.5 X 3	VPR110
ORION VC-RLS, VL-BF, UD-LS	15 X 18 X 4	VPR35
PHILIPS BLAUPUNKT TEAC, etc.	12.5 X 17 X 2.5	VPR124
PHILLIPS VR2020, 2022, 2023, 2021, 2024	12.5 X 20.5 X 3	VPR107
SANYO 6130372161 VHR1300, 1500, 2500, 2700	16 X 23 X 3	VPR115
SANYO VHR120, 4100, 5100, 5200, 5300, 5700, 7100, 7200, 7500 VHR-D4600, D4800, S700, VN-20, 31, 32, 70, 71, NEC VH81, 90, 91.	15.5 X 18 X 3	VPR117
SANYO VHR3100, 3300, 3700, VHR-D500, D700	16 X 18 X 3	VPR116
SANYO VTC5000, 5005, 5300, 5400, 5500, 6000, 6500, 9100, 9300, 9350, M10, M20, M30, M50 and others.	15 X 19 X 4	VPR58
SHARP all VC400 & 500 series eg. VC481, 581 etc. AKAI VS200 & VSP3, DETRON DVR6158, ESC VCR8025, Philips VR6440, 6441, 6540, 6541, 6640, 6641, 6740 etc. Tempest TE99, TE900, TE970R, Trackton VCR32, VCR52, Orion VCP Samsung BV617C, 627, 629, 900, 910 etc. Marantz MV740A Goldstar GHV1232, 1240, 1246, 1291, 1295, 1296, etc Videopro VCR8025 THIS IS A VERY POPULAR TYPE USED IN TOO MANY MODELS TO LIST.	18 X 17 X 4	VPR108
SHARP LATE VCA SERIES BLAUPUNKT RTV560, 740, etc... ROLLER ONLY FROM VPR120, VXL1743 & VXL2676	14 X 18.5 X 3	VPR121
Panasonic NVG series NVG20, 21, 22, 25, 40 AND MANY OTHERS. Panasonic NVJ, NVL, NVF, NVD series. TEAC/FUNAI MV3410, 4810 * Please Note! Similar outer dimensions to VPR50 and VPR123 *D = 8.3mm		
SHARP P/No. ROLR0013GEZZ Suit VC-6V3, VC600, 682, 685, 693 SHARP 700 SERIES VCA101, 103, VCH851, etc.	18 X 18 X 4	VPR113
PHILIPS 6442, 6443, 6520, 6542, 6543, 6549 etc. THIS IS A VERY POPULAR TYPE USED IN TOO MANY MODELS TO LIST		
SONY ALL LATE MODEL VHS SLVX30, 35, 50, etc. Sharp VCA, VCH, etc.. ROLLER ONLY FROM VPR134 Philips VR6448, 6449, 6548, 6591, etc... Goldstar RG20, AWA AV66, etc... * Please Note! Similar outer dimensions to VPR121 *D = 7.7mm	14 X 18 X 3 X *	VPR50
SONY SL-C5, C7, J7, T7, T9, 8000, 8080	16 X 19 X 3	VPR55
SONY SLVX37, KV14VMIAS	17 X 19 X 4	VPR52
TEAC/FUNAI MV305, 307, 330, 400, 417, 430, 435, 440, 445, 450, MV1440TV, MV220TV GENERAL VGX815A PLUS EQUIVALENTS eg. CASIO, TANDY etc.	15 X 19 X 4	VPR72



# Video Repair Parts



## VCR Overhaul Kits

## JVC OEM

### OVERHAUL KITS

The following kits are manufactured by the original corporations in Japan and contain all the parts which they recommend to be replaced when the VCR is being serviced.


Please note that many brands use the following kits. We have listed as many models as we are aware of and/or space would allow.



Typical VHS VCR Tape Transport Components

### ORIGINAL JVC OVERHAUL KIT


Suit	HR-D120, HR-D225, NEC N830, 831, N833, GE GEV-7300, GEV-8100, GEV-9300, RANK RV360, RV370, 380.
Code	PTU96075



PQM3003	BELT(D=46mm)
PQM3003-7	BELT(D=116mm)
PQM3003-8	BELT(D=28mm)
PQM3004	BELT(D=27mm)
PQM30017-5	SLIT WASHER X2
PQM30017-8	SLIT WASHER X2
PQ40134B	PINCH ROLLER
PU48907D	REEL DISK ASS.
PU48907E	REEL DISK
PU51390A	TENSION BAND
PU51402A	T'UP IDLER ARM
PU55373	T'UP CLUTCH
PU55374-3-8	IDLER ARM

### ORIGINAL JVC OVERHAUL KIT


Suit	HR-D455, HR-D725, TOSHIBA V63
Code	PTU96078-2



PQM30003-10	BELT(D=55mm)
PQM30003-14	BELT(D=30mm)
PQM30017-12	SLIT WASHER X2
PQM30017-8	SLIT WASHER
PQ40252B-4	P'ROLLER & ARM
PQ40262E	TENSION BAND
PU55822A-10	CASSETTE MECH.
PQM30001-138	TENSION SPRING
PQM30019-14	PAD

### ORIGINAL JVC OVERHAUL KIT


Suit	HR-D160, 171, HR-D180, HR-D211, 230, HR-D300, 320, HR-D321, 337, HR-D470, 530, HR-D750, HR-S5000 HR-S5500
Code	PTU96079



PQM30003-20	BELT(D=19mm)
PQM30017-28	SLIT WASHER
PQM30017-5	SLIT WASHER X2
PQ41948A	TENSION BAND
PQ42006B	P'ROLLER & ARM
PU58645-1-4	IDLER ARM

### ORIGINAL JVC OVERHAUL KIT

Suits	HRD540, HRD580, HRD860, HRD92MS, HRD960, VR6935, VR6943, VR6965, VR6975
Code	PTU96082




PQM30003-23	BELT (D=64mm)
PQM30017-12	SLIT WASHER
PQM30017-8	SLIT WASHER
PQ43501B-11	TENSION BAND
PQ43921B-2	P.R.ARM ASS'Y
PU61004-1-3	IDLER GEAR UNIT
PU61005-1-4	CLUTCH UNIT
PU61006	TIMING BELT



## ORIGINAL JVC OVERHAUL KIT


Suit	HR-D520, HR-D521, HR-D600, HR-D610, HR-D620, HR-D830
Code	PTU96083



PQM30003-23	BELT(D=64mm)
PQM30003-24	BELT(D=93mm)
PQM30017-12	SLIT WASHER
PQM30017-8	SLIT WASHER
PQ43501B-11	TENSION BAND
PQ43558A	P'ROLLER & ARM
PU60618-1-3	IDLER GEAR UNIT
PU60953-1-2	CLUTCH UNIT

## ORIGINAL JVC OVERHAUL KIT


Suit	HR-7200 & Equiv. GE GEV6900, HMV HV4000, RANK RV340
Code	PTU96095



PQM30003	BELT(D=45mm)
PQM30003-2	BELT(D=64mm)
PU48941-2	BELT(D=29mm)
PU49164	BELT(D=88mm)
PQM30017-5	SLIT WASHER X2
PQM30017-6	SLIT WASHER X2
PU48907C	REEL DISK
PU48907D	REEL DISK
PU48967B	IDLER ASSEMBLY
PU51367A	PINCH ROLLER
PU51390A	TENSION BAND
PU51402A	TAKE UP IDLER
PU53462A	TAKE UP CLUTCH

## ORIGINAL JVC OVERHAUL KIT

Suit	HR-7600, HR- 7650, HR-7655, GE GEV8900, HMV HV8000, RANK RV350
Code	PTU96097-2




PQM30003	BELT(D=46mm)
PU48941-2	BELT(D=29mm)
PU49164	BELT(D=88mm)
PQM30017-5	SLIT WASHER X2
PQM30017-6	SLIT WASHER X2
PU48907D	REEL DISK
PU48907E	REEL DISK
PU48967B	IDLER ASSEMBLY
PU51367A	PINCH ROLLER
PU51390A	TENSION BAND
PU51402A	TAKE UP IDLER
PU53462A	TAKE UP CLUTCH

## □ National Panasonic OEM

### PANASONIC "G" MECHANISM PARTS KIT


Contains VXL1490, VXL1743, VXP0878, VDG0597, VML1849, VMX1079, washers and C rings. As the G mech is very popular this kit will suit many models eg. NV-G20, 21, 22, 33, 40, NV-D38, 48, FS1, H65, 75 etc, + RTV740, 560, etc.

Code	VUA4104KIT
------	------------



### PANASONIC "G" MECH VIDEO MAINTENANCE PARTS KIT GENUINE

Suit	NVD38, 48, NVF55, 65, 66, 70, 75, 77, NVG33, 220, 300, NVJ1, 10, 11, 30, 35, 45, NVL10, 15, 20, P10, etc.
Code	VUA4116KIT



VDG0574	Main Cam Gear
VDG0343	Sub Cam Gear
VDG0348	Centre Gear
VDG0547	Clutch Gear
VXP0917	Pulley Unit
VDG0448	Loading Gear
VXP0878	Gear Unit
VML1861	Detent Arm
VDG0342	Ring Gear
VDV0169	Timing Belt
VXL1861	Play Arm
VDG0564	Load Gear T
VDG0419	Load Gear

ILLUSTRATION FROM BOX




# Video Repair Parts

## Overhaul Replacement Kits

### ECONOMY OVERHAUL KIT - JVC

Original & Non-original parts. Suit JVC HR3330, HR3600, 3360, HR3660 and eq's. Contains; PU47752 Take up clutch, PU46381 Unloading idler Belts, tyres, Pinch roller


Code  
VUD1101



### ECONOMY OVERHAUL KIT - JVC

Original & Non-original parts. JVC HR7200 7650, 2650 etc Contains; Idler assemblies PU51402A PU48967B, Take up clutch PU53462A belt kit Tyres pinch roller


Code  
VUD1102



### ECONOMY OVERHAUL KIT - JVC

Original & Non-original parts. JVC HRD-110, 120, etc. NEC N830, 831, 833 Contains; PU55373 Take up clutch, PU55374-3-8 PU51402A Idler arms Belts and Pinch roller.


Code  
VUD1103



### ECONOMY OVERHAUL KIT - NATIONAL

Original & Non-original parts. NATIONAL NV7000, 7200... Contains; VXP0343 Idler, VXP0344 Idler, VDP0908 Roller, VXZ0078 Tension band belts, roller Circlips, and washers.


Code  
VUD4088



### ECONOMY OVERHAUL KIT - NATIONAL

Original & Non-original parts. NATIONAL NV730, 770... Contains; VXP0581 Idler, VDG0177 Gear, VDP0908 Roller, VXZ0165 Tension band Belts, roller Circlips, etc.


Code  
VUD4091



### NATIONAL PANASONIC OVERHAUL KIT

Suits: NATIONAL NV250, NV280, 470, 870... etc. Contains; VXP0521 Idler, VDP0908 Roller, VXZ0165 Pinch roller Circlips and Washers.


Code  
VUD4093KIT



### ECONOMY OVERHAUL KIT - NATIONAL

NATIONAL NV300, NV333, 340... Contains; VXP0434 Idler, VXP0401 Idler, VDP0908 Roller, VXZ0129 Tension band Belts & p'roller Circlips, washers.


Code  
VUD4089



### ECONOMY OVERHAUL KIT - NATIONAL

Original & Non-original parts. NATIONAL NV370, NV850... Contains; VXP0521 Idler, VDP0908 Roller, VXZ0165 Belt All belts, Pinch roller, Circlips and Washers.


Code  
VUD4092



### NATIONAL PANASONIC OVERHAUL KIT

Suits: NATIONAL NV-G7 to 18 NVG30/H70/65... etc. Contains; VXP0521 Idler, VXL1371 Roller assembly, VXZ0165 Tension band Washers and Circlips

Code  
VUD4103KIT



Welcome, VES Admin Test Account - VES Sales Team

Online Catalogue Agencies About Us Contact Us Log Out

Search VES! Enter Keywords or Part No.:  Search

QUICK ORDER

ITEM LIBRARY  SERVICE & REPAIR PARTS  VCR PARTS  ITEM CATEGORY  PINCH ROLLERS

YOUR CURRENT SELECTION

TEST & TOOL  NEW PRODUCTS

HOME > SERVICE & REPAIR PARTS > VCR PARTS > PINCH ROLLERS

Pinch Rollers

Product Display View: List Grid

Category	Sub Category	Product Name	Image
Pinch Rollers	Akai	AKAI PINCH ROLLER	
Pinch Rollers	JVC	JVC	
Pinch Rollers	Mitsubishi	MITSUBISHI PINCH ROLLER	
Pinch Rollers	National	NATIONAL	




## □ VCR Idlers & Gears

### □ Akai


#### AKAI IDLER ASSEMBLY

Original	MI327773
Part No	
Suit	VS2,3,4, 5,6,8,15.
Code	VIA32




#### AKAI IDLER

Original	MI361964
Part No	
Suit	VS606
Code	VIA38




#### AKAI EJECT CAM GEAR

Original	MZ-360428
Part No	
Suit	VS105, 112, VS115,116 Mech. "A"
Code	MZ360428



#### AKAI CAM GEAR

Suit	VS112,165. Mech. "A"
Code	MZ360429




#### AKAI IDLER

Original	MI361964
Part No	
Equiv.	BL-B35110
Suit	VS202,303
Code	VIA25



#### AKAI IDLER ASSEMBLY

Original	BV-327815
Part No	
Suit	VS2,3,4, VS5,6,8,15.
Code	VIA35



#### AKAI GEAR TOGGLE TAKE UP


OEM	MZ424916N04
Model.	VSG204, VSG411, VSG511, VSG858,...
Code	GR4916



#### AKAI CAM GEAR No.4


Cam lever from the cassette housing.

Models	VS202, VS303, VS603, VS606, VS607
Code	MZ353169



#### AKAI IDLER ASSEMBLY

Original	MZ366960
Part No	
Suit	VS105,112, 115,116, 155,165, 240,515,X9...
Code	VIA50




#### AKAI EJECT CAM

Original	MZ364677 Also MZ367952
Part No	
Suit	VS112 Mech. "B"
Code	GR3679




#### AKAI CAM GEAR

Suit	VS112,165. Mech. "B"
Code	MZ364676




#### AKAI GEAR ASSEMBLY

Original	MI387294J
Part No	
Code	GR3872



#### AKAI GEAR CAM JOINT

Original	MZ368797T
Part No	
Suit	VS22
Code	GR3687



#### AKAI LOADING ARM

Original	MZ-V1075A090A
Part No	
Suit	VS35,etc.
Code	GR5090






# Video Repair Parts


## AKAI LOADING GEAR

Original	VT780025
Part No	
Suit	VS1,2,3,4 VS5,6,8
Code	GR7800




## AKAI LEVER ROLLER LINK

Original	BL-B353126
Part No	
Suit	VS202,VS303
Code	BL3531




## AKAI EJECT LEVER

Original	ML749693
Part No	
Suit	VS6,8,15,etc.
Code	ML749




## AKAI LOADING ARM

Original	ML-368792T
Part No	
Suit	VS35,53,55
Code	ML368792T




## AKAI LOADING ARM

Original	ML-368793T
Part No	
Suit	VS35,53,55
Code	ML368793T



## AKAI ARM SHUTTER

Cassette lid opening  
Code  
ML387349



## AKAI LOADING ARM

Original	MZ-V1075A100A
Part No	
Suit	VS35,etc.
Code	GR5100



## AKAI \*

**VS422,425,465,765,965,VSA650,F  
10,F11,F12,F30,F600**


Avoid repairs bouncing because of cassette jamming. Fit/check/replace the following when servicing any of the above models.

**Mod:** Insert **MZ732818** to support the Front loading slider and stop it from jumping the Front loading gear

## AKAI SPACER OUTSERT

Modification part. Mount under "Hook" part.

Code  
MZ732818



## AKAI AIR DAMPENER

Check spring retainer (Hook) Replace if worn.

Original  
Part No  
Code


ML391745J3  
ML3917



## AKAI SHAFT GEAR EJECT


Machined brass Replace if shaft broken.

Code  
MS732791



## AKAI SLIDE LEVER

Original	ML420168N2
Part No	
Suit	VSF440, VSG204, 216, VSG246, 305, VSG315, 317, VSG415, 445.
Code	LEV0168



## AKAI SLIDE LEVER

OEM	ML420110N4
Model.	VSF2160, VSG204, VSG415, VSG745, VSG858...
Code	LEV4210



## AKAI ARM OPENER


Original	ML-353161
Part No	
Suit	VS202,VS303
Code	ML3531





## AKAI GEAR


Suit VSF12 etc.  
Code MZ387333J



## AKAI LOADING GEAR


Use with GR7800

Original VT780026  
Part No  
Code GR7802




## AKAI ARM

Suit VS422, VS425  
Code ML387321




## AKAI CLUTCH DISC

Original MZ387298J3  
Part No  
Suit VS965 VSF30,  
300, VSF261, 441,  
VSF510, 600,  
VSG10, 43, 50.  
Code MZ387298




## AKAI LOADING ARM

Original MZ424917N00  
Part No  
Suit VSG204,...212,  
VSG405, 511,  
VSG2100, etc.  
Code GR4917




## AKAI LOADING ARM

Original MZV1102A090A  
Part No  
Suit VSG10,11,30,  
33,34,35,40,  
43,44,45,50, 54, etc.  
Code GR2090




## AKAI LOADING ARM

Original MZV1102A100A  
Part No  
Suit VSG10,11,30,  
33,34,35,40,  
43,44,45,50, 54, etc.  
Code GR2100




## AKAI CASSETTE LOADING ARM

Original BL424913N06  
Part No  
Suit VSG204,...212,  
VSG405, 511,  
VSG2100, etc.  
Code ARM4913




## AKAI GEAR

Original MI420023N4  
Part No  
Suit VSG204, 311,  
VSG405, 511,  
VSG740, 855,  
VSG2200, etc.  
Code GIA4203



## AKAI CAM GEAR

Original MZ420345J  
Part No  
Suit VSG204,...212,  
VSG405, 511,  
VSG2100, etc.  
Code GR4245




## AKAI MAIN SLIDE LEVER

OEM ML435645N1,  
ML435645N2  
Suits VSG280, VSG2DPL,  
VSG765, VSG790,  
VSG875.  
Code LEV5645




## AKAI PINCH GEAR

Original MZ420067N  
Part No  
Suit VSG204,...212,  
VSG405, 740,  
VSG2100, etc.  
Code GR4267



## AKAI CAM GEAR

Original MZ420064N  
Part No  
Suit VSG204,...212,  
VSG405, 511,  
VSG2100, etc.  
Code GR4264



## AKAI CAM GEAR

Original MZ428104N,  
MZ420328N  
Part No  
Suit VSG204,...212,  
VSG405, 511,  
VSG2100, etc.  
Code GR4204






# Video Repair Parts


## AKAI ARM LOADING BLOCK END

Original Part No	Arm BL433561N7, End BL438155C
Suit	VSG260, 262, 265, VSG460, 465, VSG765, 875, VSP170, etc.
Code	BL438155C



## AKAI SLIDE LOADING PLATE


Original Part No	ML433567N1
Suit	VSG260, 262, 265, VSG460, 465, VSG765, 875, VSP170, etc.
Code	ML433567



## □ Daewoo / NEC / AWA / Tempest


### DAEWO / NEC / AWA IDLER PLATE

Original Part No	97SB382300
Suit	VN22, 25, & more...
Code	VIA3955




### DAEWO / NEC / AWA GEAR TAKE-UP

Original Part No	97SB382410, 79TD3956
Suit	VN22, VN25, NEC, AWA, & More.
Code	GIA3956




### DAEWO / NEC / AWA GEAR RELAY

Original Part No	79TD3665, 97S0900700
Suit	VN23,24,26,27,67, 2H20D, 4H40D, DVR4773
Code	GR9366




### DAEWO / TEMPEST IDLER CLUTCH

Original Part No	97SA387600
Suit	Tempest TE970 VIDEO PRO VCR8025 Trackton VCR32 etc.
Code	VIA110



### DAEWO / TEMPEST IDLER CLUTCH

Original Part No	97SA507200
Suit	Tempest TE970 VIDEO PRO VCR8025 Trackton VCR32 etc.
Code	VIA100




## DAEWO CLEANER ROLLER

Original Part No	79V15058
Suit	VN30, VN35
Code	RL5058




## DAEWO IDLER PLATE

Original Part No	97SA301400, 79TD3690
Suit	VN23, VN26, NEC, AWA, and others.
Code	GIA3690



## DAEWO RELAY GEAR

Original Part No	79TD3664
Suit	NEC VN23, VN26, AWA 2H20D, 4H40D
Code	GR3664




## NEC / DAEWO LOADING GEAR RIGHT

OEM	79TD3688, 97SA301100
Model.	2H20D, 4H40D, DVF202, DVF562, VN23, VN65.
Code	GR3688



## DAEWO / TEMPEST RF CONVERTER

Original Part No	MCB9VA0103
Suit	DVR6158, 6358, VCR32, 52, 8025, TE99R, etc.
Size	44x53x18mm
Code	RFVR0103



Six pins


## FUNAI ARM RG ACTUATE

Original Part No	8059-17-01
Code	FU1701



## FUNAI CLUTCH ASSEMBLY

Original Part No	8059-09-302
Code	FU9302





## Funai / Teac / Palsonic

### FUNAI HOOK TRIGGER

Original 8059-10-14  
Part No  
Code FU1014

### FUNAI LEVER TRIGGER


Original 8059-10-13  
Part No  
Code FU1013

### FUNAI PLATE BRAKE

Original 8059-10-11  
Part No  
Code FU1011

### FUNAI ACTUATE BASE

Original 8059-10-09  
Part No  
Code FU1009




### FUNAI TEAC RIGHT LOADING GEAR

OEM 97SA308600  
Code GR8600




### FUNAI WORM WHEEL ASSEMBLY

Original 8000-22-313  
Part No  
Code FU2313




### FUNAI WHEEL ASSEMBLY WORM

Original 8059-16-321  
Part No  
Code FU6321




### FUNAI GUIDE POST

Original 8059-03-04  
Part No  
Code FU304




### FUNAI FRONT LOAD GEAR

Original 8059-16-319  
Part No  
Code FU6319




### FUNAI GUIDE POST

Original 8059-03-05  
Part No  
Code FU305




### FUNAI LOADING GEAR

Original 8059-11-04  
Part No  
Code FU1104




### FUNAI GEAR

Original 8059-09-06  
Part No  
Code FU906



### FUNAI CAM ASSEMBLY

Original 8059-11-303  
Part No  
Code FU1303



The screenshot shows a search interface for 'WES' (Video, Entertainment, & Service). The search bar contains 'FUNAI PARTS'. Below the search bar, there are dropdown menus for 'Part Number', 'Category', and 'Search Type'. The main area displays a grid of product cards for various Funai components, including 'CAM ASSEMBLY', 'LOADING GEAR', 'GUIDE POST', and 'WHEEL ASSEMBLY WORM'. Each card includes an image, part number, and a 'View Details' button.




# Video Repair Parts

LG / Goldstar / NEC / Teac


## LG GOLDSTAR COMPLETE ASSEMBLY

Original 321-149B  
Part No  
Code VIA1149




## LG GOLDSTAR IDLER ONLY

Original 386-075A  
Part No  
Code VIA6075




## LG GOLDSTAR COMPLETE ASSEMBLY

Original 321-256A  
Part No  
Code VIA1256




## LG GOLDSTAR IDLER ONLY

Original 386-139A  
Part No  
Code VIA6139




## LG GOLDSTAR COMPLETE ASSEMBLY

Original 321-218A  
Part No  
Code GR1218




## LG GOLDSTAR IDLER ONLY

Original 431-021A  
Part No  
Code VIA1021




## LG GOLDSTAR CLUTCH

Original 432036A  
Part No  
Code GR2036




## LG GOLDSTAR GEAR ASSEMBLY

Original 433-015A  
Part No  
Code GR3015




## LG GOLDSTAR CAM GEAR

Original 435-042B/A  
Part No  
Suit GHV51,GHV  
1232,GHV1  
246,GHV124  
6,etc.  
Code GR5042




## LG GOLDSTAR GEAR

Original 435-047A  
Part No  
Suit GHV1240  
Code GR5047



## LG GOLDSTAR GEAR ASSEMBLY


Original 435-054A  
Part No  
Code GR5054



## LG GOLDSTAR CENTRE UNIT


Complete  
assembled unit

Original 321-369A  
Part No  
Suit VCP100  
Code MEC1369



## LG GOLDSTAR PULLEY CENTRE


Original 432-021A  
Part No  
Code PC4320



## LG GOLDSTAR MECHANISM PLATE

Plate & idler


Original 256-218B  
Part No  
Code MEC2562






## LG GOLDSTAR GEAR

Original Part No	435-132A Subs 435-169A 435-146A 435-053A
Suit	AV65, GHV1296, VCR8000
Code	GR5132




## LG GOLDSTAR MECH

Original Part No	321-397C
Suit	AV66, RG20
Code	MEC1397




## LG GOLDSTAR DOOR OPENER

Original Part No	465-006A
Code	GS5006




## LG GOLDSTAR DOOR OPENER

Original Part No	465-018A 465-007A
Code	GS5018




## LG GOLDSTAR MODE CAM GEAR

Original Part No	374-003A
Code	MCG3740




## LG GOLDSTAR LEVER & PINCH GEAR KIT

Original Part No	333-206A 435-245A
Suit	AV66, RG20
Code	KIT5245




## LG GOLDSTAR IDLER

Original Part No	386-197A
Suit	VCP100, 101, VCP105, 106, VCP111, 115.
Code	VIA6197




## LG GOLDSTAR CLUTCH ASSEMBLY

Original Part No	435-038A
Code	VXP0600




## LG GOLDSTAR GEAR HOUSING

Original Part No	321-232A
Suit	GVH1290, 1291, GHV1296, 1910.
Code	MEC3212




## LG GOLDSTAR / TEAC AUTO HEAD CLEANER

Original Part No	386-296A 386-296C
Code	RL6296




## LG GOLDSTAR / NEC IDLER

Original Part No	386-396A NEC 79VG1031 VN36
Suit	P23H, P433H, P933H, RN800H, RN830H, T293H, T493H, VHG104, VNG67.
Code	GIA6396




## LG GOLDSTAR / NEC CLUTCH TAKE-UP

Original Part No	337-008A
Suit	VN36, VNG67, VHG104, 5, 6, and more!
Code	GR7008



## LG GOLDSTAR / NEC HEAD CLEANER

Original Part No	386-394A NEC VN36
Suit	P23H, P433H, P933H, RN800H, RN830H, T293H, T493H, VHG104, VNG67.
Code	ARM6394



## LG GOLDSTAR LOADING MOTOR / BRACKET

Original Part No	4811R0011A
Suit	AF293, 493, 993, AC250, 450, 950.
Code	VM0011





# Video Repair Parts

## LG LOADING ARM

Original	4471R-0015A
Part No	
Suit	V8844W
Code	ARM0015



## LG LOADING ARM

Original	4471R-0017A
Part No	
Suit	V8824W
Code	ARM0017



## LG GOLDSTAR GEAR


OEM	435-169A
Code	GR5169



## □ Hitachi


## HITACHI IDLER ASSEMBLY

Original	6886971
Part No	
Suit	VT11.
Code	VIA155




## HITACHI TYRE DRIVE IDLER

Original	6889931
Part No	
Suit	VT11,17,168
Code	VIA160




## HITACHI IDLER ASSEMBLY

Original	6886792
Part No	
Suit	VT100,120,VT130,etc.
Code	VIA145




## HITACHI CLUTCH ASSEMBLY

Original	6804834
Part No	6896954
Suit	VTM728
Code	MEC4834




## HITACHI MECHANISM

Suit	VTM740
Code	MEC7874




## HITACHI CLEANING ROLLER

Original	7472125
Part No	
Suit	VTM598E VTM838E
Code	RL1215




## HITACHI COG DRIVE IDLER

Original	6886824
Part No	
Suit	VT138,20E
Code	VIA150



## HITACHI MECHANISM


Original	7794876 Old
Part No	7794873 With 7794931
Suit	VTM748E Motor, Switch, Slide plate, etc.
Code	MEC4876



## HITACHI BRACKET FL (R)

### CASSETTE LOADER RIGHT

Original	6804982
Part No	6804987
Suit	VTM598, 728, VTM748, 818, VTM838, etc.
Code	MEC4982



## HITACHI LOAD MECHANISM

Original	7468854
Part No	
Model.	VT528, VTF778, VTM838...
Code	MEC8854



## HITACHI IDLER

OEM	6897094, 6897095
Suit	VIT588E, VT428, VTM598EM, etc.
Code	VIA165






## JVC


### JVC IDLER ASSEMBLY

Original	PU46381
Part No	
Suit	HR3300,3330, HR3660,4100
Code	VIA210




### JVC TAKE-UP CLUTCH

Suit	HR3330, HR3660
Code	PU49280



### JVC IDLER ARM

Suit	HR2650 (3mm shaft)	HR2200 (4mm)
Code	PU52190A	PU48811D




### JVC TAKE-UP CLUTCH

Suit	HRD110, HRD120, HRD125, etc.
Code	PU55373




### JVC TAKE-UP CLUTCH

Suit	HR3300, HR3330, HR3660, HR4100, HR4110,etc.
Code	PU47752




### JVC IDLER ASSEMBLY

Original	PU48967B
Part No	
Code	VIA216



### JVC IDLER ASSEMBLY

Original	PU55374-3-8
Part No	
Suit	HRD110, GE8100 N830, RV360.
Code	VIA236




### JVC ROLLER BAR TYRE

Model	GE8900, HR7600, HV7700, RV330, VR535...
Code	VT58




### JVC IDLER

Original	PU61004-1-3
Part No	
Suit	HR-D540 HR-D580
Code	PU61004




### JVC CLUTCH UNIT

Original	PU60953-1-2
Part No	
Suit	HRD520, 521, HRD600, 610, HRD620, 830 HRDX20, 22, etc.
Code	PU60953




### JVC IDLER

Original	PU58645-1-4
Part No	
Suit	HR-D series.
Code	VIA240




### JVC AIR DAMPER

Suit	HR7200
Code	PU51252




### JVC CLUTCH UNIT

Original	PU61005-1-4
Part No	
Suit	HR-D540 HR-D580
Code	PU61005



### JVC MECHANISM

Original	PU57658B-6
Part No	
Suit	HR-D series.
Code	MEC658






# Video Repair Parts


## JVC PINCH ROLLER LIFTER

Suit	HRD520,640,830 HRDS5000 HRDX20 VR3241,3275 and others.
Code	PQ32415




## JVC DRIVE GEAR ASSEMBLY

Suit	HR7600, HR7650
Code	PU51859A-2




## JVC DRIVE GEAR ASSEMBLY

Suit	HRD110, HRD111, HRD120, HRD121.
Code	PU51859C-11




## JVC IDLER GEAR UNIT

Original Part No	PU60618-1-3
Suit	HRD520,521, 525,600, 830,X20,etc.
Code	PU60618




## JVC PLATE ASSEMBLY

Suit	HRD637, 825, HRDX20, X22, X24, X42, HRDJ400, 415, 615
Code	PQ43555C10




## JVC PLATE ASSEMBLY

Suit	HRD540 HRD92
Code	PQ44326A-3




## JVC LOADING GEAR 2

Original Part No	PQ30193-1-2
Suit	HRD140,150, 250,455, 565,725, 755, N895, etc...
Code	PQ30193




## JVC ROLLER BAR

Suit	HR7650, 7700 etc.
Code	PU49042A



## JVC "GEAR-2"


Suit	NEC N830, Toshiba V55 JVC HRD120,140,141, 142,143,150,225, 250,565,725,etc...
Code	PQ40060



## JVC GEAR


Suit PUS26805  
cassette housing.

Suit	HRD120,140, HRD141,142, HRD143,150, HRD225, etc.
Code	PQ40065



## JVC CAM GEAR

Suit	PUS26805 cassette housing.
Suit	HRD150,225, HRD250,265, HRD565,725, & MORE.
Code	PQ30028




## JVC LIMITER SPRING

Fits between	PQ30028 & PQ40066
Suit	HRD110,120,140,150,220,250,455 ,565,725,755, N382,830,831,895, MV800,RV360,380, GE8100,V55,V63, VR2925,2970
Code	PQ40068-2




## JVC LOAD GEAR

Suit	PUS26805 cassette housing.
Suit	HRD120,140, HRD141,142, HRD143,150, HRD225, etc.
Code	PQ40066



## JVC SLIDE GEAR


Suit	PUS26805 cassette housing.
Suit	HRD150,225, HRD250,265, HRD565,725, & MORE.
Code	PQ40067






## JVC GUIDE ARM

Suit	HRD520,600, HRD825,830, HRDX20,X22
Code	PQ43567A-13




## JVC H.LOADING GEAR

Suit	HRD520,600, HRD825,830, HRDX20,X22
Code	PQ43570B




## JVC LOADING ARM

Suit	HRD540, 580, HRD640, etc. HRJ200, etc.
Code	PQ43537B




## JVC LOADING ARM

Suit	HRD540, 580, HRD640, etc. HRJ200, etc.
Code	PQ43542D-4




## JVC TENSION ARM LEVER

Original Part No	PQ35012-1-5 4822 4021 0367
Suit	HRJ220, 221, 425, 435, HRJ621, 625, 635, etc. VR155, 357, 455, VR656 and more.
Code	PQ35012



## JVC CONTROL CAM

Suit	HRD520,600, HRD825,830, HRDX20,X22
Code	PQ20822-2-7




## JVC TENSION SPRING

Code	PQ43500
------	---------




## JVC GUIDE ARM

Suit	HRJ220, 221, HRJ625, etc.
Code	PQ46325B




## JVC PULLEY

Suit	HRJ220, 221, HRJ625, etc.
Code	PQ35016-1-3




## JVC POLE BASE (T)

Suit	HRD910 HRJ200 HRJ400 etc...
Code	PU61103-2-7




## JVC POLE BASE (S)

Suit	HRD910 HRJ200 HRJ400 etc...
Code	PU61151-2-7




## JVC GEAR UNIT

Suit	HRD640
Code	PU61246-1-5



## JVC CLUTCH


Suit	HRD640
Code	PU61245-1-3



## JVC TAKE-UP POLE

Complete kit Suits many late models.

Code	PTU96103E
------	-----------






# Video Repair Parts


## JVC LOADING ARM TAKE-UP

Suit HRD230, 320,  
HRD370, 430  
Code PQ41985B-3




## JVC CAM GEAR UNIT

Suit HRJ600  
Equiv. PU61317-1-3  
Code PU61317-1-4




## JVC CONTROL PLATE

Suit HRJ220, 221,  
HRJ625, etc.  
Code PQ11658-1-15




## JVC CAM GEAR

Original Part No PQ20250-1-1  
Suit HRD170,  
HRD180,  
HRD530  
Code PQ20250



## JVC SUPPLY POLE

Complete kit  
Suits many late  
models.  
Code PTU96102E



## JVC STOPPER BLACK

Suit Tape Loading (S) Pole  
Base PQ61151-2-7 From  
Kit PTU96102E


Suit HRD540,830,  
HRD910,etc..  
HRJ200,etc..  
Code PQ45894



## JVC STOPPER WHITE


Suit Tape Loading (T)  
Pole Base PQ61103-2-7  
From Kit PTU96103E

Suit HRD540,830,  
HRD910,etc..  
HRJ200,etc..  
Code PQ45895




## WASHER TO SUIT "STOPPERS" ABOVE

Code PQM30017-41




## JVC SLIDE PLATE

Original 4822 4668  
Part No 3023  
Suit HRD910,  
VR253,  
VR454, etc.  
Code PQ44581B




## JVC CHANGE GEAR

Suit HRJ220, 221,  
HRJ625, etc.  
Code PQ46354




## JVC IDLER ARM

Suit HRJ220, 221,  
HRJ625, etc.  
Code PQ46312B-8



## JVC CLUTCH ASSEMBLY


Suit HRJ220, 221,  
HRJ625, etc.  
Code PQ46323A-1






## JVC LEVER METAL

Original Part No	Old PQ46342A-6 New PQ46342C-9 Philips 402240371302 482240210387
Suit	HRJ425, 635, etc. VR555-75, etc.
Code	PQ46342



## JVC LOADING ARM


Suit	HRJ220, 221, HRJ625, etc
Code	PQ46337A-7



Only one type of arm in JVC  
Beware - There are two types used in Philips, See below !

## JVC/PHILIPS LOADING ARM - TAKE 2


Original Part No	Philips 4822-402-10625, Many models.
Code	ARM625



This gear has a smaller hole !  
Beware - There are two types used in Philips, See above !

## JVC CONTROL CAM


Suit	HRJ220, 221, HRJ625, etc.
Code	PQ21684-1-3



## JVC HEAD CLEANER - CLEANER ROLLER

### CLEANER ROLLER ONLY

Suit	HRJ600, etc
Code	PQ44837




## JVC HEAD CLEANER

Suit	HRJ400
Code	PQ46019




## JVC CHANGE ARM ASSEMBLY

Original Part No	PQ46353A-1 PQ46353A-2
Suit	HRJ425, 435, HRJ625, 635, VR255, 455, 456, VR555, 655, 755
Code	PQ46353




## JVC IDLER ARM

Original Part No	LP40114-002D LP40114-004A 4822-402-11053
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	ARM4002



## JVC CLUTCH UNIT

Original Part No	LP40115-002C/D 4822-522-10701
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	VIA5002




## JVC DIRECT GEAR

Original Part No	LP40122-001A, LP40122-002A, LP30463-002A 4822-522-10699
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	GR2001




## JVC SLIDE PLATE

Original Part No	LP10080-002E/F 4822-466-11932
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	PSM0002




## JVC LOADING ARM SUPPLY

Original Part No	LP30224-001A 4822-402-11063
Suit	HRJ255, 455, HRJ655, 755. VR288, 388.
Code	GR3003




## JVC CLEANING ARM

Original Part No	PQ46436A-1
Equiv.	PQ46418-1-2
Suit	HRJ425
Code	PQ46436



## JVC TAKE-UP LEVER

Original Part No	PQ21686-1-3
Suit	HRJ615
Code	PQ21686






# Video Repair Parts

## □ Mitsubishi / AWA


### MITSUBISHI/AWA IDLER

Original	522P002010
Part No	
Suit	AV12,14,51 AV52,400,etc.
Code	VIA910




### MITSUBISHI/AWA GEAR

Original	641D799O10
Part No	
Suit	AV12,51,400, 410,TR102,etc.
Code	GR7990




### MITSUBISHI/AWA CAM GEAR (A)

Original	641B093010
Part No	
Suit	AWA/Mitsubishi
Code	GR9301




### MITSUBISHI IDLER ASSEMBLY

Original	522B01701
Part No	
Suit	HS337, HS338, HSE20 etc...
Code	VIA1701




### MITSUBISHI/AWA GEAR

Original	641D797010
Part No	
Suit	AWA AV12 AV400
Code	GR7970




### MITSUBISHI/AWA CAM GEAR (B)

Original	641B094010
Part No	
Suit	AWA AV11, 12, 14, 51, 52, AV400, 410, HS306, 307, 318, HS319, 400, 410, TR102
Code	GR9401




### MITSUBISHI GEAR IDLER

Original	522C07702
Part No	522C077020
Suit	522C07701/0
Code	HSMX1,X2, HSE11,17, HSE82,etc.



### MITSUBISHI LOADING ARM


Original	592B04701-0	592B04801-0
Part No		
Suit	HSM50,HSMX3,5,7,10,20	HSM50,HSMX3,5,7,10,20
Code	ARM701	ARM801



### MITSUBISHI REEL IDLER

### MITSUBISHI REEL IDLER


Original	522B05703
Part No	522B057030
Suit	522B05701/0
Code	HSM50,X3, HSMX5,X7, HSMX10,20.



## □ NEC

### NEC REEL DRIVE ASSEMBLY


Original	16192683
Part No	
Suit	9000 series, DS6000, DX1600, DX3000



Note: Requires ARM582


### NEC IDLER PLATE

Original	79TD3955
Part No	




### NEC CAM GEAR

Original	97S2705700
Part No	
Suit	VN20



### NEC MECHANISM

Original	97SB335300
Part No	97SA462900
Suit	VN20
Code	MEC5300






## □ NEC


### NEC LOADING GEAR

Original Part No	16443362
Suit	N901, 911, etc.
Code	GR3362



### NEC REEL DRIVE ASSEMBLY


Original Part No	16178173
Suit	16178179
Suit	N901, 911
Code	MEC8179



### NEC MODE CAM ASSEMBLY


Inc.Motor.

Original Part No	16185091
Suit	Late 9000 & DX1600,3000
Code	MCA5091



### NEC MODE CAM ASSEMBLY


Original Part No	16179645
Suit	N901
Code	MCA9645



### NEC MODE CAM ASSEMBLY

Inc. Motor.


Original Part No	16179832
Suit	N911 and Early 9000
Code	MCA9832



## □ Panasonic


### PANASONIC CLUTCH ASSEMBLY

Original Part No	VXP0265
Code	VIA312




### PANASONIC LOADING PULLEY

Suit	NV250, NVG10, NVH70, etc.
Code	VDP0985



### PANASONIC IDLER

Original Part No	VXP0245
Suit	NV8400, NV8600, NV8610.
Code	VIA308



### PANASONIC IDLER

Original Part No	VXP0329
Suit	NV2000 NV3000
Code	VIA316



### PANASONIC IDLER

Original Part No	VXP0331
Suit	NV2000 NV3000
Code	VIA320




### PANASONIC IDLER

Original Part No	VXP0344
Suit	NV7000 NV7200
Code	VIA328



### PANASONIC SUPPLY GEAR

Suit	NV100
Code	VXP0402






# Video Repair Parts

## PANASONIC IDLER PACK

Suit NV300 etc.  
Code VXL0997




## PANASONIC GEAR

Code VDG0235




## PANASONIC DISC DRIVE

OEM 482252232513  
Suit NVD38, NVFS1,  
NVG20, NVG21,  
NVG25A, NVH75,  
NVL10, NVSD1A,  
RTV560, VR6490,  
VR716/75,...  
Code VDG0335




## PANASONIC INTERMEDIATE GEAR (B)

Suit NV370  
Code VDG0115



## PANASONIC PULLEY GEAR


Suit NV870  
Code VDG0142



## PANASONIC IDLER ASSEMBLY


IDLER VXP0343

Suit NV7000  
Code VIA324




## PANASONIC TAKE-UP CLUTCH ASSEMBLY

Original VXLS0081  
Part No  
Code VIA385




## PANASONIC TAKE-UP GEAR

Suit NV100  
Code VXP0403




## PANASONIC TAKE-UP IDLER

Original VXP0433  
Part No  
Suit NV300 etc.  
Code VIA336




## PANASONIC CAM GEAR

Suit NV2000,  
NV3000,  
NV7000,  
NV7200  
Code VDG0035




## PANASONIC SHAFT GEAR

Suit NV777  
Code VDG0119




## PANASONIC DRIVE GEAR (2)

Suit NV850  
Code VDG0143



## PANASONIC GEAR

Suit NV370 etc.  
Code VDG0155



## PANASONIC ROLLER POST


Suit NV730,  
NEC 911A  
Code VXP0444A






## PANASONIC TAKE-UP IDLER

Suit	NV600
Original	VXP0488
Part No	
Code	VIA344




## PANASONIC IDLER

Suit	NV777, NV788
Original	VXP0463
Part No	
Code	VIA340




## PANASONIC KICK GEAR

Suit	NV450, NVG10, NVG30
Code	VDG0178




## PANASONIC INTERMEDIATE GEAR (B)

Suit	NV450, NVG10, NVG30
Code	VDG0188




## PANASONIC INTERMEDIATE GEAR (A)

Suit	NV450, NVG10, NVG30
Code	VDG0189




## PANASONIC CAM GEAR

Suit	NV370,450, NVG10,30,etc.
Code	VDG0200




## PANASONIC PULLEY GEAR

Suit	NVG30
Code	VDG0275




## PANASONIC SUPPLY REEL GEAR

Suit	NVG20
Code	VDG0337




## PANASONIC INTERMEDIATE GEAR

Suit	NV370, NV777,etc.
Code	VDG0146




## PANASONIC SUB CAM GEAR

Suit	NVF55,S1, NVJ35,etc.
Code	VDG0343




## PANASONIC GEAR

Suit	NV370 etc.
Code	VDG0156




## PANASONIC MAIN CAM GEAR

Suit	NVFS1, NVJ35,etc.
Code	VDG0346




## PANASONIC GEAR

Suit	NV370, NV777
Code	VDG0177



## PANASONIC CLUTCH DISC

Suit	NVD48,FS1, NVH65, NVL25, RTV560,etc.
Code	VDG0349






# Video Repair Parts


## PANASONIC P5 SECTOR PULL GEAR

Suit NVG20, 22,  
NVJ700  
Code VDG0357




## PANASONIC PINCH CAM KIT

Suit NVD38,  
F55,FS1,  
NVG33,  
H65,J1,  
NVL20,W1,  
RTV740,etc.  
Code VDG0421




## PANASONIC GEAR

Suit NVD38,  
F55,FS1,  
NVG33,  
H65,J1,  
NVL20,W1,  
RTV740,etc.  
Code VDG0483




## PANASONIC RING GEAR

Suit NVF55,FS1,  
NVJ35,etc.  
Code VDG0342




## PANASONIC PLANET GEAR

Suit NVF55,FS1,  
NVJ35,etc.  
Code VDG0345




## PANASONIC CENTRE GEAR

Suit NVF55,FS1,  
NVJ35,etc.  
Code VDG0348




## PANASONIC GEAR

Suit NV370 NV850  
etc.  
Code VXP0523




## PANASONIC CLUTCH DISC LEVER

Suit NVD48,FS1,  
NVH65,  
NVL25,  
RTV740,etc.  
Code VDG0350




## PANASONIC LOADING GEAR (S)

Suit NVD38,  
F55,FS1,  
NVG33,H65,J1,  
NVL20,W1,  
RTV560,etc.  
Code VDG0419




## PANASONIC RETAINER GEAR

Suit NVD38, F55,FS1,  
NVG33, H65,J1,  
NVL20,W1,  
RTV560,etc.  
Code VDG0422




## PANASONIC LOADING CAM GEAR

Suit NVD38, F55,FS1,  
NVG33, H65,J1,  
NVL20,W1,  
RTV560,etc.  
Code VDG0448




## PANASONIC MAIN CAM GEAR

Suit NVD38, F55,FS1,  
NVG33, H65,J1,  
NVL20,W1,  
RTV560,etc.  
Code VDG0574




## PANASONIC GEAR KIT

Original VUA4100KIT  
Part No  
Suit NVG mech'  
RTV560,etc.  
Code VUA4100



## PANASONIC SUB LOADING ARM


Suit NVD38,FS1,  
NVG20,H75,  
NVL20,etc.  
RTV560,etc.  
Code VXL1480






## PANASONIC TENSION ROLLER

Suit NVF55,FS1,etc.  
Code VXA3516




## PANASONIC ROLLER

Suit NVSD10,etc.  
Code VXA4799




## PANASONIC CLUTCH GEAR

Original Part No VXP0599  
Suit NV250...  
Code VXA360




## PANASONIC CLUTCH GEAR IDLER

Suit NV370,  
780,850  
Code VXP0595




## PANASONIC CENTRE CLUTCH

Original Part No VXP0521  
Suit NV250,450, G10  
Code VXP0600




## PANASONIC LOADING GEAR

Suit NV370,  
NV850,etc.  
Code VXP0520




## PANASONIC SPACER

Code VMX0259




## PANASONIC RELEASE LEVER

Suit NVF55,FS1,  
NVG10,J45,etc.  
RTV560,etc.  
Code VML1860




## PANASONIC SUB LOADING ARM

Suit NVF55,J1,  
NVL25,etc.  
Code VXL1856




## PANASONIC POST UNIT

Suit NVF55,FS1,etc  
Code VXL1485




## PANASONIC CAPSTAN BRAKE

Suit NVG10,20,  
NVG30,etc.  
Code VXZ0185




## PANASONIC IDLER ASSEMBLY

Original Part No VXP0521  
Suit NV250,450, G10  
etc.  
Code VXP0521




## PANASONIC IDLER

Original Part No VXP0581  
Suit NV730,770.  
Code VIA350



## PANASONIC WORM WHEEL PACK

Suit NV250,280,450,470,  
730,770,870,etc.  
Code VXP0604






# Video Repair Parts

## PANASONIC GEAR


Suit	NVHD, NVHS, NVSD, RTV, TC20S10,....
OEM	482252233439
Code	VDG0885



## PANASONIC GEAR PACK

Kit combines  
VDG0345 X3  
VDG0422 X1


Suit	NVG mech' RTV560,etc.
Code	VXP0878



## PANASONIC "G" MECHANISM PARTS KIT

Contains VXL1490,  
VXL1743, VXP0878,  
VDG0597, VML1849,  
VMX1079, washers  
and C rings.


Code	VUA4104
------	---------



## PANASONIC PINCH CAM UNIT

Suit	NVSD Mech.
Code	VDG0886

Suitable for the  
Pinch roller assembly  
VXL2246




## PANASONIC TENSION ARM

OEM	482240353993
Suit	NVG Mech
Code	VXA2674




## PANASONIC IDLER ASSEMBLY

Suit	NVSD10A NVSD20A NVSD30A
Equiv.	VXL2229
Code	VXL2378




## PANASONIC ARM

Suit	K Mechanism
Equiv.	VXL2394
Code	VXL2243




## PANASONIC MAIN LEVER UNIT

Suit	NVSD Mech.
Code	VXL2307




## PANASONIC GEAR

Suit	NVSD10A NVSD20A NVSD30A
Code	VDG0868



## PANASONIC AUTO HEAD CLEANER

Suit	NVSD10, 20, NVSD400, etc.
Code	VXL2440



## PANASONIC CLEANER ROLLER


Suit	NVHD620,670, NVSD220,230, NVSD270,280, NVSD420,430.
Code	VDP1668K



## PANASONIC SIDE PLATE


Includes opener  
lever VXL2250

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXA4660




## PANASONIC CASSETTE HOLDER

Suit	NVSD10, NVF65, 20, 30 66, 70, 90
Equiv.	VXA3832
Code	VXA4661 VXA3840



## PANASONIC SHAFT ASSEMBLY


Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXP1339






## PANASONIC SIDE PLATE


Suit NVL20, 25,  
'G' Mech  
Code VXA4076



Suit NVG25, 28,  
'G' Mech  
Equiv. VMD918  
NVH65, 75,  
Code VXA3015




Original Part No PCB#  
VEP00R12  
Suit NVJ45, etc.  
Code VXA4468




## PANASONIC SIDE PLATE

Suit NVSD10A,  
NVSD20A,  
NVSD30A  
Code VXA4806




## PANASONIC BRAKE

Suit NVSD10  
Code VXZ0312




## PANASONIC BRAKE

Code VXZ0262




## PANASONIC BRAKE

Suit Super Drive  
Code VXZ0274




## PANASONIC BRAKE

Suit NVSD10A,  
NVSD20A,  
NVSD30A  
Code VXZ0313




## PANASONIC BRAKE

Suit NVG Mech.  
Code VXL2088




## PANASONIC BRAKE

Models NVF70,  
NVF70A,  
NVJ27,  
NVJ27M,  
NVJ27MC  
Code VXL1500




## PANASONIC SHAFT

Suit NVG33,  
NVH75, etc.  
Equiv. VXP0987  
Code VXP0851




## PANASONIC LOADING ARM

Suit NVSD10A,  
NVSD20A,  
NVSD30A  
Code VXL2299



## PANASONIC SUBLOAD ARM

OEM 482240371057  
Suit NVSD10A,  
NVSD20A,  
NVSD30A  
Code VXL2306






# Video Repair Parts


## PANASONIC GEAR

OEM	VDG0069
Suits	NV300, NV600, NV777, NV788, RTV321, RTV322.
Code	VDG0158




## PANASONIC GEAR

Suit	NVSD10A, NVSD20A, NVSD30A
Equiv.	VDG0862
Code	VDG0957




## PANASONIC GEAR

Suit	NVSD10A, NVSD20A, NVSD30A
Equiv.	VDG0861
Code	VDG0956




## PANASONIC CLUTCH

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXP1409



## PANASONIC ARM


Original	VXL1861,
Part No	VXL1490
Suit	NV-J11 etc., NV-G, etc., RTV560, etc.
Code	VXL1861



## PANASONIC GEAR KIT


Kit combines VXP0767  
VDV0159 and washers.

Code	VXP0917K
------	----------




## PANASONIC CAM GEAR

Suit	NVSD20A
Code	VDG0913




## PANASONIC ARM

Code	VXL1244
------	---------



## PANASONIC GEAR


Suit	NV2000, NV3000, NV7000, NV7200, NV7800
Code	VDG0017



## PANASONIC PULLEY MOTOR COUPLING


As fitted to: VEM0427 Motor

Suit	NVSD10, 20, etc.
Description	Coupling Worm Gear
Code	VDP1434 VDG0866




## PANASONIC MAIN CAM

Original	VDG1220
Part No	
Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Code	VDG1220




## PANASONIC IDLER ARM

Original	VXL2678, VXL2792
Part No	
Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Code	VXL2792




## PANASONIC CONVERSION GEAR

Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Original	VDG1221
Part No	
Code	VDG1221



## PANASONIC TAKE-UP BRAKE


Original	VXL2667, VEK8239
Part No	
Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Code	VXL2667






## PANASONIC CENTRE CLUTCH

Suit	NVHD NVSD, NVSJ & NVFJ
Original Part No	VXP1732
Code	VXP2035




## PANASONIC CENTRE CLUTCH

Original Part No	VXP1850
Suit	NV-FJ600, NV-FJ720, NV-SJ720
Code	VXP2053




## PANASONIC LOADING ARM

Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Code	VXL2670



## PANASONIC LOADING ARM

Suit	NVSD220, 270, NVSD420, NVHD620, 670.
Code	VXL2672



## PANASONIC INCLINED BASE [T]

Suit	NV-SJ200A NV-SJ400A NV-FJ600A NV-FJ720A
Code	VXA5854



## PANASONIC LOADING ARM

Code	VXL1665
------	---------



## PANASONIC MAIN LEVER

Suit	NV-SJ200A NV-SJ400A NV-FJ600A NV-FJ720A
Code	VML3166




## Samsung

### SAMSUNG IDLER


Code VIA700

AKAI  
PALSONIC  
FUNAI  
GOLDSTAR  
TEAC




### SAMSUNG/TEMPEST IDLER

Original Part No	5253-701-1105 65253-701-110
Suit	TE900, VB900, VB910, VB2215
Code	VIA710




### SAMSUNG/TEMPEST IDLER

Original Part No	66052-600-310
Suit	TE77R, VRD100, VCP90R, VB711, 750, VB8220, PB980, 981,
Code	VIA730




### SAMSUNG/AKAI/TEMPEST IDLER

Original Part No	65153-600-011 65153-600-100
Suit	TE90H, VS11,12, DS757
Code	VIA720




### SAMSUNG TEMPEST REEL BRAKE

Original Part No	47647007205
Suit	VB520, 900, Akai VS200, TE900H
Code	RDB900



### SAMSUNG LOADING SHAFT

Original Part No	61043002500
Suit	VB300 VB370, etc.
Code	CH2500






# Video Repair Parts

## SAMSUNG PINCH DRIVE


Supplied locked into alignment.

Original Part No	67179-0069-01
Suit	VB300,etc.
Code	GR6901




## SAMSUNG CLUTCH ASSEMBLY

Original Part No	61453-0003-00
Suit	SV10, 11, 12, SV30, 80, 140
Code	VIA300




## SAMSUNG GEAR IDLER ASSEMBLY

Original Part No	61453000101
Suit	VB300 VB370, etc.
Code	GIA1001




## SAMSUNG LOADING GEAR (L)

Original Part No	61473-0107-00
Suit	SV10, 11, 12, SV30, 80, 140
Code	GR1070




## SAMSUNG LOAD SLIDE LEVER

Original Part No	66602603510
Suit	VB300 VB370, etc.
Code	LEV3510




## SAMSUNG WORM WHEEL

Original Part No	61473-0102-00
Suit	SV10, 11, 12, SV30, 80, 140
Code	GR1020




## SAMSUNG GEAR CLUTCH

Original Part No	66053-604-420
Suit	VB1560
Code	GIA4420



## SAMSUNG SHAFT ARM (F/L)

Original Part No	61403-0073-00
Suit	SV10, 11, 12, SV30, 80, 140
Code	ARM73



## SAMSUNG LOAD GEAR R

Original Part No	6526 460 6610
Suit	PB990, VB1230, VB1260, 1530, 1850.
Code	GR6610




## SAMSUNG GEAR

Original Part No	AC66-00039A
Suit	SV220B SV435B
Code	GR0039



## SAMSUNG IDLER ASSEMBLY

Original Part No	61603-0006-00
Suit	SV10, 11, 12, SV30, 80, 140
Code	GIA600



## SAMSUNG GEAR JOINT

Original Part No	61473006400
Model.	VB300, VB301, VB306, VB320, VB3260, VB336, VB370
Code	61473006401






## Sanyo / Fisher / Sony


### SANYO/FISHER IDLER ASSEMBLY

Original 143-0-741T-20001  
Part No  
Code VIA512




### SANYO IDLER ASSEMBLY

Original 143-0-4204-00100  
Part No  
Code VIA560




### SANYO ROLLER WIND PULLEY

Original 143-0-4804-00100  
Part No Fisher FVH-P530  
Code RWA530




### SANYO IDLER ASSEMBLY

Original 143-0-4904-00900 or  
Part No 621-010-1612  
Code VIA550




### SANYO IDLER ASSEMBLY

Original 613 037 4875  
Part No  
Suit VHR1100, 1300, 1500  
Code VIA565




### SANYO/SONY GEAR

Original 613-0222-701  
Part No  
Suit VHR4100 SLVX10,20  
Code GR2701




### SANYO/SONY IDLER ASSEMBLY

Original 613-022-0134 Also 613-  
Part No 093-3928  
Suit VHR4100 SLVX10,20  
Code GIA134




### SANYO IDLER CLUTCH

Original 613-100-4696  
Part No  
Suit SRT500P TLS900P  
TLS924P TLS2000  
TLSS2500P  
Code VIA4696




### SANYO IDLER ASSEMBLY

Original 143-0-6627-01202 or  
Part No 613-037-4677  
Suit VCT5000  
Code VIA514




### SANYO IDLER ASSEMBLY

Original 613-037-4776  
Part No  
Suit M10, M20  
Code VIA513




### SANYO CAM GEAR

Original 613-022-2718  
Part No  
Suit VHR4100  
Code GR2718




### SANYO FRICTION GEAR

Original 613-022-0066 613-102-  
Part No 0900  
Suit VHR4100, VHR5700,  
SVX10, 20, etc & Sony  
Code GR2266




### SANYO GEAR

Original 143-0-581T-13800  
Part No  
Suit VHR3100 etc. SV-  
VX10AS  
Code GR3800




### SANYO GEAR REEL

Original 613-152-2756  
Part No  
Suit VHR510, 530,  
VHR590, 610,  
VHR630, 650  
Code GR2756



### SANYO CAM GEAR

Original 613-156-4008  
Part No  
Suit VHR510, 530,  
VHR590, 610,  
VHR630, 650  
Code GR4008






# Video Repair Parts

## □ Sharp

### SHARP IDLER ASSEMBLY

Original NIDL0005GEZZ  
Part No  
Code NIDL0005




### SHARP IDLER ASSEMBLY

Original NIDR0004GEZZ  
Part No  
Code VIA616




### SHARP IDLER ASSEMBLY

Original NPLV0107GEZZ  
Part No  
Code VIA632




### SHARP IDLER ASSEMBLY

Original NPLV0111GEZZ  
Part No  
Code VIA636




### SHARP MASTER CAM GEAR

Original NGERH1024GEZZ  
Part No  
Suit 300 series,etc, Philips  
4802 522 37129  
Code MCG1024




### SHARP IDLER ASSEMBLY

Original NIDL0006GEZZ  
Part No  
Code NIDL0006




### SHARP IDLER

Original NPLV0051GEZZ,  
Philips 4802 528  
77224  
Code VIA628



### SHARP MOTOR PULLEY


Original NPLYV0121GEZZ  
Part No  
Suit MOTORS,  
RMOTV1004GEZZ,  
RMOTV1007GEZZ,  
RMOTV1008GEZZ,  
RMOTV1010GEZZ  
Code MP121



(See Motors this section)


### SHARP MASTER CAM GEAR

Original NGERH1043GEZZ  
Part No  
Suit VC400 series etc.  
Code MCG1043



### SHARP LEVER


Original MLEVP0134GEZZ  
Part No  
Suit VCF18, VCA105X  
Code LEV0134



### SHARP GEAR IDLER ASSEMBLY

With tape lock disable.


Original NGERH1122GEZZ  
Part No  
Suit VCA105, 111X, etc.  
Code GIA1122



### SHARP GEAR IDLER ASSEMBLY


Without tape lock disable.

Original NGERH1128GEZZ  
Part No  
Suit VCA115X,etc.  
Code GIA1128




### SHARP WORM WHEEL

Original NGERW1032GEZZ  
Part No  
Suit VCA505X etc.  
Code GR1032



### SHARP MASTER CAM GEAR


Original NGERH1074GEZZ  
Part No  
Suit VC600 series.  
Code MCG1074






## SHARP LEVER

Original	MLEVP0135GEZZ
Part No	VCF18
Suit	VC600, 700, 6F3, 6V3, etc.
Code	LEV0135




## SHARP LOADING GEAR

Original	NGERH1022GEZ
Part No	
Suit	VC481 etc.
Code	GR1022




Original	NGERH1076GEZZ
Part No	
Suit	VCH851
Code	GR1076



## SHARP LOADING GEAR

Original	NGERH3010GEZZ
Part No	
Suit	VC481 etc.
Code	GR3010




## SHARP SHIFT DRIVER LEVER

OEM	003 248 0545, MLEVP0271GEZZ, MLEVP0271AJZZ
Model.	VCA200X, VCA410X, VCA600X, VCH650X, VCH710X, VCH800X,...
Code	LEV0271




## SHARP PULLY

OEM	NPLYV0156AJZZ
Models	VCA200X, VCA400X, VCR450X, VCA600X, VCA650X, VT3448, VT5148.
Code	GIA156



## SHARP REVERSE DRIVE LEVER


Original	MLEVP0275GEZZ
Part No	
Suit	VCA200X, 220X, 250X, VCA260X, 270X, VCA400X, 410, 420.
Code	LEV0275



## SHARP WORM GEAR


Model.	VC381X, VC7700, VR401, VR901, VRD012
OEM	NGERW1003GEZZ

Code GR1003




## SHARP CAM GEAR

Original	NGERH1073GEZZ
Part No	
Suit	VC600, 700, 6F3, 6V3, etc.
Code	GR1073




## SHARP CASSETTE LOAD ARM

Original	MARMP0029GEZZ
Part No	
Suit	VC651, 684, VC685, 686.
Code	ARM29



## SHARP CASSETTE UNLOCK KEY

Original	MARMP0026GEZZ
Part No	
Suit	VC9300
Code	ARM26




## SHARP SPRING

Original	MSPRT0140GEFJ
Part No	
Suit	VC481 and other models.
Code	SPR140



## SHARP SPRING


Original	MSPRD0092GEFJ
Part No	
Suit	VC111X and other models.
Code	SPR92



## SHARP SPRING

This fits LANG9


Original	MSPRD0021GEFJ
Part No	
Code	SPR21



## SHARP DOUBLE ACTION PLATE

Known as FIXING METAL.

Original	LANGJ0009GEZZ
Part No	
Code	LANG9






# Video Repair Parts


## SHARP LOADING GEAR

Original	NGERH1119GEZZ
Part No	
Suit	VCA111X
Code	GR1119




## SHARP BRAKE LEVER

Original	MLEVP0101GEZZ
Part No	
Suit	VCA101, 103, VCD801, etc.
Code	LEV0101



## SHARP TAPE GUIDE LEVER P5

Original	MLEVP0273AJZZ
Part No	
Suit	VCA200, 400, VCA600, 650.
Code	LEV0273




## SHARP CAM GEAR

Original	NGERH1268GE00
Part No	
Suit	VCA200, 250, VCA400, 450, VCA600, 650.
Code	GR1268



## SHARP LOADING GEAR


Original	NGERH1120GEZZ
Part No	
Suit	VCA, VCB, VCD, VCH, Series
Code	GR1120



## SHARP CAM GEAR


many VC-A & VC-H Series.

Original	NGERH1129GEZZ
Part No	
Code	GR1129




## SHARP CASSETTE LOAD ARMS

Description	Left NGERW1035GEZZ	Right NGERW1034GEZZ
Suit	VCF18, 111, etc.	
Code	GR1035	GR1034




## SHARP CASSETTE OPENER

Original	MLEVP0142GE00
Part No	
Suit	VCA111X etc.
Code	LEV0142




## SHARP CAM GEAR

Original	NGERH1109GEZZ
Part No	
Suit	VCA201
Code	GR1109




## SHARP CAM GEAR

Original	NGERH1118GEZZ
Part No	
Suit	VCA & VCH series Philips VCR's VR6448, 6548 etc
Code	GR1118




## SHARP CAM GEAR

Original	NGERH1108GEZZ
Part No	
Suit	VCA series Philips VCR's VR6448, 6548 etc.
Code	GR1108




## SHARP TAKE-UP LOADING GEAR

Suit	VCA36, 41, 62, VCA72, 93, 97, & More...
Code	GR1219




## SHARP MID DRIVE MASTER CAM

Original	NGERH1217GE00
Part No	
Suit	VCA36X, VCA50X and others.
Code	MCG1217



## SHARP MID DRIVE MASTER CAM


Original	NGERH1218GE00
Part No	
Suit	VCA36X VCA50X and others.
Code	GR2180






## SHARP MECHANISM

Original Part No	CCHSS0018GE02
Suit	VCA35X etc.
Code	CH0018




## SHARP ARM

Original Part No	MARMP0032GEZZ
Suit	600 series.
Code	ARM32




## SHARP LEVER

Original Part No	MLEVP0195GEZZ ,MLEVP0133GEZZ
Suit	VCA101, 103, 111, VCD805, VCH80X, etc.
Code	LEV0195




## SHARP LOADING ARM

Original Part No	MLEVF0420GEZZ
Suit	VCA35X, 36X VCA50X, etc.
Code	LEV0420



## SHARP LOADING ARM


Original Part No	MLEVF0422GEZZ
Suit	VCA35X, 36X VCA50X, etc.
Code	LEV0422



## SHARP WORM WHEEL


From cassette housing Right

Original Part No	NGERW1033GEZZ
Suit	VCA111 VCF18
Code	GR1033




## SHARP LOADING GEAR

Original Part No	NGERH1121GEZZ
Code	GR1121




## SHARP CLUTCH MID-DRIVE

Original Part No	NGERH1221AJZZ
Suit	VCA36X ,VCA50X and others.
Code	GR1221




## SHARP REEL PULLEY MID-DRIVE

Original Part No	NPLYV0147AJZZ
Suit	VCA36X, VCA50X, and others.
Code	VIA1470



## SHARP PLAYBACK GEAR

Original Part No	NGERH1224AJZZ
Suit	VCA36X, VCA50X, and others.
Code	GR1224




## SHARP CASS HOUSE MID-DRIVE

Original Part No	NGERH1225GEZZ
Suit	VCA36X, VCA50X, and others.
Code	GR1225




## SHARP SLIDER HOLDER RIGHT

Original Part No	LHLDX1010GEOO, LHLDX1012GEOO
Suit	VCA111, VCF18
Code	LDX1010




## SHARP SLIDER HOLDER LEFT

Original Part No	LHLDX1011GEZZ
Equiv.	LHLDX1013GEZZ
Suit	VCF18, VCA111
Code	LDX1011



## SHARP SLIDE PLATE

Original Part No	MSLIF0043GEZZ
Suit	VCA111X
Code	PS0043




## SHARP LOADING GEAR



# Video Repair Parts


## SHARP FRAME (R) MID-DRIVE

Original Part No	LHLDX1025GEOO
Suit	VCA36X, VCA50X, and others.
Code	LDX1025




## SHARP FRAME (L) MID-DRIVE

Original Part No	LHLDX1024GEOO
Suit	VCA36X, VCA50X, and others.
Code	LDX1024




## SHARP SLIDER MID-DRIVE

Original Part No	LHLDX1026GEOO
Suit	VCA36X, VCA50X, and others.
Code	LDX1026




## SHARP GEAR MID-DRIVE

Original Part No	NGERH1226GEOO
Suit	VCA36X, VCA50X, and others.
Code	GR1226




## SHARP MID-DRIVE

Original Part No	NGERH1227GEZZ
Suit	VCA36X, VCA50X, and others.
Code	GR1227




## SHARP LOAD GEAR - SUPPLY

Original Part No	NGERH1220AJZZ
Suit	VCA36, 37, 41, 50, 53, VCA53, 62, 63, 67, 72, VCH93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	GR1220




## SHARP CLUTCH CONNECT ARM

Original Part No	MLEVP0241AJZZ
Suit	VCA36,37,41,50,53,VC A53,62,63,67,72,VCH 93,94,97,98,VCMH83, 93,VT3428, 5128
Code	LEV0241




## SHARP OPEN LEVER

Original Part No	MLEVP0238AJZZ
Suit	VCA36, 37, 41, 50, 53, VCA53, 62, 63, 67, 72, VCH93, 94, 97, 98, VCMH83, 93, VT3428, 5128
Code	LEV0238




## SHARP CLUTCH LEVER

Original Part No	MLEVP0240AJZZ
Suit	VCA36,37,41,50,53,VC A53,62,63,67,72,VCH 93,94,97,98,VCMH83, 93,VT3428, 5128
Code	LEV0240




## SHARP ARM BRAKE - SUPPLY

Original Part No	MLEVP0244AJZZ
Suit	VCA36,37,41,50,53,VC A53,62,63,67,72,VCH 93,94,97,98,VCMH83, 93,VT3428, 5128
Code	LEV0244




## SHARP ARM BRAKE - TAKE-UP

Original Part No	MLEVP0242AJZZ
Suit	VCA36,37,41,50,53,VC A53,62,63,67,72,VCH 93,94,97,98,VCMH83, 93,VT3428, 5128
Code	LEV0242




## SHARP SLOW BRAKE

Original Part No	MLEVP0250AJZZ
Suit	VCA36,37,41,50,53,VC A53,62,63,67,72,VCH93 ,94,97,98,VCMH83, 93, VT3428, 5128
Code	LEV0250




## SHARP PINCH DRIVE CAM

Original Part No	NGERH1216AJZZ
Suit	VCA36,37,41,50,53,VC A53,62,63,67,72,VCH 93,94,97,98,VCMH83, 93,VT3428, 5128
Code	GR1216



## SHARP LOCK LEVER - TAKE-UP


Original Part No	MLEVP0249AJZZ
Suit	VCA36,37,41,50,53,VC A53,62,63,67,72,VCH 93,94,97,98,VCMH83, 93,VT3428, 5128
Code	LEV0249





## SHARP REEL DISK

Original Part No	NDAIV1065AJOO
Suit	VCA36,37,41,50,53,VC A53,62,63,67,72,VCH 93,94,97,98,VCMH83, 93,VT3428, 5128
Code	RD1065




## SHARP DRIVE LEVER

Original Part No	MLEVF0419AJZZ
Suit	VCA36,37,41,50,53,VC A53,62,63,67,72,VCH 93,94,97,98,VCMH83, 93,VT3428, 5128
Code	LEV0419




## SHARP MID-DRIVE HOUSE LEFT

Original Part No	LHLDX1027GEZZ
Suit	VCA36X, etc....
Code	LDX1027




## SHARP MID-DRIVE GEAR

Original Part No	NGERW1052GEZZ
Suit	VCA36X, etc.
Code	GR1052




## SHARP MID-DRIVE ARM

Original Part No	MARMP0053GEZZ
Suit	VCA36X, etc.
Code	ARM53




## SHARP POLE BASE - SUPPLY

Original Part No	LPOLM0050GEZZ
Suit	VCA36,37,41,50,53,VC A53,62,63,67,72,VCH 93,94,97,98,VCMH83, 93,VT3428, 5128
Code	SPB0050




## SHARP POLE BASE - TAKE-UP

Original Part No	LPOLM0051GEZZ
Suit	VCA36,37,41,50,53, VCA53,62,63,67,72, ,VCH93,94,97,98,V CMH83, 93,VT3428, 5128
Code	TPB0051



## SHARP GEAR

Original Part No	NGERH1196GEZZ
Suit	VCH91X VT3418 VT5118
Code	GR1196




## SHARP BREAK LEVER

Original Part No	MLEVP0279AJZZ
Suit	VCA200
Code	LEV0279



## SHARP PULLEY

Original Part No	NPLYV0163GEZZ
Suit	VCA220, 270, VCA420, 470.
Code	PLY0163




## SHARP IDLER

Original Part No	NIDR0015AJZZ
Suit	NIDR0015GEZZ
Suit	VCA200, 250,VCA400, 460. VCH600, 650,VT3448, 5148
Code	NIDR0015AJZZ




## SHARP IDLER

Original Part No	NIDR0018AJZZ
Suit	NIDR0018GEZZ
Suit	VCA220, 270,VCA420, 470. GIA0018
Code	GIA0018




## SHARP SLIDE PLATE

Original Part No	MSLIP0010AJZZ
Suit	MSLIP0010GEZZ
Suit	VCA220, 270,VCA420, 470.



## SHARP GEAR

Original Part No	NGERH1270GEZZ
Suit	VCA650
Code	GR1270






# Video Repair Parts


## SHARP GEAR

Original Part No	NGERH1271GEZZ
Suit	VCH650
Code	GR1271




## SHARP MASTER CAM GEAR

Original Part No	NGER1295AJ00
Suit	VCA240, 290,VCA490, etc.
Code	GR1295




## SHARP CASSETTE HOLDER

Original Part No	LHLDX1031AJZZ
Suit	VCA200
Code	LDX1031




## SHARP LEVER

Original Part No	MLEVP0336AJZZ
Suit	VCA220, 470,VCA550, etc.VCH680, 705,VCH800, etc.
Code	LEV0336




## SHARP CASSETTE HOLDER

Original Part No	LHLDX1030AJZZ
Suit	VCA200, 250,VCA400, 450,VCA600, 650.
Code	LDX1030




## SHARP HOUSING PANEL

Original Part No	LHLDX1028AJZZ
Suit	VCA650
Code	LDX1028




## SONY ARM ASSEMBLY

Original Part No	X3727-776-1
Suit	SLV215,353 SLV75 7,777,SLVX30,X50, SLVX810,etc.
Code	GIA7761




## SHARP CAM LEVER

Original Part No	MLEVP0237GEZZ
Suit	VCA36, 41, 50, 53,VCA62, 66, 67, 72,VCH83, 93, 94, 97,VCMH80, 83, 93,VT3428, 5128, etc.
Code	LEV0237



## SONY GEAR

Original Part No	3-736-116-01
Suit	SLV215,353 SLV75 7,777,SLVX30,X50, SLVX810,etc.
Code	GR1601




## SHARP BRAKE TAKE-UP

Original Part No	MLEVP0128GEZZ
Suit	Suit most VCA, VCB, VCD, VCH,VCS, VCT, and VR, VT
Code	LEV0128




## SONY PRESS CAM

Original Part No	3-736-135-01
Suit	SLV353,757,SLVX30,X50,
Code	GR3501




## SHARP BRAKE SUPPLY

Original Part No	MLEVP0129GEZZ
Suit	Suit most VCA, VCB, VCD, VCH,VCS, VCT, and VR, VT
Code	LEV0129



## SONY GEAR


Original Part No	3-943-700-01
Suit	SLV215, SLVX35, X55, SLVX810,etc.
Code	GR7701






## SONY CHASSIS BLOCK

Original Part No	A6739-084-A
Suit	SLVX55
Code	MEC9804




## SONY ARM BLOCK

Original Part No	A6759074P
Part No	
Code	GR5074



## SONY WHEEL WORM

Original Part No	3-736-015-01
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	GR1501




## SONY PLATE SLIDE MODE

Original Part No	3-736-177-01
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	PSM7701




## SONY GEAR

Original Part No	3-736-147-01
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	GR1470




## SONY ARM TENSION REGULATOR

Original Part No	3-736-142-01
Suit	SLV757
Code	ARM4201




## SONY PULLEY

Original Part No	X3727-782-1
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	GR7821




## SONY ARM

Original Part No	373614001
Suit	SLV757,SLVX811
Code	ARM4001




## SONY CLEANING ROLLER

Original Part No	A6747-264-A A6747-267-A
Suit	SLVX30. SLV215, 777,SLVX50, 810,etc.
Code	ARM264 ARM267




## SONY LOAD GEAR

Original Part No	3-946-922-01
Suit	SLVX37,SLVX57.
Code	GR2201



## SONY STOPPER

Original Part No	3-736-111-01
Suit	SLV215,353,SLV757,777,SLVX30,X50,SLVX810,etc.
Code	STP1101



Welcome, Visit Admin Test Account, WES Sales Team

Online Catalogue Agencies About Us Contact Us Log Out

SEARCH  Search

QUICK ORDER MY ACCOUNT DOWNLOAD

HOME > SERVICE & REPAIR PARTS > VCR PARTS > VCR ROLLS > Pitch Rollers

WES NEWS

YOUR CURRENT SELECTION:

- 0 SERVICE & REPAIR PARTS
- 0 VCR PARTS
- 0 Pitch Rollers

CATEGORY

ALL

CLASS Reference Device Fuser / Fixer Controller Oscillator I/O / IBC

Pitch Rollers

Product Display View L1 L2 L3


AKAI PITCH ROLLER JVC MITSUBISHI PITCH ROLLER NATIONAL



# Video Repair Parts


## SONY MECH

The following parts are from SONY mechanism to suit SLV7000, SLVT2000 SLVX315, 317, 325, SLVX327, 335, 425, SLVX427, 515, 517, SLVX522, 525, 527, SLVX825, 835, and maybe more we are unaware of!




## SONY REEL DRIVE ASSEMBLY

Original Part No	A-6739-102-A
Suit	SLV, SLVT, SLVX Series
Code	GIA9102




## SONY GEAR

Original Part No	3-958-152-01
Suit	SLV, SLVT, SLVX Series
Code	GR5201




## SONY LOAD GEAR TAKE-UP\*

Original Part No	3-958-485-01, 3-958-485-02
Suit	SLV, SLVT, SLVX Series
Code	GR8502




## SONY GEAR\*

Original Part No	3-958-162-01, 3-958-162-02
Suit	SLV, SLVT, SLVX Series
Code	GR6202



## SONY PLATE SLIDE MODE\*


Original Part No	3-958-163-04, 3-958-163-01
Suit	SLV, SLVT, SLVX Series
Code	LEV6304



## SONY CAM GEAR (OLD)

Suits OLD FRONT LOAD DRIVE GEAR (No Longer Available from Sony.) See KIT5602 Below if replacing both cam and gear, etc.

Original Part No	3-958-161-01, 3-958-161-04
Code	CAM6104



## SONY FRONT LOAD DRIVE GEAR KIT

3-958-156-02 Gear Sony Is no longer available! Sony recommends 'Must use this kit to avoid "No tape loading or eject" problem when replacing GR5603.'


\*Includes gears & slide plate.

Suit	SLV, T, X Series, etc.
Code	KIT5602




## SONY FRONT LOAD DRIVE GEAR (NEW)\*

Original Part No	3-958-156-01, 3-958-156-03
Suit	SLV, SLVT, SLVX Series
Code	GR5603



## SONY CAM GEAR (NEW)\*


Original Part No	3-958-161-07
Suit	SLV, SLVT, SLVX Series
Code	CAM6107



Use only with GR5603  
(See info KIT5602 above!)

## SONY SWITCH MODE


Original Part No	1-413-896-21	1-413-897-11
Code	PS9621	PSM9711



## SONY POWER SUPPLY

1-413-621-11  
Complete module  
from power cord to  
Connection sockets

Suit	SLV777
Code	PSM2111




## SONY ARM OPEN LID

Original Part No	397751401
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	ARM1401



## SONY PINCH PRESS GEAR

Original Part No	397744101
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	GR4103






## SONY TG8 SUPPLY GEAR

Original	397744601
Part No	
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	GR4601



## SONY CLEANING ROLLER

Original	X39472551
Part No	
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	RL2551




## SONY LOAD GEAR TAKE-UP

Original	397745501,
Part No	397745502,
	NEW, 397745503
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	GR5503




## SONY GEAR ASSEMBLY & PULLEY

Original	X397745101
Part No	
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	GR5851




## SONY REEL DIRECT GEAR

Original	X39475841
Part No	
Suit	SL-VEZ1, 10, SL-VEZ7, 70.
Code	GR5841



## SONY WORM WHEEL GEAR


Original	397743801,
Part No	306376001
Suit	SLVEZ1, 10, 11, 22, SLVEZ4, 44, 66, 7, 70, 77.
Code	GR3801



## Toshiba

### TOSHIBA IDLER

Original	70326538
Part No	
Code	VIA820



## Teac / Philips


### TEAC / PALSONIC / FUNAI / GOLDSTAR / LG

Rebadging technology  
AND NOW PHILIPS



## PHILIPS TEAC GEAR KIT 482231010657

Original	4822 3101 0657
Part No	
Suit	MV7, 77, 777, RTV250, 256, 350, RTV356, 725, 785, VR9489.
Code	GR10657



## TEAC/PHILIPS VCR SERVICE KIT-i

Original	4822-310-31963
Part No	
Suit	GR560, GV540, MV7, 77, 777, RTV250, 256, 350, RTV456, 725, 785, VR9489/39.
Code	ES7118



## TEAC/PHILIPS VCR SERVICE KIT-b

Original	4822-310-31955
Part No	
Suit	GR560, GV540, MV7, 77, 777, RTV250, 256, 350, RTV456, 725, 785, VR9489/39.
Code	ES7111






# Video Repair Parts

## VCR Cassette Housings

### Akai

#### AKAI CASSETTE LOAD ASSEMBLY

Original Part No	BV-V1102A150A
Suit	VS422, VS425, VS765, VSA650, VSF10, VSF11, VSF12, VSF650, etc.
Code	CH1102



## Daewoo / Tempest

#### DAEWOO TEMPEST CASSETTE HOUSING

Original Part No	97SA104100, 97SA104110
Suit	DVR6158, VCR32, 52, VCR8025, TE970R, 99R.
Code	CH8025



## Funai / Teac / Palsonic

#### FUNAI TEAC PALSONIC CASSETTE HOUSING


Original Part No	62D806516301
Suit	MV3010, 3030, 3050, MV4010, 6010, Palsonic VCR9688
Code	CH6301



## LG / Goldstar


#### GOLDSTAR CASSETTE HOUSING

Original Part No	219-011A, 219-004A
Suit	AV62, GHV1241, 46, 47, GHV51, KBV9012, M22, VCR7000, VR1500, etc.
Code	CH9011




#### GOLDSTAR CASSETTE HOUSING

Original Part No	219-015B, 219-010B
Suit	AV65, GHV1290, 91, 92, 93, GHV1392, 93, 1910, VCP4200, 4300, VCP4305, 4306.
Code	CH9015



#### GOLDSTAR CASSETTE HOUSING


Original Part No	219-017B, 219A017F
Suit	AV66, RG20
Code	CH2190



## JVC / Philips


#### JVC CASSETTE HOUSING6

Suit	HRD540, 580, 920, HRDX20, 42, VR3241, etc.
Code	PUS29499B




#### JVC CASSETTE HOUSING7

Suit	HRD520EA	HRDX22
Code	PUS29499C	PUS29499E




#### JVC CASSETTE HOUSING

Suit	HRJ200, 400.
Code	PUS29672A-5




#### JVC CASSETTE HOUSING1

Suit	HRJ600
Equiv.	PUS29662A4
Code	PUS29662C1




#### JVC CASSETTE HOUSING2

Original Part No	PUS26805U
Suit	HRD140, 141, 142, HRD143, 150, 250, HRD455, 565, 566, HRD725, 755 and NEC N895.
Code	CH2681




#### JVC CASSETTE HOUSING3

Original Part No	PUS26805Q
Suit	HRD110, 111, 120, HRD121, 220, 225, RV360, 370, GE8100, 9300, N830/1/3
Code	CH2680



#### JVC CASSETTE HOUSING4


Suit	HRD170, 180, HRD160, 200, 190,etc.
Code	PUS28277F






## JVC CASSETTE HOUSING5

Original	PUS25908D-101
Part No	
Suit	HR2200, HR2650
Code	PUS25908



## JVC CASSETTE HOLDER

Suit	HR7700
Code	PU20934A



## □ Mitsubishi

### MITSUBISHI CASSETTE HOUSING


Original	590A256020
Part No	
Suit	HSE11, HSM33, 57, HSM58, 68, HSM1000, HSMX1, X2.
Code	CH5602



## □ Panasonic

### PANASONIC HOUSING

Suit	NVG10 etc.
Equiv.	VXA2562
Code	VXA2450




### PANASONIC DOOR KIT

Original	VKF0225 & Spring
Part No	VMB1171
Suit	NV370, NV600, NV788, NV850, etc.
Equiv.	VKF0225, VFK0266, VFK0335, VFK0336, VFK1715, etc.




### PANASONIC CASSETTE HOLDER

Suit	NVSD10, NVF65, 66, 20, 30
Equiv.	70, 90
Code	VXA3832




### PANASONIC SIDE PLATE

Includes opener lever	VXL2250
Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXA4660




## PANASONIC SIDE PLATE

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXA4806




## PANASONIC SHAFT ASSEMBLY

Suit	NVSD10A, NVSD20A, NVSD30A
Code	VXP1339




## PANASONIC SIDE PLATE

Suit	NVL20, 25, NVG25, 'G' Mech 28, 'G' Mech
Type	6 Pin
Code	VXA4076



## PANASONIC SHAFT


Suit	NVG33, NVH75, etc.
Equiv.	VXP0987
Code	VXP0851



## □ Samsung


### SAMSUNG CASSETTE HOUSING

Original	61227004705
Part No	
Suit	VB520, 900, Akai VS200, Tempest TE900H



## SAMSUNG CASSETTE HOUSING

Original	62052-0004-02
Part No	
Suit	VB300, VB370, VB3260, etc.



### SAMSUNG CASSETTE HOUSING

OEM	66122-700-493
Suits	TE90H, VB711, VB8220, VB970, VS11, VS12
Code	CH4930








## □ VCR Tension Bands

### □ Akai


#### AKAI TENSION BAND

Original Part No	BLB360350
Suit	VS112, VS165, 505
Code	TB3603




#### JVC TENSION BAND

Suit	HR7200, 7300, 7600, 7650, HRD110, 111, 120, 121, 225, HV4000, 8000, VCR1500, N830, 831, 833, RV340, 350, 360, 370.
Code	PU51390A




#### AKAI TENSION BLOCK

Original Part No	BL4335386
Suit	VSG280, VSG2DPL, VSG765, 790, 875.
Code	ARM5386



#### JVC TENSION BAND


Suit	HR3300, 3330, 3660, 3600, 4100, HV1000, 2000, 3000, RV300, 310, 320,
Code	PUS45904A



### □ Funai / Teac / Palsonic


#### FUNAI TENSION BAND

Original Part No	8059-08-302
Suit	MV435, 445, VX2000, etc.
Code	TB8302




#### JVC TENSION BAND

Suit	HRD455, 725 NEC
Code	N895 TOSHIBA V63




#### GOLDSTAR / NEC TENSION BAND

Original Part No	333-329A, 328-075A, NEC 79VG0998, VN36
Suit	P23H, P433H, P933H, RN800H, RN830H, T293H, T493H, VHG104, VNG67.
Code	TB3329



#### JVC TENSION BAND


Suit	HR2200, HR2650
Code	PU48784B



### □ JVC

#### JVC TENSION BAND

Suit	HRD170, 180, 210, 217, 300, 321, 370, 400, 440, 441, 470, 500, 530, 700, HRS5000, 9000 etc.
Code	PQ41948A




#### JVC TENSION BAND

Suit	HRC3
Code	PU52993A




#### JVC TENSION BAND

Suit	HRD140, 141, 142, 143, 150, 152, 156, 157, 160, 250, 257, 565, 566, 755,
Code	PQ41370B




#### JVC TENSION BAND

Original Part No	PQ46298A-3, PQ46298A-5
Suit	HRJ220, HRJ221, HRJ625
Code	PQ46298




#### JVC TENSION BAND

Equiv.	PQ44734A-1
Suit	HRD640, HRD910
Code	PQ45527A-1



#### JVC TENSION BAND

Suit	HRJ600
Code	PQ34629A-3






# Video Repair Parts

## Panasonic


### PANASONIC TENSION BAND

Suit NV7000, 7200,  
NV7500 and  
BLAUPUNKT  
RTV222  
Code VXZ0078




### PANASONIC TENSION BAND

Suit NV300, 600, NV777,  
etc. AG6200,  
RTV321.  
Code VXZ0129




### PANASONIC TENSION BAND

Suit NV250 etc. NV-G10  
etc.  
Code VXZ0165




### PANASONIC TENSION BAND

Suit NVG20, etc.  
Code VXZ0267




### PANASONIC TENSION BAND

Suit NVSD10A,  
NVSD20A, NVSD30A  
Code VXZ0310



### PANASONIC TENSION BAND

Original VXL2671, VXL2793  
Part No  
Suit NVSD220, 270,  
NVSD420,  
NVHD620, 670.  
Code VXL2671



### PANASONIC TENSION BAND


Model. NV2000, NV3000  
Code VXZ0078



## NEC

### NEC TENSION BAND


Original 16177851  
Part No  
Suit DX9012, 9014,  
DX9016, 9033,  
Code TB7851



## Samsung

### SAMSUNG TENSION BAND


Original 61543-0071-00V  
Part No  
Suit SV10, 11, 12,  
SV30, 80, 140  
Code TB7100



## Sanyo


### SANYO TENSION BAND

Original 613-160-5282  
Part No  
Suit VHR510, 530,  
VHR590, 610,  
VHR630, 650  
Code TB5282




### SANYO TENSION BAND

OEM 1430711T02100,  
6130375377,  
6130375384  
Suits TLS1000, VHR3100,  
VHR3500, VHR3700.  
Code TB4936



### SANYO TENSION BAND


Original 1430711T02021  
Part No  
Suit VHR2100, VHR2300,  
VHR2500, VHR2700,  
etc.  
Code TB2021



## Sharp


### SHARP TENSION BAND

Original LBNDK1002GEZZ.  
Part No  
Suit VCA10, 30, 60, 103,  
105, 106, 111, 505,  
605, D810, VCH80,  
VR6443, 6448,  
Code DK1002



### SHARP TENSION BAND


Original LBNDK3011GEZZ,  
Part No Philips  
480240117243  
Code DK3011






## SHARP TENSION BAND

Original Part No	PBRKZ0003GEZZ, LBNDK1001GEZZ
Suit	VC200X, 820X, 600/700 series & Philips equiv.
Code	TB0003




## SHARP TENSION BAND

Original Part No	LBNDK3008GEZZ
Suit	VC7300, VC7700, etc.
Code	DK3008




## SHARP TENSION BAND

Original Part No	LBNDK3014GEZZ, 480240357605
Suit	300, 400, 500, 6000 and Philips
Code	DK3014




## SHARP TENSION BAND

Suit	VCA36, 37, 41, VCA50, 53, 62, VCA67, 72, VCH94, 97, 98, VCMH38, H93.
Code	DK1008




## SHARP TENSION BAND

Original Part No	LBNDK1011AJZZ
Suit	VCA220, 270, VCA420, 470.
Code	DK1011




## SHARP TENSION BAND

Original Part No	LBNDK1009GEZZ
Suit	VCH650X
Code	DK1009



## SONY TENSION BAND

Original Part No	X-3943-886-1
Suit	SLVX812, SLVX822
Code	TB8861



## □ Mode Switches

### □ Akai


#### AKAI SWITCH

Original Part No	ES-348089J1
Suit	VS4
Code	SW3480




#### AKAI MODE SWITCH

Original Part No	VT372187, VT363354
Suit	VS112, 165, VS512, 515, VS516, etc.
Code	SW3721




#### AKAI MODE SWITCH

Original Part No	ES387465J
Suit	VS422, 425, VS765, 965, VSA650, 1100, VSF10, G11, & MORE
Code	SW3874



#### AKAI MODE SWITCH

Original Part No	ES353653A
Suit	VS202, 303, VS603, 606 VS607, etc.
Code	SW3536




#### AKAI MODE SWITCH

Original Part No	ES-381310J1
Suit	VS22, 26, 35, VS53, 66, 75, VCA77, R8, etc.
Code	SW3813



#### AKAI MODE SWITCH

Original Part No	ES433595, 047K120340-01
Suit	VSG280, VSG2DPL, VSG765, 790, 875.
Code	SW4001



#### AKAI MODE SWITCH

OEM	ES419326N1, ES419326J1
Suit	VSG204, VSG2300, VSG425EA, VSG745EA, etc.
Code	SW9326






# Video Repair Parts

## □ Deitron / Tempest / Tracton

### DIETRON / TEMPEST / TRACTON


Original Part No	5S30407011
Suit	TE99R,970R, VCR32,52,8052, DVR6158D,etc.
Code	SW3040



## □ Funai / Teac

### FUNAI SWITCH ASSEMBLY


Original Part No	8059-16-320
Code	FU1620



### FUNAI TEAC MODE SWITCH

8000-22-304, WA-03VO, 6 pin


Suit	MV300, 400, MV430, 435, MV1400, 1440
Code	SW3105



### FUNAI TEAC MODE SWITCH

62D806513302 Board & connectors.

Suit	MV3010, 3030, MV3050, 4010, MV6010, etc, VCR9688, etc.
Code	SW3302



### FUNAI TEAC MODE SWITCH


Original Part No	5SSF1DKM10, MMSS00320ZMB0
Suit	D284 D884, DVK10 224 424 824, MV3080 3092 4090, MV6080 6090 6092
Code	SW3200



## □ Goldstar


### GOLDSTAR MODE SWITCH

Original Part No	556-115A
Suit	VCP100,101, VCP110,115, VCP120,126, KVP120,etc.
Code	SW6115




### GOLDSTAR MODE SWITCH

Original Part No	556-085A
Suit	GHV1290,1295, GHV1910,4300, GHV4310,4320, AV64,etc.
Code	SW5560




### GOLDSTAR MODE SWITCH

Original Part No	556-055B
Suit	GHV1232,1240, GHV1241,1247, KBV9012,AV61/2, VCP4100,R7000, and more...
Code	SW6055



### GOLDSTAR MODE SWITCH

Original Part No	556-133A
Suit	AV66, RG20. and more...
Code	SW6133



### GOLDSTAR / NEC MODE SWITCH


Original Part No	556-252A & B, NEC 79VG1093 VN36
Suit	P23H, P433H, P933H, RN800H, RN830H, T293H, T493H, VHG104, VNG67.
Code	SW6252



## □ Hitachi


### HITACHI MODE SWITCH

Original Part No	5625141
Suit	VT100,110, VT111,125, VT128,138, VT150....
Code	SW5141




### HITACHI MODE SWITCH

Original Part No	5625061
Suit	VT11,14, VH600, VT9300,etc.
Code	SW5061



### HITACHI MODE SWITCH

Original Part No	5625091
Suit	VT17,19,33,34,35,38, 52,63,330,640.
Code	SW5091






## JVC


### JVC SLIDE ENCODER

Suit HRD170,171,180,210,230, PU58642  
HRD320,470,530.  
HRD227,380. PU59924




### JVC SLIDE ENCODER

Suit HRD300,337,  
HRD400,441,  
HRD700,750,  
HRS5000,5500,  
HRS9000,etc.  
Code PU60444




### JVC SLIDE ENCODER

Original PU60973-1-1  
Part No  
Suit HRD540,580  
Code PU60973




### JVC SLIDE ENCODER

Suit HRD520, 521,  
HRD830, 600,  
HRDX20, 22,  
HRJ200, etc.  
Code PU60622




### JVC SLIDE ENCODER

Original PU61247-1  
Part No  
Suit HRD640, HRD790,  
HRD910  
Code PU61247




### JVC SLIDE ENCODER

Suit HRJ600  
Code PU61322-1-2



## JVC ROTARY ENCODER

Suit HRJ220, 221,  
HRJ625, etc.  
Code PU61432-1-1




## Mitsubishi

### MITSUBISHI MODE SELECTOR

#### GREY COG


Original 439P011020  
Part No  
Suit HS337,338,  
HS347,411,  
HS421,etc..  
Code SW1102



### MITSUBISHI MODE SWITCH

#### GREEN COG


Original 439P011040  
Part No  
Suit HSE10, 20, 30  
Code SW1040



### MITSUBISHI MODE SWITCH KIT


COMPLETE KIT  
Manufacturer  
recommends:  
Replace one,  
Replace them all!

Original 439P007010  
Part No  
Code KT7010




### MITSUBISHI CASSETTE SWITCH

Original 439P00802  
Part No  
Suit AV12,51, 400,  
TR102, etc.  
Code SW8020



### MITSUBISHI MODE SWITCH

Original 439D03901,  
439D039010,  
439P03101/0  
Suit HSM50,X3,  
HSMX5,X7,  
HSMX10, 20.  
Code SW3901






# Video Repair Parts

## □ NEC


### NEC MODE SWITCH

Original 5S10407058  
Part No  
Suit VN20  
Code SW7058




### NEC MODE SWITCH

Original 5SSFMDKM10,  
Part No MMA0018OZBO,  
79TD3598  
Suit VN23,26,64, AWA  
2H20D, AWA 4H40D,  
etc  
Code SW3598



### NEC MODE SWITCH


Original 65909041  
Part No  
Suit N9000 series.  
Code SW9041



## □ National


### NATIONAL MODE SWITCH

Suit NV2000, 3000, 7000,  
7200  
Code VSS0048




### NATIONAL MODE SWITCH

Suit NV300, 340, 600,  
777, 788  
Code VSS0060




### NATIONAL MODE SWITCH

Suit NV370,380,480,630,  
NV730,770,780,850.  
Code VSS0091




### NATIONAL MODE SWITCH

Suit NVG7, 9, NVG10, 11,  
NVG12, 16,  
Code VSS0135




### NATIONAL MODE SWITCH

Suit NV100  
Code VSS0061




### NATIONAL MODE SWITCH

Suit NV250, 280, NV450,  
470, NV870, etc.  
Code VSS0110




### PANASONIC MODE SWITCH

Suit NVG20, 22, 25, 33,  
40, 45 NVH65, H75,  
L20, L25, RTV560,  
740, etc.  
Code VSS0175A




### PANASONIC MODE SWITCH

Suit NVG30  
Code VES0327



### PANASONIC MODE SWITCH

Original VSS0520  
Part No  
Suit NVSD220, 270,  
NVSD420,  
NVHD620, 670.  
Code VSS0520



### PANASONIC CASSETTE UP/DOWN SWITCH


Suit NV300, 370, 600,  
777, 788 etc.  
Equiv. VSM0046  
Code VSM0048



## □ Samsung

### SAMSUNG/TEMPEST MODE SWITCH

Original 9000-221-4109  
Part No  
Suit VB627, VB629  
Code SW6900




This switch will substitute for a Samsung/Tempest mode switch used in VB900, VB2215B and TE900. With info.



## Sanyo


### SANYO/FISHER MODE SWITCH

Original 4-2314-00251, Also  
Part No 621-006-4030  
Suit FVH-P series.  
Code SW4030




### SANYO MODE SWITCH

Original 613-110-0374, 613-  
Part No 077-4361  
Suit VHR4100,5700,  
Code SW4361




### SANYO/FISHER MODE SWITCH

Original 610 064 783, Also 4  
Part No 231V 86200  
Suit VHR1100, VHR1300,  
VHR1500  
Code SW6200




### SANYO/FISHER MODE SWITCH

Original 4-231V-86500, Also  
Part No 613-006-4820  
Suit VHR2500  
Code SW4820




### SANYO/FISHER MODE SWITCH

Original 4-231V-87400, Also  
Part No 613-006-4936  
Suit VHR3500,  
VHR3700,etc.  
Code SW4936



### SANYO REC SAFETY SWITCH

Original 4-231V-8700  
Part No  
Suit VHR3100 etc.  
Code SW8700



### MICRO PUSH SWITCHES

Most videos use  
common types and  
some are brand specific.  
For our entire switch  
range see:


<http://www.wes.com.au/>



## Sharp


### SHARP MODE SWITCH

Original QSW-R0014GEZZ  
Part No  
Suit VC581, VR6441.  
Code QSWR0014




### SHARP MODE SWITCH

Original QSW-R0019GEZZ  
Part No  
Suit VCA502, VCH851,  
etc.  
Code QSWR0019




### SHARP MODE SWITCH

Original QSW-R0026GEZZ  
Part No  
Suit VCA30, 35, VCA115,  
125.  
Code QSWR0026



### SHARP CASSETTE IN SWITCH


Original QSW-F0004GEZZ  
Part No  
Suit 300/9000 series.  
Code QSWF0004



### SHARP SWITCH

Suit many models.

Original QSWF0011GEZZ  
Part No  
Code QSWF0011




### SHARP CASSETTE IN SWITCH

Original QSW-F0021GEZZ  
Part No  
Suit DAEWOO,  
DEITRON,  
TEMPEST.  
Code QSWF0021



### SHARP LEAF SWITCH

Original QSW-F0023GEZZ  
Part No  
Suit VC51B  
Code QSWF0023






# Video Repair Parts


## SHARP MODE SWITCH

Original Part No	QSWR0008GEZZ, QSWR0010GEZZ, 480227617213
Suit	MV640, 740, VC5F3, VC383, 481, 584, 9300, VR401, 6840, VRD012
Code	QSWR0010



## SHARP MODE SWITCH

Suit	VC651, 682,6V3,6442, VR6520,6542.
Code	QSWR0017




## SHARP MODE SWITCH

Original Part No	QSWR0023GEZZ
Suit	VC780,790, VCA105,A111, VCA505,D805, VCH855,...
Code	QSWR0023




## SHARP MODE SWITCH

Original Part No	QSW-S0032GEZZ
Suit	VC381,386, VC388,390, VC9300, VR501,601, VRD022,etc...
Code	QSWS0032




## SHARP CASSETTE-IN SWITCH

Original Part No	QSWF0010GEZZ
Suit	MP121,MV740, VC387,482,581,... VC4842,8482, VR6440,6641, VR6840,6937
Equiv.	QSW-M0014GEZZ, QSW-M0019GEZZ
Code	QSWF0010



## SHARP SWITCH

Original Part No	QSW-F0013GEZZ
Suit	VC381,383,390, VR501,601,701, and more
Equiv.	QSW-M0014GEZZ, QSW-M0019GEZZ
Code	QSWF0013




## SHARP ROCKER SWITCH

Original Part No	QSW-F0022GEZZ
Suit	VC200,500,651, VC682,6F3,779, VCT85,787,793, VCA101,103,502, VR6443,6543,etc.
Code	QSWF0022




## SHARP LEAF SWITCH

Original Part No	QSW-F0024GEZZ
Suit	VC51B, VCA101, VR6443, More.
Code	QSWF0024



## SHARP SWITCH


Suit	14VT10X, VCA10,30,40,60, VCA105,115,125, VCB20,60,D810, VCH80,855,S1000, VR3360,6448,etc..
Code	QSWF0040



## SHARP CASSETTE SWITCH AND PCB

Complete PCB, switch and components, etc.


Original Part No	Old QSW-F0035GEZZ, New DUNTK3194HE00
Suit	VCA111X and others.
Code	KT3194



### □ Sony


## SONY MODE SWITCH

Original Part No	1-692-062-11
Suit	SLV715, SLV810*, SLV811, SLV815
Code	SW2012




## SONY MODE SWITCH

Original Part No	1-762-490-11, 1-762-076-11
Suit	SLVX812, SLVX822
Code	SW9011



## SONY FACIA ROTARY SWITCH


FF/REW Rotary PLAY/STOP Push	1-572-662-11
Original Part No	SLVF10, SLVX810
Suit	
Code	SW6211



### □ Push Button

## AKAI PUSH SWITCH

Original Part No	ES349367
Code	SW9367



Replacement push-switches  
See our website for more...



## □ Mode Sensors

## □ Universal Lamps

### VCR SENSING LAMP

Volts	Globe	Pack of	Code
6V	4mm	5	BIP465
8V	4mm	5	BIP485
12V	3mm	5	BIP3125
12V	4mm	5	BIP4125
12V	5mm	5	BIP5125

## □ LG / Goldstar

### GOLDSTAR SENSOR

Suits many models and many brands.

Original 513-194D

Part No LN3194

## □ National

### NATIONAL PHOTO DIODE

Used in National and other VCR's.

Code PN202S-R




## □ JVC

### JVC PHOTO DIODE

Suit HRD540, 860, X20, etc...

Code PU60625



## □ Sharp

### SHARP PHOTO DIODE

Original RH-PX0039GEZZ

Part No PX0039



### VCR SENSING LAMP

Suit older units

Volts	Code
12V	SL79-12
6V	SL79-6



## □ JVC

### JVC SENSING LAMP


Suit HR7200 etc.

30cm lead.6

volt,70mA. 4mm

Diam.

Code SL15



### JVC SENSING LAMP

As SL15

Including Plug.

20cm blue lead.

Code SL25



## □ Akai

### AKAI SENSING LAMP

VS1, 2, 3, 4, 5 etc.

12V 60mA. 50cm

lead.


Code SL40



### AKAI LAMP & HOLDER

Same as SL40

Code SL42



## □ Sharp

### SHARP SENSING LAMP

300 & 900 series 5V,

110mA, 18cm lead.


Code SL50



### SHARP LAMP & HOLDER

As SL50

Code SL52



## □ NEC


### NEC LED & HOLDER

Original 16-19-1821

Part No

Equiv. 16-18-6441

Code LN1821



## □ OptoCouplers

### OPTO COUPLERS

4N35

4N25

4N26

4N28

4N36

4N38A

ON3105

ON3131

ON3171

PC111S

PC113

PC120

PC123


PC714

PC813

PC814

PC816

PC817




## □ JVC

### JVC REEL SENSOR

Suit HRD540, 580,

HRDX20, etc.

Code PS5705



## □ SHARP

### SHARP SENSOR

Original RHPX0238GEZZ

Part No PX0238



## □ JVC


### JVC SENSOR

Original JVC HR-

Part No D725, NEC

N895

Code PU55827



## □ SHARP

### SHARP SENSOR

Original RH-PX0042GEZZ

Part No PX0042



## □ JVC

### JVC SENSOR

Original PU57650-1-1


Part No

Suit HR-D160,

275, 755,

etc.

Code PU57650



## □ SHARP

### SHARP IR SENSOR

Original RHPX0176GEZZ,

Part No RHPX0053GEZZ

Code PX0176



## □ JVC

### JVC REEL SENSOR

Suit HRD170,

180, 530

HRD520,

etc.

Code PU60271

Code PU60629



## □ ROTATION SENSOR

### ROTATION SENSOR

Original RHPX0252GEZZ

Part No

Suit VCA200X

Code PX0252




## □ OptoCouplers

### OPTO COUPLERS

Suit HR-D300,

etc.

Code PU58879



## □ Infrared

### INFRARED RECEIVER

Original NATIONAL

Part No PN313B or

PH302

Code PN313



## □ Reel Sensor

### REEL SENSOR

IR TX & RX LEDs

Code PS6002A



## INFRA-RED RECEIVER


PN323B, PH310,

ED360409 and

more!

Equiv. PH310

Code PN323





# Video Repair Parts


## Misc Parts

### Brake Pads

#### AKAI BRAKE PADS

21mm x 5mm  
Supplied in bags  
of 10 pieces.

Code  
ABP10



#### JVC BRAKE PADS

8mm x 2.5mm  
Supplied 10 pcs/bag.


Original PUM30019-2  
Part No  
Code JBP10



#### SANYO BRAKE PADS


21mm x 3.5mm  
Supplied 10 pcs/bag.

Original 613-055-7117, 143-2-  
Part No 712T-05200  
Code SBP10



## VCR Misc Parts


### JVC KNOB SET



Suit HRDX20EA      Code PQ21174

### SHARP CRYSTAL

Original RCRSB0090GEZZ  
Part No  
Code CR0090




MORE X-TALS SEE SECTION 10  
COMPONENTS

### DOOR CATCH

FRONT FLAP CLOSE  
As found on front door  
flaps on VCRs, DVDs,  
etc. Push to open  
Push to close

Code  
DL1902



## Chroma


### NATIONAL CHROMA PCBs

Code  
VEFC009  
VEFC013  
VEFC015




### PANASONIC COLOUR MODULES

Suit NVG30      Code VEFH03D  
NVJ1      VEFH04F



### PANASONIC COLOUR MODULES

Suit NVHD100, NVSD1, 10  
Equiv. VEFH29B, VEFH29C  
Code VEFH29D



## VCR Switchmode Repair

### PANASONIC SWITCHMODE REPAIR KIT

OEM kit by Panasonic. Includes Resistors, Diodes, Transistors,  
Required for repair.


Suit NVSD200, 205,  
NVSD207, 250,  
Code VUE4127KIT



Suits NVHD600,  
NVHD650,  
NVHD655,  
NVSD450.  
Code VUE4126KIT

### SONY SWITCH MODE

Original	1-413-896-21	1-413-897-11	1-413-621-11
Part No			
Suit	SLVX312PS	SLVX835	SLV777
Type	8 Pin		
Code	PS9621	PSM9711	PSM2111





## VHS Blank Tapes

### VHS BLANK VIDEO CASSETTES

STOCK MAY CHANGE  
DEPENDING ON AVAILABILITY

Excellent quality recording  
and playback with reliable  
archiving longevity.

Time      Code  
180min    VHS180




### HEAD CLEANER VHS

Non-Abrasice polyester to clean  
the entire tape path. Includes  
cleaning solution. Note this tape  
does not have a leader tape and  
may not function as expected in  
some machines.

Code  
HL-201

### EXTRA CLEANING SOLUTION


Code  
CS500



### GENERAL PURPOSE VHS TEST TAPE

This tape is designed  
as a preliminary  
service test tape for  
standard VCR's. Its  
cost effectiveness  
makes it suitable for  
initial fault finding and  
mechanical checking.  
It contains 30 minutes  
of colour bar signal  
and 1KHz audio tone.

Code  
VID50




### CASSETTE ADAPTOR VHS-C

Adapts the compact  
camcorder cassette to  
the normal size. VHS-C  
Cassettes ONLY! S-VHS  
Compatible [ NOT 8mm/Hi-8 ]  
REQUIRES "AA" BATTERY

Code  
EL303E

NOT FOR 8mm!



### MINI-DV BLANK CASSETTE - SD PANASONIC

Panasonic's AY-DVM83PQ  
MiniDV tape is designed for  
professional usage. High output  
level & low error rate. Reliable  
performance and instant access.  
Made in Japan.

Time      Code  
83minLP   DVM83PQ  
55minSP



### PRECISION VHS ALIGNMENT TAPE

Highest Quality recording.  
Suit final alignments.  
8 min RF Sweep  
8 min Colour bars 3KHz Tone  
8 min Staircase Monoscope  
333Hz Tone  
6 min Crosshatch, Linearity  
(circle & border)

Code  
VID70






# Video Repair Parts

## □ Servicing Tools and Accessories

### VCR ALIGNMENT TOOLS

Three types are available to adjust AC heads, video heads, tape guide path, transport, etc.

Code HT36




### SECURITY TAMPER LABELS

**"WARNING - WARRANTY VOID IF SEAL BROKEN OR TAMPERED WITH."**

Place over screws and seals to prevent tampering. Suit repair shops, etc. Special type sticker that will not peel off in one go. Convenient dispenser box. Roll 500 pieces

Code  
WL500



### ELECTRONIC TOOL WALLET

#### 25 PIECE REPAIR KIT

An excellent variety of common electronic repair tools for the technician Soldering/De-Soldering, Screw drivers, Cutters, all manner of handy items Zip-Case 285x195x50mm

Code  
GTK030B

More tools; See Section 07  
TOOLS & TEST EQUIPMENT



### TOOLS & TEST EQUIPMENT - SECTION 07

#### SEE SECTION 07 TOOLS & TEST EQUIPMENT

We also stock a large range of hand tools like screwdrivers needle-noze pliers NEW! Screw head pliers! Cutters, crimpers, seizure clamps, assorted sizes of metal & plastic tweezers plus lots more!



### UNIVERSAL HEAD EXTRACTOR TOOL

Extract VCR heads without damage to either head or mounting assembly. Adjustable so as to suit various brand heads.

Code  
HT800



### COTTON GLOVES

Eliminate the need to clean heads after fitting by using gloves. Recommended by leading manufacturers. Sold in pairs.

Code  
GLV2



### HAND ASSIST TOOLS

A collection of assorted hand tools scribes, hooks, blades, brushes, etc. designed to assist technicians in repair and servicing. Premium quality. Made in Japan.

Code  
SA10



### PEARL CATCHER

Order One to receive a bag of FIVE


Type Code  
Plastic PU6



### DENTIST MIRROR

Look behind things.

Code  
HT922



Please see section TOOLS & TEST EQUIPMENT



## CLEANING SWABS

### DAICHI CHAMOIS SWAB

High quality synthetic chamois tipped with 45° angled shaft. Gives easy reach, non-abrasive cleaning for video heads, etc. Approx. 75mm length

QTY	Code
10	VCS10



### FOAM CLEANING SWABS

Lint-less foam swabs with a plastic shaft. Packaged 20 per bag.

QTY	Code
20	VCS20A



### CHEMTRONICS FOAMTIPS™

Lint-free non-abrasive cellular urethane cleaning swabs.

QTY	Code
50	CF50



### DAICHI COTTON BUDS

Ridged wooden shaft white cotton tipped

QTY	Code
100	ACS100



### CHEMTRONICS COTTONTIPS™

Pharmaceutical grade extremely soft, absorbent, rigid shaft.

Description	Code
Single ended medical grade cotton bud x100	CT100
Double ended medical grade cotton bud x100	CT2000
Single ended medical grade cotton bud x1000	CT5000



### AF COTTON BUDS

Safebuds - 15cm pure cotton tipped rigid wooden sticks. Ideal for cleaning awkward corners and difficult to reach parts of computer hardware. 10 Bags of 100 Buds per bag (1,000 Buds in total)

QTY	Code
1000	ASBU000



## VCR HEAD CLEANING SPRAY

### MORE SEE TOOLS SECTION

AF Headclene Magnetic Head Cleaning Fluid 250ml Pump Spray

Non-flammable pump action  
(Contains no CFCs or HCFCs)  
cleaning fluid for magnetic read/write heads. Does not harm plastics or rubber, leaves no residue, and dissolves light grease and oil. Use with Foambuds, PC Buds, Safewipes or Safebuds.

- Non-flammable
- Leaves no residue
- Alcohol free

Size	Code
250ml	AHCE250



## MECHANICALS GREASE

### PLASTICS GREASE

Plastic to Plastic or Metal.

Size	Code
35ml	SPG35SL



### MOLYKOTE DX PASTE

White Grease for Surfaces & Bearings.

Size	Code
50g	MK6195



### MOLYKOTE BR 2 PLUS

Metal bearings, etc.

Size	Code
100g	LM47





# Video Repair Parts

