

CRUNCH

Model	Opis	Cena Detal
GPX500.2	CRUNCH GTX 2CH AMP GPX500.2	339
GPX1000.4	CRUNCH GTX 4CH AMP GPX1000.4	469
GPX750.1D	CRUNCH GTX Digital Monoblock GPX750.1D	499
GPX1100.1D	CRUNCH GTX Digital Monoblock GPX1100.1D	599
GPX2200.1D2	CRUNCH GROUNDPOUNDER Digital Monoblock GPX2200.1D	899
GPX3300.1D	CRUNCH GTX Digital Monoblock GPX3300.1D	999
GPX4400.1D	CRUNCH GTX Digital Monoblock GPX4400.1D	1199
GPX2000.5	CRUNCH GROUNDPOUNDER 5CH Hybrid AMP GPX2000.5	999
GTS2250	CRUNCH GTS 2CH AMP GTS2250	399
GTS4125	CRUNCH GTS 4CH AMP GTS4125	549
GTS1200.1D	CRUNCH GTS Digital Monoblock GTS1200.1D	699
GTS2400.1D	CRUNCH GTS Digital Monoblock GTS2400.1D	999
GTO2125	CRUNCH GTO Digital 2CH AMP GTO-2125	579
GTO4125	CRUNCH GTO Digital 4CH AMP GTO-4125	849
GTO3750	CRUNCH GTO Digital 3CH AMP GTO-3750	1149
GTO1750	CRUNCH GTO Digital Monoblock GTO-1750	899
GTX2600	CRUNCH GRAVITY 2CH AMP GTX-2600	779
GTX4800	CRUNCH GRAVITY 4CH AMP GTX-4800	999
DSX1750	CRUNCH DEFINITION Monoblock DSX-1750	649
GTI2200	CRUNCH GTI 2CH AMP GTI-2200	549
GTI1500	CRUNCH GTI Monoblock GTI-1500	899
CRB1000	CRUNCH CRB Dual-Bandpass CRB-1000	1899
CRB501	CRUNCH CRB Single-Bandpass CRB-501	1199
GTS350	CRUNCH GTS Single-Bandpass GTS-350	599
GTO8BP	CRUNCH GROUNDPOUNDER Single-Bandpass GTO-8BP	599
GTO10BP	CRUNCH GROUNDPOUNDER Single-Bandpass GTO-10BP	699
CRB250	CRUNCH CRB Single-Bassreflexbox CRB-250	449
CRB350	CRUNCH CRB Single-Bassreflexbox CRB-350	599
GP800	CRUNCH GROUNDPOUNDER Active-Subwoofer GP800	899
GP600	CRUNCH GROUNDPOUNDER Active-Subwoofer GP600	798
GTS6.2C	CRUNCH GTS 2-Way Compo 16,5 cm GTS-6.2C	399
GTS5.2C	CRUNCH GTS 2-Way Compo 13 cm GTS-5.2C	369
GTS6.2W	CRUNCH GTS Woofer 16,5 cm GTS-6.2W	249
GTS62	CRUNCH GTS Coax 16,5 cm GTS-62	269
GTS52	CRUNCH GTS Coax 13 cm GTS-52	239
GTS42	CRUNCH GTS Coax 10 cm GTS-42	219
DSX6.2C	CRUNCH DEFINITION 2-Way Compo 16,5 cm DSX-6.2C	499
DSX6.2E	CRUNCH DEFINITION 2-Way Compo 16,5 cm DSX-6.2E	449
DSX5.2E	CRUNCH DEFINITION 2-Way Compo 13 cm DSX-5.2E	429
DSX4.2E	CRUNCH DEFINITION 2-Way Compo 10 cm DSX-4.2E	399
DSX42	CRUNCH DEFINITION Coax 10 cm DSX-42	189
DSX52	CRUNCH DEFINITION Coax 13 cm DSX-52	229
DSX62	CRUNCH DEFINITION Coax 16,5 cm DSX-62	259
DSX32	CRUNCH DEFINITION Coax 8,7 cm DSX-32	149

DSX120	CRUNCH DEFINITION Coax 12 cm DSX-120	189
DSX462	CRUNCH DEFINITION Coax 4x6" DSX-462	189
DSX572	CRUNCH DEFINITION Coax 5x7" DSX-572	219
DSX6930	CRUNCH DEFINITION Triax 6x9" DSX-6930	329
DST	CRUNCH DEFINITION Tweeter 25 mm DST	179
GTI5.2C	CRUNCH GTI 2-Way Compo 13 cm GTI-5.2C	349
GTI5.2E	CRUNCH GTI 2-Way Compo 13 cm GTI-5.2E	299
GTI6.2C	CRUNCH GTI 2-Way Compo 16,5 cm GTI-6.2C	399
GTI6.2E	CRUNCH GTI 2-Way Compo 16,5 cm GTI-6.2E	349
GTI6.2T	CRUNCH GTI Tweeter 25 mm GTI-6.2T	139
GTI6.2W	CRUNCH GTI Woofer 16,5 cm GTI-6.2W	219
GTI42	CRUNCH GTI Coax 10 cm GTI-42	149
GTI52	CRUNCH GTI Coax 13 cm GTI-52	189
GTI62	CRUNCH GTI Coax 16,5 cm GTI-62	219
GTI693	CRUNCH GTI Triax 6x9" GTI-693	299
CRK10	CRUNCH Wire Kit 10 mm ² CRK10	119
CRK25	CRUNCH Wire Kit 25 mm ² CRK25	169
CRK35	CRUNCH Wire Kit 35 mm ² CRK35	239
CRC5	CRUNCH RCA Wire 5 m CRC5	40
CRC3	CRUNCH RCA Wire 3 m CRC3	33
CRC1	CRUNCH RCA Wire 1 m CRC1	24
CRC0.5	CRUNCH RCA Wire 0,5 m CRC0.5	20
CRY	CRUNCH RCA Y-Wire CRY	20