# Start Here

Epson Perfection® V100 Photo

1 Unpack

Film holder

2 Install software

Do not connect the USB cable yet.

1

Macintosh OS X:
Double-click the CD-ROM icon on the desktop.

2

Select your product:
Epson Perfection V100 Photo
Epson Perfection V350 Photo

EPSON   Exit

Select your scanner.

3

Epson Perfection V100 Photo
Software Installation

This CD-ROM has all the software and information you need for scanning.
Click the Install button to get started.

- EPSON Scan
- EPSON Creativity Suite
- ArcSoft PhotoImpression 5
- ABBYY FineReader 6.0 Sprint
- User's Guide
- Adobe Reader

If you need to reinstall individual items, click Custom.

EPSON   Custom   Install   Exit

4

Follow the on-screen instructions and select the default options.

Remove the CD when you're finished installing software.

3 Remove protective tape

**EPSON®**
EXCEED YOUR VISION

4 Connect and plug in

1

2

Plug the AC adapter into an electrical outlet to turn the scanner on.

5 Scan a photo

1

2

3

Press the ✦ **Start** button.

4

Click **Scan**.

5

EPSON Scan opens and scans your photo in **Full Auto Mode**. Wait for your scan to finish or click **Pause** to change settings.

6

View your photo in My Pictures (Windows) or Pictures (Mac OS X).

6 Scan negatives

1

2

3

Insert negatives with the shiny side facing down.

4

5


6

7

8

Follow steps 3 through 6 in section 5, "Scan a photo."

Help

User's Guide

Double-click the **Perfection V100P User's Guide** icon on your desktop.

Scanner Software Help

Click the **Help** or **?** button on your scanner software screen.

Epson Technical Support

Internet Support

Visit Epson's support website at support.epson.com and select your product for solutions to common problems for the Perfection V100 Photo. You can download drivers and documentation, get FAQs and troubleshooting advice, or e-mail Epson with your questions.

Speak to a Support Representative

U.S.: (562) 276-4382, 6 AM to 6 PM, Pacific Time, Monday through Friday

Canada: (905) 709-3839, 6 AM to 6 PM, Monday through Friday

Toll or long distance charges may apply.

Software Technical Support

ArcSoft PhotoImpression®: Phone (510) 440-9901, Fax (510) 440-1270, www.arcsoft.com, support@arcsoft.com.

ABBYY® FineReader®: (510) 226-6717, www.abbyyusa.com, support@abbyyusa.com

7 Scan slides

1

2

3

4

5

Follow steps 3 through 6 in section 5, "Scan a photo."

Do More

Restore color

1

2

Remove dust from originals

1

2

Fix photos that are too dark because of backlighting

1

2