

N 73 27567

R - 746

SIRU DEVELOPMENT — FINAL REPORT

VOLUME III
SOFTWARE DESCRIPTION AND
PROGRAM DOCUMENTATION

by
John Oehrle
March 1973

CASE FILE
COPY

CHARLES STARK DRAPER
LABORATORY

MASSACHUSETTS INSTITUTE OF TECHNOLOGY

CAMBRIDGE, MASSACHUSETTS 02139

R- 746

SIRU DEVELOPMENT — FINAL REPORT

VOLUME III

SOFTWARE DESCRIPTION AND
PROGRAM DOCUMENTATION


by

John Oehrle


March 1973

Charles Stark Draper Laboratory
Massachusetts Institute of Technology
Cambridge, Massachusetts
02139


APPROVED:


J. P. GILMORE, DEPUTY ASSOCIATE DIRECTOR

APPROVED:


N. E. SEARS, ASSOCIATE DIRECTOR

APPROVED:


D. G. HOAG, DEPUTY DIRECTOR

ACKNOWLEDGEMENT

This report was prepared under our Project No. 55-32600, sponsored by the Lyndon B. Johnson Space Center of the National Aeronautics and Space Administration through Contract No. NAS 9-8242.

The SIRU System's success in its present state of hardware, software and analytical maturity represents the dedicated efforts of many people from the NASA L. B. Johnson Space Center and The Draper Laboratory to synthesize, design, fabricate and test a redundant, body mounted inertial system employing state-of-the-art redundancy management techniques.

Singular acknowledgement for contributions to the Software developed and documented in the volume is made to :

Richard McKern for his guidance and directions,

James Keenan for the development of the calibrations and data handling programs and for the implementation of the DOS operating system,

Stephan Helfant for his aid in compiling and preparing this document for printing.

The publication of this report does not constitute approval by the National Aeronautics and Space Administration of the findings or the conclusions contained therein. It is published only for the exchange and stimulation of ideas.

SIRU DEVELOPMENT FINAL REPORT

ABSTRACT

This report presents a complete description of the development and initial evaluation of the Strapdown Inertial Reference Unit (SIRU) system sponsored by the NASA Johnson Space Center under Contract NAS9-8242.

The SIRU configuration is a modular inertial subsystem with hardware and software features that achieve fault tolerant operational capabilities. The SIRU redundant hardware design is formulated about a six gyro and six accelerometer instrument module package. The modules are mounted in this package so that their measurement input axes form a unique symmetrical pattern that corresponds to the array of perpendiculars to the faces of a regular dodecahedron. This six axes array provides redundant independent sensing and the symmetry enables the formulation of an optimal software redundant data processing structure with self-contained fault detection and isolation (FDI) capabilities.

This report consists of four volumes.

Volume I, System Development, documents the system mechanization with the analytic formulation of the FDI and processing structure; the hardware redundancy design and the individual modularity features; the computational structure and facilities; and the initial subsystem evaluation results.

Volume II, Gyro Module, is devoted specifically to the Gyro Module, the inertial instrument and its digital strapdown torque-to-balance loop, the mechanical, thermal, and electronic design and function, test procedures and test equipment and performance results and analysis.

Volume III, Software, documents the basic SIRU software coding system used in the DDP-516 computer. The documentation covers the instrument compensation software, reorganizational and FDI processing, and the inertial attitude and velocity algorithm routines as well as servicing, input/output, etc. software.

Volume IV, Accelerometer Module, is devoted specifically to the Accelerometer Module, the inertial instrument and its digital strapdown torque-to-balance loop, the mechanical, thermal and electronic design and function and performance results and analysis, as it differs from the Gyro Module.

In addition to this report, SIRU Utilization Report R-747, has been issued documenting analyses, software and evaluation activities in the application of advanced statistical FDI algorithms, calibration and alignment techniques to the SIRU system.

April 1973

SIRU SOFTWARE DESCRIPTION
and
PROGRAM DOCUMENTATION

TABLE OF CONTENTS

INTRODUCTION	1
SYSTEM ORGANIZATION	4
MAIN PROGRAM	7
Subroutines	20

INTRODUCTION:

The purpose of creating the SIRU operating system was to implement and verify operation of the algorithms shown in Figure 1 on an available laboratory computer (Honeywell DDP-516) at an update rate of 100 times/sec. These algorithms can be divided into two sets, an accelerometer data processor and a gyro data processor. In the strapdown implementation it is important to process the accelerometer information into the inertial frame using the average attitude information over the ΔV accumulation period.

The system begins to accumulate ΔV pulses from the torque to balance instrument loops after initialization. After 5 ms the system begins to accumulate $\Delta \theta$ pulses. Five ms later or 10 ms from initialization the accelerometer pulse counters give an interrupt and the accelerometer data processors perform the proper algorithms on the 10 ms of ΔV accumulation. Five ms later the 10 ms of $\Delta \theta$ accumulation is processed to update attitude. The accelerometer and gyro algorithm processing loops are performed alternately every 5 ms thereafter resulting in the required staggering of these tasks. (This software has also been run at an update rate of 50 times/second. Ref. SIRU Utilization Report R-747).

Figure 1 shows what is done during either the accelerometer or gyro 5 ms updates. On the accelerometer side we require the system to do the following tasks.

TASKS

- A1) Read the 6 accelerometer counters.
- A2) Compensate accelerometers for average scale factor, bias and the misalignments of each accelerometer's input axis around their input and pendulous reference axes.
- A3) Compensate accelerometers for errors due to $R\omega^2$ and $R\dot{\omega}$ as a function of the accelerometers' positions relative to one another.
- A4) Accumulate corrected accelerometer body output for failure detection and isolation.
- A5) Perform failure detection and isolation resulting in a current failure status.




FIGURE 1 SIRU DATA PROCESSING

- A6) Check parity equation for third fail.
- A7) Create least squares matrix (as a function of fail status) to transform the 6 compensated ΔV 's into the X, Y, Z body frame.
- A8) Do the 6 to 3 matrix multiplication.
- A9) Unitize attitude quaternion prior to velocity algorithm processing.
- A10) Do the velocity algorithm, i.e., use the current attitude quaternion to generate the velocity transformation matrix and transform the incremental body velocity into the inertial frame.
- A11) Accumulate $\Delta \bar{V}$ inertial for output processing.

On the gyro side we presently require the system to do the following tasks:

- G1) Read the table angle encoder, the six gyros & interpolators.
- G2) Compensate the gyros for $\pm \Delta SF$, NBD, ADIA, ADOA, ADSRA, anisoelasticity, misalignments, anisoinertia, SRA cross-coupling and OA coupling.
- G3) Accumulate the corrected gyro body output for failure detection and isolation.
- G4) Perform the failure detection and isolation processing resulting in a current failure status.
- G5) Check the parity equation for third fail.
- G6) Create the least squares matrix (as a function of failure status) to transform the six compensated $\Delta \theta$'s into the X, Y, Z body frame.
- G7) Do the 6 to 3 matrix multiplication.
- G8) Compensate for earth rate.
- G9) Update the quaternion attitude.

In the time remaining, output of the system's status is performed either on the teletype, the CRT display or on an incremental digistor tape for further analysis. The format is shown in the documentation of the output programs. The information outputted includes the quaternion of attitude, $\Delta \bar{V}_I$ accumulated over some interval, a squared error monitor and fail status for gyros and accelerometers, test-table angle encoder and time since initialization.

SYSTEM ORGANIZATION:

The main program (MPRO) in turn calls all the subroutines to accomplish the tasks described in the introduction. These programs are documented in the following sections in the order listed below:

<u>Program</u>	<u>Task</u>	<u>Page</u>
MPRO	main program	7
ALPO		20
SFPOUT		31
SXOU		36
SDGS		39
(FTLIBY)	Fortran library	
READ	A1,G1	43
ACOM	A2	47
GCOM		52
DCMT	G2	61
DCOA		65
ROMS	A3	69
PREX	A4	78
GARC	G3	81
GFIS		87
ERDE	G4	93
CFSE	A5	99
PFIS		112
GPRT	G5	115
PRTY		118
PPEX	A6	123
GMIN	G6	125
GPMA	A7	128
EMIN		138
MG63	G7	140
MV63	A8	146
SPUN	A9	149
VESP	A10	158
VACU	A11	169
ERC6	G8	171
AA6S	G9	174

Preceeding the documentation of these programs is a load map showing the core location of each subroutine.

SYSTEM LOAD MAP

LDRX 23665 1000 64

GO
MN
I BMPRI
MR
C BREAD
MR
C BGFI
MR
C BGCOM
MR
C BERG6
MR
C BEMIN
MR
C BGMIN
MR
C BDCDA
MR
C BACOM
MR
C BDCMT
MR
C BMV63
MR
C BMG63
MR
C BVESP
MR
C BPFIS
MR
C BAA6S
MR
C BVACU
MR
C BSPUN
MR
C BPREX
MR
C BERDE
MR
C BCFSE
MR
C BGARC
MR
C BALPO
MR
C BFPOUT
MR
C BXOU
MR
C FTLIBY

MR
C BGPMA
MR
C BPPEX
MR
C BGPRT
MR
C BPRTY
MR
C BDGS
MR
C BRIMS
LC
M
*START 01000
*HIGH 14370
*NAMES 17132
*COMM 23777
*BASE 00244
LIST 00001
RUPT 01450
ASCT 01506
ICINIT 01656
INPIP 01731
INGYRO 01764
GFIS 02070
KEYG 02225
GCUM 02242
ERCO 02726
EMIN 03034
GMIN 03100
DCOA 03144
AOAP 03252
BOAP 03254
COAP 03256
DOAP 03260
EOAP 03262
FOAP 03264
ACOM 03274
DCMI 03476
DCMT 03551
MP63 03664
MG63 04012
VELA 04206
FXX 04654
FXY 04656
FXZ 04660
FYX 04662
FYI 04664
FYZ 04666
FZX 04670
FZY 04672
FZZ 04674

PFIS	04726
KEYP	05050
ATTA	05060
VACU	05506
SPUN	05560
PARC	06040
PACC	06166
ERDE	06172
SECA	06524
GARC	07344
GACC	07524
OUTPUT	07530
DODSP	07600
FPOUTC	10340
OUT100	10552
IOMODE	10604
X1OU	10636
XNQU	10642
XNOUA	10646
XOOCT	10652
CNOU	10670
CNOUA	10675
COOCT	10750
C1OU	11004
DOPAGE	11176
CRTOUT	11476
CRTOUA	11504
SORTX	11614
F\$AT	11614
ARG\$	11676
T1OU	11747
TNOUA	11772
TNOU	11777
TOOCT	12047
MATR	12102
GMAT	12136
PPRT	12630
GPRT	12712
PRTY	12774
DGSWRT	13250
DGSRD	13311
ROMS	14000
WXPR	14333
WYPR	14334
WZPR	14335
	23777
LC	
OK	
SAVE RMPRO 64 14370 1000	
OK	

PROGRAM NAME

SOURCE: MPRO

BINARY: BMPRO

STARTING LOCATION: '1000

GENERAL DESCRIPTION:

This is the main executive of the system operating program which calls the appropriate subroutines to accomplish the algorithms defined in the introduction and the definition of system tasks. It is divided into three sections of code. First is initialization and the enabling of interrupt. Next is a waiting loop (location LOOP) which checks to see if it is time for output and if so, calls the proper output routines. When this waiting loop is interrupted (every 5 milliseconds), the program sequence goes to the last section (location RUPT) which in turn decides whether its time to update the PIPA or gyro algorithms, goes to either PDO or GDO, saves the processing registers as they were at time of interrupt, calls the appropriate algorithms following PDO or GDO, restores the processing registers and returns to whatever was being processed at time of interrupt.

The initialization section first calls DCMI (see documentation for program source name DCMT) to enable the gyro OA misalignment parameters to be taken from the base sector and saved elsewhere in core. It then zeroes out all locations in the base sector that don't contain compensation parameters (namely locations '260-'421, '430-'477, '574-'677 and '744-'777). It zeroes out the gyro and PIPA error accumulator residuals accessible through the indexed external addresses CCAG and CCAP (see programs with source names GARC and PREX). It zeroes out the 6 previous OA coupling offsets (AOAP-FOAP accessible in the program DCOA through the external address PAOA-PAOF). It zeroes the four erroneous interrupt counters (disk, ASR-33 teletype, miscellaneous and clock). It zeroes out the gyro and PIPA fail keys (KEYG and KEYP) in programs GFIS and PFIS). It zeroes WXPR, WYPR and WZPR (see program ROMS) and sets GACC and PACC to equal -6001 (used to wait 60 seconds in the error accumulator programs GARC and PREX). TCNT (the time counter for the output loop) is set to its maximum of '77777 so that an output will be done at t=0. It puts a round of '40000 in the low order residuals of the gyro pulse counts,

PIPA pulse counts, gyro x, y and z delta thetas, PIPA x, y and z delta Vs, the quaternion and the delta V inertial accumulators. The '40000 it stores in '460 is to set lamda of the quaternion equal to 1. It then generates the gyro and PIPA 6 x 3 matrices by calling GMIN and EMIN. It stores the address to go to when interrupted in '63 and calls ICINIT, which sets up the interrupt cycle (see documentation for program source name READ). Finally it does a JST (internal call) to GETM in order to set up the timing and MODE for whichever of three output modes is desired.

The output waiting loop simply checks the time counter (TCNT) to see if it is greater than or equal to the time at which to output (CRIT). * If TCNT is less than CRIT (i.e., it is not time to output) and if sense switches three and four are not reset and set respectively **, the waiting loop will just continue to loop. The waiting loop continues to get interrupted so that the PIPA and gyro processing can be updated every five milliseconds.

When enough updates have occurred and TCNT becomes greater than CRIT, the program jumps to OUT, where output is started. If sense switches three and four are set, the program will first initialize the quaternion to 1,0,0,0 (see documentation for AA6S). The program then continues at NOQZ where all the data to be output is saved in a 52 word buffer called QTMP as follows:

* Note that TCNT is incremented by 1 after every gyro algorithm loop so it counts in hundredths of a second. CRIT is set up by GETM and depends on the output mode.

** To stop this program and return to DOS (the disk operating system) sense switch four is set while sense switch three is left reset. By setting sense switch three and then setting sense switch four, the quaternion will be initialized at the time the next output starts.

<u>Location</u>	<u>Contents</u>
QTMP-QTMP+7	quaternion
QTMP+8-QTMP+13	Sum of delta V inertial since the last output
QTMP+14-QTMP+15	First and second gyro fail status
QTMP+16-QTMP+17	First and second PIPA fail status
QTMP+18-QTMP+19	Time elapsed since start of program
QTMP+20-QTMP+21	Encoder angle of test table
QTMP+22-QTMP+23	gyro and PIPA third fail indicators
QTMP+24-QTMP+37	gyro squared errors
QTMP+38-QTMP+51	PIPA squared errors

The delta V accumulators and the time counter are then zeroed after which the proper output mode is gotten. Parts of QTMP are then rescaled so that the output routine can handle them. Finally, a call to OUTPUT is made with the addresses of QTMP and MODE. Upon return from output a jump back to LOOP is made.

The last section of this main program, starting at RUPT, handles the PIPA and gyro interrupts as they come along every five milliseconds. The first interrupt, by the PIPA's, and every other one thereafter, will cause program control to "jump store" to RUPT where the SKS '507 instruction will not skip and the jump to PDO is executed. Here the processing registers (A register, keys, B register and index register) are saved and calls to the subroutines necessary to update the PIPA algorithms are made (see the introduction and description of implementation methods). The PIPA squared errors are then saved in the buffer PISE for future output, then the processing registers are restored and a JMP* RUPT causes program control to go back to where it was when last interrupted.

The second interrupt, by the gyros, and every other one thereafter, will cause control to "jump store" to RUPT where the SKS '507 instruction

* See previous page

will skip and the SKS '407 instruction will not, and the jump to GDO is executed. Here the processing registers are saved. The table angle encoder is read after which calls to the subroutines necessary to update the gyro algorithms are made (see the introduction and description of implementation methods). The output timer, TCNT, and the overall timer, TIME are incremented before a jump to COMN restores the processing registers and returns to where the program control was when the gyro interrupt occurred.

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

		REL
0001		CALL DCMI
0002 00000	0 10 00000	DBL
0003 00001	000007	DLD DZRO
0004 00002	0 02 00342	LDX ==98
0005 00003	0 35 00654	DST '422,1
0006 00004	1 04 00422	IRS 0
0007 00005	0 12 00000	IRS 0
0008 00006	0 12 00000	JMP *-3
0009 00007	0 01 00004	LDX =-40
0010 00010	0 35 00653	DST '500,1
0011 00011	1 04 00500	TRS 0
0012 00012	0 12 00000	IRS 0
0013 00013	0 12 00000	JMP *-3
0014 00014	0 01 00011	LDX ==68
0015 00015	0 35 00652	DST '700,1
0016 00016	1 04 00700	IRS 0
0017 00017	0 12 00000	IRS 0
0018 00020	0 12 00000	JMP *-3
0019 00021	0 01 00016	LDX ==28
0020 00022	0 35 00651	DST '1000,1
0021 00023	1 04 01000	DST* CCAG
0022 00024	-0 04 00337	DST* CCAP
0023 00025	-0 04 00340	IRS 0
0024 00026	0 12 00000	IRS 0
0025 00027	0 12 00000	JMP *-5
0026 00030	0 01 00023	DST* PAOA
0027 00031	-0 04 00324	DST* PAOB
0028 00032	-0 04 00325	DST* PAOC
0029 00033	-0 04 00326	DST* PAOD
0030 00034	-0 04 00327	DST* PAOE
0031 00035	-0 04 00330	DST* PAOF
0032 00036	-0 04 00331	SGL
0033 00037	000005	STA DSCT
0034 00040	0 04 00507	STA ASCT
0035 00041	0 04 00506	STA MSCT
0036 00042	0 04 00510	STA ICNT
0037 00043	0 04 00511	STA* GYEK
0038 00044	-0 04 00332	STA* PYEK
0039 00045	-0 04 00333	STA* RPXW
0040 00046	-0 04 00334	STA* RPYW
0041 00047	-0 04 00335	STA* RPZW
0042 00050	-0 04 00336	LDA ==6001
0043 00051	0 02 00650	STA* CCAG
0044 00052	-0 04 00337	STA* CCAP
0045 00053	-0 04 00340	LDA ='77777
0046 00054	0 02 00647	STA TCNT
0047 00055	0 04 00637	LDA ='40000
0048 00056	0 02 00646	STA '401
0049 00057	0 04 00401	STA '403
0050 00060	0 04 00403	STA '405
0051 00061	0 04 00405	STA '407
0052 00062	0 04 00407	STA '411
0053 00063	0 04 00411	STA '413
0054 00064	0 04 00413	STA '601
0055 00065	0 04 00601	STA '603
0056 00066	0 04 00603	STA '605
0057 00067	0 04 00605	

MTCPOCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058	00070	0 04 00607	STA	'607
0059	00071	0 04 00611	STA	'611
0060	00072	0 04 00613	STA	'613
0061	00073	0 04 00415	STA	'415
0062	00074	0 04 00417	STA	'417
0063	00075	0 04 00421	STA	'421
0064	00076	0 04 00615	STA	'615
0065	00077	0 04 00617	STA	'617
0066	00100	0 04 00621	STA	'621
0067	00101	0 04 00460	STA	'460
0068	00102	0 04 00463	STA	'463
0069	00103	0 04 00467	STA	'467
0070	00104	0 04 00473	STA	'473
0071	00105	0 04 00477	STA	'477
0072	00106	0 04 00447	STA	'447
0073	00107	0 04 00453	STA	'453
0074	00110	0 04 00457	STA	'457
0075	00111	0 10 00000	CALL	GMIN
0075	00112	0 10 00000	CALL	EMIN
0077	00113	0 02 00323	LDA	RDAD
0078	00114	0 04 00063	STA	'63
0079	00115	0 10 00000	CALL	ICINIT
0080	00116	0 02 00645	LDA	=6
0081	00117	74 0020	SMK	'20
0082	00120	0 10 00310	JST	GETM
0083	*			TO SET UP TIME
0084	*			
0085	00121	000401	LOOP	ENB
0086	00122	0 02 00637	LDA	TCNT
0087	00123	0 11 00635	CAS	CRIT
0088	00124	101000	NOP	
0089	00125	0 01 00141	JMP	OUT
0090	00126	000201	IAB	
0091	00127	111002	SS4	
0092	00130	0 01 00121	JMP	LOOP
0093	00131	100004	SR3	
0094	00132	0 01 00121	JMP	LOOP
0095	*			
0096			*	EXIT CODING
0097	*			
0098	00133	14 0047	OCP	'47
0099	00134	14 0057	OCP	'57
0100	00135	140040	CRA	
0101	00136	74 0020	SMK	'20
0102	00137	001001	INH	
0103	00140	-0 01 00631	JMP*	DOS
0104	*			
0105	*			
0106	00141	100004	OUT	SR3
0107	00142	101002	SS4	
0108	00143	0 01 00165	JMP	NO02
0109	00144	000007	DBL	
0110	00145	0 02 00342	DLD	DZRO
0111	00146	0 04 00460	DST	'460
0112	00147	0 04 00462	DST	'462
0113	00148	0 04 00464	DST	'464
0114	00151	0 04 00466	DST	'466

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0115	00152	0 04 00470	DST	'470
0116	00153	0 04 00472	DST	'472
0117	00154	0 04 00474	DST	'474
0118	00155	0 04 00476	DST	'476
0119	00156	000005	SGL	
0120	00157	0 02 00646	LDA	='40000
0121	00160	0 04 00460	STA	'460
0122	00161	0 04 00463	STA	'463
0123	00162	0 04 00467	STA	'467
0124	00163	0 04 00473	STA	'473
0125	00164	0 04 00477	STA	'477
0126	00165	000007	NOQ?	DBL
0127	00166	0 02 00460	DLD	'460
0128	00167	0 04 00346	DST	QTMP
0129	00170	0 02 00464	DLD	'464
0130	00171	0 04 00350	DST	QTMP+2
0131	00172	0 02 00470	DLD	'470
0132	00173	0 04 00352	DST	QTMP+4
0133	00174	0 02 00474	DLD	'474
0134	00175	0 04 00354	DST	QTMP+6
0135	00176	0 02 00444	DLD	'444
0136	00177	0 04 00356	DST	QTMP+8
0137	00200	0 02 00450	DLD	'450
0138	00201	0 04 00360	DST	QTMP+10
0139	00202	0 02 00454	DLD	'454
0140	00203	0 04 00362	DST	QTMP+12
0141	00204	0 02 00316	DLD	'316
0142	00205	0 04 00364	DST	QTMP+14
0143	00206	0 02 00320	DLD	'320
0144	00207	0 04 00366	DST	QTMP+16
0145	00210	0 02 00776	DLD	TIME
0146	00211	0 04 00370	DST	QTMP+18
0147	00212	0 02 00322	DLD	'322
0148	00213	0 04 00374	DST	QTMP+22
0149	00214	0 02 00324	DLD	'324
0150	00215	0 04 00372	DST	QTMP+20
0151	00216	0 02 00326	DLD	'326
0152	00217	0 04 00376	DST	QTMP+24
0153	00220	0 02 00330	DLD	'330
0154	00221	0 04 00400	DST	QTMP+26
0155	00222	0 02 00332	DLD	'332
0156	00223	0 04 00402	DST	QTMP+28
0157	00224	0 02 00436	DLD	'436
0158	00225	0 04 00404	DST	QTMP+30
0159	00226	0 02 00440	DLD	'440
0160	00227	0 04 00406	DST	QTMP+32
0161	00230	0 02 00442	DLD	'442
0162	00231	0 04 00410	DST	QTMP+34
0163	00232	0 02 00574	DLD	'574
0164	00233	0 04 00412	DST	QTMP+36
0165	00234	0 02 00432	DLD	PISE
0166	00235	0 04 00414	DST	QTMP+38
0167	00236	0 02 00434	DLD	PISE+2
0168	00237	0 04 00416	DST	QTMP+40
0169	00240	0 02 00436	DLD	PISE+4
0170	00241	0 04 00420	DST	QTMP+42
0171	00242	0 02 00440	DLD	PISE+6

MTCPOCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0172	00243	0 04 00422	DST	QTMP+44
0173	00244	0 02 00442	DLD	PISE+8
0174	00245	0 04 00424	DST	QTMP+46
0175	00246	0 02 00444	DID	PISE+10
0176	00247	0 04 00426	DST	QTMP+48
0177	00250	0 02 00446	DLD	PISE+12
0178	00251	0 04 00430	DST	QTMP+50
0179	00252	0 02 00342	DID	DZFO
0180	00253	0 04 00444	DST	'444
0181	00254	0 04 00450	DST	'450
0182	00255	0 04 00454	DST	'454
0183	00256	000005	SGL	
0184	00257	0 04 00637	STA	TCNT
0185	00260	0 10 00310	JST	GETM
0186	00261	000007	DBL	
0187	00262	0 02 00356	DLD	QTMP+8
0188	00263	0411 71	LLS	7
0189	00264	0 04 00356	DST	QTMP+8
0190	00265	0 02 00360	DLD	QTMP+10
0191	00266	0411 71	LLS	7
0192	00267	0 04 00360	DST	QTMP+10
0193	00270	0 02 00362	DLD	QTMP+12
0194	00271	0411 71	LLS	7
0195	00272	0 04 00362	DST	QTMP+12
0196	00273	0 35 00651	LDX	=-28
0197	00274	1 02 00432	DLD	QTMP+52,1
0198	00275	0411 67	LLS	9
0199	00276	1 04 00432	DST	QTMP+52,1
0200	00277	0 12 00000	IRS	0
0201	00300	0 12 00000	TRS	0
0202	00301	0 01 00274	JMP	*-5
0203	00302	000005	SGL	
0204	00303	0 10 00000	CALL	OUTPUT
0205	00304	0 000346	DAC	QTMP
0206	00305	0 000636	DAC	MODE
0207	00306	000000	OCT	0
0208	00307	0 01 00121	JMP	LOOP
0209		*		
0210	00310	0 000000	GETM	DAC **
0211	00311	140040	CRA	
0212	00312	100020	SR1	
0213	00313	141206	AOA	
0214	00314	100010	SP2	
0215	00315	0 02 00644	LDA	=2
0216	00316	0 04 00636	STA	MODE
0217		*		
0218	00317	0 04 00000	STA	0
0219	00320	1 02 00632	LDA	TCON,1
0220	00321	0 04 00635	STA	CRIT
0221	00322	-0 01 00310	JMP*	GETM
0222		*		
0223	00323	0 000000	RDAD XAC	RUPT
0224	00324	0 000000	PAOA XAC	AOAP
0225	00325	0 000000	PAOB XAC	BOAP
0226	00326	0 000000	PAOC XAC	COAP
0227	00327	0 000000	PAOD XAC	DOAP
0228	00330	0 000000	PAOE XAC	EOAP

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0229	00331	0 000000	PAOF XAC	POAP
0230	00332	0 000000	GYEK XAC	KEYG
0231	00333	0 000000	PYEK XAC	KEYP
0232	00334	0 000000	RPXW XAC	WXPR
0233	00335	0 000000	RPYW XAC	WYPR
0234	00336	0 000000	RPZW XAC	WZPR
0235	00337	1 000000	CCAG XAC	GACC,1
0236	00340	1 000000	CCAP XAC	PACC,1
0237	00342	000000	DZRO DBP	0
	00343	000000		
0238	00344	000000	DONE OCT	0,1
	00345	000001		
0239	00346	000000	QTMP BSZ	52
	00347	000000		
	00350	000000		
	00351	000000		
	00352	000000		
	00353	000000		
	00354	000000		
	00355	000000		
	00356	000000		
	00357	000000		
	00360	000000		
	00361	000000		
	00362	000000		
	00363	000000		
	00364	000000		
	00365	000000		
	00366	000000		
	00367	000000		
	00370	000000		
	00371	000000		
	00372	000000		
	00373	000000		
	00374	000000		
	00375	000000		
	00376	000000		
	00377	000000		
	00400	000000		
	00401	000000		
	00402	000000		
	00403	000000		
	00404	000000		
	00405	000000		
	00406	000000		
	00407	000000		
	00410	000000		
	00411	000000		
	00412	000000		
	00413	000000		
	00414	000000		
	00415	000000		
	00416	000000		
	00417	000000		
	00420	000000		
	00421	000000		
	00422	000000		

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

00423	000000			
00424	000000			
00425	000000			
00426	000000			
00427	000000			
00430	000000			
00431	000000			
0247	00432	000000	PTSE BSZ	14
	00433	000000		
	00434	000000		
	00435	000000		
	00436	000000		
	00437	000000		
	00440	000000		
	00441	000000		
	00442	000000		
	00443	000000		
	00444	000000		
	00445	000000		
	00446	000000		
	00447	000000		
0241		*		
0242		*		
0243		SUBR	RUPT	
0244		SUBR	ASCT	
0245		REL		
0246	00450	0 000000	RUPT	DAC **
0247	00451	14 0102	OCP	'102
0248	00452	34 0507	SKS	'507
0249	00453	0 01 00512	JMP	PDO
0250	00454	34 0407	SKS	'407
0251	00455	0 01 00565	JMP	GDO
0252	00456	34 0607	SKS	'607
0253	00457	0 01 00501	JMP	ICLK
0254	00460	34 0425	SKS	'425
0255	00461	0 01 00475	JMP	DISK
0256	00462	34 0404	SKS	'404
0257	00463	0 01 00467	JMP	ASR
0258	00464	0 12 00510	IRS	MSCT
0259	00465	000401	PSM	ENB
0260	00466	-0 01 00450	JMP*	RUPT
0261		*		
0262	00467	14 0004	ASR	OCP 4
0263	00470	54 0004		INA 4
0264	00471	101000		NOP
0265	00472	0 12 00506	IRS	ASCT
0266	00473	101000		NOP
0267	00474	0 01 00465	JMP	RSM
0268		*		
0269	00475	14 1425	DISK	OCP '1425
0270	00476	0 12 00507	IRS	DSCT
0271	00477	101000		NOP
0272	00500	0 01 00465	JMP	RSM
0273		*		
0274	00501	0 12 00511	ICLK	IRS ICNT
0275	00502	101000		NOP
0276	00503	14 0027	OCP	'27

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0277	00504	14	0067	OCP	'67
0278	00505	0	01 00465	JMP	RSM
0279	00506	000000	ASCT	BSZ	1
0280	00507	000000	DSCT	BSZ	1
0281	00510	000000	MSCT	BSZ	1
0282	00511	000000	ICNT	BSZ	1
0283		*			
0284		*			
0285	00512	0	13 00640	PDO	IMA
0286	00513	000043			TNK
0287	00514	000005			SGL
0288	00515	0	04 00641	STA	KEYS
0289	00516	000201			IAB
0290	00517	0	04 00642	STA	BREG
0291	00520	0	15 00643	STX	XREG
0292		*			
0293		*			
0294		*			
0295		*			
0296	00521	0	10 00000	CALL	INPIP
0297	00522	000401			ENB
0298	00523	0	10 00000	CALL	ACOM
0299	00524	0	10 00000	CALL	ROMS
0300	00525	0	10 00000	CALL	PARC
0301	00526	0	10 00000	CALL	PFIS
0302	00527	0	10 00000	CALL	PPRT
0303	00530	0	10 00000	CALL	EMIN
0304	00531	0	10 00000	CALL	MP63
0305	00532	0	10 00000	CALL	SPUN
0306	00533	0	10 00000	CALL	VELA
0307	00534	0	10 00000	CALL	VACU
0308	00535	000007			DBL
0309	00536	0	02 00326	DID	'326
0310	00537	0	04 00432	DST	PISE
0311	00540	0	02 00330	DID	'330
0312	00541	0	04 00434	DST	PISE+2
0313	00542	0	02 00332	DID	'332
0314	00543	0	04 00436	DST	PISE+4
0315	00544	0	02 00436	DID	'436
0316	00545	0	04 00440	DST	PISE+6
0317	00546	0	02 00440	DID	'440
0318	00547	0	04 00442	DST	PISE+8
0319	00550	0	02 00442	DID	'442
0320	00551	0	04 00444	DST	PISE+10
0321	00552	0	02 00574	DID	'574
0322	00553	0	04 00446	DST	PISE+12
0323	00554	000005			SGL
0324		*			
0325		*			
0326	00555	0	35 00643	COMM	LDX
0327	00556	0	02 00642	LDA	BREG
0328	00557	000201			IAB
0329	00560	0	02 00641	LDA	KEYS
0330	00561	171020			OTK
0331	00562	0	13 00640	IMA	AREG
0332	00563	000401			ENB
0333	00564	-0	01 00450	JMP*	RUPT

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0334		*				
0335		*				
0336	00565	0 13 00640	GDO	IMA	AREG	
0337	00566	000043		TNK		
0338	00567	000005		SGL		
0339	00570	0 04 00641		STA	KEYS	
0340	00571	000201		IAB		
0341	00572	0 04 00642		STA	BREG	
0342	00573	0 15 00643		STX	XREG	
0343		*				
0344		*				
0345	00574	34 0007		SKS	'007	WAIT FOR DIGISEC
0346	00575	0 01 00574		JMP	*-1	
0347	00576	14 0406		OCP	'406	HOLD
0348	00577	0401 62		LRS	14	WAIT 8 MCT'S
0349	00600	54 1016		INA	'1016	HIGH HALF
0350	00601	101000		NOP		
0351	00602	0 04 00324		STA	'324	
0352	00603	54 1006		INA	'1006	LOW HALF
0353	00604	101000		NOP		
0354	00605	0 04 00325		STA	'325	
0355	00606	14 0006		OCP	'006	END HOLD
0356	00607	0 10 00000		CALL	INGYRO	
0357	00610	000401		ENB		
0358	00611	0 10 00000		CALL	DCMT	
0359	00612	0 10 00000		CALL	GCOM	
0360	00613	0 10 00000		CALL	GARC	
0361	00614	0 10 00000		CALL	GFIS	
0362	00615	0 10 00000		CALL	GPRT	
0363	00616	0 10 00000		CALL	GMIN	
0364	00617	0 10 00000		CALL	MG63	
0365	00620	0 10 00000		CALL	ERCO	
0366	00621	0 10 00000		CALL	ATTA	
0367	00622	0 12 00637		IRS	TCNT	
0368	00623	000007		DBL		
0369	00624	0 02 00776		DLD	TIME	
0370	00625	0 06 00344		DAD	DONE	
0371	00626	0 04 00776		DST	TIME	
0372	00627	000005		SGL		
0373		*				
0374		*				
0375	00630	0 01 00555		JMP	COMM	
0376		*				
0377		*				
0378		*				
0379	00631	030000	DOS	OCT	30000	
0380	00632	013560	TCON	DEC	6000	30 SEC FOR TTY
0381	00633	000620		DEC	400	4 SEC FOR CRT
0382	00634	000144		DEC	100	.4 SEC FOR DGS
0383		*				
0384	00635	000000	CRIT	BSZ	1	
0385	00636	000000	MODE	BSZ	1	
0386	00637	077777	TCNT	OCT	77777	
0387	00640	000000	AREG	BSZ	1	
0388	00641	000000	KEYS	BSZ	1	
0389	00642	000000	BREG	BSZ	1	
0390	00643	000000	XREG	BSZ	1	

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0391	000776	TIME EQU	'776
0392	00644	000002	END
	00645	000006	
	00646	040000	
	00647	077777	
	00650	164217	
	00651	177744	
	00652	177674	
	00653	177730	
	00654	177636	

PROGRAM NAME (Note: this is a FORTRAN program)

SOURCE: ALPO

BINARY: BALPO

ENTRY POINTS (location): OUTPUT ('07530), DODSP ('07600)

GENERAL DESCRIPTION:

When called, this subroutine will output the information about the system status either on the teletype or the CRT screen in the format shown in Figure 2 or as a block of 104 bytes (6 single precision numbers giving gyro and PIPA fail status and third fail indication and 23 double precision numbers; 4 for the quaternion, 3 for ΔV_I , 14 for gyro and PIPA squared errors, 1 for time and 1 for the encoder) on digistor tape. See the documentation for MPRO (the main program which calls OUTPUT) and for the output subroutines SDGS, SXOU and SFPOUT.

(NO FAILS INDICATED)						
QUAT	0.999999	0.000016	0.000069	-	0.000035	
DELVRF	- 979.664062	8.601562	-	8.453125		
ERRORS	{ 0.25 A-F Gyro { 0.01 0.01 Squared { 0.06 Error { 0.39 0.14 0.87	1.89 1.89 0.01 3.51 0.39 0.56 8.26	A-F PIPA Squared Error			
			Total Squared Error			
GYRO FAIL						
PIPA FAIL						
TIME	180.00 (sec)					
TABLE ANGLE	0.761531 (IN REVOLUTIONS)					

Fig. 2 CRT System Status Display

MYCROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING
SUBROUTINE OUTPUT (ARG, MODE)

000000 DAC 000000
000001 CALL FSAT
000002 OCT 000002
000003 DAC 000000
000004 DAC 000000
 INTEGER ARG(52), MODE, MODSAV
 DATA MODSAV /-1/
000005 JMP 000000
000006 OCT 177777
 IF(MODE, EQ, 2) GOTO 100
 STG 000005
000007 LDA* MODE
000010 SUB ='000002
000011 SZE 000000
000012 JMP 000000
000013 JMP _100
 STG 000012
 IF(MODE, EQ, MODSAV) GOTO 50
000014 LDA* MODE
000015 SUB MODSAV
000016 SZE 000000
000017 JMP 000000
000020 JMP _50
 STG 000017
 CALL IOMODE(MODE)
000021 CALL IOMODE
000022 DAC* MODE
 MODSAV=MODE
000023 LDA* MODE
000024 STA MODSAV
50 CALL DODSP(ARG)
 STG _50
000025 CALL DODSP
000026 DAC* ARG
 IF(MODSAV, EQ, 1) CALL C1OU(2H ~)
000027 LDA MODSAV
000030 SUB ='000001
000031 SZE 000000
000032 JMP 000000
000033 CALL C1OU
000034 DAC ='120336
 STG 000032
 RETURN
C
C DIGITSTOP OUTPUT
C
000035 JMP* 000000
100 CALL DGSWRT(ARG, 52)
 STG _100
000036 CALL DGSWRT
000037 DAC* ARG
000040 DAC ='000064
000041 OCT 000000
 RETURN
000042 JMP* 000000
END

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

```

C
C
C
000043    STG  ='000001
000043    OCT   000001
            STG  ='000002
000044    OCT   000002
000003    DAC   ARG
000004    DAC   MODE
            STG  ='000064
000045    OCT   000064
000006    DAC   MODSAV
000036    DAC   -100
000025    DAC   -50
000000    DAC   T$0MODE
000000    DAC   DODSP
000000    DAC   C1OU
            STG  ='120336
000046    OCT   120336
000000    DAC   DGSWRT
            SUBROUTINE DODSP(ARG)
000000    DAC   000000
000001    CALL  FSAT
000002    OCT   000001
000003    DAC   000000
            COMMON/LIST/ LIST(1)
            LOGICAL LIST
            INTEGER ARG(24)
            CALL  XNOUA(8HQUAT ,8)
000004    JMP   000000
            STG   000004
000005    JMP   000000
000006    OCT   150725
000007    OCT   140724
000010    OCT   120240
000011    OCT   120240
            STG   000005
000012    CALL  XNOUA
000013    DAC   000006
000014    DAC   ='0000010
000015    OCT   000000
            DO 10 I=1,7,2
000016    LDA   ='000001
000017    STA   I
            CALL  FPOUTC(ARG(I),1,6)
000020    LDA   I
000021    ADD   ARG
000022    ADD   000024
000023    JMP   000025
000024    OCT   177777
000025    STA   T$1000
000026    CALL  FPOUTC
000027    DAC*  T$1000
000030    DAC   ='000001
000031    DAC   ='000006
000032    OCT   000000
10      CALL  XNOUA(2H ,2)

```

MICROCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

```

000033  CALL  XNOUA
000034  DAC   =*120240
000035  DAC   =*000002
000036  OCT   000000
000037  LDA   I
000040  ADD   =*000002
000041  CAS   =*000007
000042  JMP   000045
000043  JMP   000017
000044  JMP   000017
      CALL X1OU(138)
000045  CALL  X1OU
000046  DAC   =*000212
      CALL XNOUA(8HDELVRP ,8)
000047  JMP   000000
000050  OCT   142305
000051  OCT   146326
000052  OCT   151306
000053  OCT   120240
      STG   000047
000054  CALL  XNOUA
000055  DAC   C00050
000056  DAC   =*000010
000057  OCT   000000
      DO 20 I=9,13,2
000060  LDA   =*000011
000061  STA   I
      CALL FPOUTC(ARG(I),15,6)
000062  LDA   I
000063  ADD   ARG
000064  ADD   C00066
000065  JMP   000067
000066  OCT   177777
000067  STA   T$1000
000070  CALL  FPOUTC
000071  DAC*  T$1000
000072  DAC   =*000017
000073  DAC   =*000006
000074  OCT   000000
20     CALL XNOUA(2H ,2)
000075  CALL  XNOUA
000076  DAC   =*120240
000077  DAC   =*000002
000100  OCT   000000
000101  LDA   I
000102  ADD   =*000002
000103  CAS   =*000015
000104  JMP   000107
000105  JMP   000061
000106  JMP   000061
      CALL X1OU(138)
000107  CALL  X1OU
000110  DAC   =*000212
      CALL XNOUA(8HERRORS ,8)
000111  JMP   000000
000112  OCT   142722
000113  OCT   151317
  
```

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

000114 OCT 151323
000115 OCT 120240
000116 STG 000111
000116 CALL XNOUA
000117 DAC 000112
000120 DAC =0000010
000121 OCT 000000
DO 25 I=1,13,2
000122 LDA =000001
000123 STA I
CALL FPOUTC(ARG(I+24),15,2)
000124 LDA I
000125 ADD ARG
000126 ADD 000130
000127 JMP 000131
000130 OCT 000027
000131 STA T\$1000
000132 CALL FPOUTC
000133 DAC* T\$1000
000134 DAC =0000017
000135 DAC =0000002
000136 OCT 000000
CALL XNOUA(2H ,2)
000137 CALL XNOUA
000140 DAC =120240
000141 DAC =000002
000142 OCT 000000
CALL FPOUTC(ARG(I+38),15,2)
000143 LDA I
000144 ADD ARG
000145 ADD 000147
000146 JMP 000150
000147 OCT 000045
000150 STA T\$1000
000151 CALL FPOUTC
000152 DAC* T\$1000
000153 DAC =0000017
000154 DAC =0000002
000155 OCT 000000
CALL X10U(138)
000156 CALL X10U
000157 DAC =000212
25 CALL XNOUA(8H ,8)
000160 JMP 000000
000161 OCT 120240
000162 OCT 120240
000163 OCT 120240
000164 OCT 120240
STG 000160
000165 CALL XNOUA
000166 DAC 000161
000167 DAC =0000010
000170 OCT 000000
000171 LDA I
000172 ADD =0000002
000173 CAS =0000015
000174 JMP 000177

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

000175 JMP 000123
000176 JMP 000123
CALL X10U(138)
000177 CALL X10U
000200 DAC =000212
CALL XNOUA(10HGYRO FAIL ,10)
000201 JMP 000000
000202 OCT 143731
000203 OCT 151317
000204 OCT 120306
000205 OCT 140711
000206 OCT 146240
STG 000201
000207 CALL XNOUA
000210 DAC 000202
000211 DAC =000012
000212 OCT 000000
IF(ARG(15).EQ.0) GO TO 35
000213 LDA ARG
000214 ADD 000216
000215 JMP 000217
000216 OCT 000016
000217 STA T\$1000
000220 LDA* T\$1000
000221 SZE 000000
000222 JMP 000000
000223 JMP 35
STG 000222
CALL XNOUA(4H ,4)
000224 JMP 000000
000225 OCT 120240
000226 OCT 120240
STG 000224
000227 CALL XNOUA
000230 DAC 000225
000231 DAC =000004
000232 OCT 000000
CALL X10U(ARG(15)+192)
000233 LDA ARG
000234 ADD 000236
000235 JMP 000237
000236 OCT 000016
000237 STA T\$1000
000240 LDA* T\$1000
000241 ADD =000300
000242 STA T\$1001
000243 CALL X10U
000244 DAC T\$1001
IF(ARG(16).EQ.0) GO TO 35
000245 LDA ARG
000246 ADD 000250
000247 JMP 000251
000250 OCT 000017
000251 STA T\$1000
000252 LDA* T\$1000
000253 SZE 000000
000254 JMP 000000

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

```

000255    JMP   35
           STG   000254
           CALL XNOUA(4H ,4)
000256    JMP   000000
000257    OCT   120240
000260    OCT   120240
           STG   000256
000261    CALL XNOUA
000262    DAC   000257
000263    DAC   =1000004
000264    OCT   000000
           CALL X10U(ARG(16)+192)
000265    LDA   ARG
000266    ADD   000270
000267    JMP   000271
000270    OCT   000017
000271    STA   T$1000
000272    LDA*  T$1000
000273    ADD   =1000300
000274    STA   T$1001
000275    CALL X10U
000276    DAC   T$1001
           TF(ARG(23),NE,0) CALL XNOUA(10H      THIRD ,10)
000277    LDA   ARG
000300    ADD   000302
000301    JMP   000303
000302    OCT   000026
000303    STA   T$1000
000304    LDA*  T$1000
000305    SNZ   000000
000306    JMP   000000
000307    JMP   000000
000310    OCT   120240
000311    OCT   120240
000312    OCT   152310
000313    OCT   144722
000314    OCT   142240
           STG   000307
000315    CALL XNOUA
000316    DAC   000310
000317    DAC   =1000012
000320    OCT   000000
           STG   000306
35      CALL X10U(138)
           STG   35
000321    CALL X10U
000322    DAC   =1000212
           CALL XNOUA(10HPIPA FAIL ,10)
000323    JMP   000000
000324    OCT   150311
000325    OCT   150301
000326    OCT   120306
000327    OCT   140711
000330    OCT   146240
           STG   000323
000331    CALL XNOUA
000332    DAC   000324

```

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

000333 DAC ='0000012
000334 OCT 000000
IF(ARG(17), EQ.0) GO TO 40
000335 LDA ARG
000336 ADD 000340
000337 JMP 000341
000340 OCT 000020
000341 STA T\$1000
000342 LDA* T\$1000
000343 SZE 000000
000344 JMP 000000
000345 JMP -40
STG 000344
CALL XNOUA(4H ,4)
000346 JMP 000000
000347 OCT 120240
000350 OCT 120240
STG 000346
000351 CALL XNOUA
000352 DAC 000347
000353 DAC ='000004
000354 OCT 000000
CALL X1OU(ARG(17)+192)
000355 LDA ARG
000356 ADD 000360
000357 JMP 000361
000360 OCT 000020
000361 STA T\$1000
000362 LDA* T\$1000
000363 ADD ='000300
000364 STA T\$1001
000365 CALL X1OU
000366 DAC T\$1001
IF(ARG(18), EQ.0) GO TO 40
000367 LDA ARG
000370 ADD 000372
000371 JMP 000373
000372 OCT 000021
000373 STA T\$1000
000374 LDA* T\$1000
000375 SZE 000000
000376 JMP 000000
000377 JMP -40
STG 000376
CALL XNOUA(4H ,4)
000400 JMP 000000
000401 OCT 120240
000402 OCT 120240
STG 000400
000403 CALL XNOUA
000404 DAC 000401
000405 DAC ='000004
000406 OCT 000000
CALL X1OU(ARG(18)+192)
000407 LDA ARG
000410 ADD 000412
000411 JMP 000413

*MICPOCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

```

000412 OCT 000021
000413 STA T$1000
000414 LDA* T$1000
000415 ADD =000300
000416 STA T$1001
000417 CALL X1OU
000420 DAC T$1001
      IF (ARG(24), NE, 0) CALL XNOUA(10H) THIRD ,10)
000421 LDA ARG
000422 ADD 000424
000423 JMP 000425
000424 OCT 000027
000425 STA T$1000
000426 LDA* T$1000
000427 SNZ 000000
000430 JMP 000000
000431 JMP 000000
000432 OCT 120240
000433 OCT 120240
000434 OCT 152310
000435 OCT 144722
000436 OCT 142240
      STG 000431
000437 CALL XNOUA
000440 DAC 000432
000441 DAC =000012
000442 OCT 000000
      STG 000430
40     CALL X1OU(138)
      STG _40
000443 CALI X1OU
000444 DAC =000212
      CALL XNOUA(8HTIME ,8)
000445 JMP 000000
000446 OCT 152311
000447 OCT 146705
000450 OCT 120240
000451 OCT 120240
      STG 000445
000452 CALL XNOUA
000453 DAC 000446
000454 DAC =000010
000455 OCT 000000
      CALI OUT100(ARG(19))
000456 LDA ARG
000457 ADD 000461
000458 JMP 000462
000461 OCT 000022
000462 STA T$1000
000463 CALL OUT100
000464 DAC* T$1000
      CALL X1OU(138)
000465 CALL X1OU
000466 DAC =000212
      CALL XNOUA(8HTABLE ,8)
000467 JMP 000000
000470 OCT 152301
  
```

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

000471 OCT 141314
000472 OCT 142640
000473 OCT 120240
STG 000467
000474 CALL XNOUA
000475 DAC 000470
000476 DAC =0000010
000477 OCT 000000
CALL FPOUTC(ARG(21),0,6)
000500 LDA ARG
000501 ADD 000503
000502 JMP 000504
000503 OCT 000024
000504 STA T\$1000
000505 CALL FPOUTC
000506 DAC* T\$1000
000507 DAC =0000000
000510 DAC =0000006
000511 OCT 000000
CALL X10U(138)
000512 CALL X10U
000513 DAC =000212
CALL X10U(138)
000514 CALL X10U
000515 DAC =000212
RETURN
000516 JMP* 000000
END
STG =000001
000517 OCT 000001
STG =000002
000520 OCT 000002
STG =000004
000521 OCT 000004
STG =000006
000522 OCT 000006
000003 DAC ARG
000000 DAC LIST
000000 DAC XNOUA
STG =0000010
000523 OCT 000010
000033 DAC 10
STG I
000524 OCT 004640
STG =000007
000525 OCT 000007
000000 DAC FPOUTC
STG T\$1000
000526 OCT 012244
STG =120240
000527 OCT 120240
000000 DAC X10U
STG =000212
000530 OCT 000212
000075 DAC 20
STG =0000011
000531 OCT 000011

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

	STG	='000015
000532	OCT	000015
	STG	='000017
000533	OCT	000017
000160	DAC	_25
	STG	='000012
000534	OCT	000012
	STG	='000000
000535	OCT	000000
000321	DAC	_35
	STG	='000300
000536	OCT	000300
	STG	T\$1001
000537	OCT	012244
000443	DAC	_40
000000	DAC	OUT100
		\$0

PROGRAM NAME:

SOURCE: SFPOUT

BINARY: BFPOUT

ENTRY POINT (location): FPOUTC ('10340), OUT100 ('10552)

GENERAL DESCRIPTION:

FPOUTC is called by the output subroutine ALPO and prints on the teletype or displays on the CRT (See documentation for subroutine SXOU) a decimal number representation of the binary number designated by the call. The call in FORTRAN is

CALL FPOUTC (ARG, S, P)

or in DAP

CALL	FPOUTC
DAC	ARG
DAC	S
DAC	P
OCT	0

where ARG is the number to be printed, S is the number of bits after the sign bit before the binary point, and P is how many decimal digits to print after the decimal point.

OUT100 is also called by ALPO and is used to print on the teletype or display on the CRT 1/100 of a double precision integer. It is only used to print out the variable TIME, which is really a count of updates and needs to be divided by 100 to scale it to seconds. The call in FORTRAN is CALL OUT100 (TIME), or in DAP

CALL	OUT100
DAC	TIME

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001		SUBR	FPOUTC	
0002		REL		
0003 00000	0 000000	FPOU	DAC	**
0004 00001	0 10 00000	CALL	F\$AT	
0005 00002	000003	DEC3	OCT	3
0006 00003	0 00 00000	ARG	PZE	
0007 00004	0 00 00000	SCAL	PZE	
0008 00005	0 00 00000	PREC	PZE	
0009 00006	140040	CRA		
0010 00007	0 04 00166	STA	SGFL	SIGN FLAG
0011 00010	0 04 00173	STA	INT	
0012 00011	0.02 00202	LDA	BLBL	
0013 00012	0 04 00170	STA	STR	
0014 00013	0 04 00171	STA	STR+1	
0015 00014	0 04 00172	STA	STR+2	OVERLAYS CNTR
0016 00015	0 02 00206	LDA	SIX	
0017 00016	0 04 00167	STA	PPTR	
0018	*			
0019 00017	0 35 00003	LDX	ARG	
0020 00020	1 02 00001	LDA	1,1	
0021 00021	000201	IAB		
0022 00022	1 02 00000	LDA	0,1	
0023 00023	000007	DBL		
0024 00024	0 04 00174	DST	FRAC	
0025 00025	101400	SMI		
0026 00026	0 01 00033	JMP	ARGP	
0027 00027	0 12 00166	IRS	SGFL	
0028 00030	0 07 00174	DSR	FRAC	
0029 00031	0 07 00174	DSB	FRAC	
0030 00032	0 04 00174	DST	FRAC	
0031	*			
0032 00033	000005	ARGP	SGL	
0033 00034	-0 02 00004	LDA*	SCAL	
0034 00035	101040	SNZ		
0035 00036	0 01 00051	JMP	SDON	
0036 00037	101400	SMI		
0037 00040	0 01 00144	JMP	TPLS	
0038 00041	0 03 00210	ANA	OC77	
0039 00042	0 05 00201	ERA	RSI	
0040 00043	0 04 00046	STA	INS2	
0041 00044	000007	DBL		
0042 00045	0 02 00174	DLD	FRAC	
0043 00046	0 00 00000	INS2	***	
0044 00047	0 04 00174	DST	FRAC	
0045 00050	000005	SGL		
0046	*			
0047 00051	0 02 00173	SDON	LDA	INT
0048 00052	0400 60	NEXT	LRL	16
0049 00053	0 17 00207	DIV	TEN	
0050 00054	0 04 00173	STA	INT	
0051 00055	000201	IAB		
0052 00056	0 06 00176	ADD	FRMT	
0053	*			
0054 00057	000201	IAB		
0055 00060	0 02 00167	LDA	PPTR	
0056 00061	0 07 00205	SUB	ONE	
0057 00062	0 04 00167	STA	PPTR	

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058	00063	0404 77	LGR	1
0059	00064	0 04 00000	STA	0
0060	00065	1 02 00170	LDA	STR,1
0061	00066	100001	SRC	
0062	00067	000201	IAB	
0063	00070	0414 70	LGL	8
0064	00071	0402 70	LRR	8
0065	00072	1 04 00170	STA	STR,1
0066		*		
0067	00073	0 02 00173	LDA	INT
0068	00074	100040	SZE	
0069	00075	0 01 00052	JMP	NEXT
0070	00076	0 02 00166	LDA	SGFL
0071	00077	101040	SNZ	
0072	00100	0 01 00104	JMP	SOUT
0073	00101	0 02 00170	LDA	STR
0074	00102	0 05 00204	ERA	NEGS
0075	00103	0 04 00170	STA	STR
0076	00104	0 10 00000	SOUT	CALL XNOUA
0077	00105	0 000170	DAC	STR
0078	00106	0 000206	DAC	SIX
0079	00107	000000	OCT	C
0080		*		
0081	00110	-0 02 00005	LDA*	PREC
0082	00111	140407	TCA	
0083	00112	101400	SMI	
0084	00113	-0 01 00000	JMP*	FPOU
0085	00114	0 04 00172	STA	CNTR
0086	00115	0 10 00000	CALL	X1OU
0087	00116	0 000203	DAC	DOTC
0088		*		
0089	00117	0 02 00175	FLP	LDA
0090	00120	0 16 00207	MPY	LOW
0091	00121	000007	DBL	TEN
0092	00122	0 04 00166	DST	TEMP
0093	00123	0 02 00174	DLD	HIGH
0094	00124	0 16 00207	MPY	TEN
0095	00125	0 06 00176	DAD	FRMT
0096	00126	0 13 00173	IMA	DGT
0097	00127	140040	CRA	
0098	00130	000201	IAB	
0099	00131	0 06 00166	DAD	TEMP
0100	00132	100001	SRC	
0101	00133	0 12 00173	IRS	DGT
0102	00134	140100	SSP	
0103	00135	0 04 00174	DST	FRAC
0104	00136	000005	SGL	
0105	00137	0 10 00000	CALL	X1OU
0106	00140	0 000173	DAC	DGT
0107	00141	0 12 00172	IRS	CNTR
0108	00142	0 01 00117	JMP	FIP
0109	00143	-0 01 00000	JMP*	FPOU
0110		*		
0111	00144	0 05 00200	TPLS	ERA
0112	00145	141206	AOA	LST
0113	00146	0 04 00153	STA	INS1
0114	00147	0 35 00002	LDX	DEC3

MICROCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

0115	00150	140040	CRA	
0116	00151	000201	IAB	
0117	00152	1 02 00172	TPLP LDA	INT-1,1
0118	00153	0 00 00000	INS1 ***	
0119	00154	140100	SSP	
0120	00155	1 13 00172	IMA	INT-1,1
0121	00156	000201	IAB	
0122	00157	0 02 00000	LDA	0
0123	00160	0 07 00205	SUB	ONE
0124	00161	0 04 00000	STA	0
0125	00162	100040	SZE	
0126	00163	0 01 00152	JMP	TPLP
0127	00164	0 01 00051	JMP	SDON
0128		*		
0129		*		
0130		*		
0131	00166	000000	TEMP DBP	0
	00167	000000		
0132	00170	000000	STR DBP	0
	00171	000000		
0133	00172	000000	CNTR BSZ	1
0134	00173	000000	INT BSZ	1
0135	00174	000000	FRAC DBP	0
	00175	000000		
0136		000173	DGT EQU	INT
0137		000174	HIGH EQU	FRAC
0138		000175	LOW EQU	FRAC+1
0139		000166	SGPL EQU	TEMP
0140		000167	PPTR EQU	TEMP+1
0141		*		
0142	00176	000260	FRMT OCT	260,0
	00177	000000		
0143	00200	0411 77	LSTI LLS	1
0144	00201	0401 00	PSI LRS	0
0145	00202	120240	BIBL OCT	120240
0146	00203	000256	DOTC OCT	256
0147	00204	006400	NEGS OCT	6400
0148		*		
0149	00205	000001	ONE DEC	1
0150	00206	000006	SIX DEC	6
0151	00207	000012	TEN OCT	12
0152	00210	000077	OC77 DEC	63
0153	00211	000000	ZERE OCT	0
0154		FIN		
0155		*		
0156		*		
0157			SUBR	OUT100
0158			REL	
0159	00212	0 000000	OUT1 DAC	**
0160	00213	0 10 00000	CALL ARG\$	
0161	00214	-0 000212	DAC* OUT1	
0162	00215	1 02 00001	LDA	1,1
0163	00216	000201	IAB	
0164	00217	1 02 00000	LDA	0,1
0165	00220	0 17 00240	DIV	D100
0166	00221	0 04 00236	STA	OTMP
0167	00222	140040	CRA	

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0168	00223	000201	TAB
0169	00224	0 17 00240	DIV D100
0170	00225	141206	AOA
0171	00226	0 04 00237	STA OTMP+1
0172	00227	0 10 00000	CALL FPOUTC
0173	00230	0 000236	DAC OTMP
0174	00231	0 000242	DAC =15
0175	00232	0 000241	DAC =2
0176	00233	000000	OCT 0
0177	00234	0 12 00212	IPS OUT1
0178	00235	-0 01 00212	JMP* OUT1
0179		*	
0180	00236	000000	OTMP BSZ 2
	00237	000000	
0181	00240	000144	D100 DEC 100
0182	00241	000002	END
	00242	000017	

PROGRAM NAME

SOURCE: SXOU

BINARY: BXOU

ENTRY POINTS (location): IOMODE ('10604), X1OU ('10636),
XNOU ('10642), XNOUA ('10646), XOOCT ('10652)

GENERAL DESCRIPTION:

This subroutine is really an intermediary to the output calls to either the FORTRAN teletype output routines (T1OU, TNOU, TNOUA and TOOCT), or the CRT output routines (C1OU, CNOU, CNOUA and COOCT). The subroutine ALPO (see documentation) first calls IOMODE with the argument 0 if it wants to output on the teletype or 1 if it wants to output on the CRT. From then on, every call to X1OU, XNOU or XOOCT will be rerouted to look like the proper call to either the teletype or CRT routines.

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001			SUBR	IOMODE	
0002			SUBR	X1OU	
0003			SUBR	XNOU,XNO	
0004			SUBR	XNOUA,XNOA	
0005			SUBR	XOOCT	
0006			REL		
0007		*			
0008	00000	0 000000	IOMO	DAC	**
0009	00001	0 35 00000	LDX	IOMO	
0010	00002	-1 02 00000	LDA*	0,1	
0011	00003	0 35 00063	LDX	=0	
0012	00004	100040	SZE		
0013	00005	0 35 00062	LDX	=4	
0014	00006	000007	DBL		
0015	00007	1 02 00022	DLD	ADL,1	
0016	00010	0 04 00016	DST	LST	
0017	00011	1 02 00024	DLD	ADL+2,1	
0018	00012	0 04 00020	DST	LST+2	
0019	00013	000005	SGL		
0020	00014	0 12 00000	IRS	IOMO	
0021	00015	-0 01 00000	JMP*	IOMO	
0022		*			
0023	00016	000000	LST	DBP	0
	00017	000000			
0024	00020	000000		DBP	0
	00021	000000			
0025	00022	0 000000	ADL	XAC	T1OU
0026	00023	0 000000		XAC	TNOU
0027	00024	0 000000		XAC	TNOUA
0028	00025	0 000000		XAC	TOOCT
0029	00026	0 000000		XAC	C1OU
0030	00027	0 000000		XAC	CNOU
0031	00030	0 000000		XAC	CNOUA
0032	00031	0 000000		XAC	COOCT
0033		*			
0034		*			
0035	00032	0 000000	X1OU	DAC	**
0036	00033	0 35 00063	LDX	=0	
0037	00034	0 02 00032	LDA	X1OU	
0038	00035	0 01 00051	JMP	COMM	
0039		*			
0040	00036	0 000000	XNO	DAC	**
0041	00037	0 35 00061	LDX	=1	
0042	00040	0 02 00036	LDA	XNO	
0043	00041	0 01 00051	JMP	COMM	
0044		*			
0045	00042	0 000000	XNOA	DAC	**
0046	00043	0 35 00060	LDX	=2	
0047	00044	0 02 00042	LDA	XNOA	
0048	00045	0 01 00051	JMP	COMM	
0049		*			
0050	00046	0 000000	XOOC	DAC	**
0051	00047	0 35 00057	LDX	=3	
0052	00050	0 02 00046	LDA	XOOC	
0053		*			
0054	00051	-1 04 00016	COMM	STA*	LST,1
0055	00052	1 02 00016	LDA		LST,1

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0056	00053	141206	AOA
0057	00054	0 04 00056	STA TEMP
0058	00055	-0 01 00056	JMP* TEMP
0059		*	
0060	00056	000000	TEMP BSZ 1
0061		*	
0062	00057	000003	END
	00060	000002	
	00061	000001	
	00062	000004	
	00063	000000	

PROGRAM NAME

SOURCE: SDGS

BINARY: BDGS

ENTRY POINTS (location): DGSRD ('13311), DGSWRT ('13250)

GENERAL DESCRIPTION:

These two subroutines are for reading and writing words on the digistor tape. The SIRU system only writes on the digistor tape. A fortran statement; CALL DGSWRT (ARG, 52), or the DAP instructions,

CALL	DGSWRT
DAC	ARG
DAC	='64
OCT	0

when executed, will cause this subroutine to write a heading, 52 words of information starting with ARG, and one word of parity on the digistor tape. It will then return.

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

			REL	
0001			SUBR	DGSRD
0002			SUBR	DGSWRT
0003		*		
0004				
0005	00000	0 000000	DGSW	DAC **
0006	00001	0 10 00000	CALL	F\$AT
0007	00002	000002	OCT	2
0008	00003	0 00 00000	WARY	PZE
0009	00004	0 00 00000	WCNT	PZE
0010	00005	-0 02 00004	LDA*	WCNT
0011	00006	140407	TCA	
0012	00007	101400	SMI	
0013	00010	-0 01 00000	JMP*	DGSW
0014	00011	0 04 00004	STA	WCNT
0015	00012	140040	CRA	
0016	00013	0 04 00143	STA	ACC
0017	00014	0 02 00145	LDA	='201
0018	00015	0 10 00127	JST	WRT
0019	00016	0 10 00127	JST	WRT
0020	00017	0 02 00144	LDA	='177777
0021	00020	0 10 00127	JST	WRT
0022	00021	0 10 00127	JST	WRT
0023		*		
0024	00022	-0 02 00003	WLUP	LDA* WAPY
0025	00023	141340	ICA	
0026	00024	0 10 00127	JST	WRT
0027	00025	141340	ICA	
0028	00026	0 10 00127	JST	WRT
0029	00027	0 10 00122	JST	PRTY
0030	00030	0 12 00003	IRS	WARY
0031	00031	0 12 00004	IRS	WCNT
0032	00032	0 01 00022	JMP	WLUP
0033		*		
0034	00033	0 02 00143	LDA	ACC
0035	00034	141340	ICA	
0036	00035	0 10 00127	JST	WRT
0037	00036	141340	ICA	
0038	00037	0 10 00127	JST	WRT
0039	00040	-0 01 00000	JMP*	DGSW
0040		*		
0041		*		
0042		*		
0043	00041	0 000000	DGSR	DAC **
0044	00042	0 10 00000	CALL	F\$AT
0045	00043	000002	OCT	2
0046	00044	0 00 00000	RARY	PZE
0047	00045	0 00 00000	RCNT	PZE
0048	00046	-0 02 00045	LDA*	RCNT
0049	00047	140407	TCA	
0050	00050	101400	SMI	
0051	00051	-0 01 00041	JMP*	DGSR
0052	00052	0 04 00045	STA	RCNT
0053	00053	140040	CRA	
0054	00054	0 04 00143	STA	ACC
0055	00055	140040	RLOK	CRA
0056	00056	0 10 00135	JST	RD
0057	00057	0 05 00145	ERA	='201

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0058	00060	100040	SZE		
0059	00061	0 01 00055	JMP	RLOK	
0060	00062	140040	CRA		
0061	00063	0 10 00135	JST	RD	
0062	00064	0 05 00145	ERA	=*201	
0063	00065	100040	SZE		
0064	00066	0 01 00055	JMP	RLOK	
0065	00067	140040	CRA		
0066	00070	0 10 00135	JST	RD	
0067	00071	141340	ICA		
0068	00072	0 10 00135	JST	RD	
0069	00073	0 05 00144	ERA	=*177777	
0070	00074	100040	SZE		
0071	00075	0 01 00055	JMP	RLOK	
0072		*			
0073	00076	140040	RLUP	CRA	
0074	00077	0 10 00135	JST	RD	
0075	00100	141340	ICA		
0076	00101	0 10 00135	JST	RD	
0077	00102	-0 04 00044	STA*	RARY	
0078	00103	0 10 00122	JST	PRTY	
0079	00104	0 12 00044	IRS	RARY	
0080	00105	0 12 00045	IRS	RCNT	
0081	00106	0 01 00076	JMP	RLUP	
0082		*			
0083	00107	140040	CRA		
0084	00110	0 10 00135	JST	RD	
0085	00111	141340	ICA		
0086	00112	0 10 00135	JST	RD	
0087	00113	0 05 00143	ERA	ACC	
0088	00114	101040	SNZ		
0089	00115	0 01 00120	JMP	*+3	
0090	00116	140040	CRA		
0091	00117	100000	SKP		
0092	00120	141206	AOA		
0093	00121	-0 01 00041	JMP*	DGSR	
0094		*			
0095		*			
0096		*			
0097	00122	0 000000	PRTY	DAC	**
0098	00123	0 05 00143	ERA	ACC	
0099	00124	0416 77	ALR	1	
0100	00125	0 04 00143	STA	ACC	
0101	00126	-0 01 00122	JMP*	PRTY	
0102		*			
0103	00127	0 000000	WRT	DAC	**
0104	00130	14 0002	OCP	'2	
0105	00131	74 0002	OTA	'2	
0106	00132	0 01 00130	JMP	*-2	
0107	00133	14 0102	OCP	'102	
0108		*			
0109	00134	-0 01 00127	JMP*	WRT	
0110		*			
0111	00135	0 000000	RD	DAC	**
0112	00136	14 0001	OCP	'1	
0113	00137	54 0001	INA	'1	
0114	00140	0 01 00137	JMP	*-1	

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0115	00141	14 0101	OCP	'101
0116	00142	-0 01 00135	JMP*	RD
0117		*		
0118	00143	000000	ACC	BSZ 1
0119		*		
0120	00144	177777		END
	00145	000201		

PROGRAM NAME

SOURCE: READ

BINARY: BREAD

ENTRY POINTS (location): ICINIT ('01656), INPIP ('01731),
INGYRO ('01764)

GENERAL DESCRIPTION:

The subroutine ICINIT will set up the gyro and PIPA interface to interrupt the main program every 5 milliseconds. The first interrupt will be a PIPA interrupt and will occur when the PIPA counters have 10 milliseconds of data in them. The next interrupt will be a gyro interrupt 5 milliseconds later and will occur when the gyro counters have 10 milliseconds of data in them. From then on every 5 milliseconds the interrupts will occur alternately. ICINIT will also read the initial interpolator values of the gyros.

The subroutine INPIP will read the 6 PIPA pulse counters and store them in the locations indicated by the listing with a scaling of 2^{-6} pulses. For example, an octal 000400 represents one pulse or 4 cm/sec of ΔV .

The subroutine INGYRO will read the 6 gyro pulse counters, subtract the old interpolator values, add the new interpolator values and store them in the locations indicated by the listing. These are also scaled at 2^{-6} pulses. For example, an octal 000400 represents one pulse or 7×2^{-15} radians.

MTCROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

		SUBR	ICINIT	
0001		REL		
0002				
0003	00000	0 000000	ICIN DAC	**
0004	00001	14 0047	OCP	'47
0005	00002	14 0057	OCP	'57
0006	00003	14 0077	OCP	'77
0007	00004	0 02 00210	LDA	=47
0008	00005	74 0077	OTA	'77
0009	00006	0 01 00005	JMP	*-1
0010	00007	14 0027	OCP	'27
0011	00010	34 0207	SKS	'207
0012	00011	0 01 00010	JMP	*-1
0013	00012	0400 56	LRL	18
0014	00013	14 0017	OCP	'17
0015	00014	0 35 00207	LDX	=-24
0016	00015	14 0027	WLUP OCP	'27
0017	00016	34 0207	SKS	'207
0018	00017	0 01 00016	JMP	*-1
0019	00020	0 12 00000	IRS	0
0020	00021	0 01 00015	JMP	WLUP
0021	00022	14 0027	OCP	'27
0022	00023	14 0067	OCP	'67
0023	00024	0400 56	LRL	18
0024	00025	14 0007	OCP	'7
0025	00026	34 0307	SKS	'307
0026	00027	0 01 00026	JMP	*-1
0027				* READ INITIAL INTERPOLATOR DATA
0028	00030	54 1307	INA	'1307
0029	00031	0 01 00030	JMP	*-1
0030	00032	0 04 00430	STA	'430
0031	00033	54 1317	INA	'1317
0032	00034	0 01 00033	JMP	*-1
0033	00035	0 04 00431	STA	'431
0034	00036	54 1327	INA	'1327
0035	00037	0 01 00036	JMP	*-1
0036	00040	0 04 00432	STA	'432
0037	00041	54 1337	INA	'1337
0038	00042	0 01 00041	JMP	*-1
0039	00043	0 04 00433	STA	'433
0040	00044	54 1347	INA	'1347
0041	00045	0 01 00044	JMP	*-1
0042	00046	0 04 00434	STA	'434
0043	00047	54 1357	INA	'1357
0044	00050	0 01 00047	JMP	*-1
0045	00051	0 04 00435	STA	'435
0046	00052	-0 01 00000	JMP*	ICIN
0047				*
0048				*
0049				*
0050			SUBR	INPIP
0051			REL	
0052	00053	0 000000	INPI DAC	**
0053	00054	54 1107	INA	'1107
0054	00055	0 01 00054	JMP	*-1
0055	00056	141240	ICR	
0056	00057	0 04 00600	STA	PIPA
0057	00060	54 1117	INA	'1117

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058	00061	0 01 00060	JMP	*-1
0059	00062	141240	ICR	
0060	00063	0 04 00602	STA	PIPB
0061	00064	54 1127	INA	*1127
0062	00065	0 01 00064	JMP	*-1
0063	00066	141240	ICR	
0064	00067	0 04 00604	STA	PIPC
0065	00070	54 1137	INA	*1137
0066	00071	0 01 00070	JMP	*-1
0067	00072	141240	ICR	
0068	00073	0 04 00606	STA	PIPD
0069	00074	54 1147	INA	*1147
0070	00075	0 01 00074	JMP	*-1
0071	00076	141240	ICR	
0072	00077	0 04 00610	STA	PIPE
0073	00100	54 1157	INA	*1157
0074	00101	0 01 00100	JMP	*-1
0075	00102	141240	ICR	
0076	00103	0 04 00612	STA	PIPF
0077	00104	14 2017	OCP	'17
0078	00105	-0 01 00053	JMP*	INPI
0079		*		
0080		*		
0081		000600	PIPA EQU	'600
0082		000602	PIPB EQU	PIPB+2
0083		000604	PIPC EQU	PIPB+2
0084		000606	PIPD EQU	PIPC+2
0085		000610	PIPE EQU	PIPD+2
0086		000612	PIPF EQU	PIPE+2
0087			*	
0088			*	
0089			SUBR	INGYRO
0090			REL	
0091			*	
0092	00106	0 000000	INGY DAC	**
0093	00107	54 1007	TNA	*1007
0094	00110	0 01 00107	JMP	*-1
0095	00111	141240	ICR	
0096	00112	0 07 00430	SUB	*430
0097	00113	0 04 00400	STA	GYRA
0098	00114	54 1017	INA	*1017
0099	00115	0 01 00114	JMP	*-1
0100	00116	141240	ICR	
0101	00117	0 07 00431	SUB	*431
0102	00120	0 04 00402	STA	GYRB
0103	00121	54 1027	INA	*1027
0104	00122	0 01 00121	JMP	*-1
0105	00123	141240	ICR	
0106	00124	0 07 00432	SUB	*432
0107	00125	0 04 00404	STA	GYRC
0109	00126	54 1037	INA	*1037
0109	00127	0 01 00126	JMP	*-1
0110	00130	141240	ICR	
0111	00131	0 07 00433	SUB	*433
0112	00132	0 04 00406	STA	GYRD
0113	00133	54 1047	INA	*1047
0114	00134	0 01 00133	JMP	*-1

CLEAR AND ENABLE

MTCROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0115	00135	141240	ICR	
0116	00136	0 07 00434	SUB	'434
0117	00137	0 04 00410	STA	GYRE
0118	00140	54 1057	INA	'1057
0119	00141	0 01 00140	JMP	*-1
0120	00142	141240	ICR	
0121	00143	0 07 00435	SUB	'435
0122	00144	0 04 00412	STA	GYRF
0123	00145	14 0007	OCP	'7
0124				CLEAR AND ENABLE
0125	00146	34 0307	SKS	'307
0126	00147	0 01 00146	JMP	*-1
0127	00150	54 1307	INA	'1307
0128	00151	0 01 00150	JMP	*-1
0129	00152	0 04 00430	STA	'430
0130	00153	0 06 00400	ADD	GYRA
0131	00154	0 04 00400	STA	GYRA
0132	00155	54 1317	INA	'1317
0133	00156	0 01 00155	JMP	*-1
0134	00157	0 04 00431	STA	'431
0135	00160	0 06 00402	ADD	GYRB
0136	00161	0 04 00402	STA	GYRB
0137	00162	54 1327	INA	'1327
0138	00163	0 01 00162	JMP	*-1
0139	00164	0 04 00432	STA	'432
0140	00165	0 06 00404	ADD	GYRC
0141	00166	0 04 00404	STA	GYRC
0142	00167	54 1337	INA	'1337
0143	00170	0 01 00167	JMP	*-1
0144	00171	0 04 00433	STA	'433
0145	00172	0 06 00406	ADD	GYRD
0146	00173	0 04 00406	STA	GYRD
0147	00174	54 1347	INA	'1347
0148	00175	0 01 00174	JMP	*-1
0149	00176	0 04 00434	STA	'434
0150	00177	0 06 00410	ADD	GYRE
0151	00200	0 04 00410	STA	GYRE
0152	00201	54 1357	INA	'1357
0153	00202	0 01 00201	JMP	*-1
0154	00203	0 04 00435	STA	'435
0155	00204	0 06 00412	ADD	GYRF
0156	00205	0 04 00412	STA	GYRF
0157	00206	-0 01 00106	JMP*	INGY
0158			*	
0159			*	
0160		000400	GYRA EQU	'400
0161		000402	GYRB EQU	GYRA+2
0162		000404	GYRC EQU	GYRB+2
0163		000406	GYRD EQU	GYRC+2
0164		000410	GYRE EQU	GYRD+2
0165		000412	GYRF EQU	GYRE+2
0166			*	
0167	00207	177750	END	
	00210	000057		

PROGRAM NAME

SOURCE: ACOM

BINARY: BACOM

ENTRY POINTS (location): ACOM ('03274)

GENERAL DESCRIPTION:

This subroutine compensates the accelerometers for scale factor, bias and two misalignments, SO and SP, expressed as misalignments toward the negative X, Y and Z axes. Considering just the A accelerometer, the following equations are programmed.

$$\text{AAPC} = \text{AAPC} + \text{AABD} + \frac{1}{2^6} \text{AASF AAPC}$$

where

AAPC is accelerometer A's pulse count

AABD is accelerometer A's bias

and

AASF is 2^6 X accelerometer A's Δ scale factor

then

$$\text{AAPC} = \frac{1}{2^9} (\text{DVXB AAMX} + \text{DVYB AAMY} + \text{DVZB AAMZ})$$

DVXB, DVYB, DVZB are the $\Delta V_{x,y,z}$ outputs in the body frame and AAMX, Y, Z are 2^9 X accelerometer A's misalignments in the negative X, Y, Z directions. See listing for coding.

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001	REL	
0002	SUBR	ACOM
0003 00000	0 000000	ACOM DAC **
0004 00001	0 02 00600	LDA AAPC
0005 00002	0 16 00700	MPY AASF
0006 00003	000007	DBL
0007 00004	0401 72	LRS 6
0008 00005	0 06 00706	DAD AABD
0009 00006	0 06 00600	DAD AAPC
0010 00007	0 04 00600	DST AAPC
0011 00010	0 02 00602	DLD ABPC
0012 00011	0 16 00701	MPY ABSF
0013 00012	0401 72	LRS 6
0014 00013	0 06 00710	DAD ABBB
0015 00014	0 06 00602	DAD ABPC
0016 00015	0 04 00602	DST ABPC
0017 00016	0 02 00604	DLD ACPC
0018 00017	0 16 00702	MPY ACSF
0019 00020	0401 72	LRS 6
0020 00021	0 06 00712	DAD ACBD
0021 00022	0 06 00604	DAD ACPC
0022 00023	0 04 00604	DST ACPC
0023 00024	0 02 00606	DLD ADPC
0024 00025	0 16 00703	MPY ADSF
0025 00026	0401 72	LRS 6
0026 00027	0 06 00714	DAD ADBD
0027 00030	0 06 00606	DAD ADPC
0028 00031	0 04 00606	DST ADPC
0029 00032	0 02 00610	DLD AEPC
0030 00033	0 16 00704	MPY AESF
0031 00034	0401 72	LRS 6
0032 00035	0 06 00716	DAD AEBD
0033 00036	0 06 00610	DAD AEPC
0034 00037	0 04 00610	DST AEPC
0035 00040	0 02 00612	DLD AFPC
0036 00041	0 16 00705	MPY AFSP
0037 00042	0401 72	LRS 6
0038 00043	0 06 00720	DAD AFBD
0039 00044	0 06 00612	DAD AFPC
0040 00045	0 04 00612	DST AFPC
0041 00046	0 02 00614	DLD DVXB
0042 00047	0 16 00722	MPY AAMX
0043 00050	0 04 00166	DST TACM
0044 00051	0 02 00614	DLD DVXB
0045 00052	0 16 00723	MPY ARMX
0046 00053	0 04 00170	DST TBCM
0047 00054	0 02 00614	DLD DVXB
0048 00055	0 16 00724	MPY ACMX
0049 00056	0 04 00172	DST TCCM
0050 00057	0 02 00614	DLD DVXB
0051 00060	0 16 00725	MPY ADMX
0052 00061	0 04 00174	DST TDCM
0053 00062	0 02 00614	DLD DVXB
0054 00063	0 16 00726	MPY AEMX
0055 00064	0 04 00176	DST TECM
0056 00065	0 02 00614	DLD DVXB
0057 00066	0 16 00727	MPY APMX

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058 00067	0 04 00200	DST	TPCM
0059 00070	0 02 00616	DLD	DVYB
0060 00071	0 16 00730	MPY	AAMY
0061 00072	0 06 00166	DAD	TACM
0062 00073	0 04 00166	DST	TACM
0063 00074	0 02 00616	DLD	DVYB
0064 00075	0 16 00731	MPY	ABMY
0065 00076	0 06 00170	DAD	TBCM
0066 00077	0 04 00170	DST	TBCM
0067 00100	0 02 00616	DLD	DVYB
0068 00101	0 16 00732	MPY	ACMY
0069 00102	0 06 00172	DAD	TCCM
0070 00103	0 04 00172	DST	TCCM
0071 00104	0 02 00616	DLD	DVYB
0072 00105	0 16 00733	MPY	ADMY
0073 00106	0 06 00174	DAD	TDCM
0074 00107	0 04 00174	DST	TDCM
0075 00110	0 02 00616	DLD	DVYB
0076 00111	0 16 00734	MPY	AEMY
0077 00112	0 06 00176	DAD	TECM
0078 00113	0 04 00176	DST	TECM
0079 00114	0 02 00616	DLD	DVYB
0080 00115	0 16 00735	MPY	AFMY
0081 00116	0 06 00200	DAD	TPCM
0082 00117	0 04 00200	DST	TPCM
0083 00120	0 02 00620	DLD	DVZB
0084 00121	0 16 00736	MPY	AAMZ
0085 00122	0 06 00166	DAD	TACM
0086 00123	0401 67	LRS	9
0087 00124	0 06 00600	DAD	AAPC
0088 00125	0 04 00600	DST	AAPC
0089 00126	0 02 00620	DLD	DVZB
0090 00127	0 16 00737	MPY	ABMZ
0091 00130	0 06 00170	DAD	TBCM
0092 00131	0401 67	LRS	9
0093 00132	0 06 00602	DAD	ABPC
0094 00133	0 04 00602	DST	ABPC
0095 00134	0 02 00620	DLD	DVZB
0096 00135	0 16 00740	MPY	ACMZ
0097 00136	0 06 00172	DAD	TCCM
0098 00137	0401 67	LRS	9
0099 00140	0 06 00604	DAD	ACPC
0100 00141	0 04 00604	DST	ACPC
0101 00142	0 02 00620	DLD	DVZB
0102 00143	0 16 00741	MPY	ADMZ
0103 00144	0 06 00174	DAD	TDCM
0104 00145	0401 67	LRS	9
0105 00146	0 06 00606	DAD	ADPC
0106 00147	0 04 00606	DST	ADPC
0107 00150	0 02 00620	DLD	DVZB
0108 00151	0 16 00742	MPY	AEMZ
0109 00152	0 06 00176	DAD	TECM
0110 00153	0401 67	LRS	9
0111 00154	0 06 00610	DAD	AEPC
0112 00155	0 04 00610	DST	AEPC
0113 00156	0 02 00620	DLD	DVZB
0114 00157	0 16 00743	MPY	APMZ

MTCR0COMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0115	00160	0 06 00200	DAD	TFCM
0116	00161	0401 67	LRS	9
0117	00162	0 06 00612	DAD	AFPC
0118	00163	0 04 00612	DST	AFPC
0119	00164	000005	SGL	
0120	00165	-0 01 00000	JMP*	ACOM
0121		000600	AAPC	EQU '600
0122		000602	ABPC	EQU AAPC+2
0123		000604	ACPC	EQU AAPC+4
0124		000606	ADPC	EQU AAPC+6
0125		000610	AEPC	EQU AAPC+8
0126		000612	AFPC	EQU AAPC+10
0127		000700	AASF	EQU '700
0128		000701	ABSF	EQU AASF+1
0129		000702	ACSF	EQU AASF+2
0130		000703	ADSF	EQU AASF+3
0131		000704	AESP	EQU AASF+4
0132		000705	AFSF	EQU AASF+5
0133		000706	AABD	EQU '706
0134		000710	ABBD	EQU AABD+2
0135		000712	ACBD	EQU AABD+4
0136		000714	ADBD	EQU AABD+6
0137		000716	AEBD	EQU AABD+8
0138		000720	AFBD	EQU AABD+10
0139		000722	AAMX	EQU '722
0140		000723	ABMX	EQU AAMX+1
0141		000724	ACMX	EQU AAMX+2
0142		000725	ADMX	EQU AAMX+3
0143		000726	AEMX	EQU AAMX+4
0144		000727	AFMX	EQU AAMX+5
0145		000730	AAMY	EQU AAMX+6
0146		000731	ABMY	EQU AAMX+7
0147		000732	ACMY	EQU AAMX+8
0148		000733	ADMY	EQU AAMX+9
0149		000734	AEMY	EQU AAMX+10
0150		000735	AFMY	EQU AAMX+11
0151		000736	AAMZ	EQU AAMX+12
0152		000737	ABMZ	EQU AAMX+13
0153		000740	ACMZ	EQU AAMX+14
0154		000741	ADMZ	EQU AAMX+15
0155		000742	AEMZ	EQU AAMX+16
0156		000743	AFMZ	EQU AAMX+17
0157		000614	DVXB	EQU '614
0158		000616	DVYB	EQU DVXB+2
0159		000620	DVZB	EQU DVXB+4
0160	00166	000000	TACM	DBP 0
	00167	000000		
0161	00170	000000	TBCM	DBP 0
	00171	000000		
0162	00172	000000	TCCM	DBP 0
	00173	000000		
0163	00174	000000	TDCM	DBP 0
	00175	000000		
0164	00176	000000	TECM	DBP 0
	00177	000000		
0165	00200	000000	TFCM	DBP 0
	00201	000000		

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING
0166 END

PROGRAM NAME

SOURCE: GCOM

BINARY: BGCOM

ENTRY POINT (location): GCOM ('02242)

GENERAL DESCRIPTION:

This subroutine compensates the gyros for $\pm\Delta SF$, NBD, ADIA, ADOA, ADSRA, major compliance, GO, GS and OA coupling (by calling the OA coupling compensation subroutine, DCOA). Considering just the A gyro its compensation parameters are:

$$GANS = 2^6 \times \text{gyro A negative } \Delta SF$$

$$GAPS = 2^6 \times \text{gyro A positive } \Delta SF$$

$$GABD = \text{gyro A's NBD}$$

$$ADAX, Y, Z = 2^{12} \times \text{Acceleration dependent}$$

drifts of gyro A for

accelerations on the

X, Y and Z axes

(a function of ADIA, OA, SRA)

$$AASD = 2^6 \times \text{A gyro acceleration}$$

squared drift or major

compliance

$$GAMX, Y, Z = 2^{10} \times \text{gyro A's misalignment}$$

along the negative X, Y

and Z axes (functions

of GO and GS).

For the A gyro the following equations are implemented.

$$GAPC = GAPC + GABD + \frac{1}{2^6} GAPC \begin{array}{l} \text{GAPS} \\ \text{or} \\ \text{GANS} \end{array}$$

where GAPC is Gyro A's pulse count

$$GAPC = \frac{1}{2^{12}} (ADAX DVXB + ADAY DVYB + ADAZ DVZB)$$

where DVXB, DVYB and DVZB are the accelerations (in units of $\Delta V_{x,y,z}$ per update).

$$GAPC = GAPC + \frac{1}{2^6} (DVZB DVZB - DVXB DVXB - DVXB DVZB) AASD$$

where the parenthesized expression is proportional to DVAIA DVASRA, the product of the accelerations on A gyros IA and SRA.

CALL DCOA (see documentation for subroutine DCOA)

$$GAPC = GAPC + \frac{1}{2^{10}} (GAMX DTXB + GAMY DTYB + GAMZ DTZB)$$

where DTXB, DTYB and DTZB are $\Delta\theta_x$, $\Delta\theta_y$ and $\Delta\theta_z$ during the last update. (Note, since ACOM is the subroutine which compensates the accelerometers and is a little simpler, it might be better to read its documentation first).

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001	REL
0002	SUBR GCOM
0003 00000	0 000000 GCOM DAC **
0004 00001	0 02 00400 LDA GAPC
0005 00002	000007 DBL
0006 00003	101400 SMI
0007 00004	0 01 00007 JMP *+3
0008 00005	0 16 00506 MPY GANS
0009 00006	100000 SKP
0010 00007	0 16 00500 MPY GAPS
0011 00010	0401 72 LRS 6
0012 00011	0 06 00514 DAD GABD
0013 00012	0 06 00400 DAD GAPC
0014 00013	0 04 00400 DST GAPC
0015 00014	0 02 00402 DLD GBPC
0016 00015	101400 SMI
0017 00016	0 01 00021 JMP *+3
0018 00017	0 16 00507 MPY GBNS
0019 00020	100000 SKP
0020 00021	0 16 00501 MPY GBPS
0021 00022	0401 72 LRS 6
0022 00023	0 06 00516 DAD GBBB
0023 00024	0 06 00402 DAD GBPC
0024 00025	0 04 00402 DST GBPC
0025 00026	0 02 00404 DLD GCPC
0026 00027	101400 SMI
0027 00030	0 01 00033 JMP *+3
0028 00031	0 16 00510 MPY GCNS
0029 00032	100000 SKP
0030 00033	0 16 00502 MPY GCPS
0031 00034	0401 72 LRS 6
0032 00035	0 06 00520 DAD GCBD
0033 00036	0 06 00404 DAD GCPC
0034 00037	0 04 00404 DST GCPC
0035 00040	0 02 00406 DLD GDPC
0036 00041	101400 SMI
0037 00042	0 01 00045 JMP *+3
0038 00043	0 16 00511 MPY GDNS
0039 00044	100000 SKP
0040 00045	0 16 00503 MPY GDPS
0041 00046	0401 72 LRS 6
0042 00047	0 06 00522 DAD GDBD
0043 00050	0 06 00406 DAD GDPC
0044 00051	0 04 00406 DST GDPC
0045 00052	0 02 00410 DLD GEPC
0046 00053	101400 SMI
0047 00054	0 01 00057 JMP *+3
0048 00055	0 16 00512 MPY GENs
0049 00056	100000 SKP
0050 00057	0 16 00504 MPY GEPS
0051 00060	0401 72 LFS 6
0052 00061	0 06 00524 DAD GEBD
0053 00062	0 06 00410 DAD GEPC
0054 00063	0 04 00410 DST GEPC
0055 00064	0 02 00412 DLD GFPC
0056 00065	101400 SMI
0057 00066	0 01 00071 JMP *+3

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058	00067	0 16 00513	MPY	GFNS
0059	00070	100000	SKP	
0060	00071	0 16 00505	MPY	GFPS
0061	00072	0401 72	LRS	6
0062	00073	0 06 00526	DAD	GFB
0063	00074	0 06 00412	DAD	GFP
0064	00075	0 04 00412	DST	GFP
0065	00076	0 02 00614	DLD	DVXB
0066	00077	0 16 00530	MPY	ADAX
0067	00100	0 04 00450	DST	TACM
0068	00101	0 02 00614	DID	DVXB
0069	00102	0 16 00531	MPY	ADBX
0070	00103	0 04 00452	DST	TBCM
0071	00104	0 02 00614	DLD	DVXB
0072	00105	0 16 00532	MPY	ADCX
0073	00106	0 04 00454	DST	TCCM
0074	00107	0 02 00614	DLD	DVXB
0075	00110	0 16 00533	MPY	ADDX
0076	00111	0 04 00456	DST	TDCM
0077	00112	0 02 00614	DLD	DVXB
0078	00113	0 16 00534	MPY	ADEX
0079	00114	0 04 00460	DST	TECM
0080	00115	0 02 00614	DLD	DVXB
0081	00116	0 16 00535	MPY	ADFX
0082	00117	0 04 00462	DST	TFCM
0083	00120	0 02 00616	DLD	DVYB
0084	00121	0 16 00536	MPY	ADAY
0085	00122	0 06 00450	DAD	TACM
0086	00123	0 04 00450	DST	TACM
0087	00124	0 02 00616	DLD	DVYB
0088	00125	0 16 00537	MPY	ADBY
0089	00126	0 06 00452	DAD	TBCM
0090	00127	0 04 00452	DST	TBCM
0091	00130	0 02 00616	DLD	DVYB
0092	00131	0 16 00540	MPY	ADCY
0093	00132	0 06 00454	DAD	TCCM
0094	00133	0 04 00454	DST	TCCM
0095	00134	0 02 00616	DLD	DVYB
0096	00135	0 16 00541	MPY	ADDY
0097	00136	0 06 00456	DAD	TDCM
0098	00137	0 04 00456	DST	TDCM
0099	00140	0 02 00616	DLD	DVYB
0100	00141	0 16 00542	MPY	ADEY
0101	00142	0 06 00460	DAD	TECM
0102	00143	0 04 00460	DST	TECM
0103	00144	0 02 00616	DLD	DVYB
0104	00145	0 16 00543	MPY	ADFY
0105	00146	0 06 00462	DAD	TFCM
0106	00147	0 04 00462	DST	TFCM
0107	00150	0 02 00620	DLD	DVZB
0108	00151	0 16 00544	MPY	ADAZ
0109	00152	0 06 00450	DAD	TACM
0110	00153	0401 64	IIRS	12
0111	00154	0 06 00400	DAD	GAPC
0112	00155	0 04 00400	DST	GAPC
0113	00156	0 02 00620	DLD	DVZB
0114	00157	0 16 00545	MPY	ADBZ

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0115	00160	0 06	00452	DAD	TBCM
0116	00161	0 401	64	LRS	12
0117	00162	0 06	00402	DAD	GBPC
0118	00163	0 04	00402	DST	GBPC
0119	00164	0 02	00620	DLD	DVZB
0120	00165	0 16	00546	MPY	ADCZ
0121	00166	0 06	00454	DAD	TCCM
0122	00167	0 401	64	LRS	12
0123	00170	0 06	00404	DAD	GCPC
0124	00171	0 04	00404	DST	GCPC
0125	00172	0 02	00620	DLD	DVZB
0126	00173	0 16	00547	MPY	ADDZ
0127	00174	0 06	00456	DAD	TDCM
0128	00175	0 401	64	LRS	12
0129	00176	0 06	00406	DAD	GDPC
0130	00177	0 04	00406	DST	GDPC
0131	00200	0 02	00620	DLD	DVZB
0132	00201	0 16	00550	MPY	ADEZ
0133	00202	0 06	00460	DAD	TECM
0134	00203	0 401	64	LRS	12
0135	00204	0 06	00410	DAD	GEPC
0136	00205	0 04	00410	DST	GEPC
0137	00206	0 02	00620	DLD	DVZB
0138	00207	0 16	00551	MPY	ADFZ
0139	00210	0 06	00462	DAD	TPCM
0140	00211	0 401	64	LRS	12
0141	00212	0 06	00412	DAD	GFPC
0142	00213	0 04	00412	DST	GFPC
0143	00214	0 02	00614	DLD	DVXB
0144	00215	0 16	00614	MPY	DVXB
0145	00216	0 04	00434	DST	XSKU
0146	00217	0 02	00616	DLD	DVYB
0147	00220	0 16	00616	MPY	DVYB
0148	00221	0 04	00436	DST	YSQU
0149	00222	0 02	00620	DLD	DVZB
0150	00223	0 16	00620	MPY	DVZB
0151	00224	0 04	00440	DST	ZSKU
0152	00225	0 02	00614	DLD	DVXB
0153	00226	0 16	00616	MPY	DVYB
0154	00227	0 04	00442	DST	XWHY
0155	00230	0 02	00614	DLD	DVXB
0156	00231	0 16	00620	MPY	DVZB
0157	00232	0 04	00444	DST	XZEE
0158	00233	0 02	00616	DLD	DVYB
0159	00234	0 16	00620	MPY	DVZB
0160	00235	0 04	00446	DST	YZEE
0161	00236	0 02	00440	DLD	ZSKU
0162	00237	0 07	00434	DSB	XSKU
0163	00240	0 07	00444	DSB	XZEE
0164	00241	0 16	00422	MPY	AASD
0165	00242	0 401	72	LRS	6
0166	00243	0 06	00400	DAD	GAPC
0167	00244	0 04	00400	DST	GAPC
0168	00245	0 02	00440	DLD	ZSKU
0169	00246	0 07	00434	DSB	XSKU
0170	00247	0 06	00444	DAD	XZEE
0171	00250	0 16	00423	MPY	BASD

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0172	00251	0401 72	LRS	6
0173	00252	0 06 00402	DAD	GRPC
0174	00253	0 04 00402	DST	GBPC
0175	00254	0 02 00434	DLD	XSQU
0176	00255	0 07 00436	DSB	YSQU
0177	00256	0 07 00442	DSB	XWHY
0178	00257	0 16 00424	MPY	CASD
0179	00260	0401 72	LRS	6
0180	00261	0 06 00404	DAD	GCPC
0181	00262	0 04 00404	DST	GCPC
0182	00263	0 02 00434	DID	XSQU
0183	00264	0 07 00436	DSB	YSQU
0184	00265	0 06 00442	ADD	XWHY
0185	00266	0 16 00425	MPY	DASD
0186	00267	0401 72	LRS	6
0187	00270	0 06 00406	DAD	GDPC
0188	00271	0 04 00406	DST	GDPC
0189	00272	0 02 00436	DID	YSQU
0190	00273	0 07 00440	DSB	ZSQU
0191	00274	0 07 00446	DSB	YZEE
0192	00275	0 16 00426	MPY	EASD
0193	00276	0401 72	LRS	6
0194	00277	0 06 00410	DAD	GEPC
0195	00300	0 04 00410	DST	GEPC
0196	00301	0 02 00436	DLD	YSQU
0197	00302	0 07 00440	DSB	ZSQU
0198	00303	0 06 00446	ADD	YZEE
0199	00304	0 16 00427	MPY	FASD
0200	00305	0401 72	LRS	6
0201	00306	0 06 00412	DAD	GFPC
0202	00307	0 04 00412	DST	GFPC
0203	00310	000005	SGL	
0204	00311	0 10 00000	CALL	DCOA
0205	00312	000007	DBL	
0206	00313	0 02 00414	DLD	DTXB
0207	00314	0 16 00552	MPY	GAMX
0208	00315	0 04 00450	DST	TACM
0209	00316	0 02 00414	DLD	DTXB
0210	00317	0 16 00553	MPY	GEMX
0211	00320	0 04 00452	DST	TBCM
0212	00321	0 02 00414	DLD	DTXB
0213	00322	0 16 00554	MPY	GCMX
0214	00323	0 04 00454	DST	TCCM
0215	00324	0 02 00414	DLD	DTXB
0216	00325	0 16 00555	MPY	GDMX
0217	00326	0 04 00456	DST	TDCM
0218	00327	0 02 00414	DLD	DTXB
0219	00330	0 16 00556	MPY	GEMX
0220	00331	0 04 00460	DST	TECM
0221	00332	0 02 00414	DLD	DTXB
0222	00333	0 16 00557	MPY	GFMX
0223	00334	0 04 00462	DST	TFCM
0224	00335	0 02 00416	DLD	DTYB
0225	00336	0 16 00560	MPY	GAMY
0226	00337	0 06 00450	DAD	TACM
0227	00340	0 04 00450	DST	TACM
0228	00341	0 02 00416	DLD	DTYB

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0229	00342	0	16	00561	MPY	GBMY
0230	00343	0	06	00452	DAD	TBCM
0231	00344	0	04	00452	DST	TBCM
0232	00345	0	02	00416	DLD	DTYB
0233	00346	0	16	00562	MPY	GCMY
0234	00347	0	06	00454	DAD	TCCM
0235	00350	0	04	00454	DST	TCCM
0236	00351	0	02	00416	DLD	DTYB
0237	00352	0	16	00563	MPY	GDMY
0238	00353	0	06	00456	DAD	TDCM
0239	00354	0	04	00456	DST	TDCM
0240	00355	0	02	00416	DLD	DTYB
0241	00356	0	16	00564	MPY	GEMY
0242	00357	0	06	00460	DAD	TECM
0243	00360	0	04	00460	DST	TECM
0244	00361	0	02	00416	DLD	DTYB
0245	00362	0	16	00565	MPY	GFMY
0246	00363	0	06	00462	DAD	TFCM
0247	00364	0	04	00462	DST	TFCM
0248	00365	0	02	00420	DLD	DTZB
0249	00366	0	16	00566	MPY	GAMZ
0250	00367	0	06	00450	DAD	TACM
0251	00370	0401	66		LRS	10
0252	00371	0	06	00400	DAD	GAPC
0253	00372	0	04	00400	DST	GAPC
0254	00373	0	02	00420	DLD	DTZB
0255	00374	0	16	00567	MPY	GBMZ
0256	00375	0	06	00452	DAD	TBCM
0257	00376	0401	66		LRS	10
0258	00377	0	06	00402	DAD	GBPC
0259	00400	0	04	00402	DST	GBPC
0260	00401	0	02	00420	DLD	DTZB
0261	00402	0	16	00570	MPY	GCMZ
0262	00403	0	06	00454	DAD	TCCM
0263	00404	0401	66		LRS	10
0264	00405	0	06	00404	DAD	GCPC
0265	00406	0	04	00404	DST	GCPC
0266	00407	0	02	00420	DLD	DTZB
0267	00410	0	16	00571	MPY	GDMZ
0268	00411	0	06	00456	DAD	TDCM
0269	00412	0401	66		LRS	10
0270	00413	0	06	00406	DAD	GDPC
0271	00414	0	04	00406	DST	GDPC
0272	00415	0	02	00420	DLD	DTZB
0273	00416	0	16	00572	MPY	GEMZ
0274	00417	0	06	00460	DAD	TECM
0275	00420	0401	66		LRS	10
0276	00421	0	06	00410	DAD	GEPC
0277	00422	0	04	00410	DST	GEPC
0278	00423	0	02	00420	DLD	DTZB
0279	00424	0	16	00573	MPY	GFMZ
0280	00425	0	06	00462	DAD	TFCM
0281	00426	0401	66		LRS	10
0282	00427	0	06	00412	DAD	GFPC
0283	00430	0	04	00412	DST	GFPC
0284	00431	000005			SGL	
0285	00432	-0	01	000000	JMP*	GCOM

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0286	000400	GAPC EQU	*400
0287	000402	GBPC EQU	GAPC+2
0288	000404	GCPC EQU	GAPC+4
0289	000406	GDPC EQU	GAPC+6
0290	000410	GFPC EQU	GAPC+8
0291	000412	GFPC EQU	GAPC+10
0292	000500	GAPS EQU	*500
0293	000501	GPBS EQU	GAPS+1
0294	000502	GPDS EQU	GAPS+2
0295	000503	GDPS EQU	GAPS+3
0296	000504	GFPS EQU	GAPS+4
0297	000505	GFPS EQU	GAPS+5
0298	000506	GANS EQU	GAPS+6
0299	000507	GBNS EQU	GAPS+7
0300	000510	GCNS EQU	GAPS+8
0301	000511	GDNS EQU	GAPS+9
0302	000512	GENS EQU	GAPS+10
0303	000513	GFNS EQU	GAPS+11
0304	000514	GABD EQU	*514
0305	000516	GBRD EQU	GABD+2
0306	000520	GCBD EQU	GABD+4
0307	000522	GDBD EQU	GABD+6
0308	000524	GEBD EQU	GABD+8
0309	000526	GFBD EQU	GABD+10
0310	000530	ADAX EQU	*530
0311	000531	ADBX EQU	ADAX+1
0312	000532	ADCX EQU	ADAX+2
0313	000533	ADDX EQU	ADAX+3
0314	000534	ADEX EQU	ADAX+4
0315	000535	ADFX EQU	ADAX+5
0316	000536	ADAY EQU	ADAX+6
0317	000537	ADBY EQU	ADAX+7
0318	000540	ADCY EQU	ADAX+8
0319	000541	ADDY EQU	ADAX+9
0320	000542	ADEY EQU	ADAX+10
0321	000543	ADFY EQU	ADAX+11
0322	000544	ADAZ EQU	ADAX+12
0323	000545	ADBZ EQU	ADAX+13
0324	000546	ADCZ EQU	ADAX+14
0325	000547	ADDZ EQU	ADAX+15
0326	000550	ADEZ EQU	ADAX+16
0327	000551	ADFZ EQU	ADAX+17
0328	000552	GAMX EQU	*552
0329	000553	GBMX EQU	GAMX+1
0330	000554	GCMX EQU	GAMX+2
0331	000555	GDMX EQU	GAMX+3
0332	000556	GEMX EQU	GAMX+4
0333	000557	GFMX EQU	GAMX+5
0334	000560	GAMY EQU	GAMX+6
0335	000561	GBMY EQU	GAMX+7
0336	000562	GCMY EQU	GAMX+8
0337	000563	GDMY EQU	GAMX+9
0338	000564	GEMY EQU	GAMX+10
0339	000565	GFMY EQU	GAMX+11
0340	000566	GAMZ EQU	GAMX+12
0341	000567	GBMZ EQU	GAMX+13
0342	000570	GCMZ EQU	GAMX+14

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0343	000571	GDMZ EQU	GAMX+15
0344	000572	GEMZ EQU	GAMX+16
0345	000573	GFMZ EQU	GAMX+17
0346	000422	AASD EQU	'422
0347	000423	BASD EQU	AASD+1
0348	000424	CASD EQU	AASD+2
0349	000425	DASD EQU	AASD+3
0350	000426	EASD EQU	AASD+4
0351	000427	FASD EQU	AASD+5
0352	000614	DVXB EQU	'614
0353	000616	DVYB EQU	DVXB+2
0354	000620	DVZB EQU	DVXB+4
0355	000414	DTXB EQU	'414
0356	000416	DTYB EQU	DTXB+2
0357	000420	DTZB EQU	DTXB+4
0358	00434	XSQN DBP	0
	00435	000000	
0359	00436	YSQW DBP	0
	00437	000000	
0360	00440	ZSQW DBP	0
	00441	000000	
0361	00442	XWHY DBP	0
	00443	000000	
0362	00444	XZEE DBP	0
	00445	000000	
0363	00446	YZEE DBP	0
	00447	000000	
0364	00450	TACM DBP	0
	00451	000000	
0365	00452	TBCM DBP	0
	00453	000000	
0366	00454	TCCM DBP	0
	00455	000000	
0367	00456	TDCM DBP	0
	00457	000000	
0368	00460	TECM DBP	0
	00461	000000	
0369	00462	TFCM DBP	0
	00463	000000	
0370		END	

PROGRAM NAME

SOURCE: DCMT

BINARY: BDCMT

ENTRY POINTS (location): DCMI ('03476), DCMT ('03551)

GENERAL DESCRIPTION:

The subroutine DCMT modifies the misalignments of the SIRU gyros about their output axes as a function of W_{IA} , their input axis rate which is proportional to the number of pulses each gyro got in one update ($\Delta t = .01$ sec.). The subroutine DCMI is called by the initialization section of the main program and gets these misalignments from the base sector and stores them in the buffer section between the subroutines DCMI and DCMT. It does this only once and sets the word ONLO to 1 so that if the main program is restarted, it won't get misalignments from the base sector that are already modified.

Subroutine DCMT, which is called every update, takes these OA misalignments stored in the buffer, modifies them according to the gyro's IA rate and stores them back in the base sector to be used by the gyro compensation program GCOM.

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001	REL
0002	SUBR DCMI
0003	SUBR DCMT
0004 00000 0 000000	DCMI DAC **
0005 00001 0 02 00036	LDA ONLO
0006 00002 100040	SZE
0007 00003 -0 01 00000	JMP* DCMI
0008 00004 0 02 000552	LDA GAMX
0009 00005 0 04 00037	STA AMXB
0010 00006 0 02 000566	LDA GAMZ
0011 00007 0 04 00040	STA AMZB
0012 00010 0 02 000553	LDA GBMX
0013 00011 0 04 00041	STA BMXB
0014 00012 0 02 000567	LDA GBMZ
0015 00013 0 04 00042	STA BMZB
0016 00014 0 02 000554	LDA GCMX
0017 00015 0 04 00043	STA CMXB
0018 00016 0 02 000562	LDA GCMY
0019 00017 0 04 00044	STA CMYB
0020 00020 0 02 000555	LDA GDMX
0021 00021 0 04 00045	STA DMXB
0022 00022 0 02 000563	LDA GDMY
0023 00023 0 04 00046	STA DMYB
0024 00024 0 02 000564	LDA GEMY
0025 00025 0 04 00047	STA EMYB
0026 00026 0 02 000572	LDA GEMZ
0027 00027 0 04 00050	STA EMZB
0028 00030 0 02 000565	LDA GFMY
0029 00031 0 04 00051	STA FMYB
0030 00032 0 02 000573	LDA GFMZ
0031 00033 0 04 00052	STA FMZB
0032 00034 0 12 00036	IRS ONLO
0033 00035 -0 01 00000	JMP* DCMI
0034 00036 000000	ONLO OCT 0
0035 000552	GAMX EQU '552
0036 000566	GAMZ EQU GAMX+12
0037 000553	GBMX EQU GAMX+1
0038 000567	GBMZ EQU GAMX+13
0039 000554	GCMX EQU GAMX+2
0040 000562	GCNY EQU GAMX+8
0041 000555	GDMX EQU GAMX+3
0042 000563	GDNY EQU GAMX+9
0043 000564	GEMY EQU GAMX+10
0044 000572	GEMZ EQU GAMX+16
0045 000565	GFMY EQU GAMX+11
0046 000573	GFMZ EQU GAMX+17
0047 00037 000000	AMXB OCT 0
0048 00040 000000	AMZB OCT 0
0049 00041 000000	BMXB OCT 0
0050 00042 000000	BMZB OCT 0
0051 00043 000000	CMXB OCT 0
0052 00044 000000	CMYB OCT 0
0053 00045 000000	DMXB OCT 0
0054 00046 000000	DMDY OCT 0
0055 00047 000000	EMYB OCT 0
0056 00050 000000	EMZB OCT 0
0057 00051 000000	FMYB OCT 0

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058	00052	000000	PMZB	OCT	0
0059	00053	0 000000	DCMT	DAC	**
0060	00054	0 02 00400	LDA	GAPC	
0061	00055	0 16 00151	MPY	APRX	
0062	00056	0401 00	LRS	0	
0063	00057	0 06 00037	ADD	AMXB	
0064	00060	0 04 00552	STA	GAMX	
0065	00061	0 02 00400	LDA	GAPC	
0066	00062	0 16 00152	MPY	APRZ	
0067	00063	0401 00	LRS	0	
0068	00064	0 06 00040	ADD	AMZB	
0069	00065	0 04 00566	STA	GAMZ	
0070	00066	0 02 00402	LDA	GBPC	
0071	00067	0 16 00153	MPY	BPRX	
0072	00070	0401 00	LRS	0	
0073	00071	0 06 00041	ADD	BMXB	
0074	00072	0 04 00553	STA	GBMX	
0075	00073	0 02 00402	LDA	GBPC	
0076	00074	0 16 00154	MPY	BPRZ	
0077	00075	0401 00	LRS	0	
0078	00076	0 06 00042	ADD	BMZB	
0079	00077	0 04 00567	STA	GBMZ	
0080	00100	0 02 00404	LDA	GCPC	
0081	00101	0 16 00155	MPY	CPRX	
0082	00102	0401 00	LRS	0	
0083	00103	0 06 00043	ADD	CMXB	
0084	00104	0 04 00554	STA	GCMX	
0085	00105	0 02 00404	LDA	GCPC	
0086	00106	0 16 00156	MPY	CPRY	
0087	00107	0401 00	LRS	0	
0088	00110	0 06 00044	ADD	CMYB	
0089	00111	0 04 00562	STA	GCMY	
0090	00112	0 02 00406	LDA	GDPC	
0091	00113	0 16 00157	MPY	DPRX	
0092	00114	0401 00	LRS	0	
0093	00115	0 06 00045	ADD	DMXB	
0094	00116	0 04 00555	STA	GDMX	
0095	00117	0 02 00406	LDA	GDPC	
0096	00120	0 16 00160	MPY	DPRY	
0097	00121	0401 00	LRS	0	
0098	00122	0 06 00046	ADD	DMYB	
0099	00123	0 04 00563	STA	GDMY	
0100	00124	0 02 00410	LDA	GEPC	
0101	00125	0 16 00161	MPY	EPRY	
0102	00126	0401 00	LRS	0	
0103	00127	0 06 00047	ADD	EMYB	
0104	00130	0 04 00564	STA	GEMY	
0105	00131	0 02 00410	LDA	GEPC	
0106	00132	0 16 00162	MPY	EPRZ	
0107	00133	0401 00	LRS	0	
0108	00134	0 06 00050	ADD	EMZB	
0109	00135	0 04 00572	STA	GEMZ	
0110	00136	0 02 00412	LDA	GFPC	
0111	00137	0 16 00163	MPY	FPRY	
0112	00140	0401 00	LRS	0	
0113	00141	0 06 00051	ADD	FMYB	
0114	00142	0 04 00565	STA	GEMY	

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0115	00143	0 02 00412	LDA	GFPC
0116	00144	0 16 00164	MPY	FPRZ
0117	00145	0401 00	LRS	0
0118	00146	0 06 00052	ADD	FMZB
0119	00147	0 04 00573	STA	GPMZ
0120	00150	-0 01 00053	JMP*	DCMT
0121		000400	GAPC EQU	*400
0122		000402	GBPC EQU	GAPC+2
0123		000404	GCPC EQU	GAPC+4
0124		000406	GDPC EQU	GAPC+6
0125		000410	GEPC EQU	GAPC+8
0126		000412	GFPC EQU	GAPC+10
0127	00151	000000	APRX OCT	0
0128	00152	000000	APRZ OCT	0
0129	00153	000000	BPRX OCT	0
0130	00154	000000	BPRZ OCT	0
0131	00155	000000	CPRX OCT	0
0132	00156	000000	CPRY OCT	0
0133	00157	000000	DPRX OCT	0
0134	00160	000000	DPRY OCT	0
0135	00161	000000	EPRY OCT	0
0136	00162	000000	FPRZ OCT	0
0137	00163	000000	FPRY OCT	0
0138	00164	000000	FPRZ OCT	0
0139			END	

PROGRAM NAME

SOURCE: DCOA

BINARY: BDCOA

ENTRY POINT (location): DCOA ('03144)

ACCESSIBLE VARIABLES (location): AOAP ('03252)

BOAP ('03254), COAP ('03256), DOAP ('03260), EOAP ('03262),

FOAP ('03264)

GENERAL DESCRIPTION:

The SIRU gyros sense not only a rotational input about their input axes, i.e., the $\Delta\theta$ pulses over some interval would equal the integral of W_{IRA} over that interval, but also they sense a change in the rotational input about their output axes, i.e., the $\Delta\theta$ pulses over some interval would equal $(-I)/H$ times the integral of W_{ORA} over that interval. The latter can essentially be considered an error source since the gyro output is supposed to represent only the former input axis rotation.

The integral of W_{ORA} from t_1 to t_2 is simply $W_{ORA}(t_2) - W_{ORA}(t_1)$. The $\Delta\theta$ error during that interval is simply $(-I)/H W_{ORA}(t_2) - (-I)/H W_{ORA}(t_1)$. To compensate this error, one simply has to add $((I)/H)(W_{ORA}(t_2))$ and subtract $((I)/H)(W_{ORA}(t_1))$ at time t_2 . Over one update interval the rate W_{ORA} (for say the E gyro) equals

$$\frac{\Delta\theta_x}{\Delta t}$$

Since Δt is constant, we can express W_{ORA} as $K\Delta\theta_x$ and rewrite the compensation quantity as

$$+(\frac{I}{H} K) \Delta\theta_x(t_2) - (\frac{I}{H} K) \Delta\theta_x(t_1)$$

This subroutine is called once per update and calculates the first of the two compensation terms above. The second term is saved from the previous update. DTXB, DTYB and DTZB are $\Delta\theta_x$, $\Delta\theta_y$ and $\Delta\theta_z$ respectively.

GAIH, GBIH GFIH are the scaled constants equal to

$$(\frac{I}{H} K)$$

(Note that since the E gyro has its ORA along the plus x axis, GEIH will be positive whereas the F gyro, whose ORA is along the minus X axis will have a negative GFIH.) The method for compensating the E gyro is as follows: (the others are analogous)

$$\text{EOAO} = \text{DTXB GEIH} = \Delta\theta_x(t_2) \left(\frac{I}{H} K \right)$$

and

$$\text{GEPC} = \text{EOAO} + \text{GEPC} - \text{EOAP}$$

$$\text{where EOAP} = \Delta\theta_x(t_1) \left(\frac{I}{H} K \right)$$

(Note, EOAP (previous EOAO) must be set to zero at $t = 0$ and is therefore an accessible variable to the main program).

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

			REL
0001			SUBR DCOA
0002			SUBR AOAP
0003			SUBR BOAP
0004			SUBR COAP
0005			SUBR DOAP
0006			SUBR EOAP
0007			SUBR FOAP
0008			SUBR **
0009	00000	0 000000	DCOA DAC
0010	00001	0 02 00414	LDA DTXB
0011	00002	000007	DBL
0012	00003	0 16 00126	MPY GEIH
0013	00004	0 04 00102	DST EOAO
0014	00005	0 02 00414	DLD DTXB
0015	00006	0 16 00127	MPY GFIH
0016	00007	0 04 00104	DST FOAO
0017	00010	0 02 00416	DLD DTYB
0018	00011	0 16 00122	MPY GAIH
0019	00012	0 04 00072	DST AOAO
0020	00013	0 02 00416	DLD DTYB
0021	00014	0 16 00123	MPY GBIH
0022	00015	0 04 00074	DST BOAO
0023	00016	0 02 00420	DLD DTZB
0024	00017	0 16 00124	MPY GCIH
0025	00020	0 04 00076	DST COAO
0026	00021	0 02 00420	DLD DTZB
0027	00022	0 16 00125	MPY GDIH
0028	00023	0 04 00100	DST DOAO
0029	00024	0 06 00406	DAD GDPC
0030	00025	0 07 00114	DSB DOAP
0031	00026	0 04 00406	DST GDPC
0032	00027	0 02 00072	DLD AOAO
0033	00030	0 06 00400	DAD GAPC
0034	00031	0 07 00106	DSB AOAP
0035	00032	0 04 00400	DST GAPC
0036	00033	0 02 00074	DID BOAO
0037	00034	0 06 00402	DAD GBPC
0038	00035	0 07 00110	DSB BOAP
0039	00036	0 04 00402	DST GBPC
0040	00037	0 02 00076	DID COAO
0041	00040	0 06 00404	DAD GCPC
0042	00041	0 07 00112	DSB COAP
0043	00042	0 04 00404	DST GCPC
0044	00043	0 02 00102	DLD EOAO
0045	00044	0 06 00410	DAD GEPC
0046	00045	0 07 00116	DSB EOAP
0047	00046	0 04 00410	DST GEPC
0048	00047	0 02 00104	DLD FOAO
0049	00050	0 06 00412	DAD GFPC
0050	00051	0 07 00120	DSB FOAP
0051	00052	0 04 00412	DST GPPC
0052	00053	0 02 00072	DLD AOAO
0053	00054	0 04 00106	DST AOAP
0054	00055	0 02 00074	DLD BOAO
0055	00056	0 04 00110	DST BOAP
0056	00057	0 02 00076	DLD COAO
0057	00060	0 04 00112	DST COAP

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058	00061	0 02 00100	DLD	DOAO
0059	00062	0 04 00114	DST	DOAP
0060	00063	0 02 00102	DLD	EOAO
0061	00064	0 04 00116	DST	EOAP
0062	00065	0 02 00104	DLD	FOAO
0063	00066	0 04 00120	DST	FOAP
0064	00067	000005	SGL	
0065	00070	-0 01 00000	JMP*	DCOA
0066	00072	000000	AOAO DBP	0
	00073	000000		
0067	00074	000000	BOAO DBP	0
	00075	000000		
0068	00076	000000	COAO DBP	0
	00077	000000		
0069	00100	000000	DOAO DBP	0
	00101	000000		
0070	00102	000000	EOAO DBP	0
	00103	000000		
0071	00104	000000	FOAO DBP	0
	00105	000000		
0072	00106	000000	AOAP DBP	0
	00107	000000		
0073	00110	000000	BOAP DBP	0
	00111	000000		
0074	00112	000000	COAP DBP	0
	00113	000000		
0075	00114	000000	DOAP DBP	0
	00115	000000		
0076	00116	000000	EOAP DBP	0
	00117	000000		
0077	00120	000000	FOAP DBP	0
	00121	000000		
0078	00122	000000	GAIH OCT	0
0079	00123	000000	GBIH OCT	0
0080	00124	000000	GCIH OCT	0
0081	00125	000000	GDIH OCT	0
0082	00126	000000	GEIH OCT	0
0083	00127	000000	GFIH OCT	0
0084		000400	GAPC EQU	*400
0085		000402	GPBC EQU	GAPC+2
0086		000404	GCPC EQU	GAPC+4
0087		000406	GDPC EQU	GAPC+6
0088		000410	GEPC EQU	GAPC+8
0089		000412	GFPC EQU	GAPC+10
0090		000414	DTXB EQU	*414
0091		000416	DTYB EQU	DTXB+2
0092		000420	DTZB EQU	DTXB+4
0093			END	

PROGRAM NAME

SOURCE: ROMS

BINARY: BROMS

ENTRY POINTS (location): ROMS ('14000)

ACCESSIBLE VARIABLES: WXPR ('14333),

WYPR ('14334), WZPR ('14335)

GENERAL DESCRIPTION:

When the SIRU strapdown system is subjected to a rotational environment its accelerometers will sense acceleration due to $\omega^2 R$ and $\dot{\omega}R$. Since the accelerometers do not all sense acceleration at the same point, these rotation-induced accelerations will make the accelerometers appear to be in disagreement. This subroutine compensates the accelerometers to make them look as if they are all sensing acceleration at the same point (since the location of this point is not critical we pick the center of the A accelerometer so that at least the A accelerometer need not be compensated).

Consider some point which has an R vector from the center of the A accelerometer of (RX, RY, RZ). The acceleration sensed at this point different from the acceleration sensed at the center of the A accelerometer is:

$$\begin{aligned} & \bar{i}(\omega_x \omega_y RY + \omega_x \omega_z RZ - \omega_y^2 R_x - \omega_z^2 R_x + \dot{\omega}_y RZ - \dot{\omega}_z RY) \\ & + \bar{j}(\omega_y \omega_z RZ + \omega_y \omega_x RX - \omega_x^2 RY - \omega_z^2 RY + \dot{\omega}_z RX - \dot{\omega}_x RZ) \\ & + \bar{k}(\omega_z \omega_x RX + \omega_z \omega_y RY - \omega_x^2 RZ - \omega_y^2 RZ + \dot{\omega}_x RY - \dot{\omega}_y RX) \end{aligned}$$

B, C, D, E and F accelerometers can be corrected by adding the negative of the acceleration each one senses due to rotation. For the F accelerometer this would be

$$-S \text{ (Z axis acceleration)} + C \text{ (Y axis acceleration)}$$

where

$$C = \cosine, S = \sin$$

or

$$-S(\omega_z \omega_x RFX + \omega_z \omega_y RFY - \omega_x^2 RFZ - \omega_y^2 RFZ + \dot{\omega}_x RFY - \dot{\omega}_y RFX) \\ +C(\omega_y \omega_z RFZ + \omega_y \omega_x RFX - \omega_x^2 RFY - \omega_z^2 RFY + \dot{\omega}_z RFX - \dot{\omega}_x RFZ)$$

these terms can be combined to give:

$$C RFX(\omega_y \omega_x + \dot{\omega}_z) \\ + C RFY(-\omega_x^2 - \omega_z^2) \\ + C RFZ(\omega_y \omega_z - \dot{\omega}_x) \\ + S RFX(-\omega_z \omega_x + \dot{\omega}_y) \\ + S RFY(-\omega_z \dot{\omega}_y - \dot{\omega}_x) \\ + S RFY(\omega_x^2 + \omega_y^2)$$

a similar set of corrections can be derived for accelerometers B, C, D and E.

This subroutine first calculates $\omega_x \omega_y$, $\omega_x \omega_z$, $\omega_y \omega_z$, ω_x^2 , ω_y^2 , ω_z^2 , $\dot{\omega}_x$, $\dot{\omega}_y$ and $\dot{\omega}_z$ using $\Delta\theta_x$, $\Delta\theta_y$ and $\Delta\theta_z$ over one update interval as an indication of ω_x , ω_y and ω_z . It then calculates

$$\text{PAR1} = \omega_y \omega_x + \dot{\omega}_z$$

$$\text{PAR2} = \omega_x^2 + \omega_z^2$$

$$\text{PAR3} = \omega_y \omega_z - \dot{\omega}_x$$

$$\text{PAR4} = \omega_z \omega_x - \dot{\omega}_y$$

$$\text{PAR5} = \omega_z \omega_y - \dot{\omega}_x$$

$$\text{PAR6} = \omega_x^2 + \omega_y^2$$

$$\text{PAR7} = \omega_y^2 + \omega_z^2$$

$$\text{PAR8} = \omega_x \omega_y - \dot{\omega}_z$$

$$\text{PAR9} = \omega_x \omega_z + \dot{\omega}_y$$

F's correction can now be defined as:

```

C RFX PAR1
-C RFY PAR2
+C RFZ PAR3
-S RFX PAR4
-S RFY PAR5
+S RFZ PAR6

```

Without doing the whole derivation B's correction can be defined as:

```

-C RBX PAR4
-C RBY PAR5
+C RBZ PAR6
-S RBX PAR7
+S RBY PAR8
+S RBZ PAR9

```

C, D and E have similar corrections.

The terms in the above equations such as -C RBX are constants and are stored as such in this subroutine. They are functions of the following table of distances which was made from detailed drawings of the SIRU PI-frame and SIRU accelerometers.

AXIS R(cm)	A	B	C	D	E	F
X	0	-8.603	13.937	13.937	2.718	0.902
Y	0	-1.816	-24.021	-15.418	-27.081	11.130
Z	0	0	2.482	0.665	1.085	1.085

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001			ABS	
0002			ORG	*14000
0003			SUBR	WXPR
0004			SUBR	WYPR
0005			SUBR	WZPR
0006			SUBR	ROMS
0007	14000	0 000000	ROMS	DAC **
0008	14001	0 02 00414	LDA	WX
0009	14002	0 16 00416	MPY	WY
0010	14003	0 04 14322	STA	WXWY
0011	14004	0 02 00414	LDA	WX
0012	14005	0 16 00420	MPY	WZ
0013	14006	0 04 14323	STA	WXWZ
0014	14007	0 02 00416	LDA	WY
0015	14010	0 16 00420	MPY	WZ
0016	14011	0 04 14324	STA	WYWZ
0017	14012	0 02 00414	LDA	WX
0018	14013	0 16 00414	MPY	WX
0019	14014	0 04 14325	STA	WXSQ
0020	14015	0 02 00416	LDA	WY
0021	14016	0 16 00416	MPY	WY
0022	14017	0 04 14326	STA	WYSQ
0023	14020	0 02 00420	LDA	WZ
0024	14021	0 16 00420	MPY	WZ
0025	14022	0 04 14327	STA	WZSQ
0026	14023	0 02 00414	LDA	WX
0027	14024	0 07 14333	SUB	WXPR
0028	14025	0415 72	ALS	6
0029	14026	0 04 14330	STA	WXDT
0030	14027	0 02 00416	LDA	WY
0031	14030	0 07 14334	SUB	WYPR
0032	14031	0415 72	ALS	6
0033	14032	0 04 14331	STA	WYDT
0034	14033	0 02 00420	LDA	WZ
0035	14034	0 07 14335	SUB	WZPR
0036	14035	0415 72	AIS	6
0037	14036	0 04 14332	STA	WZDT
0038	14037	0 06 14322	ADD	WXWY
0039	14040	0 04 14262	STA	PAR1
0040	14041	0 16 14336	MPY	CRFX
0041	14042	000007	DBL	
0042	14043	0 04 14304	DST	CORF
0043	14044	000005	SGL	
0044	14045	0 02 14325	LDA	WXSQ
0045	14046	0 06 14327	ADD	WZSQ
0046	14047	0 04 14264	STA	PAR2
0047	14050	0 16 14337	MPY	CRFY
0048	14051	000007	DBL	
0049	14052	0 06 14304	DAD	CORF
0050	14053	0 04 14304	DST	CORF
0051	14054	000005	SGL	
0052	14055	0 02 14324	LDA	WYWZ
0053	14056	0 07 14330	SUB	WXDT
0054	14057	0 04 14266	STA	PAR3
0055	14060	0 16 14340	MPY	CRFZ
0056	14061	000007	DBL	
0057	14062	0 04 14316	DST	TEM1

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058	14063	0 06	14304	DAD	CORF
0059	14064	0 04	14304	DST	CORF
0060	14065	000005		SGL	
0061	14066	0 02	14323	LDA	WXWZ
0062	14067	0 07	14331	SUB	WYDT
0063	14070	0 04	14270	STA	PAR4
0064	14071	0 16	14341	MPY	SRFX
0065	14072	000007		DBL	
0066	14073	0 06	14304	DAD	CORF
0067	14074	0 04	14304	DST	CORF
0068	14075	000005		SGL	
0069	14076	0 02	14324	LDA	WYWZ
0070	14077	0 07	14330	SUB	WXDT
0071	14100	0 04	14272	STA	PAR5
0072	14101	0 16	14342	MPY	SRFY
0073	14102	000007		DBL	
0074	14103	0 06	14304	DAD	CORF
0075	14104	0 04	14304	DST	CORF
0076	14105	000005		SGL	
0077	14106	0 02	14325	LDA	WXSQ
0078	14107	0 06	14326	ADD	WYSQ
0079	14110	0 04	14274	STA	PAR6
0080	14111	0 16	14343	MPY	SRFZ
0081	14112	000007		DBL	
0082	14113	0 04	14306	DST	CORE
0083	14114	0 06	14304	DAD	CORF
0084	14115	0401 67		LRS	9
0085	14116	0 06	00612	DAD	'612
0086	14117	0 04	00612	DST	'612
0087	14120	000005		SGL	
0088	14121	0 02	14326	LDA	WYSQ
0089	14122	0 06	14327	ADD	WZSQ
0090	14123	0 04	14276	STA	PAR7
0091	14124	0 16	14351	MPY	CRDX
0092	14125	000007		DBL	
0093	14126	0 04	14310	DST	CORD
0094	14127	0 04	14312	DST	CORC
0095	14130	000005		SGL	
0096	14131	0 02	14322	LDA	WXWY
0097	14132	0 07	14332	SUB	WZDT
0098	14133	0 04	14300	STA	PAR8
0099	14134	0 16	14352	MPY	CRDY
0100	14135	000007		DBL	
0101	14136	0 06	14310	DAD	CORD
0102	14137	0 04	14310	DST	CORD
0103	14140	000005		SGL	
0104	14141	0 02	14323	LDA	WXWZ
0105	14142	0 06	14331	ADD	WYDT
0106	14143	0 04	14302	STA	PAR9
0107	14144	0 16	14353	MPY	CRDZ
0108	14145	000007		DBL	
0109	14146	0 06	14310	DAD	CORD
0110	14147	0 04	14310	DST	CORD
0111	14150	0 02	14264	DLD	PAR2
0112	14151	0 16	14345	MPY	CREY
0113	14152	0 06	14306	DAD	CORE
0114	14153	0 07	14316	DSB	TEM1

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0115	14154	0 04	14306	DST	CORE
0116	14155	0 02	14270	DLD	PAR4
0117	14156	0 16	14346	MPY	SREX
0118	14157	0 06	14306	DAD	CORE
0119	14160	0 04	14306	DST	CORE
0120	14161	0 02	14272	DLD	PAR5
0121	14162	0 16	14350	MPY	SREY
0122	14163	0 06	14306	DAD	CORE
0123	14164	0401 67		LRS	9
0124	14165	0 06	00610	DAD	'610
0125	14166	0 04	00610	DST	'610
0126	14167	0 02	14262	DLD	PAR1
0127	14170	0 16	14354	MPY	SRDX
0128	14171	0 04	14320	DST	TEM2
0129	14172	0 06	14310	DAD	CORD
0130	14173	0 04	14310	DST	CORD
0131	14174	0 02	14264	DLD	PAR2
0132	14175	0 16	14355	MPY	SRDY
0133	14176	0 06	14310	DAD	CORD
0134	14177	0 04	14310	DST	CORD
0135	14200	0 02	14266	DLD	PAR3
0136	14201	0 16	14356	MPY	SRDZ
0137	14202	0 06	14310	DAD	CORD
0138	14203	0401 67		LRS	9
0139	14204	0 06	00606	DAD	'606
0140	14205	0 04	00606	DST	'606
0141	14206	0 02	14300	DLD	PAR8
0142	14207	0 16	14357	MPY	CRCY
0143	14210	0 06	14312	DAD	CORC
0144	14211	0 07	14320	DSB	TEM2
0145	14212	0 04	14312	DST	CORC
0146	14213	0 02	14302	DLD	PAR9
0147	14214	0 16	14360	MPY	CRCZ
0148	14215	0 06	14312	DAD	CORC
0149	14216	0 04	14312	DST	CORC
0150	14217	0 02	14264	DLD	PAR2
0151	14220	0 16	14361	MPY	SRCY
0152	14221	0 06	14312	DAD	CORC
0153	14222	0 04	14312	DST	CORC
0154	14223	0 02	14266	DLD	PAR3
0155	14224	0 16	14362	MPY	SRCZ
0156	14225	0 06	14312	DAD	CORC
0157	14226	0401 67		LRS	9
0158	14227	0 06	00604	DAD	'604
0159	14230	0 04	00604	DST	'604
0160	14231	0 02	14270	DLD	PAR4
0161	14232	0 16	14363	MPY	CRBX
0162	14233	0 04	14314	DST	CORB
0163	14234	0 02	14272	DLD	PAR5
0164	14235	0 16	14364	MPY	CRBY
0165	14236	0 06	14314	DAD	CORB
0166	14237	0 04	14314	DST	CORB
0167	14240	0 02	14276	DLD	PAR7
0168	14241	0 16	14365	MPY	SRBX
0169	14242	0 06	14314	DAD	CORB
0170	14243	0 04	14314	DST	CORB
0171	14244	0 02	14300	DLD	PAR8

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0172	14245	0 16	14366	MPY	SRBY
0173	14246	0 06	14314	DAD	CORB
0174	14247	0401	67	LRS	9
0175	14250	0 06	00602	DAD	'602
0176	14251	0 04	00602	DST	'602
0177	14252	000005		SGL	
0178	14253	0 02	00414	LDA	WX
0179	14254	0 04	14333	STA	WXPR
0180	14255	0 02	00416	LDA	WY
0181	14256	0 04	14334	STA	WYPR
0182	14257	0 02	00420	LDA	WZ
0183	14260	0 04	14335	STA	WZPR
0184	14261	-0 01	14000	JMP*	ROMS
0185	14262	000000		PAR1	DBP
	14263	000000			0
0186	14264	000000		PAR2	DBP
	14265	000000			0
0187	14266	000000		PAR3	DBP
	14267	000000			0
0188	14270	000000		PAR4	DBP
	14271	000000			0
0189	14272	000000		PAR5	DBP
	14273	000000			0
0190	14274	000000		PAR6	DBP
	14275	000000			0
0191	14276	000000		PAR7	DBP
	14277	000000			0
0192	14300	000000		PAR8	DBP
	14301	000000			0
0193	14302	000000		PAR9	DBP
	14303	000000			0
0194	14304	000000		CORF	DBP
	14305	000000			0
0195	14306	000000		CORE	DBP
	14307	000000			0
0196	14310	000000		CORD	DBP
	14311	000000			0
0197	14312	000000		CORC	DBP
	14313	000000			0
0198	14314	000000		CORB	DBP
	14315	000000			0
0199	14316	000000		TEM1	DBP
	14317	000000			0
0200	14320	000000		TEM2	DBP
	14321	000000			0
0201	14322	000000		WXWY	OCT
0202	14323	000000		WXWZ	OCT
0203	14324	000000		WYWZ	OCT
0204	14325	000000		WXSQ	OCT
0205	14326	000000		WYSQ	OCT
0206	14327	000000		WZSQ	OCT
0207	14330	000000		WXDT	OCT
0208	14331	000000		WYDT	OCT
0209	14332	000000		WZDT	OCT
0210	14333	000000		WXPR	OCT
0211	14334	000000		WYPR	OCT
0212	14335	000000		WZPR	OCT

MICROCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

0213	14336	001145	CRFX DEC	76.703B12
0214	14337	161152	CRFY DEC	-946.8B12
0215	14340	001342	CRFZ DEC	92.26B12
0216	14341	177205	SRFX DEC	-47.405B12
0217	14342	166667	SRFY DEC	-585.15B12
0218	14343	000710	SRFZ DEC	57.02B12
0219	14344	174307	CREX DEC	-231.19B12
0220	14345	134003	CREY DEC	-2303.69B12
0221	14346	135670	SREX DEC	-142.88
	14347	107535		
0222	14350	026176	SREY DEC	1423.76B12
0223	14351	155364	CRDX DEC	-1185.55B12
0224	14352	153404	CRDY DEC	-1311.52B12
0225	14353	000704	CRDZ DEC	56.609B12
0226	14354	164433	SRDX DEC	-732.71B12
0227	14355	163254	SRDY DEC	-810.56B12
0228	14356	177351	SRDZ DEC	-34.986B12
0229	14357	140046	CRCY DEC	-2043.33B12
0230	14360	003230	CRCZ DEC	211.096B12
0231	14361	023566	SRCY DEC	1262.85B12
0232	14362	002023	SRCZ DEC	130.464B12
0233	14363	013336	CRBX DEC	731.813B12
0234	14364	002323	CRBY DEC	154.49B12
0235	14365	007042	SRBX DEC	452.29B12
0236	14366	176405	SRBY DEC	-95.48B12
0237		000414	WX EQU	'414
0238		000416	WY EQU	'416
0239		000420	WZ EQU	'420
0240			END	

PROGRAM NAME:

SOURCE: PREX

BINARY: BPREX

ENTRY POINTS (location): PARC ('06040)

ACCESSABLE VARIABLES (location): PACC ('06166)

GENERAL DESCRIPTION:

This subroutine is essentially equivalent to GARC, the gyro error accumulator, except it only accumulates compensated pulses from the six PIPAs. The only other difference is that when it is time to purge the PIPA accumulators, it puts a 1 in location '765 (note the instruction IRS '765) which clues the PIPA parity equation solver (program source name PPEX, subroutine entry point PPRT) not to do its calculation. This feature is solely for timing considerations.

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

			REL	
0001			SUBR	PARC
0002			SUBR	PACC
0003				
0004	00000	0 000000	PARC	DAC **
0005	00001	0 12 00126	IRS	PACC
0006	00002	0 01 00023	JMP	NPCC
0007	00003	0 12 00765	IRS	'765
0008	00004	0 02 00131	LDA	=-6000
0009	00005	0 04 00126	STA	PACC
0010	00006	0 35 00130	LDX	=-12
0011	00007	000007	DBL	
0012	00010	1 02 00316	LUPE	DLD PAPA+12,1
0013	00011	1 07 00106	DSB	ARES+12,1
0014	00012	1 04 00316	DST	PAPA+12,1
0015	00013	1 02 00124	DID	ARRS+12,1
0016	00014	1 07 00106	DSB	ARES+12,1
0017	00015	1 04 00106	DST	ARES+12,1
0018	00016	1 02 00316	DLD	PAPA+12,1
0019	00017	1 04 00124	DST	ARRS+12,1
0020	00020	0 12 00000	IRS	0
0021	00021	0 12 00000	IRS	0
0022	00022	0 01 00010	JMP	LUPE
0023	00023	0 02 00600	NPCC	LDA PAPC
0024	00024	000007	DBL	
0025	00025	0401 61	LRS	15
0026	00026	0 06 00302	DAD	PAPA
0027	00027	0 04 00302	DST	PAPA
0028	00030	0401 73	LRS	5
0029	00031	0 04 00744	DST	AARP
0030	00032	0 02 00602	DLD	PBPC
0031	00033	0401 61	LRS	15
0032	00034	0 06 00304	DAD	PBPA
0033	00035	0 04 00304	DST	PBPA
0034	00036	0401 73	LRS	5
0035	00037	0 04 00746	DST	BARP
0036	00040	0 02 00604	DLD	PCPC
0037	00041	0401 61	LRS	15
0038	00042	0 06 00306	DAD	PCPA
0039	00043	0 04 00306	DST	PCPA
0040	00044	0401 73	LRS	5
0041	00045	0 04 00750	DST	CARP
0042	00046	0 02 00606	DLD	PDPC
0043	00047	0401 61	LRS	15
0044	00050	0 06 00310	DAD	PDPA
0045	00051	0 04 00310	DST	PDPA
0046	00052	0401 73	LRS	5
0047	00053	0 04 00752	DST	DARP
0048	00054	0 02 00610	DLD	PEPC
0049	00055	0401 61	LRS	15
0050	00056	0 06 00312	DAD	PEPA
0051	00057	0 04 00312	DST	PEPA
0052	00060	0401 73	LRS	5
0053	00061	0 04 00754	DST	EARP
0054	00062	0 02 00612	DLD	PFPC
0055	00063	0401 61	LRS	15
0056	00064	0 06 00314	DAD	PPPA
0057	00065	0 04 00314	DST	PFPA

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058	00066	0401 73	LRS	5
0059	00067	0 04 00756	DST	FARP
0060	00070	000005	SGL	
0061	00071	-0 01 00000	JMF*	PARC
0062		000600	PAPC EQU	*600
0063		000602	PBPC EQU	PAPC+2
0064		000604	PCPC EQU	PAPC+4
0065		000606	PDPC EQU	PAPC+6
0066		000610	PEPC EQU	PAPC+8
0067		000612	PFPC EQU	PAPC+10
0068		000302	PAPA EQU	*302
0069		000304	PBPA EQU	PAPA+2
0070		000306	PCPA EQU	PAPA+4
0071		000310	PDPA EQU	PAPA+6
0072		000312	PEPA EQU	PAPA+8
0073		000314	PFPA EQU	PAPA+10
0074		000744	AARP EQU	*744
0075		000746	BARP EQU	AARP+2
0076		000750	CARP EQU	AARP+4
0077		000752	DARP EQU	AARP+6
0078		000754	EARP EQU	AARP+8
0079		000756	FARP EQU	AARP+10
0080	00072	000000	ARES DBP	0
	00073	000000		
0081	00074	000000	BRES DBP	0
	00075	000000		
0082	00076	000000	CRS DBP	0
	00077	000000		
0083	00100	000000	DRS DBP	0
	00101	000000		
0084	00102	000000	ERES DBP	0
	00103	000000		
0085	00104	000000	PRS DBP	0
	00105	000000		
0086	00106	000000	SRES DBP	0
	00107	000000		
0087	00110	000000	ARRS DBP	0
	00111	000000		
0088	00112	000000	BRRS DBP	0
	00113	000000		
0089	00114	000000	CRRS DBP	0
	00115	000000		
0090	00116	000000	DRRS DBP	0
	00117	000000		
0091	00120	000000	ERRS DBP	0
	00121	000000		
0092	00122	000000	FRRS DBP	0
	00123	000000		
0093	00124	000000	SRRS DBP	0
	00125	000000		
0094	00126	164217	PACC DEC	-6001
0095	00127	000000	STSE OCT	0
0096	00130	177764		END
	00131	164220		

PROGRAM NAME:

SOURCE: GARC

BINARY: BGARC

ENTRY POINTS (location): GARC ('07344)

ACCESSABLE VARIABLES (location): GACC ('07524)

GENERAL DESCRIPTION:

This subroutine accumulates the 6 compensated gyro pulse counts (GAPC, GBPC, GCPC, GDPC, GEPC and GFPC) in the six gyro pulse accumulators (GAPA, GBPA, GCPA, GDPA, GEPA and GFPA) and then stores the accumulations in the six arguments (AARG, BARG, CARG, DARG, EARG, and FARG) for the squared error calculator (see documentation for program source name CFSE, subroutine entry point SECA). It also accumulates

$$\sum |\Delta\theta X| + |\Delta\theta Y| + |\Delta\theta Z|$$

to be used to increase the maximum allowable total squared error to allow for dynamic scale factor and misalignment errors (see documentation for GFIS).

The 6 compensated gyro pulse counts are double precision numbers with the high order word being of significance and the low order word being carried along as a residual. Thus, every time an LRS 15 instruction operates on a gyro pulse count in the accumulator, it is simply to shift the residual out. Scaling can best be expressed by giving the representation of one gyro pulse for GAPC, GAPA and AARG.

GAPC oct 00400, 00000

GAPA oct 00000, 00400

AARG oct 00000, 00010

Therefore, the bit granularity of the arguments used by the squared error calculator is $\pm 1/8$ pulse.

In order that the gyro pulse accumulators don't overflow, they are periodically purged of old accumulation. Define A (t_1, t_2) to be the accumulation of gyro pulses between times t_1 and t_2 . Every minute starting at $t = 60$, the following purge is performed (let us look just at the A gyro accumulator).

$$GAPA = GAPA - ARES$$

$$ARES = ARRS - ARES$$

$$ARRS = GAPA$$

ARES = A gyro residual.

ARRS = A gyro residual residual.

following this procedure we get:

at time = 60

$$GAPA = GAPA - ARES$$

$$GAPA = A(0, 60) - 0 = A(0, 60)$$

$$ARES = ARRS - ARES = 0 - 0 = 0$$

$$ARRS = GAPA = A(0, 60)$$

at time = 120

$$GAPA = GAPA - ARES$$

$$GAPA = A(0, 120) - 0 = A(0, 120)$$

$$ARES = ARRS - ARES = A(0, 60) - 0 = A(0, 60)$$

$$ARRS = GAPA = A(0, 120)$$

at time = 180

$$GAPA = GAPA - ARES$$

$$GAPA = A(0, 180) - A(0, 60) = A(60, 180)$$

$$ARES = ARRS - ARES = A(0, 120) - A(0, 60) = A(60, 120)$$

$$ARRS = GAPA = A(60, 180)$$

at time = 240


$$GAPA = GAPA - ARES$$

$$GAPA = A(60, 240) - A(60, 120) = A(120, 240)$$

$$ARES = ARRS - ARES = A(60, 180) - A(60, 120) = A(120, 180)$$

$$ARRS = GAPA = A(120, 240) \text{ etc.}$$

the flow chart follows.



FLOWCHART - GARC

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001			REL	
0002			SUBR	GARC
0003			SUBR	GACC
0004	00000	0 000000	GARC	DAC **
0005	00001	0 12 00160	IRS	GACC
0006	00002	0 01 00032	JMP	NGCC
0007	00003	0 02 00163	LDA	=-6000
0008	00004	0 04 00160	STA	GACC
0009	00005	0 35 00162	LDX	=-12
0010	00006	000007	DBL	
0011	00007	1 02 00302	LUPE	DLD GAPA+12,1
0012	00010	1 07 00140	DSB	AFRS+12,1
0013	00011	1 04 00302	DST	GAPA+12,1
0014	00012	1 02 00156	DLD	AFRS+12,1
0015	00013	1 07 00140	DSB	ARES+12,1
0016	00014	1 04 00140	DST	ARES+12,1
0017	00015	1 02 00302	DLD	GAPA+12,1
0018	00016	1 04 00156	DST	ARRS+12,1
0019	00017	0 12 00000	IRS	0
0020	00020	0 12 00000	IRS	0
0021	00021	0 01 00007	JMP	LUPE
0022	00022	0 02 00774	DLD	SUDT
0023	00023	0 07 00140	DSB	SPES
0024	00024	0 04 00774	DST	SUDT
0025	00025	0 02 00156	DLD	SPRS
0026	00026	0 07 00140	DSB	SPES
0027	00027	0 04 00140	DST	SRES
0028	00030	0 02 00774	DLD	SUDT
0029	00031	0 04 00156	DST	SRRS
0030	00032	0 02 00400	NGCC	LDA GAPC
0031	00033	000007	DBL	
0032	00034	0401 61	LRS	15
0033	00035	0 06 00266	DAD	GAPA
0034	00036	0 04 00266	DST	GAPA
0035	00037	0401 73	LRS	5
0036	00040	0 04 00744	DST	AARG
0037	00041	0 02 00402	DLD	GBPC
0038	00042	0401 61	LRS	15
0039	00043	0 06 00270	DAD	GBPA
0040	00044	0 04 00270	DST	GBPA
0041	00045	0401 73	LRS	5
0042	00046	0 04 00746	DST	BARG
0043	00047	0 02 00404	DLD	GCPC
0044	00050	0401 61	LRS	15
0045	00051	0 06 00272	DAD	GCPA
0046	00052	0 04 00272	DST	GCPA
0047	00053	0401 73	LRS	5
0048	00054	0 04 00750	DST	CARG
0049	00055	0 02 00406	DLD	GDPC
0050	00056	0401 61	LRS	15
0051	00057	0 06 00274	DAD	GDPA
0052	00060	0 04 00274	DST	GDPA
0053	00061	0401 73	LRS	5
0054	00062	0 04 00752	DST	DARG
0055	00063	0 02 00410	DLD	GEPC
0056	00064	0401 61	LRS	15
0057	00065	0 06 00276	DAD	GEPA

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058	00066	0 04 00276	DST	GEPA
0059	00067	0401 73	LRS	5
0060	00070	0 04 00754	DST	EARG
0061	00071	0 02 00412	DID	GPPC
0062	00072	0401 61	LRS	15
0063	00073	0 06 00300	DAD	GFPA
0064	00074	0 04 00300	DST	GFPA
0065	00075	0401 73	LRS	5
0066	00076	0 04 00756	DST	FARG
0067	00077	000005	SGL	
0068	00100	0 02 00414	LDA	DTXB
0069	00101	100400	SPL	
0070	00102	140407	TCA	
0071	00103	0 04 00161	STA	STSE
0072	00104	0 02 00416	LDA	DTYB
0073	00105	100400	SPL	
0074	00106	140407	TCA	
0075	00107	0 06 00161	ADD	STSE
0076	00110	0 04 00161	STA	STSE
0077	00111	0 02 00420	LDA	DTZB
0078	00112	100400	SPL	
0079	00113	140407	TCA	
0080	00114	0 06 00161	ADD	STSE
0081	00115	000007	DBL	
0082	00116	0401 61	LRS	15
0083	00117	0 06 00774	DAD	SUDT
0084	00120	0 04 00774	DST	SUDT
0085	00121	000005	SGL	
0086	00122	-0 01 00000	JMP*	GARC
0087		000400	GAPC EQU	'400
0088		000402	GBPC EQU	GAPC+2
0089		000404	GCPC EQU	GAPC+4
0090		000406	GPBC EQU	GAPC+6
0091		000410	GPFC EQU	GAPC+8
0092		000412	GFPC EQU	GAPC+10
0093		000266	GAPA EQU	'266
0094		000270	GBPA EQU	GAPA+2
0095		000272	CPA EQU	GAPA+4
0096		000274	GDPA EQU	GAPA+6
0097		000276	GEPA EQU	GAPA+8
0098		000300	GFPA EQU	GAPA+10
0099		000744	AARG EQU	'744
0100		000746	BARG EQU	AARG+2
0101		000750	CARG EQU	AARG+4
0102		000752	DARG EQU	AARG+6
0103		000754	EARG EQU	AARG+8
0104		000756	FARG EQU	AARG+10
0105		000414	DTXB EQU	'414
0106		000416	DTYB EQU	DTXB+2
0107		000420	DTZB EQU	DTXB+4
0108		000774	SUDT EQU	'774
0109	00124	000000	ARES DBP	0
	00125	000000		
0110	00126	000000	BRES DBP	0
	00127	000000		
0111	00130	000000	CRES DBP	0
	00131	000000		

MTCRCCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0112	00132	000000	DRES	DBP	0
	00133	000000			
0113	00134	000000	ERES	DBP	0
	00135	000000			
0114	00136	000000	FRES	DBP	0
	00137	000000			
0115	00140	000000	SRES	DBP	0
	00141	000000			
0116	00142	000000	ARRS	DBP	0
	00143	000000			
0117	00144	000000	BRRS	DBP	0
	00145	000000			
0118	00146	000000	CRRS	DBP	0
	00147	000000			
0119	00150	000000	DRRS	DBP	0
	00151	000000			
0120	00152	000000	ERRS	DBP	0
	00153	000000			
0121	00154	000000	FRRS	DBP	0
	00155	000000			
0122	00156	000000	SRRS	DBP	0
	00157	000000			
0123	00160	164217	GACC	DEC	-6001
0124	00161	000000	STSE	OCT	0
0125	00162	177764			END
	00163	164220			

PROGRAM NAME

SOURCE: GFIS

BINARY: BGFIS


ENTRY POINTS (location): GFIS ('2070)

ACCESSABLE VARIABLES (location): KEYG ('2225)


GENERAL DESCRIPTION:


This subroutine controls the logic for the gyro failure detection and isolation. When called (once every gyro update) it decides which failure (first or second) should be searched for using such considerations as gyro fail status and which search it made the previous time. It will then store in locations '760 and '761 the maximum allowable total squared error (MASE) for either the first (FMSE) or second (SMSE) failure search. (FMSE and SMSE are modified at the beginning of this subroutine to allow for dynamic errors. Location '774 contains a proportion of the sum of the absolute values of the total rotations about axes X, Y and Z. Adding the square of this sum to FFAD and SFAD gives the modified maximum allowable total squared errors FMSE and SMSE).

It will store in location '762 the squared error ratio for either the first fail (FFRT) or second fail (SFRT) isolation criteria (see documentation for SECA, program source name CFSE). In location '763 it will store the number of the instrument to be considered failed (see documentation for ERDE). It will then call ERDE which, in turn, calls the squared error calculator SECA (program source name CFSE). Since the gyro error accumulator (GARC) has been called prior to GFIS, SECA has the proper arguments for the instrument accumulated measurements. GFIS gives SECA the proper total allowable squared error and the proper squared error ratio. After the squared errors have been calculated and a decision of detection and/or isolation has been made, ERDE will store the decision code in location '764 and return to GFIS. GFIS will then decide what the gyro fail status should be and store the number of the gyro first and second failures in location '316 and '317 respectively. The logic of this program is shown in the following flow chart. Note that sense switch 3, if set, will prevent any failure from healing.



FLOWCHART - GFIS





MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001			REL	
0002			SUBR	GFIS
0003			SUBR	KEYG
0004	00000	0 000000	GFIS	DAC **
0005	00001	0 02 00774	LDA	'774
0006	00002	0405 75	ARS	3
0007	00003	0 04 00142	STA	ALOP
0008	00004	0 16 00142	MPY	AIOP
0009	00005	000007	DRL	
0010	00006	0 04 00142	DST	ALOP
0011	00007	0 06 00144	DAD	FFAD
0012	00010	0 04 00136	DST	FMSE
0013	00011	0 02 00142	DLD	ALOP
0014	00012	0 06 00146	DAD	SFAD
0015	00013	0 04 00140	DST	SMSE
0016	00014	000005	SGL	
0017	00015	0 02 00316	LDA	'316
0018	00016	100040	SZE	
0019	00017	0 01 00032	JMP	ALOF
0020	00020	140040	FFTR	CRA
0021	00021	0 04 00135	STA	KEYG
0022	00022	0 04 00763	STA	'763
0023	00023	0 02 00133	LDA	FFRT
0024	00024	0 04 00762	STA	'762
0025	00025	000007	DBL	
0026	00026	0 02 00136	DLD	FMSE
0027	00027	0 04 00760	DST	'760
0028	00030	000005	SGL	
0029	00031	0 01 00046	JMP	COCA
0030	00032	0 02 00135	ALOF	LDA
0031	00033	100040	SZE	KEYG
0032	00034	0 01 00020	JMP	FFTR
0033	00035	0 02 00316	LDA	'316
0034	00036	0 04 00135	STA	KEYG
0035	00037	0 04 00763	STA	'763
0036	00040	0 02 00134	LDA	SFRT
0037	00041	0 04 00762	STA	'762
0038	00042	000007	DRI	
0039	00043	0 02 00140	DLD	SMSE
0040	00044	0 04 00760	DST	'760
0041	00045	000005	SGL	
0042	00046	0 10 00000	COCA	CALL ERDE
0043	00047	0 02 00135	LDA	KEYG
0044	00050	100040	SZE	
0045	00051	0 01 00117	JMP	SFSR
0046	00052	0 02 00764	LDA	'764
0047	00053	100040	SZE	
0048	00054	0 01 00063	JMP	NOZE
0049	00055	100004	SR3	
0050	00056	-0 01 00000	JMP*	GFIS
0051	00057	140040	CRA	
0052	00060	0 04 00316	STA	'316
0053	00061	0 04 00317	STA	'317
0054	00062	-0 01 00000	JMP*	GFIS
0055	00063	0 07 00150	NOZE	SUB =7
0056	00064	101400	SMI	
0057	00065	-0 01 00000	JMP*	GFIS

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0058	00066	0 02	00764	LDA	'764
0059	00067	0 11	00316	CAS	'316
0060	00070	0 01	00072	JMP	*+2
0061	00071	-0 01	00000	JMP*	GFIS
0062	00072	0 11	00317	CAS	'317
0063	00073	0 01	00075	JMP	*+2
0064	00074	0 01	00112	JMP	SPCA
0065	00075	0 02	00316	LDA	'316
0066	00076	101040		SNZ	
0067	00077	0 01	00105	JMP	*+6
0068	00100	0 02	00317	LDA	'317
0069	00101	101040		SNZ	
0070	00102	0 01	00112	JMP	SPCA
0071	00103	100004		SR3	
0072	00104	-0 01	00000	JMP*	GFIS
0073	00105	0 02	00764	LDA	'764
0074	00106	0 04	00316	STA	'316
0075	00107	140040		CRA	
0076	00110	0 04	00317	STA	'317
0077	00111	-0 01	00000	JMP*	GFIS
0078	00112	0 02	00316	SPCA	LDA
0079	00113	0 04	00317	STA	'317
0080	00114	0 02	00764	LDA	'764
0081	00115	0 04	00316	STA	'316
0082	00116	-0 01	00000	JMP*	GFIS
0083	00117	0 02	00764	SFSR	LDA
0084	00120	0 07	00150	SUB	=7
0085	00121	101400		SMI	
0086	00122	-0 01	00000	JMP*	GFIS
0087	00123	0 02	00317	LDA	'317
0088	00124	101040		SNZ	
0089	00125	0 01	00130	JMP	*+3
0090	00126	100004		SR3	
0091	00127	-0 01	00000	JMP*	GFIS
0092	00130	0 02	00764	LDA	'764
0093	00131	0 04	00317	STA	'317
0094	00132	-0 01	00000	JMP*	GFIS
0095	00133	034343		FFRT OCT	34343
0096	00134	030600		SFR OCT	30600
0097	00135	000000		KEYG OCT	0
0098	00136	000000		FMSE DBP	0
	00137	000000			
0099	00140	000000		SMSE DBP	0
	00141	000000			
0100	00142	000000		ALOP DBP	0
	00143	000000			
0101	00144	000000		PFAD OCT	0,2200
	00145	002200			
0102	00146	000000		SFAD OCT	0,1632
	00147	001632			
0103	00150	000007		END	

PROGRAM NAME

SOURCE: ERDE

BINARY: BERDE

ENTRY POINTS (location: ERDE ('06172)

GENERAL DESCRIPTION:

This subroutine is called by either the gyro failure detection and isolation logic subroutine (GFIS) or the PIPA failure detection and isolation logic subroutine (PFIS) and in turn calls the squared error calculator (SECA, program source name CFSE). Core location '763 tells this subroutine which instrument is to be considered failed. If location '763 is zero, it means that no instrument is to be considered failed and when it calls SECA, it must indicate this with a -7 in the index register. SECA will then calculate the no fail squared error equations and return with a code in the A register which ERDE will store in core location '764 so that its calling program (either GFIS or PFIS) can use the result.


If the failure key (location '763) is a 1, 2, 3, 4, 5 or 6, it indicates that the second fail squared error equations are to be calculated considering A, B, C, D, E or F as the failed instrument. Again, ERDE will store the return from SECA in location '764 for use by GFIS or PFIS. If '763 is a 1 and instrument A is to be considered failed, MA (see description of SECA, program source name CFSE), the accumulated measurement of instrument A, must be replaced by

$$\sqrt{0.2} (MB - MC - MD + ME + MF)$$

the calculation of MA using MB, MC, MD, ME and MF. Then when SECA calculates the first fail squared error equations using the new MA and the old MB, MC, MD, ME and MF, it gets the same results it would have gotten had it used the second fail squared error equations considering A failed. Similarly, if the fail key ('763) is a 2, B is considered failed and MB must be replaced by

$$\sqrt{0.2} (MA + MC + MD + ME + MF)$$

Also, with instrument B failed, the index register must contain a -2 when SECA is called. Similar steps are taken when instruments C, D, E or F are to be considered failed. The flow chart for the subroutine ERDE follows:



FLOWCHART - ERDE

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001		REL	
0002		SUBR	ERDE
0003 00000	0 000000	ERDE	DAC **
0004 00001	0 02 00763	LDA	*763
0005 00002	100040	SZE	
0006 00003	0 01 00010	JMP	AROP
0007 00004	0 35 00331	LDX	=-7
0008 00005	0 10 00000	CALL	SECA
0009 00006	0 04 00764	STA	*764
0010 00007	-0 01 00000	JMP*	ERDE
0011 00010	0 04 00000	AROP	STA 0
0012 00011	-1 01 00011	EASE	JMP* EASE, 1
0013 00012	0 000020	DAC	AFAL
0014 00013	0 000057	DAC	BFAL
0015 00014	0 000116	DAC	CFAL
0016 00015	0 000166	DAC	DFAL
0017 00016	0 000225	DAC	EFAL
0018 00017	0 000264	DAC	FFAL
0019 00020	000007	AFAL	DBL
0020 00021	0 02 00746	LDA	MB
0021 00022	0 06 00754	ADD	ME
0022 00023	0 06 00756	ADD	MF
0023 00024	0 07 00750	SUB	MC
0024 00025	0 07 00752	SUB	MD
0025 00026	0 04 00160	STA	TEM1
0026 00027	0 16 00155	MPY	RPTT
0027 00030	0 04 00162	STA	TEM2
0028 00031	0 02 00160	LDA	TEM1
0029 00032	000201	IAB	
0030 00033	0 16 00155	MPY	RPTT
0031 00034	0 06 00164	ADD	HALF
0032 00035	000201	IAB	
0033 00036	140040	CRA	
0034 00037	0 06 00162	ADD	TEM2
0035 00040	0 04 00162	STA	TEM2
0036 00041	0 02 00160	LDA	TEM1
0037 00042	0 16 00156	MPY	RPTT+1
0038 00043	0 06 00164	ADD	HALF
0039 00044	140320	CSA	
0040 00045	000201	IAB	
0041 00046	140040	CRA	
0042 00047	100001	SRC	
0043 00050	140401	CMA	
0044 00051	0 06 00162	ADD	TEM2
0045 00052	0 04 00744	STA	MA
0046 00053	0 35 00327	LDX	=-1
0047 00054	0 10 00000	CALL	SECA
0048 00055	0 04 00764	STA	*764
0049 00056	-0 01 00000	JMP*	ERDE
0050 00057	000007	BFAL	DBL
0051 00060	0 02 00744	LDA	MA
0052 00061	0 06 00750	ADD	MC
0053 00062	0 06 00752	ADD	MD
0054 00063	0 06 00754	ADD	ME
0055 00064	0 06 00756	ADD	MF
0056 00065	0 04 00160	STA	TEM1
0057 00066	0 16 00155	MPY	RPTT

MTCROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058	00067	0 04	00162	STA	TFM2
0059	00070	0 02	00160	LDA	TEM1
0060	00071	000201		IAB	
0061	00072	0 16	00155	MPY	RPTT
0062	00073	0 06	00164	ADD	HALF
0063	00074	000201		IAB	
0064	00075	140040		CRA	
0065	00076	0 06	00162	ADD	TEM2
0066	00077	0 04	00162	STA	TEM2
0067	00100	0 02	00160	LDA	TEM1
0068	00101	0 16	00156	MPY	RPTT+1
0069	00102	0 06	00164	ADD	HALF
0070	00103	140320		CSA	
0071	00104	000201		IAB	
0072	00105	140040		CRA	
0073	00106	100001		SPC	
0074	00107	140401		CMA	
0075	00110	0 06	00162	ADD	TEM2
0076	00111	0 04	00746	STA	MB
0077	00112	0 35	00326	LDX	=-2
0078	00113	0 10	00000	CALL	SFCA
0079	00114	0 04	00764	STA	'764
0080	00115	-0 01	00000	JMP*	EPDE
0081	00116	000007	CFAL	DBL	
0082	00117	0 02	00746	LDA	MB
0083	00120	0 06	00752	ADD	MD
0084	00121	0 06	00756	ADD	MF
0085	00122	0 07	00744	SUB	MA
0086	00123	0 07	00754	SUB	MF
0087	00124	0 04	00160	STA	TEM1
0088	00125	0 16	00155	MPY	RPTT
0089	00126	0 04	00162	STA	TEM2
0090	00127	0 02	00160	LDA	TFM1
0091	00130	000201		IAB	
0092	00131	0 16	00155	MPY	RPTT
0093	00132	0 06	00164	ADD	HALF
0094	00133	000201		IAB	
0095	00134	140040		CRA	
0096	00135	0 06	00162	ADD	TEM2
0097	00136	0 04	00162	STA	TEM2
0098	00137	0 02	00160	LDA	TEM1
0099	00140	0 16	00156	MPY	RPTT+1
0100	00141	0 06	00164	ADD	HALF
0101	00142	140320		CSA	
0102	00143	000201		IAB	
0103	00144	140040		CRA	
0104	00145	100001		SPC	
0105	00146	140401		CMA	
0106	00147	0 06	00162	ADD	TEM2
0107	00150	0 04	00750	STA	MC
0108	00151	0 35	00325	LDX	=-3
0109	00152	0 10	00000	CALL	SECA
0110	00153	0 04	00764	STA	'764
0111	00154	-0 01	00000	JMP*	ERDE
0112	00155	034476	RPTT DEC	.4472135955BB0.	
	00156	022705			
0113	00160	000000	TEM1 DBP	0	

MICROCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

00161	000000			
0114	00162	000000	TEM2 DBP	0
00163	000000			
0115	00164	000000	HALF OCT	0,40000
00165	040000			
0116	00166	000007	DFAL DBL	
0117	00167	0 02 00746	LDA	MB
0118	00170	0 06 00750	ADD	MC
0119	00171	0 06 00754	ADD	MF
0120	00172	0 07 00744	SUB	MA
0121	00173	0 07 00756	SUB	MF
0122	00174	0 04 00160	STA	TEM1
0123	00175	0 16 00155	MPY	RPTT
0124	00176	0 04 00162	STA	TEM2
0125	00177	0 02 00160	LDA	TEM1
0126	00200	000201	IAB	
0127	00201	0 16 00155	MPY	RPTT
0128	00202	0 06 00164	ADD	HALF
0129	00203	000201	IAB	
0130	00204	140040	CRA	
0131	00205	0 06 00162	ADD	TEM2
0132	00206	0 04 00162	STA	TEM2
0133	00207	0 02 00160	LDA	TEM1
0134	00210	0 16 00156	MPY	RPTT+1
0135	00211	0 06 00164	ADD	HALF
0136	00212	140320	CSA	
0137	00213	000201	IAB	
0138	00214	140040	CRA	
0139	00215	100001	SRC	
0140	00216	140401	CMA	
0141	00217	0 06 00162	ADD	TEM2
0142	00220	0 04 00752	STA	MD
0143	00221	0 35 00330	LDY	=-4
0144	00222	0 10 00000	CALL	SECA
0145	00223	0 04 00764	STA	1764
0146	00224	-0 01 00000	JMP*	ERDE
0147	00225	000007	EFAL DBL	
0148	00226	0 02 00744	LDA	MA
0149	00227	0 06 00746	ADD	MB
0150	00230	0 06 00752	ADD	MD
0151	00231	0 07 00750	SUB	MC
0152	00232	0 07 00756	SUB	MF
0153	00233	0 04 00160	STA	TEM1
0154	00234	0 16 00155	MPY	RPTT
0155	00235	0 04 00162	STA	TEM2
0156	00236	0 02 00160	LDA	TEM1
0157	00237	000201	IAB	
0158	00240	0 16 00155	MPY	RPTT
0159	00241	0 06 00164	ADD	HALF
0160	00242	000201	IAB	
0161	00243	140040	CRA	
0162	00244	0 06 00162	ADD	TEM2
0163	00245	0 04 00162	STA	TEM2
0164	00246	0 02 00160	LDA	TEM1
0165	00247	0 16 00156	MPY	RPTT+1
0166	00250	0 06 00164	ADD	HALF
0167	00251	140320	CSA	

MTCR0COMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0168	00252	000201	IAB
0169	00253	140040	CRA
0170	00254	100001	SRC
0171	00255	140401	CMA
0172	00256	0 06 00162	ADD TEM2
0173	00257	0 04 00754	STA ME
0174	00260	0 35 00324	LDX ==5
0175	00261	0 10 00000	CALL SECA
0176	00262	0 04 00764	STA *764
0177	00263	-0 01 00000	JMP* ERDE
0178	00264	000007 FFAL	DBL
0179	00265	0 02 00744	LDA MA
0180	00266	0 06 00746	ADD MB
0181	00267	0 06 00750	ADD MC
0182	00270	0 07 00752	SUB MD
0183	00271	0 07 00754	SUB ME
0184	00272	0 04 00160	STA TEM1
0185	00273	0 16 00155	MPY RPTT
0186	00274	0 04 00162	STA TEM2
0187	00275	0 02 00160	LDA TEM1
0188	00276	000201	IAB
0189	00277	0 16 00155	MPY RPTT
0190	00300	0 06 00164	ADD HALF
0191	00301	000201	IAB
0192	00302	140040	CRA
0193	00303	0 06 00162	ADD TEM2
0194	00304	0 04 00162	STA TEM2
0195	00305	0 02 00160	LDA TEM1
0196	00306	0 16 00156	MPY RPTT+1
0197	00307	0 06 00164	ADD HALF
0198	00310	140320	CSA
0199	00311	000201	IAB
0200	00312	140040	CRA
0201	00313	100001	SRC
0202	00314	140401	CMA
0203	00315	0 06 00162	ADD TEM2
0204	00316	0 04 00756	STA MF
0205	00317	0 35 00323	LDX ==6
0206	00320	0 10 00000	CALL SECA
0207	00321	0 04 00764	STA *764
0208	00322	-0 01 00000	JMP* ERDE
0209		000744 MA	EQU *744
0210		000746 MB	EQU MA+2
0211		000750 MC	EQU MA+4
0212		000752 MD	EQU MA+6
0213		000754 ME	EQU MD+2
0214		000756 MF	EQU MD+4
0215	00323	177772	END
	00324	177773	
	00325	177775	
	00326	177776	
	00327	177777	
	00330	177774	
	00331	177771	

PROGRAM NAME

SOURCE: CFSE

BINARY: BCFSE

RELATED MEMOS: FAILURE ISOLATION IN SIRU (OEHRLE)

ENTRY POINTS (location): SECA ('06524)

GENERAL DESCRIPTION:

This subroutine, when called, will calculate either the first or second squared errors of instruments A-F from a set of accumulated measurements (MA - MF) stored in the base sector of the DDP 516, decide whether the total squared error is greater than some limit (also stored in the base sector) and if it is, decide if any instruments squared error exceeds a certain fraction (also stored in the base sector) of the total squared error. Then it will return with a code in the A register indicating the result of the above decisions. If during the calculations the error in any instrument exceeds or equals 2^{12} pulses (an overflow condition), or if the total squared error exceeds or equals 2^{24} pulses squared, the return code in the A register will indicate that the calculations could not be completed due to huge errors in one or more instruments.

The arguments MA - MF (see documentation for subroutines GARC + PREX) are stored in locations '744 - '757 and are six double precision numbers. If the calling program (see documentation for subroutine ERDE) wishes the squared errors calculated for the second fail detection with say instrument A failed, it will replace MA with what MB - MF calculate for MA (substituting this new MA and the old MB - MF into the first fail equations calculates the second fail squared errors for instruments B - F and therefore, eliminates writing 6 sets of second fail equations) and put a -1 in the index register. If instrument B is failed it will calculate MB from the other 5 measurements and put a -2 in the index register, etc.


The following are the return codes:

code	meaning
0	TSE (total squared error) did not exceed MASE (maximum allowable squared error stored in the base sector in location '760).
1-6	TSE0 did exceed MASE and the squared error of instrument A (for code 1) B (for code 2) etc. exceeded FONT TSE0 (FONT is the squared error ratio criteria to isolate a failure. It is .44 for a first fail isolation and .38 for a second fail isolation and is put in the base sector in location '762 by the calling program (see documentation for subroutines GFIS & PFIS).
7	TSE0 exceeded MASE but no instrument's squared error exceeded FONT TSE0
8-13	There was a huge error $\geq 2^{12}$ pulses when calculating the error of instrument A (for code of 8) B (for code of 9) etc.


14

In summing ASE0
through FSEO (A squared error
through F squared error)
to get TSE0, an
overflow occurred
(the sum was $\geq 2^{24}$
pulses squared)

The subroutine flow chart follows:



FLOWCHART - SECA



MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

			SUBR	SECA
0001			REL	
0002				
0003	00000	0 000000	SECA	DAC **
0004	00001	000007		DBL
0005	00002	0 12 00000		IRS 0
0006	00003	0 01 00012	JMP	ACAL
0007	00004	140040		CRA
0008	00005	000201		IAB
0009	00006	140040		CRA
0010	00007	0 04 00224	STA	AEO
0011	00010	0 04 00326	STA	ASEO
0012	00011	0 01 00060	JMP	BTFC
0013	00012	0 02 00750	ACAL	LDA MC
0014	00013	0 06 00752		ADD MD
0015	00014	0 07 00746		SUB MB
0016	00015	0 07 00754		SUB ME
0017	00016	0 07 00756		SUB MF
0018	00017	0 04 00216	STA	TEM1
0019	00020	0 16 00213		MPY RPTT
0020	00021	0 04 00220	STA	TEM2
0021	00022	0 02 00216	LDA	TEM1
0022	00023	000201		IAB
0023	00024	0 16 00213		MPY RPTT
0024	00025	0 06 00222	ADD	HALF
0025	00026	000201		IAB
0026	00027	140040		CRA
0027	00030	0 06 00220	ADD	TEM2
0028	00031	0 04 00220	STA	TEM2
0029	00032	0 02 00216	LDA	TEM1
0030	00033	0 16 00214		MPY RPTT+1
0031	00034	0 06 00222	ADD	HALF
0032	00035	140320		CSA
0033	00036	000201		IAB
0034	00037	140040		CRA
0035	00040	100001		SRC
0036	00041	140401		CMA
0037	00042	0 06 00220	ADD	TEM2
0038	00043	0 06 00744	ADD	MA
0039	00044	0 04 00224	STA	AEO
0040	00045	101400		SMI
0041	00046	0 01 00051	JMP	AEPO
0042	00047	0 07 00224	SUB	AEO
0043	00050	0 07 00224	SUB	AEO
0044	00051	101040	AEPO	SNZ
0045	00052	0 01 00054	JMP	SESE
0046	00053	0 01 00565	JMP	HUAE
0047	00054	000201	SESE	IAB
0048	00055	0 04 00326	STA	ASEO
0049	00056	0 16 00326		MPY ASEO
0050	00057	0 04 00326	STA	ASEO
0051	00060	0 12 00000	BTFC	IRS 0
0052	00061	0 01 00070	JMP	BCAL
0053	00062	140040		CRA
0054	00063	000201		IAB
0055	00064	140040		CRA
0056	00065	0 04 00226	STA	BEO
0057	00066	0 04 00330	STA	BSEO

MTCFOCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058	00067	0 01 00141	JMP	CTPC
0059	00070	140040	BCAL	CRA
0060	00071	000201		IAB
0061	00072	140040		CRA
0062	00073	0 07 00744	SUB	MA
0063	00074	0 07 00750	SUB	MC
0064	00075	0 07 00752	SUB	MD
0065	00076	0 07 00754	SUB	ME
0066	00077	0 07 00756	SUB	MF
0067	00100	0 04 00216	STA	TEM1
0068	00101	0 16 00213	MPY	RPTT
0069	00102	0 04 00220	STA	TEM2
0070	00103	0 02 00216	LDA	TEM1
0071	00104	000201	TAB	
0072	00105	0 16 00213	MPY	RPTT
0073	00106	0 06 00222	ADD	HALF
0074	00107	000201	IAB	
0075	00110	140040	CRA	
0076	00111	0 06 00220	ADD	TEM2
0077	00112	0 04 00220	STA	TEM2
0078	00113	0 02 00216	LDA	TEM1
0079	00114	0 16 00214	MPY	RPTT+1
0080	00115	0 06 00222	ADD	HALF
0081	00116	140320	CSA	
0082	00117	000201	TAB	
0083	00120	140040	CRA	
0084	00121	100001	SPC	
0085	00122	140401	CMA	
0086	00123	0 06 00220	ADD	TEM2
0087	00124	0 06 00746	ADD	ME
0088	00125	0 04 00226	STA	BEO
0089	00126	101400	SMI	
0090	00127	0 01 00132	JMP	BEPO
0091	00130	0 07 00226	SUB	BEO
0092	00131	0 07 00226	SUB	BEO
0093	00132	101040	BEPO	SNZ
0094	00133	0 01 00135	JMP	LTSE
0095	00134	0 01 00570	JMP	HURE
0096	00135	000201	LTSE	IAB
0097	00136	0 04 00330	STA	BSE0
0098	00137	0 16 00330	MPY	BSE0
0099	00140	0 04 00330	STA	BSE0
0100	00141	0 12 00000	CTFC	IRS
0101	00142	0 01 00151	JMP	CCAL
0102	00143	140040	CRA	
0103	00144	000201	IAB	
0104	00145	140040	CRA	
0105	00146	0 04 00230	STA	CFO
0106	00147	0 04 00332	STA	CSE0
0107	00150	0 01 00244	JMP	DTFC
0108	00151	0 02 00744	CCAL	LDA
0109	00152	0 06 00754	ADD	ME
0110	00153	0 07 00746	SUB	MB
0111	00154	0 07 00752	SUB	MD
0112	00155	0 07 00756	SUB	MF
0113	00156	0 04 00216	STA	TEM1
0114	00157	0 16 00213	MPY	RPTT

MICROCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

0115	00160	0 04 00220	STA	TEM2
0116	00161	0 02 00216	LDA	TEM1
0117	00162	000201	IAB	
0118	00163	0 16 00213	MPY	RPTT
0119	00164	0 06 00222	ADD	HALF
0120	00165	000201	IAB	
0121	00166	140040	CRA	
0122	00167	0 06 00220	ADD	TEM2
0123	00170	0 04 00220	STA	TEM2
0124	00171	0 02 00216	LDA	TEM1
0125	00172	0 16 00214	MPY	RPTT+1
0126	00173	0 06 00222	ADD	HALF
0127	00174	140320	CSA	
0128	00175	000201	IAB	
0129	00176	140040	CRA	
0130	00177	100001	SRC	
0131	00200	140401	CMA	
0132	00201	0 06 00220	ADD	TEM2
0133	00202	0 06 00750	ADD	MC
0134	00203	0 04 00230	STA	CEO
0135	00204	101400	SMI	
0136	00205	0 01 00210	JMP	CEPO
0137	00206	0 07 00230	SUB	CEO
0138	00207	0 07 00230	SUB	CEO
0139	00210	101040	CEPO	SNZ
0140	00211	0 01 00240	JMP	NBSE
0141	00212	0 01 00573	JMP	HUCE
0142	00213	034476	RPTT	DEC .4472135955BB0
	00214	022705		
0143	00216	000000	TEM1	DBP 0
	00217	000000		
0144	00220	000000	TEM2	DBP 0
	00221	000000		
0145	00222	000000	HALF	OCT 0,40000
	00223	040000		
0146	00224	000000	AEO	DBP 0
	00225	000000		
0147	00226	000000	BEO	DBP 0
	00227	000000		
0148	00230	000000	CEO	DBP 0
	00231	000000		
0149	00232	000000	DEC	DBP 0
	00233	000000		
0150	00234	000000	EEO	DBP 0
	00235	000000		
0151	00236	000000	FEO	DBP 0
	00237	000000		
0152		000326	AEO	EQU '326
0153		000330	BEO	EQU '330
0154		000332	CEO	EQU '332
0155		000436	DEO	EQU '436
0156		000440	EEO	EQU '440
0157		000442	FEO	EQU '442
0158		000574	TEO	EQU '574
0159	00240	000201	NBSE	IAB
0160	00241	0 04 00332	STA	CEO
0161	00242	0 16 00332	MPY	CEO

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0162	00243	0 04 00332	STA	CSE0
0163	00244	0 12 00000	DTPC	IRS 0
0164	00245	0 01 00254	JMP	DCAL
0165	00246	140040	CRA	
0166	00247	000201	IAB	
0167	00250	140040	CRA	
0168	00251	0 04 00232	STA	DE0
0169	00252	0 04 00436	STA	DSE0
0170	00253	0 01 00322	JMP	ETFC
0171	00254	0 02 00744	DCAL	LDA MA
0172	00255	0 06 00756	ADD	MF
0173	00256	0 07 00746	SUB	MB
0174	00257	0 07 00750	SUB	MC
0175	00260	0 07 00754	SUB	ME
0176	00261	0 04 00216	STA	TEM1
0177	00262	0 16 00213	MPY	RPTT
0178	00263	0 04 00220	STA	TEM2
0179	00264	0 02 00216	LDA	TEM1
0180	00265	000201	IAB	
0181	00266	0 16 00213	MPY	RPTT
0182	00267	0 06 00222	ADD	HALF
0183	00270	000201	TAB	
0184	00271	140040	CRA	
0185	00272	0 06 00220	ADD	TEM2
0186	00273	0 04 00220	STA	TEM2
0187	00274	0 02 00216	LDA	TEM1
0188	00275	0 16 00214	MPY	RPTT+1
0189	00276	0 06 00222	ADD	HALF
0190	00277	140320	CSA	
0191	00300	000201	IAB	
0192	00301	140040	CRA	
0193	00302	100001	SRC	
0194	00303	140401	CMA	
0195	00304	0 06 00220	ADD	TEM2
0196	00305	0 06 00752	ADD	MD
0197	00306	0 04 00232	STA	DE0
0198	00307	101400	SMT	
0199	00310	0 01 00313	JMP	DEPO
0200	00311	0 07 00232	SUB	DE0
0201	00312	0 07 00232	SUB	DE0
0202	00313	101040	DEPO	SNZ
0203	00314	0 01 00316	JMP	RSSE
0204	00315	0 01 00576	JMP	HUDE
0205	00316	000201	RSSE	IAB
0206	00317	0 04 00436	STA	DSE0
0207	00320	0 16 00436	MPY	DSE0
0208	00321	0 04 00436	STA	DSE0
0209	00322	0 12 00000	ETFC	IRS 0
0210	00323	0 01 00332	JMP	ECAL
0211	00324	140040	CRA	
0212	00325	000201	TAB	
0213	00326	140040	CRA	
0214	00327	0 04 00234	STA	EFO
0215	00330	0 04 00440	STA	ESE0
0216	00331	0 01 00400	JMP	FTFC
0217	00332	0 02 00750	ECAL	LDA MC
0218	00333	0 06 00756	ADD	MF

MICPOCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0219 00334	0 07 00744	SUB	MA
0220 00335	0 07 00746	SUB	MB
0221 00336	0 07 00752	SUB	MD
0222 00337	0 04 00216	STA	TEM1
0223 00340	0 16 00213	MPY	RPTT
0224 00341	0 04 00220	STA	TEM2
0225 00342	0 02 00216	LDA	TEM1
0226 00343	000201	IAB	
0227 00344	0 16 00213	MPY	RPTT
0228 00345	0 06 00222	ADD	HALF
0229 00346	000201	IAB	
0230 00347	140040	CRA	
0231 00350	0 06 00220	ADD	TEM2
0232 00351	0 04 00220	STA	TEM2
0233 00352	0 02 00216	LDA	TEM1
0234 00353	0 16 00214	MPY	RPTT+1
0235 00354	0 06 00222	ADD	HALF
0236 00355	140320	CSA	
0237 00356	000201	IAB	
0238 00357	140040	CRA	
0239 00360	100001	SRC	
0240 00361	140401	CMA	
0241 00362	0 06 00220	ADD	TEM2
0242 00363	0 06 00754	ADD	ME
0243 00364	0 04 00234	STA	EEO
0244 00365	101400	SMI	
0245 00366	0 01 00371	JMP	EEPO
0246 00367	0 07 00234	SUB	EEO
0247 00370	0 07 00234	SUB	EEO
0248 00371	101040	EEPO	SNZ
0249 00372	0 01 00374	JMP	LESE
0250 00373	0 01 00601	JMP	HUEE
0251 00374	000201	LESE	IAB
0252 00375	0 04 00440	STA	ESEO
0253 00376	0 16 00440	MPY	ESEO
0254 00377	0 04 00440	STA	ESEO
0255 00400	0 12 00000	FTFC	IRS
0256 00401	0 01 00410	JMP	FCAL
0257 00402	140040	CRA	
0258 00403	000201	IAB	
0259 00404	140040	CRA	
0260 00405	0 04 00236	STA	FEO
0261 00406	0 04 00442	STA	FSEO
0262 00407	0 01 00456	JMP	NTFC
0263 00410	0 02 00752	FCAL	LDA
0264 00411	0 06 00754	ADD	ME
0265 00412	0 07 00744	SUB	MA
0266 00413	0 07 00746	SUB	MB
0267 00414	0 07 00750	SUB	MC
0268 00415	0 04 00216	STA	TEM1
0269 00416	0 16 00213	MPY	RPTT
0270 00417	0 04 00220	STA	TEM2
0271 00420	0 02 00216	LDA	TEM1
0272 00421	000201	IAB	
0273 00422	0 16 00213	MPY	RPTT
0274 00423	0 06 00222	ADD	HALF
0275 00424	000201	IAB	

MICROCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

0276	00425	140040	CRA	
0277	00426	0 06 00220	ADD	TEM2
0278	00427	0 04 00220	STA	TEM2
0279	00430	0 02 00216	LDA	TEM1
0280	00431	0 16 00214	MPY	RPTT+1
0281	00432	0 06 00222	ADD	HALF
0282	00433	140320	CSA	
0283	00434	000201	IAB	
0284	00435	140040	CRA	
0285	00436	100001	SRC	
0286	00437	140401	CMA	
0287	00440	0 06 00220	ADD	TEM2
0288	00441	0 06 00756	ADD	MF
0289	00442	0 04 00236	STA	FEO
0290	00443	101400	SMI	
0291	00444	0 01 00447	JMP	FEPO
0292	00445	0 07 00236	SUB	FEO
0293	00446	0 07 00236	SUB	FEO
0294	00447	101040	FEPO	SNZ
0295	00450	0 01 00452	JMP	VMSE
0296	00451	0 01 00604	JMP	HUFE
0297	00452	000201	VMSE	IAB
0298	00453	0 04 00442	STA	FSEO
0299	00454	0 16 00442	MPY	FSEO
0300	00455	0 04 00442	STA	FSEO
0301	00456	0 06 00326	NTFC	ADD
0302	00457	100001	SRC	ASEO
0303	00460	0 01 00562	JMP	OVFL
0304	00461	0 06 00330	ADD	BSEO
0305	00462	100001	SRC	
0306	00463	0 01 00562	JMP	OVFL
0307	00464	0 06 00332	ADD	CSEO
0308	00465	100001	SRC	
0309	00466	0 01 00562	JMP	OVFL
0310	00467	0 06 00436	ADD	DSFO
0311	00470	100001	SRC	
0312	00471	0 01 00562	JMP	OVFL
0313	00472	0 06 00440	ADD	ESEO
0314	00473	100001	SRC	
0315	00474	0 01 00562	JMP	OVFL
0316	00475	0 04 00574	STA	TSEO
0317	00476	0 07 00760	SUB	MASE
0318	00477	100400	SPL	
0319	00500	0 01 00557	JMP	ZRTU
0320	00501	0 02 00574	LDA	TSEO
0321	00502	0 16 00762	MPY	FONT
0322	00503	0 04 00220	STA	TEM2
0323	00504	0 02 00574	LDA	TSEO
0324	00505	000201	TAB	
0325	00506	0 16 00762	MPY	FONT
0326	00507	000201	IAB	
0327	00510	140040	CRA	
0328	00511	0 06 00220	ADD	TEM2
0329	00512	0 04 00220	STA	TEM2
0330	00513	0 35 00617	LDX	=1
0331	00514	0 02 00326	LDA	ASEO
0332	00515	0 07 00220	SUB	TEM2

MICROCOMP TELRCOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0333	00516	101400	SMI	
0334	00517	0 01 00554	JMP	FOND
0335	00520	0 12 00000	IRS	0
0336	00521	0 .02 00330	LDA	BSE0
0337	00522	0 07 00220	SUB	TEM2
0338	00523	101400	SMI	
0339	00524	0 01 00554	JMP	FOND
0340	00525	0 12 00000	IRS	0
0341	00526	0 02 00332	LDA	CSE0
0342	00527	0 07 00220	SUB	TEM2
0343	00530	101400	SMI	
0344	00531	0 01 00554	JMP	FOND
0345	00532	0 12 00000	IRS	0
0346	00533	0 02 00436	LDA	DSE0
0347	00534	0 07 00220	SUB	TEM2
0348	00535	101400	SMI	
0349	00536	0 01 00554	JMP	FOND
0350	00537	0 12 00000	IRS	0
0351	00540	0 02 00440	LDA	ESE0
0352	00541	0 07 00220	SUB	TEM2
0353	00542	101400	SMI	
0354	00543	0 01 00554	JMP	FOND
0355	00544	0 12 00000	IRS	0
0356	00545	0 02 00442	LDA	FSE0
0357	00546	0 07 00220	SUB	TEM2
0358	00547	101400	SMI	
0359	00550	0 01 00554	JMP	FOND
0360	00551	000005	SGL	
0361	00552	0 02 00616	LDA	=7
0362	00553	-0 01 00000	JMP*	SECA
0363	00554	000005	FOND	SGL
0364	00555	0 02 00000	LDA	0
0365	00556	-0 01 00000	JMP*	SECA
0366	00557	000005	ZPTU	SGL
0367	00560	140040	CRA	
0368	00561	-0 01 00000	JMP*	SECA
0369	00562	000005	OVFL	SGL
0370	00563	0 02 00615	LDA	=14
0371	00564	-0 01 00000	JMP*	SECA
0372	00565	000005	HUAE	SGL
0373	00566	0 02 00614	LDA	=8
0374	00567	-0 01 00000	JMP*	SECA
0375	00570	000005	HUBE	SGL
0376	00571	0 02 00613	LDA	=9
0377	00572	-0 01 00000	JMP*	SECA
0378	00573	000005	HUCE	SGL
0379	00574	0 02 00612	LDA	=10
0380	00575	-0 01 00000	JMP*	SECA
0381	00576	000005	HUDE	SGL
0382	00577	0 02 00611	LDA	=11
0383	00600	-0 01 00000	JMP*	SECA
0384	00601	000005	HUEE	SGL
0385	00602	0 02 00610	LDA	=12
0386	00603	-0 01 00000	JMP*	SECA
0387	00604	000005	HUFE	SGL
0388	00605	0 02 00607	LDA	=13
0389	00606	-0 01 00000	JMP*	SECA

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0390	000762	FONT EQU	'762
0391	000744	MA EQU	'744
0392	000746	ME EQU	MA+2
0393	000750	MC EQU	MA+4
0394	000752	MD EQU	MA+6
0395	000754	ME EQU	MD+2
0396	000756	MF EQU	MD+4
0397	000760	MASE EQU	'760
0398	00607	000015	END
	00610	000014	
	00611	000013	
	00612	000012	
	00613	000011	
	00614	000010	
	00615	000016	
	00616	000007	
	00617	000001	

PROGRAM NAME

SOURCE: PFIS

BINARY: BPFIS

ENTRY POINTS (location): PFIS ('04725)

ACCESSIBLE VARIABLES (location): KEYP ('05050)

GENERAL DESCRIPTION:

This subroutine controls the logic for the PIPA failure detection and isolation. It is identical to the subroutine GFIS, which controls the gyro failure detection and isolation, except that the PIPA fail status is contained in location '320 and '321 instead of '316 and '317 and that the PIPA maximum allowable squared errors (FMSE and SMSE) are not modified at the beginning of this subroutine as are the gyro's at the beginning of GFIS. So see documentation for the subroutine GFIS.

MICPOCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001			REL	
0002			SUBR	PFIS
0003			SUBR	KEYP
0004	00000	0 000000	PFIS	DAC **
0005	00001	0 02 00320	LDA	*320
0006	00002	100040	SZE	
0007	00003	0 01 00016	JMP	ALOF
0008	00004	140040	FFTR	CRA
0009	00005	0 04 00122	STA	KEYP
0010	00006	0 04 00763	STA	*763
0011	00007	0 02 00117	LDA	FFRT
0012	00010	0 04 00762	STA	*762
0013	00011	000007	DBL	
0014	00012	0 02 00124	DLD	FMSE
0015	00013	0 04 00760	DST	*760
0016	00014	000005	SGL	
0017	00015	0 01 00032	JMP	COCA
0018	00016	0 02 00122	ALOF	LDA KEYP
0019	00017	100040	SZE	
0020	00020	0 01 00004	JMP	FFTR
0021	00021	0 02 00320	LDA	*320
0022	00022	0 04 00122	STA	KEYP
0023	00023	0 04 00763	STA	*763
0024	00024	0 02 00120	LDA	SPRT
0025	00025	0 04 00762	STA	*762
0026	00026	000007	DBL	
0027	00027	0 02 00126	DLD	SMSE
0028	00030	0 04 00760	DST	*760
0029	00031	000005	SGL	
0030	00032	0 10 00000	COCA	CALL ERDE
0031	00033	0 02 00122	LDA	KEYP
0032	00034	100040	SZE	
0033	00035	0 01 00103	JMP	SFSR
0034	00036	0 02 00764	LDA	*764
0035	00037	100040	SZE	
0036	00040	0 01 00047	JMP	NOZE
0037	00041	100004	SR3	
0038	00042	-0 01 00000	JMP*	PFIS
0039	00043	140040	CRA	
0040	00044	0 04 00320	STA	*320
0041	00045	0 04 00321	STA	*321
0042	00046	-0 01 00000	JMP*	PFIS
0043	00047	0 07 00130	NOZE	SUB =7
0044	00050	101400	SMI	
0045	00051	-0 01 00000	JMP*	PFIS
0046	00052	0 02 00764	LDA	*764
0047	00053	0 11 00320	CAS	*320
0048	00054	0 01 00056	JMP	*+2
0049	00055	-0 01 00000	JMP*	PFIS
0050	00056	0 11 00321	CAS	*321
0051	00057	0 01 00061	JMP	*+2
0052	00060	0 01 00076	JMP	SPCA
0053	00061	0 02 00320	LDA	*320
0054	00062	101040	SNZ	
0055	00063	0 01 00071	JMP	*+6
0056	00064	0 02 00321	LDA	*321
0057	00065	101040	SNZ	

MICROCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

0058	00066	0 01 00076	JMP	SPCA
0059	00067	100004	SR3	
0060	00070	-0 01 00000	JMP*	PFIS
0061	00071	0 02 00764	LDA	'764
0062	00072	0 04 00320	STA	'320
0063	00073	140040	CRA	
0064	00074	0 04 00321	STA	'321
0065	00075	-0 01 00000	JMP*	PFIS
0066	00076	0 02 00320	SPCA	LDA
0067	00077	0 04 00321	STA	'320
0068	00100	0 02 00764	LDA	'764
0069	00101	0 04 00320	STA	'320
0070	00102	-0 01 00000	JMP*	PFIS
0071	00103	0 02 00764	SFSR	LDA
0072	00104	0 07 00130	SUB	=7
0073	00105	101400	SMI	
0074	00106	-0 01 00000	JMP*	PPIS
0075	00107	0 02 00321	LDA	'321
0076	00110	101040	SNZ	
0077	00111	0 01 00114	JMP	*+3
0078	00112	100004	SR3	
0079	00113	-0 01 00000	JMP*	PFIS
0080	00114	0 02 00764	LDA	'764
0081	00115	0 04 00321	STA	'321
0082	00116	-0 01 00000	JMP*	PFIS
0083	00117	034343	FFRT	OCT
0084	00120	030600	SFR	OCT
0085	00122	000000	KEYP	DBP
	00123	000000		0
0086	00124	000000	FMSE	OCT
	00125	020000		0,20000
0087	00126	000000	SMSE	OCT
	00127	014632		0,14632
0088	00130	000007		END

PROGRAM NAME

SOURCE: GPRT

BINARY: BGPRT

ENTRY POINT (location): GPRT ('12712)

GENERAL DESCRIPTION:

This subroutine, when called, will in turn call PRTY to solve for the gyro parity equation if there are already 2 gyro failures. If the appropriate parity equation indicates an overflow or exceeds a certain limit it will store a 1 in octal location 322. Otherwise, octal location 322 will stay zero. The limit the equation must exceed (GMSE) is three pulses (GBSE = OCT 0, 30) plus some appropriate fraction of the

$$\sum |\Delta\theta_x| + |\Delta\theta_y| + |\Delta\theta_z|$$

which is stored in '774 by the gyro error accumulator GARC and allows for dynamic errors. This limit is calculated by the first four instructions of this subroutine.

GPRT will then set ('322) to zero and determine if there are 2 gyro failures (the gyro first and second fails are stored in octal locations 316 and 317). If there are not 2 failures, it will return. Otherwise, it calculates in the A register the code necessary to tell PRTY which parity equation to calculate. The codes are:

<u>Parity Equation</u>	<u>2 failures</u>	<u>code</u>
CDEF	A, B	0
BDEF	A, C	7
BCEF	A, D	14
BCDF	A, E	21
BCDE	A, F	28
ADEF	B, C	35
ACEF	B, D	42
ACDF	B, E	49
ACDE	B, F	56
ABEF	C, D	63
ABDF	C, E	70
ABDE	C, F	77
ABC F	D, E	84
ABCE	D, F	91
ABCD	E, F	98

The general method for calculating the code is the same as that used by GMIN for the gyro matrix generator. When PRTY returns, GPRT determines if the parity equation either exceeds its limit or has overflowed. In either case, it will indicate so by changing octal location 322 to a 1 before returning.

MICROCOMP' TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

		SUBR	GPRT
0001		REL	
0002		DAC	**
0003	00000	0 000000	GPRT
0004	00001	0 02 00774	LDA
0005	00002	0405 75	ARS
0006	00003	0 06 00053	ADD
0007	00004	0 04 00051	STA
0008	00005	140040	CRA
0009	00006	0 04 00322	STA
0010	00007	0 02 00317	LDA
0011	00010	101040	SNZ
0012	00011	-0 01 00000	JMP*
0013	00012	0 11 00316	CAS
0014	00013	0 01 00024	JMP
0015	00014	101000	SFLA
0016	00015	0 06 00045	NOP
0017	00016	0 04 00046	ADD
0018	00017	0 02 00316	ADST
0019	00020	0415 75	STA
0020	00021	0 07 00316	IDPT
0021	00022	-0 06 00046	LDA
0022	00023	0 01 00033	'316
0023	00024	0 02 00316	SPLA
0024	00025	0 06 00045	LDA
0025	00026	0 04 00046	ADD
0026	00027	0 02 00317	ADST
0027	00028	0415 75	STA
0028	00029	0 07 00317	IDPT
0029	00030	-0 06 00046	LDA
0030	00031	0 10 00000	'316
0031	00032	PRCL	CALL
0032	00033	101000	PRTY
0033	00034	000400	NOP
0034	00035	00036	SPL
0035	00036	0 01 00042	OVRF
0036	00037	000007	DBL
0037	00038	0 07 00050	DSB
0038	00039	101400	GMSE
0039	00040	0 12 00322	SMI
0040	00041	00042	OVRF
0041	00043	00005	IRS
0042	00044	-0 01 00000	'322
0043	00045	0 000054	JMP*
0044	00046	000000	GPRT
0045	00047	000000	ADST
0046	00048	000000	DAC
0047	00049	000000	CRPS
0048	00050	000000	0
0049	00051	000030	IDPT
0050	00052	000000	DBP
0051	00053	000030	0
0052	00054	000000	0,30
0053	00055	000000	GMSE
0054	00056	177762	OCT
0055	00057	000016	0,30
0056	00058	000043	GBSE
0057	00059	000061	OCT
0058	00060	000070	0,30
0059	00061	000000	CRPS
0060	00062	0,177762,16,43,61,70	OCT
0061	00063		
0062	00064		
0063	00065		
0064	00066		
0065	00067		
0066	00068		
0067	00069		
0068	00070		
0069	00071		
0070	00072		
0071	00073		
0072	00074		
0073	00075		
0074	00076		
0075	00077		
0076	00078		
0077	00079		
0078	00080		
0079	00081		
0080	00082		
0081	00083		
0082	00084		
0083	00085		
0084	00086		
0085	00087		
0086	00088		
0087	00089		
0088	00090		
0089	00091		
0090	00092		
0091	00093		
0092	00094		
0093	00095		
0094	00096		
0095	00097		
0096	00098		
0097	00099		
0098	00100		
0099	00101		
0100	00102		
0101	00103		
0102	00104		
0103	00105		
0104	00106		
0105	00107		
0106	00108		
0107	00109		
0108	00110		
0109	00111		
0110	00112		
0111	00113		
0112	00114		
0113	00115		
0114	00116		
0115	00117		
0116	00118		
0117	00119		
0118	00120		
0119	00121		
0120	00122		
0121	00123		
0122	00124		
0123	00125		
0124	00126		
0125	00127		
0126	00128		
0127	00129		
0128	00130		
0129	00131		
0130	00132		
0131	00133		
0132	00134		
0133	00135		
0134	00136		
0135	00137		
0136	00138		
0137	00139		
0138	00140		
0139	00141		
0140	00142		
0141	00143		
0142	00144		
0143	00145		
0144	00146		
0145	00147		
0146	00148		
0147	00149		
0148	00150		
0149	00151		
0150	00152		
0151	00153		
0152	00154		
0153	00155		
0154	00156		
0155	00157		
0156	00158		
0157	00159		
0158	00160		
0159	00161		
0160	00162		
0161	00163		
0162	00164		
0163	00165		
0164	00166		
0165	00167		
0166	00168		
0167	00169		
0168	00170		
0169	00171		
0170	00172		
0171	00173		
0172	00174		
0173	00175		
0174	00176		
0175	00177		
0176	00178		
0177	00179		
0178	00180		
0179	00181		
0180	00182		
0181	00183		
0182	00184		
0183	00185		
0184	00186		
0185	00187		
0186	00188		
0187	00189		
0188	00190		
0189	00191		
0190	00192		
0191	00193		
0192	00194		
0193	00195		
0194	00196		
0195	00197		
0196	00198		
0197	00199		
0198	00200		
0199	00201		
0200	00202		
0201	00203		
0202	00204		
0203	00205		
0204	00206		
0205	00207		
0206	00208		
0207	00209		
0208	00210		
0209	00211		
0210	00212		
0211	00213		
0212	00214		
0213	00215		
0214	00216		
0215	00217		
0216	00218		
0217	00219		
0218	00220		
0219	00221		
0220	00222		
0221	00223		
0222	00224		
0223	00225		
0224	00226		
0225	00227		
0226	00228		
0227	00229		
0228	00230		
0229	00231		
0230	00232		
0231	00233		
0232	00234		
0233	00235		
0234	00236		
0235	00237		
0236	00238		
0237	00239		
0238	00240		
0239	00241		
0240	00242		
0241	00243		
0242	00244		
0243	00245		
0244	00246		
0245	00247		
0246	00248		
0247	00249		
0248	00250		
0249	00251		
0250	00252		
0251	00253		
0252	00254		
0253	00255		
0254	00256		
0255	00257		
0256	00258		
0257	00259		
0258	00260		
0259	00261		
0260	00262		
0261	00263		
0262	00264		
0263	00265		
0264	00266		
0265	00267		
0266	00268		
0267	00269		
0268	00270		
0269	00271		
0270	00272		
0271	00273		
0272	00274		
0273	00275		
0274	00276		
0275	00277		
0276	00278		
0277	00279		
0278	00280		
0279	00281		
0280	00282		
0281	00283		
0282	00284		
0283	00285		
0284	00286		
0285	00287		
0286	00288		
0287	00289		
0288	00290		
0289	00291		
0290	00292		
0291	00293		
0292	00294		
0293	00295		
0294	00296		
0295	00297		
0296	00298		
0297	00299		
0298	00300		
0299	00301		
0300	00302		
0301	00303		
0302	00304		
0303	00305		
0304	00306		
0305	00307		
0306	00308		
0307	00309		
0308	00310		
0309	00311		
0310	00312		
0311	00313		
0312	00314		
0313	00315		
0314	00316		
0315	00317		
0316	00318		
0317	00319		
0318	00320		
0319	00321		
0320	00322		
0321	00323		
0322	00324		
0323	00325		
0324	00326		
0325	00327		
0326	00328		
0327	00329		
0328	00330		
0329	00331		
0330	00332		
0331	00333		
0332	00334		
0333	00335		
0334	00336		
0335	00337		
0336	00338		
0337	00339		
0338	00340		
0339	00341		
0340	00342		
0341	00343		
0342	00344		
0343	00345		
0344	00346		
0345	00347		
0346	00348		
0347	00349		
0348	00350		
0349	00351		
0350</td			

PROGRAM NAME:

SOURCE: PRTY

BINARY: BPRTY

ENTRY POINTS (location): PRTY ('12774)

GENERAL DESCRIPTION:

This subroutine calculates the parity equation used to detect third failures from the arguments stored in locations '744 - '757 by the gyro or PIPA error accumulators. It is called by GPRT if and when the gyro fail status indicates 2 failures and by PPRT (program source name PPEX) if and when the PIPA fail status indicates 2 failures. When called the A register contains a code to tell which of the fifteen parity equations to calculate (see documentation for GPRT). For example, if instruments C and F were failed, the code would be 77 (octal 115) and the JMP* PONT, the fifth instruction in PRTY would effect a jump to the block of code: (note, at this point the (A, B) register contains a double precision zero).

DSB	MB
DSB	ME
DST	SINT
DLD	MA
DAD	MD
DST	COST
JMP	CALC

SINT is the sine term of the parity equation = - MB - ME. COST is the cosine term of the parity equation = MA + MD. Each of the 15 parity equations has a block of code (7 instructions each) similar to the block above. The jump to CALC will start a sequence of instructions which will multiply SINT by SINE = sine α and COST by COSN = cosine α and then add the two results and take the absolute value. If the high order word of this double precision result is zero (which indicates that the absolute value of the parity equation is less than 2^{15} or 2^{12} instrument pulses), this subroutine will return with the parity equation result in the (A, B) register. If the high order word is not zero, (A, B) will contain a double precision -1 at the return.

MTCROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

		SUBR	PRTY
0001		REL	
0002			
0003	00000	0 000000	PRTY DAC **
0004	00001	0 06 00252	ADD ADAB
0005	00002	0 04 00253	STA PONT
0006	00003	000007	DBL
0007	00004	0 02 00232	DLD DZRO
0008	00005	-0 01 00253	JMP* PONT
0009	00006	0 02 00752	ABFA DLD MD
0010	00007	0 07 00750	DSB MC
0011	00010	0 04 00236	DST COST
0012	00011	0 02 00756	DLD MF
0013	00012	0 07 00754	DSB ME
0014	00013	0 04 00234	DST SINT
0015	00014	0 01 00156	JMP CALC
0016	00015	0 02 00752	DLD MD
0017	00016	0 06 00754	DAD ME
0018	00017	0 04 00234	DST SINT
0019	00020	0 02 00756	DLD MF
0020	00021	0 07 00746	DSB MB
0021	00022	0 04 00236	DST COST
0022	00023	0 01 00156	JMP CALC
0023	00024	0 02 00750	DLD MC
0024	00025	0 06 00756	DAD MF
0025	00026	0 04 00234	DST SINT
0026	00027	0 02 00754	DLD ME
0027	00030	0 07 00746	DSB MB
0028	00031	0 04 00236	DST COST
0029	00032	0 01 00156	JMP CALC
0030	00033	0 07 00746	DSB MB
0031	00034	0 07 00750	DSB MC
0032	00035	0 04 00234	DST SINT
0033	00036	0 02 00752	DLD MD
0034	00037	0 06 00756	DAD MF
0035	00040	0 04 00236	DST COST
0036	00041	0 01 00156	JMP CALC
0037	00042	0 07 00746	DSB MB
0038	00043	0 07 00752	DSB MD
0039	00044	0 04 00234	DST SINT
0040	00045	0 02 00750	DLD MC
0041	00046	0 06 00754	DAD ME
0042	00047	0 04 00236	DST COST
0043	00050	0 01 00156	JMP CALC
0044	00051	0 02 00754	DLD ME
0045	00052	0 07 00744	DSB MA
0046	00053	0 04 00236	DST COST
0047	00054	0 02 00756	DLD MF
0048	00055	0 07 00752	DSB MD
0049	00056	0 04 00234	DST SINT
0050	00057	0 01 00156	JMP CALC
0051	00060	0 02 00744	DLD MA
0052	00061	0 07 00756	DSB MF
0053	00062	0 04 00236	DST COST
0054	00063	0 02 00750	DLD MC
0055	00064	0 07 00754	DSB ME
0056	00065	0 04 00234	DST SINT
0057	00066	0 01 00156	JMP CALC

MICROCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

0058	00067	0 02 00744	DLD	MA
0059	00070	0 07 00752	DSB	MD
0060	00071	0 04 00234	DST	SINT
0061	00072	0 02 00750	DLD	MC
0062	00073	0 07 00756	DSB	MF
0063	00074	0 04 00236	DST	COST
0064	00075	0 01 00156	JMP	CALC
0065	00076	0 02 00744	DLD	MA
0066	00077	0 07 00750	DSB	MC
0067	00100	0 04 00234	DST	SINT
0068	00101	0 02 00752	DLD	MD
0069	00102	0 07 00754	DSB	ME
0070	00103	0 04 00236	DST	COST
0071	00104	0 01 00156	JMP	CALC
0072	00105	0 07 00744	DSB	MA
0073	00106	0 07 00746	DSB	MB
0074	00107	0 04 00234	DST	SINT
0075	00110	0 02 00754	DLD	ME
0076	00111	0 06 00756	DAD	MF
0077	00112	0 04 00236	DST	COST
0078	00113	0 01 00156	JMP	CALC
0079	00114	0 02 00744	DLD	MA
0080	00115	0 06 00756	DAD	MF
0081	00116	0 04 00234	DST	SINT
0082	00117	0 02 00752	DLD	MD
0083	00120	0 07 00746	DSB	MB
0084	00121	0 04 00236	DST	COST
0085	00122	0 01 00156	JMP	CALC
0086	00123	0 07 00746	DSB	MB
0087	00124	0 07 00754	DSB	ME
0088	00125	0 04 00234	DST	SINT
0089	00126	0 02 00744	DLD	MA
0090	00127	0 06 00752	DAD	MD
0091	00130	0 04 00236	DST	COST
0092	00131	0 01 00156	JMP	CALC
0093	00132	0 07 00746	DSB	MF
0094	00133	0 07 00756	DSB	MF
0095	00134	0 04 00234	DST	SINT
0096	00135	0 02 00744	DLD	MA
0097	00136	0 06 00750	DAD	MC
0098	00137	0 04 00236	DST	COST
0099	00140	0 01 00156	JMP	CALC
0100	00141	0 02 00744	DLD	MA
0101	00142	0 06 00754	DAD	ME
0102	00143	0 04 00234	DST	SINT
0103	00144	0 02 00750	DLD	MC
0104	00145	0 07 00746	DSB	MB
0105	00146	0 04 00236	DST	COST
0106	00147	0 01 00156	JMP	CALC
0107	00150	0 02 00744	DLD	MA
0108	00151	0 07 00746	DSB	MB
0109	00152	0 04 00236	DST	COST
0110	00153	0 02 00750	DLD	MC
0111	00154	0 06 00752	DAD	MD
0112	00155	0 04 00234	DST	SINT
0113	00156	0 02 00234	CALC	DLD
0114	00157	0 16 00245	MPY	SINE+1

MTCROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0115	00160	0401 77	LRS	1
0116	00161	0 04 00240	DST	TEM1
0117	00162	0 02 00244	DLD	SINE
0118	00163	0 16 00235	MPY	SINT+1
0119	00164	0401 77	LRS	1
0120	00165	0 06 00240	DAD	TEM1
0121	00166	0 06 00250	DAD	HALF
0122	00167	0401 62	LRS	14
0123	00170	0 04 00240	DST	TEM1
0124	00171	0 02 00234	DLD	SINT
0125	00172	0 16 00244	MPY	SINE
0126	00173	0 06 00240	DAD	TEM1
0127	00174	0 04 00234	DST	SINT
0128	00175	0 02 00236	DLD	COST
0129	00176	0 16 00247	MPY	COSN+1
0130	00177	0401 77	LRS	1
0131	00200	0 04 00240	DST	TEM1
0132	00201	0 02 00246	DLD	COSN
0133	00202	0 16 00237	MPY	COST+1
0134	00203	0401 77	LRS	1
0135	00204	0 06 00240	DAD	TEM1
0136	00205	0 06 00250	DAD	HALF
0137	00206	0401 62	LRS	14
0138	00207	0 04 00240	DST	TEM1
0139	00210	0 02 00236	DLD	COST
0140	00211	0 16 00246	MPY	COSN
0141	00212	0 06 00240	DAD	TEM1
0142	00213	0 06 00234	DAD	SINT
0143	00214	0 04 00236	DST	COST
0144	00215	101400	SMI	
0145	00216	0 01 00222	JMP	*+4
0146	00217	0 07 00236	DSB	COST
0147	00220	0 07 00236	DSB	COST
0148	00221	0 04 00236	DST	COST
0149	00222	100040	SZE	
0150	00223	0 01 00226	JMP	HUER
0151	00224	000005	SGL	
0152	00225	-0 01 00000	JMP*	PRTY
0153	00226	0 02 00242	HUER	DLD
0154	00227	000005	SGL	
0155	00230	-0 01 00000	JMP*	PRTY
0156		000744	MA	EQU '744
0157		000746	MB	EQU MA+2
0158		000750	MC	EQU MA+4
0159		000752	MD	EQU MA+6
0160		000754	ME	EQU MA+8
0161		000756	MF	EQU MA+10
0162	00232	000000	DZRO	DBP 0
	00233	000000		
0163	00234	000000	SINT	DBP 0
	00235	000000		
0164	00236	000000	COST	DBP 0
	00237	000000		
0165	00240	000000	TEM1	DBP 0
	00241	000000		
0166	00242	177777	NEG1	OCT 177777,77777
	00243	077777		

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0167	00244	041513	SINE OCT	41513,12033
	00245	012033		
0168	00246	066342	COSN OCT	66342,10027
	00247	010027		
0169	00250	000000	HALF OCT	0,20000
	00251	020000		
0170	00252	0 000006	ADAB DAC	ABFA
0171	00253	000000	PONT OCT	0
0172			END	

PROGRAM NAME

SOURCE: PPEX

BINARY: BPPEX

ENTRY POINT (location): PPRT ('12360)

GENERAL DESCRIPTION:

This subroutine determines PIPA third failures in a similar way to the way GPRT determines gyro third failures. However, it does not allow for dynamic errors as does GPRT and will not do its parity equation calculation if octal location 765 is set to 1. This would indicate that on this update the PIPA error accumulator (program source name PREX, subroutine entry point PARC) is purging its accumulation. The timing considerations are so stringent that at times, doing both jobs would be impossible. Other than the above considerations, look to GPRT for documentation of the methods used.

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

		SUBR	PPRT
0001		REL	
0002		DAC	**
0003	00000	0 000000	PPRT
0004	00001	0 02 00765	LDA
0005	00002	101040	SNZ
0006	00003	0 01 00007	JMP
0007	00004	140040	CRA
0008	00005	0 04 00765	STA
0009	00006	-0 01 00000	JMP*
0010	00007	140040	GOAH
0011	00010	0 04 00323	CRA
0012	00011	0 02 00321	STA
0013	00012	101040	SNZ
0014	00013	-0 01 00000	JMP*
0015	00014	0 11 00320	CAS
0016	00015	0 01 00026	JMP
0017	00016	101000	SFLA
0018	00017	0 06 00047	NOP
0019	00020	0 04 00050	ADD
0020	00021	0 02 00320	IDPT
0021	00022	0415 75	LDA
0022	00023	0 07 00320	ALS
0023	00024	-0 06 00050	SUB
0024	00025	0 01 00035	ADD*
0025	00026	0 02 00320	IDPT
0026	00027	0 06 00047	SFLA
0027	00028	0 04 00050	LDA
0028	00031	0 02 00321	ADD
0029	00032	0415 75	IDPT
0030	00033	0 07 00321	PRCL
0031	00034	-0 06 00050	CALL
0032	00035	0 10 00000	PRTY
0033	00036	101000	NOP
0034	00037	100400	SPL
0035	00040	0 01 00044	JMP
0036	00041	000007	OVRF
0037	00042	0 07 00052	DBL
0038	00043	101400	DSB
0039	00044	0 12 00323	PMSE
0040	00045	000005	SMI
0041	00046	-0 01 00000	OVRF
0042	00047	0 000054	IRS
0043	00050	000000	SGL
0044	00051	000000	JMP*
0045	00052	000000	PPRT
0046	00053	000040	ADST
0047	00054	000000	DAC
0048	00055	177762	CRPS
0049	00056	000016	OCT
0050	00057	000043	0
0051	00058	000061	PMSE
0052	00059	000070	OCT
0053	00060	0,177762,16,43,61,70	END

PROGRAM NAME

SOURCE: GMIN

BINARY: BGMIN


ENTRY POINTS (location): GMIN ('03100)

GENERAL DESCRIPTION:

This subroutine, when called, will calculate, using the gyro fail status from locations '316 and '317, the code which tells the gyro least squares matrix generator (see documentation for program source name GPMA, subroutine entry point GMAT) which of the 22 matrices to generate. Prior to the call to GMAT, this code is put in the A register. The codes are:

<u>fail status</u>	<u>code</u>
no fail	0
A fail	9
B fail	18
C fail	27
D fail	36
E fail	45
F fail	54
AB fail	63
AC fail	72
AD fail	81
AE fail	90
AF fail	99
BC fail	108
BD fail	117
BE fail	126
BF fail	135
CD fail	144
CE fail	153
CF fail	162
DE fail	171
DF fail	180
EF fail	189

If there is no second fail, i.e., ('317) = 0, then the code is simply 9 x ('316), or the number of the first fail (0 - 6) times 9. If there is a second fail, first a decision is made as to which of the two fails is larger, i.e., F fail (6) is larger than B fail (2). The code is then generated by taking 9 x the larger fail plus 45 if the smaller fail is A (1), 81 if the smaller fail is B (2), 108 if the smaller fail is C (3), 126 if the smaller fail is D (4), or 135 if the smaller fail is E (5). 45, 81, 108, 126 and 135 have the octal equivalents 55, 121, 154, 176 and 207 respectively. The program flow chart follows.



FLOWCHART - GMIN

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

		REL	SUBR	GMIN
0001				
0002				
0003	00000	0 000000	GMIN	DAC **
0004	00001	0 02 00317	LDA	*317
0005	00002	101040	SNZ	
0006	00003	0 01 00026	JMP	OOFA
0007	00004	0 11 00316	CAS	*316
0008	00005	0 01 00016	JMP	SFLA
0009	00006	0 01 00026	JMP	OOFA
0010	00007	0 06 00033	ADD	ADST
0011	00010	0 04 00034	STA	IDPT
0012	00011	0 02 00316	LDA	*316
0013	00012	0415 75	ALS	3
0014	00013	0 06 00316	ADD	*316
0015	00014	-0 06 00034	ADD*	IDPT
0016	00015	0 01 00031	JMP	PMCL
0017	00016	0 02 00316	SFLA	LDA *316
0018	00017	0 06 00033	ADD	ADST
0019	00020	0 04 00034	STA	IDPT
0020	00021	0 02 00317	LDA	*317
0021	00022	0415 75	ALS	3
0022	00023	0 06 00317	ADD	*317
0023	00024	-0 06 00034	ADD*	IDPT
0024	00025	0 01 00031	JMP	PMCL
0025	00026	0 02 00316	OOFA	LDA *316
0026	00027	0415 75	ALS	3
0027	00030	0 06 00316	ADD	*316
0028	00031	0 10 00000	PMCL	CALL GMAT
0029	00032	-0 01 00000	JMP*	GMTN
0030	00033	0 000035	ADST	DAC SUTA
0031	00034	000000	IDPT	BSZ 1
0032	00035	000000	SUTA	OCT 0,55,121,154,176,207
00036		000055		
00037		000121		
00040		000154		
00041		000176		
00042		000207		

0033

END

PROGRAM NAME

SOURCE: GPMA

BINARY: BGPMA

ENTRY POINTS (location): MATR ('12102), GMAT ('12136)

GENERAL DESCRIPTION:

This program contains the two subroutines GMAT and MATR which generate the appropriate gyro or PIPA 6 x 3 least square matrix when called (with the proper code in the A register) by GMIN or EMIN (see documentation for GMIN and EMIN). These subroutines make use of two tables. The first, the double precision data table (DPDT), contains all the double precision fractions used in any of the 22 (1 no fail, 6 single fail and 15 double fail) least square matrices. For example, the first fraction in the table is a double precision 0(DBP 0), the second is

$$\frac{\sin \alpha}{2} = 0.26865556403$$


(OCT 20645, 45016), the third is

$$-\frac{\sin \alpha}{2}, \text{ the fourth is } \frac{\cos \alpha}{2}$$

The second table (TABL) contains 22 sets of pointers, each set of which indicates which constants from the first table belong to a particular matrix. Each set is made of 9 16 bit words, or 18 bytes. Since there are 18 elements to each 6 x 3 matrix, each byte points to one element. For example, the first nine words (octal 1000, 3004, 6, 4004, 10, 1000, 6, 1000, 4002) point to the constants for the no fail matrix. The next nine point to the constants for the A fail matrix. The code that GMIN or EMIN generates before calling GMAT or MATR tells where in the TABL to get the first of the nine words that point to the matrix corresponding to the gyro or PIPA fail status. Consider again the first nine words in TABL pointing to the no fail matrix constants. The first of the nine words is octal 1000 or binary 00000010 00000000, which when broken into bytes becomes octal 2, 0. All nine broken in to bytes become 2, 0, 6, 4, 0, 6, 10, 4, 0, 10, 2, 0, 0, 6, 2, 0, 10, 2. Calling sine α S and cos α C, these 18 bytes point respectively to

$$\frac{S}{2}, 0, \frac{C}{2}, -\frac{S}{2}, 0, \frac{C}{2}, -\frac{C}{2}, -\frac{S}{2}, 0, -\frac{C}{2}, \frac{S}{2}, 0, 0, \frac{C}{2}, \frac{S}{2}, 0, -\frac{C}{2} \text{ and } \frac{S}{2},$$

which are the 18 elements of the no fail matrix. The flow chart for GMAT
(MATR is analogous) follows:



FLOWCHART - GMAT

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001			SUBR	MATR
0002			SUBR	GMAT
0003			REL	
0004	00000	0 000000	MATR	DAC **
0005	00001	0 06 00070	ADD	ADTB
0006	00002	0 04 00071	STA	BOMD
0007	00003	0 35 00524	LDX	='177734
0008	00004	0 01 00006	JMP	BEGN
0009	00005	0 12 00071	FULL	IRS
0010	00006	-0 02 00071	BEGN	LDA* BOMD
0011	00007	141140	ICL	
0012	00010	0 06 00073	ADD	ADPT
0013	00011	0 04 00072	STA	TEMP
0014	00012	000007	DRL	
0015	00013	-0 02 00072	DLD*	TEMP
0016	00014	1 04 00666	DST	'666,1
0017	00015	000005	SGL	
0018	00016	0 12 00000	IRS	0
0019	00017	0 12 00000	IRS	0
0020	00020	-0 02 00071	LDA*	BOMD
0021	00021	141050	CAL	
0022	00022	0 06 00073	ADD	ADPT
0023	00023	0 04 00072	STA	TEMP
0024	00024	000007	DBL	
0025	00025	-0 02 00072	DLD*	TEMP
0026	00026	1 04 00666	DST	'666,1
0027	00027	000005	SGL	
0028	00030	0 12 00000	IRS	0
0029	00031	0 12 00000	IRS	0
0030	00032	0 01 00005	JMP	FULL
0031	00033	-0 01 00000	JMP*	MATR
0032	00034	0 000000	GMAT	DAC **
0033	00035	0 06 00070	ADD	ADTB
0034	00036	0 04 00071	STA	BOMD
0035	00037	0 35 00524	LDY	='177734
0036	00040	0 01 00042	JMP	GEGN
0037	00041	0 12 00071	GUIL	IRS
0038	00042	-0 02 00071	GEGN	LDA* BOMD
0039	00043	141140	ICL	
0040	00044	0 06 00073	ADD	ADPT
0041	00045	0 04 00072	STA	TEMP
0042	00046	000007	DBL	
0043	00047	-0 02 00072	DLD*	TEMP
0044	00050	1 04 00400	DST	'400,1
0045	00051	000005	SGL	
0046	00052	0 12 00000	IRS	0
0047	00053	0 12 00000	IRS	0
0048	00054	-0 02 00071	LDA*	BOMD
0049	00055	141050	CAL	
0050	00056	0 06 00073	ADD	ADPT
0051	00057	0 04 00072	STA	TEMP
0052	00060	000007	DBL	
0053	00061	-0 02 00072	DLD*	TEMP
0054	00062	1 04 00400	DST	'400,1
0055	00063	000005	SGL	
0056	00064	0 12 00000	IPS	0
0057	00065	0 12 00000	IRS	0

MICROCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

0058	00066	0 01 00041	JMP	GULL
0059	00067	-0 01 00034	JMP*	GMAT
0060	00070	0 000216	ADTB	DAC
0061	00071	000000	BOMD	BSZ
0062	00072	000000	TEMP	BSZ
0063	00073	0 000074	ADPT	DAC
0064	00074	000000	DPDT	DPDT
	00075	000000	DPDT	DBP
	00075	000000		0
0065	00076	020645	OCT	20645,45016
	00077	045016		
0066	00100	157132	OCT	157132,32762
	00101	032762		
0067	00102	033161	OCT	33161,04013
	00103	004013		
0068	00104	144616	OCT	144616,73765
	00105	073765		
0069	00106	011231	OCT	11231,36014
	00107	036014		
0070	00110	166546	OCT	166546,41764
	00111	041764		
0071	00112	047311	OCT	47311,72023
	00113	072023		
0072	00114	130466	OCT	130466,5755
	00115	005755		
0073	00116	034776	OCT	34776,33025
	00117	033025		
0074	00120	143001	OCT	143001,44753
	00121	044753		
0075	00122	042575	OCT	42575,13015
	00123	013015		
0076	00124	135202	OCT	135202,64763
	00125	064763		
0077	00126	007414	OCT	7414,7002
	00127	007002		
0078	00130	170363	OCT	170363,70776
	00131	070776		
0079	00132	014130	OCT	14130,66010
	00133	066010		
0080	00134	163647	OCT	163647,11770
	00135	011770		
0081	00136	045474	OCT	45474,43011
	00137	043011		
0082	00140	132303	OCT	132303,34767
	00141	034767		
0083	00142	074674	OCT	74674,16047
	00143	016047		
0084	00144	103103	OCT	103103,61731
	00145	061731		
0085	00146	003155	OCT	03155,03010
	00147	003010		
0086	00150	174622	OCT	174622,74770
	00151	074770		
0087	00152	043503	OCT	43503,66422
	00153	066422		
0088	00154	134274	OCT	134274,11356
	00155	011356		
0089	00156	040326	OCT	40326,63412

MICROCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

00157	063412			
0090	00160	137451	OCT	137451,14366
	00161	014366		
0091	00162	050551	OCT	50651,46021
	00163	046021		
0092	00164	127126	OCT	127126,31757
	00165	031757		
0093	00166	031170	OCT	31170,27424
	00167	027424		
0094	00170	146607	OCT	146607,50354
	00171	050354		
0095	00172	046660	OCT	46660,71432
	00173	071432		
0096	00174	131117	OCT	131117,6346
	00175	006346		
0097	00176	076664	OCT	76664,72435
	00177	072435		
0098	00200	101113	OCT	101113,5343
	00201	005343		
0099	00202	024022	OCT	24022,50026
	00203	050026		
0100	00204	153755	OCT	153755,27752
	00205	027752		
0101	00206	005145	OCT	05145,57377
	00207	057377		
0102	00210	172632	OCT	172632,20401
	00211	020401		
0103	00212	026013	OCT	26013,24414
	00213	024414		
0104	00214	151764	OCT	151764,53364
	00215	053364		
0105	00216	001000	TABL OCT	1000,3004,6
	00217	003004		
	00220	000006		
0106	00221	004004	OCT	4004,10,1000
	00222	000010		
	00223	001000		
0107	00224	000006	OCT	6,1000,4002
	00225	001000		
	00226	004002		
0108	00227	000000	OCT	0,14,16
	00230	000014		
	00231	000016		
0109	00232	014004	OCT	14004,20030,1040
	00233	020030		
	00234	001040		
0110	00235	015006	OCT	15006,11032,4022
	00236	011032		
	00237	004022		
0111	00240	005000	OCT	5000,7000,0
	00241	007000		
	00242	000000		
0112	00243	014004	OCT	14004,17030,1036
	00244	017030		
	00245	001036		
0113	00246	016006	OCT	16006,11034,4022
	00247	011034		

MICROCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

00250	004022			
0114	00251	011032	OCT	11032,3024,16006
	00252	003024		
	00253	016006		
0115	00254	000000	OCT	0,20,5000
	00255	000020		
	00256	005000		
0116	00257	017026	OCT	17026,1040,14002
	00260	001040		
	00261	014002		
0117	00262	011034	OCT	11034,3024,15006
	00263	003024		
	00264	015006		
0118	00265	010014	OCT	10014,0,0
	00266	000000		
	00267	000000		
0119	00270	020026	OCT	20026,1036,14002
	00271	001036		
	00272	014002		
0120	00273	001036	OCT	1036,13004,17026
	00274	013004		
	00275	017026		
0121	00276	004024	OCT	4024,16010,11032
	00277	016010		
	00300	011032		
0122	00301	000000	OCT	0,0,10012
	00302	000000		
	00303	010012		
0123	00304	001040	OCT	1040,13004,20026
	00305	013004		
	00306	020026		
0124	00307	004024	OCT	4024,15010,11034
	00310	015010		
	00311	011034		
0125	00312	000016	OCT	16,5000,0
	00313	005000		
	00314	000000		
0126	00315	000000	OCT	0,0,0
	00316	000000		
	00317	000000		
0127	00320	022004	OCT	22004,44,1000
	00321	000044		
	00322	001000		
0128	00323	000006	OCT	6,23000,4046
	00324	023000		
	00325	004046		
0129	00326	000000	OCT	0,110,46056
	00327	000110		
	00330	046056		
0130	00331	000000	OCT	0,104,25120
	00332	000104		
	00333	025120		
0131	00334	027066	OCT	27066,37054,32072
	00335	037054		
	00336	032072		
0132	00337	000000	OCT	0,110,45056
	00340	000110		

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

00341	045056			
0133	00342	042054	OCT	42054,50000,0
	00343	050000		
	00344	000000		
0134	00345	026062	OCT	26062,35056,34076
	00346	035056		
	00347	034076		
0135	00350	000000	OCT	0,54,47102
	00351	000054		
	00352	047102		
0136	00353	034100	OCT	34100,30064,35054
	00354	030064		
	00355	035054		
0137	00356	000000	OCT	0,112,30106
	00357	000112		
	00360	030106		
0138	00361	000000	OCT	0,54,50102
	00362	000054		
	00363	050102		
0139	00364	032074	OCT	32074,26070,37060
	00365	026070		
	00366	037060		
0140	00367	045056	OCT	45056,43000,0
	00370	043000		
	00371	000000		
0141	00372	043112	OCT	43112,27000,0
	00373	027000		
	00374	000000		
0142	00375	000000	OCT	0,104,25116
	00376	000104		
	00377	025116		
0143	00401	025062	OCT	25062,35060,34076
	00401	035060		
	00402	034076		
0144	00403	043114	OCT	43114,27000,0
	00404	027000		
	00405	000000		
0145	00406	042054	OCT	42054,47000,0
	00407	047000		
	00410	000000		
0146	00411	030066	OCT	30066,37052,32072
	00412	037052		
	00413	032072		
0147	00414	025116	OCT	25116,41000,0
	00415	041000		
	00416	000000		
0148	00417	032074	OCT	32074,25070,37056
	00420	025070		
	00421	037056		
0149	00422	000000	OCT	0,114,30106
	00423	000114		
	00424	030106		
0150	00425	025120	OCT	25120,41000,0
	00426	041000		
	00427	000000		
0151	00430	034100	OCT	34100,27064,35052
	00431	027064		

MICROCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

00432	035052		
0152	00433	046056	OCT 46056,43000,0
	00434	043000	
	00435	000000	
0153	00436	023000	OCT 23000,3050,6
	00437	003050	
	00440	000006	
0154	00441	000000	OCT 0,0,0
	00442	000000	
	00443	000000	
0155	00444	000042	OCT 42,1000,22002
	00445	001000	
	00446	022002	
0156	00447	037056	OCT 37056,33074,25062
	00450	033074	
	00451	025062	
0157	00452	000000	OCT 0,60,43112
	00453	000060	
	00454	043112	
0158	00455	000000	OCT 0,120,42052
	00456	000120	
	00457	042052	
0159	00460	035054	OCT 35054,31100,30066
	00461	031100	
	00462	030066	
0160	00463	000000	OCT 0,60,43114
	00464	000060	
	00465	043114	
0161	00466	047102	OCT 47102,25000,0
	00467	025000	
	00470	000000	
0162	00471	035052	OCT 35052,31100,27066
	00472	031100	
	00473	027066	
0163	00474	030110	OCT 30110,46000,0
	00475	046000	
	00476	000000	
0164	00477	000000	OCT 0,116,42052
	00500	000116	
	00501	042052	
0165	00502	037060	OCT 37060,33074,26062
	00503	033074	
	00504	026062	
0166	00505	030110	OCT 30110,45000,0
	00506	045000	
	00507	000000	
0167	00510	050102	OCT 50102,25000,0
	00511	025000	
	00512	000000	
0168	00513	001000	OCT 1000,21004,42
	00514	021004	
	00515	000042	
0169	00516	004050	OCT 4050,10,23000
	00517	000010	
	00520	023000	
0170	00521	000000	OCT 0,0,0
	00522	000000	

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING
00523 000000
0171 00524 177734 END

PROGRAM NAME

SOURCE: EMIN

BINARY: BEMIN

ENTRY POINTS (location): EMIN ('03034)

GENERAL DESCRIPTION:

This subroutine, when called, will calculate, using the PIPA fail status from locations '320 and '321, the code which tells the PIPA least squares matrix generator (see documentation for program source name GPMA, subroutine entry point MATR) which of the 22 matrices to generate. Prior to the call to MATR, this code is put in the A register. For an explanation of the codes and a flow chart of this subroutine, see documentation for program source name GMIN.

MICPOCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001	REL
0002	SUBR
0003 00000	0 000000 EMIN DAC **
0004 00001	0 02 00321 LDA '321
0005 00002	101040 SNZ
0006 00003	0 01 00026 JMP OOPA
0007 00004	0 11 00320 CAS '320
0008 00005	0 01 00016 JMP SFLA
0009 00006	0 01 00026 JMP OOPA
0010 00007	0 06 00033 ADD ADST
0011 00010	0 04 00034 STA IDPT
0012 00011	0 02 00320 LDA '320
0013 00012	0415 75 A.I.S 3
0014 00013	0 06 00320 ADD '320
0015 00014	-0 06 00034 ADD* IDPT
0016 00015	0 01 00031 JMP PMCL
0017 00016	0 02 00320 SFLA LDA '320
0018 00017	0 06 00033 ADD ADST
0019 00020	0 04 00034 STA IDPT
0020 00021	0 02 00321 LDA '321
0021 00022	0415 75 ALS 3
0022 00023	0 06 00321 ADD '321
0023 00024	-0 06 00034 ADD* IDPT
0024 00025	0 01 00031 JMP PMCL
0025 00026	0 02 00320 OOPA LDA '320
0026 00027	0415 75 ALS 3
0027 00030	0 06 00320 ADD '320
0028 00031	0 10 00000 PMCL CALL MATR
0029 00032	-0 01 000000 JMP* EMIN
0030 00033	0 000035 ADST DAC SUTA
0031 00034	0000000 IDPT BSZ 1
0032 00035	0000000 SUTA OCT 0,55,121,154,176,207
00036	000055
00037	000121
00040	000154
00041	000176
00042	000207
0033	END

PROGRAM NAME

SOURCE: MG63

BINARY: BMG63

ENTRY POINTS (location): MG63 ('04012)

GENERAL DESCRIPTION:

This subroutine performs the 6×3 matrix multiplication which transforms the six gyro $\Delta\theta$ outputs into the x, y, z frame. The 6×3 matrix is stored as double precision fractions in locations '334 — '377 and it is the least squares matrix corresponding to the gyro fail status. The six gyro pulse counts are single precision fractions scaled at $7 2^{-8}$ radians (for example, 1 gyro pulse would be represented as an octal 000400 = $7 2^{15}$ radians) and are stored in locations '400, '402, '404, '406, '410, and '412 respectively.

$\Delta\theta X$, $\Delta\theta Y$ and $\Delta\theta Z$ are first formed in temporary double precision accumulators DTXU, DTYU and DTZU, double precision fractions scaled at $7 2^{-8}$ radians. These are then multiplied by $7/4$ and added into DTXB, DTYB and DTZB (locations) '414-'415, '416-'417 and '420-'421), which are double precision fractions now scaled at 2^{-6} radians. Since the attitude algorithm (see documentation for ATTA, program name AA6S) only uses the high order of DTXB, DTYB and DTZB, the low order is saved as a residual and at the beginning of MG63 only the high order is zeroed.

The internal subroutine MUPY will do three single by double multiplies and adds, performing the functions expressed by the following equations:

$$DTXU = DTXU + (GMAT + I) PTMP$$

$$DTYU = DTYU + (GMAT + 2 + I) PTMP$$

$$DTZU = DTZU + (GMAT + 4 + I) PTMP$$

where $(GMAT + 2 + I)$ is the double precision fractional matrix element stored in locations '334 + 2 + I and '334 + 3 + I, where I is the contents of the index register. If, for example, I = 6 and PTMP = GBPC (gyro B

pulse count), the above equations can be written:

$$DTXU = DTXU + ('342, '343) GBPC$$

$$DTYU = DTYU + ('344, '345) GBPC$$


$$DTZU = DTZU + ('346, '347) GBPC$$

The 6 x 3 matrix is shown below and it can be seen that the above example shows how all of gyro B's contribution to the X, Y and Z axes can be gotten by setting I = 6, PTMP = GBPC and doing the internal subroutine MUPY.

('334, '335) ('342, '343) ('350, '351) ('356, '357) ('364, '365) ('372, '373)
('336, '337) ('344, '345) ('352, '353) ('360, '361) ('366, '367) ('374, '375)
('340, '341) ('346, '347) ('354, '355) ('362, '363) ('370, '371) ('376, '377)

6 x 3 matrix storage locations.

The flow chart for MG63 follows:



FLOWCHART - MG63

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

			REL
0001			SUBR MG63
0002			
0003	00000	0 000000	MG63 DAC **
0004	00001	140040	CRA
0005	00002	0 04 00102	STA DTXU
0006	00003	0 04 00103	STA DTXU+1
0007	00004	0 04 00104	STA DTU
0008	00005	0 04 00105	STA DTU+1
0009	00006	0 04 00106	STA DTZU
0010	00007	0 04 00107	STA DTZU+1
0011	00010	0 04 00414	STA DTXB
0012	00011	0 04 00416	STA DTU
0013	00012	0 04 00420	STA DTZB
0014	00013	0 04 00000	STA 0
0015	00014	0 02 00400	LDA GPC
0016	00015	0 04 00100	STA PTMP
0017	00016	0 10 00112	JST MUPY
0018	00017	0 35 00173	LDX =6
0019	00020	0 02 00402	LDA GPC
0020	00021	0 04 00100	STA PTMP
0021	00022	0 10 00112	JST MUPY
0022	00023	0 35 00172	LDX =12
0023	00024	0 02 00404	LDA GPC
0024	00025	0 04 00100	STA PTMP
0025	00026	0 10 00112	JST MUPY
0026	00027	0 35 00171	LDX =18
0027	00030	0 02 00406	LDA GPC
0028	00031	0 04 00100	STA PTMP
0029	00032	0 10 00112	JST MUPY
0030	00033	0 35 00170	LDY =24
0031	00034	0 02 00410	LDA GPC
0032	00035	0 04 00100	STA PTMP
0033	00036	0 10 00112	JST MUPY
0034	00037	0 35 00167	LDX =30
0035	00040	0 02 00412	LDA GPC
0036	00041	0 04 00100	STA PTMP
0037	00042	0 10 00112	JST MUPY
0038	00043	000007	DBL
0039	00044	0 02 00074	DLD DBPO
0040	00045	0 07 00102	DSB DTXU
0041	00046	0401 76	LRS 2
0042	00047	0 06 00102	DAD DTXU
0043	00050	0 06 00102	DAD DTXU
0044	00051	0 06 00414	DAD DTXB
0045	00052	0 04 00414	DST DTXB
0046	00053	0 02 00074	DLD DBPO
0047	00054	0 07 00104	DSB DTU
0048	00055	0401 76	LRS 2
0049	00056	0 06 00104	DAD DTU
0050	00057	0 06 00104	DAD DTU
0051	00060	0 06 00416	DAD DTU
0052	00061	0 04 00416	DST DTU
0053	00062	0 02 00074	DLD DBPO
0054	00063	0 07 00106	DSB DTZU
0055	00064	0401 76	LRS 2
0056	00065	0 06 00106	DAD DTZU
0057	00066	0 06 00106	DAD DTZU

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0058	00067	0 06 00420	DAD	DTZB
0059	00070	0 04 00420	DST	DTZB
0060	00071	000005	SGL	
0061	00072	-0 01 00000	JMP*	MG63
0062	00074	000000	DBP0 DBP	0
	00075	000000		
0063	00076	000000	TEMP DBP	0
	00077	000000		
0064	00100	000000	PTMP DBP	0
	00101	000000		
0065	00102	000000	DTXU DBP	0
	00103	000000		
0066	00104	000000	DTYU DBP	0
	00105	000000		
0067	00106	000000	DTZU DBP	0
	00107	000000		
0068	00110	000000	HALF OCT	0,40000
	00111	040000		
0069		000414	DTXB EQU	*414
0070		000416	DTYB EQU	DTXB+2
0071		000420	DTZB EQU	DTXB+4
0072		000400	GAPC EQU	*400
0073		000402	GBPC EQU	GAPC+2
0074		000404	GCPC EQU	GAPC+4
0075		000406	GDPC EQU	GAPC+6
0076		000410	GEPC EQU	GAPC+8
0077		000412	GFPC EQU	GAPC+10
0078		000334	GMAT EQU	*334
0079	00112	0 000000	MUPY DAC	**
0080	00113	000007	DBL	
0081	00114	1 16 00334	MPY	GMAT,1
0082	00115	0 04 00076	DST	TEMP
0083	00116	0 02 00100	DLD	PTMP
0084	00117	1 16 00335	MPY	GMAT+1,1
0085	00120	0 06 00110	DAD	HALF
0086	00121	140320	CSA	
0087	00122	000201	IAB	
0088	00123	140040	CRA	
0089	00124	100001	SRC	
0090	00125	140401	CMA	
0091	00126	0 06 00076	DAD	TEMP
0092	00127	0 06 00102	DAC	DTXU
0093	00130	0 04 00102	DST	DTXU
0094	00131	0 02 00100	DLD	PTMP
0095	00132	1 16 00336	MPY	GMAT+2,1
0096	00133	0 04 00076	DST	TEMP
0097	00134	0 02 00100	DLD	PTMP
0098	00135	1 16 00337	MPY	GMAT+3,1
0099	00136	0 06 00110	DAD	HALF
0100	00137	140320	CSA	
0101	00140	000201	IAB	
0102	00141	140040	CRA	
0103	00142	100001	SRC	
0104	00143	140401	CMA	
0105	00144	0 06 00076	DAD	TEMP
0106	00145	0 06 00104	DAD	DTYU
0107	00146	0 04 00104	DST	DTYU

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0108	00147	0 02	00100	DLD	PTMP
0109	00150	1 16	00340	MPY	GMAT+4,1
0110	00151	0 04	00076	DST	TEMP
0111	00152	0 02	00100	DLD	PTMP
0112	00153	1 16	00341	MPY	GMAT+5,1
0113	00154	0 06	00110	DAD	HALF
0114	00155	140320		CSA	
0115	00156	000201		IAB	
0116	00157	140040		CRA	
0117	00160	100001		SRC	
0118	00161	140401		CMA	
0119	00162	0 .06	00076	DAD	TEMP
0120	00163	0 .06	00106	DAD	DTZU
0121	00164	0 .04	00106	DST	DTZU
0122	00165	000005		SGL	
0123	00166	-0 .01	00112	JMP*	MUPY
0124	00167	000036		END	
	00170	000030			
	00171	000022			
	00172	000014			
	00173	000006			

PROGRAM NAME

SOURCE: MV63

BINARY BMV63

ENTRY POINTS (location): MP63 ('03664)

GENERAL DESCRIPTION:

This subroutine performs the 6 x 3 matrix multiplication which transforms the 6 PIPA ΔV outputs into the X, Y, Z frame. It is an almost identical program to MG63 (see documentation for MG63) except that ΔV_X , ΔV_Y and ΔV_Z do not have to be scaled by 7/4 as in the gyro 6 x 3 multiplication.

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

		REL	
0001		SUBR	MP63
0002		DAC	**
0003 00000	0 000000	MP63	
0004 00001	140040	CRA	
0005 00002	0 04 00614	STA	DVXB
0006 00003	0 04 00616	STA	DVYB
0007 00004	0 04 00620	STA	DVZB
0008 00005	0 04 00000	STA	0
0009 00006	0 02 00600	LDA	AAPC
0010 00007	0 04 00040	STA	PTMP
0011 00010	0 10 00044	JST	MUPY
0012 00011	0 35 00125	LDX	=6
0013 00012	0 02 00602	LDA	ABPC
0014 00013	0 04 00040	STA	PTMP
0015 00014	0 10 00044	JST	MUPY
0016 00015	0 35 00124	LDX	=12
0017 00016	0 02 00604	LDA	ACPC
0018 00017	0 04 00040	STA	PTMP
0019 00020	0 10 00044	JST	MUPY
0020 00021	0 35 00123	LDX	=18
0021 00022	0 02 00606	LDA	ADPC
0022 00023	0 04 00040	STA	PTMP
0023 00024	0 10 00044	JST	MUPY
0024 00025	0 35 00122	LDX	=24
0025 00026	0 02 00610	LDA	AEPC
0026 00027	0 04 00040	STA	PTMP
0027 00030	0 10 00044	JST	MUPY
0028 00031	0 35 00121	LDX	=30
0029 00032	0 02 00612	LDA	AFPC
0030 00033	0 04 00040	STA	PTMP
0031 00034	0 10 00044	JST	MUPY
0032 00035	-0 01 00000	JMP*	MP63
0033 00036	000000	TEMP	DBP
0037	000000		0
0034 00040	000000	PTMP	DBP
0041	000000		0
0035 00042	0000000	HALF	OCT
0043	040000		0,40000
0036	000614	DVXB	EQU
0037	000616	DVVB	EQU
0038	000620	DVZB	EQU
0039	000600	AAPC	EQU
0040	000602	ABPC	EQU
0041	000604	ACPC	EQU
0042	000606	ADPC	EQU
0043	000610	AEPC	EQU
0044	000612	AFPC	EQU
0045	000622	PMAT	EQU
0046 00044	0 000000	MUPY	DAC
0047 00045	000007		**
0048 00046	1 16 00622	DBL	
0049 00047	0 04 00036	MPY	PMAT,1
0050 00050	0 02 00040	DST	TEMP
0051 00051	1 16 00623	DLD	PTMP
0052 00052	0 06 00042	MPY	PMAT+1,1
0053 00053	140320	DAD	HALF
0054 00054	000201	CSA	
		IAB	

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0055	00055	140040	CRA
0056	00056	100001	SRC
0057	00057	140401	CMA
0058	00060	0 06 00036	DAD TEMP
0059	00061	0 06 00614	DAD DVXB
0060	00062	0 04 00614	DST DVXB
0061	00063	0 02 00040	DLD PTMP
0062	00064	1 16 00624	MPY PMAT+2,1
0063	00065	0 04 00036	DST TEMP
0064	00066	0 02 00040	DLD PTMP
0065	00067	1 16 00625	MPY PMAT+3,1
0066	00070	0 06 00042	DAD HALF
0067	00071	140320	CSA
0068	00072	000201	IAB
0069	00073	140040	CRA
0070	00074	100001	SRC
0071	00075	140401	CMA
0072	00076	0 06 00036	DAD TEMP
0073	00077	0 06 00616	DAD DVYB
0074	00100	0 04 00616	DST DVYB
0075	00101	0 02 00040	DLD PTMP
0076	00102	1 16 00626	MPY PMAT+4,1
0077	00103	0 04 00036	DST TEMP
0078	00104	0 02 00040	DLD PTMP
0079	00105	1 16 00627	MPY PMAT+5,1
0080	00106	0 06 00042	DAD HALF
0081	00107	140320	CSA
0082	00110	000201	IAB
0083	00111	140040	CRA
0084	00112	100001	SRC
0085	00113	140401	CMA
0086	00114	0 06 00036	DAD TEMP
0087	00115	0 06 00620	DAD DVZB
0088	00116	0 04 00620	DST DVZB
0089	00117	000005	SGL
0090	00120	-0 01 00044	JMP* MUPY
0091	00121	000036	END
	00122	000030	
	00123	000022	
	00124	000014	
	00125	000006	

PROGRAM NAME

SOURCE: SPUN

BINARY: BSPUN

ENTRY POINTS (location): SPUN ('05560)

GENERAL DESCRIPTION:

This subroutine when called will correct the quaternion in order to maintain it as a unit quaternion. It imposes the constraint that

$$\lambda^2 + \rho_x^2 + \rho_y^2 + \rho_z^2 = 1.$$

Ideally the equations to be implemented would be

$$\begin{aligned}\lambda' &= \lambda d \\ \rho_x' &= \rho_x d \\ \rho_y' &= \rho_y d \\ \rho_z' &= \rho_z d\end{aligned}$$

where

$$d = \frac{1}{\sqrt{\lambda^2 + \rho_x^2 + \rho_y^2 + \rho_z^2}}$$

However, since the sum of the squares of the elements of the quaternion never deviates significantly from 1, we can simplify as follows:

$$\epsilon = \lambda^2 + \rho_x^2 + \rho_y^2 + \rho_z^2 - 1$$

or $\lambda^2 + \rho_x^2 + \rho_y^2 + \rho_z^2 = 1 + \epsilon$

$$\sqrt{\lambda^2 + \rho_x^2 + \rho_y^2 + \rho_z^2} = \sqrt{1 + \epsilon} \approx 1 + \frac{\epsilon}{2}$$

$$d \approx \frac{1}{1 + \frac{\epsilon}{2}} \approx 1 - \frac{\epsilon}{2}$$

so

$$\lambda' \approx \lambda(1 - \frac{\epsilon}{2})$$

$$\rho_x' \approx \rho_x(1 - \frac{\epsilon}{2})$$

$$\rho_y' \approx \rho_y(1 - \frac{\epsilon}{2})$$

$$\rho_z' \approx \rho_z(1 - \frac{\epsilon}{2})$$

Using the scaling and terminology for the quaternion described in the program AA6S

$$(i.e., L = \frac{\lambda}{2}, RX = \frac{\rho_x}{2}, RY = \frac{\rho_y}{2} \text{ and } RZ = \frac{\rho_z}{2})$$

we derive the new constraint that

$$L^2 + RX^2 + RY^2 + RZ^2 \text{ equal } 1/4$$

$$L' = L D$$

$$RX' = RX D$$

$$RY' = RY D$$

$$RZ' = RZ D$$

where

$$D = \frac{1}{\sqrt{L^2 + RX^2 + RY^2 + RZ^2}}$$

$$E = L^2 + RX^2 + RY^2 + RZ^2 - \frac{1}{4}$$

$$L^2 + RX^2 + RY^2 + RZ^2 = \frac{1}{4} + E$$

$$\sqrt{L^2 + RX^2 + RY^2 + RZ^2} = \sqrt{\frac{1}{4} + E} \approx \frac{1}{2} + E$$

$$D \approx \frac{1}{1 + 2E} \approx 1 - 2E$$

so

$$L' = L (1 - 2E)$$

$$RX' = RX (1 - 2E)$$

$$RY' = RY (1 - 2E)$$

$$RZ' = RZ (1 - 2E)$$

or

$$\begin{aligned}\Delta L &= -2E L \\ \Delta RX &= -2E RX \\ \Delta RY &= -2E RY \\ \Delta RZ &= -2E RZ\end{aligned}$$

Now expand the ΔL term (the ΔRX , ΔRY and ΔRZ terms are analogous). Since ΔL is very small we shall really calculate

$$2^{24} \Delta L = -2^{25} E L.$$

define FACT = $-2^{25} E$. Then

$$\Delta L = \frac{\text{FACT } L}{2^{24}}$$

since

$$L = L_1 + \frac{L_2}{2^{15}} + \frac{L_3}{2^{30}}$$

then

$$\Delta L = \frac{\text{FACT } L_1}{2^{24}} + \frac{\text{FACT } L_2}{2^{39}} + \frac{\text{FACT } L_3}{2^{54}}$$

and we need only calculate

$$\Delta L = \frac{\text{FACT } L_1}{2^{24}}$$

repeating we have

$$E = L^2 + RX^2 + RY^2 + RZ^2 - 1/4$$

and

$$L^2 = L_1^2 + \frac{L_2^2}{2^{30}} + \frac{L_3^2}{2^{60}} + \frac{L_1 L_2}{2^{14}} + \frac{L_1 L_3}{2^{29}} + \frac{L_2 L_3}{2^{44}}$$

$$RX^2 = RX_1^2 + \frac{RX_2^2}{2^{30}} + \frac{RX_3^2}{2^{60}} + \frac{RX_1 RX_2}{2^{14}} + \frac{RX_1 RX_3}{2^{29}} + \frac{RX_2 RX_3}{2^{44}}$$

$$RY^2 = \dots$$

$$RZ^2 = \dots$$

substituting and gathering terms we get

$$\begin{aligned} E &= L_1^2 + R_{X1}^2 + R_{Y1}^2 + R_{Z1}^2 \\ &+ \frac{L_2^2 + R_{X2}^2 + R_{Y2}^2 + R_{Z2}^2}{2^{30}} + \frac{L_3^2 + R_{X3}^2 + R_{Y3}^2 + R_{Z3}^2}{2^{60}} \\ &+ \frac{L_1 L_2 + R_{X1} R_{X2} + R_{Y1} R_{Y2} + R_{Z1} R_{Z2}}{2^{14}} \\ &+ \frac{L_1 L_3 + R_{X1} R_{X3} + R_{Y1} R_{Y3} + R_{Z1} R_{Z3}}{2^{29}} \\ &+ \frac{L_2 L_3 + R_{X2} R_{X3} + R_{Y2} R_{Y3} + R_{Z2} R_{Z3}}{2^{44}} - \frac{1}{4} \end{aligned}$$


We now want to calculate

$$FACT = -2^{25}E$$

Since FACT has only 15 bits of significance, all terms contributing to E with denominators greater than 2^{40} can be ignored. This eliminates the terms

$$\frac{L_3^2}{2^{60}} \text{ and } \frac{L_2 L_3}{2^{44}}$$

The flow chart for the implementation on the DDP516 of the above derivation follows.



FLOWCHART - SPUN

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

			REL	
			SUBR	SPUN
0001				
0002				
0003	00000	0 000000	SPUN	DAC **
0004	00001	0 02 00461	LDA	L2
0005	00002	000007	DBL	
0006	00003	0 16 00461	MPY	L2
0007	00004	0401 77	LRS	1
0008	00005	0 04 00244	DST	OVFP
0009	00006	0 02 00462	DLD	L3
0010	00007	000201	IAB	
0011	00010	0 07 00254	DSB	FUDG
0012	00011	0 16 00460	MPY	L1
0013	00012	0 06 00244	DAD	OVFP
0014	00013	0401 76	LRS	2
0015	00014	0 04 00242	DST	SUMM
0016	00015	0 02 00464	DLD	RX1
0017	00016	000201	IAB	
0018	00017	0 16 00465	MPY	RX2
0019	00020	0401 77	LRS	1
0020	00021	0 04 00244	DST	OVFP
0021	00022	0 02 00466	DLD	RX3
0022	00023	000201	IAB	
0023	00024	0 07 00254	DSB	FUDG
0024	00025	0 16 00464	MPY	RX1
0025	00026	0 06 00244	DAD	OVFP
0026	00027	0401 76	LRS	2
0027	00030	0 06 00242	DAD	SUMM
0028	00031	0 04 00242	DST	SUMM
0029	00032	0 02 00470	DLD	RY1
0030	00033	000201	IAB	
0031	00034	0 16 00471	MPY	RY2
0032	00035	0401 77	LRS	1
0033	00036	0 04 00244	DST	OVFP
0034	00037	0 02 00472	DLD	RY3
0035	00040	000201	IAB	
0036	00041	0 07 00254	DSB	FUDG
0037	00042	0 16 00470	MPY	RY1
0038	00043	0 06 00244	DAD	OVFP
0039	00044	0401 76	LRS	2
0040	00045	0 06 00242	DAD	SUMM
0041	00046	0 04 00242	DST	SUMM
0042	00047	0 02 00474	DLD	RZ1
0043	00050	000201	IAB	
0044	00051	0 16 00475	MPY	RZ2
0045	00052	0401 77	LRS	1
0046	00053	0 04 00244	DST	OVFP
0047	00054	0 02 00476	DLD	RZ3
0048	00055	000201	IAB	
0049	00056	0 07 00254	DSB	FUDG
0050	00057	0 16 00474	MPY	RZ1
0051	00060	0 06 00244	DAD	OVFP
0052	00061	0401 76	LRS	2
0053	00062	0 06 00242	DAD	SUMM
0054	00063	0401 61	LRS	15
0055	00064	0 04 00242	DST	SUMM
0056	00065	0 02 00460	DLD	L1
0057	00066	0 16 00461	MPY	L2

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058 00067	0 04 00244	DST	OVFP
0059 00070	0 02 00464	DLD	RX1
0060 00071	0 16 00465	MPY	RX2
0061 00072	0 06 00244	DAD	OVFP
0062 00073	0 04 00244	DST	OVFP
0063 00074	0 02 00470	DLD	RY1
0064 00075	0 16 00471	MPY	RY2
0065 00076	0 06 00244	DAD	OVFP
0066 00077	0 04 00244	DST	OVFP
0067 00100	0 02 00474	DLD	RZ1
0068 00101	0 16 00475	MPY	BZ2
0069 00102	0 06 00244	DAD	OVFP
0070 00103	0401 76	LRS	2
0071 00104	0 06 00242	DAD	SUMM
0072 00105	0 04 00242	DST	SUMM
0073 00106	0411 75	LLS	3
0074 00107	140040	CRA	
0075 00110	0 04 00252	DST	THRD
0076 00111	0 02 00242	DLD	SUMM
0077 00112	0401 64	LRS	12
0078 00113	0 04 00242	DST	SUMM
0079 00114	0 02 00460	DLD	L1
0080 00115	0 16 00460	MPY	L1
0081 00116	0 06 00242	DAD	SUMM
0082 00117	0 04 00242	DST	SUMM
0083 00120	0 02 00464	DLD	RX1
0084 00121	0 16 00464	MPY	RX1
0085 00122	0 06 00242	DAD	SUMM
0086 00123	0 04 00242	DST	SUMM
0087 00124	0 02 00470	DLD	RY1
0088 00125	0 16 00470	MPY	RY1
0089 00126	0 06 00242	DAD	SUMM
0090 00127	0 04 00242	DST	SUMM
0091 00130	0 02 00474	DLD	RZ1
0092 00131	0 16 00474	MPY	RZ1
0093 00132	0 06 00242	DAD	SUMM
0094 00133	0 07 00250	DSB	TWNZ
0095 00134	000201	IAB	
0096 00135	140040	CRA	
0097 00136	000201	IAB	
0098 00137	0 06 00252	DAD	THRD
0099 00140	0411 66	LLS	10
0100 00141	0 06 00256	DAD	HALF
0101 00142	140407	TCA	
0102 00143	0 04 00246	DST	FACT
0103 00144	0 16 00460	MPY	L1
0104 00145	0 06 00256	DAD	HALF
0105 00146	000201	IAB	
0106 00147	140040	CRA	
0107 00150	000201	IAB	
0108 00151	0401 67	LRS	9
0109 00152	0 06 00462	DAD	L3
0110 00153	0 04 00244	DST	OVFP
0111 00154	140040	CRA	
0112 00155	0 04 00462	DST	L3
0113 00156	0 02 00244	DLD	OVFP
0114 00157	0401 61	LRS	15

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0115	00160	0 06 00460	DAD	L1
0116	00161	0 04 00460	DST	L1
0117	00162	0 02 00464	DLD	RX1
0118	00163	0 16 00246	MPY	FACT
0119	00164	0 06 00256	DAD	HALF
0120	00165	000201	IAB	
0121	00166	140040	CRA	
0122	00167	000201	IAB	
0123	00170	0401 67	LRS	9
0124	00171	0 06 00466	DAD	RX3
0125	00172	0 04 00244	DST	OVFP
0126	00173	140040	CRA	
0127	00174	0 04 00466	DST	RX3
0128	00175	0 02 00244	DLD	OVFP
0129	00176	0401 61	LRS	15
0130	00177	0 06 00464	DAD	RX1
0131	00200	0 04 00464	DST	RX1
0132	00201	0 02 00470	DLD	RY1
0133	00202	0 16 00246	MPY	FACT
0134	00203	0 06 00256	DAD	HALF
0135	00204	000201	IAB	
0136	00205	140040	CRA	
0137	00206	000201	IAB	
0138	00207	0401 67	LRS	9
0139	00210	0 06 00472	DAD	RY3
0140	00211	0 04 00244	DST	OVFP
0141	00212	140040	CRA	
0142	00213	0 04 00472	DST	RY3
0143	00214	0 02 00244	DLD	OVFP
0144	00215	0401 61	LRS	15
0145	00216	0 06 00470	DAD	RY1
0146	00217	0 04 00470	DST	RY1
0147	00220	0 02 00474	DLD	RZ1
0148	00221	0 16 00246	MPY	FACT
0149	00222	0 06 00256	DAD	HALF
0150	00223	000201	IAB	
0151	00224	140040	CRA	
0152	00225	000201	IAB	
0153	00226	0401 67	LRS	9
0154	00227	0 06 00476	DAD	RZ3
0155	00230	0 04 00244	DST	OVFP
0156	00231	140040	CRA	
0157	00232	0 04 00476	DST	RZ3
0158	00233	0 02 00244	DLD	OVFP
0159	00234	0401 61	LRS	15
0160	00235	0 06 00474	DAD	RZ1
0161	00236	0 04 00474	DST	RZ1
0162	00237	000005	SGL	
0163	00240	-0 01 00000	JMP*	SPUN
0164	00242	000000	SUMM DBP	0
	00243	000000		
0165	00244	000000	OVFP DBP	0
	00245	000000		
0166	00246	000000	FACT DBP	0
	00247	000000		
0167	00250	020000	TWNZ OCT	20000,0
	00251	000000		

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0168	00252	000000	THRD	DBP	0
	00253	000000			
0169	00254	040000	FUDG	OCT	40000,0
	00255	000000			
0170	00256	000000	HALF	OCT	0,40000
	00257	040000			
0171		000460	L1	EQU	*460
0172		000461	L2	EQU	L1+1
0173		000462	L3	EQU	L1+2
0174		000464	RX1	EQU	L1+4
0175		000465	RX2	EQU	L1+5
0176		000466	RX3	EQU	L1+6
0177		000470	RY1	EQU	L1+8
0178		000471	RY2	EQU	L1+9
0179		000472	RY3	EQU	L1+10
0180		000474	RZ1	EQU	L1+12
0181		000475	RZ2	EQU	L1+13
0182		000476	RZ3	EQU	L1+14
0183				END	

PROGRAM NAME

SOURCE: VESP

BINARY: BVESP

RELATED MEMOS: T-493

ENTRY POINTS (location): VELA ('04206)

ACCESSABLE VARIABLES (location): FXX ('04654),

FXY ('04656), FXZ ('04660), FYX ('04662), FYY ('04664),

FYZ ('04666), FZX ('04670), FZY ('04672),

PZZ ('04674)

GENERAL DESCRIPTION:

This subroutine, when called, will construct a cosine matrix from the quaternion which transforms a vector in the body frame to the inertial frame. It will then multiply the ΔV in the body frame by this matrix to get ΔV in the inertial frame. The cosine matrix can be expressed in terms of the quaternion elements as:

$$C(Q) = \begin{bmatrix} 1 - 2(\rho_y^2 + \rho_z^2) & 2(\rho_x\rho_y - \lambda\rho_z) & 2(\rho_x\rho_z + \lambda\rho_y) \\ 2(\rho_x\rho_y + \lambda\rho_z) & 1 - 2(\rho_x^2 + \rho_z^2) & 2(\rho_y\rho_z - \lambda\rho_x) \\ 2(\rho_x\rho_z - \lambda\rho_y) & 2(\rho_y\rho_z + \lambda\rho_x) & 1 - 2(\rho_x^2 + \rho_y^2) \end{bmatrix}$$

This can be written as:

$$\begin{bmatrix} f_{xx} & f_{xy} & f_{xz} \\ f_{yx} & f_{yy} & f_{yz} \\ f_{zx} & f_{zy} & f_{zz} \end{bmatrix}$$

where

$$f_{xx} = 1 - 2(\rho_y^2 + \rho_z^2)$$

$$f_{xy} = 2(\rho_x\rho_y - \lambda\rho_z)$$

$$f_{xz} = 2(\rho_x\rho_z + \lambda\rho_y)$$

$$f_{zz} = 1 - 2(\rho_x^2 + \rho_y^2)$$

Observe that all elements of the matrix consist of various combinations of the nine quaternion products: ρ_x^2 , ρ_y^2 , ρ_z^2 , $\rho_x \rho_y$, $\rho_x \rho_z$, $\rho_y \rho_z$, $\lambda \rho_x$, $\lambda \rho_y$ and $\lambda \rho_z$. Therefore, in the subroutine implementation the nine quaternion products are first calculated. Only 30 bits of each quaternion element is used and the cosine matrix elements are calculated to have a word size of 30 bits also. Scaling is as follows:

$$\lambda = 2L1 + \frac{L2}{2^{14}}$$

$$\rho_x = 2RX1 + \frac{RX2}{2^{14}}$$

$$\rho_y = 2RY1 + \frac{RY2}{2^{14}}$$

$$\rho_z = 2RZ1 + \frac{RZ2}{2^{14}}$$

$$\rho_x^2 = 4RX1^2 + \frac{RX1 RX2}{2^{12}} + \frac{RXZ^2}{2^{28}}$$

or

$$RXSQ = \frac{\rho_x^2}{2} = 2RX1^2 + \frac{RX1 RX2}{2^{13}} + \frac{RX2^2}{2^{29}}$$

the other 8 quaternion products are scaled the same as ρ_x^2 .

We also define:

$$FXX = \frac{f_{xx}}{4} = \frac{1}{4} - \left(\frac{\rho_y^2}{2} + \frac{\rho_z^2}{2} \right)$$

$$\vdots \\ FZZ = \frac{f_{zz}}{4} = \frac{1}{4} - \left(\frac{\rho_x^2}{2} + \frac{\rho_y^2}{2} \right)$$

or

$$F_{XX} = \frac{1}{4} - R_{YSQ} - R_{ZSQ}$$

$$F_{ZZ} = \frac{1}{4} - R_{XSQ} - R_{YSQ}$$


Now we can write the equations to be implemented as:

$$DVIX = 4 (F_{XX} DVXB + F_{XY} DVYB + F_{XZ} DVZB)$$

$$DVIIY = 4 (F_{YX} DVXB + F_{YY} DVYB + F_{YZ} DVZB)$$

$$DVIZ = 4 (F_{ZX} DVXB + F_{ZY} DVYB + F_{ZZ} DVZB)$$

where DVIX is ΔV in the inertial frame scaled the same as DVBX, ΔV in the body frame. The flow chart for the implementation on the DDP-516 of the above derivation follows:



FLOWCHART - VELA

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001			REL	
0002			SUBR	FXX
0003			SUBR	FXY
0004			SUBR	FXZ
0005			SUBR	FYX
0006			SUBR	FYY
0007			SUBR	FYZ
0008			SUBR	FZX
0009			SUBR	FZY
0010			SUBR	FZZ
0011			SUBR	VELA
0012	00000	0 000000	VELA	DAC **
0013	00001	0 02 00465	LDA	RX2
0014	00002	000007	DBL	
0015	00003	0 16 00465	MPY	RX2
0016	00004	000201	IAB	
0017	00005	1400 40	CRA	
0018	00006	0401 77	LRS	1
0019	00007	0 04 00444	DST	T1
0020	00010	0 02 00464	DLD	RX1
0021	00011	0 16 00465	MPY	RX2
0022	00012	0 06 00444	DAD	T1
0023	00013	0 06 00512	DAD	SQRD
0024	00014	0401 63	LRS	13
0025	00015	0 04 00444	DST	T1
0026	00016	0 02 00464	DLD	RX1
0027	00017	0 16 00464	MPY	RX1
0028	00020	0411 77	LLS	1
0029	00021	0 06 00444	DAD	T1
0030	00022	0 04 00470	DST	RYSQ
0031	00023	0 02 00470	DLD	RY1
0032	00024	000201	IAB	
0033	00025	0 16 00471	MPY	RY2
0034	00026	000201	IAB	
0035	00027	1400 40	CRA	
0036	00030	0401 77	LRS	1
0037	00031	0 04 00444	DST	T1
0038	00032	0 02 00470	DID	RY1
0039	00033	0 16 00471	MPY	RY2
0040	00034	0 06 00444	DAD	T1
0041	00035	0 06 00512	DAD	SQRD
0042	00036	0401 63	LRS	13
0043	00037	0 04 00444	DST	T1
0044	00040	0 02 00470	DLD	RY1
0045	00041	0 16 00470	MPY	RY1
0046	00042	0411 77	LLS	1
0047	00043	0 06 00444	DAD	T1
0048	00044	0 04 00472	DST	RYSQ
0049	00045	0 02 00474	DLD	RZ1
0050	00046	000201	IAB	
0051	00047	0 16 00475	MPY	RZ2
0052	00050	000201	IAB	
0053	00051	1400 40	CRA	
0054	00052	0401 77	LRS	1
0055	00053	0 04 00444	DST	T1
0056	00054	0 02 00474	DLD	RZ1
0057	00055	0 16 00475	MPY	RZ2

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0058	00056	0 06 00444	DAD	T1
0059	00057	0 06 00512	DAD	SORD
0060	00060	0401 63	LRS	13
0061	00061	0 04 00444	DST	T1
0062	00062	0 02 00474	DLD	RZ1
0063	00063	0 16 00474	MPY	RZ1
0064	00064	0411 77	LLS	1
0065	00065	0 06 00444	DAD	T1
0066	00066	0 04 00474	DST	RZSQ
0067	00067	0 02 00460	DLD	L1
0068	00070	000201	IAB	
0069	00071	0 16 00465	MPY	RX2
0070	00072	000201	IAB	
0071	00073	140040	CRA	
0072	00074	0 04 00444	DST	T1
0073	00075	0 02 00460	DLD	L1
0074	00076	0 16 00465	MPY	RX2
0075	00077	0 06 00444	DAD	T1
0076	00100	0 04 00444	DST	T1
0077	00101	0 02 00464	DLD	RX1
0078	00102	0 16 00461	MPY	L2
0079	00103	0 06 00444	DAD	T1
0080	00104	0 06 00514	DAD	CPRD
0081	00105	0401 62	LRS	14
0082	00106	0 04 00444	DST	T1
0083	00107	0 02 00460	DLD	L1
0084	00110	0 16 00464	MPY	RX1
0085	00111	0411 77	LLS	1
0086	00112	0 06 00444	DAD	T1
0087	00113	0 04 00476	DST	LRX
0088	00114	0 02 00460	DLD	L1
0089	00115	000201	IAB	
0090	00116	0 16 00471	MPY	RY2
0091	00117	000201	IAB	
0092	00120	140040	CRA	
0093	00121	0 04 00444	DST	T1
0094	00122	0 02 00460	DLD	L1
0095	00123	0 16 00471	MPY	RY2
0096	00124	0 06 00444	DAD	T1
0097	00125	0 04 00444	DST	T1
0098	00126	0 02 00470	DLD	RY1
0099	00127	0 16 00461	MPY	L2
0100	00130	0 06 00444	DAD	T1
0101	00131	0 06 00514	DAD	CPRD
0102	00132	0401 62	LRS	14
0103	00133	0 04 00444	DST	T1
0104	00134	0 02 00460	DLD	L1
0105	00135	0 16 00470	MPY	RY1
0106	00136	0411 77	LLS	1
0107	00137	0 06 00444	DAD	T1
0108	00140	0 04 00500	DST	LRY
0109	00141	0 02 00460	DLD	L1
0110	00142	000201	IAB	
0111	00143	0 16 00475	MPY	RZ2
0112	00144	000201	IAB	
0113	00145	140040	CRA	
0114	00146	0 04 00444	DST	T1

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0115	00147	0 02 00460	DLD	L1
0116	00150	0 16 00475	MPY	RZ2
0117	00151	0 06 00444	DAD	T1
0118	00152	0 04 00444	DST	T1
0119	00153	0 02 00474	DLD	RZ1
0120	00154	0 16 00461	MPY	L2
0121	00155	0 06 00444	DAD	T1
0122	00156	0 06 00514	DAD	CPRD
0123	00157	0401 62	LRS	14
0124	00160	0 04 00444	DST	T1
0125	00161	0 02 00460	DLD	L1
0126	00162	0 16 00474	MPY	RZ1
0127	00163	0411 77	LLS	1
0128	00164	0 06 00444	DAD	T1
0129	00165	0 04 00502	DST	LRZ
0130	00166	0 02 00464	DLD	RX1
0131	00167	000201	IAB	
0132	00170	0 16 00471	MPY	RY2
0133	00171	000201	IAB	
0134	00172	140040	CRA	
0135	00173	0 04 00444	DST	T1
0136	00174	0 02 00464	DLD	RX1
0137	00175	0 16 00471	MPY	RY2
0138	00176	0 06 00444	DAD	T1
0139	00177	0 04 00444	DST	T1
0140	00200	0 02 00470	DLD	RY1
0141	00201	0 16 00465	MPY	RY2
0142	00202	0 06 00444	DAD	T1
0143	00203	0 06 00514	DAD	CPRD
0144	00204	0401 62	LRS	14
0145	00205	0 04 00444	DST	T1
0146	00206	0 02 00464	DLD	RX1
0147	00207	0 16 00470	MPY	RY1
0148	00210	0411 77	LLS	1
0149	00211	0 06 00444	DAD	T1
0150	00212	0 04 00504	DST	RXRY
0151	00213	0 02 00464	DLD	RX1
0152	00214	000201	IAB	
0153	00215	0 16 00475	MPY	RZ2
0154	00216	000201	IAB	
0155	00217	140040	CRA	
0156	00220	0 04 00444	DST	T1
0157	00221	0 02 00464	DLD	RX1
0158	00222	0 16 00475	MPY	RZ2
0159	00223	0 06 00444	DAD	T1
0160	00224	0 04 00444	DST	T1
0161	00225	0 02 00474	DLD	RZ1
0162	00226	0 16 00465	MPY	RY2
0163	00227	0 06 00444	DAD	T1
0164	00230	0 06 00514	DAD	CPRD
0165	00231	0401 62	LRS	14
0166	00232	0 04 00444	DST	T1
0167	00233	0 02 00464	DLD	RX1
0168	00234	0 16 00474	MPY	RZ1
0169	00235	0411 77	LLS	1
0170	00236	0 06 00444	DAD	T1
0171	00237	0 04 00506	DST	RXRZ

MICPOCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0172	00240	0 02 00470	DLD	RY1
0173	00241	000201	IAB	
0174	00242	0 16 00475	MPY	RZ2
0175	00243	000201	TAB	
0176	00244	140040	CRA	
0177	00245	0 04 00444	DST	T1
0178	00246	0 02 00470	DLD	RY1
0179	00247	0 16 00475	MPY	RZ2
0180	00250	0 06 00444	DAD	T1
0181	00251	0 04 00444	DST	T1
0182	00252	0 02 00474	DLD	RZ1
0183	00253	0 16 00471	MPY	RY2
0184	00254	0 06 00444	DAD	T1
0185	00255	0 06 00514	DAD	CPRD
0186	00256	0401 62	LRS	14
0187	00257	0 04 00444	DST	T1
0188	00260	0 02 00470	DLD	RY1
0189	00261	0 16 00474	MPY	RZ1
0190	00262	0411 77	LLS	1
0191	00263	0 06 00444	DAD	T1
0192	00264	0 04 00510	DST	RYRZ
0193	00265	0 02 00516	DLD	ONQT
0194	00266	0 07 00472	DSB	RYSQ
0195	00267	0 07 00474	DSB	RZSQ
0196	00270	0 04 00446	DST	FXY
0197	00271	0 02 00504	DLD	RXRY
0198	00272	0 07 00502	DSB	LPZ
0199	00273	0 04 00450	DST	FXY
0200	00274	0 02 00506	DLD	RXRZ
0201	00275	0 06 00500	DAD	LRY
0202	00276	0 04 00452	DST	FXZ
0203	00277	0 02 00516	DLD	ONQT
0204	00300	0 07 00470	DSB	RKSQ
0205	00301	0 07 00474	DSB	RZSQ
0206	00302	0 04 00456	DST	FYY
0207	00303	0 02 00510	DLD	RYRZ
0208	00304	0 07 00476	DSB	LRX
0209	00305	0 04 00460	DST	FYZ
0210	00306	0 02 00504	DLD	RXRY
0211	00307	0 06 00502	DAD	LRZ
0212	00310	0 04 00454	DST	FXY
0213	00311	0 02 00516	DLD	ONQT
0214	00312	0 07 00470	DSB	RXSQ
0215	00313	0 07 00472	DSB	RYSQ
0216	00314	0 04 00466	DST	FZZ
0217	00315	0 02 00506	DLD	RXRZ
0218	00316	0 07 00500	DSB	LRY
0219	00317	0 04 00462	DST	FZX
0220	00320	0 02 00510	DLD	RYRZ
0221	00321	0 06 00476	DAD	LRX
0222	00322	0 04 00464	DST	FZY
0223	00323	0 02 00446	DLD	FXX
0224	00324	0 16 00614	MPY	DVBK
0225	00325	0 04 00666	DST	DVIX
0226	00326	0 02 00450	DLD	FYY
0227	00327	0 16 00616	MPY	DVBY
0228	00330	0 06 00666	DAD	DVIX

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0229	00331	0 04 00666	DST	DVIX
0230	00332	0 02 00452	DLD	FXZ
0231	00333	0 16 00620	MPY	DVBZ
0232	00334	0 06 00666	DAD	DVIX
0233	00335	0411 76	LLS	2
0234	00336	0 04 00666	DST	DVIX
0235	00337	0 02 00454	DLD	FYX
0236	00340	0 16 00614	MPY	DVBX
0237	00341	0 04 00670	DST	DVIY
0238	00342	0 02 00456	DLD	FYY
0239	00343	0 16 00616	MPY	DVBY
0240	00344	0 06 00670	DAD	DVIY
0241	00345	0 04 00670	DST	DVIY
0242	00346	0 02 00460	DLD	FYZ
0243	00347	0 16 00620	MPY	DVBZ
0244	00350	0 06 00670	DAD	DVIY
0245	00351	0411 76	LLS	2
0246	00352	0 04 00670	DST	DVIY
0247	00353	0 02 00462	DLD	FZX
0248	00354	0 16 00614	MPY	DVBX
0249	00355	0 04 00672	DST	DVIZ
0250	00356	0 02 00464	DLD	FZY
0251	00357	0 16 00616	MPY	DVBY
0252	00360	0 06 00672	DAD	DVIZ
0253	00361	0 04 00672	DST	DVIZ
0254	00362	0 02 00466	DLD	FZZ
0255	00363	0 16 00620	MPY	DVBZ
0256	00364	0 06 00672	DAD	DVIZ
0257	00365	0411 76	LLS	2
0258	00366	0 04 00672	DST	DVIZ
0259	00367	0 02 00614	DLD	DVBX
0260	00370	0 16 00447	MPY	FXX+1
0261	00371	0 04 00444	DST	T1
0262	00372	0 02 00616	DLD	DVBY
0263	00373	0 16 00451	MPY	FXY+1
0264	00374	0 06 00444	DAD	T1
0265	00375	0 04 00444	DST	T1
0266	00376	0 02 00620	DLD	DVBZ
0267	00377	0 16 00453	MPY	FXZ+1
0268	00400	0 06 00444	DAD	T1
0269	00401	0 06 00512	DAD	SQRD
0270	00402	0401 63	LRS	13
0271	00403	0 06 00666	DAD	DVIX
0272	00404	0 04 00666	DST	DVIX
0273	00405	0 02 00614	DLD	DVBX
0274	00406	0 16 00455	MPY	FYX+1
0275	00407	0 04 00444	DST	T1
0276	00410	0 02 00616	DLD	DVBY
0277	00411	0 16 00457	MPY	FYY+1
0278	00412	0 06 00444	DAD	T1
0279	00413	0 04 00444	DST	T1
0280	00414	0 02 00620	DLD	DVBZ
0281	00415	0 16 00461	MPY	FYZ+1
0282	00416	0 06 00444	DAD	T1
0283	00417	0 06 00512	DAD	SQRD
0284	00420	0401 63	LRS	13
0285	00421	0 06 00670	DAD	DVIY

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0286	00422	0 04 00670	DST	DVIY
0287	00423	0 02 00614	DLD	DVBX
0288	00424	0 16 00463	MPY	FZX+1
0289	00425	0 04 00444	DST	T1
0290	00426	0 02 00616	DLD	DVBY
0291	00427	0 16 00465	MPY	FZY+1
0292	00430	0 06 00444	DAD	T1
0293	00431	0 04 00444	DST	T1
0294	00432	0 02 00620	DLD	DVBZ
0295	00433	0 16 00467	MPY	FZZ+1
0296	00434	0 06 00444	DAD	T1
0297	00435	0 06 00512	DAD	SQRD
0298	00436	0401 63	LRS	13
0299	00437	0 06 00672	DAD	DVIZ
0300	00440	0 04 00672	DST	DVIZ
0301	00441	000005	SGL	
0302	00442	-0 01 00000	JMP*	VELA
0303	00444	000000	T1	DBP
	00445	000000		
0304	00446	000000	FXX	DBP
	00447	000000		
0305	00450	000000	FXY	DBP
	00451	000000		
0306	00452	000000	FXZ	DBP
	00453	000000		
0307	00454	000000	FYX	DBP
	00455	000000		
0308	00456	000000	FYY	DBP
	00457	000000		
0309	00460	000000	FYZ	DBP
	00461	000000		
0310	00462	000000	FZX	DBP
	00463	000000		
0311	00464	000000	FZY	DBP
	00465	000000		
0312	00466	000000	FZZ	DBP
	00467	000000		
0313	00470	000000	RXSQ	DBP
	00471	000000		
0314	00472	000000	RYSQ	DBP
	00473	000000		
0315	00474	000000	RZSQ	DBP
	00475	000000		
0316	00476	000000	LRX	DBP
	00477	000000		
0317	00500	000000	LRY	DBP
	00501	000000		
0318	00502	000000	LRZ	DBP
	00503	000000		
0319	00504	000000	RXRY	DBP
	00505	000000		
0320	00506	000000	RXRZ	DBP
	00507	000000		
0321	00510	000000	RYRZ	DBP
	00511	000000		
0322	00512	000000	SQRD OCT	0,10000
	00513	010000		

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0323	00514	000000	CPRD OCT	0,20000
	00515	020000		
0324	00516	020000	ONQT OCT	20000,0
	00517	000000		
0325		000460	L1 EQU	*460
0326		000461	L2 EQU	L1+1
0327		000464	RX1 EQU	L1+4
0328		000465	RX2 EQU	L1+5
0329		000470	RY1 EQU	L1+8
0330		000471	RY2 EQU	L1+9
0331		000474	RZ1 EQU	L1+12
0332		000475	RZ2 EQU	L1+13
0333		000614	DVBX EQU	*614
0334		000616	DVBY EQU	DVBX+2
0335		000620	DVBZ EQU	DVBX+4
0336		000666	DVIX EQU	*666
0337		000670	DVIY EQU	DVIX+2
0338		000672	DVIZ EQU	DVIX+4
0339			END	

PROGRAM NAME:

SOURCE: VACU

BINARY: BVACU

ENTRY POINTS (location): VACU ('05506)

GENERAL DESCRIPTION:

This subroutine, when called, accumulates delta velocity in the inertial frame (DVIX, DVYIY and DVIZ calculated by the velocity algorithm, program source name VESP subroutine entry point VELA). The three accumulators (XAV1-XAV3, YAV1-YAV3 and ZAV1-ZAV3) are triple precision accumulators and a brief examination of this subroutine will show that it performs the following three tasks:

$$XAV = XAV + \frac{DVIX}{2^{15}}$$

$$YAV = YAV + \frac{DVYIY}{2^{15}}$$

$$ZAV = ZAV + \frac{DVIZ}{2^{15}}$$

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001			REL	
0002			SUBR	VACU
0003 00000	0 000000	VACU	DAC	**
0004 00001	000007		DBL	
0005 00002	0 02 00666		DLD	DVIX
0006 00003	140040		CRA	
0007 00004	0 06 00446		DAD	XAV3
0008 00005	0 04 00446		DST	XAV3
0009 00006	000201		IAB	
0010 00007	140040		CRA	
0011 00010	000201		IAB	
0012 00011	0 06 00666		DAD	DVIX
0013 00012	0401 61		LRS	15
0014 00013	0 06 00444		DAD	XAV1
0015 00014	0 04 00444		DST	XAV1
0016 00015	0 02 00670		DLD	DVIY
0017 00016	140040		CRA	
0018 00017	0 06 00452		DAD	YAV3
0019 00020	0 04 00452		DST	YAV3
0020 00021	000201		IAB	
0021 00022	140040		CRA	
0022 00023	000201		IAB	
0023 00024	0 06 00670		DAD	DVIY
0024 00025	0401 61		LRS	15
0025 00026	0 06 00450		DAD	YAV1
0026 00027	0 04 00450		DST	YAV1
0027 00030	0 02 00672		DLD	DVIZ
0028 00031	140040		CRA	
0029 00032	0 06 00456		DAD	ZAV3
0030 00033	0 04 00456		DST	ZAV3
0031 00034	000201		IAB	
0032 00035	140040		CRA	
0033 00036	000201		IAB	
0034 00037	0 06 00672		DAD	DVIZ
0035 00040	0401 61		LRS	15
0036 00041	0 06 00454		DAD	ZAV1
0037 00042	0 04 00454		DST	ZAV1
0038 00043	000005		SGL	
0039 00044	140040		CRA	
0040 00045	0 04 00446		STA	XAV3
0041 00046	0 04 00452		STA	YAV3
0042 00047	0 04 00456		STA	ZAV3
0043 00050	-0 01 00000		JMP*	VACU
0044	000666	DVIX	EQU	'666
0045	000670	DVIY	EQU	DVIX+2
0046	000672	DVIZ	EQU	DVIX+4
0047	000444	XAV1	EQU	'444
0048	000446	XAV3	EQU	XAV1+2
0049	000450	YAV1	EQU	XAV1+4
0050	000452	YAV3	EQU	XAV1+6
0051	000454	ZAV1	EQU	XAV1+8
0052	000456	ZAV3	EQU	XAV1+10
0053			END	

PROGRAM NAME

SOURCE: ERC6

BINARY: BERC6

ENTRY POINTS (location): ERCO ('2726)

GENERAL DESCRIPTION:

This subroutine will do the equivalent of torquing a gyro in a gimbal IMU. It essentially compensates the gyros for a drift in the inertial frame and is used to take out WIE, earth rate, thus the acronym ERCO or earth rate compensation. It does this by transforming the negative of the drift in the inertial frame into the body frame and adding it to the gyros as an equivalent NBD. It makes use of the cosine matrix (C_B^I) developed from the quaternion by the subroutine VELA which transforms the ΔV_B into ΔV_I . The gyro drift in the body frame due to earth rate is:

$$\begin{bmatrix} \omega_{IEXB} \\ \omega_{IEYB} \\ \omega_{IEZB} \end{bmatrix} = C_B^{IT} \begin{bmatrix} \omega_{IEXI} \\ \omega_{IEYI} \\ \omega_{IEZI} \end{bmatrix}$$

C_B^I is created by VELA and its elements are FXX, FXY, FXZ, FYX, FYY, FYZ, FZX, FZY and FZZ. This subroutine gains access to the constants by using the pseudo-op XAC or external address constant. For example, the pseudo-op XFXX XAC FXX puts the address of FXX in the location called XFXX. Of course, the transpose of the above matrix (C_B^{IT}) is FXX, FYX, FZX, FXY, FYY, FZY, FXZ, FYZ and FZZ.

The X, Y and Z inertial rates to be compensated for are stored in octal locations 250, 251 and 252 respectively. These are specially scaled constants that are the negative of the earth rate sensed on these inertial axes. If, for example, the X, Y and Z inertial axes were north, east and down at this latitude ($42^\circ, 21', 51''$), locations 250, 251 and 252 would contain the octal constants -44121, 0 and 40763. The $\Delta\theta_X$, $\Delta\theta_Y$ and $\Delta\theta_Z$ to be compensated are contained in octal locations 414, 416 and 420. The subroutine itself is so straight-forward that no flow chart is necessary.

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

			REL	
			SUBR	ERCO
0001				
0002				
0003	00000	0 000000	ERCO	DAC **
0004	00001	000007		DBL
0005	00002	-0 02 00074	DLD*	XFXX
0006	00003	0 06 00072	DAD	MRRD
0007	00004	0 16 00250	MPY	'250
0008	00005	0 04 00064	DST	XERC
0009	00006	-0 02 00077	DLD*	XFYX
0010	00007	0 06 00072	DAD	MRRD
0011	00010	0 16 00251	MPY	'251
0012	00011	0 06 00064	DAD	XERC
0013	00012	0 04 00064	DST	XERC
0014	00013	-0 02 00102	DLD*	XFZX
0015	00014	0 06 00072	DAD	MRRD
0016	00015	0 16 00252	MPY	'252
0017	00016	0 06 00064	DAD	XERC
0018	00017	0401 64	LRS	12
0019	00020	0 06 00414	DAD	'414
0020	00021	0 04 00414	DST	'414
0021	00022	-0 02 00075	DLD*	XFXY
0022	00023	0 06 00072	DAD	MRRD
0023	00024	0 16 00250	MPY	'250
0024	00025	0 04 00066	DST	YERC
0025	00026	-0 02 00100	DLD*	XFYY
0026	00027	0 06 00072	DAD	MRRD
0027	00030	0 16 00251	MPY	'251
0028	00031	0 06 00066	DAD	YERC
0029	00032	0 04 00066	DST	YERC
0030	00033	-0 02 00103	DLD*	XFZY
0031	00034	0 06 00072	DAD	MRRD
0032	00035	0 16 00252	MPY	'252
0033	00036	0 06 00066	DAD	YERC
0034	00037	0401 64	LRS	12
0035	00040	0 06 00416	DAD	'416
0036	00041	0 04 00416	DST	'416
0037	00042	-0 02 00076	DLD*	XPXZ
0038	00043	0 06 00072	DAD	MRRD
0039	00044	0 16 00250	MPY	'250
0040	00045	0 04 00070	DST	ZERC
0041	00046	-0 02 00101	DLD*	XFYZ
0042	00047	0 06 00072	DAD	MRRD
0043	00050	0 16 00251	MPY	'251
0044	00051	0 06 00070	DAD	ZERC
0045	00052	0 04 00070	DST	ZERC
0046	00053	-0 02 00104	DLD*	XFZZ
0047	00054	0 06 00072	DAD	MRRD
0048	00055	0 16 00252	MPY	'252
0049	00056	0 06 00070	DAD	ZERC
0050	00057	0401 64	LRS	12
0051	00060	0 06 00420	DAD	'420
0052	00061	0 04 00420	DST	'420
0053	00062	000005	SGL	
0054	00063	-0 01 00000	JMP*	ERCO
0055	00064	000000 XERC	DBP	0
	00065	000000		
0056	00066	000000 YERC	DBP	0

MTCPOCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

00067	000000			
0057	00070	000000	ZFRC DBP	0
	00071	000000		
0058	00072	000000	MRRD OCT	0,40000
	00073	040000		
0059	00074	0 000000	XFXX XAC	FXX
0060	00075	0 000000	XFXY XAC	FXY
0061	00076	0 000000	XFXZ XAC	FXZ
0062	00077	0 000000	XFYX XAC	FYX
0063	00100	0 000000	XFYY XAC	FYY
0064	00101	0 000000	XFYZ XAC	FYZ
0065	00102	0 000000	XFZX XAC	FZX
0066	00103	0 000000	XFZY XAC	FZY
0067	00104	0 000000	XFZZ XAC	FZZ
0068			END	

PROGRAM NAME

SOURCE: AA6S

BINARY: BAA6S

RELATED MEMOS: T-493

ENTRY POINTS (location): ATTA ('05060)

GENERAL DESCRIPTION:

This subroutine when called will perform a third order attitude algorithm to update the quaternion of rotation. The equation representing the algorithm can be expressed as:

$$\rho_x' = \lambda S\alpha_x + R\rho_x + S(\rho_y\alpha_z - \rho_z\alpha_y)$$

$$\rho_y' = \lambda S\alpha_y + R\rho_y + S(\rho_z\alpha_x - \rho_x\alpha_z)$$

$$\rho_z' = \lambda S\alpha_z + R\rho_z + S(\bar{\rho}_z\alpha_y - \rho_y\alpha_x)$$

$$\lambda' = -S(\bar{\rho} \cdot \bar{\alpha}) + R\lambda$$

where

$$\bar{\alpha} = \Delta \frac{\theta}{2}$$

$$M = \bar{\alpha} \cdot \bar{\alpha}$$

$$R = (1 - \frac{1}{2}M)$$

$$S = (1 - \frac{1}{6}M)$$

expanding this equation, if we define $\Delta = \Delta\theta_x\Delta\theta_x + \Delta\theta_y\Delta\theta_y + \Delta\theta_z\Delta\theta_z$

$$\rho_x' = \lambda(1 - \frac{\Delta}{24})\frac{\Delta\theta_x}{2} + (1 - \frac{\Delta}{8})\rho_x + (1 - \frac{\Delta}{24})\left(\frac{\rho_y\Delta\theta_z - \rho_z\Delta\theta_y}{2}\right)$$

therefore:

$$\rho_x' = \rho_x + \frac{\lambda\Delta\theta_x}{2} - \frac{\lambda\Delta\Delta\theta_x}{48} - \frac{\Delta\rho_x}{8} + \frac{\rho_y\Delta\theta_z - \rho_z\Delta\theta_y}{2} - \Delta\frac{(\rho_y\Delta\theta_z - \rho_z\Delta\theta_y)}{48}$$

to determine ρ_y' , replace x, y, z subscripts by y, z, x in the equation for ρ_x' . To determine ρ_z' , replace x, y, z subscripts by z, x, y in the equation

for ρ_x' . Then,

$$\lambda' = -S(\bar{\rho} + \bar{\alpha}) + R\lambda$$

therefore:

$$\lambda' = \lambda - \frac{\Delta}{8}\lambda - \frac{(\rho_x \Delta \theta_x + \rho_y \Delta \theta_y + \rho_z \Delta \theta_z)}{2} + \frac{\Delta}{48}(\rho_x \Delta \theta_x + \rho_y \Delta \theta_y + \rho_z \Delta \theta_z)$$

In the present DDP516 implementation the actual numbers in the computer are scaled as follows:

$$DX = 2^6 \Delta \theta_x \text{ or } \Delta \theta_x = DX 2^{-6}$$

$$DY = 2^6 \Delta \theta_y \text{ or } \Delta \theta_y = DY 2^{-6}$$

$$DZ = 2^6 \Delta \theta_z \text{ or } \Delta \theta_z = DZ 2^{-6}$$

$$RX = \frac{\rho_x}{2} \text{ or } \rho_x = 2RX$$

$$RY = \frac{\rho_y}{2} \text{ or } \rho_y = 2RY$$

$$RZ = \frac{\rho_z}{2} \text{ or } \rho_z = 2RZ$$

$$L = \frac{\lambda}{2} \text{ or } \lambda = 2L$$

$$D^2 = 2^{12} \Delta \text{ or } \Delta = D^2 2^{-12} = (DX^2 + DY^2 + DZ^2) 2^{-12}$$

now substituting this scaling into the equation given above we find:

$$\begin{aligned} 2RX' &= 2RX + \frac{L DX}{2^6} - \frac{L D^2 DX}{3 2^{21}} - \frac{D^2 RX}{2^{14}} \\ &\quad + \frac{RY DZ - RZ DY}{2^6} - \frac{D^2 (RY DZ - RZ DY)}{3 2^{21}} \end{aligned}$$

if we define

$$\Delta RX = RX' - RX$$

then,

$$\Delta RX = \frac{L DX}{2^7} - \frac{L D^2 DX}{3 \cdot 2^{22}} - \frac{D^2 RX}{2^{15}} + \frac{RY DZ - RZ DY}{2^7} - \frac{D^2(RY DZ - RZ DY)}{3 \cdot 2^{22}}$$

also,

$$2L' = 2L - \frac{D^2 L}{2^{14}} - \frac{RX DX + RY DY + RZ DZ}{2^6}$$

$$+ \frac{D^2(RX DX + RY DY + RZ DZ)}{3 \cdot 2^{21}}$$

and if

$$\Delta L = L' - L,$$

$$\Delta L = -\frac{D^2 L}{2^{15}} - \frac{RX DX + RY DY + RZ DZ}{2^7} + \frac{D^2(RX DX + RY DY + RZ DZ)}{3 \cdot 2^{22}}$$

The equations for ΔRY and ΔRZ are obtained in a similar manner.

A 16 bit word in the DDP516 is made up of a sign bit and 15 bits of fraction. For example, 0110 000 000 000 000 represents +.75 decimal. Each quaternion component is made up of three of these numbers. For example, L will be represented by

$$L_1 + \frac{L_2}{2^{15}} + \frac{L_3}{2^{30}},$$

which is equivalent to a 45 bit signed fraction where the sign bits of L_2 and L_3 are ignored. In core L_1 is in location '460, L_2 in '461 and $L_3 + '40000^*$ is in '463. Location '462 is normally zero except when '463 overflows into '462 which is then added to '461. RX, RY and RZ follow L in core in locations '464, '470 and '474 respectively. A unit quaternion in core

$$(\lambda = 1, \rho_x = 0, \rho_y = 0, \rho_z = 0)$$

or

$$L = 1/2, RX = 0, RY = 0, RZ = 0$$

would look like the following (in octal):

* Since only L_1 and L_2 are used in the velocity algorithm, the '40000 (1/2) added to L_3 is for rounding.

loc.	'460	'461	'462	'463
L	040000	000000	000000	040000
	L1	L2		L3+'40000
loc.	'464	'465	'466	'467
RX	000000	000000	000000	040000
	RX1	RX2		RX3+'40000
loc.	'470	'471	'472	'473
RY	000000	000000	000000	040000
	RY1	RY2		RY3+'40000
loc.	'474	'475	'476	'477
RZ	000000	000000	000000	040000
	RZ1	RZ2		RZ3+'40000

DX, DY and DZ are single precision fractions. However, D^2 will be 30 bits and will be represented by

$$D^2_1 + \frac{D^2_2}{2^{15}}$$

With these considerations in mind the quaternion update equations can be expanded as:

$$\begin{aligned}
\Delta RX &= \frac{L1 \ DX}{2^7} + \frac{L2 \ DX}{2^{22}} + \frac{L3 \ DX}{2^{37}} \\
&\quad - \frac{DX \ D^2_1 \ L1}{3 \times 2^{22}} - \frac{DX \ D^2_1 \ L2}{3 \times 2^{37}} - \frac{DX \ D^2_1 \ L3}{3 \times 2^{52}} \\
&\quad - \frac{DX \ D^2_2 \ L1}{3 \times 2^{37}} - \frac{DX \ D^2_2 \ L2}{3 \times 2^{52}} - \frac{DX \ D^2_2 \ L3}{3 \times 2^{67}} \\
&\quad - \frac{D^2_1 \ RX1}{2^{15}} - \frac{D^2_1 \ RX2}{2^{30}} - \frac{D^2_1 \ RX3}{2^{45}} \\
&\quad - \frac{D^2_2 \ RX1}{2^{30}} - \frac{D^2_2 \ RX2}{2^{45}} - \frac{D^2_2 \ RX3}{2^{60}} \\
&\quad + \frac{RY1 \ DZ}{2^7} + \frac{RY2 \ DZ}{2^{22}} + \frac{RY3 \ DZ}{2^{37}} \\
&\quad - \frac{RZ1 \ DY}{2^7} - \frac{RZ2 \ DY}{2^{22}} - \frac{RZ3 \ DY}{2^{37}}
\end{aligned}$$

$$\begin{aligned}
& - \frac{D^2_1 RY1 DZ}{3 \times 2^{22}} - \frac{D^2_1 RY2 DZ}{3 \times 2^{37}} - \frac{D^2_1 RY3 DZ}{3 \times 2^{52}} \\
& + \frac{D^2_1 RZ1 DY}{3 \times 2^{22}} + \frac{D^2_1 RZ2 DY}{3 \times 2^{37}} + \frac{D^2_1 RZ3 DY}{3 \times 2^{52}} \\
& - \frac{D^2_2 RY1 DZ}{3 \times 2^{37}} - \frac{D^2_2 RY2 DZ}{3 \times 2^{52}} - \frac{D^2_2 RY3 DZ}{3 \times 2^{67}} \\
& + \frac{D^2_2 RZ1 DY}{3 \times 2^{37}} + \frac{D^2_2 RZ2 DY}{3 \times 2^{52}} + \frac{D^2_2 RZ3 DY}{3 \times 2^{67}} \\
\Delta L = & - \frac{D^2_1 L1}{2^{15}} - \frac{D^2_1 L2}{2^{30}} - \frac{D^2_1 L3}{2^{45}} - \frac{D^2_2 L1}{2^{30}} - \frac{D^2_2 L2}{2^{45}} - \frac{D^2_2 L3}{2^{60}} \\
& - \frac{RX1 DX}{2^7} - \frac{RX2 DX}{2^{22}} - \frac{RX3 DX}{2^{37}} - \frac{RY1 DY}{2^7} - \frac{RY2 DY}{2^{22}} - \frac{RY3 DY}{2^{37}} \\
& - \frac{RZ1 DZ}{2^7} - \frac{RZ2 DZ}{2^{22}} - \frac{RZ3 DZ}{2^{37}} \\
& + \frac{D^2_1 RX1 DX}{3 \times 2^{22}} + \frac{D^2_1 RX2 DX}{3 \times 2^{37}} + \frac{D^2_1 RX3 DX}{3 \times 2^{52}} \\
& + \frac{D^2_1 RY1 DY}{3 \times 2^{22}} + \frac{D^2_1 RY2 DY}{3 \times 2^{37}} + \frac{D^2_1 RY3 DY}{3 \times 2^{52}} \\
& + \frac{D^2_1 RZ1 DZ}{3 \times 2^{22}} + \frac{D^2_1 RZ2 DZ}{3 \times 2^{37}} + \frac{D^2_1 RZ3 DZ}{3 \times 2^{52}} \\
& + \frac{D^2_2 RX1 DX}{3 \times 2^{37}} + \frac{D^2_2 RX2 DX}{3 \times 2^{52}} + \frac{D^2_2 RX3 DX}{3 \times 2^{67}} \\
& + \frac{D^2_2 RY1 DY}{3 \times 2^{37}} + \frac{D^2_2 RY2 DY}{3 \times 2^{52}} + \frac{D^2_2 RY3 DY}{3 \times 2^{67}} \\
& + \frac{D^2_2 RZ1 DZ}{3 \times 2^{37}} + \frac{D^2_2 RZ2 DZ}{3 \times 2^{52}} + \frac{D^2_2 RZ3 DZ}{3 \times 2^{67}}
\end{aligned}$$

With ΔRY and ΔRZ defined in a similar manner.

The algorithm that is written considers L, RX, RY and RZ to have only 37 bits of significance. Therefore, all terms in the final equations with denominators greater than 2^{37} can be ignored. This simplifies the final equations to be programmed to:

$$\begin{aligned}\Delta RX &= \frac{L_1 DX}{2^7} + \frac{L_2 DX}{2^{22}} - \frac{DX D^2_1 L_1}{3 \times 2^{22}} \\ &\quad - \frac{D^2_1 RX_1}{2^{15}} - \frac{D^2_1 RX_2}{2^{30}} - \frac{D^2_2 RX_1}{2^{30}} \\ &\quad + \frac{RY_1 DZ}{2^7} + \frac{RY_2 DZ}{2^{22}} - \frac{RZ_1 DY}{2^7} - \frac{RZ_2 DY}{2^{22}} \\ &\quad - \frac{D^2_1 RY_1 DZ}{3 \times 2^{22}} + \frac{D^2_1 RZ_1 DY}{3 \times 2^{22}}\end{aligned}$$

and,

$$\begin{aligned}\Delta L &= -\frac{D^2_1 L_1}{2^{15}} - \frac{D^2_1 L_2}{2^{30}} - \frac{D^2_2 L_1}{2^{30}} \\ &\quad - \frac{RX_1 DX}{2^7} - \frac{RX_2 DX}{2^{22}} - \frac{RY_1 DY}{2^7} - \frac{RY_2 DY}{2^{22}} - \frac{RZ_1 DZ}{2^7} - \frac{RZ_2 DZ}{2^{22}} \\ &\quad + \frac{D^2_1 RX_1 DX}{3 \times 2^{22}} + \frac{D^2_1 RY_1 DY}{3 \times 2^{22}} + \frac{D^2_1 RZ_1 DZ}{3 \times 2^{22}}\end{aligned}$$

The final simplification is to replace


$$(-2D^2_1)/3$$

with a variable called D3 and to calculate $2^7 \Delta RX$, $2^7 \Delta RY$, $2^7 \Delta RZ$ and $2^7 \Delta L$ before deriving ΔRX , ΔRY , ΔRZ and ΔL . The program equations then are:

$$\begin{aligned}2^7 \Delta RX &= L_1 DX + \frac{L_2 DX}{2^{15}} + \frac{DX D3 L_1}{2^{16}} \\ &\quad - \frac{D^2_1 RX_1}{2^8} - \frac{D^2_1 RX_2}{2^{23}} - \frac{D^2_2 RX_1}{2^{23}} \\ &\quad + RY_1 DZ + \frac{RY_2 DZ}{2^{15}} - RZ_1 DY - \frac{RZ_2 DY}{2^{15}} \\ &\quad + \frac{D3 RY_1 DZ}{2^{16}} - \frac{D3 RZ_1 DY}{2^{16}}\end{aligned}$$

and,

$$\begin{aligned} 2^7 \Delta L &= -\frac{D_1^2 L_1}{2^8} - \frac{D_1^2 L_2}{2^{23}} - \frac{D_2^2 L_1}{2^{23}} \\ &\quad - RX_1 DX - \frac{RX_2 DX}{2^{15}} - RY_1 DY - \frac{RY_2 DY}{2^{15}} - RZ_1 DZ - \frac{RZ_2 DZ}{2^{15}} \\ &\quad - \frac{D_3 RX_1 DX}{2^{16}} - \frac{D_3 RY_1 DY}{2^{16}} - \frac{D_3 RZ_1 DZ}{2^{16}} \end{aligned}$$



FLOWCHART - ATTA

The Double Precision Accumulator

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0001	REL		
0002	SUBR	ATTA	
0003 00000	0 000000	ATTA DAC	**
0004 00001	0 02 00414	LDA	DX
0005 00002	000007	DBL	
0006 00003	0 16 00414	MPY	DX
0007 00004	0 04 00410	DST	D1
0008 00005	0 02 00416	DLD	DY
0009 00006	0 16 00416	MPY	DY
0010 00007	0 06 00410	DAD	D1
0011 00010	0 04 00410	DST	D1
0012 00011	0 02 00420	DLD	DZ
0013 00012	0 16 00420	MPY	DZ
0014 00013	0 06 00410	DAD	D1
0015 00014	0 04 00410	DST	D1
0016 00015	0 16 00424	MPY	= 125253
0017 00016	0 06 00420	DAD	TRND
0018 00017	0 04 00412	DST	D3
0019 00020	0 02 00416	DLD	DY
0020 00021	0 16 00475	MPY	RZ2
0021 00022	0 04 00414	DST	S1
0022 00023	0 02 00420	DLD	DZ
0023 00024	0 16 00471	MPY	RY2
0024 00025	0 07 00414	DSB	S1
0025 00026	0 04 00414	DST	S1
0026 00027	0 02 00414	DLD	DX
0027 00030	0 16 00461	MPY	L2
0028 00031	0 06 00414	DAD	S1
0029 00032	0 04 00414	DST	S1
0030 00033	0 02 00464	DLD	RX1
0031 00034	0 16 00411	MPY	D2
0032 00035	0 04 00416	DST	S2
0033 00036	0 02 00410	DLD	D1
0034 00037	0 16 00465	MPY	RX2
0035 00040	0 06 00416	DAD	S2
0036 00041	0401 61	LRS	15
0037 00042	0 04 00416	DST	S2
0038 00043	0 02 00410	DLD	D1
0039 00044	0 16 00464	MPY	RX1
0040 00045	0 06 00416	DAD	S2
0041 00046	0 04 00416	DST	S2
0042 00047	0 02 00416	DLD	DY
0043 00050	0 16 00474	MPY	RZ1
0044 00051	0 04 00402	DST	DLRX
0045 00052	0 02 00420	DLD	DZ
0046 00053	0 16 00470	MPY	RY1
0047 00054	0 07 00402	DSB	DLRX
0048 00055	0 04 00402	DST	DLRX
0049 00056	0 02 00414	DLD	DX
0050 00057	0 16 00460	MPY	L1
0051 00060	0 06 00402	DAD	DLRX
0052 00061	0 04 00402	DST	DLRX
0053 00062	0 16 00412	MPY	D3
0054 00063	0401 77	LRS	1
0055 00064	0 06 00414	DAD	S1
0056 00065	0401 71	LRS	7
0057 00066	0 07 00416	DSB	S2

MICROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0058	00067	0 06 00422	DAD	SRND
0059	00070	0401 70	LRS	8
0060	00071	0 06 00402	DAD	DLRX
0061	00072	0 04 00402	DST	DLRX
0062	00073	0 02 00420	DLD	DZ
0063	00074	0 16 00465	MPY	RX2
0064	00075	0 04 00414	DST	S1
0065	00076	0 02 00414	DLD	DX
0066	00077	0 16 00475	MPY	RZ2
0067	00100	0 07 00414	DSB	S1
0068	00101	0 04 00414	DST	S1
0069	00102	0 02 00416	DLD	DY
0070	00103	0 16 00461	MPY	L2
0071	00104	0 06 00414	DAD	S1
0072	00105	0 04 00414	DST	S1
0073	00106	0 02 00470	DID	RY1
0074	00107	0 16 00411	MPY	D2
0075	00110	0 04 00416	DST	S2
0076	00111	0 02 00410	DLC	D1
0077	00112	0 16 00471	MPY	RY2
0078	00113	0 06 00416	DAD	S2
0079	00114	0401 61	LRS	15
0080	00115	0 04 00416	DST	S2
0081	00116	0 02 00410	DID	D1
0082	00117	0 16 00470	MPY	RY1
0083	00120	0 06 00416	DAD	S2
0084	00121	0 04 00416	DST	S2
0085	00122	0 02 00420	DLD	DZ
0086	00123	0 16 00464	MPY	RX1
0087	00124	0 04 00404	DST	DLRY
0088	00125	0 02 00414	DLD	DX
0089	00126	0 16 00474	MPY	RZ1
0090	00127	0 07 00404	DSB	DLRY
0091	00130	0 04 00404	DST	DLRY
0092	00131	0 02 00416	DLD	DY
0093	00132	0 16 00460	MPY	L1
0094	00133	0 06 00404	DAD	DLRY
0095	00134	0 04 00404	DST	DLRY
0096	00135	0 16 00412	MPY	D3
0097	00136	0401 77	LRS	1
0098	00137	0 06 00414	DAD	S1
0099	00140	0401 71	LRS	7
0100	00141	0 07 00416	DSB	S2
0101	00142	0 06 00422	DAD	SRND
0102	00143	0401 70	LRS	8
0103	00144	0 06 00404	DAD	DLRY
0104	00145	0 04 00404	DST	DLRY
0105	00146	0 02 00414	DLD	DX
0106	00147	0 16 00471	MPY	RY2
0107	00150	0 04 00414	DST	S1
0108	00151	0 02 00416	DLD	DY
0109	00152	0 16 00465	MPY	RX2
0110	00153	0 07 00414	DSB	S1
0111	00154	0 04 00414	DST	S1
0112	00155	0 02 00420	DLD	DZ
0113	00156	0 16 00461	MPY	L2
0114	00157	0 06 00414	DAD	S1

MICROCOMP TELECOMMUNICATED DATA
 DDP-516 ASSEMBLY LISTING

0115 00160	0 04 00414	DST	S1
0116 00161	0 02 00474	DLD	RZ1
0117 00162	0 16 00411	MPY	D2
0118 00163	0 04 00416	DST	S2
0119 00164	0 02 00410	DLD	D1
0120 00165	0 16 00475	MPY	RZ2
0121 00166	0 06 00416	DAD	S2
0122 00167	0401 61	LRS	15
0123 00170	0 04 00416	DST	S2
0124 00171	0 02 00410	DLD	D1
0125 00172	0 16 00474	MPY	RZ1
0126 00173	0 06 00416	DAD	S2
0127 00174	0 04 00416	DST	S2
0128 00175	0 02 00414	DLD	DX
0129 00176	0 16 00470	MPY	RY1
0130 00177	0 04 00406	DST	DLRZ
0131 00200	0 02 00416	DLD	DY
0132 00201	0 16 00464	MPY	RX1
0133 00202	0 07 00406	DSB	DLRZ
0134 00203	0 04 00406	DST	DLRZ
0135 00204	0 02 00420	DLD	DZ
0136 00205	0 16 00460	MPY	L1
0137 00206	0 06 00406	DAD	DLRZ
0138 00207	0 04 00406	DST	DLRZ
0139 00210	0 16 00412	MPY	D3
0140 00211	0401 77	LRS	1
0141 00212	0 06 00414	DAD	S1
0142 00213	0401 71	LRS	7
0143 00214	0 07 00416	DSB	S2
0144 00215	0 06 00422	DAD	SRND
0145 00216	0401 70	LRS	8
0146 00217	0 06 00406	DAD	DLRZ
0147 00220	0 04 00406	DST	DLRZ
0148 00221	0 02 00414	DLD	DX
0149 00222	0 16 00465	MPY	RX2
0150 00223	0 04 00414	DST	S1
0151 00224	0 02 00416	DLD	DY
0152 00225	0 16 00471	MPY	RY2
0153 00226	0 06 00414	DAD	S1
0154 00227	0 04 00414	DST	S1
0155 00230	0 02 00420	DLD	DZ
0156 00231	0 16 00475	MPY	RZ2
0157 00232	0 06 00414	DAD	S1
0158 00233	0 04 00414	DST	S1
0159 00234	0 02 00460	DLD	L1
0160 00235	0 16 00411	MPY	D2
0161 00236	0 04 00416	DST	S2
0162 00237	0 02 00410	DLD	D1
0163 00240	0 16 00461	MPY	L2
0164 00241	0 06 00416	DAD	S2
0165 00242	0401 61	LRS	15
0166 00243	0 04 00416	DST	S2
0167 00244	0 02 00410	DLD	D1
0168 00245	0 16 00460	MPY	L1
0169 00246	0 06 00416	DAD	S2
0170 00247	0 04 00416	DST	S2
0171 00250	0 02 00414	DLD	DX

MTCROCOMP TELECOMMUNICATED DATA

DDP-516 ASSEMBLY LISTING

0172	00251	0 16 00464	MPY	RX1
0173	00252	0 04 00400	DST	DLL
0174	00253	0 02 00416	DLD	DY
0175	00254	0 16 00470	MPY	RY1
0176	00255	0 06 00400	DAD	DLI
0177	00256	0 04 00400	DST	DLL
0178	00257	0 02 00420	DLD	DZ
0179	00260	140407	TCA	
0180	00261	0 16 00474	MPY	RZ1
0181	00262	0 07 00400	DSB	DLL
0182	00263	0 04 00400	DST	DLL
0183	00264	0 16 00412	MPY	D3
0184	00265	0401 77	LRS	1
0185	00266	0 07 00414	DSB	S1
0186	00267	0401 71	LRS	7
0187	00270	0 07 00416	DSB	S2
0188	00271	0 06 00422	DAD	SRND
0189	00272	0401 70	LRS	8
0190	00273	0 06 00400	DAD	DLL
0191	00274	0 04 00400	DST	DLI
0192	00275	140040	CRA	
0193	00276	000201	IAB	
0194	00277	0401 71	LRS	7
0195	00300	140040	CRA	
0196	00301	0 06 00462	DAD	L3
0197	00302	0 04 00462	DST	L3
0198	00303	000201	IAB	
0199	00304	140040	CRA	
0200	00305	0 06 00460	DAD	L1
0201	00306	0 04 00460	DST	L1
0202	00307	0 02 00400	DLD	DLL
0203	00310	0401 71	LRS	7
0204	00311	0 06 00460	DAD	L1
0205	00312	0 04 00460	DST	L1
0206	00313	0 02 00402	DLD	DLRX
0207	00314	140040	CRA	
0208	00315	000201	IAB	
0209	00316	0401 71	LRS	7
0210	00317	140040	CRA	
0211	00320	0 06 00466	DAD	RX3
0212	00321	0 04 00466	DST	RX3
0213	00322	000201	IAB	
0214	00323	140040	CRA	
0215	00324	0 06 00464	DAD	RX1
0216	00325	0 04 00464	DST	RX1
0217	00326	0 02 00402	DLD	DLRX
0218	00327	0401 71	LRS	7
0219	00330	0 06 00464	DAD	RX1
0220	00331	0 04 00464	DST	RX1
0221	00332	0 02 00404	DLD	DLRY
0222	00333	140040	CRA	
0223	00334	000201	IAB	
0224	00335	0401 71	LRS	7
0225	00336	140040	CRA	
0226	00337	0 06 00472	DAD	RY3
0227	00340	0 04 00472	DST	RY3
0228	00341	000201	IAB	

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0229	00342	140040	CRA	
0230	00343	0 06 00470	DAD	RY1
0231	00344	0 04 00470	DST	RY1
0232	00345	0 02 00404	DLD	DLRY
0233	00346	0401 71	LRS	7
0234	00347	0 06 00470	DAD	RY1
0235	00350	0 04 00470	DST	RY1
0236	00351	0 02 00406	DLD	DLRZ
0237	00352	140040	CRA	
0238	00353	000201	IAB	
0239	00354	0401 71	LRS	7
0240	00355	140040	CRA	
0241	00356	0 06 00476	DAD	RZ3
0242	00357	0 04 00476	DST	RZ3
0243	00360	000201	IAB	
0244	00361	140040	CRA	
0245	00362	0 06 00474	DAD	RZ1
0246	00363	0 04 00474	DST	RZ1
0247	00364	0 02 00406	DLD	DLRZ
0248	00365	0401 71	LRS	7
0249	00366	0 06 00474	DAD	RZ1
0250	00367	0 04 00474	DST	RZ1
0251	00370	000005	SGL	
0252	00371	140040	CRA	
0253	00372	0 04 00462	STA	L3
0254	00373	0 04 00466	STA	RX3
0255	00374	0 04 00472	STA	RY3
0256	00375	0 04 00476	STA	RZ3
0257	00376	-0 01 00000	JMP*	ATTA
0258	00400	000000	DLL	DBP
	00401	000000		
0259	00402	000000	DLRX	DBP
	00403	000000		
0260	00404	000000	DLRY	DBP
	00405	000000		
0261	00406	000000	DLRZ	DBP
	00407	000000		
0262	00410	000000	D1	OCT
0263	00411	000000	D2	OCT
0264	00412	000000	D3	DBP
	00413	000000		
0265	00414	000000	S1	DBP
	00415	000000		
0266	00416	000000	S2	DBP
	00417	000000		
0267	00420	000000	TRND	OCT
	00421	040000		0,40000
0268	00422	000000	SRND	OCT
	00423	000200		0,200
0269	000414	DX	EQU	'414
0270	000416	DY	EQU	DX+2
0271	000420	DZ	EQU	DX+4
0272	000460	L1	EQU	'460
0273	000461	L2	EQU	L1+1
0274	000462	L3	EQU	L1+2
0275	000464	RX1	EQU	L1+4
0276	000465	RX2	EQU	L1+5

MICROCOMP TELECOMMUNICATED DATA
DDP-516 ASSEMBLY LISTING

0277	000466	RX3	EQU	L1+6
0278	000470	RY1	EQU	L1+8
0279	000471	RY2	EQU	L1+9
0280	000472	RY3	EQU	L1+10
0281	000474	RZ1	EQU	L1+12
0282	000475	RZ2	EQU	L1+13
0283	000476	RZ3	EQU	L1+14
0284 00424	125253		END	

DISTRIBUTION LIST

Internal:

R. Ragan	W. Woolsey
D. Hoag	G. Ogletree
N. Sears	R. McKern (10)
R. Battin	R. Trueblood
L. Larson	M. Hamilton
J. Harper	S. Copps
G. Silver (JSC)	J. Kernan
T. Lawton (JSC)	R. Cushing
E. Olsson (JSC)	T. Shuck
R. Cooper	D. Brown
D. Dove	J. StAmand
G. Edmonds	R. White
J. Feldman	L. Willy
P. Felleman	W. Trosky
J. Gilmore (25)	R. Sheridan
S. Helfant	J. Sinkiewicz
R. Hutchinson	C. Lory
G. Bukow	B. Katz
R. Booth (50)	D. Sprague
R. Blaha	T. Schamp
K. Vincent	R. White
H. Musoff	E. Salamin
J. Oehrle	M. Johnston
G. McWeeney	R. Millard
D. Swanson	W. Tanner
A. Laats	H. McOuat
E. Jones	Apollo Library (2) MIT/DL Doc. Center (10)

External:

NASA/MSC	National Aeronautics and Space Administration Lyndon B. Johnson Space Center APOLLO Document Control Group (BM86) (18 + 1R) Houston, Texas 77058	(36 + 1R)
	Attn: T. Lins, EG2 K. Cox, EG2 W. Swingle, EG5 M. Jones, EG5 T. Barry, EG5 J. Hanaway, EG7 W. Bradford, EA2 H. Tindall, EA R. Chilton, EG R. Nobles, FM7 D. Cheatham, EG S. Mann, FM7 P. Pixley, FM4 R. Savelly, FM4 A. Weatherstroem, EG5 S. Kamin, FM7 B. Cochrell, FM4 R. Eckelkamp, FM4 T. Lapko, BC7	
NASA/MSFC	National Aeronautics and Space Administration George C. Marshall Space Flight Center Huntsville, Alabama 35812	(20)
	Attn: M. Brooks, S&E-ASTR-SG H. Brown, S&E-ASTR-SGA G. Doane, S&E-ASTR-SGA B. Doran, S&E-ASTR-SGA B. Gaines, R-ASTR-GCC B. Moore, S&E-ASTR-DIR F. Wojtalik, S&E-ASTR-G B. Wiesenmaier, S&E-CSE-F	
	Codes: A&TS-PR-RS (1) A&TS-PR-M (1) A&TS-MS-IL (1) A&TS-MS-IP (2) A&TS-MS-IP (2) S&E-ASTR-GD (2) S&E-ASTR-S (2)	
NASA/HDQ	National Aeronautics and Space Administration 600 Independence Ave., SW Washington 25, DC 20546	(3)
	Attn: R. Murad, MHE L. Goolsby, ROA E. Hall, MTG	
NASA/AMES	National Aeronautics and Space Administration Ames Research Center Moffet Field, California 94035	(2)
	Attn: R. Hruby H. Lessing	