

PHONES (044) 360-7-130 (050) 336-0-130 (063) 788-0-130 (067) 233-0-130 (068) 282-0-130

130 Internet store of autogoods



294-0-130 597-0-130

> SKYPE km-130

CAR RECEIVERS — Receivers • Media receivers and stations • Native receivers • CD/DVD changers • FM-modulators/USB adapters • Flash memory • Facia plates and adapters • Antennas • Accessories |

CAR AUDIO — Car audio speakers • Amplifiers • Subwoofers • Processors • Crossovers • Headphones • Accessories | TRIP COMPUTERS — Universal computers • Model computers • Accessories |

GPS NAVIGATORS — Portable GPS • Built-in GPS • GPS modules • GPS trackers • Antennas for GPS navigators • Accessories | VIDEO — DVR • TV sets and monitors • Car TV tuners • Cameras • Videomodules
• Transcoders • Car TV antennas • Accessories | SECURITY SYSTEMS — Car alarms • Bike alarms • Mechanical blockers • Immobilizers • Sensors • Accessories | OPTIC AND LIGHT — Xenon • Bixenon • Lamps
• LED • Stroboscopes • Optic and Headlights • Washers • Light, rain sensors • Accessories | PARKTRONICS AND MIRRORS — Rear parktronics • Combined parktronics • Rear-view mirrors
• Accessories | HEATING AND COOLING — Seat heaters • Mirrors heaters • Screen-wipers heaters • Engine heaters • Auto-refrigerators • Air conditioning units • Accessories | TUNING — Vibro-isolation
• Noise-isolation • Tint films • Accessories | ACCESSORIES — Radar-detectors • Handsfree, Bluetooth • Windowlifters • Compressors • Beeps, loudspeakers • Measuring instruments • Cleaners • Carsits
• Miscellaneous | MOUNTING — Installation kits • Upholstery • Grilles • Tubes • Cable and wire • Tools • Miscellaneous | POWER — Batteries • Converters • Start-charging equipment • Capacitors
• Accessories | MARINE AUDIO AND ELECTRONICS — Marine receivers • Marine audio speakers • Marine subwoofers • Marine amplifiers • Accessories | CAR CARE PRODUCTS — Additives • Washer fluid • Care accessories • Car polish • Flavors • Adhesives and sealants | LIQUID AND OIL — Motor oil • Transmission oil • Brake fluid • Antifreeze • Technical lubricant



In store "130" you can find and buy almost all necessary goods for your auto in Kyiv and other cities, delivery by ground and postal services. Our experienced consultants will provide you with exhaustive information and help you to chose the very particular thing. We are waiting for you at the address

http://130.com.ua



UP 2.5 / UP2.5i UP 2.5B UR 2.5 Gothia 3

Welcome

Thank you for buying a DLS Ultimate speaker.

This manual will show you how to do a correct installation. Please read the entire manual before beginning the installation. Install the speakers yourself if you feel confident with our instructions and if you have the proper tools. The ULTIMATE speakers are our best speaker line but a poor installation job can destroy the final result even from these speakers. So if you feel unsure, turn over the installation job to someone better suited to it.

Installation

The speakers should be installed high up in the door side or in the dashboard. These speakers doesn't require any box. When the midrange is mounted high up on the dashboard the mid level creates a frequency peak in some vehicles. If so use the low "mid level" in the filter box. If the level is still too high, connect a 3-5 ohm resistor in series with the + feed. We recommend you to install them in a strong baffle of MDFboard or similar. A strong baffle will improve the sound quality. If you don't have the possibility of doing strong baffles you must use the steel rings coming with the drivers to improve the stability of the mounting.

Wiring

Use high quality speaker cables like DLS HQS or similar. Avoid using the factory pre-installed cabling, they will not give the sound reproduction that you should expect from these high class speakers.

Make sure the cables don't get jammed causing a short circuit to ground. This can damage the output circuits of your head unit or amplifier.

Connect the cables with correct polarity to the speakers. Observe the markings on the terminals. The red marked terminal is plus and the black is minus.

Break-in period

Allow the speakers to play at normal volume for at least 15-20 hours. After this time the performance is correct.

Technical Assistance

For technical assistance ask the shop where the product was sold or the distributor in your country.

You can also send an e-mail to info@dls.se

Information can also be found on our web-site www.dls.se We follow a policy of continuous advancement in development. For this reason all or part of specifications & designs may be changed without prior notice.

Warranty service

This speaker is covered by warranty, depending on the conditions in the country where it is sold. If the speaker is returned for service, please include the original dated receipt (or a copy) with the product.



DLS Svenska AB P.O. Box 13029 SE-40251 Göteborg, Sweden Tel: +46 31 840060 Fax: +46 31 844021 E-mail: info@dls.se

www.dls.se

Technical data UP 2.5 / UP 2.5i / UP 2.5B

Size Nom. power (RMS) Maximum power 2,5" (6,3 cm) 90 Watts RMS 160 Watts 400 Hz-8000 Hz Frequency range 500 Hz - 5000 Hz Use HP 18-24 dB slope /oct. Rec. frequency use for active crossover Sensitivity 91 dB / W / m Resonanst freq. / Fs Magnet diameter 490 Hz 65 mm / 2,56' 100 mm / 3,94" 15 mm / 0,59" Outer diameter Installation depth

Cone Voice coil Doped fabric 52 mm / 2" al. flat wire

Technical data UR 2.5

Mounting hole

Size Nom. power (RMS) 2,5" (6,3 cm) with rear chamber 90 Watts RMS 160 Watts 400 Hz-8000 Hz Maximum power Frequency range 500 Hz - 4500 Hz Use HP 18-24 dB slope /oct. Rec. frequency use for active crossover 91 dB / W / m Sensitivity Resonanst freq. / Fs 430 Hz 65 mm / 2,56 Magnet diameter Outer diameter 100 mm / 3,94" Installation depth 26 mm / 1,02° Mounting hole 82 mm / 3,23" Doped fabric 52 mm / 2" al. flat wire Voice coil

82 mm / 3,23"

Technical data Gothia 3


2,5" (6,3 cm) with rear chamber 100 Watts RMS 160 Watts 250 Hz-8000 Hz 400 Hz - 4500 Hz Nom. power (RMS) Maximum power Frequency range Rec. frequency use for Use HP 18-24 dB slope /oct. Active crossover Sensitivity 91 dB / W / m Resonanst freq. / Fs 280 Hz +- 0,5 mm Magnet diameter 80 mm / 3,15" Outer diameter Installation depth 120 mm / 4,72" 28 mm / 1,1" Mounting hole 95 mm / 3,74" Doped fabric Cone

Crossover

Voice coil

The speakers must be used with either a passive or an active filter in a 3-way configuration. If you can't use active filters you can build your own passive filter like in this example. It is a 6/6 dB slope band pass filter ~500 - 4500 Hz

75 mm / 3" al. flat wire



This rather simple passive filter can be used for UP2.5 / UR2.5. Iridium 3 should only be used in active crossover mode. Use polypropylene capacitor and low-resistance air coil. The resistor is used to adjust the level. The 4,7 omhs is a standard value but you must find a resistor value that matches the sensitivity of the other speakers in your system. In some configurations you don't have to use a resistor at all.

Changing grilles on UR2.5



1. Remove the rear chamber by bending with a screwdriver on the three spots where it is attached to the driver. Be careful!



2. Rear chamber removed.



3. Remove the grille from the driver unit like this.



4. Grille removed.



5. The other grille in place.



6. Reinstall the rear chamber and use the screws to put all parts together again.