



**Kodak**

# Scan Station 700 Series

Administrator's Guide

## 3rd Party Licenses

This software is based in part on the work of the Independent JPEG Group

Copyright (C)2009-2013 D. R. Commander. All Rights Reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the libjpeg-turbo Project nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS", AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

# Safety

---

- Place the *Kodak Scan Station 710/730EX* on a level work surface capable of supporting 9.97 kg (22 lbs.)
- When placing the Scan Station, make sure that the electrical power outlet is located within 1.52 metres (5 feet) of the Scan Station and is easily accessible.
- When relocating the Scan Station, it is recommended that two people lift the Scan Station and use safe lifting techniques.
- Do not install the Scan Station in a location subject to dust, humidity or steam. This may cause electrical shock or a fire. Only use the Scan Station indoors in a dry location.
- When disconnecting equipment from the electric socket, be sure to grasp the plug, not the cord.
- Never disassemble or modify the AC adapter, as this is dangerous.
- Do not use an AC adapter other than the one provided with the Scan Station. Do not use the AC adapter provided with the Scan Station for any other products.
- Be sure the power cord is securely plugged into the wall outlet. Failure to do so may cause electrical shock or fire.
- Do not damage, knot, cut or modify the power cord or use a damaged power cord. This may cause electrical shock or fire.
- The Scan Station requires a dedicated and properly grounded power outlet. Do not use an extension cord or power strip with the Scan Station.
- Leave sufficient space around the power outlet so it can be easily unplugged in case of an emergency.
- Do not use the Scan Station if it becomes inordinately hot, has a strange odor, emits smoke, or makes unfamiliar noises. Immediately stop the Scan Station and disconnect the power cord from the power outlet. Contact Kodak Service.
- Do not disassemble, service or modify the Scan Station except as explained in the Administrator's Guide.
- Do not move the Scan Station with the power cord and interface cable attached. This may cause damage to the cord/cable. Remove the power cord from the wall outlet before moving or relocating the Scan Station.
- Follow the Kodak recommended cleaning procedures. Do not use air, liquid or gas spray cleaners. These cleaners displace dust, dirt and debris to other locations within the scanner, which may cause the Scan Station to malfunction.
- Material Safety Data Sheets (MSDS) for chemical products are available on the Kodak website at: [www.kodakalaris.com/go/msds](http://www.kodakalaris.com/go/msds). When accessing the MSDSs from the website, you will be required to provide the catalog number of the consumable you want the Material Safety Data Sheet for.

## Environmental information

- The *Kodak Scan Station 710/730EX* is designed to meet worldwide environmental requirements.
- Guidelines are available for the disposal of consumable items that are replaced during maintenance or service; follow local regulations or contact Kodak locally for more information.
- The *Kodak Scan Station 710/730EX* is Energy Star compliant and shipped from the factory with the default time set to 15 minutes.
- For recycling or reuse information, contact your local authorities, or in the USA, visit: [www.kodakalaris.com/go/scannerrecycling](http://www.kodakalaris.com/go/scannerrecycling).
- The product packaging is recyclable.
- Parts are designed for reuse or recycling.



### European Union

This symbol indicates that when the last user wishes to discard this product, it must be sent to appropriate facilities for recovery and recycling. Please contact your local Kodak representative or refer to [www.kodakalaris.com/go/recycle](http://www.kodakalaris.com/go/recycle) for additional information on the collection and recovery programs available for this product.

Please consult [www.kodakalaris.com/go/REACH](http://www.kodakalaris.com/go/REACH) for information about the presence of substances included on the candidate list according to article 59(1) of Regulation (EC) No. 1907/2006 (REACH).

## Battery Information

This product contains a Lithium Ion button cell battery. This battery can only be removed or replaced by a qualified Service Engineer.

### CAUTION:

- Risk of explosion if the battery is replaced by an incorrect type.
- Dispose of used batteries according to the instructions.

## Acoustic emission

Maschinenlärminformationsverordnung – 3, GSGV  
Der arbeitsplatzbezogene Emissionswert beträgt <70 db(A).

[Machine Noise Information Ordinance — 3, GSGV  
The operator-position noise emission value is <70 dB(A).]

phase est de 230 V.

## EMC statements

**United States:** This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of these measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for additional suggestions.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation.

**Korea:** As this equipment has obtained EMC registration for household use, it can be used in an area including residential areas.

**미 기기는 가정용으로 전자파적합등록을 한 기기로서 주거지역에서는 물론 모든 지역에서 사용할 수 있습니다.**

**Japan:** This is a Class B product based on the standard of the Voluntary Control Council for interference by information Technology Equipment (VCCI). If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。  
取扱説明書に従って正しい取り扱いをして下さい。

# CONTENTS

---

<b>OVERVIEW</b>	<b>1-1</b>
<b>PRE-INSTALLATION CHECKLIST</b>	<b>2-1</b>
<b>INSTALLATION AND GETTING STARTED</b>	<b>3-1</b>
<b>CONFIGURING DEVICE SETTINGS</b>	<b>4-1</b>
<b>DEFINING SCAN SETTINGS</b>	<b>5-1</b>
<b>CREATING DESTINATIONS</b>	<b>6-1</b>
<b>ADDING AND MANAGING GROUPS</b>	<b>7-1</b>
<b>CREATING JOBS</b>	<b>8-1</b>
<b>MONITORING AND MANAGING YOUR SCAN STATIONS</b>	<b>9-1</b>
<b>MAINTENANCE</b>	<b>10-1</b>
<b>TROUBLESHOOTING</b>	<b>11-1</b>
<b>GLOSSARY</b>	<b>12-1</b>
<b>APPENDICES</b>	<b>A-C</b>
<b>Specifications</b>	
<b>Network Protocol</b>	
<b>Warranty</b>	

# 1 Overview

---

## Contents

What's in the box .....	1-1
Setting up the Scan Station.....	1-2
Setting up configurations .....	1-3
Scan Station components .....	1-5

The *Kodak* Scan Station 710/730EX is designed as a walk-up device that requires no host PC or application software. It works with and uses an existing network and network shared services to communicate with other network devices or destinations. The Scan Station 710/730EX is a capture solution that allows you to quickly send your documents via email, network, networked printers, USB drives, fax, FTP, SharePoint and Kofax Front Office Server with a simple touch.

This Administrator's Guide provides the information you need to setup and administer the *Kodak* Scan Station 710 and *Kodak* Scan Station 730EX. For the purpose of these models will be referred to as *Kodak* Scan Station 700 Series. Any differences between these models will be noted.

## What's in the box

Before you begin open the box and check the contents:

- *Kodak* Scan Station 710/730EX
- Power cord bundle
- Welcome Folio which includes:
  - Installation CD
  - Registration sheets
  - User Reference Guide, English
  - Maintenance Reference Guide, English
  - Installation Guide
  - Country Contact sheet
  - Miscellaneous flyers

## Setting up the Scan Station

Carefully unpack the Scan Station 710/730EX and place it on a clean, dry and level surface. Refer to the Installation Guide or the “Rear view” illustration later in this chapter for port locations.

1. Select the appropriate AC power cord. Plug the power adapter into the power port on the Scan Station. Plug one end of the power cord into the power adapter and plug the other end into the wall outlet.
2. Plug one end of the 10/100/1000 Base T network cable (customer provided) into the Ethernet port of the Scan Station and plug the other end of the network cable into the network port.
3. If you have a Scan Station 730EX, connect a phone line to the RJ-11 modem port.
4. When the Scan Station is properly connected, press the power button and wait a few moments for the Scan Station to start up and display the application.
5. Proceed to Chapter 2, *Pre-installation Checklist* to review and gather the necessary configuration information before installing the *Kodak Scan Station 700 Series - Scanner Administration* application and creating configurations.
6. After reviewing the Pre-installation Checklist, you can setup your configurations. See Chapters 3-8 for more information.

## Setting up configurations

You must configure the Scan Station using the *Kodak Scan Station 700 Series - Scanner Administration* application before you can use it. The application allows you to configure and manage your Scan Stations.

A Scan Station configuration consists of setting the following groups of options: Device Settings, Scan Settings, Destinations, Groups, and Jobs. These options are accessible via the Configuration tab on the Scan Station 700 Series - Scanner Administration application using the Edit menu.

- **Device Settings** — consists of the following configuration items. See *Chapter 4 for more information*.
  - **Device Options:** used to configure the Scan Station (e.g., display language, date, time, etc.).
  - **Email Server:** used to configure the Scan Station to use an SMTP server. Configuration of an email server is required if you will be sending documents to an email destination.
  - **Active Directory Server:** used to configure the location of an Active Directory Server. This will be required if you want to define users and groups of users from your Active Directory Server.
  - **Fax:** used to configure fax options. Fax configuration will be required if you will be sending scanned documents via fax.
- **Scan Settings** — allows you to define items that determine how a document will be scanned (e.g., black and white, two sided, 300 dpi, etc.), the output format (e.g., PDF, JPEG, XLS, etc.), any special processing, and how to name the scanned document. Multiple scan settings can be configured. For example, you can setup a scan setting configuration for scanning color documents, and another scan setting configuration for scanning black and white documents. After defining your scan setting configuration, you will be prompted to name your configurations for later use. See *Chapter 5 for more information*.
- **Destinations** — allows you to define where the scanned image(s) is sent or stored. The Scan Station can send or store documents to email, a network folder, printer, FTP, fax, email to fax, SharePoint, and Kofax Front Office Server. See *Chapter 6 for more information*.
- **Groups** — groups are used to control access to jobs for specific users or groups of users. See *Chapter 7 for more information*.
- **Jobs** — jobs are a combination of Scan Settings, Destinations and Groups. A job is represented on the Scan Station user interface as a single button, such as *Invoices*. A job allows one touch scanning since a job will define how a document should be scanned and formatted (Scan Settings), where the document should be stored or sent (Destinations), and the users or groups of users that are allowed to use a particular job (Groups). See *Chapter 8 for more information*.




It is suggested that scan settings, destinations and groups be defined before defining any jobs. Each Scan Setting, Destination and Group configuration will have an associated name that will be used when defining a job.

The Scan Station can be configured to force a user to login. The login information is matched with the groups defined for each job. When a user logs into the Scan Station, the only buttons that will be displayed are jobs that the user has access to.


## Scan Station components

### Front view




- 1 Input tray extender** — pull this extender out to accommodate document sizes over 8 1/2 x 11 inches (A4).
- 2 Input tray** — holds up to 75 sheets of 80 g/m<sup>2</sup> (20 lb.) paper.
- 3 Side guides** — slide the guides back and forth to accommodate the width of the documents you want to scan.
- 4 Touch screen** — allows you to easily select a job or navigate through optional selections with a simple touch. The touchscreen is the primary user interface for interacting with the Scan Station.
- 5 Output tray panel** — covers the transport when not in use. This panel must be open to scan documents. When opened, collects the scanned documents. The Scan Station cover cannot be opened when the output tray panel is closed.
- 6 Output tray extender** — pull this extender out when scanning documents longer than 11 inches (28 cm).
- 7 Microphone** — used for creating voice annotation.
- 8 Power** — turns the power on. See the section entitled, “Indicator lights” in Chapter 11 for more information.

## Inside view



- 1 **Separation module release lever/separation module** — push the release lever down to remove the separation module for cleaning or replacement. The separation module provides smooth document feeding and separation of various sizes, thicknesses and textures of documents.
- 2 **Gap release lever** — allows you to manually adjust the space between the feed module and separation module for documents that require special handling.
- 3 **Scan Station cover release lever** — opens the Scan Station to allow access to the paper path for cleaning or clearing a document jam.
- 4 **Feed module** — provides smooth document feeding and separation of various sizes, thicknesses and textures of documents.
- 5 **Paper present sensor** — detects the presence of documents in the input tray.
- 6 **Feed module cover** — this cover needs to be removed when cleaning or replacing the feed module or feed module tires.
- 7 **Imaging guides** — for optimum image quality, keep the upper and lower imaging guides clean.
- 8 **Multifeed detection sensor** — detects if more than one document enters the paper path at a time.

## Rear view



- 1 **Modem port** — the RJ-11 port connects the fax modem to a phone line. This is only for the Scan Station 730EX.
- 2 **Security lock port** — connects a security lock to the Scan Station. You can purchase a standard security lock at an office supply store. Refer to the instructions provided with the security lock for installation procedures.
- 3 **Power port** — connects the power cord/adaptor to the Scan Station.
- 4 **USB ports** — connects peripheral devices (e.g., keyboard, mouse and other accessories) to the Scan Station.
- 5 **Ethernet port** — connects the Scan Station to the network.

## 2 Pre-installation Checklist

---

### Contents

Network configuration details.....	2-1
Best practices .....	2-1
Pre-installation checklist .....	2-2

### Network configuration details

Because the Scan Station is a network device, a basic knowledge of networking principles and terminology is helpful. You should be familiar with the concept of creating user accounts (on domains), sharing folders, setting access privileges, the Universal Naming Convention (UNC), using IP addresses, fully qualified domain names (FQDNs) and creating user groups.

NOTE: Some of the concepts covered in this section assume knowledge of Microsoft NT Domains and permissions. Refer to your documentation for Microsoft Windows Server 2003, 2008 or 2012 for more information.

### Best practices

**Scan Station user groups** — for network domain environments, you should create a user group for all Scan Stations. This group will be used to hold account names that are assigned to each Scan Station. Minimally, there should be one account name that is assigned to each Scan Station. Optimally, each Scan Station should be assigned its own unique username and password and these accounts should be contained within a group that is reserved specifically for Scan Stations. These account names will be used when configuring the Scan Station's network settings and entered into the *Username*, *Password*, and *Network Domain* fields.

NOTE: The Scan Station groups and login names must be given appropriate privileges to access the network resources that the user will see as Destination selections at the Scan Station.

**Workgroup environments** — for network environments that use the Microsoft "Workgroup" configuration, you may be required to create an account name and password to be assigned to Scan Stations. These account names will be used when configuring the Scan Station's network settings and entered into the *Username* and *Password* fields. The *Network Domain* field should be left blank in Workgroup environments.

**Network folders** — it is recommended that you create network folders, for either Destination or Automatic Configuration Schedule updates, that can be accessed (minimally read, write, change access) by any Scan Station login account or by the user group created for Scan Stations.

**UNC names for folders** — you will need to know the fully qualified UNC name for each network folder that will be used by your Scan Station(s). When configuring network destinations, this will be the information entered into the *Address* field of the Add: Network Folder dialog box. For example, you could create a folder called “*scanfolder*” on a server called “*acmeserver*” that would be reserved for Scan Station access. You would reference it by the following UNC name: `\\acmeserver\scanfolder`.

**NETBIOS usage** — in network environments that use routers it is common practice to block NETBIOS traffic on your router. You may need to know the IP address of the server where you want to scan documents. By substituting the IP address of the server instead of the NETBIOS computer name, you can bypass the network traffic restrictions that may cause network scanning to fail. For example, the previously defined network address: `\\acmeserver\scanfolder` should be replaced with something similar to: `\\192.168.2.10\scanfolder`.

## Pre-installation checklist

It is recommended that you review this checklist **before** configuring the Kodak Scan Station 710/730EX. This information is needed to create the initial configuration file to complete the installation. Locate any information you are unsure of before creating the configuration file. See your system or network administrator if you have questions about this information.

Device Settings/IP Address		
The following settings are found using the Scanner tab and by selecting <b>Scanner&gt;Modify Scanner</b> .		
Parameter Name	Your Setting	Chapter Reference
Automatic (DHCP)		See Chapter 9, “Modifying a Scan Station”.
<b>IP Address Settings — Static</b>		
Static (IPv4)		
IP Address		
Subnet Mask		
Default Gateway		
Preferred DNS Server		
Alternate DNS Server		
Preferred WINS Server		
Alternate WINS Server		
Device Settings/Network Destination Credentials		
The following settings are found using the Configuration tab and by selecting <b>Edit&gt;Device Settings</b> .		
Parameter Name	Your Setting	Chapter Reference
Username, Password, Domain		<ul style="list-style-type: none"> <li>• See Chapter 9, “Best practices” for creating an account for your Scan Station.</li> <li>• See Chapter 4, “Configuring your device options”.</li> </ul>
Automatic Configuration Schedule		

**Device Settings/Email (SMTP) Server**

The following settings are found using the Configuration tab and by selecting **Edit>Device Settings**.

Parameter Name	Your Setting	Chapter Reference
Email Server Address		See Chapter 4, "Configuring email settings".
Username, Password, Domain		
Port		
Authentication Scheme		
Maximum Attachment Size		
Security Type		

**Device Settings/Active Directory Server**

The following settings are found using the Configuration tab and by selecting **Edit>Device Settings**.

Parameter Name	Your Setting	Chapter Reference
Server Address		See Chapter 4, "Active Directory Server settings".
Username, Password, Domain		
Port		
Base DN		
Search Field Tag		
Email Address Tag		
Full Name Field Tag		
Home Directory Tag		
Fax Field Tag		
Security Type		

**Device Settings/Fax**

The following settings are found using the Configuration tab and by selecting **Edit>Device Settings**.

Parameter Name	Your Setting	Chapter Reference
Outside Line Prefix		See Chapter 4, "Fax settings".
Modem Country Code		
LAN Fax Server Domain Name		

**Network Destination**

The following settings are found using the Configuration tab and by selecting **Edit>Destinations**.

Parameter Name	Your Setting	Chapter Reference
Complete directory path (the folder where you will put the scanned documents).		Chapter 6, "Setting up a network destination".

### Printer Destination

The following settings are found using the Configuration tab and by selecting **Edit>Destinations**.

Parameter Name	Your Setting	Chapter Reference
Complete directory path (the directory path to the printer server queue)		Chapter 6, "Setting up a printer destination".
Username, Password, Domain		
Address (for direct connection to a printer)		
Driver name (for direct connection to a printer)		
Port name (for direct connection to a printer)		

### FTP Destination

The following settings are found using the Configuration tab and by selecting **Edit>Destinations**.

Parameter Name	Your Setting	Chapter Reference
Server name and directory path		Chapter 6, "Setting up a FTP site".
Username, Password		
Protocol (FTP)		
Port number		
Passive (Enable/Disable)		
Proxy <ul style="list-style-type: none"><li>• Proxy Type</li><li>• Proxy Address</li><li>• Username</li><li>• Password</li><li>• Port Number</li></ul>		

### FTPS Destination

The following settings are found using the Configuration tab and by selecting **Edit>Destinations**.

Parameter Name	Your Setting	Chapter Reference
Server name and directory path		Chapter 6, "Setting up a FTP site".
Username, Password		
Protocol (FTPS)		
Port number		
Encryption		
Passive (Enable/Disable)		
SSL Server Certificate (Enable/Disable)		
Proxy <ul style="list-style-type: none"><li>• Proxy Type</li><li>• Proxy Address</li><li>• Username</li><li>• Password</li><li>• Port Number</li></ul>		



### SFTP Destination

The following settings are found using the Configuration tab and by selecting **Edit>Destinations**.

Parameter Name	Your Setting	Chapter Reference
Server name and directory path		Chapter 6, "Setting up a FTP site".
Username, Password		
Protocol (SFTP)		
Port number		
Private Key File, Password		
Proxy <ul style="list-style-type: none"><li>• Proxy Type</li><li>• Proxy Address</li><li>• Username</li><li>• Password</li><li>• Port Number</li></ul>		

### SharePoint Destination

The following settings are found using the Configuration tab and by selecting **Edit>Destinations**.

Parameter Name	Your Setting	Chapter Reference
SharePoint website URL		Chapter 6, "Adding a SharePoint group".
Username, Password		
Document Path		
Index Fields		
Certificate, Password		
Proxy <ul style="list-style-type: none"><li>• Proxy Address</li><li>• Username</li><li>• Password</li><li>• Port Number</li></ul>		

### Kofax Front Office Server Destination

The following settings are found using the Configuration tab and by selecting **Edit>Destinations**.

Parameter Name	Your Setting	Chapter Reference
Kofax Front Office Server address		Chapter 6, "Adding a Kofax Front Office Server group".
Port number		
Username, Password		
Client ID		
Shortcut Type		
Shortcut Name		
Index Fields		
Certificate, Password		

# 3 Installation and Getting Started

---

## Contents

Setup overview .....	3-1
Power saver mode and activating the Scan Station.....	3-1
Installing the <i>Kodak</i> Scan Station 700 Series - Scanner Administration application .....	3-2
The main screen .....	3-3
Menus .....	3-5
File menu .....	3-5
Edit menu.....	3-6
Scanner menu.....	3-6
Help menu.....	3-9
Icons .....	3-9

## Setup overview

Following is a list of things you need to do to prepare for configuring your Scan Station 710/730EX.

- Unpack your Scan Station(s) according to the unpacking instructions in the box that your Scan Station was packaged in.
- Setup the Scan Station and make the necessary connections. See the Installation Guide or the section entitled, “Setting up the Scan Station” in Chapter 1.
- Review the pre-installation checklist in Chapter 2 and gather all of the information required to configure the Scan Station. Having this information available in advance will help ensure an easy Scan Station configuration.
- When the Scan Station is properly connected, press the power button and wait a few moments for the Scan Station to start up and display the application.
- Install the *Kodak* Scan Station 700 Series - Scanner Administration application on a separate PC. See the section entitled, “Installing the *Kodak* Scan Station 700 Series - Scanner Administration application” later in this chapter for procedures.

## Power saver mode and activating the Scan Station

By default, after 15 minutes of inactivity, the Scan Station will automatically enter into power saver mode.

To activate the Scan Station from power saver mode press the power button.

## Installing the *Kodak Scan Station 700 Series - Scanner Administration* application

You must install the *Kodak Scan Station 700 Series - Scanner Administration* application on a host PC. The *Kodak Scan Station 700 Series - Scanner Administration* application allows you to properly setup, configure and manage Scan Station 700/710/720EX/730EX/500/520EX devices over a network in an efficient and productive manner. This application communicates with *Kodak Scan Station 500* and *700* devices over the network; thereby minimizing the need for individual access to multiple Scan Stations.


1. Insert the Installation CD titled, "Scanner Administration and Supporting Documentation" in the CD-ROM drive on the computer where the *Kodak Scan Station 700 Series - Scanner Administration* application will be installed. The installation software starts up automatically.

NOTE: If .NET Framework 4.0 is not already installed, the *Kodak Scan Station 700 Series - Scanner Administration* application installer will install them before installing the *Kodak Scan Station 700 Series- Scanner Administration* application.

2. Click **Next** when the *Kodak Scan Station 700 Series* splash screen is displayed.
3. Click **Next** when the Welcome screen is displayed.
4. Click **I Agree** after you have read and agreed with the terms of the Software License Agreement, then click **Next**.

The Ready to Install Program screen will be displayed.

5. Click **Install** to continue.
6. After the *Kodak Scan Station 700 Series - Scanner Administration* application has been installed, click **Finish**.
7. Remove the Installation CD from the CD-ROM drive.
8. After installing and running the application, the *Kodak Scan Station 700 Series - Scanner Administration* main screen will be displayed.




## The main screen

The main screen provides two tabs:

- **Scanners tab** — allows you to monitor any Scan Stations that have been discovered and configured. See Chapter 9, *Monitoring and Managing Your Scan Stations* for more information.

NOTE: In addition to the Scan Station 710/730EX, the *Kodak Scan Station 500/520EX/700/720EX* can be managed from the Scanner tab and the Scanner menu.




- **Configuration tab** — allows you to configure and set up your Scan Stations. After you have created at least one configuration, this screen will be displayed with a list of your previously created configurations.

NOTE: The Configuration tab and the File and Edit menus only apply to the Scan Station 700/710/720EX/730EX.

The Scan Station 500/520EX must be configured using the *Kodak Scan Station Configuration Organizer*. See your Administrator's Guide for the *Kodak 500/520EX* for more information.

A *configuration* is a collection of Device settings, Scan settings, Destinations, Groups, and Job settings. Configurations are stored on your PC in a configuration database and maintained by the *Kodak Scan Station 700 Series - Scanner Administration* application. Detailed procedures for configuring these settings are described in Chapters 4-8.




## Menus

The File, Edit, Scanner and Help menus are available from the *Kodak Scan Station 700 Series - Scanner Administration* main screen.

NOTE: When the Configuration tab is selected, only the File, Edit and Help menus are available.

When the Scanners tab is selected, only the Scanner and Help menus are available.

### File menu



Following is a description of the menu options on the File menu.

**Add** — allows you to create a new configuration from the default or from an existing configuration.

- **From default configuration:** when selected, displays the Device Settings screen. For more information see Chapter 4, *Device Settings*.
- **From selected configuration:** when selected, displays the Configuration Name screen which allows you to name a new configuration which is based on the currently selected configuration. If you want to base a new configuration on an existing one (not the default), select the base configuration, then select **File>Add>From the selected configuration**. If there are no configurations (other than the default), this option is grayed out.

**Save** — saves the selected configuration to the configuration database located on the PC running the *Kodak Scan Station 700 Series - Scanner Administration* application.

**Rename** — displays the Configuration Name screen allowing you to rename the selected configuration.

**Delete** — deletes the selected configuration.


**Upload** — allows you to send the selected configuration to the Scan Station. This option is grayed out if no Scan Stations are accessible by the *Kodak Scan Station 700 Series - Scanner Administration* application.

**Import** — allows you to import a configuration file from any location to the *Kodak Scan Station 700 Series - Scanner Administration* application.

**Export** — allows you to export a configuration file from the *Kodak Scan Station 700 Series - Scanner Administration* application to any location.

**Exit** — closes the *Kodak Scan Station 700 Series - Scanner Administration* application.

## Edit menu



Following is a description of the menu options on the Edit menu.

**Device Settings** — allows you to configure the parameters that the Scan Station needs to send emails, communicate with an Active Directory Server for security purposes, set Scan Station defaults and configure fax settings. For more information, see Chapter 4, *Device Settings*.


**Scan Settings** — allows you to set basic image processing settings, such as, color/grayscale/black and white, output file format, compression, and some advanced options like Hole Fill, Streak Filter, etc. For more information, see Chapter 5, *Scan Settings*.

**Destinations** — allows you to add or modify destinations (e.g., email, network folder, printer, FTP site, etc.) that define where the scanned output will be sent. For more information, see Chapter 6, *Creating Destinations*.

**Groups** — allows you to create or modify a group of users from an Active Directory Server. Other users that are not in an Active Directory Server group can also be added. For more information, see Chapter 7, *Adding and Managing Groups*.

**Jobs** — allows you to create or modify jobs which are a collection of scan settings, destinations and groups of users. For more information, see Chapter 8, *Creating Jobs*.

## Scanner menu



Following is a description of the menu options on the Scanner menu. Refer to Chapter 9, *Monitoring and Managing Your Scan Stations* for more information and procedures regarding these options.

**Add Scanner** — displays the Add Scanner dialog box, which allows you to register Scan Stations that you want to manage remotely.

**Discover Devices** — allows you to scan a range of IP addresses and automatically register any Scan Station within that range that responds to the request.

**NOTE:** Any Scan Station that has previously had its Remote Access Password set will not respond to the discovery request. If this is the case, you will need to manually add the Scan Station by selecting **Scanner>Add Scanner** and enter the Scan Station's name or IP address and the Scan Station's password.

**Modify Scanner** — allows you to rename the selected Scan Station and configure network settings.

**Delete Scanner** — deletes the selected Scan Station(s) from the list of administered Scan Stations.

**Select All** — allows you to select all the Scan Stations that are displayed in the list; you can also press Ctrl+A to select all Scan Stations.

**Deselect All** — allows you to deselect all the Scan Stations that are currently selected; you can also press Ctrl+D to deselect all Scan Stations.

**Remote Access Password** — displays the Remote Access Password dialog box which allows you to change the network connection password to the Scan Station.

This password is used by the *Kodak Scan Station 700 Series - Scanner Administration* to communicate with the Scan Station. An organization can have more than one instance of the Scanner Administration software running at one time. Only those instances that are aware of the password for a particular Scan Station can communicate with that Scan Station. If a Scan Station with a Remote Access Password is deleted from the grid view, the password will be required to add the Scan Station back to the grid view. For more information, see the section entitled, “Grid view” in Chapter 9

**Refresh Status** — displays the current state of the selected Scan Station(s):

- **Idle** — the Scan Station is currently active on the network; but not in use.

NOTE: Any user interaction using the touch screen will put the Scan Station into the *In Use* state (see below).

- **Scanning** — Scan Station is scanning.
- **Processing images** — the Scan Station is processing images (e.g., converting images to PDF).
- **Sending email** — the Scan Station is sending an email.
- **Saving** — images are being saved to a USB drive, network folder, FTP site, or a SharePoint site.
- **Printing** — the Scan Station is printing images using a remote printer.
- **Scan Completed** — the Scan Station has successfully completed the scanning session. When **Done** is selected on the Scan Station, the Scan Station will go into the *Idle* state.
- **Error** — the Scan Station failed to complete the scanning session. When **Done** is selected on the Scan Station, the Scan Station will go into the *Idle* state.
- **Cancelled** — the scanning session has been cancelled. After the inactivity time period has been reached, the Scan Station will go into the *Idle* state.
- **Preview** — the Scan Station Preview feature is in use.
- **Sending Fax** — the Scan Station is sending a fax. This is only displayed if the Scan Station is not currently scanning.
- **Receiving Fax** — the Scan Station is receiving a fax. This is only displayed if the Scan Station is not currently scanning.
- **Powering down** — the Scan Station is in the process of a power-down sequence.
- **Rebooting** — the Scan Station is in the process of being restarted.




- **Updating** — the configuration file or firmware is currently being updated.
- **In Use** — when a USB flash drive is inserted, a user is logging in or is interacting with the Scan Station, this state is displayed.
- **Not found** — the Scan Station cannot be found on the network (e.g., power is turned off).

**Refresh Rate** — allows you to set the amount of time that the application will try and communicate with all Scan Stations.

**HTTP Timeout** — allows you to adjust the amount of time (in seconds) that the HTTP commands have to complete. If some commands timeout and do not complete, adjust this to a higher value.

**HTTPS** — turning **HTTPS** on will encrypt data as it is communicated between the *Kodak* Scan Station 700 Series - Scanner Administration application and the Scan Station.

**Device** — provides the following options. Procedures on how to use these functions are described in Chapter 9, *Monitoring and Managing Your Scan Stations*.




- **Retrieve Logs:** allows you to save the log files retrieved from the selected Scan Station.
- **Clear Logs:** when selected, the following message will be displayed, ***Are you sure you want to clear the log files of the selected scanner?*** If you click **Yes**, the log files will be cleared.
- **Retrieve Transaction Logs:** allows you to save the transaction log file retrieved from the selected Scan Station.
- **Clear Transaction Logs:** when selected, the following message will be displayed, ***Are you sure you want to clear the transaction log files of the selected scanner?*** If you click **Yes**, the transaction log files will be cleared.
- **Save All Logs:** saves all available log files found on the selected Scan Stations and saves them to the selected directory. The logs will be saved in the selected directory under the Device Name folder of the Scan Station.

- **Details:** provides device information about the selected Scan Stations including network configuration, software versions and page count.
- **Update Time/Date:** allows you to set the NTP time server for all selected Scan Stations.

**Power Options** — provides options for restarting and turning off the selected Scan Stations.

**Upload Firmware** — displays the Open dialog box which allows you to upload new firmware updates to the Scan Station.

## Help menu



Following is a description of the menu options on the Help menu.

**Contents** — provides help topics for the *Kodak* Scan Station 700 Series - Scanner Administration.

**Index** — provides help topics for the *Kodak* Scan Station 700 Series - Scanner Administration.

**About** — displays the About screen for the *Kodak* Scan Station 700 Series - Scanner Administration application, which provides information about the current version of the software.

## Icons

The information in Chapters 4-8 outline a step-by-step procedure for setting up your Scan Stations. Most screens have one or more of the following icons.



Creates a new entity.



Edits an existing entity.



Deletes the selected entity.



Displays the current state of the Scan Station:

- Idle
- Scanning
- Processing images
- Sending email
- Saving
- Printing
- Scan Completed
- Error
- Cancelled
- Preview
- Sending Fax
- Receiving Fax
- Powering down
- Rebooting
- Updating
- In Use
- Not found



Retrieves, displays and allows the saving of the log file on the selected Scan Station.



Displays and allows the saving of the transaction log file on the selected Scan Station.



Displays detailed information about the selected Scan Station (e.g., software version, IP address, etc.).


# 4 Configuring Device Settings

---


## Contents

Device Settings .....	4-1
Configuring your device options.....	4-3
Configuring email settings.....	4-8
Configuring Active Directory Server settings .....	4-10
Configuring Fax settings .....	4-12

## Device Settings




The Device Settings option allows you to configure the Scan Station for sending emails, sending and receiving faxes, communicate with the Active Directory Server for authentication purposes and set Scan Station defaults.



To set up a configuration:

1. Select the configuration that you want to apply settings to or create a new configuration (**File>Add**).

## 2. Select **Edit>Device Settings**.




Check all options that you want to configure and click **Next**. The software will step you through each option.

- **Device Options** — allows you to set the following options:
  - Language
  - Local Access Password
  - Network Destination Credentials
  - Automatic Configuration Schedule
  - Volume
  - Configuration Options
  - Date and Time
  - Power Saver
- **Email Server** — for the Scan Station to send documents to email recipients, you must define how the Scan Station will access your email server (e.g., SMTP, Return Email Address, etc.).
- **Active Directory Server** — allows you to configure your connection to the Active Directory Server which allows the Scan Station to authenticate credentials and look up specific user information, such as their home directory on the network.
- **Fax** — allows you to configure the Scan Station to send and receive faxes.

## Configuring your device options

This screen allows you to setup the following device options:



**Language** — click the down arrow to select the language that will be used on the Scan Station display.

Language:

**Local Access Password** — allows you to set a password that controls administrator access to the Scan Station.

Password: 
  
 Confirm new password:

Force User Login	Local Access Password Set	Local Access Password Blank (default)
<b>On</b>	The user must login into the Scan Station with their user name and password. The local access password is required to update the Scan Station if a user inserts a USB drive containing a configuration file.	The user will login into the Scan Station with their user name and password. No password is required to update the Scan Station if a USB drive containing a configuration file is inserted.
<b>Off</b>	Local access password is required to apply a configuration file at the Scan Station with a USB flash drive containing a configuration file.	No access control.

It is recommended that a local access password be set to guard against a non-privileged user from gaining access to administrator functions.

**Network Destination Credentials** — when selected, define the **Username**, **Password** and **Domain** required to access network resources.

⤴ Network Destination Credentials

Username:

Password:

Domain:

**NOTE:** This is only used for network folders when **Force User Login** (on the Active Directory Server screen) is not enabled.

1. Enter the network user name assigned to the Scan Station. For more information see the section entitled, “Network configuration details” in Chapter 2.

**NOTE:** If you want the Scan Station to have access to network printers or network shared folders, the credentials provided must have sufficient privileges to access these resources.

2. Enter the password for the network user name in the *Password* field.

**NOTE:** This password is only used by the Scan Station and will never be displayed in readable form. The password is stored in encrypted format.

3. Enter the Microsoft network domain name which the Scan Station will be connected to in the *Domain* field. In a workgroup environment, this field can be left blank.

**Automatic Configuration Schedule** — the Scan Station can be configured to look for an updated configuration on specific days and times and firmware updates. Select this option to allow your Scan Station to automatically look for an updated configuration.

⤴ Automatic Configuration Schedule

Folder:

Day(s):

Time of Day:  :

1. Enter a network folder where the Scan Station will find updated configuration settings.
2. Select which day(s) of the week this operation will be performed.
3. Select the time of day you want your Scan Station to check for updates.


**NOTE:** When updating a configuration using this method, the fields on the Add Scanner and Modify Scanner dialog boxes will not be updated: *Scanner Name*, *IP Address* and *Remote Access Password*.

**Volume** — allows you to adjust the master volume of the Scan Station. This will affect the speaker sound from the FAX modem and voice annotation playback.



**NOTE:** If you do not hear the fax dial tone after changing the volume, you may need to restart the Scan Station.

**Configuration Options** — provides the following options



- **Allow File Naming** — if enabled, allows a user to configure file name options on the Scan Station.
- **Allow Saving to USB drive** — allows you to enable scanning to a USB drive. This may be useful in more secure environments where tighter control is required.
- **Hide Network Folder location** — enable this option to provide a more secure environment by partially hiding the location of the network folder. If this option is enabled, only the end of the network folder path will be displayed on the Scan Station touchscreen. For example: \\server\myfolder will be displayed as: ...**myfolder**.
- **Fast Scanning (one button press scanning)** — allows a user to scan instantly without waiting for the 10-second delay, the Settings Review screen or the Destination Review screen to be displayed. A message will only be displayed if the scan session was unsuccessful.
- **Allow Voice Annotation** — when enabled, allows a user to record a voice annotation for each batch of scanned documents. By default, this option is enabled.



- **Enable Restricted mode (users cannot select or change destinations)** — when enabled, will only allow users to select a pre-defined job from the Scan Station touchscreen. These jobs cannot be changed by the user.
- **Allow SHAREPOINT index field changes** — when enabled, allows a user to change existing index fields.
- **Allow Kofax Front Office Server index field changes** — when enabled, allows a user to change existing index fields.
- **Log all transactions** — the Scan Station can log all transactions (all activity related to login, scanning and saving to destinations) to a separate transaction file. This file is in XML format and can be downloaded from the Scan Station. This is useful in environments that are security-minded or where transactions are used for billing. By default, all transactions are logged (checked). You can disable transaction logging by unchecking the checkbox.
- **Background processing** — allows you to select how jobs are processed. If background processing is selected, all jobs will be submitted to a queue and, by default, be processed in a first in, first out (FIFO) manner. This allows a user to start a second scan job immediately after the first job is scanned, even if the first scan job is still being processing.
- **Run the Setup Wizard at next restart** — when selected, the Setup Wizard will run when the Scan Station restarts, which provides a step-by-step procedure allowing you to select configuration options (e.g., time, date, etc.) when the Scan Station is restarted.

NOTE: The Setup Wizard is run from the Scan Station (not the *Kodak Scan Station 700 Series - Scanner Administration* application).


- **Enable Output Metadata** — with each document scanned, a .xml file will be created and sent to the destination along with the scan file. A .xsd file that can be used for metadata verification is on the Installation CD.

**Date** — allows you to set the date format on the Scan Station.



1. From the *Date Separator* drop-down list, select a symbol to use as a separator in the date format.
2. Select how you want the date displayed on the Scan Station touchscreen by selecting a format (year, month, day) from the *Date Format* drop-down list.

**Time** — allows you to set the time format on the Scan Station.



1. Select the **Time Zone** based on the Scan Station's location.  
NOTE: If Scan Stations are located in different time zones, separate configuration files will be necessary.
2. If you want the Scan Station to automatically adjust for daylight savings time, check the **Daylight Savings** check box.
3. Select either **12 Hour** or **24 Hour** time format from the *Clock* drop-down list.
4. Select the desired separator symbol that will be displayed in the time format from the *Time Separator* drop-down list.
5. Select the hours, minutes, seconds of how you want the time format to be displayed: **hh:mm:ss**, **h:mm:ss**, **hh:mm** or **h:mm**.

**Power Saver** — use the up and down arrows to set the amount of time the Scan Station needs to be inactive before it goes into power saver mode. The default is 15 minutes.




Depending on the options you selected on the main Device Settings screen, you will have the option of clicking **Next** which will display the next device you want to configure, or **Finish** which will return you to the Configuration tab.

## Configuring email settings

For the Scan Station to send documents to email recipients, you must define how the Scan Station will access your email server.

1. Check **Email Server** and click **Next**.



The screenshot shows the 'Device Settings' window for the KODAK Scan Station 700 Series. The window title is 'KODAK Scan Station 700 Series - Scanner Administration'. The 'Device Settings' section includes the following fields and controls:

- Email Server Address: Text box containing 'Myemailaddress'
- Username: Text box
- Password: Text box
- Domain: Text box
- Port: Spin box set to '25'
- Authentication Scheme: Dropdown menu set to 'Use Strongest'
- Maximum Attachment Size (MB): Spin box set to '25'
- Return Email Address: Text box
- Allow Custom Email Addresses: Checkmark
- Allow Custom Email Subject: Checkmark
- Security Type: Dropdown menu set to 'None'
- Test Connection: Button

At the bottom of the window are four buttons: 'Cancel', 'Previous', 'Next', and 'Finish'.

2. Enter an IP address or a fully qualified domain name of your SMTP server in the *Email Server Address* field.
3. If your SMTP server requires it, enter a **Username**, **Password** and an optional **Domain** name for the email server account that the Scan Station will log into.
4. Most email servers communicate on port 25. If your email server communicates on a different port, select the desired port number.
5. Select **Authentication Scheme** to select the specific SMTP Authentication Scheme used by your email server. Select from the following options:
  - Use Strongest
  - None
  - Plain
  - Login
  - MD5 Challenge Response
  - NTLM

**NOTE:** **Use Strongest** will select the strongest available authentication scheme reported by the email server. For more information on authentication schemes, consult your network administrator.

6. Use the up and down arrows to select the desired **Maximum Attachment Size** of an email attachment that can be sent successfully (1 to 99 MB in 1 MB increments).

7. Enter the email address where you want a notification to be sent that an email could not be delivered by the Scan Station in the *Return Email Address* field. This email address will also be put in the *From* field on the email.
8. If you do not want the user to have the ability to enter an email address that is not currently in the address book, uncheck the **Allow custom Email Addresses** checkbox.
9. If you do not want the user to have the ability to enter information in the subject line when scanning to email destinations, uncheck the **Allow custom Email Subject** checkbox.
10. Select the security type to setup a secure connection to your email server. Selections are: **None**, **SSL** or **Use StartTLS**.
  - **SSL**: select this option if your email server requires Secure Socket Layer (SSL).
  - **Use StartTLS**: select this option if you want to enable a secure SMTP connection.

NOTE: If selected, make sure your email server is configured to use StartTLS. If it is not, the Scan Station will fail to send an email.

11. Click **Test Connection** if you want to check to be sure your settings are correct. When finished, a *Success* or *Failure* message will be displayed. If the test connection failed, verify that all of your settings are correct and make any necessary changes, until a *Success* message is displayed.


NOTE: You may need to use the scroll bar to access the Test Connection button.

Depending on the options you selected on the main Device Settings screen, you will have the option of clicking **Next** which will display the next device you want to configure, or **Finish** which will return you to the Configuration tab.

## Configuring Active Directory Server settings

If you selected to configure the Active Directory Server, proceed with the following steps. If not, go to the section that describes the next device you want to configure.

The Active Directory Server allows you to setup a central location for network administration and security.



The screenshot shows the 'Device Settings' dialog box for the KODAK Scan Station 700 Series. The dialog has a title bar with the text 'KODAK Scan Station 700 Series - Scanner Administration' and a close button. The main area is titled 'Device Settings' and contains several input fields and dropdown menus. The fields are: 'Active Directory Server Address', 'Username', 'Password', 'Domain', 'Port' (with a dropdown menu showing '389'), 'Base DN', 'Search Field Tag' (with 'sn' entered), 'Email Address Tag' (with 'mail' entered), 'Full Name Field Tag' (with 'displayname' entered), 'Home Directory Tag' (with 'HomeDirectory' entered), 'Fax Field Tag' (with 'facsimiletelephonenumber' entered), and 'Search Results To Return' (with '50' entered). At the bottom of the dialog are four buttons: 'Cancel', 'Previous', 'Next', and 'Finish'.

1. Enter an IP address or a fully qualified domain name in the *Active Directory Server Address* field.
2. If your server requires it, enter a **Username**, **Password** and an optional **Domain** name for the Active Directory Server account that the Scan Station will log into.
3. Most Active Directory Servers communicate on port 389. If your Active Directory Server communicates on a different port, select the desired port number.
4. The Base DN (Distinguished Name), Search Field Tag, Email Address Tag, and Full Name Field Tag are strings that define the search criteria for the Active Directory Server. See your network administrator for the specific format of these strings. When you have the correct format, enter the **Base DN**, **Search Field Tag**, **Email Address Tag** and **Full Name Field Tag**.
5. In the *Home Directory Tag* field enter the name of the tag in your Active Directory Server that defines where the user's home directory is located. This requires the home directory to be defined in your Active Directory Server database.

If **Force User Login** is checked, when the user logs into the Scan Station, their home directory will automatically be used as their destination.

6. Enter the Active Directory Server **Fax Field Tag** for the tag to use when searching the Active Directory Server for fax numbers. For more information, contact your network administrator for the exact string to use (e.g., facsimiletelephonenumber).
7. Select the maximum number of records to display when performing a search from the *Search Results To Return* field. Select a number from 1 to 1000.

NOTE: You may need to use the scroll bar to access the **Security Type**, **Force User Login** and the **Test Connection** options.

8. Select the **Security Type** to setup a secure connection to your Active Directory Server. Selections are: **None**, **SSL** or **TLS**.
  - If you select **SSL** or **TLS**, the *Certificate* and *Certificate Password* fields will be displayed allowing you to select a certificate file.
  - Some certificates require a password. If your certificate requires a password, enter the password.
9. If you check **Force User Login**, it requires the user to login before beginning a scan session. At login, the user will have to enter a user name, password and domain. These credentials will be used to access network resources.

NOTE: A default administrator account is available for logging onto the Scan Station after enabling **Force User Login**. Initially the Local Access password will be “blank” and it is up to you to set this password to prevent user access to administrative functions. For information on this Local Access password, see the section entitled, “Configuring your device options” earlier in this chapter.

10. Click **Test Connection** if you want to check to be sure your settings are correct. When finished, a *Success* or *Failure* message will be displayed. If the test connection failed, verify that all of your settings are correct and make any necessary changes, until a *Success* message is displayed.


Depending on the options you selected on the main Device Settings screen, you will have the option of clicking **Next** which will display the next option you want to configure, or **Finish** which will return you to the Configuration tab.

## Configuring Fax settings

If you selected to configure Fax, proceed with the following steps.

**NOTE:** Dial-up fax settings are for the Scan Station 730EX only. Dial-up configuration settings will be ignored if they are sent to a Scan Station 710.

Fax settings can be configured to allow the Scan Station to send and receive faxes.



The screenshot shows a window titled "KODAK Scan Station 700 Series - Scanner Administration" with a sub-header "Device Settings". The window contains the following fields and controls:

- Sender's Fax Number: Text input field
- Outside Line Prefix: Text input field
- Modem Country Code: Dropdown menu with "None" selected
- Fax Failure Retries: Text input field with "0" entered
- Delay Between Retries (minutes): Text input field with "0" entered
- Fax Notification Email Address: Text input field
- Allow Fax Notification: Checkmark (checked)
- Allow Custom Fax Numbers: Checkmark (checked)
- LAN Fax Server Domain Name: Text input field

At the bottom right of the window are four buttons: "Cancel", "Previous", "Next", and "Finish".

### NOTES:

- Steps 1-8 are for the dial-up modem only (Scan Station 730EX).
  - Enter a fax number in the *Sender's Fax Number* field. This number will be displayed on the banner of outgoing faxes.
11. If your phone system requires a number to get an outside line, enter the prefix that the user needs to enter to access an outside line (e.g., 9, is frequently used and a comma “,” may be used to insert a pause) in the *Outside Line Prefix* field. Each comma pauses the dialing sequence for about 3 seconds. You can use multiple commas to increase the pause time.
  12. Select **Modem Country Code** to display a list of countries and the associated codes that configure the modem for use in the selected country.

13. Enter the number of times the Scan Station will attempt to send a fax in the *Fax Failure Retries* field.
14. Enter the number of minutes the Scan Station will wait between attempting to send a fax in the *Delay Between Retries* field.
15. If you want someone to be notified every time a fax is sent (*Success* or *Failure*), enter the email address of the person/group who should be notified in the *Fax Notification Email Address* field.
16. Check **Allow Fax Notification** if you want the user to be able to specify an email address, printer or both for *Success* and *Failure* notifications. Refer to the following table for how the **Fax Notification Email Address** and **Allow Fax Notification** work together.

Fax Notification Email Address field	Allow Fax Notification Checked	Allow Fax Notification Unchecked
<b>If specified</b>	<ul style="list-style-type: none"> <li>• Notification will be sent to the email address specified in the <i>Fax Notification Email Address</i> field.</li> <li>• The user will also be able to enter an email address on the Scan Station before scanning; if an email address is entered, a notification will be sent the that address as well.</li> </ul>	<ul style="list-style-type: none"> <li>• Notification will be sent to the email address specified in the <i>Fax Notification Email Address</i> field.</li> </ul>
<b>If left blank</b>	<ul style="list-style-type: none"> <li>• The user will be able to enter an email address on the Scan Station before scanning; if an email address is entered, a notification will be sent the that address.</li> </ul>	<ul style="list-style-type: none"> <li>• No notifications will be sent.</li> </ul>

NOTE: Fax/Printer notifications can only be configured after destinations have been defined and at least one printer has been defined. For information about setting up a printer see the section entitled, "Setting up a printer destination" in Chapter 6.

17. Check **Allow Custom Fax Numbers** if you want the user to be able to enter a fax number on the Scan Station.
18. Enter the LAN fax server domain name for customers who use an email-to-fax service (e.g., Nextiva). This setting configures how LAN fax destinations will be sent.

NOTE: This only works with an email-to-fax service that only requires sending to a particular fax number on that domain where no login is required.



19. When you have finished entering information on this screen, click **Next**. The following screen will be displayed.

KODAK Scan Station 700 Series - Scanner Administration

Device Settings

Will the Scan Station be used for receiving faxes?

Yes

No

Cancel Previous Next Finish

20. If you do not want to allow the Scan Station to receive faxes, click **No**; otherwise click **Yes** and enter the required information in the *Incoming Fax Configuration* fields.

KODAK Scan Station 700 Series - Scanner Administration

Device Settings

Will the Scan Station be used for receiving faxes?

Yes

No

Incoming Fax configuration

Network Folder:

Email Address:

Printer:

None

FTP:

None

Save as PDF

Cancel Previous Next Finish

If desired, enter one or more of the following:

- a fully qualified path name to the network folder where the incoming fax will be saved.
- the email address of the person/group where the incoming fax will be delivered.
- the printer name where the incoming fax will be sent for printing.
- the FTP site where the incoming fax will be saved.

21. Check **Save as PDF** if the incoming fax will be saved as a PDF file.

NOTES:

- If you configure the Scan Station to receive incoming faxes, you must define at least one destination; otherwise the faxes will not be delivered.
- In order for faxes to be routed to either a printer, network folder or FTP site, these destinations must be created in advance in order to be selected.

22. Click **Finish**.


# 5 Defining Scan Settings

---


- Scan Settings..... 5-3
- Black and White Settings ..... 5-5
- Color Settings ..... 5-6
- Advanced Settings ..... 5-8
- PDF Settings..... 5-11
- Filename Settings ..... 5-12


Scan Settings provide basic image processing settings, such as, color/ grayscale/black and white, output file format, compression, and some advanced options like Hole Fill, Streak Filter, etc.


1. Select **Edit>Scan Settings**.



The Setup Scan Settings screen will be displayed.




2. Click the **Add**  icon. The following screen will be displayed.



3. Make selections from any of the categories (e.g., Black and White Settings, Advanced Settings, etc.).

NOTE: For a detailed description about the options, see the sections that follow.

4. When finished making selections, click **Next**.



5. Enter a name in the *Scan Settings Name* field that describes this scan setting.
6. Click **Finish**.
7. Click **Finish**.

## Scan Settings

## Scan Settings

Setting	Value
Scan As:	Black and White
File Type:	PDF
Input Document:	Two Sided
Resolution (DPI):	300
Document Type:	Text with Graphics
Cropping:	Automatic
Post Scan Rotation:	Automatic

**Scan As** — select how you want documents to be scanned. Selections are: **Color**, **Grayscale**, **Black and White**.

**File Type** — select one of the following options:

- **JPEG**: this option is only available for Color or Grayscale. If your *Scan As* selection is **Black and White** and **JPEG** is selected, your *Scan As* selection will automatically change to **Color**.
- **TIFF - Single Pages**: creates multiple files, one for each side of a scanned page. Selections are: **None** (Uncompressed), **Group 4** or **JPEG** compression.
- **TIFF - Multi Page**: creates one file that contains all of the scanned pages. Selections are: **None** (Uncompressed), **Group 4** or **JPEG** compression.

NOTE: The compression setting depends on the *Scan As* selection. If the *Scan As* selection is **Black and White**, select a compression setting from the Black and White Settings. If the *Scan As* selection is **Color** or **Grayscale**, select a compression setting from the Color Settings.

- **PDF**: creates a PDF document. See the section entitled, “PDF Settings” later in this chapter for more information.
- **DOC**: creates a Microsoft Word document.
- **RTF**: creates a Rich Text Format file which can be read by a number of applications.
- **XLS**: creates a Microsoft Excel spreadsheet.

NOTES:

- When scanning to DOC, RTF and XLS, optical character recognition is performed on the scanned image. The .doc, .rtf or .xls file produced is based on the OCR results; therefore, the result may not be identical to the original.
- When you select DOC, RTF or XLS, the *Language* option will be displayed. Select the language you want used to generate the file.

**Input Type** — select one of the following options:

- **Two Sided**: the Scan Station will scan the front and back in a single pass.
- **One-Sided - Face Down**: if you select this option, the documents must be put in the input tray face down (the side you want to scan facing the input tray).
- **One-Sided - Face Up**: if you select this option, the documents must be put in the input tray face up (the side you want to scan facing toward you).

**Resolution (DPI)** — select **100, 150, 200, 240, 300, 400** or **600** dpi. Higher resolutions produce better quality images, but larger file sizes.

NOTE: If the *Document Type* is **PDF**, this resolution setting is ignored because the PDF resolution setting is used.

**Document Type** — select one of the following options:

- **Text with Graphics**: the documents contain a mix of text, business graphics (bar graphs, pie charts, etc.) and line art.
- **Text**: the documents contain mostly text.
- **Photographs**: the documents contain mostly photographs.

**Cropping** — select one of the following options:

- **Automatic**: automatically detects the border of an image and straightens it if necessary.
- **Aggressive**: automatically detects the border of an image, straightens it if necessary, and eliminates any residual black border on any image edges. In order to achieve this, there is a possibility that a small amount of image data from the edge of the document may be lost.

**Post Scan Rotation** — select **None** or **Automatic**. If you select **Automatic**, the Scan Station will analyze each document to determine how it was fed and rotate the image to the proper orientation.

## Black and White Settings

The Black and White settings will be grayed out, if your *Scan As* selection is **Color** or **Grayscale**.

⤴ Black and White Settings

Compression:	Group 4
Conversion Quality:	Best (iThresholding)
Contrast:	50
Noise Filters:	None
Image Filters:	None

**Compression** — you can select **None** or **Group 4**.

**Conversion Quality** —allows you to select **Best** (iThresholding) or **Normal** (ATP).

- **Best (iThresholding)** — the Scan Station dynamically evaluates each document to determine the optimal threshold value to produce the highest quality image. This allows scanning of mixed document sets with varying quality (such as faint text, shaded backgrounds, or color backgrounds) to be scanned using a single setting thus reducing the need for document sorting. When **Best** is selected, only *Contrast* can be adjusted.
- **Normal (ATP)** (Adaptive Threshold Processing) — separates the foreground information in an image (e.g., text, graphics, lines, etc.) from the background information (i.e., white or non-white paper background). When **Normal** is selected, you can adjust both *Threshold* and *Contrast*.

**Contrast** — adjusts the amount of the image foreground which is kept or attenuated. Decreasing this setting will reduce the amount of noise at the expense of possibly losing faint text. Increasing this setting will help make faint text more visible at the expense of creating more noise.

**Threshold** — aids in controlling the level at which a pixel is considered black or white. Decreasing this setting will make the image appear lighter, and can be used to subdue background noise. Increasing this setting will make the image appear darker, and can be used to help pick up light information. This options range from 0 to 255.

**Noise Filters** — select one of the following options:

- **Lone Pixel:** reduces random noise by converting a single black pixel to white when it is completely surrounded by white pixels or by converting a single white pixel to black when it is completely surrounded by black pixels.
- **Majority Rule:** sets each pixel based on its surrounding pixels. The pixel will become white if the majority of the surrounding pixels are white and vice versa.

**Image Filters** — you can select **None** or **Halftone Removal**. Halftone Removal enhances dot matrix text and images with halftone screens (e.g., newspaper photographs).

## Color Settings

The screenshot shows a 'Color Settings' panel with a list of options and their corresponding values in dropdown menus:

Setting	Value
Compression:	JPEG
Quality:	Good
Brightness and Contrast:	Automatic
Color Balance:	Automatic
Sharpen:	None
Background Smoothing:	None

**Compression** — select **JPEG** or **None**. JPEG creates multiple files, one for the front and back of a page. If JPEG is selected, you can select a *Quality* option of: **Draft**, **Good**, **Better**, **Best** or **Superior**.

**Quality** — allows you to select a **Draft**, **Good**, **Better**, **Best** or **Superior** quality option. When saving a file as PDF, predefined resolution settings will be used when selecting **Good** (150 dpi), **Better** (200 dpi), and **Best** (300 dpi). The Scan Station dpi settings will not be used when scanning in PDF mode.

NOTE: The quality settings impact the final size of the file (Draft producing the smallest file size and Superior producing the largest file size).

**Brightness and Contrast** — you can select **None**, **Automatic** or **Manual**. If you select **Automatic**, the Scan Station will select the values to use. If you select **Manual**, you can set specific values that will be used for all images:

- **Brightness:** changes the amount of white in the color or grayscale image. The values range from 1 to 100.
- **Contrast:** enhances or diminishes the differences between light and dark pixels.

NOTE: If you are scanning documents with faint text added for security and dark text that you want to keep for OCR, decrease this setting.



**Color Balance** — select one of the following options:

- **None**
- **Automatic:** adjusts the white background of each document to pure white. This option compensates for the variations that occur between different weights and brands of paper. This is not recommended for use with photographs.
- **Automatic - Advanced:** for advanced users that want to further adjust the Automatic option.
  - **Aggressiveness:** allows you to adjust the extent of the variation. Increasing this value can help with documents that have yellowed due to age. The values range from -2 to 2.
- **Manual:** allows you to set specific values that will be used for all images:
  - **Red:** changes the amount of red in the color image. The values range from 1 to 100.
  - **Green:** changes the amount of green in the color image. The values range from 1 to 100.
  - **Blue:** changes the amount of blue in the color image. The values range from 1 to 100.

NOTE: Color Balance is not available for grayscale images.

**Sharpen** — controls the enhancement of edges in the document. Options include: **None**, **Normal**, **High** and **Exaggerated**.

**Background Smoothing** — using this option for documents or forms with a background color will help produce images with a more uniform background color. This option improves image quality and may reduce file size.

- **None**
- **Automatic:** smooths up to three background colors.
- **Automatic - Advanced:** for advanced users that want to further adjust the **Automatic** option.
  - **Aggressiveness:** allows you to adjust the extent to which the background(s) are determined. The values range from -10 to 10.

## Advanced Settings

⤴ Advanced Settings

Hole Fill:

Blank Image Detection:

Image Edge Fill:

Streak Filter:

Color Dropout:

Combine Front and Back Images:

Multifeed Ultrasonic Detection:

Maximum Document Length (in):

Reverse Page Order:

- **Hole Fill:** allows you to fill in the holes that are around the edges of your document. The types of holes that are filled include: round, rectangular, and irregularly shaped (e.g., double-punched or those having a slight tear that could have occurred when the document was removed from a binder).
- **Blank Image Detection:** used to detect blank pages (e.g., the back side of a document), so these pages can be discarded. If you select this option, you can select **Based on Document Content** where you can select a percentage where document images that fall below the selected percentage will be discarded.
- **Image Edge Fill:** fills the edges of the final electronic image by covering the area with the selected color.
  - **None**
  - **Automatic:** the scanner will automatically fill the edges of the image using the surrounding color.
  - **Automatic - include tears:** in addition to filling the edges, the Scan Station will also fill in tears along the edge of document.
  - **White:** allows you to enter values for the **Top, Bottom, Left** and **Right** margins.
  - **Black:** allows you to enter values for the **Top, Bottom, Left** and **Right** margins.

- **Streak Filter:** allows you to configure the Scan Station to filter vertical streaks from your images. Streaks are lines which may appear on an image and are not part of the original document. Streaks may be caused by contaminants on your documents (e.g., dirt, dust or frayed edges) or by not following the recommended cleaning procedures for your Scan Station. Click **Streak Filter** to turn this option on where you can select an *Aggressiveness* value which allows you to adjust the extent at which the streaks are filtered. The values range from -2 to 2.
- **Color Dropout** — used to eliminate a form's background so that only the entered data is included in the electronic image (e.g., remove the form's lines and boxes). For black and white images, these settings affect the grayscale version of the document which the Scan Station analyzes to produce that electronic image. This option is only applicable for grayscale and black and white images. Select one of the following options:
  - **None**
  - **Multiple:** drops colors other than dark shades (e.g., black or dark blue ink)
  - **Predominant:** drops the predominant color
  - **Blue**
  - **Green**
  - **Red**

When you select **Multiple** or **Predominant**, you can adjust the *Aggressiveness* value to the extent at which colors are dropped. The values range from -2 to 2. The default is 0.

**Combine Front and Back Images** — typically one image is created for a document the front side and another image is created for the back side. Turn this option on if you want one image that contains both the front side and back side of the document. Select one of the following options:

- **None**
- **Front on Top:** front side will be above the back side within the image.
- **Front on Bottom:** back side will be above the front side within the image.
- **Front on Left:** front side will be to the left of the back side within the image.
- **Front on Right:** back side will be to the left of the front side within the image.

**Multifeed Ultrasonic Detection** — multifeed detection aids in document processing by detecting documents that may go through the feeder overlapped. Multifeeds can happen due to stapled documents, adhesives on documents, or electrostatically charged documents. Check this option if you want to enable a *Multifeed Response* when a multifeed is detected.

- **Multifeed Sensitivity** — controls how aggressively the scanner will work to determine if more than one document is fed into the scanner. Multifeeds are triggered by detecting air gaps between documents. This allows multifeed detection to be used with job sets containing documents with mixed thicknesses.

- **Low:** least aggressive setting and is less likely to detect labels, poor quality, thick or wrinkled documents as multi-fed documents.
- **Medium:** use if your job set has varying document thicknesses or labels attached to the document. Depending on the label material, most documents with labels should not be detected as a multi-fed document.
- **High:** the most aggressive setting. This is a good setting to use if all documents have a thickness no greater than 20-lb. bond paper.

NOTE: Regardless of the setting, “sticky” notes may still be detected as multi-fed documents.

- **Multifeed Response** — select what action you want the Scan Station to take when a multifeed is detected. With all options, the condition will be logged in the Scan Station.

- **Continue Scanning:** the Scan Station will continue to scan.
- **Stop Scanning:** scanning will stop and you will have to option to continue scanning or cancel the batch. Verify that the paper path has been cleared and restart the scan session from the scanning application.

**Maximum Document Length (in.)** — allows you to select the maximum length of the documents in your job. If the Scan Station detects a document longer than this value, it will determine that a paper jam has occurred. The default is 14 inches. Maximum length is 160 inches; minimum length is 2.5 inches.

**Reverse Page Order** — if enabled, the Scan Station will reverse the order of the scanned images from the order in which the documents were scanned.

**Allow Adding Pages To Scan Job** — when enabled, the user can continue to add pages to a scan job. After all pages in the input tray have been scanned, a message will be displayed asking if they want to add more pages. If the user selects **Yes**, the additional pages will be scanned and the message will be displayed again until the user selects **No**, or the 30-second timeout has occurred.

## Barcode Type — select a barcode type.

Allow Adding Pages To Scan Job:

Barcode Type:  Code 3 of 9  
 CODABAR  
 Interleaved 2 of 5  
 Code 128  
 UPC-A

Barcodes are read anywhere on the front and back of a document. The read order is left to right, top to bottom in both horizontal and vertical orientations. A maximum of 10 barcodes are read on each side of a document.

NOTE: Barcode accuracy is highly dependent on the quality of the scanned image. Higher resolution and larger barcodes will increase accuracy. Recommended scanner settings are 300 dpi, black and white or grayscale. If your output type is **PDF**, the **Best** quality setting should be used. Image compression may also affect accuracy. Choose the minimum compression, or uncompressed, to increase read accuracy.

Select the barcode type(s) from the *Barcode Type* list that match the barcodes on the documents to be scanned. Barcode data read when a document is scanned will be saved as metadata to a corresponding .xml file. An .xsd file has been provided on the Installation CD to validate the metadata file for integration into your backend system.

NOTE: You must check **Enable output metadata** in Device Settings to create the output metadata file.

Available barcode types are:

- Code 3 of 9
- CODABAR
- Interleaved 2 of 5
- Code 128
- EAN 13
- UPC-A
- UPC-E
- EAN 8
- EAN 13
- PDF-417 2D Code

NOTE: Selection of multiple barcode types may affect throughput performance.

## PDF Settings



The image shows a 'PDF Settings' dialog box with the following options:

- Quality:** A dropdown menu currently set to 'Good'.
- Searchable:** An unchecked checkbox.
- Single Pages:** An unchecked checkbox.
- Secure:** An unchecked checkbox.
- Compatibility:** A dropdown menu currently set to 'PDF v1.6'.

**Quality** — allows you to select a **Good**, **Better** or **Best** quality option. When saving a file as PDF, predefined resolution settings will be used when selecting **Good** (150 dpi), **Better** (200 dpi), and **Best** (300 dpi). The Scan Station dpi settings will not be used when scanning in PDF mode.

**Searchable** — creates a single- or multi-page document that contains both text and image data. OCR (Optical Character Recognition) technology is used to extract text information from the scanned image data. When you select this option, the *Language* option is displayed. Select the language you want used to generate the PDF file.

NOTE: This option specifically turns on OCR. OCR can also be enabled by selecting XLS, DOC and RTF output.


**Single Pages** — creates a PDF file for every page scanned. If scanning a two-sided document, a separate file will be created for both the front and back page.

**Secure** — allows the user to enter a password that will be used to encrypt the file before the file is delivered. The password will be sent in a separate email when *Email* is one of the destination selections.

**Compatibility** — this option is specialized for the digital preservation of electronic documents and is used if you want to generate a PDF that will be used for long term needs. Select the desired PDF option from the drop-down list.

NOTE: **PDF/A** and **Secure** are mutually exclusive.

## Filename Settings



File Name Settings allow you to define values that determine the locations (directories or subdirectories) and file name used when creating scanned documents. You can define a folder name where scanned documents will be placed when scanning to a network folder, FTP location or USB drive destination. You can also define the file name prefix that will be applied to every scanned document created. Scanned documents are created with this prefix and have an optional date and time stamp appended to the prefix. For example, if you define a prefix of *receipts* and a folder name of *2012*, the scanned document file name will have the format: *receipts\_20120117\_092219.tif* and is placed in a folder called *2012*.

- **Device Name** — allows you to use the Scan Station name in the file name or as part of the file path.
- **Date** — allows you to enter the date in the file name or as part of the file path.
- **Time (hhmmssff)** — allows you to add the time (hhmmssff) in the file name or as part of the file path.
- **Sequence Number** — allows you to use a sequence number in the file name or as part of the file path.
- **Text** — allows you to type in text that will be used in the file name or as part of the file path. This is limited to the maximum characters allowed by the target operating system.
- **Directory Separator** — allows you to use a separator in the file name or as part of the file path.

### NOTES:

- Use the up and down arrows to reorder the items in the boxes.
- When entering values, the sample file name will be displayed in the text box at the bottom of the screen.
- When you select *Text*, *Date* or *Sequence Number* additional selections will be displayed on the right.
- At least one entry must always be in the *File Name* field.

# 6 Creating Destinations

---


## Contents

Accessing the Destinations screen .....	6-1
Destination layout and terminology .....	6-3
Setting up an email destination .....	6-4
Importing an email address book .....	6-6
Setting up a network destination .....	6-8
Setting up a printer destination .....	6-10
Setting up a FTP site .....	6-14
Setting up a fax or fax to email destination .....	6-18
Adding a SharePoint group .....	6-19
Adding a Kofax Front Office Server group .....	6-21

This chapter provides procedures for adding destinations (e.g., email, network folder, printer, FTP, etc.).


## Accessing the Destinations screen

1. Select **Edit>Destinations**.






The Setup Destinations screen will be displayed.



2. Click the **Add** icon to display the Destinations screen. The Destinations screen allows you to create destinations for: Email, Network, Printer, FTP, Fax, Email to Fax, SharePoint and Kofax Front Office Server.




3. Select the destination type you want to create. When you select a destination type, a recommended name for the destination will be displayed in the *Destination Name* field. You can change this name by entering a name that is meaningful to you. This is the name that will be displayed on the Scan Station touchscreen.
4. Click **Next**. The application will step you through each destination configuration.

NOTE: For a detailed description about the different destination types see the sections that follow.


## Destination layout and terminology

After setting up a destination, a screen similar to the one below will list your destination types, destination groups and destinations.



## Setting up a email destination

1. Select **Edit>Destinations**. The Setup Destinations screen will be displayed.
2. Click the **Add** icon to display the Destinations screen.
3. Select **Email**.
4. Click **Next**.




5. Enter a name in the *Description* field and an email address in the *Enter a complete email address* field where you want the scanned documents to be sent.
  - **Search** allows you to search the network address book for email addresses. Any addresses found while searching can be added to the currently selected email group.

### NOTES:

- The network address book is the one associated with the SMTP server configured under Device Settings (Email server).
  - If more than 20 addresses are found that match the search criteria, you may want to refine your search by adding more information, such as the first name of the person you are searching; for example, "smith joe" instead of just "smith".
  - Wildcards can be added before and after the search criteria.
  - The Search function relies on the Active Directory Server device settings specified to function correctly. See the section entitled, "Configuring Active Directory Settings" in Chapter 4 for more information.
- **Import** allows you to import a CSV file. See the next section entitled, "Importing an email address book" for more information.

6. Click **Finish**. The following screen will be displayed showing the email destinations and groups.



7. If you want to add more email destinations within the same email destination group, select the **Add** icon and repeat Steps 5 and 6.
8. To add another email destination group, select the email destination type and then click the **Add** icon, otherwise, click **Finish**.

## Importing an email address book

CSV files are data files that represent database information. Each row contains data values that are separated by a comma. Each comma found on a line of text represents a column of data from the original database. The example below shows typical data exported from Microsoft's Outlook Express.

**NOTE:** The first row may contain the data column header information and **not** actual data.


**First Row** First Name,Last Name,Email Address  
Smith,John,johnsmith@rochester.rr.com  
Tom,Brown,Tombrown123@yahoo.com  
William,Doe,wdoe@msn.com

Outlook Express allows you to export your email address book to a comma-separated file. When you export your email address book, you can select which data columns you want to export.

**NOTE:** Other email programs may not allow you to select which data columns to export.

It is recommended that you only export the first name, last name, and email address.

1. Click **Import**. The **Import Email Addresses** dialog box will be displayed.



2. Enter the file name in the *File* field that contains the email addresses you want to import. If necessary, use the **Browse** button to locate the file.

3. Many email client applications automatically export the column headings as the first row of data. If you do not want to import the column headings as the first row, check **Skip first row of data**.

NOTE: Some email applications also export the data with additional quote characters surrounding the data. The quote characters will be removed while importing data.

4. Enter the column numbers where the **First Name**, **Last Name** and **Email Address** appear in the CSV file.

After selecting a CSV file and column locations, a preview will be displayed showing the results of the file Column Location selections. If the column selections are changed, the preview will reflect these changes.

For example, if the three *File Column Location* values are 1, 2, and 3 the preview would display the following:

First Name Last Name	Email Address
----------------------	---------------

The First Name and Last Name are combined to form the email address display name. The Email Address is used to create the email address.


If all three File Column Location values were set to 1, then the preview would look like this:

First Name First Name	First Name
-----------------------	------------

5. Click **Import**. The email addresses will be added to the selected email group.

## Setting up a network destination


1. Select **Edit>Destinations**. The Setup Destinations screen will be displayed.
2. Click the **Add** icon to display the Destinations screen.
3. Select **Network**.
4. Click **Next**.



5. Enter a network destination name that is meaningful to you in the *Description* field.
6. Enter a fully qualified folder path in the *Enter a complete directory path* field and click **Finish**.

NOTE: You must use a full network path if you are scanning to a DFS based network.

The following screen will be displayed showing the network destination and group.



7. If you want to add more network destinations within the same network destination group, select the **Add** icon and repeat Steps 5 and 6.
8. To add another network destination group, select the network destination type and then click the **Add** icon, otherwise, click **Finish**.



## Setting up a printer destination

The Scan Station uses the Microsoft “*Point and Print*” technology for installing print drivers and connecting to network printers. Typically, network printers are attached to print servers which manage the scheduling of print jobs for one or more network printers. These print servers manage print queues for each connected printer and can also deliver and install print drivers to other network PCs or devices.


NOTE: Before installing printers, be sure you have a Windows 7 or Windows 8 (32-bit) compatible driver on the print server or host PC.

The Scan Station can connect to printers in the following ways:

- Connect to a printer that is connected to a print server on a network domain.
- Connect to a printer that is shared by another computer on a network workgroup.
- Connect to a network printer that is directly connected to the network via an Ethernet cable plugged directly into a router or hub.

In each of these scenarios, Microsoft Windows may also require login credentials for any device requesting access to a network printer.


1. Select **Edit>Destinations**. The Setup Destinations screen will be displayed.
2. Click the **Add** icon to display the Destinations screen.
3. Select **Printer**.
4. Click **Next**.



The screenshot shows a Windows-style dialog box titled "KODAK Scan Station 700 Series - Scanner Administration" with a sub-header "Destinations". The dialog contains several input fields: "Description", "Enter a complete directory path (Ex. \\printserver\printq):", "Username:", "Password:", "Domain:", and a section for "Printer Driver Settings" which includes "Address:" and "Driver Name:". At the bottom right, there are four buttons: "Cancel", "Previous", "Next", and "Finish".

5. Enter any text that describes the printer in the *Description* field.
  - If you want to connect to a print server on a network domain or to a printer that is shared by another computer on a network, continue with Step 6.
  - If you want to connect to a network printer that is directly connected to the network via an Ethernet cable plugged directly into a router or hub, click the **Printer Driver Settings** down arrow and continue with Step 11.
6. Enter the fully qualified path to the printer server and print queue (e.g., \\printservername\printqueue) in the *Enter a complete directory path* field.
7. If the network domain is configured to require authentication to install a printer driver, enter the **Username**, **Password**, and **Domain** names.

NOTE: If proper authentication is not provided, the printer and its driver may not be installed on the Scan Station.
8. Click **Finish**. The following screen will be displayed showing the printer destination and group.




9. If you want to add more printer destinations within the same printer destination group, select the **Add** icon and repeat Steps 5 - 8.
10. To add another printer destination group, select the printer destination type and then click the **Add** icon, otherwise click **Finish**.

If you want to configure a printer that is directly connected to the network, follow Steps 11 - 18. The printer must first be “shared” from a computer on the network in order to download the print driver. The shared printer must also be configured to provide a Windows 7 driver for the printer. Once shared, you need the driver name and port name from this computer.

11. In the *Enter a complete directory path* field, enter the network printer IP address and print queue (e.g., \\192.168.1.136\printQueue Name).

On the PC that is sharing the printer:


12. Click **Start>Settings>Printers and Faxes** and select the installed printer.
13. Right-click on the installed printer and select **Properties**. The Properties window will be displayed.




14. Write down the **Driver Name**. The location of this information may be different for each printer.

15. On the Ports tab, write down the exact text that appears on the selected Port value.

NOTE: As shown below, this would be "IP\_192.168.2.137".



16. Return to the *Kodak Scan Station 700 Series - Scanner Administration* application and enter the fully qualified address of the PC sharing the printer including the *share* name (e.g., \\workgroupPC\BrotherH) in the *Address* field.




17. With the information from Steps 14 and 15, enter the driver name and the port name in their respective fields.
18. If you want to add more printer destinations within the same printer destination group, select the **Add** icon and repeat this procedure starting with Step 5.
19. To add another printer destination group, select the printer destination type and then click the **Add** icon, otherwise click **Finish**.

The printer driver will be installed from the sharing PC. A connection will be made between the printer and the Scan Station using the IP address entered. After the initial installation, the shared printer connection is no longer required and the Scan Station will be able to communicate directly with the network printer.

NOTE: If a printer fails to install, check the logfile for the error code. Search for the error code on the Microsoft website.

## Setting up a FTP site

1. Select **Edit>Destinations**. The Setup Destinations screen will be displayed.
2. Click the **Add** icon to display the Destinations screen.
3. Select **FTP**.
4. Click **Next**.



5. Make an entry in the *Description*, *Enter a server name and directory path*, *Username* and *Password* fields. The *Enter server name and directory path* field should contain a complete path to the FTP site including the subfolder into which scanned documents will be placed. For example, `ftp://ftp.acme.com/documents` would connect to the FTP site `ftp.acme.com` and place the scanned documents in the folder `documents`.
6. Select the desired **Protocol** option: **FTP**, **FTPS** or **SFTP**.
  - If you select **FTP** the following options are available:
    - If the FTP site communicates on a port other than Port 21, change the value using the up and down arrows.
    - You may optionally select **Passive** if required by the FTP server. **Passive** is commonly used if the FTP site is outside of the firewall.

Click the **Proxy** down arrow to configure the proxy settings.

- Select **USER after login** for the *Proxy Type*.
- Enter the **Proxy Address** in the form of a fully qualified domain name (e.g., FTP.acme.com) or as an IP address.
- Enter the **Username** and **Password** required to access the proxy server.
- If the proxy server is configured to communicate on a port other than Port 21, change the value using the up and down arrows.

- If you select **FTPS** the following options are available:

- Select an **Encryption** option: **Implicit** or **Explicit**.

When set to **Explicit**, the Scan Station and the server negotiate on whether or not to encrypt the data and what form of encryption should be used. Explicit FTPS is on Port 21. The Scan Station will accommodate this selection if the server is capable of receiving encrypted data.

When set to **Implicit**, the Scan Station is expected to always send encrypted data. The default port is 990.

Consult the FTP server administrator for the appropriate encryption option.

- Check **Passive** if you want to enable Passive port negotiation.
- Check **Require verifiable SSL server certificate** if your network environment is more security conscious and you require your certificates to be up-to-date and signed by a certificate authority.

Click the **Proxy** down arrow to configure the proxy settings.

- Select **SOCKS** as your *Proxy Type*.
- Enter the **Proxy Address** in the form of a fully qualified domain name (e.g., FTP.acme.com) or as an IP address.
- Enter the **Username** and **Password** required to access the proxy server.
- If the proxy server is configured to communicate on a port other than Port 1080, change the value using the up and down arrows.
- Select the appropriate **Version** for the proxy server. If you do not know if you should use **SOCKS4** or **SOCKS5**, consult your administrator.

- If you select **SFTP** the following options are available:
  - If the SFTP site communicates on a port other than Port 22, change the value using the up and down arrows. When you select **SFTP**, the port value will automatically change to the default value of Port 22.
  - A Private Key file is an encrypted key that is used to access the SFTP server. There are several different types of Private Key files. Use the **Browse** button to select the Private Key file stored on your computer or network. Consult the SFTP administrator for the appropriate Private Key file to use.  
  
NOTE: Private Key files encrypted with DSA 2048, 4096 bits and Putty SSH1 RSA are not supported.
  - If you entered a Private Key file and the file is password protected, you must enter a password. The password is used to decrypt the Private Key file.

Click the **Proxy** down arrow to configure the proxy settings. SFTP supports two proxy types: **HTTP** and **SOCKS**.

#### **HTTP**

- If you select **HTTP** as your Proxy Type, enter the **Proxy Address** in the form of a fully qualified domain name (e.g., FTP.acme.com) or as an IP address.
- Enter the **Username** and **Password** required to access the proxy server.
- If the proxy server is configured to communicate on a port other than Port 81, change the value using the up and down arrows.
- Select the appropriate **Authentication Type** for the proxy server. If you do not know if you should use **LOGIN** or **NTLM**, consult your administrator.

#### **SOCKS**

- If you select **SOCKS** as your Proxy Type, enter the **Proxy Address** in the form of a fully qualified domain name (e.g., FTP.acme.com) or as an IP address.
- Enter the **Username** and **Password** required to access the proxy server.
- If the proxy server is configured to communicate on a port other than Port 1080, change the value using the up and down arrows.
- Select the appropriate **Version** for the proxy server. If you do not know if you should use **SOCKS4** or **SOCKS5**, consult your administrator.

7. Click **Finish**.
8. If you want to add more FTP destinations within the same FTP destination group, select the **Add** icon and repeat Steps 5 - 8.
9. To add another FTP destination group, select the FTP destination type and then click the **Add** icon, otherwise, click **Finish**.




## Setting up a fax or email to fax destination

You can setup a destination to a fax machine or email to fax. The steps are the same for either destination.

NOTE: You can only set up a fax destination or an email to fax destination (not both) for a specific configuration.


1. Select **Edit>Destinations**. The Setup Destinations screen will be displayed.
2. Click the **Add** icon to display the Destinations screen.
3. Select **Fax** or **Email to Fax**.
4. Click **Next**.



5. Enter a name in the *Description* field and a fax number (or email to fax number) in the *Enter a Fax Number (Email to Fax Number)* field, then click **Finish**.
6. If you want to add more fax destinations within the same fax destination group, select the **Add** icon and repeat Step 5.
7. To add another fax destination group, select the fax destination type and then click the **Add** icon, otherwise, click **Finish**.

## Adding a SharePoint group

1. Select **Edit>Destinations**. The Setup Destinations screen will be displayed.
2. Click the **Add** icon to display the Destinations screen.
3. Select **SharePoint**.
4. Click **Next**.



5. Make an entry in the *Description* field that identifies the destination.
6. Enter the address of the SharePoint server in the *Enter a complete SharePoint website* field. This field must contain a complete path to the SharePoint site.
7. Make an entry in the *Username* and *Password* fields.
8. If the SharePoint site you want the user to access is secure, you will need to enter the certificate file and password by clicking the **Certificate** arrow. The SharePoint Certificate options will be displayed.
  - Enter the name of the certificate file in the *Certificate* field. The following file extensions are allowed: .cer, .crt, .der, .pfx, .p12, .p76, and p7c.
  - Enter the certificate password that the user should enter to open and decrypt the certificate file.
9. If your company requires the use of a proxy server before communicating with the SharePoint site, you must define these proxy settings by clicking the **Proxy** arrow.
10. Enter the **Proxy Address** in the form of a fully qualified domain name (e.g., proxy.mycompany.com) or as an IP address.
11. Enter the **Username** and **Password** required to access the proxy server.

12. If the proxy server is configured to communicate on a port other than Port 80, change or enter the value using the up and down arrows.
13. In the *Documents Path* field, enter the path to the folder where the documents will be scanned. If necessary, use the **Browse** button to help locate the folder.
14. If there are required index fields for the selected library, select the **Index Fields** button. The Index Fields dialog box will be displayed that shows the required and optional index fields associated with the selected library.

NOTES:

- A maximum of 5000 characters is allowed in the *Index Notes* field. If you enter more than 5000 characters, a warning message will not be displayed until you click in another area in the input field. At that point, when you click **OK** on the message, all of the data you entered in the *Index Notes* field will be deleted.
- The first part of the document path is the library; anything after that, is a subdirectory. The library contains index fields.
- You must have a certificate before entering index fields (see Step 8).
- If the index field has a down arrow to the right of the index value, click it to display the value options.


The supported types of index fields are:

Single line of text	Multiple lines of text
Choice	Number
Currency	Date and Time
Lookup	Yes/No
Person or Group	Hyperlink or Picture

15. If you want to add more SharePoint destinations within the same SharePoint destination group, select the **Add** icon and repeat Steps 5 - 14.
16. To add another SharePoint destination group, select the SharePoint destination type and then click the **Add** icon, otherwise click **Finish**.

## Adding a Kofax Front Office Server group

1. Select **Edit>Destinations**. The Setup Destinations screen will be displayed.
2. Click the **Add** icon to display the Destinations screen.
3. Select **Kofax Front Office Server**.
4. Click **Next**.



KODAK Scan Station 700 Series - Scanner Administration

Destinations

Description

Enter a complete Kofax Front Office Server address (Ex. http://server)

Port:

80

Username:

Password:

Client ID (The device MAC address in this format xx-xx-xx-xx-xx-xx):

Shortcut Type:

Group

Cancel Previous Next Finish

5. Make an entry in the *Description* field that identifies the destination.
6. Enter a server address in the *Enter a complete Kofax Front Office Server address* field.
7. If the proxy server is configured to communicate on a port other than Port 80, select the correct value.
8. Enter the **Username** and **Password** required to access the Kofax Front Office Server.
9. In the *Client ID* field, enter the Scan Station's MAC address (address format: xx-xx-xx-xx-xx-xx). This information can be found on the About screen on the Scan Station.
10. Select **Group** or **Personal** from the *Shortcut Type* list.
11. Click **Browse** to locate the Shortcut name. The Select Shortcut dialog box will be displayed. Select the desired shortcut and click **OK**.

12. Click **Index Fields**. The Index Fields dialog box will be displayed. Index fields will vary based on each company's implementation of the Kofax Front Office Server.
13. If the Kofax Front Office Server is secure, enter (or browse to) the name of the certificate file in the *Certificate* field. The following file extensions are allowed: .cer, .crt, .der, .pfx, .p12, .p76, and p7c.
14. Enter the certificate password that the user will need to enter to open and decrypt the certificate file.
15. If you want to add more Kofax Front Office Server destinations within the same Kofax Front Office Server destination group, select the **Add** icon and repeat Steps 5 - 14.
16. To add another Kofax Front Office Server destination group, select the Kofax Front Office Server destination type and click the **Add** icon, otherwise click **Finish**.

# 7 Adding and Managing Groups

---


This chapter provides procedures for adding and maintaining groups.

Groups are a collection of network users whose names can be extracted from the Active Directory Server. You can create a group from the contents of an existing Active Directory Server group and you can add individual users from the Active Directory Server to your group. For more information see the section entitled, "Configuring Active Directory Server settings" in Chapter 4.


## Assigning groups

Setting up groups makes it easier to restrict access to specific jobs to groups of users.

1. Select **Edit>Groups**.



The Setup Groups screen will be displayed.



2. Click the **Add** icon to display the Group screen.

KODAK Scan Station 700 Series - Scanner Administration

Group  
Step 1 of 4

Group Name:  
Sues group

Cancel Previous Next Finish

3. Enter the desired group name and click **Next**. Group names can be anything that is meaningful to you that defines a group of users.

KODAK Scan Station 700 Series - Scanner Administration

Group  
Step 2 of 4


Do you want to add groups from LDAP?

Yes  
 No

Cancel Previous Next Finish

- If you do not want to add groups from your Active Directory Server, click **No**, then click **Next** and continue with Step 8.

- If you select **Yes**, the search fields will be displayed allowing you to find a group name from your Active Directory Server (LDAP).




4. In the *Enter the Group to search* field, enter the name of the group that you want to add and click **Search**.

**NOTES:**

- If you entered search criteria that generated too many hits, a message will be displayed asking you to refine your search criteria.
  - Wildcards can be added before and after the search criteria.
5. Select the group(s) that you want to add from the list on the right and click the left arrow. The groups will be added in the *List of groups* box.
  6. Repeat Steps 4 and 5 to add other groups to the list.
- NOTE:** If you want to delete a group from the *List of groups*, select the group you want to delete and click the **Delete** icon.



7. When finished, click **Next**.



8. To add users from the Active Directory Server, select **Yes**.

9. Enter the name of the user you want to add to the group and click **Search**.


**NOTES:**

- If too many addresses are found that match the search criteria, you may want to refine your search by adding more information, such as the first name of the person you are searching; for example, "smith joe" instead of just "smith".
- Wildcards can be added before and after the search criteria.

10. Select the user(s) to add to the group from the displayed list and click the left arrow.

11. When you are finished adding all users to your group, click **Next**.

A listing of the groups and users will be displayed.




12. Click **Finish**.

## 8 Creating Jobs


---

Because jobs are a collection of scan settings, destinations and groups of users, it is recommended that you create jobs after you have defined all of these settings.

1. Select **Edit>Jobs**.



The Setup Jobs screen will be displayed.



2. Click the **Add** icon. The Job screen will be displayed.


The screenshot shows a software window titled "KODAK Scan Station 700 Series - Scanner Administration" with a sub-header "Job" and "Step 1 of 5". The main area contains a "Job Name:" label followed by a text input field. Below that is "Job button image (optional):" with a "Set image..." button and an empty image box. Three radio buttons are listed: "Display job name" (selected), "Display image", and "Display image and job name". A "Job Button Preview:" label is above a larger empty box. At the bottom right are four buttons: "Cancel", "Previous", "Next", and "Finish".

3. Enter a job name. As you enter the job name, it will be displayed in the *Job Button Preview* box. This is how the name will appear on the Scan Station touchscreen.
4. If desired, you can select an image file that you want to use as a background to the job name. Click **Set image** to locate the desired image file.

NOTES:


- The maximum image width is 200 pixels; the maximum image height is 130 pixels. Images will be automatically scaled to size.
  - If you select an image file, the **Display image and name** option will automatically be selected.
  - The image that you select will copied into the configuration file.
5. Select one of the following:
    - **Display Job name** — only the job name will be displayed on the Job Button
    - **Display image** — only the image will be displayed on the Job Button.
    - **Display image and name** — both the job name and image will be displayed on the Job Button.

6. Click **Next**. The following screen will be displayed.



7. Select the Scan Settings you want to use for this job and click **Next**. The following screen will be displayed.

NOTE: You can also create new scan settings from this screen by clicking the **Add** icon.




8. Select the destination(s) where want this job to be sent:


- You can select entire destination groups by clicking the highest level checkbox for the group.
- You can select individual destinations by clicking on the destination(s) that is displayed below the group name.

- If you want to create another destination on-the-fly, click the **Add** icon. The Destinations screen will be displayed allowing you to add another destination. For procedures on adding destinations see Chapter 6, *Creating Destinations*.

9. Click **Next**, then select the group where you want to send this job.




10. When finished, click **Next**. A summary of your job settings will be displayed.




11. Click **Finish**.

Once a job has been defined and the configuration has been uploaded to a Scan Station, the Jobs-only screen will be displayed on the Scan Station touchscreen instead of the normal user interface.



Once a job has been defined and the configuration has been uploaded to a Scan Station, the Jobs-only screen will be displayed on the Scan Station touchscreen instead of the normal user interface.





# 9 Monitoring and Managing Your Scan Stations

---


## Contents

Scanners tab.....	9-2
Toolbar .....	9-2
Grid view .....	9-4
Network configuration options.....	9-5
Adding a Scan Station.....	9-5
Discovering devices .....	9-7
Modifying a Scan Station .....	9-8
Deleting a Scan Station.....	9-9
Changing a password .....	9-9
Configurations/configuration files.....	9-10
Updating your Scan Station .....	9-10
Method 1 .....	9-11
Method 2 .....	9-13
Method 3 .....	9-15
Method 4 .....	9-16
Method 5 .....	9-17
Scan Station Security .....	9-18
Password protecting the Scan Station .....	9-19
Retrieving and clearing files.....	9-20
Retrieving the Scan Station log file .....	9-20
Clearing a log file .....	9-22
Retrieving the Scan Station transaction log file .....	9-23
Clearing a transaction log file .....	9-24
Saving all log files .....	9-24
Scan Station details .....	9-25
Updating Time/Date remotely .....	9-25
Turning off one or more Scan Stations.....	9-26
Restarting one or more Scan Stations .....	9-26
Moving one or more Scan Stations .....	9-27

This chapter provides information for monitoring any Scan Stations that have been found on the network and configured.

## Scanners tab




The Scanners tab contains the specific data to identify and connect to Scan Stations on a network.







When the Scanners tab is active, you will have access to the Scanner menu. The options on the Scanner and Help menus are described in the section entitled, “Menu options” in Chapter 3.

## The toolbar

The toolbar provides quick access to commonly used functions. The toolbar is always displayed. You cannot add, delete or move toolbar buttons.

Icon	Description
	Displays the Add Scanner dialog box, which allows you to choose Scan Stations that will be managed remotely.
	Allows you to rename the selected Scan Station and set network settings.
	Allows you to delete the selected Scan Station from the list of managed Scan Stations.

	<p>Refreshes the grid to display the current state of the Scan Station:</p> <ul style="list-style-type: none"> <li>• Idle</li> <li>• Scanning</li> <li>• Processing images</li> <li>• Sending email</li> <li>• Saving</li> <li>• Printing</li> <li>• Scan completed</li> <li>• Error</li> <li>• Cancelled</li> <li>• Preview</li> <li>• Sending Fax</li> <li>• Receiving Fax</li> <li>• Powering down</li> <li>• Rebooting</li> <li>• Updating</li> <li>• In Use</li> <li>• Not found</li> </ul> <p>For a description of these states see the section entitled, "Menu options" in Chapter 3.</p>
	<p>Retrieves, displays and allows the saving of the log file on the selected Scan Station.</p>
	<p>Displays and allows the saving of the transaction log file on the selected Scan Station.</p>
	<p>Displays detailed information about the selected Scan Station (e.g., software version, IP address, etc.).</p>

## Grid view

Following is a description of the grid view columns

Scanner Name	IP Address	DHCP	HTTPS	Scanner Group	Model	Status	Last Command	Comment	Mac Address
KSS51002806	150.102.77.197	✓			720EX	Not Found	File Upload - 5/5/2014 1:52:10 PM - Success		00224D9ECE49

**Scanner Name** — displays the name assigned to the Scan Station.

**IP Address** — displays the IP address that is associated with the Scan Station.

**DHCP** — if the Scan Station is configured to retrieve the IP address using DHCP, this field will be checked. If the Scan Station is configured to use a statically defined IP address, this field will be blank.

**HTTPS** — if the Scan Station is configured to communicate using HTTPS, this field will be checked.

**Scanner Group** — Scan Stations can be associated with a group name. This column displays the group that the Scan Station is part of. This is set when adding a Scan Station.

NOTE: This is not the same as the group of users defined when creating and modifying configurations.

**Model** — displays the model number of the Scan Station (i.e., 730EX, 710, 5XX, etc.).

**Status** — displays the current status of the Scan Station (e.g., idle, scanning, updating, rebooting, etc.).

NOTE: When you press F5, the status of the discovered Scan Stations will be refreshed immediately.

**Last Command** — displays the last command that was issued by the administrator including the date, time and the success or failure of the action performed.


**Comment** — any comments added by the administrator when a Scan Station is added will be displayed in this column.

**Mac Address** — displays the unique identifier of the network adapter.

## Network configuration options

Before you can start adding or discovering Scan Stations you must know the IP address or the device name; preferably both.

To get the name of your Scan Station:

1. Be sure the Scan Station is on and operational.
2. Click on the Information icon  on the Scan Station to display the name and IP address if the Scan Station is connected to a network.


## Adding a Scan Station

Before adding a Scan Station to manage remotely, it is suggested that you obtain the Scan Station name(s) and/or IP addresses and remote access password(s) of the Scan Stations you want to add.

NOTE: The Scan Station will only have an IP address if the Scan Station is connected to a network and has been configured.

As Scan Stations are added, the main screen will be updated.

1. Select **Scanner>Add Scanner**. The Add Scanner dialog box will be displayed.



2. Enter the name of the Scan Station in the *Scanner Name* field.

NOTE: Acceptable values in this field are: alphanumeric characters and a dash. No spaces or other symbols are allowed.

3. Enter the IP address. The IP address must be in IPv4 format xxx.xxx.xxx.xxx.

4. Enter the remote access password for the Scan Station. See the section entitled, "Configuration your device options" in Chapter 4 for more information.

NOTE: This field can be left blank. Leave this field blank if there is no remote access password set for the Scan Station.

5. If desired, enter a name of the group (or location). This name will be displayed in the grid view. For example, the Scan Station may be located in the main branch of a corporation.
6. If desired, enter any additional information that is important to you in the *Comment* field. For example, you can enter the name of the department where the Scan Station is located.
7. Click **Add**. The Scan Station name and information will be displayed on the *Kodak Scan Station 700 Series - Scanner Administration* main screen.

NOTES:


- If the Scan Station is not found or if you are adding a Scan Station that will be installed on the network at a later time, the message, ***There was an error communicating with the device, would you like to Add it anyway?*** will be displayed. Click **Yes** to add the Scan Station.
  - If an incorrect IP address is entered, you may have to delete the Scan Station information from the *Kodak Scan Station 700 Series - Scanner Administration* main screen and add it again with the correct information.
8. Follow Steps 1 - 7 to add additional Scan Stations to this group.

## Discovering devices

The Discover Devices option allows you to scan a range of IP addresses to find and automatically register any Scan Station that has an IP address that falls within the defined range of addresses.

NOTE: The Discover Devices option only works on Scan Stations that have not had their remote access password set. This is the password that was set using the **Scanner>Add Scanner** menu option from the Scanner tab or from the **Scanner>Remote Access Password** menu option.

1. Select **Scanner>Discover Devices**. The Discover Devices dialog box will be displayed.



2. Enter the first IP address where you want to start the search within a range of IP addresses in the *Start IP Address* field.


NOTE: As soon as you click on (or tab to) the *End IP Address* field, the end IP address will automatically be filled in with an address that is 10 greater than the start IP address (e.g., Start = 192.168.1.1, End = 192.168.1.10).

3. Enter the last IP address where you want to end the search in the *End IP Address* field.
4. Click **Search**. The search will begin. Depending on the range of the search, this process may take a few minutes. As IP addresses are found within the range, they will automatically be registered.

NOTE: If you select an address range that spans the upper two address segments of the IP address, it may take an exceedingly long time to discover devices (e.g., 192.168.1.1 - 192.169.1.1 or 192.168.1.1 - 193.168.1.1).


## Modifying a Scan Station

1. Select **Scanner>Modify Scanner**. The Modify Scanner dialog box will be displayed.



2. Make any required changes.

**NOTE:** If you select **Static IP Address**, the Static IP Address dialog box will be displayed allowing you to change IP address settings.




3. Click **OK**.



## Deleting a Scan Station

1. Select **Scanner>Delete Scanner**. The Delete Scanner dialog box will be displayed.




2. Click **Yes**.

## Changing a remote access password

1. Select **Scanner>Remote Access Password**. This password is used by the *Kodak Scan Station 700 Series - Scanner Administration* to communicate with the Scan Station.

The Remote Access Password dialog box will be displayed.



2. Enter the Scan Station remote access password in the *Current password* field.  
**NOTE:** This field will be grayed out if there is no remote access password set.
3. Enter a new remote access password in the *New password* field.
4. Re-enter the new remote access password in the *Confirm new password* field.
5. Click **OK**.

## Configurations/ configuration files

Configurations are a collection of settings that include: Device Settings, Scan Settings, Destinations, Groups and Jobs. Configurations are stored in two places: on the PC running the *Kodak Scan Station 700 Series - Scanner Administration* application and on the Scan Station(s) where the configuration file is uploaded. For more information on the difference between configurations and configuration files, see Chapter 13, *Glossary*.

## Updating your Scan Station

There are five ways to update your Scan Station:

- **Method 1.** Uploading configurations and firmware updates using the *Kodak Scan Station 700 Series - Scanner Administration* application. The Scan Station will automatically recognize the new configuration or update package and perform an update automatically. See the section entitled, “Method 1” later in this chapter for more information.
- **Method 2.** The configuration file and optional firmware update package is stored on a network drive and the Scan Station is configured to poll this shared folder at a specific day and time for updates. See the section entitled, “Method 2” later in this chapter for more information.
- **Method 3.** The configuration file is stored on a USB drive inserted into a Scan Station. You will be asked if you want to update the Scan Station’s configuration. If you select **Yes**, you will be prompted to update individual items. See the section entitled, “Method 3” later in this chapter for more information.
- **Method 4.** The configuration file can be exported to a USB drive for use in configuring a Scan Station manually. When installing a configuration file using a USB drive, if the contents of the configuration file do not match the exact contents of the configuration file currently stored on the Scan Station, you will be prompted to update the Scan Station with the configuration on the USB drive. If you select **No**, the Scan Station will be placed into local administrative mode. At this point you can modify most of the Scan Station’s settings and they will be updated as soon as you remove the USB drive. See the section entitled, “Method 4” later in this chapter for more information.
- **Method 5.** The configuration file is stored on a USB drive with a firmware update package. Only the firmware will be updated with this method. See the section entitled, “Method 5” later in this chapter for more information.


## Method 1

The configuration file and optional update package is uploaded using the *Kodak Scan Station 700 Series - Scanner Administration* application. The Scan Station will recognize the new configuration file or update package and perform an update automatically.

### Uploading configuration files

1. From the Configuration tab, select the configuration you want to upload to the Scan Station.
2. Select **File>Upload**. The following screen will be displayed

NOTE: If the selected configuration has changed, an asterisk will appear next to the configuration name. You must select **File>Save** before the configuration can be uploaded to the Scan Station.



3. Check the boxes next to the Scan Stations where you want to upload the configuration.


NOTE: The Scan Station will be restarted automatically after the upload process.

## Uploading firmware

1. Select the Scan Station(s) where you want to send new firmware.

NOTE: To select more than one Scan Station, use the Ctrl or Shift key and click the mouse button. The selected Scan Stations will be highlighted.

2. Select **Scanner>Upload Firmware**. The Open dialog box will be displayed.



3. Select the file that you want to upload and click **Open**.

NOTES:

- Only a KSSUpdate.exe file can be uploaded to the Scan Station.
- The message, **Uploading, Please wait** will be displayed while the file is being uploaded.
- If the Scan Station firmware and the KSSUpdate firmware are at the same revision level, no action will be taken.
- You can “roll-back” to an older version or update to a newer version of the Scan Station firmware. If an older version of the KSSUpdate.exe file is uploaded, the Scan Station will be rolled back to use the older version of the firmware. If a newer version is uploaded, the Scan Station will be updated with this newer firmware.
- You can obtain update packages from your Service Representative. Update packages will always be a file called KSSUpdate.exe.

## Method 2

The Scan Station can be configured to monitor a network folder where configurations and firmware updates are installed.

**NOTE: If you have a Scan Station 710, it is suggested that you do not use this method because it will go into Low Power mode.**

1. Select the Configuration tab.
2. Select the configuration that you want to modify.
3. Select **Edit>Device Settings**.
4. Check **Device Options** and click **Next**.
5. Click the **Automatic Configuration Schedule** arrow and define the following values.

The screenshot shows the 'Automatic Configuration Schedule' configuration window. It has a title bar with a collapse icon and the text 'Automatic Configuration Schedule'. Below the title bar are three fields: 'Folder:' with an empty text input box; 'Day(s):' with a dropdown menu showing 'Every Day'; and 'Time of Day:' with two spinners, the first showing '07' and the second showing '00', separated by a colon.

- Path to the folder where updates can be found.
- Which day of the week (Every Day, Every Monday, etc.).
- The time of day to check for updates (a 24-hour clock).

For example, you may want to monitor the folder `\\myserver\updates\myscanstationID` on *Every Monday*, at *7:00 a.m.*

There are two ways to remotely configure and update your Scan Station:

- **Single file/folder update** — create a single folder on the network where all Scan Stations are configured to monitor for updated configuration files. This way allows you to send a single configuration to all of the Scan Stations on a network at one time. This is recommended when all of your Scan Stations share the same configuration.

NOTE: When using remote update, some configuration settings (Scanner name, IP address and Remote Access Password), are ignored to avoid creating duplicate devices on your network.

- **Multiple files/folder update** — if each of your Scan Stations require a different configuration, it is recommended that a common folder is created on the network with subfolders underneath to store individual configuration files for each Scan Station on your network. Each Scan Station should then be configured to monitor the appropriate folder for updates.

On the defined day of the week and time, the Scan Station checks for the specified folder on the network, and if found, examines the contents of the folder looking for a KSS.xml file and an optional KSSUpdate.exe file. If the KSS.xml file and/or the KSSUpdate.exe file is found, the modification date and time will be compared to the last time a configuration was executed on the Scan Station. If the KSS.xml file and/or the KSSUpdate.exe file is more current, the configuration settings and/or new firmware update in the file are applied to the Scan Station.

NOTES:

- You can obtain update packages from the Kodak website or from your Service Representative. Update packages will always be a KSSUpdate.exe file.
- To configure your network folder (the folder you specified in the Automatic Configuration Schedule: Step 5) for configuration and firmware updates:
  1. Select the Configuration tab.
  2. Select a configuration file to write to the network folder.
  3. Select **File>Export** to write the configuration file to a network folder. The Save As screen will be displayed.
  4. Save the file on the network folder with the name **KSS.xml** and click **Save**.
  5. Copy KSSUpdate.exe to the network folder.

### Method 3

This method requires a configuration file to be copied to a USB drive. When the USB drive is inserted into the Scan Station and recognized, you will be prompted to update the Scan Station configuration.

NOTE: If a local access password is set, you will be prompted to enter the local access password.



If you select **Yes**, you will be prompted to update individual items. When the configuration update is complete, click **OK** or remove the USB drive and the Scan Station will automatically be restarted.

This method must be repeated for each Scan Station.


To configure your USB drive for configuration updates:

1. Select the Configuration tab.
2. Select a configuration file to write to the USB drive.
3. Select **File>Export** to write the configuration file to a USB drive. The Save As screen will be displayed.
4. Save the file on the USB drive with the name **KSS.xml** and click **Save**.

## Method 4

This method allows you to interactively select any of the Scan Station settings that are available in Settings mode on the Scan Station touchscreen and modify their values. When the USB drive with the configuration file is inserted into the Scan Station and recognized, you will be prompted to update the Scan Station configuration.

NOTE: If a local access password is set, you will be prompted to enter the local access password.



If you select **No**, the Scan Station will be placed into local administrative mode. At this point you can modify most of the Scan Station's settings and they will be updated when you remove the USB drive.

To configure your USB drive for configuration updates:

1. Select the Configuration tab.
2. Select a configuration file to write to the USB drive.
3. Select **File>Export** to write the configuration file to a USB drive. The Save As screen will be displayed.
4. Save the file on the USB drive with the name **KSS.xml** and click **Save**.

For more information see the document entitled, "Configuring User Settings".



## Method 5

This method requires an update package and a configuration file to be copied to a USB drive. When the USB drive is inserted into the Scan Station and recognized, if the update package is a different version than the currently installed version, you will be prompted to update the Scan Station firmware. Both the old version number and the version number of the update package will be displayed. If you decide to update the firmware, all the data found in the update package will be copied to the Scan Station and installed. When the installation is complete, click **OK** or remove the USB drive and the Scan Station will automatically be restarted.

When the Scan Station detects the configuration file (kss.xml) the message, ***Do you want to be prompted to update the device configuration?*** will be displayed. Select **Yes** and follow the prompts on the Scan Station if an update package (KSSUpdate.exe) is also on the USB drive and you want the Scan Station firmware updated.

NOTE: You can obtain update packages from your Service Representative. Update packages will always be a KSSUpdate.exe file.

To configure your USB drive for firmware updates:

1. Select the Configuration tab.
2. Select a configuration file to write to the USB drive.
3. Select **File>Export** to write the configuration file to a USB drive. The Save As screen will be displayed.
4. Save the file on the USB drive with the name **KSS.xml** and click **Save**.
5. Copy KSSUpdate.exe to the USB drive.

## Scan Station Security

Security is an important part of every day business. It is important that network devices do not allow intrusions from outside sources. The Scan Station 700 Series is configured to prevent external attacks from the Internet and from direct access by users. The following security features will block access to the Scan Station's operating system.

- The Scan Station uses a firewall and blocks nearly all incoming network traffic. Most inbound ports are blocked and will not respond to queries from the network.
- The Scan Station is also configured to respond to an echo (also known as a *ping*). This can be useful for diagnosing connectivity issues.
- The Scan Station is protected from external intrusions via the Scan Station USB ports. The operating system is configured to disable any auto-run action that could occur when presenting a new USB device to the system. The Scan Station recognizes the presence of a USB removable device, but will only open and read files that have been created and encrypted specifically for use by the Scan Station. Any file found on a removable device that is not properly encrypted will be ignored. This makes it almost impossible to introduce a virus by inserting a removable device with an infected executable.
- Viruses frequently find their way into a network-connected computer via email. Most viruses are spread as email attachments and infect a computer after the email has been opened and the attachment executed. The Scan Station does not receive any incoming emails, therefore, it cannot be infected in this manner.
- The Scan Station will only read a valid, encrypted configuration file.
- The underlying operating system is not available to the administrator or user. Updates to the operating system and/or the Scan Station firmware will be made available on the Kodak Alaris website (<http://www.kodakalaris.com/go/disupport>) as needed.
- To help secure your Scan Station set the Remote Access Password. For more information, see the section entitled, "Scanner menu" in Chapter 3.
- You can require a user to login before scanning. For more information, see the section entitled, "Configuring your device options" in Chapter 4.

## **Password protecting the Scan Station**


You can require a user to log into the Scan Station before scanning. If you want to assign a local access password, see the section entitled, “Configuring your device options” in Chapter 4. This security feature is intended for use in companies or departments that have sensitive material that they want to prevent being scanned and control distribution. Once the local access password is assigned, access will be blocked to all users who do not know the password. On a Scan Station that is password-protected, users will be given three tries to correctly enter the password. After the third failed attempt, the Scan Station displays a warning message for several minutes and then will return to the local access password entry screen.

The local access password also works in conjunction with the inactivity timer built into the Scan Station. In normal operation, after a Scan Station has been used and has remained idle for 30 seconds, a warning screen will be displayed asking the user if they want to reset all Scan Station settings to the default state. If no selections are made, then after two more minutes of inactivity, the device will be returned to its default state. At this point, the user will need to re-enter the local access password to use the Scan Station.

**NOTE:** As an added measure of security, individual users can be required to log into the Scan Station. See the section entitled, “Active Directory Server settings” in Chapter 4.

## Retrieving and clearing files

Options for retrieving and clearing log files are accessible by selecting **Scanner>Device**.



## Retrieving the Scan Station log file

The Retrieve Logs option allows you to save the log file retrieved from the selected Scan Station. The log file extension is .log. The log file contains information about the Scan Station (e.g., document jams, etc.).

Two methods are available for saving log files:


- Method 1. Using the *Kodak Scan Station 700 Series - Scanner Administration* application.
- Method 2. Using a USB drive.

### Method 1


1. Select the Scan Station.

**NOTE:** To select more than one Scan Station, use the Ctrl or Shift key and click the mouse button. The selected Scan Stations will be highlighted.

2. Select **Scanner>Device>Retrieve Logs**. The log file for the selected Scan Station will be displayed.



3. Click **Save**. The Save As dialog box will be displayed.




4. Enter a file name for the log file and click **Save**.

## Method 2

1. Create a configuration file (kss.xml) on a new USB drive.
2. Insert the USB drive into the Scan Station's USB port to put the Scan Station into local administrative mode. The following message will be displayed.



3. Select **No**. The Scan Station will display the Settings icons.
4. Using the arrows, scroll until the Diagnostics icon  is displayed and selected.
5. Select **Save Logs** and click **Yes** to save the log file to the USB drive.

The analog.log, kss.xml.log and NTBT.log.txt files will be saved to the USB drive.

## Clearing a log file

To clear a log file:

1. Select the Scan Station(s) where you want to clear the logs.
2. Select **Scanner>Device>Clear Logs**. The following message will be displayed, ***Are you sure you want to clear the log files of the selected Scanner?***
3. Click **Yes**.

## Retrieving the Scan Station transaction log file


The Retrieve Transaction Logs option allows you to save the transaction log file retrieved from the selected Scan Station. The transaction log file extension is .xml. The transaction log file contains actual Scan Station transactions (i.e., destinations, time of transaction, recipient, sender, status of the transaction, number of pages scanned).

Two methods are available for saving log files:


- Method 1. Using the *Kodak Scan Station 700 Series - Scanner Administration* application.
- Method 2. Using a USB drive.

### Method 1

1. Select a Scan Station.
2. Select **Scanner>Device>Retrieve Transaction Logs**. The transaction log file for the selected Scan Station will be displayed.




3. Click **Save**. The Save As dialog box will be displayed.




4. Enter a file name and click **Save**.

## Method 2

1. Create a configuration file (kss.xml) on a new USB drive.
2. Insert the USB drive into the Scan Station's USB port to put the Scan Station into local administrative mode. The following message will be displayed.



3. Select **No**. The Scan Station will display the Settings icons.
4. Using the arrows, scroll until the Diagnostics icon  is displayed and selected.
5. Select **Save Transaction Log** and click **Yes** to save the transaction log file to the USB drive. The following message will be displayed, ***The transaction log has been copied to your USB drive. Do you wish to clear the transaction log?***
6. Click **Yes** to clear the log.

The <Time>\_<Date>\_TransactionLog.xml file will be saved to the USB drive.

## Clearing a transaction log file

To clear a transaction log file:

1. Select the Scan Station(s) that you want to clear the transaction logs.  
**NOTE:** To select more than one Scan Station, use the Ctrl or Shift key and click the mouse button. The selected Scan Stations will be highlighted.
2. Select **Scanner>Device>Clear Transaction Logs**. The following message will be displayed, ***Are you sure you want to clear the transaction log files of the selected Scanner?***
3. Click **Yes**.

## Saving all log files

The Save All Logs option allows you to retrieve any available log files found on the selected Scan Station(s). You will be asked for a directory where you want to store the log files. The directory will contain folders of the selected Scan Station names and the retrieved log files will be placed in these folders.



## Scan Station details


To view the details of a selected Scan Station:

- Select **Scanner>Device>Details**. The Details dialog box will be displayed with detailed information about the selected Scan Station (e.g., software version, IP address, etc.).

## Updating the Time/Date remotely

If your network has access to an NTP server, you can configure all of your Scan Stations to synch their internal clock with the NTP server by using the Update Time/Date option.

1. Select **Scanner>Device>Update Time/Date**. The following dialog box will be displayed.



2. Enter the Server Name or IP Address of the NTP server from which you want to synchronize the Scan Station's clock.
3. Select the port of the NTP server. The default is 123.
4. Enter the amount of time (in milliseconds) after which the Scan Station will stop attempting to synchronize its internal clock (500 milliseconds = 1/2 second). Do not change the default, unless you experience problems.
5. Select Version **3** or **4** of the NTP server.
6. Click **Update**.

## Turning off one or more Scan Stations

Occasionally it may be necessary to turn off a Scan Station(s) for a particular reason (e.g., scheduled downtime on the network, a scheduled power outage or because a particular Scan Station may require maintenance). When this becomes necessary, you can turn off any Scan Station remotely.

1. Select the Scan Station(s) you want to power off.
2. Select **Scanner>Power Options>Power Off**. The message, **Are you sure you want to power down the selected Scanner?** will be displayed.
3. Click **Yes** to continue to power down the Scan Station(s).

NOTE: You can also power off or restart the Scan Station by pressing the Power button.


## Restarting one or more Scan Stations

Occasionally it may be necessary to restart a Scan Station(s) for a particular reason (e.g., after loading new firmware). When this becomes necessary, you can restart any Scan Station remotely.

1. Select **Scanner>Power Options>Reboot**. The message, **Are you sure you want to reboot the selected Scanner?** will be displayed.
2. Click **Yes** to continue to restart the Scan Station(s).

NOTE: You can also power off or restart the Scan Station by pressing the Power button.

If there are jobs in the background processing queue when you restart or turn off the Scan Station using the *Kodak Scan Station 700 Series - Scanner Administration* application (**Scanner>Power Options**), a list of options will be displayed.



- Select the desired option and click **OK**.

## **Moving one or more Scan Stations**

If you need to move a Scan Station(s) from one network to another.

1. Power off the Scan Station.
2. Unplug the power cord and network cable.
3. Move the Scan Station(s) to the desired location.
4. Make the power cord and network cable connections.
5. Power on the Scan Station(s).

# 10 Maintenance

---

## Contents

Opening the Scan Station cover .....	10-1
Cleaning procedures.....	10-2
Cleaning the rollers .....	10-2
Cleaning the separation module.....	10-3
Cleaning the feed module .....	10-4
Vacuuming the Scan Station .....	10-5
Cleaning the imaging area .....	10-6
Running a transport cleaning sheet.....	10-6
Replacement procedures .....	10-7
Replacing the separation module and tires .....	10-7
Replacing the pre-separation pad .....	10-9
Replacing the feed module and tires .....	10-10
Adjusting the pre-separation roller tension .....	10-12
Supplies and consumables .....	10-13

## Opening the Scan Station cover

1. Before opening the Scan Station cover, be sure the output tray cover is lowered.



2. Press and hold the Scan Station cover release lever and pull the Scan Station cover open.



3. When you finish cleaning the Scan Station or replacing a part, close the Scan Station cover with both hands.

## Cleaning procedures

Your Scan Station needs to be cleaned periodically. If your documents do not feed easily, if several documents feed at the same time or if streaks appear on your images, it is time to clean your Scan Station. The section entitled, "Supplies and consumables" at the end of this chapter provides a listing of the supplies required to clean your Scan Station.

*IMPORTANT: Use only non-flammable cleaners such as those provided through Kodak Parts Services. Do not use household cleaners.*

*Allow surfaces to cool to ambient temperature before use. Do not use cleaners on hot surfaces.*

*Use adequate ventilation. Do not use cleaners in confined areas.*

*Do not use air, liquid or gas spray cleaners. These cleaners displace dust, dirt and debris to other locations within the Scan Station.*


*Do not use alcohol-based cleaners on the tires or imaging guides.*

### NOTES:

- Before beginning cleaning procedures, turn the Scan Station power off and disconnect the electrical power.
- Wash your hands with soap and water after performing maintenance procedures.

## Cleaning the rollers

1. Open the Scan Station cover.
2. With a roller cleaning pad, wipe the feed rollers from side to side. Rotate the feed rollers to clean the entire surface.




*IMPORTANT: The roller cleaning pad contains sodium lauryl ether sulfate which can cause eye irritation. Wash your hands with soap and water after performing maintenance procedures. Refer to the MSDS (Material Safety Data Sheet) for more information.*

3. Dry the rollers with a lint-free cloth.


## Cleaning the separation module

The separation module should be removed from the Scan Station for best cleaning results.

1. Push the separation module up to snap out and lift it out of position.




2. Manually rotate and wipe the separation module tires with a roller cleaning pad.



3. Inspect the separation module.

If the separation module tires show signs of wear or damage, replace the tires or the separation module. See “Replacement procedures” for more information.


4. Insert the separation module by aligning the tabs with the slots and snapping it into position.




### Cleaning the feed module

NOTE: The paper present sensor is located to the left of the feed module. Be careful not to damage the paper present sensor when removing or cleaning around the feed module.


1. Pull against the raised edge of the feed module cover and lift it up and out of position..



2. Rotate the feed module forward and push it to the left to lift it out of position.




3. Manually rotate and wipe the feed module tires with a roller cleaning pad.



4. Inspect the feed module.

If the feed module tires show signs of wear or damage, replace the tires or the feed module. See the “Replacement procedures” for more information.

5. Using a vacuum or cleaning pad, remove dust and debris from the feed module area.
6. Reinstall the feed module by aligning the pins and pushing it toward the left to fit it into position. Be sure the gears are aligned and it snaps into place. Roll the feed module back into place.



7. Reinstall the feed module cover by aligning the tabs with the slots and pushing it back into position until it snaps into place.

### **Vacuuming the Scan Station**


Before cleaning the imaging area, it is suggested that you vacuum the inside of the Scan Station to remove any dust and debris.



## Cleaning the imaging area

1. Wipe the upper and lower imaging area using a Staticide wipe. Be careful not to scratch the imaging area when cleaning.

*IMPORTANT: Staticide wipes contain isopropanol which can cause eye irritation and dry skin. Wash your hands with soap and water after performing maintenance procedures. Refer to the MSDS for more information.*



2. Wipe the upper and lower imaging area again using the reusable optics cleaner pad to remove any streaks.
3. When finished, close the Scan Station cover with both hands.

## Running a transport cleaning sheet

1. Remove the wrapping from the Transport Cleaning Sheet.
2. Adjust the side guides to fit the cleaning sheet.
3. Place a transport cleaning sheet in the input tray (adhesive side facing you) in portrait orientation.
4. Select any job or select a destination and touch the green Scan button.
5. After the transport cleaning sheet is scanned, turn it over (adhesive side facing the input tray) and scan it again.
6. Open the Scan Station cover and wipe the imaging area with a lint-free cloth.
7. Close the Scan Station cover with both hands.
8. Check your image quality.
9. If necessary, repeat this procedure until all residue is removed from the rollers.

**NOTE:** When a transport cleaning sheet gets very dirty, discard it and use a new one.

## Replacement procedures


*Kodak Scan Stations* use replaceable tires that can feed a wide range of document types, sizes and thicknesses. Tire life and performance will vary based on the customer's document set, the frequency of cleaning the paper path and tires, and following the recommended schedule for changing tires. Nominal tire life is approximately 125,000 pages. Usage figures are not guaranteed. Customer operating environments, document type, the condition of documents being scanned, and not following the recommended cleaning and replacement procedures, can cause the life of the consumables to vary. You should change the tires if you notice an increase in multiple feeds, stoppages, or a decrease in feeder performance that is not resolved by following the cleaning procedures.

### NOTES:


- Before beginning replacement procedures, turn off the Scan Station and disconnect the electrical power.
- For certain paper types (such as carbonless paper or newsprint), failure to clean regularly, and/or use of non-recommended cleaning solvents can shorten roller life.

### Replacing the separation module and tires

1. Push the separation module up to snap out and lift it out of position.




- If you are replacing the separation module, insert the new separation module by aligning the tabs with the slots and snapping it into position.



- If you are replacing the tires, continue with Step 2.

2. Holding onto the separation module, rotate the release lever back so you can access the separation roller.


**CAUTION: Use caution as the release lever is spring-loaded and will snap back if you do not hold it in place.**



3. Remove the separation roller from the separation module housing.
4. Remove each tire by sliding the tire off the core.
5. Install each new tire by gently pulling it over the core.  
*IMPORTANT: Do not overstretch the tire, it may tear.*
6. Reinstall the separation roller in the separation roller housing. Be sure the separation roller snaps into place.
7. Reinstall the separation module by aligning the tabs with the slots and snapping it into position.

## Replacing the pre-separation pad

1. Remove the separation module from the Scan Station by following the steps previously described in “Replacing the separation module and tires”.
2. Hold the separation module in both hands and locate the two tabs which protrude slightly from the back of the separation module.
3. Push down on the tabs until the pre-separation pad protrudes slightly from the front of the separation module.
4. Grasp the pre-separation pad and pull it out of the separation module.




5. Discard the worn pre-separation pad.
6. Align the side tabs of a new pre-separation pad with the slots on the separation module.
7. Push the pre-separation pad firmly in the slots until the pre-separation pad flap rests lightly against the separation module tires.
8. Reinstall the separation module by aligning the tabs with the slots and snapping it into position.


## Replacing the feed module and tires

NOTE: The paper present sensor is located to the left of the feed module. Be careful not to damage the paper present sensor when removing or cleaning around the feed module.

1. Pull against the raised edge of the feed module cover and lift it up and out of position.




2. Rotate the feed module forward and push it to the left to lift it out of position.




- If you are replacing the feed module, insert the new feed module by aligning the pins and pushing it toward the left to fit it into position. Be sure the gears are aligned and it snaps into place, then go to Step 8.
- If you are replacing the tires, continue with Step 3.

3. Remove one core assembly by lifting up and out of position.
4. Remove each tire by sliding the tire off the core.



5. Install each new tire by gently pulling it over the core.  
*IMPORTANT: Do not overstretch the tire; it may tear.*
6. Replace the core assembly in the feed module. You may need to slide the shaft to the right or left so the core fits properly within the feed module housing.
7. Repeat the replacement procedure outlined above for the other core assembly.
8. Reinstall the feed module by aligning the pins and pushing it toward the left to fit it into position.




9. Reinstall the feed module cover by aligning the tabs in the slots and pushing the feed module cover down until it snaps into place.


## Adjusting the pre-separation roller tension

If you are experiencing multi-feeds or document jams, it may be necessary to adjust the pre-separation roller tension.

1. Remove the separation module by following the steps described previously in “Replacing the separation module and tires”.
2. Locate the spring on the separation module.
3. Lift the spring from the holder and move it to the left or right as desired to adjust the tension.



4. When finished, reinsert the separation module by aligning the tabs with the slots and snapping it into position.



## Supplies and consumables

Contact your Scan Station supplier to order supplies.

Description	CAT No.
<i>Kodak</i> Feed Rollers (quantity: 12)	148 4864
<i>Kodak</i> Separation Module	173 6115
<i>Kodak</i> Feed Module	826 9607
<i>Kodak Digital Science</i> Roller Cleaning Pads (quantity: 24)	853 5981
<i>Kodak Digital Science</i> Transport Cleaning Sheets (quantity: 50)	169 0783
Staticide Wipes (quantity: 6 boxes of 24)	896 5519

NOTE: Items and catalog numbers are subject to change.

Material Safety Data Sheets (MSDS) for chemical products are available on the Kodak website at: [www.kodakalaris.com/go/msds](http://www.kodakalaris.com/go/msds). When accessing the MSDSs from the website, you will be required to provide the catalog number of the consumable you want the Material Safety Data Sheet for.




# 11 Troubleshooting

## Contents

Problem solving .....	11-1
Indicator lights .....	11-5
Saving error log files .....	11-6
Contacting Service .....	11-6

## Problem solving

Occasionally you may encounter a situation with your Scan Station where it may not function properly. Use the chart below as a guide to check possible solutions to help you resolve the situation before calling Technical Support.

Problem	Possible Solution
<p>Regular cleaning and Scan Station maintenance is required to keep documents scanning smoothly and provide optimum image quality. Follow the recommended cleaning procedures in <i>Chapter 10, Maintenance</i> for best Scan Station performance.</p>	
<p>Documents are jamming or multiple documents are feeding</p>	<p>Make sure that:</p> <ul style="list-style-type: none"> <li>• the side guides are adjusted for the correct document width.</li> <li>• the input tray does not have more than 75 sheets of 80 g/m<sup>2</sup> (20 lb.) paper in the tray.</li> <li>• the output tray is adjusted for the length of the documents you are scanning.</li> <li>• all documents meet the specifications for size, weight and type as outlined in Appendix A, <i>Specifications</i>.</li> <li>• the Scan Station and rollers are clean.</li> <li>• the rollers are not worn and do not need to be replaced.</li> <li>• the spring on the pre-separation module is adjusted to the proper tension. See the procedures in Chapter 10, <i>Maintenance</i>.</li> <li>• the feed module and pre-separation module is installed properly and securely in place. See the procedures in Chapter 10, <i>Maintenance</i>.</li> </ul> <p><b>To remove a document jam:</b></p> <p><i>IMPORTANT: Be sure the output tray is <b>lowered</b> before opening the cover. Do not pull the jammed document out of the Scan Station; open the Scan Station cover first.</i></p> <ul style="list-style-type: none"> <li>• Press and hold the Scan Station cover release lever and pull the Scan Station cover open.</li> </ul>  <ul style="list-style-type: none"> <li>• Remove any jammed document(s) from inside the Scan Station.</li> <li>• Close the Scan Station cover and resume scanning.</li> </ul>
<p>Scan Station will not scan/feed documents</p>	<p>Make sure that:</p> <ul style="list-style-type: none"> <li>• the power cord is plugged securely into the back of Scan Station and the wall outlet.</li> <li>• the power switch is on; LED is blue.</li> <li>• the wall outlet is not defective (call a licensed electrician).</li> <li>• document(s) is making contact with the feed rollers.</li> </ul>

Problem	Possible Solution
No images are being displayed	Be sure the documents you are scanning are placed properly in the input tray based on how your job is configured. For example, if your job is set up to scan documents <b>one-sided - face down</b> , be sure the side you want to scan is facing the input tray (not facing you). If you are unsure as to how the job is configured, contact your System Administrator.
Roller marks appear on the document after scanning	Clean the rollers. See the procedures in Chapter 10, <i>Maintenance</i> .
Images have black background bleed-through	When scanning translucent documents, black bleed-through may be displayed on the image. To minimize this, adjust the Contrast value on the Scan Settings screen.
Red, green or blue streaks are running through a color photo	The Scan Station is dirty and needs to be cleaned. Refer to the “Cleaning procedures” in Chapter 10, <i>Maintenance</i> .
Image quality is poor or decreased	Clean the Scan Station. Refer to the “Cleaning procedures” in Chapter 10, <i>Maintenance</i> .

Network Authentication Issues	Possible Solution
The Scan Station 700 Series - Scanner Administration application cannot communicate with the Scan Station when the Scan Station is powered up and is left idle for more than 15 minutes then goes to into power saver mode.	<p>Wake On LAN (WOL) is designed to work using a broadcast address, thus it is more likely to work reliably when a Scan Station and the Scanner Administration application are on the same subnet. It can be used across subnets but it will only work if the ARP tables in routers/ switches on the network still contain information about the Scan Station. This information is volatile and the longer a Scan Station is in power saver mode, the less likely it will work. However, if the Scan Station is down for only a short time, quite often things will work fine.</p> <p>These limitations are not limited to Scan Station. This is a network infrastructure restriction.</p> <p>It is suggested that you assign a Static IP address to the Scan Station.</p>
Cannot receive incoming faxes even though the Scan Station is properly configured	<ul style="list-style-type: none"> <li>• Be sure you are connected to an analog phone line (not a digital phone line).</li> <li>• Verify the following: <ol style="list-style-type: none"> <li>1. Make sure the cable is plugged into the RJ11 port in the back of the Scan Station.</li> <li>2. Be sure that the fax options are configured correctly for receiving faxes. For more information, see the section entitled, “Configuring Fax settings” in Chapter 4.</li> </ol> </li> </ul>
Domain authentication	<p>Check the following to verify for correct connections in a network domain.</p> <p>These settings can be accessed by selecting the Configuration tab and selecting <b>Edit&gt;Device Settings</b>. Check <b>Device Options</b> and click <b>Next</b>. Open the <b>Network Destination Credentials</b> option and verify the network <i>Username</i>, <i>Password</i> and <i>Domain</i> name.</p> <p>If these are not set correctly, the Scan Station will not be able to access the domain.</p>
Device name is not unique	<p>All Scan Stations have a default name assigned from the factory. The default name is: <b>KSSxxxxxxx</b> (where xxxxxxxx represents the Scan Stations’ serial number). This ensures that all Scan Station device names are unique. If you leave this option blank when you are configuring the Device Name, the Scan Station will continue to use the default factory-installed device name. If you want to change the default Device name, you must select a <b>unique</b> name.</p>

Network Authentication Issues	Possible Solution
Checking the account name and password	<p>If your Scan Station does not scan to a network location or stops scanning to a network location, you may have issues with the logon credentials supplied to the Scan Station. When creating network accounts that are assigned to the Scan Station, certain properties may be applied to the account such as, <i>Change password upon first log on</i> and <i>Change password every xx days</i>. It is recommended that these types of restrictions are not applied to accounts that will be used for a Scan Station.</p> <p>A network administrator can verify the account settings assigned to a Scan Station by using the credentials to log on to a normal network computer. If you are unable to logon to your network using these credentials, there may be a problem with the account. A network administrator can modify the settings. It may also be necessary to reset the password.</p>
<b>Workgroup authentication</b>	If having trouble writing to a locally shared folder in a workgroup, check the permissions attached to the folder from the PC on the network that is sharing the folder. Make sure the folder's Permissions allow access to the Scan Station.
<b>Email Authentication</b>	Verify that the authentication method defined in the Scan Station settings match the authentication method of your SMTP server. Currently the Scan Station supports simple password, NTLM and Challenge Response. These settings can be verified by using a Windows mail client such as Outlook Express and creating a mail account that uses the username and password assigned to the Scan Station.
<b>SMTP server problems</b>	<p>Follow these procedures to resolve issues with the SMTP server address:</p> <ul style="list-style-type: none"> <li>• Verify that other email clients on different device are able to send mail and reach the SMTP server.</li> <li>• Change your configuration file to identify the SMTP server with an IP address instead of a Fully Qualified Domain Name (FQDN). If you are able to reach the SMTP server with the IP address but not the FQDN, you have a DNS resolution problem. Check to make sure you are able to reach the DNS server and that it correctly resolves FQDNs.</li> <li>• Your SMTP server may require SSL or TLS. See your Network Administrator if you need to select either of these options.</li> </ul>
<b>Finding the SMTP server address</b>	<p>Use the following procedure to find the SMTP server address:</p> <ul style="list-style-type: none"> <li>• Examine the settings of the mail client in use on your workstation to find the IP address or Fully Qualified Domain Name for the SMTP server, or</li> <li>• examine the emails sent from an internal mail client and display the full email header, or</li> <li>• ask the administrator of the mail server for this information.</li> </ul>
<b>Verifying an SMTP server address</b>	<p>In the <i>Kodak Scan Station 700 Series - Scanner Administration</i> application, use <b>Test Connection</b>.</p> <p>Send mail to the SMTP server using a mail client application from a PC attached to the same network as the Scan Station.</p> <ul style="list-style-type: none"> <li>• If the mail was successfully sent and received, the SMTP server address is valid.</li> <li>• If you are unable to send an email to the SMTP server, review any error messages you receive. It is possible the SMTP server address is valid, but the authentication credentials are not valid.</li> </ul>

Network Authentication Issues	Possible Solution
<p><b>FTP authentication</b></p>	<p>Scanning to FTP sites may require the configuration of two sets of credentials: proxy credentials and FTP server credentials.</p> <p>If your network environment requires the use of a proxy server to access external FTP sites, you need to configure appropriate proxy credentials that include username, password and authentication method. Proxy authentication methods include: <b>User after login</b> and <b>None</b>. You may also need to configure a username and password to access the FTP server. The Scan Station also supports anonymous FTP.</p>
<p><b>Your network Domain name</b></p>	<p>To find the domain name your Scan Station will use, follow these steps:</p> <ol style="list-style-type: none"> <li>1. From a PC logged onto the same network/domain that the Scan Station will use, right-click on <b>Computer</b> and select <b>Properties</b>. On the next screen, select <b>Advanced System Settings</b> to display the System Properties window.</li> <li>2. Select the Computer Name tab.</li> </ol> <div data-bbox="673 646 1166 1207" data-label="Image"> <p>The screenshot shows the 'System Properties' dialog box with the 'Computer Name' tab selected. The 'Computer Name' sub-tab is active. The 'Computer description' field is empty. Below it, an example is given: 'For example: "Kitchen Computer" or "Mary's Computer"'. The 'Full computer name' is 'km-di-w' and the 'Workgroup' is 'DI-PRO'. There are two buttons: 'Network ID...' and 'Change...'. At the bottom are 'OK', 'Cancel', and 'Apply' buttons.</p> </div> <p>If you are on a domain, the Domain name is listed in the <i>Domain</i> field (see above).</p> <ol style="list-style-type: none"> <li>3. Copy the <b>Domain name</b> so you can enter it into the <i>Domain</i> field of the Default Credentials. (access <b>Edit&gt;Device Settings</b> from the Configuration tab).</li> <li>4. Select <b>Device Options</b> and click <b>Next</b>.</li> <li>5. Click the <b>Network Destination Credentials</b> down arrow and enter the Domain name.</li> </ol>

Scan to Network Share Issues	Possible Solution
<p><b>Unable to scan to network folder</b></p>	<p>Using another Windows XP, Windows Vista, Windows 7 or Windows 8 machine on your network, ping the NETBIOS computer name of the Share destination. For example, if your destination is <b>\\Servername\Sharename</b>, ping <i>Servername</i>.</p> <ul style="list-style-type: none"> <li>• If you get a reply to your ping, NETBIOS name resolution is working and the problem may be with the share name or permissions to the share.</li> <li>• If you do <b>not</b> get a response, NETBIOS name resolution is not working. If you know you have a valid shared folder, you can use either the IP address or, in some cases, the Fully Qualified Domain Name in place of the server name. For example, if the IP address of the computer that hosts the share is <i>100.100.100.1</i> and the Fully Qualified Domain Name is <i>server.company.com</i> you could try using either: <b>\\100.100.100.1\Sharename</b> or <b>\\server.company.com\sharename</b>. One of these two usually works in place of NETBIOS names in the destination address for the share.</li> <li>• If NETBIOS name resolution is not working and it is your only choice for defining network paths, ask your network administrator about changing your router's configuration. Many organizations block TCP/IP traffic over ports 137 and 139, which are the TCP ports Microsoft uses for NETBIOS over TCP/IP. When these ports are blocked, you cannot resolve a NETBIOS name if the path to the destination address crosses router (e.g., subnet) boundaries.</li> <li>• Using another Windows XP, Windows Vista, Windows 7 or Windows 8 on your network, open Windows Explorer and map a network drive to <b>\\Servername\Sharename</b>. If this does not work, check the Permissions of the shared folder on the host computer. Make sure either <i>Everyone</i> or the user account for the Scan Station has Read and Write permissions to the shared folder.</li> <li>• To verify a network shared folder is accessible on your network, from another PC on your network, click <b>Start&gt;Run</b>. In the <i>Open</i> field, type in the server name (e.g., <i>\\servername</i>) and click <b>OK</b>. If the server is accessible, then all available shared resources will be displayed. Select one of these shared resources to verify it is active. If not, correct the <i>Permissions</i> on the shared folder before trying to access the folder from the Scan Station.</li> </ul>


## Indicator lights

The power button is illuminated blue when the Scan Station is on and ready. Following is a description of LED status:

LED	Status
Steady blue	<ul style="list-style-type: none"> <li>• Briefly displayed when the Scan Station is first turned on.</li> <li>• Scan Station is on and ready to scan.</li> </ul>
Flashing blue	<ul style="list-style-type: none"> <li>• Indicates the Scan Station is initializing from powering on or warming up and preparing to scan.</li> <li>• Low power mode.</li> </ul>
Flashing or steady red	<ul style="list-style-type: none"> <li>• Briefly displayed when the Scan Station is first turned on.</li> <li>• Indicates a Scan Station error, such as the Scan Station cover is open.</li> </ul>

## Saving error log files

You may be asked by Service personnel to send the log files as an email attachment for further diagnostics. Create a configuration file on a new USB drive.

1. Insert the USB drive into the Scan Station's USB port to put the Scan Station into local administrative mode. The Scan Station will display the Settings icons.
2. Using the arrows, scroll until the Diagnostics icon  is displayed and selected.
3. Select **Save Logs** and click **Yes** to save the log file to the USB drive.

The analog.log and kss700.xml.log files will be saved to the USB drive.

You can also use the *Kodak Scan Station 700 Series - Scanner Administration* application to save log files.

1. Launch the *Kodak Scan Station 700 Series - Scanner Administration* application.
2. Click the **Scanners** tab.
3. Select **Scanners>Device** and select the type of file you want to save.

## Contacting Service

1. Visit [www.kodakalaris.com/go/disupport](http://www.kodakalaris.com/go/disupport) to obtain the most current phone number for your country.
2. When calling, please have the following information ready:
  - A description of your problem.
  - The Scan Station serial number.

## 12 Glossary

---

**Authentication credentials** — a username, password and optional network domain name that grants the Scan Station access to network resources.

**Automatic Configuration Schedule** — the ability to schedule firmware and configuration updates for Scan Stations from a remote location on the network.

**Challenge Response (CRAM-MD5)** — an encryption algorithm used for authenticating access to an email server.

**Configuration** — a collection of device settings, scan settings, destinations, groups and job settings. Configurations are stored on your computer's hard drive and typically contain additional information that defines which Scan Stations have been configured with this collection of settings. A configuration is not represented by a single file on the hard drive but it can be exported to a single encrypted .xml file for use in manually configuring Scan Stations.

**Configuration name** — this is the name given to a collection of device settings, scan settings, destinations, groups and job settings.

**Configuration file** — an encrypted .xml file containing all the settings for the device. Basically, a configuration file tells the Scan Station who it is, how to scan and where to send the digital files.

**DFS (Distributed File System)** — allows you to group shared folders located on different servers by transparently connecting them to one or more DFS namespaces. A DFS namespace is a virtual view of shared folders in an organization. Using the DFS tools, you can select which shared folders to present in the namespace, design the hierarchy in which those folders appear, and determine the names that the shared folders show in the namespace. When a user views the namespace, the folders appear to reside on a single, high-capacity hard disk.

**DHCP (Domain Host Control Protocol)** — a network protocol that dynamically assigns network addresses (IP addresses) to computers and other network devices.

**FQDN (Fully Qualified Domain Name)** — a human-readable name linked to the IP address of a computer. It includes both the computer's host name and domain name.

**FTP (File Transfer Protocol)** — a standard Internet protocol which is a simple way to exchange files between computers on the Internet. Like the Hypertext Transfer Protocol (HTTP), which transfers displayable Web pages and related files, and the Simple Mail Transfer Protocol (SMTP), which transfers email, FTP is an application protocol that uses the Internet's TCP/IP protocols. FTP is commonly used to transfer Web page files from their creator to the computer that acts as their server for everyone on the Internet. It is also commonly used to download programs and other files to your computer from other servers.

**IP address** (*Internet Protocol*) — used to reference computers on a network. Addresses presented in a universal format of four, three-digit numeric values separated by a period (e.g., 192.168.1.1). Each address segment can be in the range of 0-255.

**Job Name** — a collection of scan settings, destinations and groups. A job allows Scan Station administrators to simplify complex tasks by grouping scan settings, destinations and groups of users together allowing the user to select a job with the touch of a single button. This is the name of the button that is displayed on the Scan Station touchscreen.

### **Kodak Scan Station 700 Series - Scanner Administration**

**Application** — this is the software that is used to setup, configure and manage Scan Station devices over a network.

**Local Administrative mode** — allows you to perform administrative functions directly on the Scan Station. Local administrative mode is activated by inserting a USB drive with a valid configuration file into one of the Scan Station's USB ports.

**Local Access password** — this is the password that controls user access to the Scan Station. See the section entitled, "Configuring your device options" in Chapter 4 for more information.

**NETBIOS** (*Network Basic Input Output System*) — a network layer that allows applications on different computers to communicate within a local area network. NETBIOS is used in most physical topologies and is a staple of Windows NT networks. A broadcast "protocol" that does not support a routing mechanism, NETBIOS is often carried over other protocols to allow its continued use in larger modern (routed) networks.

**NETBIOS Name** — also known as the *computer name* in Microsoft Windows, the NETBIOS name is a unique name for the device. Only 15 characters can be used.

**NT Domain Server** — a Microsoft Windows based server that defines a network domain. A network domain defines a grouping of computers and computer resources such as; printers, mail servers and file servers.

**NTLM** — an authentication algorithm for accessing an email server.

**Ping** — typically a command line program that allows a user or administrator to see if a specific device is active and responsive on the network. For example, *ping 127.0.0.1* will test to see if a local computer (the one you are using) can respond to a network request.

**Proxy Server** — acts as an intermediary between a workstation user and the Internet so that the enterprise can ensure security, administrative control, and caching service. A proxy server is associated with or part of a gateway server that separates the enterprise network from the outside network and a firewall server that protects the enterprise network from outside intrusion.

**Remote Access password** — this password controls access to the Scan Station from the *Kodak Scan Station 700 Series - Scanner Administration Application*. See the section entitled, "Scanner menu: Remote Access Password" in Chapter 3 for more information.



**Router** — a device that allows multiple computers and devices to connect to a local area network. A router can also be one of many routers that comprise a wide area network (WAN).

**SMTP** (*Simple Mail Transfer Protocol*) — is a protocol used in sending and receiving email.

**TCP/IP** (*Transmission Control Protocol / Internet Protocol*) — a suite of protocols tailored to specific needs for advanced networking. Named after TCP and IP, the first of the many protocols in the suite. TCP/IP forms the basic standard for communication over the Internet.

**TCP Port** — special number in the header of a network data packet, TCP ports are used to map data to computer processes or applications. For example, a server receiving incoming TCP data packets with a number of 21 in the header will normally map that data to the FTP process running on the server (21 is the standard port for initiating an FTP session with a client).

**UNC** (*Universal Naming Convention*) — a standard for identifying servers, printers and other resources in a network, a UNC path uses double slashes or backslashes to precede the name of the computer and a single slash to precede the name of the resource being accessed. In Windows operating systems, the UNC name format is:

`\\servername\sharename\path\filename`

**Workgroup** — a Microsoft network mechanism for grouping multiple computers and computer resources without the use of an actual network domain.

**Router** — a device that allows multiple computers and devices to connect to a local area network. A router can also be one of many routers that comprise a wide area network (WAN).

**SMTP** (*Simple Mail Transfer Protocol*) — is a protocol used in sending and receiving email.

**TCP/IP** (*Transmission Control Protocol / Internet Protocol*) — a suite of protocols tailored to specific needs for advanced networking. Named after TCP and IP, the first of the many protocols in the suite. TCP/IP forms the basic standard for communication over the Internet.

**TCP Port** — special number in the header of a network data packet, TCP ports are used to map data to computer processes or applications. For example, a server receiving incoming TCP data packets with a number of 21 in the header will normally map that data to the FTP process running on the server (21 is the standard port for initiating an FTP session with a client).

**UNC** (*Universal Naming Convention*) — a standard for identifying servers, printers and other resources in a network, a UNC path uses double slashes or backslashes to precede the name of the computer and a single slash to precede the name of the resource being accessed. In Windows operating systems, the UNC name format is:

`\\servername\sharename\path\filename`

**Workgroup** — a Microsoft network mechanism for grouping multiple computers and computer resources without the use of an actual network domain.

# Appendix A Specifications

This appendix provides Scan Station specifications and system requirements.

<b>Connectivity</b>	10/100/1000 Mb/sec Ethernet LAN, RJ-45 For Scan Station 730EX only: Internal 56 K fax modem, RJ-11
<b>Output methods</b>	Scan to network share, scan to print, scan to email, scan to fax, scan to portable USB flash drive, scan to FTP (anonymous, authenticated, with proxy support), SharePoint and Kofax Front Office Server group
<b>Network protocols</b>	TCP/IP, SMB, authenticated SMTP (login, plain text, CRAM, NTLM), DHCP (or static), Network domain authentication
<b>Security features</b>	PDF private key encryption, option to enable/disable the ability to scan to portable USB drives, secure login via LDAP, activity logging by login ID, IP port blocking
<b>Scanner Administration (for System Admin)</b>	Secure login with a customizable password, ability to create and manage lists of Scan Station 500/700 devices, group and classify managed devices, update the configuration and/or embedded software of one, some or all managed devices, view the status of managed devices, remotely access and manage the log files of a single-managed device, restart or power off a single-managed device.
<b>File format output</b>	Single- and multi-page TIFF, JPEG, PDF, searchable PDF, PDF/A, Microsoft Word, Microsoft Excel, RTF, encrypted PDF, optional JPEG compressed, TIFF and WAV audio files
<b>Control panel</b>	24.6 cm (9.7-inch), 1024 x 768 (XGA) TFT LCD with touch screen
<b>Audio</b>	Built in microphone and speaker to record and playback annotation messages
<b>Scanning technology</b>	Duplex scanning with dual Color Quadlinear CCD, 600 dpi optical resolution Capture bit depth is 30 bits (10 x 3) Color output bit depth is 24 bits (8 x 3) Grayscale output bit depth is 256 levels (8-bit)
<b>Output resolutions</b>	75, 100, 150, 200, 300, 400 and 600
<b>Imaging features</b>	Perfect Page scanning, deskew, auto crop, content-based blank page removal, auto orientation, Hole Fill, Edge Fill, Streak Filter, Color Dropout, etc.
<b>Throughput speeds (portrait, letter-size)</b>	Black and white/grayscale/color: up to 50 ppm/100 ipm at 200 dpi
<b>Multifeed Detection</b>	with ultrasonic technology
<b>Illumination</b>	Dual Indirect LED
<b>Feeder</b>	Up to 75 sheets of 80 g/m <sup>2</sup> (20 lb.) paper
<b>Maximum document size</b>	215 x 863 mm (8.5 x 34 in.) - may be restricted at certain resolutions
<b>Minimum document size</b>	50 x 63.5 mm (2 x 2.5 in.) Multiple-sheet feeding: 75 x 125 mm (3 x 5 in.)
<b>Paper thickness and weight</b>	413 g/m <sup>2</sup> (110 lb.) paper and ID cards up to 1.25 mm (0.05 in.) thick
<b>Recommended daily volume</b>	Up to 6000 pages per day
<b>Dimensions</b>	<b>Height:</b> 20.8 cm / 8.2 in. <b>Width:</b> 34.9 cm / 13.8 in. <b>Depth:</b> 38.1 cm / 15 in.

<b>Weight</b>	9.97 kg (22 lbs.)
<b>Recommended portable USB drive specs</b>	USB 2.0, minimum size for configuration: 2 GB minimum size for storing images/files: 2 GB
<b>Power consumption</b>	<b>Off mode:</b> <0.3 W AC <b>Energy Star/Sleep:</b> < 5W AC <b>Idle:</b> 24 W AC <b>Operating:</b> <55W AC
<b>Electrical requirements</b>	100 - 240 V (international), 50/60 Hz
<b>Operating Temperature</b>	10°C to 35°C (50°F to 95°F)
<b>Altitude</b>	<2000 meters (6562 feet)
<b>Humidity</b>	10 to 85% relative humidity
<b>Environmental Factors</b>	Energy Star qualified scanners

## System requirements

The *Kodak* Scan Station 700 Series - Scanner Administration application which is installed on a PC, requires one of the following operating systems:

- Windows XP, Service Pack 3
- Windows Vista, Service Pack 2
- Windows 7
- Windows 8

All require Microsoft .Net 4.0 Framework which will automatically be installed if not detected.

## Appendix B Supported Network Protocols

---

The Scan Station 700 Series connects directly into an Ethernet-based IP network, using a standard RJ45 connection, working independently within the following environments:

- Microsoft Windows Server 2003, 2008 and 2012 (TCP/IP, MS sharing, SMTP, FTP, Printing)
- NetWare 3.x and 4.x with MS services for NetWare (TCP/IP, MS Sharing, SMTP, FTP)
- Unix/Linux environments (SMTP and FTP only)

NOTE: Your network environment may or may not support all of the network protocols mentioned above.

The Scan Station 700 Series supports sending attached images by email using the SMTP and authenticated SMTP protocols. Methods supported for authenticated SMTP include: simple password, NTLM and Challenge Response. If your SMTP server requires authentication before use, you also need to supply credentials to the Scan Station.

NOTE: Kerberos support is not included at this time.

Anonymous FTP (File Transfer Protocol) and authenticated FTP are also supported, including proxy support. To use either form of authenticated FTP (with or without proxy), the FTP configuration will need sufficient credentials to access the FTP site. This information should be available from your network administrator.

While the Scan Station 700 Series can be used in heterogeneous networks with SMTP and FTP, printing to network printers and scanning to network shared folders requires Microsoft printer drivers and SMB (Server Message Block) drive access respectively.

When used within a Microsoft NT Domain, the Scan Station accesses domain resources (shared drives and printers) with a standard domain user account.

When used within a Microsoft workgroup, the Scan Station can access workgroup resources (shared drives and printers) without any login credentials providing workgroup PCs have been configured to allow guest access to their shared resources.

# Appendix C Warranty - US and Canada only

---

Congratulations on the purchase of a *Kodak Scanner*. *Kodak Scanners* are designed to provide end users with the highest performance and reliability. All *Kodak Scanners* are covered by the following Limited Warranty.

## **Limited Warranty for *Kodak Scanners***

Kodak Alaris Inc. provides the following Limited Warranty on *Kodak Scanners* (excluding spare parts and consumables) distributed by Kodak Alaris or through Kodak Alaris' authorized distribution channels:

Kodak Alaris Inc. warrants that a *Kodak Scanner*, from the time of sale through the Limited Warranty period applicable to the Product, will be free of defects in materials or workmanship and will conform to the performance specifications applicable for the particular *Kodak Scanner*.

All *Kodak Scanners* are subject to the Warranty Exclusions described below. A *Kodak Scanner* found to be defective or which does not conform to the product specifications will be repaired or replaced with new or refurbished product at Kodak Alaris' option.

Purchasers may determine the applicable Limited Warranty period for the *Kodak Scanners* purchased by visiting [www.kodakalaris.com/go/disupport](http://www.kodakalaris.com/go/disupport) or by reviewing the Limited Warranty Summary Card enclosed with the *Kodak Scanner*.

Proof of purchase is required to demonstrate eligibility for warranty service.

## **Warranty exclusions**

Kodak Alaris' Limited Warranty does not apply to a *Kodak Scanner* that has been subjected to physical damage after purchase, caused, for example, by casualty, accident, acts of God or transportation, including (a) by a failure to properly package and ship the Scanner back to Kodak Alaris for warranty service in accordance with Kodak Alaris' then current Packaging and Shipping Guidelines, including failure to replace the shipping restraint prior to shipping, or by a failure to remove the shipping restraint prior to use; (b) resulting from the user's installation, system integration, programming, re-installation of user operating systems or applications software, systems engineering, relocation, reconstruction of data, or removal of the product or any component (including breakage of a connector, cover, glass, pins, trays or seal); (c) from service, modification or repair not performed by Kodak Alaris or a service provider authorized by Kodak Alaris or by tampering, use of counterfeit or other non-Kodak Alaris components, assemblies, accessories, or modules; (d) by misuse, unreasonable handling or maintenance, mistreatment, operator error, failure to provide proper supervision or maintenance, including use of cleaning products or other accessories not approved by Kodak Alaris or use in contravention of recommended procedures or specifications; (e) by environmental conditions (such as excessive heat or other unsuitable physical operating environment), corrosion, staining, electrical work external to the product or failure to provide electro-static discharge (ESD) protection; (f) by failure to install firmware updates or releases available for the product and (g) by such other supplemental exclusions published from time to time online at [www.kodakalaris.com/go/disupport](http://www.kodakalaris.com/go/disupport).

Kodak Alaris provides no Limited Warranty for products purchased from countries other than the United State and Canada. Purchasers of products from foreign distribution channels must seek warranty coverage, if any, through the original source of purchase.

Kodak Alaris provides no Limited Warranty for products that are purchased as part of a third party manufacturer's product, computer system or other electronic device.

Any warranty for these products is provided by the OEM (Original Equipment Manufacturer) as part of that manufacturer's product or system.

The replacement product assumes the remainder of the Limited Warranty period applicable to the defective product or thirty (30) days, whichever is longer.

## **Installation Warning and Disclaimer**

KODAK ALARIS WILL NOT BE RESPONSIBLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES RESULTING FROM THE SALE, INSTALLATION, USE, SERVICING OR IMPROPER FUNCTIONING OF THIS PRODUCT, REGARDLESS OF THE CAUSE. SUCH DAMAGES FOR WHICH KODAK ALARIS WILL NOT BE RESPONSIBLE, INCLUDE, BUT ARE NOT LIMITED TO, LOSS OF REVENUE OR PROFIT, LOSS OF DATA, DOWNTIME COSTS, LOSS OF USE OF THE PRODUCT, COST OF ANY SUBSTITUTE PRODUCT, FACILITIES OR SERVICES OR CLAIMS OF CUSTOMERS FOR SUCH DAMAGES.

If there is any conflict between other sections of this appendix and the Limited Warranty, the terms of the Limited Warranty prevail.

### **How to obtain Limited Warranty service**

*Kodak* Scanners are supplied with information on unpacking, setup, installation and operation. Careful reading of the User's Guide will answer most of the technical questions the end user might have regarding proper installation, operation and maintenance of the product. However, should additional technical support be required, you may visit our website at: [www.kodakalaris.com/go/disupport](http://www.kodakalaris.com/go/disupport) or contact: Kodak Alaris' Response Center: **(800) 822-1414**

The Response Center is available Monday – Friday (excluding Kodak Alaris holidays) 8 a.m. to 5 p.m. EST.

Before placing the call, the eligible purchaser should have the *Kodak* Scanner model number, part number, serial number and proof of purchase available. The eligible purchaser should also be prepared to provide a description of the problem.

Response Center personnel will assist the end user in resolving the problem over the phone. The end user may be asked to run some simple, self-diagnostic tests and report the resulting status and error code messages. This will assist the Response Center in determining if the problem is the *Kodak* Scanner or another component and if the problem can be resolved over the phone. If the Response Center determines a hardware problem exists that is covered either under the Limited Warranty or a purchased Maintenance Agreement, a Return Material Authorization Number (RMA) will be assigned as needed, a service request will be initiated and repair or replacement procedures will follow.

### **Packaging and shipping guidelines**

Purchaser must ship all warranty returns in a method that guarantees full protection of the product from shipping damage. Failure to do so will void the *Kodak* Scanner warranty. Kodak Alaris advises the purchaser to keep the original box and packing materials for storing or shipping. Kodak Alaris is not responsible for issues related to shipping damage. The purchaser must return only the *Kodak* Scanner. Prior to shipment, purchaser must remove and retain all "add-on" items, (i.e. adapters, cables, software, manuals, etc.). Kodak Alaris accepts no responsibility for these items and they will not be returned with the repaired or replacement *Kodak* Scanner. All products should be returned to Kodak Alaris in the original shipping container, or an authorized packaging box for the units being returned. Purchaser must install the shipping restraint before the *Kodak* Scanner is shipped. When the original packaging is not available, contact Kodak Alaris' Response Center at (800) 822-1414 for part numbers and replacement packaging ordering information.

### **Return procedure**

Eligible purchasers seeking services for *Kodak* Scanners covered under this Limited Warranty must obtain a Return Material Authorization number ("RMA") by calling (800) 822-1414 and within ten (10) business days from the date of issuance of the RMA must return the *Kodak* Scanner to the address designated in the RMA at the end user's own expense and risk, in compliance with Kodak Alaris' current Packaging and Shipping Guidelines.

Any defective products or parts replaced by Kodak Alaris become the property of Kodak Alaris.

### **Customer responsibility**

BY REQUESTING SERVICE, THE ELIGIBLE PURCHASER ACKNOWLEDGES THE TERMS OF THE LIMITED WARRANTY, INCLUDING THE DISCLAIMER AND LIMITATION OF LIABILITY PROVISIONS. PRIOR TO SEEKING SERVICE, THE END USER MUST BACK-UP ANY DATA OR FILES THAT MAY BECOME DAMAGED OR LOST. KODAK ALARIS IS, WITHOUT LIMITATION, NOT RESPONSIBLE FOR LOST OR DAMAGED DATA OR FILES.

### **Warranty Service descriptions**

Kodak Alaris offers a range of service programs to support its Limited Warranty and to assist with the use and care of the *Kodak* Scanner ("Service Methods"). A *Kodak* Scanner represents an important investment. *Kodak* Scanners provide the productivity needed to stay competitive. The sudden loss of this productivity, even temporarily, could seriously affect the ability to meet commitments. Downtime can be very expensive, not just in the cost of the repair but also in time lost. To help alleviate these problems, Kodak Alaris may use one of the service methods listed below, depending upon product type, in providing service under its Limited Warranty.

Included with selected *Kodak* Scanners is a Limited Warranty Registration card and a Limited Warranty Summary card. The Limited Warranty Summary card is specific by model. The Limited Warranty Summary card contains important warranty information, including the model number and the Limited Warranty. Refer to the Limited Warranty Summary card to determine the available Service Methods applicable to the particular *Kodak* Scanner.

If the Limited Warranty Registration card or Limited Warranty Summary card cannot be located, additional information may be obtained about the product, including updated warranty and service program information and restrictions, online at [www.kodakalaris.com/go/disupport](http://www.kodakalaris.com/go/disupport).

To avoid service delays, Kodak Alaris urges end users to complete and return the enclosed Limited Warranty Registration Card at the first opportunity. If you cannot locate the Limited Warranty Registration card, you may register online at [www.kodakalaris.com/go/disupport](http://www.kodakalaris.com/go/disupport).

Kodak Alaris also provides a variety of service programs that may be purchased to assist with the use and care of the *Kodak* Scanner.

Kodak Alaris is committed to providing its customers with quality, performance, reliability and service under the Limited Warranty.

We expect to have a supply of spare parts and consumables for at least 5 years after product manufacture has been discontinued.

### **On-site service**

For the selected *Kodak* Scanner, and after the Response Center verifies a hardware problem, a service call will be opened and logged. A Kodak Alaris Field Engineer will be dispatched to the product location to perform repair service if the product is located within the contiguous forty-eight (48) United States, in certain areas of Alaska and Hawaii, and if there are no security, safety or physical requirements that would restrict the Field Engineer's access to the scanner. For additional information on service areas, visit our website at: [www.kodakalaris.com/go/docimaging](http://www.kodakalaris.com/go/docimaging). On-Site Service will be provided between the hours of 8 a.m. and 5 p.m. local time, Monday through Friday (excluding Kodak Alaris holidays).

### **Advanced Unit Replacement (AUR)**

AUR may be one of the easiest and most comprehensive service offerings in the industry. In the unlikely event of a product defect, for eligible purchasers of certain *Kodak* Scanners, Kodak Alaris will replace that product within two business days.

The AUR provides advance replacement on specific failed or broken *Kodak* Scanner. To be eligible to take advantage of the AUR, the eligible purchaser must obtain an RMA number, sign an Advance Replacement Agreement and provide a credit card deposit to secure the replacement product. The RMA number should be kept in the event that the status of the replacement product needs to be checked. The eligible purchaser will be asked for the address where the replacement product is to be shipped. The eligible purchaser will also be faxed packing and shipping instructions for the malfunctioning product. The eligible purchaser will then receive a replacement product within 2 business days after the service call initiation and Kodak Alaris' receipt of the signed agreement. The malfunctioning product must be received by Kodak Alaris within ten (10) days of the end user's receipt of the replacement product or the end user's credit card will be charged the list price of the replacement product. Shipment of replacement Imaging Product will be made at Kodak Alaris' expense and choice of freight carrier. Shipments not made under Kodak Alaris' directions and choice of freight carrier may void the Limited Warranty.

Before the product is returned to Kodak Alaris, be sure to remove all options and accessories (which include power cord, documentation, etc.) that are not covered by the Limited Warranty. The box and packaging in which the replacement product was shipped must be used to return the malfunctioning product. If the malfunctioning product is not returned in the box and packaging in which the replacement product was shipped the Limited Warranty may be voided. The Return Material Authorization Number ("RMA") must be clearly marked on the outside of the box to ensure proper receipt and credit of the defective product.

### **Depot service**

If the *Kodak* Scanner is not eligible for AUR or On-Site Service, an eligible purchaser may utilize our Depot Repair Service. The eligible purchaser will be instructed to ship the product to the nearest authorized Depot Repair Center. Product must be shipped at the eligible purchaser's risk and expense to the repair center. Before the product is returned to the repair center, be sure to remove all options and accessories (which include power cord, documentation, etc.) not covered by the Limited Warranty. All products should be returned to Kodak Alaris in the original shipping container, or in a recommended packing box. The *Kodak* Scanner must have the shipping restraint installed before it is shipped. When the original packaging is not available, contact Kodak Alaris' Response Center at (800) 822-1414, for ordering information. Eligible purchasers seeking services for *Kodak* Scanners must obtain a Return Material Authorization number ("RMA") by calling (800) 822-1414, and within ten (10) business days from the date of issuance of the RMA must return the *Kodak* Scanner to the address designated in the RMA at the end user's own expense and risk. The Return Material Authorization Number ("RMA") must be clearly marked on the outside of the box to ensure proper receipt and credit of the defective product.

Upon receipt of the product, the repair center will repair product within ten (10) business days. The repaired product will be shipped back two-day express mail at no expense to the eligible purchaser.

### **Important restrictions**

**Eligibility:** The Advance Exchange Program and the Depot Service are available to eligible purchasers in the fifty (50) United States, and On-Site Service is available in the contiguous forty-eight (48) states and in certain areas of Alaska and Hawaii for products purchased from authorized distributors of Kodak Alaris. The *Kodak* Scanner will be ineligible for any service under warranty if the product falls under any of Kodak Alaris' then-current Warranty Exclusions, including a purchaser's failure to return defective products to Kodak Alaris in compliance with Kodak Alaris' then current Packaging and Shipping Guidelines. Persons are only considered "eligible purchasers" or "end users" if they originally purchased the *Kodak* Scanner for their own personal or business use, and not for resale.

**Consumables:** Consumables are items that wear out under normal use and must be replaced by the end user as needed. Consumables, supplies, other expendable items and those items identified as being the user's responsibility in the User's Guide are not covered under the Limited Warranty.

Any defective products or parts replaced by Kodak Alaris become the property of Kodak Alaris.



**Contacting Kodak Alaris**

For Information on *Kodak* Scanners:

Website: [www.kodakalaris.com/go/docimaging](http://www.kodakalaris.com/go/docimaging)

For U.S. Service, Repair and Technical Assistance by Telephone:

Telephone technical support is available Monday-Friday between the hours of 5 a.m. to 5 p.m. excluding Kodak Alaris holidays.

Phone: (800) 822-1414

For Technical Documentation and FAQ's available 24 hours a day:

Website: [www.kodakalaris.com/go/docimaging](http://www.kodakalaris.com/go/docimaging)

For Service Program Information

Website: [www.kodakalaris.com](http://www.kodakalaris.com)

Phone: (800) 822-1414

