



Sony Ericsson

txt pro<sup>TM</sup>

Isiqondisi Incwadi yeziqondiso yomsebenzisi

Sony Ericsson  
make.believe

# Okuquketwhe

<b>Yizwa okunye. Thola ukuthi kanjani.....</b>	<b>5</b>
<b>Ukuqalisa.....</b>	<b>6</b>
Uqalisa ifoni yakho okokuqala.....	6
<b>Ukuqala ngokwazi ucingo lwakho.....</b>	<b>7</b>
Uhlolojikelele lwefoni.....	7
Ukushaja ibhethri.....	7
Ukusebenzisa ikhi yasekhaya.....	8
Iskrini sasekhaya.....	8
Iskrini sohlelo .....	9
Ukusebenzisa iskrini esithinthwayo.....	10
Amasethingi e-inthanethi nawokuthumela imilayezo.....	10
Ihlolojikelele lwamasethingi efonini.....	10
<b>Uhlelo lwabangane .....</b>	<b>12</b>
Ihlaza lesigameko.....	12
<b>Imiyalezo esheshayo.....</b>	<b>14</b>
<b>Ufaka umbhalo.....</b>	<b>15</b>
Ukusebenzisa ikhibhodi yokuslayidela ngaphandle.....	15
Ukusebenzisa ikhiphedi eseskrinini.....	15
<b>Oxhu. nabo .....</b>	<b>17</b>
<b>Ukushaya ucingo.....</b>	<b>18</b>
<b>Umculo.....</b>	<b>19</b>
Isidlali somculo.....	19
<b>Uku-xhuma ifoni yakho kukhompuyutha.....</b>	<b>20</b>
Ukudlulisa nokuphatha okuquketwhe usebenzisa intambo ye-USB. . .	20
<b>Ikhamera.....</b>	<b>21</b>
Izilawuli zesitholi sokubonwayo ne-khamera.....	21
<b>Ubuchwepheshe be-TrackID™.....</b>	<b>22</b>
<b>PlayNow™.....</b>	<b>23</b>
<b>I-multimedia nokuthumela imiyalezo.....</b>	<b>24</b>
<b>I-imeyli.....</b>	<b>25</b>
<b>Ubuchwepheshe obungenawaya be-Bluetooth™.....</b>	<b>26</b>
<b>i-Wi-Fi®.....</b>	<b>27</b>
<b>Isipheqi se-web.....</b>	<b>28</b>
Ukupheqa iwebhu.....	28
<b>Uphawu olwengeziwe.....</b>	<b>29</b>
Ama-alamu.....	29

Imeyli yezwi.....	29
<b>Ukukhiya nokuvikela ifoni yakho.....</b>	<b>30</b>
Inamba ye-IMEI.....	30
<b>Ukucubungula inkinga.....</b>	<b>31</b>
Ucingo lwami alusebenzi njengokulindelekile.....	31
Ukusetha kabusha ifoni yakho.....	31
Asikho uphawu sokushaja ibhethri esivelayo lapho ngiqala ukushaja ucingo.....	31
Angikwazi ukusebenzi amasevisi asekeleke ku-Inthanethi.....	31
Ayikho inethiwekhi.....	31
Izingcingo oluphuthumayo kuphela.....	31
Ilokhi ye-SIM icushiwe .....	32
IPuk ivaliwe. Xhumana no- opharetha. ....	32
<b>Ulwazi lwezomthetho.....</b>	<b>33</b>
<b>Inkomba.....</b>	<b>34</b>

# Ulwazi olubalulekile

**Uyacelwa ukuba ufunde ikhasi lolwazi *Olubalulekile ngaphambi* kokusebenzisa ifoni ephathekayo.**

- ! Amanye amasevisi nezimpawu ezichazwe lapha kuli mhlahlandlela Womsebenzisi akusekelwe kuwo wonke amazwe/izifunda noma yiwo wonke amanethiwekhi kanye/noma abahlinzeki bemisebenzi kuyo yonke indawo. Ngaphandle komkhawulo, lokhu kuqondiswe kuInamba Ephuthumayo Yomhlaba ye-GSM u-112. Uyacelwa ukuba uxhumane u-opharetha wenethiwekhi noma umhlinzeki wesevisi ukuze uthole ukuthi noma yiyiphi isevisi noma uphawu oluthile kuyatholakala yini kanye nokuthi ukutholakala okwengeziwe kuyatholakala yini noma kuyakhokhelwa yini ngokukusebenzisa.

# Yizwa okunye. Thola ukuthi kanjani.

Vakashela i[www.sonyericsson.com/support](http://www.sonyericsson.com/support) ukufunda okuningi ngefoni yakho.

# Ukuqalisa

Okunye kwemiyalo yokuqalisa kuphrintwe kubhokisi locingo lwakho. Phansi kwalokhu uzathola ukwaziswa okukusiza ukuqalisa.

## Ukufaka noma ukukhipha imemori khadi

- ! Kungenzeka kufanele uthenge imemori khadi iyodwa.



- 1 Faka imemori khadi umbala ogolide ubheke phansi.
- 2 Ukukhipha imemori khadi, cindezela I-EDGE yememory khadi ngaphakathi bese uyikhulula ngokushesha.

## Ukukhiya iskrini

- Uma iskrini sisebenza, cindezela kancane ikhi le /m-0.

## Ukuvula iskrini

- Uma iskrini sivaliwe, cindezela kafushani ikhi ye /m-0.

## Uqalisa ifoni yakho okokuqala

Uma uvula ucingo lwakho okwakuqala, isiqondiso sukusethapha ikusiza ukufaka amasethingi ocingo avamile njalo uthathe oxhumana nabo. Ungakwazi ukungena kwi-siqondiso sokusethapha kamuva kumasethingi efonu.

## Ukusetha ulimi lwefoni

- 1 Uma uqalisa ifoni yakho, uhlu lwezilimi luyavela. Pheqa uhlwini bese ukhetha ulimi lwakho.
- 2 Thinta **Enza**.

## Ukungenisa oxhumana nabo ku-SIM khadi

- Uma uqala ifoni yakho okokuqala ufake i-SIM khadi, isiqondiso sesethaphu ikutshela ukuba ungenise oxhumana nabo abaku-SIM. Thinta **Buyisa okuxhunye**.
- 💡 Uma ukopisha oxhumana nabo phakathi kwamafoni amabili usebenzisa i-SIM card yakho, izinga nohlobo lokwaziswa ongaludlulisa ngomxhumani ngamunye kukhawuliwe.


## Ukusetha isikhathi nosuku

- 1 Uma uqalisa ifoni yakho, isethaphu wizadi ikucela ukuthi usethe isikhathi nosuku. Thinta **Isikhathi Nosuku**.
  - 2 Thola bese uthinta **Isikhathi**.
  - 3 Thinta isikhala samahora nemizuzu ukulungisa isikhathi.
  - 4 Thinta **Gcina**.
  - 5 Thola bese uthinta **Usuku**.
  - 6 Thinta izikhala zosuku, inyanga nonyaka ukulungisa usuku.
  - 7 Thinta **Gcina**.
- 💡 Uma usetha isikhathi nosuku, ungakhetha futhi isimo se-display yesikhathi nosuku oyithandayo. Thinta **Ukuhleleka kwes**. noma **Ukuhleleka usuku** ukukhetha isimo osithandayo.

# Ukuqala ngokwazi ucingo lwakho

## Uhlolojikelele lwefoni


- 1 Isixhuma msindo esiwu 3.5mm
- 2 Inkomba ebonisa ukugcwala kwebhulethi
- 3 Isipikha sendlebe
- 4 Isikala bude buduze
- 5 Thinta iskrini
- 6 Hlehlisa ikhibhodi
- 7 Ukhiye wasekhaya




- 8 Imakhrofoni
- 9 Ukuxhuma kwe shaja/ikhebula leUSB
- 10 Ibhathini lamandla/khiya isikilini
- 11 Ilensi yekhamera
- 12 Ukhiye we volumu
- 13 Ispikha
- 14 Ukhiye we khamera



## Ukushaja ibhethri

Ibhethri lefoni yakho lishajwe ngokwengxenywe uma uthenga ifoni. kungathatha imizuzu embalwa ngaphambi kokuthi uphawu lwebhethri  luvele e-krinini uma uxhuma ikhebula yeshaja yefoni emthombeni wamandla, njengembobo yokuxhuma yeUSB noma ishaja yefoni. Usengayi-sebenzisa ifoni yakho ngenkathi ishaja.

- ! Ibhethri lizoqala ukuyekela ukushaja uma selishaje ngokugcwele bese liyashaja futhi ngemva kwesikhashana. Lokhu okokwelula impilo yebhethri okungenza izinga lokushaja libonakale lingaphansi kwe 100 phesenti.



### Ukushaja ifoni usebenzisa i-adaptha yamandla

- Xhuma ifoni eziko likagesi usebenzisa intambo ye-USB ne-adaptha yamandla.

### Ukusebenzisa ikhi yasekhaya



### Yiya eskrinini sasekhaya


- cindezela ikhi lasekhaya.

### Iskrini sasekhaya

I **Iskrini sasekhaya**-gateway yakho ophawini olokhulu efonini yakho. Ungahlela ngezimpawu ezihlukile zohlelo, izingamuleli, iphepha lodonga nokuningi. I **Iskrini sasekhaya**-yelulela ngale kobubanzi be-display yeskrini esijwayelekile, kukunikeze indlu eyengeziwe yokudlala.


- ! Vala amahlelo akho avuliwe ngaphambi kokuba uye ku **Iskrini sasekhaya**. Kungenjalo lamahlelo angasebenza kwibackground anze isivinini sefoni yakho sinciphe.






## Iskrini sohlelo

Iskrini sohlelo sikunika igunya lokuthola inhlelo ecingweni lwakho ngokusheshile. Ungalungisisa lesi skrini. Khumbula ukuba iskrini sohlelo sedlula ububanzi beskrini yensukwini, ngalokho kungadingakala ukuthi uphequle kwesokunxele kumbe kwesokudla ukuze ubone konke.



- 💡 Ikhombisa eliphezu kweskrini liveza iskrini sohlelo. Ngo mzekeliso,  ikhombisa ukuthi uphakathi kwengxenywe yeskrini.

### Ukuvula iskrini sohlelo


Kunezindlela ezimbili zokuvula iskrini senhlelo:

- Ku **Iskrini sasekhaya**, donsela  phezulu.
- Pheqululela phezulu kunoma iyiphi indawo ku **Iskrini sasekhaya**.



### Ukupheqa uhlelo lweskrini

- Kusuka kuhlelo lweskrini, phequla kwesokudla kumbe kwesonxele.

### Ukugudlula uhlelo kusiya kukhona lweskrini sohlelo

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thinta futhi ubambe into kuze kube yilapho izimpawu zohlelo zivele kumakhona esikrini.
- 3 Donsa into kwelinye lamakhona.

## Ukugudlula uhlelo kuskrini senhlelo

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
  - 2 Thinta futhi ubambe into kuze kube yilapho izimpawu zohlelo zivele kumakhona esikrini.
  - 3 Donsa into ukwedlula iskrini okuso ukubheka ingxenye yesinye iskrini sohlelo.
-  Izinto ezikuskrini sohlelo lokunye okwengeziwe zinhlelo zangempela, njalo hhayimashothikhathi. Ngakho ke uma ugudlula into kusukela kuskrini sohlelo esisodwa kuya kwenye indawo, ugudlula uhlelo langempela, futhi awenzi ishothikhathi.


## Ukusebenzisa iskrini esithintwayo

### Ukuvula noma ukugqamisa into ethile

- Qhwabaza leyo into.

### Ukuphawula noma ukungaphawuli kokukhethwa kukho

- Thinta ibhokisi lokuhlola elifanele, noma kwezinye izimo thinta iswishi eceleni kwegama lokukhethwa kukho.



### Ukubuyela emuva eskinini

- Thinta , uma okukhethwa kukho -kutholakala.

## Pheqa

Pheqa ngokugudlala umunwe wakho phezulu noma phansi eskrinini. Kwamanye amakhasi e-web ungapheqa nasemaceleni.

- ! Ukudonsa noma ukuphequlula ngeke kuqalise utho eskrinini sakho.

## Amasethingi e-inthanethi nawokuthumela imilayezo


Emafonini amaningi aphahekayo inethiwekhi no opharetha, ukuthumela imilayezo namasethingi e-inthanethi kuzasekufakiwe efonini yakho. Kwesinye isikhathi amasethingi alandwa uma uqala ngqa ukuvula ifoni yakho ufake i-SIM khadi.

Unga yengeza ngezandla njalo ushintshe isethingi ye inthanethi njalo eyokuthumela imilayezo kucingo lwakho ngasiphi sikhathi, noma uthole isethingi ethunyelwe kucingo lwakho. Ukuthola usizo oluningi ngokubuyekeza isethingi ye inthanethi nokuthumela imilayezo kucingo lwakho, yiya ku[www.sonyericsson.com/support](http://www.sonyericsson.com/support). Xhumana no-opharetha wenethiwekhi yakho uma udinga ukwaziswa okwengeziwe ngamasethingi okubhalisela ubulungu.


## Ihlojikelele lwamasethingi e-efoni

Ungahlela amasethingi ukuze avumelane nawe. Ngokwesibonelo, Ungalungisa amasethingi e **Isikhathi nosuk**. nawe **Ulimi lwefoni**.

### Ukushintsha ulwimi lwefoni

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
  - 2 Thola bese uthinta **Amaseting** > **Ulimi nokubhala** > **Ulimi lwefoni**.
  - 3 Khetha ongakhetha kukho.
- ! Uma ukhetha ulwimi olungeyilo bese ungakwazi ukufunda umbhalo we-menu yiya ku[www.sonyericsson.com/support](http://www.sonyericsson.com/support) ukuthola usizo.

### Ukuvula i-modi ye-flight

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thola bese uthinta **Amaseting** > **Okujwayelekile**.
- 3 Khetha **I-Flight mode**.

# Uhlelo lwabangane


Uhlelo lwabangane luqoqa ukukhulumisana kwakho labangane abahlanu kubheka elilodwa. Ukukhulumisana konke – imibiko, imbhalo nemiyalezo, ucingo olungaphendulwanga ivela kuskrini sekhaya. Mane uthinta thinta isithombe somngane kuskrini sekhaya ukubheka konke ukukhulumisana kwakho naye.


## Ihluza lesigameko

Sebenzisa ithebhu  ukufona:

- Bheka inamba zefoni zabangane bakho
- Bheka ucingo olungaphendulwanga olusuka kubangane bakho
- Fona




Sebenzisa ithebhu lokuthumela imiyalezo  uku:

- Bheka njalo uphendule imiyalezo esuka kubangane bakho  
Ithebhu lephrofayli  likunika okukhethwa kukho okulandelayo:
- Imininingwane yoxhumana naye – Bheka imininingwane yoxhumana naye, njalo uhlele nom uthumele oxhumana naye ukwaziswa
- I akhawunti yeFacebook™ – Faka imininingwane yabangane ye akhawunti eyeFacebook™, noma uwathole kuhla labo xhumana nabo kuFacebook™
- I akhawunti yeTwitter™ - Faka imininingwane yabangane ye akhawunti eyeTwitter™, noma ubathole kuhla labo xhumana nabo kuTwitter™
- Susa umngane - Susa umngane kusuka kuhlelo lwabangane
- ! Uma ungasusa omunye kwabangane abahlanu abayintandokazi yakho ku **Oxhu. nabo**, ukwaziswa konke okulandisa lumngane luya suswa kuhlelo lwabangane.


Ithebhu yeFacebook™  ikunika okukhethwa kukho okulandelayo:

- Bheka isimo, imbiko nesithombe kuFacebook™ yomngane wakho
- Ukuphathwa kwe akhawunti: faka imininingwane yabamngane ye akhawunti eyeFacebook™, noma uwathole kuhla labo xhumana nabo kuFacebook™
- Vuselela izigameko zeFacebook™  
Ithebhu yeTwitter™  ikunika okukhethwa kukho okulandelayo:
- Thola isimo, imbiko nesithombe kuTwitter™ yomngane wakho
- Ukuphathwa kwe akhawunti: faka imininingwane yabamngane ye akhawunti eyeTwitter™, noma uwathole kuhla labo xhumana nabo kuTwitter™
- Vuselela izigameko zeTwitter™
- ! Inamba zezigameko ezintsha zoqoqo lunye ngalunye zivela phezu kwekhona kwesokudla kuthebhu yoqoqo.


## Ukuyengeza umngane kuhlelo lwabangane

- 1 Kusuka ku **Iskrini sasekhaya**, phequlula kwesonxele.
- 2 Thinta thinta ku **Thinta thinta lapha kuqala** thayela eliphakathi kweskrini ukuqala uhlelo lwabangane.
- 3 Thinta thinta inkinobho yaphakathi .
- 4 Oxhumana nabo bonke abasecingweni lwakho babukiswa. Thinta thinta oxhumana naye ukumuyengeza njengomunye wabangane abahlanu oseduze labo. Unga yengeza umngane omunye ngesikhathi sinye.
- 5 Ukuyengeza omunye umngane, thinta thinta enye inkinombo  ukuthi ivele phakathi. Thinta thinta inkinombo ephakathi , ubesu phinda isahluko sesine.
- ! Uhlelo lwabangane lusebenzisa isithombe esihambelana noxhumana nabo. Kodwa kudingeka ukuthi ubeneqiniso maqala ukuthi ugcine labo oxhumana nabo kumemori yefoni yakho.


### Ukulungisa buyekeza leningi

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thola bese uthinta **Amaseting > Amaseting > Uhlelo lomngane > Buyekeza ifrikhwensi**.
- 3 Khetha ongakhetha kukho.


### Ukulungisa uxhumano olwenyule nomngane


- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thola bese uthinta **Amaseting > Amaseting > Uhlelo lomngane > Uxhumano olwenyule**.
- 3 Khetha ongakhetha kukho.

### Ukufonela umngane kusuka kuhlelo lwabangane

- 1 Thinta thinta isithombe somngane ubesuthinta thinta .
- 2 Thinta thinta inamba kusuka kuhla oluvelayo.

### Ukuhlngana nabangane kuFacebook ngohlelo lwabangane

- 1 Thinta thinta isithombe somngane ubesuthinta thinta .
- 2 Thinta thinta njalo ubambe isigameko, ubesukhetha okukhethwa kukho.
- 3 Landela imiyalelo evelayo.


 Ungasingatha izigameko zeTwitter™ ngendlela efanayo.

### Ukuvula uhlelo lwabangane


- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thola bese uthinta **Uhlelo lomngane**.


### Ukukhipha ubuyekeza beFacebook skrini sekhaya sakho

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thola bese uthinta **Amaseting > Amaseting > Uhlelo lomngane**.
- 3 Thinta thinta   icele le **Ithebhu ye Facebook** ukuze i   ishintsha ukuya .
- 4 Uma ufuna ukubukisa ubuyekeza beFacebook™ kuskrini sakho sekhaya, thinta thinta  icele le **Ithebhu ye Facebook** ukuze i  ishintsha ukuya .

 Ungakhipha ubuyekeza beTwitter™ kuskrini sakho sekhaya ngendlela efanayo.

### Ukuphendula umyalezo womngane kusuka kuhlelo lwabangane

- 1 Thinta thinta isithombe somngane ubesuthinta thinta .
- 2 Thinta **Bhala imiyalezo**.
- 3 Faka umbhalo womyalezo wakho. Masewuqedile, thinta **Thumel**.

 Uma ufuna ukudlulisa noma ukususa umyalezo owamukele, thinta thinta njalo ubambe umyalezo ubusukhetha okukhethwa kukho. Ukuthumela imiyalezo okwenzile kuhlelo lwabangane buyatshengiswa ku **Ethuthukis**. loluhlelo.


# Imiyalezo esheshayo

Sebenzisa uhlelo lwemiyalezo esheshayo ukuxoxa nabanye abantu njalo uhlanganyele kumaqembu e miyalezo esheshayo ukukhuluma ngesihloko esikujabulisayo. Umhlinzeki wesevisi yemiyalezo esheshayo ungashiyana kusici abayinika abasebenzisi.

Phambi kokuba usebenziseimiyalezo esheshayo, kudinga ukuthi ubenesethingi elungile kucingo lwakho. Kwesinye isikhathi, isethingi kungenzeka ukuthi kade isisethiwe kucingo lwakho. Noma ungayamukela isethingi kuhlobo yomuyalezo osethiwe kusuka kuumhlinzeki wesevisi yemiyalezo esheshayo.

## Ukusehapha i-Google Talk™

! Uma usuyisethaphile kakade i-akhawunti ye-Google™ kufoni yakho, akunasidingo sokwenza isethapha i-Google Talk™ eceleni.

- 1 Ku **Iskrini sasekhaya** yakho, donsela  phezulu.
- 2 Thola bese uthinta **Talk**.
- 3 Landela iwizadi yokurejista ukuze wakhe i-akhawunti ye-Google™, noma usayine ungene uma usunayo kakade i-akhawunti. Manje ifoni yakho isikulungele ukusetshenziswa ne-Gmail™ kanye ne-Google Talk™.
- 4 Manje ifoni yakho isikulungele ukusetshenziswa ne-Gmail™ kanye ne-Google Talk™.

## Ukuqala i-Google Talk™

- 1 Ku **Iskrini sasekhaya** yakho, donsela  phezulu.
- 2 Thola bese uthinta **Talk**.


# Ufaka umbhalo

Ungakwazi ukufaka amabala, inombolo nehlamvu ezikhethekile usebenzisa islideout QWERTY khibhodi noma ikhiphedi ekuskrini.

## Ukusebenzisa ikhibhodi yokuslayidela ngaphandle

Shelelezisa ifoni yakho ukuvula njalo ukuqala faka umbhalo ngekhithodi yeQWERTY. Uma usebenzisa ikhibhodi yokuslayidela ngaphandle, ungashintsha ukuze usebenzise ikhiphedi eseskrinini ngasiphi sikhathi.


### Ukufaka iletha elikhulu

- Cindezela  kafishane, ubesufaka iletha. Ikhibhodi ibisela kuletha encane emva kokufaka iletha.


### Ukuvula ilokhi yofeleba

- Phambi kokufaka umbhalo, cindezela  kuze kuvele lokhu  kuskrini.


### Ukufaka uhlamvu usebenzisa i-mode toggle key

- Cindezela  ubesu cindezela isikhiye esilohlamvu lombala ofanayo. Ngomzekelisa, cindezela lesisikhiye kanye ubesu cindezela u "T" ukufaka u"1".


### Ukufaka inhlamvu nge mode toggle key khiya

- 1 Cindezela  kabili ukukhiya i- mode toggle key, ubesucindezela isikheyi ezishiyene ezilohlamvu wombala ofanayo.
- 2 Ukuvula i- mode toggle key, icindezele futhi.

### Ukufaka izimpawu



- 1 Uma ungafaka umbhalo, cindezela . Ikhiphedi elemifanekiso ivela kuskrini sefoni.
- 2 Thinta thinta umfanekiso wemfiso yakho kuskrini.

### Ukushintsha ulimi lokubhala

- 1 Uma ungafaka umbhalo, cindezela .
- 2 Khetha kokukhethwa kukho kuskrini.

## Ukusebenzisa ikhiphedi eseskrinini

Uma uqala uhlelo noma ukhetha isikhala esidinga umbhalo noma inombolo, ikhiphedi eseskrinini ivela ngedifolthi.

Ungasebenzisa indlela eziningi zokufaka umbhalo yokuthetha okuxubile  noma indlela esheshayo  yokufaka umbhalo.




### Uku-display ikhiphedi bese ufaka umbhalo

- Thinta isikhala sombhalo i-display ikhiphedi, bese ufaka umbhalo wakho.

### Ukugudluka phakathi kwezinhlamvu ezinkulu nezincane

- Phambi kokuba ufake iletha, thinta thinta  ukushintsha kuletha elikhulu , noma kwencane.

### Ukuvula ilokhi yofeleba

- Ngaphambi kokuba uthayiphe ibizo, thinta thinta  noma  kuze kuvele lokhu .

### Ukufaka izinamba usebenzisa ikhiphedi

- Uma ufaka umbhalo, thinta . Ikhiphedi elinezinamba liyavela.

### Ukufaka izimpawu

- Uma ufaka umbhalo, thinta 🌐 & 🌐. Ikiphedi elinezimpawu liyavela.

### Ukushintsha ulimi lokubhala

- 1 Uma ufaka umbhalo, thinta uphawu lolimi, ngokwesibonelo, Eng 🌐.
- 2 Khetha ongakhetha kukho.

### Ukufaka umbhalo usebenzisa i-multitap text input

- 1 Uma ufaka umbhalo, thinta uphawu lolimi, ngokwesibonelo, Eng 🌐.
- 2 Thinta **Ukuqhawabazaningi** ukushintshela ku-multitap input.
- 3 ukubhala igama, thinta ikhi lohlamvu kaningi kuze kuvele uhlamvu olufunayo.

### Ufaka umbhalo usebenzisa umbhalo we-quick text input


- 1 Uma ufaka umbhalo, thinta uphawu lolimi, ngokwesibonelo, Eng 🌐.
- 2 Thinta **Umbhalo osheshayo** ushintshele ku-quick text input.
- 3 Ukubhala igama, thinta uhlamvu ngalunye kanye, nanoma uhlamvu olufunayo kungelona elokuqala kwi-khi.
- 4 Thinta igama elivelayo noma thinta ⏴ ukukhetha igama ohlwini.
- 5 Uma igama olifunayo lingekho ohlwini, thinta **Pela**, yenza iznguquko, bese uyathinta **Gcina**.





# Oxhu. nabo


Sebenzisa uhlelo lwe-**Oxhu. nabo** ukugcina imininingwane yabantu obaziyo. Faka izinombolo zabo zefoni, amakheli e-imeyili, izinsuku zokuzalwa kanye neminye imininingwane. Ungagcina ithrekhi yakho konke ukuxhumana nomxhumani othile.

## Ukufonela oxhumana naye


- 1 Ku **Iskrini sasekhaya**, thinta thinta .
- 2 Thinta oxhumana naye.
- 3 Thinta inamba yefoni oyifunayo koxhumana naye.

## Ukwengeza oxhumana naye

- 1 Kusuka ku **Iskrini sasekhaya**, donsa  kusiyaphezulu ubesu thinta thinta .
- 2 Thinta **Engeza oxhumana**.
- 3 Thinta thinta **Igama**, ubesufaka igama noxhumana naye njalo uthinta thinte **Enza**.
- 4 Thinta thinta **Inamba yefoni**, ubesufaka inombolo njalo uthinta thinte **Enza**.
- 5 Yengeza noma yikuphi ukwazizwa okwengeziwe ofuna ukuyengeza kokuxhumana, ubesupheqa njalo uthinta thinte **Gcina**. Ukwengeza amabhokisi okwaziswa s, thinta **Yengeza okunye**.

 Ungakwazi ukwengeza oxhumana nabo kwilogi yezingcingo zakho.

## Ukwenza ibhekaphu yoxhumana nabo kwi-memori khadi

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thinta **Amaseting > Oxhu. nabo > Lokulo ekha lemem**.

## Ukubuyisela oxhumana nabo kusukela ku-memori khadi

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thinta **Amaseting > Oxhu. nabo > Buyisel kukwikhad lememo**.

# Ukushaya ucingo


## Ukwenza ucingo oluphuthumayo

- 1 Ku **Iskrini sasekhaya**, thinta thinta 📱.
  - 2 Faka inombolo yezimo eziphuthumayo bese uyathinta 📞. Ukususa inombolo, thinta 🗑️.
- 💡 Ugenza izincingo eziphuthumayo uma ingekho ikhadi ye-SIM efakiwe.

## Ukufona

- 1 Ku **Iskrini sasekhaya**, thinta thinta 📱.
- 2 Uma ilogi yezingcingo ivela thinta 📱 ukufaka iphedi yokudayela yokubheka.
- 3 Faka inombolo ofuna ukuyifonela bese uyathinta 📞. Ukususa inombolo, thinta 🗑️.

## Ukuphendula ifoni



- Donsa 📞 ensandleni sokunxele ize ithinte 📞.

## Ukwenqaba ifoni

- Donsa 📞 kwesokudla uze uthinte 📞.

## Ukuqeda ucingo


- Qhwabaza 📞.

# Umculo

Thola okwengeziwe ngesidlali sakho somculo. Ungalalela umculo, amabhuku alalelwayo nama-podcasts. Singatha uhlu lwakho lokudlala, bese uthumela umculo owuthandayo kubangane.

- Faka uhlelo lwe-Media Go™ lwekhompuyutha yakho bese udlulise lokho okuqukethwe ukusuka nokuya kumemori khadi nasocingweni lwakho. i-Media Go™ ingalandwa ku [www.sonyericsson.com/support](http://www.sonyericsson.com/support).

## Isidlali somculo



- 1 Bheka umugqa wokudlalayo manje
- 2 Ubuciko bekhava (uma bukhona)
- 3 Inkonobho Dlala/Ima Kancane
- 4 Yiya ku-threkhi elandelayo kumugqa wamanje wokudlalayo, noma dlulisela phambili
- 5 Isikhathi esidlule somucu owudlalayo njengamanje
- 6 Isikhombi senqubekelaphambili: dlulisela phambili noma wayindela emuva ngokudonsa nokuthinta
- 7 Yiya ku-threkhi edlulile kumugqa wamanje wokudlalwayo, noma wayindela emuva
- 8 Pheqa umculo ku-memori khadi yakho

### Ukushintsha amathrekhi

- Kusidlali somculo, qhwabaza noma .

### Ukumisa isikhashana ithrekhi

- Kusidlali somculo, thinta .

### Ukudlulisa ngokushesha nokubuyisela emuva umculo

- Kumdlalo womculo, thinta uqhubeke nokubeka noma .

- Ungadonsa uphawu lwesiboniso sokuqhubekayo ngakwesokudla noma esobunxele.

### Ukulungisa ivolumu ye-audio

- Cindezela ikhi levolumu.

# Uku-xhuma ifoni yakho kukhompuyutha

Xhuma ifoni yakho kukhompuyutha uqale ukudlulisa izithombe, umculo namanye amafayela.

- ! Kungenzeka ungakwazi ukudlulisa okunye ongenalo ilungelo lokushicilela phakathi nefoni yakho nekhompuyutha.

## Ukudlulisa nokuphatha okuqukethwe usebenzisa intambo ye-USB

Indlela ejwayelekile kakhulu yokudlulisa amafayela phakathi kwefoni yakho ne-khompuyutha kuwukusebenzisa intambo ye-USB. Uma ifoni ne-khompuyutha sezixhumene, ungasondisa nokwethula okuqukethwe kusukela kwenye usebenzisa ifayela lemfuna ku-khompuyutha yakho.

- ! Cinisekisa ukuthi ubeka amafayela kuzinhlobo zamafolda ahambelanayo. Ngokwesibonelo, faka amafayela womculo wakho ku-folda *Umculo*. Amafayela wohlelo lwe-Java wona ehlukile. Kufanele uwabeke kufolda *Okunye*.

### Ukudonsa ubeke okuqukethwe phakathi kwefoni ne-Khompuyutha

- 1 Xhuma intambo ye-USB efonini nase-Khompuyutheni.
  - 2 **Foni:** Khetha **Londoloz okuningi**.
  - 3 **Khompuyutha:** linda kuvele imemori yefoni nememori khadi njengamadiski angaphandle kumafayela emfuna.
  - 4 **Khompuyutha:** Kwi-Khompuyutha yedeskithophu, klika kabili kuphawu *Iwelkhompuyutha Yami*.
  - 5 **Khompuyutha:** Ukubheka imiqulu yememori yefoni kanye neyememori khadi, klika kabili ophawini olumelela ifoni yakho.
  - 6 **Khompuyutha:** Kopisha bese unamathisela ifayela lakhole, noma donsa uyibeke, efoldeni eqondene kwi-Khompuyutha yakho, kwimemori yefoni yakho, kwimemori khadi yakho.
- ! Awukwazi ukusebenzisa ifoni yakho uma uthumela amafayela.


### Ukunqamula ukuxhuma ikhebula le-USB ngokuphephile

- ! ungakunqamuli ukuxhuma kwentambo yakho ye-USB uma usathumela okuqukethwe ngoba lokhu kungonakalisa okuqukethwe.
- 1 **Khompuyutha:** Sebenzisa isisebenzi sokukhipha isisetshenziswa esilukhuni ukukhetha idivayisi ofuna ukungayixhumi, bese uyaklikha *Misa*.
  - 2 Khipha ikhebula le-USB.
- ! Imithetho ye-Khompuyutha ingase yehluke kuye ngesistimu yokusebenza kwe-Khompuyutha. Bheka umqulu wesistimu wokusebenza kwe-Khompuyutha yakho uma ufuna ulwazi olwengeziwe.

# Ikhamera

Thatha izithombe, rekhoda amavidyo, buka ama-albhamu bese wabelane ngamakliphu nezithombe ozithandayo nabangane bakho - konke ngohlelo lwakho lwekhamera.

## Izilawuli zesitholi sokubonwayo ne-khamera



- 1 Sondeza/uhlelise kutholakala kuphela ku-modi ye-vidiyo
- 2 Ikhamera khiye. Cindezela ukuthatha isithombe noma ukurekhoda ividiyo kliphu.
- 3 Thatha izithombe
- 4 Phuma ku khamera
- 5 Shintsha phakathi kwe-khamera emile noma ye-vidiyo
- 6 Rekhoda amakliphu wevidyo
- 7 Shintsha phakathi kwe-khamera emile noma ye-vidiyo
- 8 Bheka izithombe namavidyo kliphu
- 9 Khetha ubude be-vidyo
- 10 Bheka izithombe namavidyo kliphu

# Ubuchwepheshe be-TrackID™

Sebenzisa isevisi yokuhlonza umculo ye-TrackID™ ukubona ithrekhi yomculo loyo uzwa udlala endaweni yakho. Rekhoda nje isampuli emfushani yeculo uzothola ukwaziswa kommculi, isihloko ne-albhamu ngemizuzwana. Futhi ungakwazi ukuthenga amathrekhi ahlonzwa i-TrackID™. Ukuthola imiphumela emihle kakhulu, sebenzisa ubuchwepheshe be-TrackID™ endaweni ethulile. Uma une inkinga ngokusebenzisa loluhlelo, beka *Angikwazi ukusebenzi amasevisi asekeleke ku-Inthanethi* kukhasi 31.

- ! Uhlelo lwe-TrackID™ nesivisi ye-TrackID™ azisekelwa emazweni/izifunda zonke, noma yiyo wonke amanethiwekhi ne/noma abahlinzeki besevisi ezindaweni zonke.

## Ukucinga ulwazi lwethrekhi

- 1 Vula **TrackID™** uhlelo bese uthinta **Qopha**.
- 2 Bamba ifoni yakho ukuyela emthonjeni womculo. Imiphumela ibhoniswe eskrinini semiphumela.
- 3 Phegulula kwesokuxele noma sokudla ukubheka imiphumela yokucinga okwedlule.

# PlayNow™

Sebenzisa uhlelo lwe-PlayNow™ ukuze uzule efonini yakho, uthenge futhi ulande umculo wamuva, imidlalo, imisindo yefoni, izinhlelo, ama-themes namaphepha odonga.




! PlayNow™ Ayitholakali kuwo wonke amazwe.

## Ukuqalisa i-PlayNow™


- 1 Ukusuka ku-u **Iskrini sasekhaya**, hudulela  phezul.
- 2 Thola bese uqhwebaza .

# I-multimedia nokuthumela imiyalezo

## Ukwakha nokuthumela umbiko

- 1 Ku **Iskrini sasekhaya**, thinta thinta .
- 2 Thinta **Umyalezo omusha** > **Bhala imiyalezo**. Faka umbiko wakho bese uthinta .
- 3 Ukwengeza umemukeli, khetha oxhumana naye ohlwini oluvelayo. Ungathinta ibhokisi lombhalo, ufake inamba ngokwakho bese uyathinta **Enza**.
- 4 Uma ufuna ukwengeza isithombe noma i-video, thinta  bese ukhetha okukhethwa kukho.
- 5 Masewuqedile, thinta **Thumel**.

## Ukufunda umyalezo owamukelwe



- 1 Ku **Iskrini sasekhaya**, thinta thinta .
- 2 Thinta ithredi yomyalezo.
- 3 Ukulanda umyalezo ongakalandiwe, thinta umyalezo.
- 4 Uma umyalezo owamukelwe usingathe umculo noma ividiyo, thinta leyonto bese uthinta **Bheka ividiyo** noma **Dlala i-odiyo**.





# I-imeyli

Sebenzisa ifoni yakho ukuthumela nokwamukela ama-imeyli nge akhawunti ye-imeyli yakho ejwayelekile. Ngaphambi kokuba uqale udinga ama sethingi enthanethi alungile efonini yakho. Bheka *Amasethingi e-inthanethi nawokuthumela imilayezo* ekhasini 10.

## Ukusetapha i-imeyli akhawunti efonini yakho

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
  - 2 Thola bese uthinta **I-imeyli**.
  - 3 Khetha i-imeyli akhawunti. Uma i-akhawunti ofuna ukuyisebenzisa ingekho kuhlu, thinta **Okunye**.
  - 4 Faka ikheli le-imeyli yakho nephasiwedi, bese uthinta **Qhubeka**.
  - 5 Uma ifoni yakho ayikwazi ukulanda amasethingi we-imeyli akhawunti yakho ngokuzenzakalelayo, afake ngesandla.
-  Uma udinga ukufaka amasethingi ngesandla, xhumana nomhlinzeki wakho wesivisi ye-imeyli ukuthola amasethingi we-imeyli akhawunti alungile. Ngokwesibonelo, udinga ukwazi ukuthi uhlobo lwe-akhawunti luyi-POP3 noma IMAP.



## Uwakha nokuthumela umbiko we-imeyli

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thola bese uthinta **I-imeyli**.
- 3 Thinta **Bhala omusha**.
- 4 Thinta **Faka umemukeli** bese ufaka ikheli lomemukeli, bese uyathinta **Enza**. Ungengeza abemukeli abengeziwe ngendlela efanayo, noma ususe umemukeli ngokuthinta .
- 5 Thinta **Indaba** bese ufaka isihloko se-imeyli.
- 6 Thinta **Bhala i-imeyli**, bese ufaka umbiko wombhalo wakho.
- 7 Ukufaka ifayela, thinta **Namathelisa**, khetha uhlobo lwefayela oyifunayo, bese ukhetha ifayela ofuna ukulithumela.
- 8 Thinta **Thumel**.

# Ubuchwepheshe obungenawaya be-Bluetooth™

Vula isici se-Bluetooth™ efonini yakho bese wenze uxhumano olungenantambo kumanye amadivaysi ahambelana ne-Bluetooth™ njenge khyomputha, izici zehendsifri, namafoni. Uxhumano lwe-Bluetooth™ lusebenza kangcono phakathi nesigaba samamitha angu-10 (ubude obungu 33), ngaphandle kwezinto eziqinile maphakathi. Kwezinye izimo kumelwe ubhanqanise ngesandla ifoni yakho namanye amadivaysi e-Bluetooth™. Khumbula uku-setha ifoni yakho ukuze ibonwe amanye amaBluetooth™ divaysi uma ufuna.


## Ukuvula umsebenzi we-Bluetooth™ bese wenza ifoni yakho ibonakale

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thola bese uthinta **Amaseting** > **Ukuxhumeka** > **I-Bluetooth**.
- 3 Thinta **I-Bluetooth** bese uthinta inkinobho ye vula/vala ukuvula i-Bluetooth.  ivela ku-ibha lezinga.
- 4 Thinta **Okubonakalayo** bese uthinta inkinobho ye vula/vala ukwenza ifoni yakho ibonakale.

# i-Wi-Fi®

Uma usebenzisa i-Wi-Fi® unalo igunya lokuthola I-inthanethi engenawaya kwifoni. Uma ufuna igunya lokuthola I-inthanethi ngokusebenzisa uxhumano lwe-Wi-Fi® udinga ukucinga uphinde uxhume kwi-nethiwekhi ye-Wi-Fi® etholakalayo. Amandla esignali enethiwekhi ye-Wi-Fi® ayahluka kuya kendawo okuyo. Uma useduze nokuthola igunya lenethiwekhi yeWi-Fi® ayanda amandla esignali.





## Ukuvula i- Wi-Fi®

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
  - 2 Thola bese uthinta **Amaseting > Ukuxhumeka > I-Wi-Fi**.
  - 3 Thinta thinta **I-Wi-Fi** noma thinta thinta inkinombo yokuvula /vala umsebenzi weWi-Fi.
- ! Kungathatha imizuzu emibalwa ngaphambi kokuthi iWi-Fi® isebenze.




## Ukusebenzisa inethiwekhi yezaziso seWi-Fi®

- 1 Qiniseka ukucisha iWi-Fi®.
- 2 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 3 Thola bese uthinta **Amaseting > Ukuxhumeka > I-Wi-Fi**.
- 4 Thinta thinta **Isaziso senethiwekhi** noma thinta thinta ukuvula kumbe ukuvula ukuyenza kusebenze izaziso zeWi-Fi®. Ungathola izaziso uma inethiwekhi entsha yeWi-Fi® itholakala eduze.

## Uku xhuma kwinethiwekhi yeWi-Fi®

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
  - 2 Thola bese uthinta **Amaseting > Ukuxhumeka > I-Wi-Fi**.
  - 3 Inethiwekhi yeWi-Fi® iyatholakala ngaphansi **Amanethiwekhi e Wi-Fi**. Amanethiwekhi atholakalayo kungaba avulekile noma alondekile. Amanethiwekhi avuliwe akhombiswe nge  amanethiwekhi avaliwe akhombiswe nge  eceleni kwegama lenethiwekhi yeWi-Fi®.
  - 4 Thinta thinta inethiwekhi yeWi-Fi® ukuze uxhumane nayo. Uma ufuna ukuxhuma kwinethiwekhi yeWi-Fi®, ucelwa ukuthi ufake iphasiwedi.  itshengiswa kwibha yezinga uma usuxhumene.
- 💡 Kwezinye izindawo amanethiwekhi eWi-Fi® avuliwe adinga uvule ikhasi le-web ngaphambi kokuthola igunya lokungena kwinethiwekhi. Xhumana nomphathi wenethiwekhi yeWi-Fi® ukuze uthole olunye ulwazi.

## Ukulayisha isithombe


- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thola bese uthinta **I-albhamu** .
- 3 Qhwabaza i-thumbnail yesithombe.
- 4 Thinta iskrini ukuveza izilawuli.
- 5 Thinta .
- 6 Khetha **Ku Picasa**.

# Isipheqi se-web

## Ukupheqa iwebhu

Buka futhi uphenye amakhasi ewebhu, bhukumakha intandokazi yakho, yakha amashothikhathi, bese uphequlula kunamawindi amaningi avuliwe ngesikhathi esisodwa.

### Ukuya ekhasi le-web


- 1 Thinta .
- 2 Thinta isikhala sombhalo ukuqalisa ikhiphedi.
- 3 Faka ikheli le-web.
- 4 Thinta **Ya**.

# Uphawu olwengeziwe


## Ama-alamu

Hlela i-alamu yakho uvuke ngethoni yakho ye-alamu oyithandayo noma isiteshi somsakazo. Ama-alamu aqalisiwe ayezwakala noma ifoni yakhe icishiwe.

### Ukusetha i-alamu entsha

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thola bese uthinta **I-alamu**.
- 3 Thinta **Ngeza okusha**.
- 4 Setha isikhathi se-alamu bese ufaka imininingwane efanele ezikhaleni ku **Umbhalo we-alamu**, **Ukuphindeka** ne **Uphawu lwe-alamu**, bese uthinta **Enza**.

### Ukususa i-alamu

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thola bese uthinta **I-alamu**.
- 3 Pheqa i-alamu oyisethile ofuna ukuyisusa bese uyathinta.
- 4 Pheqa phansi bese uyathinta **Susa**.


### Ukuthulisa i-alamu

- 1 Uma i-alamu ikhala, donsela **Slayida ukuze ucime** ukuyela kusokudla ukucisha i-alamu.
- 2 Ukuphinda i-alamu, khetha **Ukubuthisa**.


## Imeyli yezwi

Uma ukubhalisela ubulungu kwakho kuhlenganisa isevisi yemeyili yezwi, abashayi cingo bangakushiyela umbiko wezwi uma ungakwazi ukuphendula ifoni. Inombolo yesevisi yakho yemeyili yezwi kangingi igcinwa ku-SIM khadi yakho. Uma kungenjalo, ungathola lenombolo kumhlinzeki wakho wesevisi bese uyifaka ngesandla.

### ukufaka inamba yesevisi yemeyili yezwi

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Khetha **Amaseting > Izingci > Imey. yezwi**.
- 3 Faka inamba yemeyili yezwi bese uyathinta **Enza**.

### Ukufonela isevisi yemeyili yezwi


- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thinta **Imey. yezwi**.

# Ukukhiya nokuvikela ifoni yakho

## Inamba ye-IMEI

Yonke ifoni inesihlonzi se-IMEI (International Mobile Equipment Identity) namba. kufanele ugcine ikopi lalenamba. Uma ifoni yakho yebiwe inethiwekhi yakho ingasebenzisa i-IMEI namba yakho ukumisa ifoni yakho ukungena kwinethiwekhi ezweni lakini.

### Ukubheka inombolo ye-IMEI efonini yakho

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thola bese uthinta **Amaseting** > **Okujwayelekile** > **Ngefoni**.

### Ukushintsha i-Pin ye-SIM khadi

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thola bese uyathinta **Amaseting** > **Okujwayelekile** > **Ukuphepha** > **Shintsha uphini**, bese ulandela izeluleko.

# Ukucubungula inkinga

## Ucingo lwami alusebenzi njengokulindelekile

Uma unezinkinga ngocingo lwakho, hlola lawa macebiso ngaphambi kokuzama okunye:

- Luqale phansi ucingo lwakho.
- Khipha ubuye ufake ibhethri ne-SIM khadi yakho. Bese u-qala kabusha ifoni yakho.
- Buyekeza ifoni yakho. Noma une-software yamuva, ukubukeza ifoni yakho kungayenza isimame kangcono i-software futhi ixazulule nezinye izinkinga. Ngokusebenzisa ukubuyekeza kwakamuva efonini yakho, unagaqinisekisa ukusebenza okuphezulu futhi uthole nokwengeziwe kwakamuva.
- Setha kabusha ifoni yakho.




Yiba nesineke ngenkathi iqala kabusha ifoni yakho. Ukuqala kabusha ifoni yakho ngenkathi isetha kabusha kungayilimaza unomphelelo ifoni yakho.

## Ukusetha kabusha ifoni yakho

Uma usetha kabusha ifoni yakho, ususa yonke idatha, kuhlangukise namahlelo alandiwe. Usetha ifoni esimweni ebiyingaso uma uqala ukuyivula. Ngaphambi kokuba uyisethe kabusha, qiniseka ukwenza ibhekaphu kwanoma iyiphi idatha ebalulekile egcinwe efonini yakho.

### Ukusetha kabusha ifoni

- 1 Ku **Iskrini sasekhaya**, donsela  phezulu.
- 2 Thola bese uthinta **Amaseting** > **Okujwayelekile** > **Isihleli esikhulu** > **Hlela konke**.
- 3 Thinta **Seth kabu**.

## Asikho uphawu sokushaja ibhethri esivelayo lapho ngiqala ukushaja ucingo

Kungathatha imizuzu embalwa ngaphambi kokuba isithonjana sivele eskhrinini.

## Angikwazi ukusebenzi amasevisi asekeleke ku-Inthanethi

Qiniseka ukuthi ukubhalisela ubulungu kuhlangukisa ukulanda idatha nokuthi amaseethingi e-inthanethi efonini yakho alungile. Xhumana ne-opharetha wenethiwekhi yakho ngolwazi olubanzi mayelana namaseethingi okubhalisela ubulungu.

## Ayikho inethiwekhi

- Ucingo lwakho i-Flight mode. Qinisekisa ukuthi i-Flight mode sicishiwe.
- Alukho uphawu lwethiwekhi olutholwa ngocingo lwakho, noma uphawu olutholayo llibuthakathaka. Xhumana u-opharetha wenethiwekhi ukuqinisekisa ukuthi leyo ndawo okuyo ithola inethiwekhi.
- i-SIM khadi yakho ayisebenzi kahle. Faka i-SIM khadi yakho kolunye ucingo. Uma lokhu kusebenza, kungenzeka ukuthi wucingo lwakho olunenkinga. Uma kunjalo, xhumana nesikhungo samasevisi e-Sony Ericsson esiseduzane.

## Izingcingo oluphuthumayo kuphela

Ungaphakathi kwenethiwekhi, kodwa awuvunyelwe ukuyisebenzisa. Noma kunjalo, esimeni esiphuthumayo, abanye u-opharetha wenethiwekhi bayakuvumela ukuba ushayele inamba ephuthumayo yomhlaba 112.

## **Ilokhi ye-SIM icushiwe**

Ufake i-PIN yakho kathathu ngokungalingile. Ukuvula ucingo, udinga i-PUK (Ukhiye wakho wokuvula) onikwe yi opharetha yakho.

## **IPuk ivaliwe. Xhumana no- opharetha.**

Ufake i-PUK yakho ngokungalingile izikhathi kashumi zilandelana. Sicela uxhumane nomhlinzeki wesevisi yakho.



# Ulwazi lwezomthetho

## I-Sony Ericsson txt pro™ CK15i/CK15a

Le Ncwadi yeziqondiso yomsebenzisi ishicilelwe ngabakwa-Sony Ericsson Mobile Communications AB noma inkampani yangakini esebenzisana nabo, ngaphandle kwewaranti ethile. Ubungcono nezinguquko kule ncwadi yokusebenzisa ucingo okwenziwe amaphutha okuthayipha, ukungalingi kolwazi lwamanje, noma ubungcono ezinhlweni kanye/noma amathuluzi, kungenziwa ngu-Sony Ericsson Mobile Communications AB noma ingasiphi isikhathi ngaphandle kwesaziso. Izinguquko ezinjalo, ngakho, ziyongeniswa kwizimumusho ezintsha zale Gaydi yokusebenzisa ifoni.

Wonke amalungelo agodliwe.

©Sony Ericsson Mobile Communications AB, 2010

Inamba yokushicilela: 1244-7441.1

**Qaphela: Amanye amasevisi nezici okuchazwe kule Gaydi yomsebenzisi akusekelwe yiwo wonke amanethiwekhi kanye/noma abahlizeki besevisi kuzo zonke izindawo. Ngaphandle kwemingcele, lokhu kuhlangukisa i-GSM inamba ephuthumayo yomhlaba 112. Sicela uxhumane no-opharetha wenethiwekhi noma umhlizeki wesevisi yakho ukuze ubone ubukhona besevisi ethile noma uphawu nokuthi kudingeka igunya elengeziwe noma ukusetshenziswa kwemali kuyadingeka.**

Ifoni yekho ephathekayo inekhono lokulanda, ukulondoloza nokudlulisa okuqukethwe okwengeziwe, isb. amaringithoni. Ukusetshenziswa kwalokhu okuqukethwe kungakhawulwa noma kunqandwe ngamalungelo amaqembu esithathu, kubandakanya kodwa kungacini ngokukhawulwa ngaphansi kwemithethi yamalungelo okushicilela. Wena, hhayi u-Sony Ericsson, unamandla aphelele kokuqukethwe okwengeziwe okulanda noma okudlulisa kuvela efonini yakho. Ngaphambi kokusebenzisa okuqukethwe okwengeziwe, sicela uqinisekise ukuthi ukusebenzisa okuhlosile kulayisensiwe noma kugunyaziwe. U-Sony Ericsson akagqiniseki ngokungabi naphutha, ubuqotho noma ikhwalithi yokuqukethwe okwengeziwe noma okunye okuqukethwe kwabantu besithathu. U-Sony Ericsson ngeke abekwe icala ngisho ngaphansi kwaziphi izimo ngokusebenzisa kwakho okungalingile kokuqukethwe okwengeziwe noma okunye okuqukethwe kwabantu besithathu.

Izithelo zonke njalo amabizo enkampani abizwe la uphawu lokuhweba noma uphawu lokuhweba olubhalisiwe lwabanikazi.

Lencwadi yeziqondiso yomsebenzisi ingakupha izihlonzi noma izinhlelo eziphiwe amaqembu esithathu. Ukusetshenziswa kohlelo noma izinkonzo ezinjalo kusengafuna ubhalise ngokwahlukile nalowo muntu wesithathu onikeza lezozinkonzo futhi usengathola eminye imithetho eyengeziwe ukuze usebenzise lezozinkonzo. Ezinhlweni okungenwe kuzo noma ngewebusaythi yeqembu lesithathu, sicela uhlale igunya lewebusaythi ne nomgomo wokungokomuntu kusengaphambili. I-Sony Ericsson ayiqiniseki ubukhona noma ukusebenza kwewebusaythi leqembu lesithathu noma izinhlizeki eziphiwe.

Lo mkhqiizo uvikelwe ngamalungelo athile olwazi akwa-Microsoft. Ukusebenzisa nokusabalalisa kwalo buchwepheshe ngaphandle kwalo mkhqiizo akuvunyelwe ngaphandle kwelaysensi yakwa-Microsoft.

Amanye amagama omkhqiizo nezinkampani abalwe lapha kungaba izimpawu zokuthengisa zabanikazi abafanele. Noma imaphi amalungelo anganikiwe ngokubhalwa lapha agodliwe. Zonke ezinye izimpawu zokuhweba zingezabaninizo.

Yonke imiboniso ingeyekubonisa kuphela futhi kungenzeka ingakhombisi ngokungenaphutha ifoni uqobo lwayo.

Microsoft, Windows and Vista yizimpawu zokuhweba ezibhalisiwe noma yizimpawu zokuhweba zakwaMicrosoft Corporation e-United States namanye amazwe.

"Imigoqo yokuthelisa: Lo mkhqiizo, kubandakanya noma iyiphi isofthiwe noma idatha yobuchwepheshe ekulo mkhqiizo noma ekumkhqiizo ohambisana nawo, ungaba ngaphansi kweziqondiso zokungenisa nokuthelisa ze-European Union, i-United States namanye amazwe. Umsebenzisi nanoma yimuphi umnikazi womkhqiizo uyavuma ukhlonipha yonke le mithetho nokuthi kuyisibopho sakhe ukuthola noma yimaphi amalaysensi adingekayo okuthelisa, ukuthelisa kabusha, noma ukungenisa lo mkhqiizo. Ngaphandle kokukhawula okungaphambili, futhi njengesibonelo, umsebenzisi nanoma yimuphi owumnikazi womkhqiizo: (1) akufanele ahambise ngokwazi izinhlelo zalapho kuyiwa khona eMqulwini kuSahluko II seMigomo yeSigungu se-European (EC) 428/2009; (2), kufanele kuvumelane nemigomo yolawulo yalapho kuyiwa khona wohulumeni wasw-U.S ("EAR"), 15 C.F.R. §§ 730-774, <http://www.bis.doc.gov/> ) ilawulwa umyango we-Commerce, Isikhungo sezokuphepha; futhi (3) kufanele avumelane nemigoqo yezomnotho (30 C.F.R. §§ 500 et. seq., <http://www.treas.gov/offices/enforcement/ofac/>) elawulwa umnyango we-Treasury, iHovisi lezimpahla zangaphandle. Umsebenzisi womkhqiizo akufanele ahambise umkhqiizo noma awuthumele, izesekeli noma isofthiwe ehlukile kunoma iliphi izwe, isifunda noma umuntu akuvunyelwe yilemigoqo."

# Inkomba

<b>A</b>		
amacingo .....	18	umyalezo wesithombe .....
amasevisi okuhlanganyela izithombe nabanye		umyalezo wombhalo .....
ukulayisha ku- .....	27	Uxhumano lwe-USB .....
		24
		24
		20
<b>I</b>		
i-audio		
ukulungisa ivolumu .....	19	
I-Inthanethi		
Isipheqi se-web .....	28	
I-MMS .....	24	
I-PIN .....	30	
i-PUK .....	30	
I-SMS .....	24	
i-Wi-Fi® .....	27	
ibhethri .....	7	
lifonibhuku .....	17	
imeyli yezwi .....	29	
Imibiko		
imidya enhlobonhlobo .....	24	
isithombe .....	24	
umbhalo .....	24	
imidlalo .....	23	
imisa isikhashana ithrekhi .....	19	
indlela yokukhiya iskrini .....	30	
isevisi yokuphendula .....	29	
Isipheqi se-web .....	28	
isiqondiso sokusethapha .....	6	
isithombe		
ukulayisha kusiya ku alhamu yelwebhu .....	27	
Iskrini sasekhaya .....	8	
Iyacinga		
ukwaziswa kwe-threkhi .....	22	
umculo usebenzisa ubuqwepheshe be-		
TrackID™ .....	22	
izinhlelo .....	23	
<b>O</b>		
oxhumana nabo .....	17	
<b>P</b>		
PlayNow™ .....	23	
<b>S</b>		
Setha kabusha .....	31	
SIM .....	30	
<b>U</b>		
Ubuchwepheshe be-TrackID™ .....	22	
Icinga ukwaziswa kwe-threkhi .....	22	
Ubuchwepheshe obungenawaya be-Bluetooth™ .	26	
ukucubungula inkinga .....	31	
<i>Ukufona Bheka izingcingo</i>		
ukukhiya iskrini .....	30	
ukulungisa ivolumu .....	19	
<i>ukupheqa - beka isipheqi se-web</i>		
ukushaja .....	7	
ukushintsha amathrekhi .....	19	
ukuzulazula .....	10	
Ulwazi lomuntu uqobo lwakhe .....	17	
umculo .....	19	
ama-bhuku alalwelayo .....	19	
i-podcast .....	19	
imisa isikhashana ithrekhi .....	19	
isibukwa sesidlali .....	19	
iyalanda .....	23	
ukulungisa ivolumu .....	19	
ukushintsha amathrekhi .....	19	
umyalezo onhlobonhlobo .....	24	